

MXO 5C Series Oscilloscope User Manual

dataTec

Mess- und Prüftechnik. Die Experten.

**Ihr Ansprechpartner /
Your Partner:**

dataTec AG

E-Mail: info@datatec.eu

datatec.eu



1803050502
Version 10

ROHDE & SCHWARZ
Make ideas real



This documentation describes the following MXO 5C series models with firmware version 2.9.x.x.

- MXO 54C, 4 channels (1802.3000k04)
- MXO 58C, 8 channels (1802.2000k08)



Mess- und Prüftechnik. Die Experten.

**Ihr Ansprechpartner /
Your Partner:**

dataTec AG

E-Mail: info@datatec.eu

datatec.eu

© 2026 Rohde & Schwarz

Muehldorfstr. 15, 81671 Muenchen, Germany

Phone: +49 89 41 29 - 0

Email: info@rohde-schwarz.com

Internet: www.rohde-schwarz.com

Subject to change – data without tolerance limits is not binding.

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG.

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

MATLAB® is a registered trademark of The MathWorks, Inc.

TEKTRONIX, TEK, and TEKPROBE are registered trademarks of Tektronix, Inc.

All other trademarks are the properties of their respective owners.

1803.0505.02 | Version 10 | MXO 5C Series

Throughout this manual, products from Rohde & Schwarz are indicated without the ® symbol.

Contents

1	Safety and regulatory information.....	23
1.1	Safety instructions.....	23
1.2	Labels on the product.....	29
1.3	Warning messages in the documentation.....	29
1.4	CE declaration of conformity.....	30
1.5	Where to find key documents on Rohde & Schwarz.....	30
1.6	Korea certification class A.....	30
2	Preface.....	31
2.1	Key features.....	31
2.2	Documentation overview.....	31
2.2.1	Manuals and instrument help.....	31
2.2.2	Specifications and product brochure.....	32
2.2.3	Calibration certificate.....	32
2.2.4	Release notes, open source acknowledgment.....	33
2.2.5	Application notes, application cards, videos.....	33
2.3	Options described in this document.....	33
3	Getting Started.....	35
3.1	Preparing for use.....	35
3.1.1	Lifting and carrying.....	35
3.1.2	Unpacking and checking.....	35
3.1.3	Choosing the operating site.....	35
3.1.4	Setting up the product.....	36
3.1.5	Considerations for test setup.....	37
3.1.6	Connecting to power.....	38
3.1.7	Connecting to LAN.....	39
3.1.8	Connecting a monitor, mouse and keyboard.....	39
3.1.9	Switching on or off.....	40
3.2	Instrument tour.....	41
3.2.1	Front view.....	41
3.2.2	Rear view.....	43

4	Operating the instrument.....	46
4.1	Accessing the GUI.....	46
4.2	Information on the display.....	47
4.3	Control elements on the GUI.....	49
4.4	Keys and controls of the emulated front panel.....	52
4.4.1	Trigger controls.....	53
4.4.2	Horizontal controls.....	54
4.4.3	Vertical controls.....	55
4.4.4	Analysis keys.....	58
4.5	Applications.....	61
4.6	Toolbar.....	61
4.6.1	Using the toolbar.....	62
4.6.2	Configuring the toolbar.....	62
4.6.3	Toolbar functions.....	63
4.7	Signal bar.....	66
4.8	Working with waveforms.....	67
4.9	Rohde & Schwarz SmartGrid.....	69
4.10	Using the selection menu.....	71
4.11	Using dialogs.....	73
4.12	Entering data.....	73
4.13	Displaying results.....	76
4.14	Adding annotations.....	77
4.15	Information and notifications.....	78
4.16	Getting user assistance.....	80
4.16.1	Displaying help.....	80
4.16.2	Using help.....	80
5	Instrument setup.....	82
5.1	System settings.....	83
5.1.1	About settings.....	83
5.1.2	Network settings.....	84
5.1.3	Network drive mapping.....	87
5.1.4	Remote settings.....	89
5.1.5	Localization settings.....	90

5.1.6	Date and time settings.....	90
5.2	Option settings.....	92
5.2.1	Software options settings.....	92
5.3	Appearance settings.....	95
5.3.1	Colors.....	95
5.3.2	Grid.....	98
5.3.3	Dialogs.....	100
5.3.4	Peak list.....	101
5.3.5	Miscellaneous.....	101
5.4	Display settings.....	102
5.4.1	Persistence settings.....	102
5.4.2	Signal settings.....	103
5.4.3	Backlight settings.....	104
5.5	Front panel settings.....	104
5.5.1	Hardkeys: function assignment.....	104
5.5.2	Knobs.....	105
5.5.3	LED.....	105
5.6	Preset setup.....	106
5.6.1	Preset settings.....	106
5.6.2	Factory preset.....	108
5.6.3	Restoring settings.....	108
5.7	Maintenance settings.....	109
5.7.1	Firmware update.....	109
5.7.2	Alignment.....	109
5.7.3	Power management.....	112
5.7.4	Self-test.....	112
5.7.5	Service.....	113
5.8	Save / recall settings.....	114
5.8.1	Autonaming.....	114
5.8.2	CSV export.....	116
6	Acquisition and waveform setup.....	117
6.1	Horizontal setup.....	117
6.1.1	About the horizontal system.....	117

6.1.2	Horizontal Setup settings.....	118
6.1.3	Zoom settings.....	119
6.1.4	Roll mode.....	119
6.1.5	Reference clock.....	121
6.2	Acquisition.....	122
6.2.1	About the acquisition system.....	122
6.2.2	Acquisition setup.....	123
6.2.3	Segmentation settings.....	129
6.2.4	High definition mode.....	130
6.2.5	History settings.....	132
6.2.6	Speed.....	132
6.3	Vertical setup.....	132
6.3.1	About the vertical system.....	133
6.3.2	Vertical Setup settings.....	133
6.3.3	Bandwidth settings.....	136
6.3.4	Probe settings.....	137
6.3.5	Other vertical settings.....	137
6.4	Probes.....	138
6.4.1	Common probe settings.....	139
6.4.2	Setup for passive probes.....	141
6.4.3	Setup for active voltage probes.....	142
6.4.4	Setup for current probes.....	148
6.4.5	Modular probes.....	150
6.4.6	Setup for optical isolated probe systems.....	153
6.4.7	Probe adapter R&S RT-Z2T.....	157
6.4.8	Probe info.....	158
6.4.9	Adjusting passive probes.....	160
7	Trigger.....	161
7.1	Basics of triggering.....	161
7.1.1	Trigger information.....	162
7.2	Common trigger settings.....	163
7.3	Trigger sequence.....	165
7.3.1	Sequence setup.....	166

7.4	Trigger types.....	167
7.4.1	Edge trigger.....	168
7.4.2	Edge trigger on external trigger source.....	169
7.4.3	Glitch trigger.....	170
7.4.4	Width trigger.....	172
7.4.5	Runt trigger.....	173
7.4.6	Window trigger.....	175
7.4.7	Timeout trigger.....	177
7.4.8	Interval trigger.....	178
7.4.9	Slew rate trigger.....	180
7.4.10	Setup & Hold.....	182
7.4.11	State trigger.....	184
7.4.12	Pattern trigger.....	185
7.4.13	Line trigger.....	190
7.5	Trigger mode / holdoff.....	190
7.6	Hysteresis.....	192
7.7	Channel filter.....	194
7.8	Actions on trigger.....	195
7.9	Zone trigger.....	197
7.9.1	Using trigger zones and areas.....	202
7.9.2	Zone trigger settings.....	204
7.9.3	Logic operator settings.....	206
7.9.4	History settings.....	208
8	Signal configuration.....	209
8.1	Reference level setup.....	209
8.2	Gate setup.....	211
8.3	Timing reference.....	213
8.3.1	General settings of the timing reference.....	213
8.3.2	Explicit clock signal.....	213
8.3.3	Clock data recovery by software CDR.....	215
9	Waveform analysis.....	219
9.1	Zoom.....	219
9.1.1	Zoom settings.....	219

9.1.2	Zooming for details.....	222
9.2	Mathematics.....	223
9.2.1	Creating math waveforms.....	224
9.2.2	General math waveforms settings.....	224
9.2.3	Operator settings.....	225
9.2.4	Filter settings.....	227
9.2.5	Equations.....	229
9.2.6	Scale settings for math waveforms.....	234
9.3	History.....	235
9.3.1	About history.....	235
9.3.2	History setup.....	236
9.3.3	Quick access history dialog.....	239
9.3.4	Using history.....	240
9.4	Reference waveforms.....	241
9.4.1	Working with reference waveforms.....	242
9.4.2	Settings for reference waveforms.....	243
9.5	Waveform histograms.....	250
9.5.1	Histogram settings.....	251
9.5.2	Creating histograms.....	254
9.5.3	Exporting histograms.....	255
10	Measurements.....	256
10.1	Cursor measurements.....	256
10.1.1	Cursors and results of cursor measurements.....	256
10.1.2	Using cursors.....	257
10.1.3	Settings for cursor measurements.....	259
10.2	Automatic measurements.....	267
10.2.1	Measurement setup in general.....	267
10.2.2	Reference levels for measurements.....	274
10.2.3	Gate settings for measurements.....	275
10.2.4	Amplitude/time measurements.....	275
10.2.5	Histogram measurements.....	285
10.2.6	Basic jitter analysis (option R&S MXO5C-K12).....	287
10.2.7	Eye measurements (option R&S MXO5C-K136).....	292

10.2.8	Protocol measurements (option R&S MXO5C-K500).....	299
10.2.9	Annotation for measurements.....	304
10.2.10	Measurement results.....	305
10.2.11	Analysis of measurement results.....	306
11	Spectrum analysis.....	313
11.1	Fundamentals of spectrum analysis.....	313
11.2	Configuring spectrum waveforms.....	316
11.3	Spectrum setup.....	318
11.4	Spectrum scale.....	321
11.5	Spectrum gate.....	322
11.6	Spectrum peak list.....	323
11.7	Spectrum overlap.....	327
12	Applications.....	329
12.1	Mask testing.....	329
12.1.1	About mask testing.....	329
12.1.2	Mask test setup: general settings.....	331
12.1.3	Mask test setup: segment definition.....	333
12.1.4	Actions on mask test results.....	335
12.1.5	Working with masks.....	336
12.2	Frequency response analysis (option R&S MXO5C-K36).....	340
12.2.1	About the frequency response analysis plot.....	341
12.2.2	Using a frequency response analysis.....	343
12.2.3	Dependencies of the measurement setup.....	344
12.2.4	Settings for frequency response analysis.....	345
12.2.5	Saving results of frequency response analysis.....	356
12.2.6	Reference waveforms of FRA curves.....	357
12.3	Power analysis (option R&S MXO5C-K31).....	361
12.3.1	Power analysis initial settings.....	361
12.3.2	Power quality.....	365
12.3.3	Power harmonics.....	371
12.3.4	Switching loss.....	378
12.3.5	Turn on/off time.....	384
12.3.6	Power efficiency.....	389

12.3.7	Safe operating area (SOA).....	396
12.3.8	Common functions for power measurements.....	402
12.4	3-phase power analysis (option R&S MXO5C-K333).....	407
12.4.1	3-phase power analysis initial settings.....	408
12.4.2	3-phase power quality.....	409
12.4.3	3-phase power harmonics.....	415
12.4.4	Common functions for 3-phase power measurements.....	423
12.5	Digital voltmeter.....	428
12.5.1	Using the digital voltmeter.....	428
12.5.2	Settings of the digital voltmeter.....	429
12.6	XY-plot.....	431
12.6.1	Settings for XY-plots.....	431
12.6.2	Displaying an XY-diagram.....	432
12.7	Eye analysis (option R&S MXO5C-K136).....	432
12.7.1	Calculation and display of eye diagrams.....	432
12.7.2	Eye diagram setup.....	433
12.7.3	Analysis of eye diagrams.....	437
13	Data and file management.....	438
13.1	Accessing, retrieving and handling data.....	438
13.2	Save/recall dialog.....	439
13.3	General and measurement settings: savesets.....	441
13.3.1	Using savesets.....	441
13.3.2	Waveform generator saveset.....	443
13.4	Waveform data.....	445
13.4.1	Save waveforms: settings.....	445
13.4.2	Saving waveforms.....	450
13.4.3	Waveform export files.....	452
13.5	Histogram data export.....	461
13.5.1	Histogram export files.....	462
13.5.2	Settings for histogram export.....	463
13.6	Results.....	464
13.7	Sessions.....	466
13.7.1	Save a session.....	466

13.7.2	Load a session.....	468
13.8	Screenshots.....	469
13.8.1	Screenshot settings.....	470
13.8.2	Configuring and saving screenshots.....	473
13.8.3	Image viewer.....	474
13.9	File browser dialog.....	474
14	Protocol analysis.....	476
14.1	Basics of protocol analysis.....	477
14.1.1	Setup - general settings.....	477
14.1.2	Thresholds.....	478
14.1.3	Display.....	480
14.1.4	Filter.....	484
14.1.5	Trigger.....	485
14.1.6	Measure.....	489
14.1.7	Export protocol results.....	490
14.1.8	Bit pattern editor.....	491
14.2	SPI bus (IC electronics, option R&S MXO5C-K510).....	492
14.2.1	About the SPI protocol.....	492
14.2.2	SPI configuration.....	493
14.2.3	SPI filter.....	497
14.2.4	SPI hardware trigger.....	499
14.2.5	SPI software trigger.....	501
14.2.6	Measure.....	504
14.2.7	SPI decode results.....	504
14.2.8	Performing SPI decoding.....	506
14.3	QUAD-SPI bus (IC electronics, option R&S MXO5C-K510).....	510
14.3.1	About the QUAD-SPI protocol.....	510
14.3.2	QUAD-SPI configuration.....	511
14.3.3	QUAD SPI filter.....	519
14.3.4	QUAD SPI software trigger.....	522
14.3.5	Measure.....	525
14.3.6	QUAD-SPI decode results.....	525
14.3.7	Performing QUAD-SPI decoding.....	527

14.4 I²C (IC electronics, option R&S MXO5C-K510).....	529
14.4.1 About the I ² C protocol.....	530
14.4.2 I ² C configuration.....	532
14.4.3 I ² C filter.....	536
14.4.4 I ² C hardware trigger.....	538
14.4.5 I ² C software trigger.....	542
14.4.6 Measure.....	545
14.4.7 I ² C decode results.....	546
14.4.8 Performing I ² C decoding.....	547
14.5 I3C (IC electronics, option R&S MXO5C-K550).....	551
14.5.1 About the I3C protocol.....	552
14.5.2 I3C configuration.....	553
14.5.3 I3C filter.....	557
14.5.4 I3C software trigger.....	560
14.5.5 Measure.....	563
14.5.6 I3C decode results.....	563
14.5.7 Performing I3C decoding.....	565
14.6 UART (IC electronics, option R&S MXO5C-K510).....	568
14.6.1 About the UART / RS-232 interface.....	569
14.6.2 UART configuration.....	570
14.6.3 UART filter.....	573
14.6.4 UART hardware trigger.....	575
14.6.5 UART software trigger.....	576
14.6.6 Measure.....	579
14.6.7 UART decode results.....	579
14.6.8 Performing UART decoding.....	581
14.7 NRZ clocked & unclocked (option R&S MXO5C-K510).....	584
14.7.1 NRZ basics.....	584
14.7.2 NRZ configuration.....	584
14.7.3 NRZ filter.....	588
14.7.4 NRZ frame format configuration.....	592
14.7.5 NRZ software trigger.....	601
14.7.6 Measure.....	605

14.7.7	Performing NRZ decoding.....	605
14.7.8	NRZ decode results.....	607
14.8	Manchester (option R&S MXO5C-K510).....	609
14.8.1	Manchester basics.....	610
14.8.2	Manchester configuration.....	612
14.8.3	Manchester filter.....	616
14.8.4	Manchester frame format configuration.....	619
14.8.5	Manchester software trigger.....	628
14.8.6	Measure.....	631
14.8.7	Performing Manchester decoding.....	632
14.8.8	Manchester decode results.....	633
14.9	CAN (automotive electronics, option R&S MXO5C-K520).....	635
14.9.1	CAN configuration.....	636
14.9.2	CAN filter.....	642
14.9.3	CAN hardware trigger.....	645
14.9.4	CAN software trigger.....	654
14.9.5	Measure.....	658
14.9.6	CAN decode results.....	658
14.9.7	Performing CAN decoding.....	660
14.10	LIN (automotive electronics, option R&S MXO5C-K520).....	666
14.10.1	About the LIN protocol.....	666
14.10.2	LIN configuration.....	667
14.10.3	LIN filter.....	670
14.10.4	LIN hardware trigger.....	672
14.10.5	LIN software trigger.....	675
14.10.6	Measure.....	678
14.10.7	LIN decode results.....	678
14.10.8	Performing LIN decoding.....	680
14.11	SENT (automotive electronics, option R&S MXO5C-K520).....	683
14.11.1	About the SENT protocol.....	683
14.11.2	SENT configuration.....	687
14.11.3	SENT filter.....	691
14.11.4	SENT software trigger.....	695

14.11.5	Measure.....	698
14.11.6	SENT decode results.....	698
14.11.7	Performing SENT decoding.....	700
14.12	ARINC 429 (aerospace electronics, option R&S MXO5C-K530).....	703
14.12.1	About the ARINC 429.....	703
14.12.2	ARINC 429 configuration.....	704
14.12.3	ARINC 429 filter.....	707
14.12.4	ARINC 429 software trigger.....	710
14.12.5	Measure.....	713
14.12.6	ARINC 429 decode results.....	713
14.12.7	Performing ARINC 429 decoding.....	715
14.13	SpaceWire (aerospace communications, option R&S MXO5C-K530).....	716
14.13.1	SpaceWire basics.....	717
14.13.2	SpaceWire configuration.....	718
14.13.3	SpaceWire filter.....	720
14.13.4	SpaceWire software trigger.....	723
14.13.5	Measure.....	726
14.13.6	Performing SpaceWire decoding.....	726
14.13.7	SpaceWire decode results.....	728
14.14	MIL-1553 (aerospace electronics, option R&S MXO5C-K530).....	729
14.14.1	About the MIL-1553 protocol.....	730
14.14.2	MIL-1553 configuration.....	732
14.14.3	MIL-1553 filter.....	734
14.14.4	MIL-1553 software trigger.....	737
14.14.5	Measure.....	740
14.14.6	MIL-1553 decode results.....	740
14.14.7	Performing MIL-1553 decoding.....	742
14.15	SPMI (mobile electronics, option R&S MXO5C-K550).....	744
14.15.1	SPMI configuration.....	744
14.15.2	SPMI filter.....	747
14.15.3	SPMI software trigger.....	749
14.15.4	Measure.....	753
14.15.5	SPMI decode results.....	753

14.15.6	Performing SPMI decoding.....	755
14.16	RFFE (mobile electronics, option R&S MXO5C-K550).....	758
14.16.1	About the RFFE protocol.....	758
14.16.2	RFFE configuration.....	759
14.16.3	RFFE filter.....	762
14.16.4	RFFE software trigger.....	766
14.16.5	Measure.....	770
14.16.6	RFFE decode results.....	770
14.16.7	Performing RFFE decoding.....	772
14.17	10BASE-T1S (automotive Ethernet, option R&S MXO5C-K560).....	775
14.17.1	10BASE-T1S basics.....	775
14.17.2	10BASE-T1S configuration.....	776
14.17.3	10BASE-T1S filter.....	781
14.17.4	10BASE-T1S software trigger.....	783
14.17.5	Measure.....	786
14.17.6	10BASE-T1S decode results.....	786
14.17.7	Performing 10BASE-T1S decoding.....	788
14.18	100BASE-T1 (automotive Ethernet, option R&S MXO5C-K560).....	791
14.18.1	100BASE-T1 configuration.....	791
14.18.2	100BASE-T1S filter.....	794
14.18.3	100BASE-T1 software trigger.....	796
14.18.4	Measure.....	800
14.18.5	100BASE-T1 decode results.....	800
14.18.6	Performing 100BASE-T1 decoding.....	802
14.19	1000BASE-T1 (automotive Ethernet, option R&S MXO5C-K560).....	804
14.19.1	1000BASE-T1 basics.....	805
14.19.2	1000BASE-T1 configuration.....	805
14.19.3	1000BASE-T1 filter.....	808
14.19.4	1000BASE-T1 software trigger.....	811
14.19.5	Measure.....	815
14.19.6	1000BASE-T1 decode results.....	815
14.19.7	Performing 1000BASE-T1 decoding.....	817
14.20	USB 1.1 (option R&S MXO5C-K570).....	820

14.20.1	USB protocol basics.....	820
14.20.2	USB 1.1 configuration.....	825
14.20.3	USB 1.1 filter.....	829
14.20.4	USB 1.1 trigger.....	832
14.20.5	Measure.....	836
14.20.6	USB 1.1 decode results.....	836
14.21	USB 2.0 (option R&S MXO5C-K570).....	838
14.21.1	About the USB protocol.....	838
14.21.2	USB 2.0 configuration.....	838
14.21.3	USB 2.0 filter.....	842
14.21.4	USB 2.0 trigger.....	844
14.21.5	Measure.....	848
14.21.6	USB 2.0 decode results.....	848
15	Logic analysis on digital channels.....	851
15.1	Logic configuration.....	851
15.1.1	Setup.....	852
15.1.2	Bus.....	854
15.1.3	Label settings.....	855
15.1.4	Skew settings.....	856
15.2	Display.....	857
15.2.1	Logic bus - decode table.....	858
16	Waveform generator (option R&S MXO5C-B6).....	859
16.1	Setup of the waveform generator.....	859
16.1.1	General settings.....	859
16.1.2	Modulation settings.....	864
16.1.3	Sweep settings.....	866
16.1.4	Arbitrary waveforms.....	867
16.2	Synchronize settings.....	871
16.3	Configuring the waveform generator.....	872
16.3.1	Configuring a function waveform.....	872
16.3.2	Configuring a modulation waveform.....	872
16.3.3	Configuring a sine sweep waveform.....	874
16.3.4	Configuring an arbitrary waveform.....	874

17	Network operation.....	876
17.1	Connecting the instrument to the network (LAN).....	876
17.1.1	Connecting the instrument to the network.....	876
17.1.2	Assigning the IP address.....	877
17.1.3	Using host names.....	877
17.2	ScopeSync.....	878
17.2.1	ScopeSync concept.....	878
17.2.2	Setting up the ScopeSync connection of two oscilloscopes.....	882
17.2.3	ScopeSync settings.....	884
17.3	Web interface.....	889
17.3.1	Settings on the MXO 5C.....	889
17.3.2	Web browser.....	889
17.4	Remote operation with VNC client.....	895
17.5	Remote control.....	895
17.5.1	Remote control interfaces and protocols.....	896
17.5.2	Starting and stopping remote control.....	897
17.6	Remote control - status reporting system.....	898
17.6.1	Hierarchy of status registers.....	898
17.6.2	Structure of a SCPI status register.....	900
17.6.3	Contents of the status registers.....	901
17.6.4	Error queue.....	906
17.6.5	Reset values of the status reporting system.....	906
18	Remote control commands.....	908
18.1	Conventions used in remote command description.....	908
18.2	Finding the appropriate command.....	909
18.3	Error messages on remote commands.....	909
18.4	Frequently used parameters and suffixes.....	910
18.4.1	Waveform parameter.....	910
18.4.2	Slope parameter.....	911
18.4.3	Polarity parameter.....	911
18.5	Programming examples.....	911
18.5.1	SmartGrid layout with zoom.....	911
18.5.2	Creating a mask.....	915

18.5.3	Saving screenshots to file.....	916
18.5.4	Data transfer in roll mode.....	916
18.6	Common commands.....	917
18.7	General remote settings.....	920
18.8	Instrument setup.....	923
18.8.1	System.....	923
18.8.2	Network drive mapping.....	926
18.8.3	SmartGrid.....	927
18.8.4	Toolbar.....	934
18.8.5	Annotations.....	934
18.8.6	Appearance.....	946
18.8.7	Display.....	954
18.8.8	Save/Recall.....	957
18.8.9	Preset.....	959
18.8.10	Maintenance.....	960
18.9	Acquisition and waveform setup.....	962
18.9.1	Starting and stopping acquisition.....	962
18.9.2	Horizontal setup.....	963
18.9.3	Roll mode.....	964
18.9.4	Acquisition setup.....	966
18.9.5	Vertical setup.....	971
18.9.6	Probes.....	977
18.9.7	Fast segmentation.....	1002
18.9.8	High definition mode.....	1002
18.9.9	Waveform data export.....	1003
18.9.10	Reference clock.....	1005
18.10	Trigger.....	1006
18.10.1	Common trigger settings.....	1006
18.10.2	Trigger sequence.....	1008
18.10.3	Edge trigger.....	1010
18.10.4	Glitch trigger.....	1013
18.10.5	Width trigger.....	1014
18.10.6	Runt trigger.....	1015

18.10.7	Window trigger.....	1018
18.10.8	Timeout trigger.....	1021
18.10.9	Interval trigger.....	1022
18.10.10	Slew rate trigger.....	1023
18.10.11	Setup & Hold.....	1026
18.10.12	State trigger.....	1028
18.10.13	Pattern trigger.....	1029
18.10.14	Trigger mode, holdoff.....	1031
18.10.15	Hysteresis.....	1035
18.10.16	Channel filter.....	1037
18.10.17	Actions on trigger.....	1038
18.10.18	Zone trigger.....	1041
18.11	Signal configuration.....	1048
18.11.1	Reference levels.....	1048
18.11.2	Gate.....	1053
18.11.3	Timing reference.....	1056
18.12	Waveform analysis.....	1064
18.12.1	Zoom.....	1064
18.12.2	Mathematics.....	1073
18.12.3	History.....	1078
18.12.4	Reference waveforms.....	1081
18.12.5	Waveform histograms.....	1091
18.13	Data management.....	1097
18.13.1	Instrument settings.....	1097
18.13.2	Saveset.....	1104
18.13.3	Generator saveset.....	1104
18.13.4	Waveform export to file.....	1105
18.13.5	Fast data export.....	1109
18.13.6	Waveform histograms.....	1110
18.13.7	Sessions.....	1111
18.13.8	Results.....	1113
18.13.9	Screenshots.....	1114
18.14	Automatic measurements.....	1117

18.14.1	General settings.....	1117
18.14.2	Settings for amplitude/time measurements.....	1122
18.14.3	Settings for jitter measurements.....	1126
18.14.4	Default settings for eye measurements.....	1129
18.14.5	Settings for eye measurements.....	1131
18.14.6	Settings for protocol measurements.....	1135
18.14.7	Results.....	1137
18.14.8	Statistics.....	1139
18.14.9	Tracks.....	1141
18.15	Cursor measurements.....	1144
18.15.1	Cursor setup.....	1144
18.15.2	Cursor results.....	1153
18.15.3	Peak search using cursors.....	1155
18.15.4	Cursor appearance.....	1157
18.16	Spectrum analysis.....	1157
18.16.1	Spectrum setup.....	1157
18.16.2	Spectrum gate.....	1166
18.16.3	Peak list.....	1167
18.16.4	Spectrum with frames and overlap.....	1171
18.16.5	Data export of spectrum waveforms.....	1174
18.17	Applications.....	1176
18.17.1	Mask testing.....	1176
18.17.2	Frequency response analysis (option R&S MXO5C-K36).....	1186
18.17.3	Power analysis (option R&S MXO5C-K31).....	1209
18.17.4	3-phase power analysis (option R&S MXO5C-K333).....	1275
18.17.5	Digital voltmeter.....	1310
18.17.6	XY-plot.....	1313
18.17.7	Eye analysis (option R&S MXO5C-K136).....	1314
18.18	Protocols.....	1321
18.18.1	Configuration settings for all serial protocols.....	1322
18.18.2	SPI (option R&S MXO5C-K510).....	1327
18.18.3	QUAD-SPI (option R&S MXO5C-K510).....	1352
18.18.4	I ² C (option R&S MXO5C-K510).....	1384

18.18.5	I3C (option R&S MXO5C-K550).....	1410
18.18.6	UART / RS-232 (option R&S MXO5C- K510).....	1434
18.18.7	NRZ Clocked (option R&S MXO5C-K510).....	1456
18.18.8	NRZ Unclocked (option R&S MXO5C-K510).....	1484
18.18.9	Manchester (option R&S MXO5C-K510).....	1510
18.18.10	CAN (option R&S MXO5C-K520).....	1538
18.18.11	LIN (option R&S MXO5C-K520).....	1577
18.18.12	SENT (option R&S MXO5C-K520).....	1601
18.18.13	ARINC 429 (option R&S MXO5C-K530).....	1627
18.18.14	MIL-1553 (option R&S MXO5C-K530).....	1645
18.18.15	SpaceWire (option R&S MXO5C-K530).....	1663
18.18.16	SPMI (option R&S MXO5C-K550).....	1681
18.18.17	RFFE (option R&S MXO5C-K550).....	1703
18.18.18	10BASE-T1S (option R&S MXO5C-K560).....	1726
18.18.19	100BASE-T1 (option R&S MXO5C-K560).....	1748
18.18.20	1000BASE-T1 (option R&S MXO5C-K560).....	1770
18.18.21	USB 1.1 (option R&S MXO5C-K570).....	1792
18.18.22	USB 2.0 (option R&S MXO5C-K570).....	1814
18.19	Logic analysis on digital channels.....	1836
18.19.1	Digital channels.....	1837
18.19.2	Logic configuration.....	1840
18.19.3	Digital resolution.....	1848
18.19.4	Export of digital data.....	1849
18.20	Waveform generator (option R&S MXO5C-B6).....	1852
18.20.1	Waveform generator setup.....	1852
18.20.2	Synchronize settings.....	1870
18.21	ScopeSync.....	1872
18.22	Status reporting.....	1875
18.22.1	General commands.....	1876
18.22.2	STATus:OPERation register.....	1876
18.22.3	STATus:QUESTionable registers.....	1878
18.22.4	Reading out the CONDition part.....	1880
18.22.5	Reading out the EVENT part.....	1881

18.22.6	Controlling the ENABLE part.....	1881
18.22.7	Controlling the negative transition part.....	1882
18.22.8	Controlling the positive transition part.....	1883
18.22.9	Other status commands.....	1883
18.22.10	Programming tips and examples.....	1884
18.23	Deprecated commands.....	1886
18.23.1	Base instrument.....	1886
18.23.2	Applications.....	1886
18.23.3	Serial protocols.....	1887
19	Maintenance and support.....	1897
19.1	Cleaning.....	1897
19.2	Changing fuses.....	1897
19.3	Contacting customer support.....	1898
19.4	Information for technical support.....	1898
19.5	Data security.....	1899
19.6	Transporting.....	1899
19.7	Storage.....	1899
19.8	Disposal.....	1899
	List of commands.....	1901

1 Safety and regulatory information

The product documentation helps you to use the product safely and efficiently.

Where do I find safety information?

Safety information is part of the product documentation. It warns you of potential dangers and gives instructions on how to prevent personal injury or damage caused by dangerous situations. Safety information is provided as follows:

- In [Section 1.1, "Safety instructions"](#), on page 23. The same information is provided in many languages in printed format. The printed "Safety Instructions" for "Oscilloscopes and Accessories" are delivered with the instrument and the probes.
- Throughout the documentation, safety instructions are provided when you need to take care during setup or operation.

Intended use

The MXO 5C product is designed for measurements on circuits that are only indirectly connected to the mains or not connected at all. It is not rated for any measurement category.

The product is intended for the development, production and verification of electronic components and devices in industrial, administrative, and laboratory environments. Use the product only for its designated purpose. Observe the operating conditions and performance limits stated in the specifications document.

Target audience

The target audience of this document includes developers and technicians, administrators and maintenance personnel using oscilloscopes and probes. The required skills and experience of the users depend on the test setup and application of the product.

1.1 Safety instructions

Products from the Rohde & Schwarz group of companies are manufactured according to the highest technical standards. To use the products safely, follow the instructions provided here and in the product documentation. Keep the product documentation nearby and offer it to other users.

Use the product only for its intended use and within its performance limits. Intended use and limits are described in the product documentation such as the specifications document, manuals and the printed "Safety Instructions" document. If you are unsure about the appropriate use, contact Rohde & Schwarz customer support.

Using the product requires skilled persons or specially trained personnel. These users also need sound knowledge of at least one of the languages in which the user interfaces and the product documentation are available.

Reconfigure or adjust the product only as described in the product documentation or the specifications document. Any other modifications can affect safety and are not permitted.

Never open the casing of the product. Only service personnel authorized by Rohde & Schwarz are allowed to repair the product. If any part of the product is damaged or broken, stop using the product. Contact Rohde & Schwarz customer support at <https://www.rohde-schwarz.com/support>.

In these safety instructions, the term "product" covers instruments (oscilloscopes), probes and their accessories.

Lifting and carrying the instrument

Check the specifications document for the maximum weight of the instrument. A single person can only carry a maximum of 18 kg safely depending on age, gender and physical condition. If your instrument is heavier than 18 kg, do not move or carry it by yourself.

Use the instrument handles to move or carry the instrument. Do not use the mounted accessories instead of the handles. Accessories are not designed to carry the weight of the instrument.

To move the instrument safely, you can use lifting or transporting equipment such as lift trucks and forklifts. Follow the instructions provided by the equipment manufacturer.

Choosing the operating site

Only use the product indoors. The product casing is not waterproof. Water that enters can electrically connect the casing with live parts, which can lead to electric shock, serious personal injury or death if you touch the casing.

If Rohde & Schwarz provides accessories designed for outdoor use of your product, e.g. a protective cover, you can use the product outdoors.

You can operate the product up to an altitude of 2000 m above sea level. If a higher altitude is permissible, the value is provided in the specifications document. The product is suitable for pollution degree 2 environments where nonconductive contamination can occur. For more information on environmental conditions such as ambient temperature and humidity, see the specifications document.

Setting up the product

Always place the product on a stable, flat and level surface with the bottom of the product facing down. If the product is designed for different positions, secure the product so that it cannot fall over.

If the product has foldable feet, always fold the feet completely in or out to ensure stability. The feet can collapse if they are not folded out completely or if the product is moved without lifting it. The foldable feet are designed to carry the weight of the product, but not an extra load.

If stacking is possible, keep in mind that a stack of products can fall over and cause injury.

If you mount products in a rack, ensure that the rack has sufficient load capacity and stability. Observe the specifications of the rack manufacturer. Always install the products from the bottom shelf to the top shelf so that the rack stands securely. Secure the product so that it cannot fall off the rack.

Connecting the product

Before connecting the interfaces or measuring inputs of the product to other products or electrical circuits, make sure that the other products or electrical circuits provide special protection against electric shock. This protection principle is referred to as SELV (safety extra-low voltage) and is based on a low voltage level and increased insulation. Exceptions are indicated by a measurement category on the product and given in the specifications document.

Connecting to power and grounding

The mains power supply input of the instrument complies with overvoltage category II. Connect the product to a fixed installation used to supply energy-consuming equipment such as household appliances and similar loads. Keep in mind that electrically powered products have risks, such as electric shock, fire, personal injury or even death.

Take the following measures for your safety:

- Do not use an isolating transformer to connect the instrument to the mains power supply.
- Before switching on the product, ensure that the voltage and frequency indicated on the product match the available power source. If the power adapter does not adjust automatically, set the correct value and check the rating of the fuse.
- If a product has an exchangeable fuse, its type and characteristics are indicated next to the fuse holder. Before changing the fuse, switch off the product and disconnect it from the power source. How to change the fuse is described in the product documentation.
- Only use the power cable delivered with the product. It complies with country-specific safety requirements. Only insert the plug into an outlet with protective conductor terminal.
- Only use intact cables and route them carefully so that they cannot be damaged. Check the power cables regularly to ensure that they are undamaged. Also ensure that nobody can trip over loose cables.
- If you connect the product to an external power supply, use the one delivered with the product or recommended in the product documentation. The external power supply must conform to the country-specific regulations.
- Ensure that you can disconnect the product from the power source at any time. Pull the power plug to disconnect the product. The power plug must be easily accessible. If the product is integrated into a system that does not meet these requirements, provide an easily accessible circuit breaker at the system level.
- Replace parts that are relevant to safety only by original parts, e.g. power cables or fuses.

Performing measurements

Take the following measures for your safety:

- To ascertain a voltage-free state, use an appropriate voltage tester. Any measurement setup including an oscilloscope is not suitable for this purpose.
- The maximum input voltage on channel inputs and the external trigger input must not exceed the value specified in the specifications document.
- Observe all voltage and current ratings of the instrument, the probes, and the accessories. Exceeding the allowed voltages can lead to an electric shock. Limits and ratings are marked on the products and listed in the specifications documents.
Consider that the rated voltage depends on the frequency. The voltage limitation curves or values are provided in the specifications document.
- Never cause any short circuits when measuring sources with high output currents.
- Use only probes and accessories that comply with the measurement category (CAT) of your measurement task. If the product is rated for any measurement category, the permitted category is indicated on the product and in the specifications document. If you use other than Rohde & Schwarz accessories, make sure that they are suitable for the instrument and the measurement task.
- Set the correct attenuation factor on the instrument according to the probe being used. Otherwise, the measurement results do not reflect the actual voltage level, and you might misjudge the actual risk.
- When working with high voltages and current probes, observe the additional operating conditions specified in these safety instructions.
- The probe pins are extremely pointed and can easily penetrate clothes and the skin. Handle the probe pins with great care. To exchange a probe pin, use tweezers or pliers to avoid injuries. When transporting the accessories, always use the box supplied with the probe.
- Prevent the probe from receiving mechanical shock. Avoid putting excessive strain on the probe cable or exposing it to sharp bends. Touching a broken cable during measurements can cause injuries.
- Set up all probe connections to the instrument before applying power.

Working with hazardous voltages

Voltages higher than 30 V RMS, or 42 V peak, or 60 V DC are regarded as hazardous contact voltages. Direct contact with them can cause serious injuries.

Make sure that only electrically skilled persons use the products for measurements on hazardous contact voltages. These working conditions require special education and experience to perceive risks and to avoid hazards which electricity can create.

When working with hazardous contact voltages, use protective measures to preclude direct contact with the measurement setup:

- Do not touch exposed connections and components when power is applied.
- Switch off the test circuit while connecting and disconnecting probe leads.
- Use only insulated voltage probes, test leads and adapters.
- Make sure that the input leads fulfill the safety requirements for your measurement.

The delivered input leads might have a jacket wear indicator that indicates a worn jacket by different jacket color. In this case, do not use the input lead. Replace it with a new one.

- When connecting to the DUT, keep your fingers behind finger guard. Remove jewelry, watches, and other metallic objects. Only use 4 mm safety banana plugs.

Using optical isolated probe systems

Optical isolated probes are classified as class 1 laser product. Class 1 lasers are safe under all conditions of normal use. The product fully contains the beam of a higher-class laser. Take the following measures for your safety:

- To avoid exposure to the laser beam, never remove any covers from the probe head or probe receiver, and never disassemble the product.
- Check the product before using to ensure that it is undamaged. If you have dropped the product or exposed it to excessive mechanical stress, always check the product. Do not use the product if any component is damaged.
- Send the product to service regularly.

Optical isolated probes measure differential voltages. The test circuit can have a different potential. The common mode voltage between the potentials of the DUT and the oscilloscope can be much higher than the differential voltage and is not measured by the probe. To avoid the risk of electrical shock, use protective measures:

- Always de-energize the test circuit before installing or removing the tip module.
- Never exceed the differential voltage rating.
- When measuring on a test circuit with high common mode voltage, use a tripod to hold the probe head.
- Keep the probe head and the tip cable away from circuits with different potential to prevent arc flash caused by a different potential.

Working with current probes


When working with current probes, you can measure high-frequency currents or currents that contain high-frequency components.

- Switch off the test circuit while connecting the probe.
- Do not attach the clamp to bare unisolated conductors. To avoid injury from a short circuit, measure at a location on an insulated wire where the insulation is sufficient for the circuit voltage.
- Connect the probe only to the secondary side of a breaker. With this measure, you can avoid injury if a short circuit occurs.
- The following effects can cause burns and fire or damage to the measurement site:
 - Eddy current loss can cause heating of the sensor head.
 - Dielectric heating can cause heating of cord insulation and other materials.
- When measuring current that includes a high-frequency component, consider the derating characteristics of the probe. Do not measure any current that exceeds the rated current.
- Using the probes with high frequencies or strong magnetic fields may cause the device to become abnormally hot, resulting in fire, equipment damage, or burns.

Measurement categories

IEC 61010-2-030 defines measurement categories that rate instruments on their ability to resist short transient overvoltages that occur in addition to the working voltage. Use the measurement setup only in electrical environments for which they are rated.

- 0 - Instruments without rated measurement category
For measurements performed on circuits not directly connected to mains, for example, electronics, circuits powered by batteries, and specially protected secondary circuits. This measurement category is also known as CAT I.
- CAT II:
For measurements performed on circuits directly connected to the low-voltage installation by a standard socket outlet, for example, household appliances and portable tools.
- CAT III:
For measurements performed in the building installation, such as junction boxes, circuit breakers, distribution boards, and equipment with permanent connection to the fixed installation.
- CAT IV:
For measurements performed at the source of the low-voltage installation, such as electricity meters and primary overcurrent protection devices.



Cleaning the product

Use a dry, lint-free cloth to clean the product. When cleaning, keep in mind that the casing is not waterproof. Do not use liquid cleaning agents.

Meaning of safety labels

Safety labels on the product and its accessories warn against potential hazards.

	Potential hazard Read the product documentation to avoid personal injury or product damage.

	Electrical hazard Indicates live parts. Risk of electric shock, fire, personal injury or even death.
	Protective conductor terminal Connect this terminal to a grounded external conductor or to protective ground. This connection protects you against electric shock if an electric problem occurs.

1.2 Labels on the product

Labels on the casing inform about:

- Personal safety, see ["Meaning of safety labels"](#) on page 28
- Product and environment safety, see [Table 1-1](#)
- Identification of the product

Table 1-1: Labels regarding product and environment safety

	Chassis grounding terminal
	Take care when handling electrostatic sensitive devices.
	Labeling in line with EN 50419 for disposal of electrical and electronic equipment after the product has come to the end of its life. For more information, see "Disposing of electrical and electronic equipment" on page 1900.

1.3 Warning messages in the documentation

A warning message points out a risk or danger that you need to be aware of. The signal word indicates the severity of the safety hazard and how likely it will occur if you do not follow the safety precautions.

WARNING

Potentially hazardous situation. Could result in death or serious injury if not avoided.

CAUTION

Potentially hazardous situation. Could result in minor or moderate injury if not avoided.

NOTICE

Potential risks of damage. Could result in damage to the supported product or to other property.

1.4 CE declaration of conformity

The CE declaration of conformity of the instrument is delivered with the product. Keep the document for further reference.

The current version of this CE declaration of conformity is available at:

www.rohde-schwarz.com/company-documents/mxo5c/

1.5 Where to find key documents on Rohde & Schwarz

Certificates issued to Rohde & Schwarz that are relevant for your country are provided at www.rohde-schwarz.com/key-documents, e.g. concerning:

- Quality management
- Environmental management
- Information security management
- Accreditations

1.6 Korea certification class A



이 기기는 업무용(A급) 전자파 적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

2 Preface

2.1 Key features

The MXO 5C series oscilloscope is the first compact Rohde & Schwarz oscilloscope with 2 U height, which makes it the ideal choice for rack applications.

An integrated low-power e-ink display shows key information such as instrument IP address, firmware version, software options, and status for fast setup.

MXO 5C uses same building blocks as R&S MXO 5 series oscilloscopes and has the same outstanding specifications. It can be controlled remotely via LAN with the integrated web browser and virtual front panel.

- 4 channels with 350 MHz to 2 GHz bandwidth or 8 channels with 100 MHz to 2 GHz bandwidth
- Fastest update rate of up to 4.5 million waveforms/s thanks to MXO-EP ASIC
- 12 bit ADC at all sample rates, and 18 bit vertical resolution in HD mode
- Deep standard memory: 500 Mpoints per channel
- Superior spectrum analysis with 45 000 FFT/s, which allows capture of spurious spectrum events
4 simultaneous spectrums with independent time and frequency control
- High-precision digital trigger with best-in-class trigger jitter, also available in HD mode
- Nearly zero blind time: up to 99% real-time signal activity capture
- Integrated arbitrary waveform generator
- Logic analysis with 16 digital channels
- Dual-path serial protocol analysis
- Eco-friendly design: low power consumption, automatic power-up capability, scarcely audible

2.2 Documentation overview

This section provides an overview of the MXO 5C user documentation.

2.2.1 Manuals and instrument help

You find the manuals on the product page at:

www.rohde-schwarz.com/manual/mxo5C

Getting started manual

Introduces the MXO 5C and describes how to set up the product. A printed English version is included in the delivery.

User manual and help

Contains the description of all instrument modes and functions. It also provides an introduction to remote control, a complete description of the remote control commands with programming examples, and information on maintenance and instrument interfaces. Includes the contents of the getting started manual.

The contents of the user manual are available as help in the MXO 5C. The help offers quick, context-sensitive access to the complete information on the instrument and its firmware.

The user manual is available for download or immediate display on the internet.

Safety instructions

Provides safety information in many languages. The printed document is delivered with the product.

Instrument security procedures manual

Deals with security issues when working with the MXO 5C in secure areas. It is available for download on the internet.

Service manual

Describes the performance test for checking compliance with rated specifications, firmware update, adjustments, installing options and maintenance. The service manual is available for registered users on the global Rohde & Schwarz information system (GLORIS, <https://gloris.rohde-schwarz.com>).

2.2.2 Specifications and product brochure

The specifications document, also known as the data sheet, contains the technical specifications of the MXO 5C. It also lists the firmware applications and their order numbers, and optional accessories. The product brochure provides an overview of the instrument and deals with the specific characteristics.

www.rohde-schwarz.com/brochure-datasheet/mxo5C

2.2.3 Calibration certificate

The document is available on <https://gloris.rohde-schwarz.com/calcert>. You need the device ID of your instrument, which you can find on a label on the rear panel.

2.2.4 Release notes, open source acknowledgment

The release notes list new features, improvements and known issues of the current firmware version, and describe the firmware installation. The open source acknowledgment document provides verbatim license texts of the used open source software. It can also be read directly on the instrument.

www.rohde-schwarz.com/firmware/mxo5C

2.2.5 Application notes, application cards, videos

Various documents and videos deal with special applications or background information on particular topics.

[R&S®MXO 5C - Applications](#)

Find various videos on Rohde & Schwarz products and test and measurement topics on YouTube: <https://www.youtube.com/@Rohde-Schwarz>

2.3 Options described in this document

In addition to the base unit, the following options are described in this documentation:

Type	Designation	Order No.
R&S MXO5C-B1	MSO	1802.3023.02
R&S MXO5C-B6	Waveform and pattern generator	1802.3030.02
R&S MXO5C-K12	Basic jitter analysis	1801.8638.02
R&S MXO5C-K31	Power analysis	1802.3130.02
R&S MXO5C-K36	Frequency response analysis	1802.3146.02
R&S MXO5C-K136	Eye analysis	1801.8644.02
R&S MXO5C-K333	3-phase power analysis	1801.8673.02
R&S MXO5C-K500	Bus analysis	1803.1401.02
R&S MXO5C-K510	Triggering and decoding low speed serial buses: I2C, SPI, UART/RS-232/RS-422/RS-485, QUAD-SPI, NRZ clocked, NRZ unclocked, Manchester	1803.1418.02
R&S MXO5C-K520	Triggering and decoding automotive protocols: CAN, CAN FD, CAN XL, LIN, SENT	1803.1424.02
R&S MXO5C-K530	Decoding aerospace protocols: ARINC 429, MIL-STD-1553, SpaceWire	1803.1430.02
R&S MXO5C-K550	Decoding MIPI low speed protocols: I3C, RFFE, SPMI	1803.1430.02

Options described in this document

Type	Designation	Order No.
R&S MXO5C-K560	Decoding automotive Ethernet protocols: 10BASE-T1S, 100BASE-T1, 1000BASE-T1	1803.1453.02
R&S MXO5C-K570	Decoding automotive USB protocols: USB 1.1, USB 2.0	1801.9034.02

3 Getting Started

3.1 Preparing for use

Here, you can find basic information about setting up the instrument for the first time or when changing the operating site.

3.1.1 Lifting and carrying

See: "[Lifting and carrying the instrument](#)" on page 24.

3.1.2 Unpacking and checking

1. Unpack the product carefully.
2. Retain the original packing material. Use it when transporting or shipping the product later.
3. Using the delivery notes, check the equipment for completeness.
4. Check the equipment for damage.

If the delivery is incomplete or equipment is damaged, contact Rohde & Schwarz.

3.1.3 Choosing the operating site

Specific operating conditions ensure proper operation and avoid damage to the product and connected devices. For information on environmental conditions such as ambient temperature and humidity, see the specifications document.

For safety information, see "[Choosing the operating site](#)" on page 24.

Electromagnetic compatibility classes

The electromagnetic compatibility (EMC) class indicates where you can operate the product. The EMC class of the product is given in the specifications document.

- Class B equipment is suitable for use in:
 - Residential environments
 - Environments that are directly connected to a low-voltage supply network that supplies residential buildings
- Class A equipment is intended for use in industrial environments. It can cause radio disturbances in residential environments due to possible conducted and radiated disturbances. It is therefore not suitable for class B environments.

If class A equipment causes radio disturbances, take appropriate measures to eliminate them.

3.1.4 Setting up the product

When setting up the instrument, follow the safety instructions:

- "Setting up the product" on page 24
- "Intended use" on page 23

3.1.4.1 Placing the product on a bench top

For standalone operation, place the instrument on a horizontal bench with even, flat surface. The instrument can be used in horizontal position, standing on its feet, or with the support feet on the bottom extended.

To place the product on a bench top


1. Place the product on a stable, flat and level surface. Ensure that the surface can support the weight of the product. For information on the weight, see the specifications document.
2. **CAUTION!** Foldable feet can collapse. For safety information, see "Setting up the product" on page 24.

Always fold the feet completely in or out. With folded-out feet, do not place anything on top or underneath the product.

3. **WARNING!** A stack of products can fall over and cause injury. Never stack more than three products on top of each other. Instead, mount them in a rack.

Stack as follows:

- If the products have foldable feet, fold them in completely.
- All products must have the same dimensions (width and length).
- Do not exceed a total load of 50 kg placed on the product at the bottom of the stack.



- Left = Stacked correctly
 Middle left = Stacked incorrectly, too many products
 Middle right = Stacked incorrectly, different dimensions
 Right = Stacked incorrectly, folded-out feet

4. **NOTICE!** Overheating can damage the product.

Prevent overheating as follows:

- Keep a minimum distance of 10 cm between the fan openings of the product and any object in the vicinity to provide sufficient airflow and ventilation.
- Do not place the product next to heat-generating equipment such as radiators or other products.

3.1.4.2 Mounting the product in a rack

To prepare the rack

1. Observe the requirements and instructions in ["Setting up the product"](#) on page 24.
2. **NOTICE!** Insufficient airflow can cause overheating and damage the product. Design and implement an efficient ventilation concept for the rack.

To mount the oscilloscope in a rack

1. Use a rackmount kit to prepare the instrument for rack mounting.
 - a) Order the rackmount kit designed for your oscilloscope. For the order number, see specifications document.
 - b) Mount the rackmount kit. Follow the assembly instructions provided with the rackmount kit.
2. Lift the product to shelf height. If the rack is high, use a safe climbing aid when placing on upper shelves.
3. Grip the product by the handles. Slide the product onto the shelf until the rack brackets fit closely to the rack.
4. Tighten all screws at the rack brackets with a tightening torque of 1.2 Nm to secure the product at the rack.

To unmount the product from a rack

1. Loosen the screws at the rack brackets.
2. Remove the product from the rack.
3. If placing the product on a bench top again, unmount the rackmount kit from the product. Follow the instructions provided with the rackmount kit.

3.1.5 Considerations for test setup

Observe safety instructions, see ["Performing measurements"](#) on page 26.

Cable selection and electromagnetic interference (EMI)

Electromagnetic interference (EMI) can affect the measurement results.

To suppress electromagnetic radiation during operation:

- Use high-quality shielded cables, for example, double-shielded RF and LAN cables.
- Always terminate open cable ends.
- Ensure that connected external devices comply with EMC regulations.

Measuring accessories

Use only probes and measuring accessories that comply with IEC 61010-031.

Signal input and output levels

Information on signal levels is provided in the specifications document. Keep the signal levels within the specified ranges to avoid damage to the product and connected devices.

Preventing electrostatic discharge (ESD)

Electrostatic discharge is most likely to occur when you connect or disconnect a DUT.

- **NOTICE!** Electrostatic discharge can damage the electronic components of the product and the device under test (DUT).

Ground yourself to prevent electrostatic discharge damage:

- a) Use a wrist strap and cord to connect yourself to ground.
- b) Use a conductive floor mat and heel strap combination.

During operation, if the firmware observes a serious unexpected disturbance (e.g. due to ESD), it resets some hardware components and initiates a new alignment to ensure proper instrument functioning. Then it restores the user settings to the state before the disturbance.

3.1.6 Connecting to power

For safety information, see ["Connecting to power and grounding"](#) on page 25.

The MXO 5C can be used with different AC power voltages and adapts itself automatically to it.

The nominal ranges are indicated on a label near the power connector on the instrument and in the specifications document.

1. Plug the AC power cable into the AC power connector on the rear panel of the product. Only use the AC power cable that is delivered with the product.
2. Plug the AC power cable into a power outlet with ground contact.

If the voltage dips at the AC power connector (according to EN 61326-2-1 6.4.101), a restart of the MXO 5C can happen. All instrument settings are restored after the restart.

3.1.7 Connecting to LAN

For remote operation of the instrument using a computer, you need a local area network (LAN) connection.

Network environment

Before connecting the product to a LAN, consider the following:

- Install the latest firmware to reduce security risks.
- For internet or remote access, use secured connections if applicable.
- Ensure that the network settings comply with the security policies of your company. Contact your local system administrator or IT department before connecting your product to your company LAN.
- When connected to the LAN, the product may potentially be accessed from the internet, which may be a security risk. For example, attackers might misuse or damage the product.

To connect a LAN cable

- ▶ Connect an RJ-45 cable to the LAN connector on the rear panel, and to the LAN.

For supported LAN interfaces, refer to the specifications document.

By default, the MXO 5C is configured to use DHCP. Configuration of a static IP address is not required.

3.1.8 Connecting a monitor, mouse and keyboard

For direct operation of the MXO 5C series oscilloscope, connect a mouse, keyboard and monitor. If you use a touchscreen, mouse and keyboard are redundant. If you operate the oscilloscope only remotely, you do not need these devices.

Using the HDMI and DisplayPort connectors on the rear panel, you can connect one or two external monitors or projectors to the oscilloscope. The display connectors are *not* plug & play, the monitors are recognized by the instrument during the boot process.

1. **NOTICE!** Missing ground contact can damage the oscilloscope.
Ensure that the monitor and the oscilloscope are connected to a ground contact.
See also: [Section 3.1.6, "Connecting to power"](#), on page 38.
2. **NOTICE!** Use only standard-compliant monitor cables.
Connect the monitor or projector to a display connector.
3. Switch on the oscilloscope. See also ["To switch on the product"](#) on page 40.
The oscilloscope recognizes the external monitor. During the running session, you can disconnect the monitor and connect it again.

If the monitor provides touch functionality, an additional connection can be required, e.g. a USB connection. Refer to the documentation of your monitor.

To connect a mouse and a keyboard

- Connect the mouse and the keyboard to any of the USB connectors.

3.1.9 Switching on or off

The instrument is switched on or off with the power switch and the [Power] key. The [Power] key is located in the bottom left corner of the front panel. The power switch is located at the rear panel of the instrument.

Table 3-1: Overview of power states

Status	LED	Power switch
Off	● (unlighted)	[0] (off)
Standby	● yellow	[1] (on)
Ready	● green	[1] (on)

To switch on the product

The product is off but connected to power.

1. Set the switch on the power supply to position [1].
The power key on the front panel lights up.
2. Press the [Power] key on the front panel.
The instrument performs a system check, boots the operating system, and then starts the MXO 5C firmware.
The [Power] key turns green and the illuminated keys on the front panel light up. If the previous session was terminated regularly, the oscilloscope uses the last settings.

Before you start measurements, be sure to comply with the warm-up phase specified in the specifications document.

To shut down the product

The product is in the ready state.

- Press the [Power] key.
All current settings are saved, and the software shuts down. The [Power] key turns yellow. The standby power supplies only the power switch circuits.

Remote command for firmware shutdown: [SYSTem:EXIT](#) on page 924.

To disconnect from power

The product is in the standby state.

1. **NOTICE!** Risk of data loss. If you disconnect the product from power when it is in the ready state, you can lose settings and data. Shut it down first.

Set the switch on the power supply to position [0].

The LED of the [Power] key is switched off.

2. Disconnect the product from the power source.

3.2 Instrument tour

This section describes the front and rear view of the instrument including all connectors.

3.2.1 Front view

This section describes the instrument's front panel.




Figure 3-1: Front view of MXO 58C with 8 input channels

- 1 = Chassis grounding terminal
- 2 = Connectors for probe compensation
- 3 = E ink display
- 4 = Information LEDs and "Info" key to turn display pages
- 5 = USB connectors
- 6 = Connectors for logic probe (R&S MXO5C-B1 Mixed Signal option)
- 7 = Analog input channels
- 8 = [Power] key

[Power] key

The [Power] key is located on the lower left corner of the front panel. It starts up and shuts down the instrument's software.

The light of the key shows the instrument state, see [Section 3.1.9, "Switching on or off"](#), on page 40.

Remote command:

`SYSTem:SHUTdown` on page 925

Analog channel inputs

The MXO 5C has 4 or 8 channel inputs to connect the input signals, depending on the model.

You can connect probes with Rohde & Schwarz probe interface or BNC connectors. The input impedance is selectable, the values are 50 Ω and 1 M Ω .

The maximum input voltage on channel inputs is:

- 400 V (V_p) and 300 V (RMS) at 1 M Ω input impedance, derates at 20 dB/decade to 5 V (RMS) above 250 kHz.
- 30 V (V_p) and 5 V (RMS) at 50 Ω input impedance

E ink display and [Info] key

The electronic ink display shows the basic information of the MXO 5C series oscilloscope. If the instrument is on, connection information such as IP address, host name, and LAN connection status is shown, among others.

Instrument Model	MXO54C
Bandwidth, Memory	2 GHz, 1 Gpts
Firmware Version	2.4
Host Name	MXO54C-100
IP Address	192.168.1.100
Ethernet Status	Connected

You can turn the display pages using the "Info" key on the right side of the display. The second page shows LXI information, for example, several addresses of the instrument.

LXI	
MAC Address	00:E0:33:0D:E5:18
IPv4 Address	192.168.1.100
IPv6 Address	fe80::2e0:33ff:fe0d:e518

If the instrument has been shut down with the [Power] key or the  "Power" icon in the "Menu", the display shows general instrument information.

Instrument Model	MXO54C
Bandwidth, Memory	2 GHz, 1 Gpts
Serial Number	100864
Firmware Version	2.4
Option List	B6, B110, K36 K31, K500, ...

If the instrument has been disconnected from power without shutdown before, the information of the running instrument remains on the display.

To do an LXI LAN reset, press and hold the [Info] key for 5 seconds. The reset changes all network settings to default. Use the reset when you cannot access the instrument via LAN due to invalid configuration.

Information LEDs: Trigger and Scope Ready

The "Trigger" indicates if the instrument has triggered, according to the selected trigger mode.

The "Scope Ready" LED lights up when the firmware is running, and indicates the connection status:

- Blinking: the device indicator in the instrument's web browser is switched on.
- Green: the instrument is connected to the LAN.
- Orange: initializing the LAN, or waiting for a DHCP answer.
- Blue: the instrument is not connected to the LAN.
- Red: connection error. Check if the LAN cable is connected correctly.

Logic Channels

Two connectors for logical probes with 8 digital channels each (D0 to D7 and D8 to D15). Using logic channels requires the Mixed Signal Option R&S MXO5C-B1.

The maximum input voltage at 100 k Ω input impedance is ± 40 V (Vp) and 32 V (RMS), derates to 7 V (RMS) with 20 dB/decade at frequencies above 25 MHz. The maximum input frequency for a signal with the minimum input voltage swing and normal hysteresis setting is 400 MHz.

USB

Three USB 3.0 interfaces type A. They are used to:

- Directly connect a computer to control the oscilloscope
- Connect a USB flash drive for storing and reloading instrument settings, and to update firmware
- Connect touchscreen control

Probe Comp.

Probe compensation terminal to adjust passive probes to the input channel.



Square-wave signal for probe compensation.



Ground connector for probes.

For details, see the specifications document.

Grounding terminal

4 mm banana jack to connect ground of DUT and test fixtures, and wrist strap.

3.2.2 Rear view

On the instrument's rear panel, you find more connectors and the power supply switch.




Figure 3-2: Rear panel view of MXO 5C series oscilloscope

- 1 = Solid state disk (SSD)
- 2 = LAN connector
- 3 = USB connector
- 4 = Option slot
- 5 = AC power supply connector and mains power switch
- 6 = External trigger input
- 7 = Trigger Out connector
- 8 = Ref In 10MHz
- 9 = Ref Out 10MHz
- 10 = Connector for optional function generator output (BNC, R&S MXO5C-B6 arbitrary waveform generator option)
- 11 = HDMI display output
- 12 = DisplayPort display output

AC power supply connector and mains power switch

The instrument supports a wide range power supply. It automatically adjusts to the correct range for the applied voltage. There is no line voltage selector.

The AC mains power switch disconnects the instrument from the AC power line.

When you power up the instrument, be sure to comply with the warm-up phase specified in the specifications document before you start measurements.

LAN

8-pin RJ-45 connector used to connect the instrument to a Local Area Network (LAN). It supports 10/100/1000BASE-T, LXI compliant.

USB

Two USB 3.0 interfaces type A.

Trigger In

The external trigger input is a BNC connector that is used to control the measurement by an external signal. The trigger level can be set from -5 V to 5 V.

For the external trigger input, the maximum input voltage is 400 V (V_p) and 300 V (RMS) at 1 M Ω input impedance.

Transient overvoltages on all input connectors must not exceed 400 V (V_p).

Trigger Out

BNC output that can function as pass/fail output or trigger output.

Ref In 10 MHz

BNC input connector for 10 MHz reference frequency signals.

Ref Out 10 MHz

BNC output for 10 MHz frequency reference. Can be switched between internal and external reference.

See also: "Menu" > "Horizontal" > "Setup" tab > "Ref clock"

Gen1, Gen 2: Function generator

BNC output of the function generator, requires option R&S MXO5C-B6.

HDMI

HDMI Version 2.0 connector for an external monitor or projector. The monitor shows the complete content of the instrument's screen.

DisplayPort

DisplayPort connector for an external monitor or projector. It supports DisplayPort++ version 1.3.

4 Operating the instrument

There are several ways to operate the MXO 5C series oscilloscope.

- **Remote control**
Create programs to automatize repeating settings, tests, and measurements. The instrument is connected to a computer that runs the program.
This way of operation is described in: [Section 18, "Remote control commands"](#), on page 908.
- **Remote operation**
For remote monitoring and operation of the instrument, a VNC server is installed on the oscilloscope. You need a LAN connection to the computer, and a VNC client or web browser to connect to the instrument, and to access the GUI.
- **Local operation**
To get access to the GUI, you need a monitor, mouse and keyboard connected to the instrument. Alternatively, you can connect a touchscreen.

4.1 Accessing the GUI

You can access the GUI locally using a connected monitor, or via LAN and a browser or VNC client.

To access the GUI using a connected monitor

1. Connect a monitor, mouse and keyboard to the oscilloscope.
See [Section 3.1.8, "Connecting a monitor, mouse and keyboard"](#), on page 39.

2. Start the instrument.

The monitor displays the GUI. You can operate the instrument using the menu, dialogs, signal bar and other means of interaction in the GUI.

To access the GUI via LAN

1. Connect the oscilloscope to the LAN.
See [Section 3.1.7, "Connecting to LAN"](#), on page 39.
2. Switch on the oscilloscope.
3. Open a browser on a computer connected to the instrument via LAN.
4. Enter the IP address of the MXO 5C series oscilloscope.
The IP address is shown on the display of the oscilloscope, on one of the display pages.
5. Select "Web control".

The computer shows the instrument display. You see a live image of the instrument, and you can operate the instrument remotely.

To get comprehensive information on usage and functionality of the oscilloscope, open the instrument's help.

4.2 Information on the display

The GUI shows the waveforms and measurement results, and also information and everything that you need to control the measurements. All waveform-related GUI elements are explained in this section. An overview of control elements - like dialog, toolbar - is given in [Section 4.3, "Control elements on the GUI"](#), on page 49.



Figure 4-1: Information in the graphical user interface

- 1 = Diagram
- 2 = Layout
- 3 = Trigger position
- 4 = Toolbar
- 5 = Grid
- 6 = Trigger, horizontal and acquisition label
- 7 = Info
- 8 = Trigger level
- 9 = Menu
- 10 = Signal bar with signal activators (10a), and active waveforms (10b)
- 11 = Channel markers indicate the ground levels

Diagram

A diagram shows one or more waveforms: analog and digital channels, reference and math waveforms, tracks, and serial buses. Zoom details, spectrum and other special waveforms are shown in separate diagrams. One diagram can hold up to 16 analog waveforms, i.e. analog channels, reference and math waveforms, and tracks.

To arrange the diagrams on the screen, the Rohde & Schwarz SmartGrid function helps you to find the target place simply and quickly. For details, see [Section 4.9, "Rohde & Schwarz SmartGrid"](#), on page 69. You can also adjust the diagram size by dragging the diagram border.

Layout tab

A layout shows a set of diagrams and result tables. You can configure up to four layout tabs using the SmartGrid functionality. For details, see [Section 4.9, "Rohde & Schwarz SmartGrid"](#), on page 69.

Grid

The grid shows the vertical and horizontal divisions. The division lines are labeled with the correspondent values. The grid labels have the color of the waveform to which they belong. If several waveforms are shown in one diagram, the grid has the color of the selected waveform.

Trigger position and trigger level

The blue markers show the horizontal position of the trigger and the vertical trigger level. You can touch and move the trigger markers in the diagram to set the positions. The trigger point is the zero point of the diagram.

The trigger position can be moved outside the diagram.

Trigger

The "Trigger" label shows the main trigger settings. If you tap the label, the corresponding dialog opens.




Figure 4-2: Trigger label

- 1 = Trigger source
- 2 = Trigger type
- 3 = Trigger level
- 4 = Trigger mode
- 5 = Trigger state
- 6 = Trigger type specific settings
- 7 = Trigger slope

See also: [Section 7.1.1, "Trigger information"](#), on page 162.

Horizontal

The "Horizontal" label shows the main timebase settings. If you tap the label, the corresponding dialog opens.



Figure 4-3: Horizontal label

- 1 = Time scale
- 2 = Horizontal position

Acquisition

The "Acquisition" label shows the main acquisition settings, and the progress of long acquisitions. If you tap the label, the corresponding dialog opens.



Figure 4-4: Acquisition label

- 1 = Sample rate (before interpolation)
- 2 = Record length. A yellow warning icon indicates insufficient memory.
- 3 = Acquisition mode
- 4 = Number of acquired waveforms
- 5 = Resolution. Active high definition mode is indicated by "HD".

Info

The "Info" button on the toolbar points to the status messages and other information. To open the message box, tap the button.

See also: [Section 4.15, "Information and notifications"](#), on page 78.

Signal bar

The signal bar summarizes all waveforms as described in [Section 4.7, "Signal bar"](#), on page 66.

4.3 Control elements on the GUI

The GUI provides everything that you need for control, to analyze waveforms, and to get measurement results. [Figure 4-5](#) shows the control elements at a glance.



Figure 4-5: Control elements on the graphical user interface

- 1 = Toolbar
- 2 = Tab in a dialog
- 3 = Dialog
- 4 = Result table
- 5 = Signal bar
- 6 = Menu




Figure 4-6: Control elements on the graphical user interface

- 1 = Toolbar
- 2 = Tab in a dialog
- 3 = Dialog
- 4 = Result table
- 5 = Signal bar
- 6 = Menu

Toolbar (1)

The icons on the toolbar provide quick and easy access to the most important functionality. For a detailed description, refer to [Section 4.6, "Toolbar"](#), on page 61.

If you adjust the settings of an analyzing function, e.g., cursor measurement, the overlay menu is shown instead of the icons. The overlay menu provides the most important settings of the current action. If you need more settings, "Setup" opens the corresponding dialog.

Dialog (2, 3)

The tabs of the dialogs contain all task-oriented settings and operations, and buttons for calling related tabs. The usage of dialogs is described in [Section 4.11, "Using dialogs"](#), on page 73.

Result table (4)

If you perform cursor or automatic measurements, the result table shows the results of the action below the diagrams. You can move the result tables to the left or right of the diagrams.

See also: [Section 4.13, "Displaying results"](#), on page 76.

Signal bar (5)


The signal bar summarizes all waveforms as described in [Section 4.7, "Signal bar"](#), on page 66.

Menu (6)

The menu provides access to the complete functionality of the MXO 5C.

At the bottom of the menu, you find the "Keyboard" icon to open the on-screen keyboard. The "Power" icon shuts down the firmware.

At the top of the menu, you can find a search field for a quick access to any parameter you need. A list of all found results is shown on the left side of the menu. Tap the result entry and the dialog containing this parameter opens.



4.4 Keys and controls of the emulated front panel

If you control the oscilloscope using a LAN connection and the web browser, you can also use the keys and knobs on the emulated front panel.

1. Establish a web browser connection to the MXO 5C, see ["To access the GUI via LAN"](#) on page 46.

2. In the "Web control" view, activate "Front panel".

Now you can use the keys and knobs on the emulated front panel. Their functionality is described in the following sections.

4.4.1 Trigger controls

The keys and knob in the Trigger functional block adjust the trigger and start or stop acquisition.



[Run / Stop]

Starts and stops the continuous acquisition.

The [Run / Stop] key lights green when the acquisition is running. When the acquisition is stopped, the key lights red.

Remote command:

[RUN](#) on page 962

[STOP](#) on page 962

[Single]

Starts a defined number of acquisitions.

The [Single] key lights green when the acquisition is running. When the acquisition is stopped, the key lights red.

Press the key again to stop a running acquisition. To set the number of acquisitions, select "Menu" > "Acquisition", and set "N-single/avg count".

Remote command:

[SINGLE](#) on page 962

[Level]

The rotary knob sets the trigger level for all trigger types that require one level. For trigger types with two levels, the knob sets the lower level. Turn clockwise to move up the trigger level. Press the knob to set the trigger level to 50% of the signal amplitude.

Remote command:

`TRIGger:EVENT<ev>:LEVel<n>[:VALue]` on page 1007

[Auto Norm]

Toggles the trigger mode between "Auto" and "Normal". The current setting is shown on the trigger label.

Auto The instrument triggers repeatedly after a time interval if the trigger conditions are not fulfilled. If a real trigger occurs, it takes precedence. The time interval depends on the timebase.

Norm The instrument acquires a waveform only if a trigger occurs. The "Norm" indicator turns green.

Remote command:

`TRIGger:MODE` on page 1031

[Slope]

Toggles the trigger slope or trigger polarity, dependent on the trigger type. The current setting is shown on the trigger label.

[Source]

Toggles the trigger source: C1, C2, C3, etc. The key lights up in the color of the selected channel.

[Zone]

For future use.

4.4.2 Horizontal controls

The rotary knobs in the Horizontal functional block adjust the horizontal parameters. These settings are effective for all channel waveforms. In addition, a [Zoom] key is available.



[Position]

The rotary knob changes the horizontal position of the waveforms. Turn clockwise to move the waveforms to the right. To set the value to zero, press the knob. The current value is shown in the "Horizontal" label above the diagram.

The horizontal position defines the zero point of the diagram. It is the time distance to the reference point, which marks the rescaling center of the horizontal scale.

In a spectrum diagram, the knob changes the center frequency.

Remote command:

[TIMEbase:HORizontal:POSition](#) on page 964

[CALCulate:SPECTrum<sp>:FREQuency:CENTer](#) on page 1159

[Scale]

The rotary knob adjusts the horizontal scale for all signals. The horizontal scale is also known as timebase.

Turn clockwise to stretch the waveforms. Doing so, the scale value *time/div* decreases. Press the knob to toggle between coarse and fine scale adjustment.

In a spectrum diagram, the knob changes the span.

Remote command:

[TIMEbase:SCALE](#) on page 963

[CALCulate:SPECTrum<sp>:FREQuency:SPAN](#) on page 1160

[Zoom]

Activates a zoom and supports the zoom setup.

If no zoom is on, the first press opens a zoom diagram for the active diagram. If at least one zoom is shown, the keypress opens the "Zoom" dialog. If only one zoom is defined, the next press closes the dialog and removes the zoom. If several zooms are defined and the dialog is open, the key toggles the zooms.

4.4.3 Vertical controls

The keys and knobs in the Vertical functional block select a signal and adjust the vertical scale and position of the selected signal.



Figure 4-7: Vertical controls of MXO 5C with 4 input channels



Figure 4-8: Vertical controls of MXO 5C with 8 input channels

[C<n>]

Turns on and selects a channel. If the channel is active, the key lights up in the corresponding channel color.

The effect of the keypress depends on state of the channel:

- If channel is off: turns on the channel and selects it.
- If the channel is on and in focus (selected): opens the corresponding channel dialog.
- If the channel is on, but not in focus (not selected): selects the channel waveform.
- If the channel is selected, and the dialog is open: turns off the channel, and closes the dialog.

The vertical rotary knobs are focused on the selected waveform. They are illuminated in the color of the selected waveform.

Remote command:

[CHANnel<ch>:STATe](#) on page 972

[Position]

The vertical [Position] knob changes the vertical offset or the position of the selected waveform. The horizontal axis and the selected waveform are moved vertically. You can select whether the knob changes the offset or the position in the "Menu" > "Settings" > "Frontpanel" > "Knobs" dialog.

- Position indicates the vertical location in divisions.
- Offset moves the vertical center of the selected channel to the offset value.

If the selected waveform is a math or reference waveform, serial bus, or logic channel, the knob changes its vertical position.

The knob lights up in the color of the selected waveform. Turn clockwise to move up the waveform. To set the value to zero, press the knob.

The current offset value is shown in the channel icon.

Remote command:

[CHANnel<ch>:POSition](#) on page 973

[CHANnel<ch>:OFFSet](#) on page 973

[Scale]

Sets the vertical scale, which defines the displayed amplitude of the selected waveform.

The [Scale] knob lights up in the color of the selected waveform.

Turn the knob clockwise to stretch the waveform. Doing so, the scale value V/div decreases. Press the knob to toggle between fine and coarse adjustment. For analog waveforms, the scale value is shown in the signal icon.

To get the maximum resolution of the waveform amplitude, make sure that the waveforms cover most of the diagram's height.

Remote command:

[CHANnel<ch>:SCALE](#) on page 972

[CALCulate:MATH<m>:VERTical:SCALE\[:VALue\]](#) on page 1075

[REFCurve<rc>:SCALE](#) on page 1085

[Gen]

Available only for MXO 5C with 4 input channels.

Opens the "Waveform Generator" dialog, if option R&S MXO5C-B6 is installed.

The waveform generator can generate various function and arbitrary waveforms, sweeps, and parallel patterns. For detailed characteristics, refer to the specifications document.

[Logic]

Available only for MXO 5C with 4 input channels.

Opens the "Logic" dialog to configure and enable the logic buses L1 to L4. A logic bus (or parallel bus) has up to 16 logic (digital) channels. If logic buses are active, pressing the key toggles these buses.

The key lights up if at least one logic bus is enabled.

[Bus]

Available only for MXO 5C with 4 input channels.

Opens and closes the "Protocol" tab in the "Apps" dialog, where you can select the required serial protocol and proceed to the protocol setup. The key lights up if the decoding of a serial bus is active.

[FFT]

Available only for MXO 5C with 4 input channels.

Opens and closes the "Spectrum" dialog. The key lights up if a spectrum is active.

[Ref]

Opens the "Reference" dialog box, where you can configure and display reference waveforms. Press the key repeatedly to switch the reference waveform.

If a reference waveform is selected, the vertical rotary knobs are illuminated in white or light gray (default colors), depending on the selected waveform.

[Math]

Opens the "Math" dialog, where you can configure the calculation of mathematical waveforms using various mathematic operations on other waveforms. Press the key repeatedly to toggle the selected math waveform. If no math waveform is active, the key closes the dialog.

If a math waveform is selected, the vertical rotary knobs are illuminated in blue (default color).

4.4.4 Analysis keys

The controls in the bottom functional block have various functions.

**[Multiuse]**

The multiuse knob changes the element that is in focus. It lights up when a function is active on the knob.

- If a numeric entry field in a dialog has the focus: turn to increase or decrease the value. Press the knob to toggle fine and coarse increment.
- If a cursor set has the focus: press to toggle the cursor line, and turn to adjust its position.
- If a zoom has the focus: press to toggle the edges of the zoom, and turn to adjust its position.
- If a gate has the focus: press to toggle the complete gate and the edges of the gate, and turn to adjust its position.
- To change the intensity, press the [Intensity] key and turn the knob.

[Intensity]

Adjusts the intensity of the waveforms on the screen: Press the [Intensity] key and turn the [Multiuse] knob. The current value is shown in the input box in the upper right corner of the screen.

[Cursor]

Starts a cursor measurement: sets vertical and horizontal cursors in the active diagram, and displays results of the cursor measurement. If cursors are already set, the keypress opens the "Cursor" dialog, where you can adjust the settings. The next keypress closes the dialog.

Cursors are markers which are placed at points of interest on a waveform. The instrument measures the cursor positions and delta values between parallel cursors.

If cursors are already set but not in focus, pressing the key sets the focus on the cursor set. You can adjust the cursor lines using the [Multiuse] knob.

If a cursor set has the focus, the key opens the "Cursor" dialog. If one cursor set is "On", the next press closes the dialog. If several cursors are "On", pressing the key toggles the cursor sets.

[Measure]

Opens the "Measurement" dialog, where you can set up various measurements. If the dialog is open, pressing the key closes the dialog.

[History]

Activates the history and opens the history player. The next keypress closes the player. The history shows stored acquisitions that were acquired before the current one. The key is illuminated as long as the history is active.

[HD]

Activates the high definition mode and opens the "HD Mode" dialog box.

If the dialog is open, pressing the key closes the dialog. If the dialog is closed, the key disables the high definition mode. The key is illuminated as long as the HD mode is active.

[Touch Lock]

The [Touch Lock] has an effect on a connected monitor with touchscreen. It locks the touchscreen of the monitor to prevent unintended use. When the touchscreen is off, the key is illuminated. Press again to unlock the touchscreen.

If no monitor with touchscreen is connected, you can also activate or deactivate the touch lock. The setting takes effect when you connect a monitor with touchscreen.

**Camera **

Performs the action that is assigned to the key in "Settings" > "Front panel" > "Hard-keys". By default, the key saves a screenshot of the waveform display.

[Preset]

Resets the instrument to a predefined state and starts the continuous acquisition. All measurements, mask tests, zoom, and most individual settings are deleted, and all channels except for channel 1 are disabled.

You can define preset configurations and save them to a file. The [Preset] key can be configured to set either factory defaults or a user-defined preset configuration.

[Autoset]

The instrument analyzes the enabled channel signals, and adjusts appropriate horizontal, vertical, and trigger settings to display stable waveforms.

In particular, the horizontal scale is set to a common value for all active channels, record length and sample rate are set to automatic detection. Vertical scale and offset are set for each channel individually. Probe settings, channel coupling and impedance remain unchanged. The trigger source is set to the signal with the lowest frequency, and the trigger type to positive edge. The trigger level is adjusted, and the trigger position is set to the reference point. Measurements, math and spectrum waveforms are kept. Undo and redo of an autoset is possible.

[Clear]

Deletes all measurement results including long-term measurement and statistics, all waveforms, and the history.


Apps

Opens the "Apps" dialog, where you can start an application, serial protocol or another analysis function.

4.5 Applications

The "Apps" dialog provides fast access to all available applications, for example, to serial protocols, frequency response analysis or file browser.

- ▶ To open the "Apps" dialog:
 - Open "Menu" > "Apps".
 - Press the  [Apps] key on the front panel.



4.6 Toolbar

The toolbar provides direct access to important control and measurement functions.



By default, the toolbar shows the most frequently used functions. You can configure the content of the toolbar, see [Section 4.6.2, "Configuring the toolbar"](#), on page 62.

4.6.1 Using the toolbar

Using the toolbar is easy and straightforward.

Some of the toolbar functions are one-click actions. These actions are performed immediately when you tap the icon.

Other toolbar functions are analyzing functions. These actions are interactive actions.

To use analyzing functions (interactive actions)

1. Tap the icon of the function in the toolbar.
2. Check and adjust the settings in the overlay menu.
3. Select the source waveform if needed. For zoom, drag a rectangle, or tap the diagram to define the zoom area.
4. If the overlay menu does not close automatically, tap the  icon.

4.6.2 Configuring the toolbar

You can configure the content of the toolbar so that only the required functions are displayed.

The toolbar configuration is part of the user preferences. It is retained when you switch off and on the instrument, and you can save it in the user preferences and user-defined preset.

1. To open the toolbar configuration, tap the icon in the toolbar:



2. Select the required toolbar functions:
 - a) In the "Show/Hide tools" section, disable all functions that you do not need.
 - b) In the "Show/Hide tools" section, enable the functions that you want to add to the toolbar.
 - c) In the "Drag to rearrange tools" section, move the icons to arrange them as required.
3. To empty the toolbar, select "Deslect all".
4. To get the factory configuration of the toolbar, select "Restore default".

A detailed description of the toolbar functions is given in [Section 4.6.3, "Toolbar functions"](#), on page 63.

Remote commands:

- `DISPlay:TOOLBar:COUNT?` on page 934
- `DISPlay:TOOLBar:DESelect` on page 934
- `DISPlay:TOOLBar:REStore` on page 934

4.6.3 Toolbar functions

This section describes all toolbar functions.



You can configure the content of the toolbar, see [Section 4.6.2, "Configuring the toolbar"](#), on page 62.

Undo.....	63
Redo.....	64
Help.....	64
Recall.....	64
Save setup.....	64
Screenshot.....	64
Annotate.....	64
Clear.....	64
Autoset.....	64
Preset.....	65
Run / stop and Run single.....	65
Force trigger.....	65
Add zoom.....	65
Add cursor.....	65
Measure.....	65
Add mask.....	65
Histogram.....	65
Add gate.....	65
Edit spectrum.....	66
Save waveform.....	66
Add zone trigger.....	66
Delete.....	66
File browser.....	66
DVM.....	66
XY.....	66
Get signals.....	66
Image viewer.....	66
Gen1, Gen2.....	66



Undo

Undoes the last setting actions step by step. On a keyboard, you can use the shortcut [Ctrl]+[Z].

Some actions cannot be revoked: locking the touchscreen with [Touch Lock], and saving data.

The undo stack is deleted when reloading settings from file, and during reference waveform actions (save, load and preset with active reference waveform).

**Redo**

Recovers the undo steps in reverse order. On a keyboard, you can use the shortcut [Ctrl]+[Y].

**Help**

Enables the context help display. The help window opens when you tap a parameter.

See also: ["To display the context help"](#) on page 80.

**Recall**

Opens a window to select and load instrument settings that were previously stored in a saveset.

**Save setup**

Saves the current instrument settings in a saveset.

You can reload the saveset using the "Recall" toolbar icon, or using "Menu" > "Save/recall" > "Recall" tab > "Saveset".

The filename is created according to the autonaming pattern, defined in "Menu" > "Settings" > "Save / recall" > "Autonaming" tab.

**Screenshot**

Saves a screenshot of the current display using the settings defined in "Menu" > "Save/recall" > "Save" tab > "Screenshot".

**Annotate**

Displays drawing tools for marking areas on the diagram, and for adding text. You can also select the color.

See also: [Section 4.14, "Adding annotations"](#), on page 77.

**Clear**

Deletes all measurement results including all waveforms and statistics.

Remote command:

[DISPlay:CLR](#) on page 956

**Autoset**

Performs an autoset. The instrument analyzes the enabled channel signals, and adjusts appropriate horizontal, vertical, and trigger settings to display stable waveforms.

The icon has the same functionality as the corresponding key on the front panel. It is useful when you operate the instrument remotely.

**Preset**

Resets the instrument to a predefined state and starts the continuous acquisition. All measurements, mask tests, zoom, and most individual settings are deleted, and all channels except for channel 1 are disabled.

The icon has the same functionality as the corresponding key on the front panel. It is useful when you operate the instrument remotely.

**Run / stop and Run single**

Starts and stops the continuous acquisition, or starts a defined number of acquisition cycles. The icons have the same functionality as the corresponding keys on the front panel. They are useful when you operate the instrument remotely.

**Force trigger**

Starts an immediate single acquisition. If the acquisition is running in normal mode and no valid trigger occurs, use "Force trigger" to confirm that a signal is available. Then you can use the displayed waveform to determine how to trigger on it.

**Add zoom**

Adds a zoom diagram, an area of the acquired waveform which is visually enlarged. Click a diagram to create a zoom or draw a rectangle to define the range of the zoom.

**Add cursor**

Adds a cursor set. Select the cursor type and the source to be measured.

See also: [Section 10.1, "Cursor measurements"](#), on page 256.

**Measure**

Adds one or more measurements to the waveform.

Tap the icon, and select the category and the measurements in the overlay menu. Select the waveform to be measured, and close the overlay menu.

**Add mask**

Starts the on-screen mask definition and the testing against the defined mask.

Tap the icon and draw a rectangle for the first mask segment. Use the overlay menu to add more segments to the mask, to create more masks, and to edit mask segments on the display. You can also move the mask segments on the screen.

**Histogram**

Creates a histogram. Tapping the icon opens the overlay menu, where you select the histogram type. Tap a diagram, or drag a rectangle on the diagram to define the histogram window. The histogram for the selected waveform is created.

**Add gate**

Creates a new gate.

Tap the icon, and then tap the diagram or draw a rectangle to define the limits of the gate. The "Gate" dialog opens, where you can adjust the gate settings and add measurements to use the gate.

**Edit spectrum**

Edit the existing spectrum settings in the overlay menu.

**Save waveform**

Saves the selected waveform.

**Add zone trigger**

Defines a zone trigger, which combines the trigger condition with the intersection or non-intersection of one or more zones.

See also: [Section 7.9, "Zone trigger"](#), on page 197.

**Delete**

Removes waveforms, diagrams, zooms, trigger zones and other elements from the display.

Tap the "Delete" icon. A recycle bin icon marks all objects that can be deleted. Tap this icon to remove an object. Tap the "Delete" icon again to disable the function.

**File browser**

Opens the file browser dialog.

See: [Section 13.9, "File browser dialog"](#), on page 474.

**DVM**

Starts the digital voltmeter application.

See: [Section 12.5, "Digital voltmeter"](#), on page 428.

**XY**

Starts the XY-plot application.

See: [Section 12.6, "XY-plot"](#), on page 431.

**Get signals**

Imports the active analog channel waveforms from the connected oscilloscope.

See [Section 17.2, "ScopeSync"](#), on page 878.

**Image viewer**

Starts the screenshot viewer.

See: [Section 13.8.3, "Image viewer"](#), on page 474.

**Gen1, Gen2**

Turns on or off the waveform generator. For better visibility, a generator icon is darker than the other icons in the toolbar.

4.7 Signal bar

The signal bar is the control center for all waveforms. All enabled waveforms are shown on the left side of the signal bar. On the right side of the signal bar, you see the

signal activators of inactive waveforms and buses. On the right of the signal bar, you find signal activators for the waveform generator and ScopeSync connections.

When you tap a signal activator, the corresponding dialog opens. to enable the waveform. The signal activators for analog and digital channels and for math waveforms also activate the waveform.

Each waveform is represented by a signal icon. If the waveform is shown in a diagram, the signal icon displays its main settings. If you tap a signal icon, the dialog with settings for this waveform opens. If you tap the "Minimize" icon on the signal icon, the waveform switches from the diagram area to the signal icon: the icon is grayed out. See [Section 4.8, "Working with waveforms"](#), on page 67 for a detailed description.

In [Figure 4-1](#), the signal icons C1, C2 and C3 show the main settings, and the waveforms are displayed in diagrams.




Figure 4-9: Signal label of an active analog channel

- 1 = Vertical scale
- 2 = Offset
- 3 = Bandwidth
- 4 = Coupling and termination

If many waveforms are active, then waveforms of the same type are grouped in one signal icon. Tap the group icon to open the individual signal icons.

4.8 Working with waveforms

The MXO 5C can create and display many waveform types. The most important are:

- Channel waveforms:
For each analog input channel, one channel waveform is shown.
- Reference waveforms:
Reference waveforms can be used as reference for comparison and analysis.
- Math waveforms:
Mathematic waveforms can be created with mathematic operations performed on channel, reference, and other math waveforms.
- Zoom waveforms:
Zoom waveforms show the details of waveforms.
- Digital waveforms:
The Mixed Signal Option R&S MXO5C-B1 provides 16 digital channels grouped in two logic probes (pods) with 8 channels each.

Waveform handling

The MXO 5C can show and analyze many waveforms. To handle this multitude while keeping track of it, the MXO 5C provides intelligent support:

- The color system helps to distinguish the waveforms.
The color of the vertical rotary knobs indicates the signal that is focused (selected). The color of each waveform can be changed, the color of its signal icon and of the illuminated keys is adjusted to the new color. Alternatively, a color table can be assigned to a waveform.
Settings: "Menu" > "Settings" > "Appearance" > "Colors" tab.
- You can arrange the waveforms in one diagram, or in separate diagrams. The Rohde & Schwarz SmartGrid function helps to arrange the waveforms.
See also: ["Diagram"](#) on page 48.

Waveform states

Depending on its place on the screen and the effect of settings, a waveform has one of the following states:

- Off
- Active:
The waveform is shown in a diagram
- Selected:
One of the active waveforms that has the focus. In each diagram, one of the assigned waveforms is selected – it appears "on top" in the diagram, and the grid labels have the color of the selected waveform.
The vertical [Position] and the [Scale] knobs are illuminated with the color of the selected waveform.
- Minimized:
The waveform signal icon is greyed out, and the waveform is removed from the diagram.

To switch a waveform on

A channel waveform is activated when you connect the probe. You can switch it on and off according to your needs.

- ▶ Choose one of the following ways:
 - Press the channel key.
 - Select the signal activator in the signal bar.
 - In the "Vertical" dialog box, select the channel. Tap "Show channel" > "On".The waveform is now active, selected, and is shown in the diagram.

Remote command: [CHANnel<ch>:STATe](#) on page 972

To select a waveform

- ▶ Choose one of the following ways:
 - Tap the waveform in the waveform diagram.
 - Tap the signal icon.

- To select a channel, reference, or math waveform, press the corresponding key.

Note: Zoom waveforms in zoom diagrams cannot be selected.

To minimize a waveform

- ▶ Tap the "Minimize" icon in the upper right corner of the waveform's signal icon in the signal bar.

The waveform disappears from the diagram and the signal icon turns lighter gray.

- ▶ To set the waveform back to its previous diagram immediately, use "Undo".

To arrange a waveform using the SmartGrid

- ▶ See [Section 4.9, "Rohde & Schwarz SmartGrid"](#), on page 69.

To switch off a waveform

- ▶ Do one of the following:
 - Tap the "Delete" icon in the toolbar, and then signal icon of the waveform. You can also tap the waveform directly. If several waveforms overlap or lie close together, a selection list is shown.
 - To switch off a minimized waveform, tap the "Close" icon in the upper right corner of the signal icon.
 - If the waveform is an input channel:
 - Disable "Show channel" in the "Vertical" > "Setup" tab.
 - Select the channel. Then press its channel key twice.

Remote command: `CHANnel<ch>:STATe` on page 972

4.9 Rohde & Schwarz SmartGrid

The Rohde & Schwarz SmartGrid helps to create and arrange the diagrams on the screen with drag&drop. The diagram layout depends on the position where you drop the signal icon, in relation to an existing diagram.




Figure 4-10: SmartGrid positions

- 1 = In the existing diagram, overlay of signal
- 2 = New diagram on the left or right
- 3 = New diagram above or below

The diagram configuration is deleted when you use "Preset" or *RST.

To arrange a waveform using the SmartGrid

1. Select the layout that you want to rearrange.
2. Drag the signal icon to the diagram area, and move it around.
The Rohde & Schwarz SmartGrid appears and a blue or highlighted area shows where the waveform will be placed.




3. Drop the waveform in the target area.
The waveform appears in an existing or in a new diagram, and it is selected for further actions.
4. To change the size of a diagram, touch the border between two diagram frames and drag it to the required position.
5. If a diagram is empty, you see a trash can icon in the diagram center. Use the icon to delete the diagram, or drag waveform icons into the diagram.

Remote commands: see [Section 18.8.3, "SmartGrid"](#), on page 927.

Working with layouts

A SmartGrid configuration of one or more diagrams is called "tab" or "layout". You can define several layouts and switch between them.



- 1 = Tab 1 (layout 1, blue underline indicates that the set is currently displayed)
- 2 = Tab 2 (layout 2)
- 3 = Tap to remove a layout
- 4 = Tap to add a layout


You can add up to four layouts at the upper left corner of the screen:

1. Tap on the  icon next to the layout.
A new layout is created.
2. To change the layout name, touch and hold the tab name. The on-screen keyboard opens to enter the new name. Names must be unique.
3. To remove the layout, tap on the  next to the layouts title.

4.10 Using the selection menu

The selection menu, or comb menu, helps select objects on the screen if several objects are close beside. These objects are, for example, waveforms, zoom edges, gate limits, trigger zones and cursor lines. When you tap or click a point in a diagram, the firmware determines the objects around the point and provides an appropriate menu. Each found object is represented by a comb. The selection menu is created and arranged anew at each finger tap, there are no predefined positions for the objects.


Table 4-1: Selection menu icons

Symbol	Description
	Comb
	 : indicates that a submenu is available. If more than 6 objects are detected, related objects are grouped to submenus. Tap on the object group to display the submenu
	 : indicates that there are more than 6 objects that are available. In this case some of the objects are not directly displayed. Tap on one of the combs and rotate the selection to display all the choices.

To use the selection menu


1. Tap the screen at the point of interest.

The selection menu provides all objects that were found around the point. In the image below, the objects of "Cursor Cu1" and "Zoom Z1" are grouped in submenu.



2. Select the comb of the needed object, or object group.
3. If you have selected an object, the object gets the focus. Change its position directly on the screen or with the [Multiuse] knob, or perform other actions depending on the selected object.
4. If you have selected an object group, the submenu opens.

The image shows the submenu of "Zoom Z1".



5. In the submenu, select the comb of the needed object.
6. Modify the selected object as required.

4.11 Using dialogs

All functionality is provided in dialogs as known from computer programs. This section provides an overview of the accessing methods and describes how to use the dialogs.

Each dialog has icons in the upper right corner:

	Closes the dialog.
	Opens the help window for the dialog.
	Shift sideways to change the transparency of the dialog.



For direct access to important control and measurement functions, use the toolbar, see [Section 4.6, "Toolbar"](#), on page 61.

To open a dialog

- Perform one of the following actions:
 - Open the "Menu", and select the menu entry.
 - Press the function key on the front panel.
 - Double-tap a result to open the corresponding settings dialog.
 - To open the "Vertical" dialog of a waveform, tap the signal icon.
 - Tap the "Horizontal", "Acquisition" or "Trigger" label to open the corresponding dialog.

To close a dialog

- Tap the "Close" icon in the upper right corner.

4.12 Entering data

To set parameter values and enter other data, you use the various knobs and the on-screen keypad or keyboard.

To use scale, position and level knobs

The instrument has dedicated rotary knobs to set vertical and horizontal positions and scale, and the trigger level.

1. Turn the knob to change the value.
2. Press the knob:
 - [Scale]: to toggle the increment.
 - [Position]: to set to zero.
 - [Level]: to set the trigger level to 50% of the signal.


To enter values with the on-screen keypad

To enter numeric values and units in dialogs, an on-screen keypad is available.

1. Double-tap the entry field. The on-screen keypad opens.




2. Enter a numeric value using the following methods:
 - To use the default value, tap "Reset" (if available).
 - To get the value that was used before the keypad was displayed, tap "CE".
 - To use the minimum or maximum value, tap "Min" or "Max", respectively.
 - To increase the displayed value in fixed steps, tap "Inc".
To decrease the value in fixed steps, tap "Dec".
 - To enter a user-defined value, tap the numbers and complete the entry by tapping the unit button.
 - "+" changes the sign of the value.
 - To calculate a value, tap the calculator icon to display the arithmetic operators. Use the displayed fields to calculate your values.



3. To activate caps lock when you enter a text value, double-tap the shift key (up arrow key).
4. Tap to complete the entry.

To enable the on-screen keyboard

1. Tap "Menu".
2. Tap on "Keyboard" to enable the on-screen keyboard.



If the on-screen keyboard is enabled, the keyboard icon is colored blue. If it is disabled, the color is white.

To enter data with the on-screen keyboard

1. Double-tap the entry field to open the on-screen keyboard.



2. Enter the text as you would on a normal keyboard.
 - To change the language, tap . The current language is shown on the blank key.
 - To display numbers and signs, tap .
3. Tap to complete the entry or to minimize the keyboard.

4.13 Displaying results


The results of measurements, protocol decoding and others are displayed immediately. The font size can be adjusted.

To arrange the results on the display

1. Touch and hold the "....." field on top of the results table.



2. Drag on the screen. The SmartGrid indicates where the result table can be placed. Drop the box on one of the buttons. The results are shown at the left the right, or below the diagrams.



To open the corresponding settings

- Double-tap one of the result values.
The corresponding dialog opens.

To adjust the font size of results

1. Open the "Menu" > "Settings" > "Appearance" dialog.
2. Select the "Dialogs" tab.
3. Set the "Result dialog" > "Font size".

4.14 Adding annotations


The MXO 5C provides an easy way to add annotations to the screen. With the toolbar "Annotate" you can add text, forms or even draw.

To add an annotation

1. On the toolbar, tap on the "Annotate" icon.



The annotation overlay menu opens.



2. Tap "Color selection" and select the color that you want to use for your annotations.
3. Add one or more of the following:
 - One of the predefined forms: "Arrow" or "Rectangle"
 - "Text": adds a text element to the screen and opens on-screen keyboard. You can change the text later, by tapping on an existing annotation and typing in the new text.
 - "Draw": you can draw any form on the screen.



4. To move one of the annotations, tap on it and drag it to the required position.

To remove an annotation

1. In the "Annotate" overlay menu, tap on "Remove".
2. Tap on any existing "Arrow", "Rectangle" or "Text" annotation to remove it.
3. The "Remove" function, acts as an eraser on drawings: it enables you to erase only certain parts of your drawing. Drag your finger over any part of your drawing to erase it.
4. To remove all annotations from the screen, tap on "Remove all".

Remote commands: see [Section 18.8.5, "Annotations"](#), on page 934.

4.15 Information and notifications

The MXO 5C provides various information:

- Instrument information, e.g. connection status, firmware version
- Notifications, e.g. status messages, incompatible settings, insufficient memory
- Progress information, e.g. for long acquisitions, data saving

Instrument information

In the upper right corner of the screen, you see the Rohde & Schwarz logo, date and time, the symbolic information on LAN connection and the notifications status.



The connection status icon in the upper right corner indicates the status of the LAN connection.



- Green indicates that the instrument is connected to the LAN.
- Red indicates a connection error - mostly the LAN cable is not connected.

- Blinking indicates that the device indicator on the instrument's homepage is switched on, and a device identification command was sent.
- To see the instrument information, select the Rohde & Schwarz logo.
You can find information about the instrument model, bandwidth, network settings, firmware version and operating time.
- To hide the date and time or change the display format, select the date/time display.

Notifications

Notifications are status messages, information on mismatching settings, insufficient memory and similar information. They are displayed for a few seconds and saved.

- To read the notifications, select "Info".
You can delete the list of notifications.



Progress information

If an acquisition, operation or process takes more time until results are displayed, a progress bar or symbol indicates that a process is running.

The progress of saving operations and update or creation of a reference waveform is shown in a progress bar. You can cancel the process. A notification informs about the result.




Figure 4-11: Progress bar for saving waveform data

The progress of running acquisitions is shown in the acquisition label. A circle indicates the state of the current, incomplete acquisition. Progress in roll mode, average mode and single acquisition with $N > 1$ is indicated by a progress bar and counter.



Figure 4-12: Progress of incomplete long acquisition in average mode, Run single = 5, first acquisition is finished


4.16 Getting user assistance

If you need information on the functionality, you can use the integrated product help. It provides contextual information on a setting or dialog. If the help window is open, you can browse and search for further information using links, table of contents, and search.

4.16.1 Displaying help

To display the context help

1. Enable the "Help" icon on the toolbar.



2. Tap the parameter for which you need information.

The "Help" window opens and displays the comprehensive description and the corresponding remote command. You can browse the help for further information.

To open a dialog help

1. Open a dialog.
2. Tap the ⓘ "Help" icon in the dialog header.
3. Tap a subtab or menu item.

The help window opens with the dialog help page, where you can select the topics.


4.16.2 Using help

You can find a specific information and navigate the contents by following means:

- Table of contents
- Buttons in the help window title:



- "Home": Go to the start page
- "Back", "Forward": Browse the pages that you visited before
- Search with filter:




- Enter the word to be found, or a phrase in quotes.
- Tap the filter icon and select the information type.

5 Instrument setup

Access: "Menu" > "Settings".

In the "Settings" dialog, you can adapt various instrument settings to your requirements, such as language, display appearance, and assign functions to some keys.



The following settings and procedures are described in the current section:


• System settings	83
• Option settings	92
• Appearance settings	95
• Display settings	102
• Front panel settings	104
• Preset setup	106
• Maintenance settings	109
• Save / recall settings	114

5.1 System settings

In the "Settings" > "System" dialog box, you find all instrument, firmware and network-related information. Here you can also set the language that is used in the dialogs.

5.1.1 About settings

Access: "Menu" > "Settings" > "System" > "About".



Instrument

Displays general information about the instrument, including:

- "Material number"
- "Serial number"
- "Device ID"
- "Firmware version"

Remote command:

*[IDN?](#) on page 918

FW update

Opens the "FW update" dialog box. See [Section 5.7.1, "Firmware update"](#), on page 109.

Open source acknowledgment


Displays the "Open Source Acknowledgment" document.

LucasFonts EULA

Displays the copyright of the font provider.

5.1.2 Network settings

Access: "Menu" > "Settings" > "System" > "Network".

**Host name**

Indicates the currently defined host name. This value is required to configure the instrument for work in a network.

You can change the host name here. After changing the host name, you have to reboot the instrument.

NOTICE! Risk of network problems. Incorrect configuration of the host name can create network problems. Consult your network administrator before changing the name.

Remote command:

`SYSTEM:COMMunicate:NET[:HOSTname]` on page 924

Automatic IP (DHCP)


If enabled, the IP address of the oscilloscope is obtained automatically.

IP address

Shows the current IP address of the instrument. If "Automatic IP (DHCP)" is "Off", you can change the IP address here. For complete manual configuration, select "Advanced". See also: [Section 17.1, "Connecting the instrument to the network \(LAN\)"](#), on page 876.

Advanced

Opens a dialog box to configure the network connection.



You need these settings to configure the LAN connection manually, without DHCP.

NOTICE! Connection errors can affect the entire network. Make sure to assign valid address information before connecting the instrument to the LAN. Contact your network administrator to obtain a valid IP address and other connection data.

See also: [Section 17.1, "Connecting the instrument to the network \(LAN\)"](#), on page 876.

Web password

Password for LAN configuration. The default password is *LxiWebIfc*.

LXI LAN reset

Resets the LAN configuration to its default configuration. Use the reset when you cannot access the instrument via LAN due to invalid configuration.

You can initiate the reset also directly on the instrument. Press and hold the [Info] key for 5 seconds.

The LAN settings are configured in the "Advanced" dialog, or using the instrument's web browser (see [Section 17.3, "Web interface"](#), on page 889).

The LAN reset uses the LAN Configuration Initialize (LCI) reset mechanism for the instrument. According to the LXI standard, a LAN reset must set the following network parameters to a default state:

Parameter	Value
TCP/IP mode	DHCP + auto IP address
Dynamic DNS	Enabled
ICMP ping	Enabled
Password for LAN configuration	LxiWebIfc


LXI info

Opens a dialog with relevant LXI information. You can reload the information, for example, after changing connection data in the instrument's web browser.

For information on the LXI standard, refer to the LXI website at <https://www.lxistandard.org>.

LXI settings

Opens a dialog with important LXI settings. These settings are also available in the instrument's web browser.



Description desired ← LXI settings

Network description of the instrument.

VXI-11 Discovery ← LXI settings

Enables the automatic detection in a LAN via the VXI-11 discovery protocol and programming by IVI drivers.

ICMP ping IPv4, ICMP ping IPv6 ← LXI settings

Enables the ping utility to verify the connection between the LXI-compliant instrument and another device. Ping is useful for diagnosing IP network or router failures. The ping utility is not password-protected.

HiSLIP port ← LXI settings

Sets the port that is used by the High Speed LAN Instrument Protocol (HiSLIP).

5.1.3 Network drive mapping

You can map up to 8 network drives or shared folders to the MXO 5C and store the measurement data directly in one of these folders.

Requirements:

- The MXO 5C and the target folder must be in the same network. Connection is established via DHCP. Direct connection is not supported.
- You need administrative rights and credentials to access the folder.
- Make sure that the network connection is not restricted by security settings.


5.1.3.1 Connecting a network drive

1. Open "Menu" > "Settings" > "System" > "Network drives".
2. Select "+ Add".
3. Tap the "Empty" button.
4. Enter the "Local folder" on the MXO 5C, the "Network folder", and access credentials. For details, see [Section 5.1.3.2, "Network drive settings"](#), on page 87.
5. Tap "Connect".

If you want to connect a folder on your personal computer, share this folder and give full permissions to all users before you connect the folder to the MXO 5C: Folder properties > "Sharing" > "Advanced Sharing".

5.1.3.2 Network drive settings

Access: "Menu" > "Settings" > "System" > "Network drives" > "+ Add" > select drive



Local folder

Set the local folder on the MXO 5C, to which the network folder is mapped. Under this name, you find the connected folder in the file browser on the instrument and in the "File manager" of the web interface.

Remote command:

[MMEMory:NDRive<m>:LPATh](#) on page 926

Network folder

Sets the network folder that is mapped to the local folder. Use the full path in UNC syntax, for example, `\\net1\data\team1\osc`.

Remote command:

[MMEMory:NDRive<m>:NPATh](#) on page 926

User name, Password

Enter the user name and the password to access the network folder.

Remote command:

[MMEMory:NDRive<m>:UNAME](#) on page 927

[MMEMory:NDRive<m>:PWORd](#) on page 927

Connect, Disconnect, Connection state

Connect or disconnects the remote network folder to the local folder. An "Info" message informs on success or failure, and the overall connection state is shown in the dialog.


Remote command:

[MMEMory:NDRive<m>:CONNect](#) on page 926

[MMEMory:NDRive<m>:DCONnect](#) on page 926

5.1.4 Remote settings

Access: "Menu" > "Settings" > "System" > "Remote".



The following settings are required for remote control and data transfer via a connected computer.

Transfer data format

Selects the data format that is used for transmission of waveform data from the MXO 5C to the controlling computer.

If you need physical data (e.g. in Volt or Ampere) for further analysis, use the floating point formats for export. No data conversion is needed.

"Ascii"	Data values are returned in ASCII format as a list of comma-separated values in floating point format.
"FLOAT"	Binary format. Up to 7 significant digits are stored (32 bit). If there are more than 7 digits, the number is rounded off.
"DOUBLE"	Binary format. Up to 15 significant digits of the numbers (64 bit) are stored.
"INT8/16/32"	Signed integer data with length 8/16/ 32 bit.

Remote command:

[FORMat \[:DATA\]](#) on page 921

Bit pattern format


Sets the format for all bit pattern queries.

Remote command:

[FORMat:BPATtern](#) on page 922

5.1.5 Localization settings

Access: "Menu" > "Settings" > "System" > "Localization".




Language

Selects the language in which the menu, dialogs, results and other screen information is displayed. You can change the language on runtime.

Available languages are, for example, English, German, French, Japanese. For a complete list of supported languages, refer to the specifications document.

5.1.6 Date and time settings

Access: "Menu" > "Settings" > "System" > "Date/time".



The instrument uses the system time of the operating system, but you can change date and time for the MXO 5C firmware.

1. To change the date:
 - a) Tap the date button.
 - b) Select the date in the calendar.
 - c) Tap the blue calendar icon to close the calendar.
2. To change the time, move the hour, minute and second sliders to the required values.
3. Adjust the "Region" and "City" to indicate your location.
4. Tap "Apply".

Remote command:

- [SYSTem:DATE](#) on page 924
- [SYSTem:TIME](#) on page 925

5.2 Option settings

Additional options for the MXO 5C are enabled using a license key. To obtain the license key, consult your sales representative.

You can obtain registered or unregistered licenses.




Unregistered licenses

Unregistered licenses are not assigned to a particular instrument. The instrument accepts only registered licenses. If your license is delivered unregistered, use the online tool [R&S License Manager](#) to register the license for your instrument. The registration of a permanent license is irreversible, so ensure that you register it for the correct instrument. For registration, you need the device ID of the instrument on which the option will be installed.

5.2.1 Software options settings


Access: "Settings" > "Options" > "Software"



In this dialog, you can access settings for installing and deactivating options. In the "Detailed info" dialog, you can get an overview of all options installed on your MXO 5C.

5.2.1.1 Install options

Access: "Settings" > "Options" > "Software" > "Install"



In the "Install" tab, you can install new options using license keys.

Enter new option key

Enter the license key here to activate the option. For license keys delivered as a file, use ["Install from file"](#) on page 94.

Install from file

If you got a license file, install the license here.

Tap "Open" to open the file selection dialog, or enter the complete path and filename.

5.2.1.2 Deactivate options

Access: "Settings" > "Options" > "Software" > "Deactivate"

To deactivate an option, use the "Deactivate" dialog. When you deactivate, note the response key, or save the response to a file. Registered options cannot be deactivated, they are bound to the instrument.

5.2.1.3 Detailed info

In the "Detailed info" dialog, you can get an overview of all options installed on your MXO 5C with status and expire information.

Software options: Info

Active	Short desc.	Description	State	Privilege	Valid from	Valid to	Expires ...
Deactivat...	B2415	1.5 GHz Ba...	Official	Customer order	P...		
	B6	Arbitrary W...	Official	Customer order	P...		
	B108	800 Mpts ...	Official	Customer order	P...		
	K36	Frequency ...	Official	Customer order	P...		
	K31	Power Anal...	Official	Customer order	P...		
	K500	Bus Analysis	Official	Customer order	P...		
	K510	Low Speed ...	Official	Customer order	P...		
	K520	Automotive...	Official	Customer order	P...		
	K530	Aerospace ...	Official	Customer order	P...		
	K550	MIPI Low S...	Official	Customer order	P...		
	K560	Automotive...	Official	Customer order	P...		

Back

5.3 Appearance settings


In the "Settings" > "Appearance" dialog box, you define the look and feel of the display element, e.g. waveform colors, result position, or grid behavior.

Appearance settings are not included in user-defined presets. To reset all appearance settings at once, use the factory preset.

5.3.1 Colors

Access: "Settings" > "Appearance" > "Colors"

By default, various colors are assigned to the different waveform types for better visibility and distinguishability. You can change the color assignment and assign another color or a color table to waveforms. For digital channels, you can select any color, or use the default color with state coloring.

**Category**

Selects the category of the waveform, e.g. "Channels", "Math", "Reference".

You can then select one of the waveforms of the selected category with "Color source".

Color source

Selects the waveform to which the color or the color table is assigned.

Use color table

If enabled, the selected waveform is displayed according to its assigned color table.

If disabled, the selected color is displayed, and the intensity of the signal color varies according to the cumulative occurrence of the values.

The setting is not available for digital channels and parallel buses.

Remote command:

[DISPlay:COLor:SIGNal:USE](#) on page 948

Assigned color table

Assigns a color table to the source waveform instead of a dedicated color. Color tables define the color of the waveform pixels depending on the cumulative occurrence of the associated values.

The following color tables are provided:

- "False colors": color changes gradually in a wide color spectrum.
- "Single Event": single events and seldom events appear yellow, a higher cumulative occurrence is shown with blue color. This view helps to identify specific events.
- "Spectrum": colors display the wavelengths of the light. Low cumulative occurrence is displayed blue like high wavelength.
- "Temperature": color changes gradually from blue (low temperature) to red (high temperature) with increasing cumulative occurrence.


Remote command:

[DISPlay:COLor:SIGNal:ASSign](#) on page 947

Color

Shows the current color of the selected waveform. To change the color, tap the button.

In the "Color" dialog, you can pick from a list of basic colors. To define another color, select "User defined colors", and adjust the color settings.



The color of the waveform, its signal icon, and the illuminated keys are adjusted to the new color. If the waveform is a spectrum, the knobs for vertical scale and position retain the color of the spectrum's source.

Remote command:

`DISPlay:COLor:SIGNal:COLor` on page 947

Set to default color

Resets the color of the selected waveform to the factory default.

Remote command:

`DISPlay:COLor:SIGNal:COLor <Signal>,DEF`

Use state coloring

The setting is available for digital channels and logic buses.

If enabled, the high and low levels and the state transition get different predefined colors.

If disabled, you can select a color for the digital channel or bus. The channel is displayed with the selected color, and the high level has a thicker line than the low level.





Figure 5-1: D0 has a selected color (blue). D1 and D2 have state coloring. D1 is on low level, D2 changes from low to high.

5.3.2 Grid

Access: "Settings" > "Appearance" > "Grid"



Show grid

If selected, a grid is displayed in the diagram area. A grid helps you associate a specific data point to its exact value on the x- or y-axis.

Remote command:

[DISPlay:DIAGram:GRID](#) on page 951

Show labels


If selected, labels mark values on the x- and y-axes in specified intervals in the diagram.

Remote command:

[DISPlay:DIAGram:LABels](#) on page 951

Show fine grid scale

If selected, the crosshair is displayed as a ruler with scale markers. If disabled, the crosshair is shown as dashed lines.



Remote command:

[DISPlay:DIAGram:FINegrid](#) on page 951

Show crosshair

If selected, a crosshair is displayed in the diagram area. A crosshair allows you to select a specific data point by its coordinates.

Remote command:

[DISPlay:DIAGram:CROSshair](#) on page 951

Keep X-grid fixed

If enabled, the vertical grid lines remain in their position when the horizontal position is changed. Only the values at the grid lines are adapted.

Remote command:

[DISPlay:DIAGram:XFIXed](#) on page 952

Keep Y-grid fixed

If enabled, the horizontal grid lines remain in their position when the position of the curve is changed. Only the values at the grid lines are adapted.

Fixed horizontal grid lines correspond to the behavior of traditional oscilloscopes.

Remote command:

[DISPlay:DIAGram:YFIXed](#) on page 952

Show div label (x)


If selected, the time scale value is shown at the diagram bottom instead of the horizontal grid labels. For example, 10 ns/div is shown instead of the values 0, 10, 20, 30... ns.

Remote command:

[DISPlay:DIAGram:XPDivlabel](#) on page 952

5.3.3 Dialogs

Access: "Settings" > "Appearance" > "Dialogs"



Font size (Dialog)

Sets the font size of the text in dialog boxes.

Remote command:

[DISPlay:DIALog:FONTsize](#) on page 953

Transparency (Dialog)

Sets the transparency of the dialog box background. For high transparency values, you can see the waveform display in the background, and possibly check the effect of the changed setting. For lower transparency values, readability in the dialog box improves.

You can also set the dialog transparency by moving the transparency bar at the top of the dialog.



Remote command:

[DISPlay:DIALog:TRANsparency](#) on page 953

Font size (Result dialog)


Sets the font size of the text in result tables.

Remote command:

[DISPlay:RESult:FONTsize](#) on page 953

5.3.4 Peak list

Access: "Settings" > "Appearance" > "Peak list"



Peak list settings apply to peak list measurements. They are visible when the peak list for spectrum measurements is enabled.

Frame type


Defines the layout of the labels, full border or none.

Remote command:

[CALCulate:SPECTrum<sp>:PLIST:LABEL:BORe](#) on page 953


5.3.5 Miscellaneous

Access: "Settings" > "Appearance" > "Misc"



Clock style

Select how the clock in the upper right corner of the screen is displayed:




- "Show seconds": format is hh:mm:ss
- "Hide seconds": format is hh:mm
- "Hide clock": no time is shown

5.4 Display settings

In the "Settings" > "Display" dialog, you can define the display settings like brightness and signal intensity.

5.4.1 Persistence settings

Access: "Menu" > "Settings" > "Display" > "Persistence".

**Enable**

If enabled, each new data point in the diagram area remains on the screen for the duration that is defined using [Time](#), or as long as [Infinite persistence](#) is enabled.

If disabled, the waveform points are displayed only for the current acquisition.

Remote command:

[DISPlay:PERStence\[:STATe\]](#) on page 955

Infinite persistence

If infinite persistence is enabled, each new waveform point remains on the screen until this option is disabled. Use infinite persistence to display rare events in the signal.

Remote command:

[DISPlay:PERsistence:INFinite](#) on page 954

Time

Sets a time factor that controls how long the waveforms points fade away from the display. Thus, the MXO 5C emulates the persistence of analog phosphor screens.

Remote command:

[DISPlay:PERsistence:TIME](#) on page 954

Reset


Resets the display, removing all persistent waveform points.

Remote command:

[DISPlay:PERsistence:RESet](#) on page 954

5.4.2 Signal settings

Access: "Menu" > "Settings" > "Display" > "Signal".



Intensity

The intensity determines the strength of the waveform line in the diagram. Enter a percentage between 0 (not visible) and 100% (strong). The default value is 50%.

You can also use the [Intensity] knob to adjust the waveform intensity directly.

Remote command:

[DISPlay:INTensity](#) on page 955

Waveform style

Selects the style in which the waveform is displayed.


- "Vectors" The individual waveform points are connected by a line.
Define the strength of the line using the [Intensity] knob.
- "Dots" Only the individual waveform points are displayed.
To see the dots of one waveform, perform one acquisition with [Single] and N=1 ([N-single/avg count](#)). During continuous acquisition, or a [Single] acquisition with N > 1, the dots of multiple subsequent waveforms are displayed on the screen, and the waveform looks like a line.

Remote command:

[DISPlay:DIAGram:STYLe](#) on page 955

5.4.3 Backlight settings

Access: "Menu" > "Settings" > "Display" > "Backlight".



Brightness

Sets the background luminosity of the touchscreen.

Remote command:

[DISPlay:BACKlight\[:BRIGtness\]](#) on page 956

Dimm on user inactivity

Selects a time, after which the monitor brightness is reduced, if the instrument was inactive. Remote control of the instrument is also considered as an activity.

Remote command:


[DISPlay:BACKlight:DIMMING](#) on page 956

5.5 Front panel settings

In the "Front panel" dialog box, you can assign functions to keys and knobs and adjust the brightness of the keys.

5.5.1 Hardkeys: function assignment

Access: "Settings" > "Front panel" > "Hardkeys"



Camera hardkey action

The Camera key on the bottom right is a shortcut key that initiates an associated action.

You can assign one of the following actions:


- Save screenshot
- Open screenshot setup

Configure the settings for the selected action.

- Screenshots: "Save/recall" key > "Save" tab > "Screenshot", see [Section 13.8, "Screenshots"](#), on page 469.

5.5.2 Knobs

Access: "Settings" > "Front panel" > "Knobs"




Vertical

The vertical Position knob can change the waveform position or the offset of the selected waveform. Select the action that you want to perform.

See also: "[[Position](#)]" on page 57.

5.5.3 LED

Access: "Settings" > "Front panel" > "LED".

**Brightness**

Defines the luminosity of illuminated front panel keys and knobs.


5.6 Preset setup

The preset sets the MXO 5C to a default configuration, or to a user-defined configuration. A user-defined preset file is one of the saveset files, which are stored locally. It contains the measurement setup, while the user's display settings are not included. You can save the current configuration to a preset file, and enable the saved preset file to be applied with the "Preset" toolbar icon.

See also: [Section 13.3, "General and measurement settings: savesets"](#), on page 441.

5.6.1 Preset settings

Access: "Menu" > "Settings" > "Preset" > "Settings".



Preset

Set the MXO 5C to a default configuration, or to a user-defined configuration.

Enable user-defined preset

If enabled, the settings from the selected saveset are restored when the [Preset] key is pressed.

If disabled, [Preset] sets the instrument to the factory defaults.

Remote command:

[USERdefined:PRESet\[:ENABLE\]](#) on page 960

Preset file selection

Select the saveset file that contains the required settings.

<Directory>	Shows the currently used directory. To change the directory, tap the button and select the correct directory in the file dialog.
"Preset file name"	Enter the filename of the preset file. This file is loaded on user-defined preset. The filename is also used when you save a preset file with "Save".
"File extension"	The file extension is .set.

Remote command:

[USERdefined:PRESet:NAME](#) on page 959

[USERdefined:PRESet:OPEN](#) on page 959

Save, Open

"Save" writes the current settings immediately to the file that is named in "Preset file name" in the selected directory. "Open" loads a saveset file as preset settings.

Remote command:

[USERdefined:PRESet:SAVE](#) on page 959

[USERdefined:PRESet:OPEN](#) on page 959

5.6.2 Factory preset

Access: "Menu" > "Settings" > "Preset" > "Factory".

Factory preset

Resets the MXO 5C to the factory default settings, to the initial state. Factory settings comprise all instrument settings.

Remote command:

[SYSTem:PRESet](#) on page 925

5.6.3 Restoring settings

When you have changed many settings, and you are not sure which settings are causing which effect, you can restore the default settings and start anew. The following methods are available:

- Saving the settings as a user-defined preset and rest the settings to user-defined default values
- Restoring all settings on the MXO 5C to the factory-defined values
- Loading settings from a file

To save a user-defined preset

1. Open the "Menu" > "Settings" > "Preset" tab.
2. Enter a name for the preset file. Select the file format.
3. Tap "Save preset file".

Note: If you want to store the file in another directory than the displayed one, select "Save as". See also: [Section 13.9, "File browser dialog"](#), on page 474.

To rest the settings to user-defined default values

1. Open the "Menu" > "Settings" > "Preset" > "Settings" tab.
2. In "Preset file name", enter the name of the file that contains the required settings.
3. To use these settings as preset values, select "Enable user-defined preset".
4. Tap "Preset".

To preset the instrument whenever needed, press the [Preset] key.

To restore all settings to the factory defaults

1. Open the "Menu" > "Settings" > "Preset" > "Factory" tab.
2. Tap the "Factory preset" button.

All settings on the MXO 5C are reset to their factory-defined values.

As long as no user-defined preset file is loaded and "Enable user-defined preset" is disabled, the preset also resets the settings to factory defaults.

5.7 Maintenance settings

In the "Settings" > "Maintenance" dialog box, you can update the firmware, perform self-alignment.

5.7.1 Firmware update

Access: "Menu" > "Settings" > "Maintenance" > "FW update".

Your instrument is delivered with the latest firmware version. Firmware updates are provided on the internet at:

The "Release Notes" describe the improvements and modifications of all firmware versions. They also explain how to update the firmware. They are available along with the firmware on the same web page.

Remote commands:


- `SYSTem:FW:FILEpath` on page 924
- `SYSTem:FW:START` on page 925

5.7.2 Alignment

When data from several input channels is displayed at the same time, it can be necessary to align the data. Alignment is done vertically or horizontally to synchronize the time bases or amplitudes and positions. Perform an alignment, for example, when strong temperature changes occur ($> 5^{\circ}$).

5.7.2.1 Alignment settings

Access: "Menu" > "Settings" > "Maintenance" > "Alignment"

**Start alignment**

Starts the self-alignment procedure for all channels.

Date, Time, Overall alignment state

Show the date, time and the summary result of the self-alignment process: not aligned, passed or failed. Detailed results are provided on the "Alignment results" tab.

Remote command:

[CALibration:DATE?](#) on page 960


[CALibration:TIME?](#) on page 961

[CALibration:RESult?](#) on page 961

Show results

Opens a dialog to display the alignment results.

For each channel, the results of the individual alignment steps are shown for all technical channel component. In case you require support, you may be asked to provide this information.



Alignment results	
Name	Result
C1	Init
C2	Init
C3	Init
C4	Init
C5	Init
C6	Init
C7	Init
C8	Init
Logic 1	Init
Logic 2	Init
Ext trig	Init

5.7.2.2 Performing a self-alignment

The self-alignment aligns the data from several input channels vertically and horizontally to synchronize the timebases, amplitudes and positions. The self-alignment process includes a basic hardware check.


Recommendation on performing the self-alignment:

- When putting the instrument into operation for the first time
 - After a firmware update
 - Once a week
 - When major temperature changes occur ($> 5^{\circ}$)
1. Warm up the instrument before you start the self-alignment. The minimum warm-up time is indicated in the specifications document.
 2. Remove the probes from the input connectors.
 3. Open "Menu" > "Settings" > "Maintenance".
 4. In the "Alignment" tab, tap "Start alignment".

The alignment is performed, the process can take several minutes. A message box informs you about the running process, wait until this message box closes. The overall pass/fail result is shown in the "Overall alignment state" field.

5.7.3 Power management

Access: "Menu" > "Settings" > "Maintenance" > "Power mgmt."



Auto power up

If enabled, the instrument powers up automatically when it is connected to the mains voltage, and after a power outage. If disabled, the instrument also powers up after a power outage if it was running when the power outage occurred.


Remote command:

[SYSTem:APUP](#) on page 961

5.7.4 Self-test

The instrument's selftest checks the hardware for correct operation. Perform the self-test if you suspect problems in hardware operation.

Access: "Settings" > "Maintenance"> "Selftest"



The selftest can take several minutes. The summary result is shown in the "Selftest results" field, and the results of the single tests are shown in the "Result" column of the test table.

Run tests

Starts the selftest.

Remote command:

[*TST?](#) on page 920

Selftest results


Shows the summary result of the self-test: pass or fail.

Test table

The table shows the available tests and their particular tests results. This can be helpful in case you need support.

5.7.5 Service

Access: "Menu" > "Settings" > "Maintenance" > "Service"

**Create report**

Creates a service report.

The service report is a ZIP file with a complete bug report, all relevant setup information, reporting and log files, alignment files, and the instrument configuration.

If a USB flash drive is connected, the report is saved on the USB flash drive. Otherwise, the report is saved in the user data folder `/home/storage/userData`.

See also: [Section 19.4, "Information for technical support"](#), on page 1898.

Remote command:


[SERVice:REPort](#) on page 961

5.8 Save / recall settings

5.8.1 Autonoming

Access: "Menu" > "Settings" > "Save/recall" > "Autonoming" tab.

5.8.1.1 Autonoming settings



In the "Autonoming" tab, you can define the pattern for automatic filename generation. This name is used as the default filename. The default path is the storage location for all saved files and their subdirectories. The local directory for user data is /home/storage/userData, the path to a USB storage device is /run/media/usb/<MyDriveName>/.

User text

If enabled, inserts the specified user text after the prefix.

Remote command:

[MMEMory:AUTonoming:USERtext](#) on page 958

[MMEMory:AUTonoming:TEXT](#) on page 959

File name

If enabled, inserts the default filename. The filename indicates the type of data that is saved, for example, RefCurve.

Remote command:

[MMEMory:AUTonaming:PREFix](#) on page 957

Date/time

If enabled, the current date and time are inserted in the filename pattern.

Remote command:

[MMEMory:AUTonaming:TIME](#) on page 957

Index

If enabled, inserts an index.

Remote command:

[MMEMory:AUTonaming:INDEX](#) on page 957

Enable autosave

Enables the automatic saving. A saveset is generated and saved in a given interval that you define with "Autosave interval". If you switch off the instrument, the last saved settings are recovered.

Remote command:

[MMEMory:AUSave:ENABLE](#) on page 957

[MMEMory:AUSave:INTERval](#) on page 958

Default path for all file operations

Defines the path that is displayed in the file selection dialog box for loading and storing operations. Locally, all user data is written to `/home/storage/userData`. You can create subfolders in this folder.

If a USB storage device is connected, the path is automatically changed to the USB path `/run/media/usb/<MyDriveName>/`.

To switch the directory quickly, double-tap the path button. Use the symbols on the left of the file explorer box to change the directory.

Remote command:

[MMEMory:AUTonaming:DEFAULTpath](#) on page 958

Reset path

Resets the default file path to the factory default.

Remote command:

[MMEMory:AUTonaming:RESPath](#) on page 958

[MMEMory:AUTonaming:RESall](#) on page 958

5.8.1.2 Defining default file paths and names

When a save or load operation is performed, a default filename and path is provided. You can configure which path is used, and how the filename is generated. In the file selection dialog box, you can change the folder and name as desired.

To define the default file path

1. Tap "Menu" > "Settings".
2. Select the "Save/recall" tab.
3. Select the "Autonaming" tab.
4. Double-tap the path button.
The directory selection dialog box is opened.
5. Select the folder in which the data is stored by default. Use the symbols on the left of the file explorer box to switch to often used directories.
Alternatively, you can tap the "Default path for all file operations" field and type the path.
6. To restore the factory-set default path, tap "Reset" next to the path field.

To define the automatic filename pattern

The automatic filename pattern can consist of the following elements:

<FileName>_<UserText>_<Date>_<Index>_<Time>

The prefix depends on the data type to be stored and cannot be changed by the user. The other elements can be enabled or disabled as required.

1. Tap "Menu" > "Settings".
2. Select the "Save/recall" tab.
3. Select the "Autonaming" tab.
4. If you want to exclude the "File name", "Date/time" or an "Index" (serial number), disable the corresponding option.
5. To insert a user-defined text after the prefix, enable "User text". Enter the text in the edit field.

The specified elements are used to generate the default filename for the next storage operation.

5.8.2 CSV export

Access: "Menu" > "Settings" > "Save/recall" > "CSV export" tab.

Currently, there are no active settings in this dialog.

6 Acquisition and waveform setup

6.1 Horizontal setup


The "Horizontal" dialog provides the timebase configuration for channel and spectrum waveforms.

6.1.1 About the horizontal system

Horizontal settings, also known as timebase settings, adjust the waveforms in horizontal direction.

Typically, the trigger is the determining point of the waveform record. In many scenarios, you want to analyze the waveform some time before or after the trigger. To adjust the horizontal acquisition window to the waveform section of interest, you can use the following parameters:

- The **horizontal position** defines the time distance of the trigger point (the zero point of the diagram) to the reference point. Changing the horizontal position, you can move the trigger point, even outside the screen.
- The **reference point** is the rescaling center of the time scale on the screen. If you modify the time scale, the reference point remains fixed on the screen, and the scale is stretched or compressed to both sides of the reference point.



Unlike vertical settings, which are waveform-specific, the horizontal settings apply to all active waveforms.


Timebase settings are interdependent:

$$\text{Timebase range} = \text{Time scale} * \text{Number of divisions}$$

The number of divisions is 10, which is the only constant parameter.

6.1.2 Horizontal Setup settings

Access: "Menu" > "Horizontal" > "Setup" tab, or tap the "Horizontal" label above the diagram.



Time scale

Sets the horizontal scale, the time per division, for all waveforms in the time domain, for example, channel and math waveforms.

Increase the scale to see a longer time interval of the waveform. Decrease the scale to see it in more detail. The scale has a point that remains fixed on the screen when the scale value is changing: the reference point.

Remote command:

[TIMEbase:SCALE](#) on page 963

Timebase range

Sets the time of one acquisition, which is the time across the 10 divisions of the diagram: *Acquisition time = Time scale * 10 divisions*.

Changing the acquisition time changes the time scale, too.

For long timebases, the acquisition progress is shown in the acquisition label.

Remote command:

[TIMEbase:RANGe](#) on page 963

Position

Defines the time distance between the reference point and the trigger point, which is the zero point of the diagram. The horizontal position is also known as trigger offset.

If you want to see a section of the waveform some time before or after the trigger, enter this time as horizontal position. The requested waveform section is shown around the reference point. Use positive values to see waveform sections after the trigger - the waveform and the diagram origin move to the left.

Remote command:

[TIMEbase:HORizontal:POSition](#) on page 964

Reference point

Sets the position of the reference point in % of the screen. It defines which part of the waveform is shown.

The reference point marks the rescaling center of the time scale on the screen. If you modify the time scale, the reference point remains fixed on the screen, and the scale is stretched or compressed to both sides of the reference point. If the "Position" is 0, the trigger point is on the reference point.

The reference point is not marked in the diagram.

Remote command:


`TIMEbase:REference` on page 964

6.1.3 Zoom settings

The zoom settings are described in [Section 9.1, "Zoom"](#), on page 219.

6.1.4 Roll mode

Access: "Menu" > "Horizontal" > "Roll" tab.



In this dialog, you can define the behavior of the roll mode.

Roll mode and acquisition setup

The settings "SR mode" and "RL mode" can affect the display of the waveform display in roll mode if these settings are set to "Manual". The resulting acquisition time is centered on the screen center.

If the acquisition time (*record length / sample rate*) is longer than the timebase range, the roll mode starts invisibly, outside the right screen edge. The data appears with some delay.


If the acquisition time is shorter than the timebase range, there is a gap from the right screen edge to the beginning of the data. If "SR mode" and "RL mode" are set to "Auto", the instrument optimizes the acquisition settings.

Roll mode settings

Progress bar	120
Mode	120
Start roll time	120
Off screen capture	121

Progress bar

The "Roll" progress bar in the "Acquisition" label shows how the record length is filled. The bar turns green when all samples are acquired, and the record is filled.



Left = incomplete roll waveform

Middle = roll completed with "Off screen capture" = Off

Right = roll completed with "Off screen capture" = On

Mode

Selects, if the roll mode is started automatically by the instrument or if it is turned off.

In roll mode, the instrument shows the waveforms immediately, without waiting for the complete acquisition of the waveform record. If the timebase is slow - at long time scale values - the roll mode saves time waiting for the waveform display. The instrument displays the newly acquired waveform points at the right edge of the display and moves the waveform to the left.

The roll mode has the following restrictions:

- Roll mode disables persistence.
- Event actions are not possible.

The instrument activates the roll mode automatically if the following conditions are fulfilled:

- "Timebase range" exceeds the defined "Start roll time".
- "Acquisition mode" is set to "Sample" or "Peak detect".
- Actual sample rate $\leq 0.05 \cdot$ sample rate of the instrument, i.e. ≤ 250 Msample/s or 125 Msample/s depending on the number of active channels.
- "N-single/avg count" = 1.
- Fast segmentation is disabled.
- Event actions are disabled.
- All serial buses are disabled.
- All mask tests are disabled.

Measurement statistics evaluate the currently displayed waveform. Therefore, "Measure all events" is enabled automatically in roll mode.

See also: ["Roll mode and acquisition setup"](#) on page 119.

Remote command:

[TIMEbase:ROLL:ENABLE](#) on page 964

[TIMEbase:ROLL:STATE?](#) on page 966

Start roll time

Sets the minimum acquisition time for the automatic start of the roll mode.

The instrument activates the roll mode automatically if the "Timebase range" exceeds the value of the "Start roll time".

Remote command:

[TIMEbase:ROLL:MTIME](#) on page 965

Off screen capture

If enabled, the analyzable waveform in roll mode is extended. You can run the roll mode, stop the acquisition after some time, and analyze the data that is on the display and in the invisible area on the left.

If "Off screen capture" = Off, the analyzable record length is the value that is set in the "Acquisition" > "Setup" tab. The record length determines the length of the displayed waveform.

If "Off screen capture" = On, the whole acquisition memory can be used. After the defined record length is filled, more data is recorded at the left of the completed record length until you stop the acquisition or the acquisition memory is filled.

The current number of recorded data points is shown in the progress bar when the bar is green, or returned by the remote command [ACQUIRE:ROLLmode:POINTS?](#). See also: "Roll mode and acquisition setup" on page 119.

The "Roll" progress bar in the "Acquisition" label shows how the record length is filled.

After stopping the acquisition, you can analyze the complete roll waveform, including the invisible part:

- Increase the "Time scale" to see a longer part of the waveform.
- Scroll the waveform: tap and drag the waveform to the right.

If you want to save the waveform, disable "Off screen capture". When the needed data is displayed, save the waveform. Thus, one record length is saved. With active "Off screen capture", the amount of data cannot be limited.

Remote command:


[ACQUIRE:ROLLmode:OSCapture](#) on page 965

[ACQUIRE:ROLLmode:POINTS?](#) on page 965

6.1.5 Reference clock

Access: "Menu" > "Horizontal" > "Setup" tab > "Ref clock"

The oven-controlled crystal oscillator (OCXO) produces a 10 MHz internal reference signal with precise and stable frequency. You can output this clock signal for synchronization of other instruments. Conversely, you can also use an external 10 MHz reference signal. The input and output connectors for reference signals are on the rear panel of the instrument.

**Ref. osc. source**

Selects the source of the reference clock: internal 10 MHz reference signal of the OCXO, or an external 10 MHz reference signal..

Remote command:

[SENSe\[:ROSCillator\]:SOURce](#) on page 1005

Output 10 MHz ref. signal

Sends the internal reference clock signal to the Ref Out 10MHz connector.

If "Ref. osc. source" is set to extern, the external reference signal is output instead of the internal clock.

Remote command:

[SENSe\[:ROSCillator\]:OUTPut\[:ENABle\]](#) on page 1005

6.2 Acquisition


Access: "Menu" > "Acquisition".

Acquisition settings define the processing of the captured samples in the instrument.

6.2.1 About the acquisition system

Sampling and processing

The A/D converter samples the continuous signal under test at specific points in time and captures digital values. The converter is working at a constant rate specified in GHz.



The captured values are processed according to the acquisition settings. The result is a waveform record that contains **waveform samples** and is stored in the **waveform memory**. The waveform samples are displayed on the screen and build up the waveform.

The number of waveform samples in one waveform record is called **record length**. The rate of recording waveform samples - the number of waveform samples per second - is the **sample rate**. The higher the sample rate, the better the resolution is and the more details of the waveform are visible.

$$\text{Sample rate} = 1 / \text{Resolution}$$

The sample rate can be the same as the constant rate of the A/D converter, or higher, or lower. To get a higher sample rate, interpolation is used. Several interpolation methods are available. Other processing methods reduce the sample rate, or build the resulting waveform from several consecutive acquisitions of the signal. These methods are called acquisition modes.

Minimum sample rate and aliasing

A sufficient resolution is essential for correct reconstruction of the waveform. If the signal is undersampled, aliasing occurs - a false waveform is displayed. To avoid aliasing and accurately reconstruct a signal, the sample rate must be at least 3 to 5 times the fastest frequency component of the signal. A higher sample rate increases signal fidelity, increases the chance to capture glitches and other signal anomalies, and improves the zoom-in capabilities.

Interleaving

The MXO 5C with **8 channels** achieves its highest sample rate of 5 Gsample/s by interleaving channels by twos. Interleaving assumes that only one of the paired channels is used. If the second channel of a pair is used (on display, or as trigger source, math source, or measurement source), the interleaving mode is disabled. Without interleaving, the channels work with 2.5 Gsample/s and reduced bandwidth.

The interleaved channels of an 8-channel oscilloscope are:

- C1 and C5
- C2 and C6
- C3 and C7
- C4 and C8

The **4-channel** MXO 5C is always in interleaving mode, and all 4 channels work with 5 Gsample/s and maximum bandwidth.

6.2.2 Acquisition setup

Access: "Menu" > "Acquisition" > "Setup" tab.




Figure 6-1: Acquisition settings: automatic sample rate and record length




Figure 6-2: Acquisition settings: manual sample rate and record length

Run/stop

Starts and stops the continuous acquisition.

The [Run / Stop] key lights green when the acquisition is running. When the acquisition is stopped, the key lights red.

As a remote action in a ScopeSync setup, "Run/stop" starts a continuous acquisition on both connected scopes, or stops the acquisition. With active ScopeSync, continuous acquisition is a series of single acquisitions: after each trigger, the acquired waveforms of selected channels are transferred to scope 1. Only waveforms that are based on the identical trigger event are shown simultaneously on scope 1. When you stop the acquisition, the ongoing waveform import is completed.

The Run / Stop key and the "Run / stop" tool adapt their function if ScopeSync is active.

Remote command:

[RUN](#) on page 962

[STOP](#) on page 962

Run single

Starts a defined number of acquisitions.

The [Single] key lights green when the acquisition is running. When the acquisition is stopped, the key lights red.

To set the number of acquisitions, set "N-single/avg count" in the "Acquisition" setup. The acquisition progress is shown in the acquisition label, see ["Progress information"](#) on page 79.

As a remote action in a ScopeSync setup, "Run single" starts a single acquisition on both connected scopes. It is a real single acquisition, the "N-single/avg count" setting is ignored.

The Single key and the "Run single" tool adapt their function if ScopeSync is active.

Remote command:

[SINGLe](#) on page 962

SR mode

Defines how the sample rate is set.

The sample rate considers the samples of the ADC, and the processing of the captured samples including interpolation.

"Auto" Sample rate is determined automatically and changes due to instrument internal adjustments due to other setting changes. You can set a minimum sample rate with [Min. sample rate](#).

"Manual" The sample rate is manually defined with [Sample rate](#).

Remote command:

[ACQuire:SRATe:MODE](#) on page 970

Min. sample rate

Sets the minimum value of the sample rate for calculation in automatic sample rate mode. It is the sample rate of the processed waveform record including interpolation.

Remote command:

[ACQuire:SRATe:MINimum](#) on page 970

Sample rate

Sets the number of waveform points per second in manual sample rate mode. It is the sample rate of the processed waveform record including interpolation.

The sample rate in the dialog differs from the sample rate that is shown in the acquisition label above the diagram. The value in the acquisition label shows the sample rate of the acquisition itself, before interpolation. It is the ADC sample rate or an integer decimated value of the ADC sample rate, which allows you to estimate whether the signal was sufficiently sampled in the acquisition.

If interpolation is used to reach the defined value, it is indicated by "Sample rate (IT)" in the dialog.

Remote command:

[ACQuire:SRATe\[:VALue\]](#) on page 970

RL mode

Selects the mode of the waveform record length adjustment.

The record length is the number of waveform samples that are stored in one waveform record after processing, including interpolation. It determines the length of the displayed waveform.

"Auto" Record length is determined automatically and changes due to instrument internal adjustments due to other setting changes. You can set a maximum record length with [Record length limit](#).

"Manual" The waveform record length is manually defined with [Record length](#).

Remote command:

[ACQUIRE:POINTS:MODE](#) on page 968

Record length limit

Sets the maximum value of the record length for calculation in automatic record length mode.

Remote command:

[ACQUIRE:POINTS:MAXIMUM](#) on page 968

Record length

Sets the record length in manual record length mode.

If the record length value is too high in combination with other settings and activated features, the memory is not sufficient to process the data. In this case, a warning information is shown in the dialog.

Remote command:

[ACQUIRE:POINTS\[:VALUE\]](#) on page 968

[ACQUIRE:POMEMORY?](#) on page 969

N-single/avg count

The acquisition and average count has several effects:

- It sets the number of waveforms acquired with "Run single".
- It defines the number of waveforms used to calculate the average waveform. Thus, the instrument acquires sufficient waveforms to calculate the correct average if "Average" is enabled for waveform arithmetic. The higher the value is, the better the noise is reduced.
- It sets the number of acquisitions to be acquired in a fast-segmentation acquisition series, and in the history.
- It is the "Finished" criteria for a mask test.

The setting is read-only if "Segmented" > "Acquire maximum" is "On". See also ["Acquire maximum"](#) on page 130.

Remote command:

[ACQUIRE:COUNT](#) on page 967

Resolution

Shows the current resolution.

The resolution is the time between two waveform samples in the waveform record. It considers the processing of the captured samples including interpolation. A fine resolution with low values produces a more precise waveform record. The resolution is the reciprocal of the sample rate.

If interpolation is used to reach the defined value, it is indicated by "Resolution (IT)" in the dialog.

Remote command:

[ACQUIRE:RESOLUTION?](#) on page 969

Acquisition mode

Sets how the waveform is built from the captured samples.

"Sample"	Usually, most signals are displayed optimally with this acquisition mode but very short glitches can remain undiscovered by this method.
"Peak detect"	The minimum and the maximum of n samples are recorded as waveform points, the other samples are discarded. Thus the instrument can detect fast signal peaks at slow time scale settings that would be missed with other acquisition modes.
"Envelope"	Each acquisition is done in peak detection mode, and the minimum and maximum values in a sample interval over some consecutive acquisitions build the envelope. The resulting diagram shows two envelope waveforms: the minimums (floor) and maximums (roof).
"Average"	The average is calculated from the data of the current acquisition and a specific number of consecutive acquisitions before. The method reduces random noise. It requires a stable, triggered and repetitive signal. The number of acquisitions for average calculation is defined with N-single/avg count. If the waveform is clipped, the instrument shows a distorted average waveform to indicate the clipping. Adjust the vertical scale to avoid the clipping. The acquisition progress is shown in the acquisition label.

Remote command:

[ACQUIRE:TYPE](#) on page 971

Current average count

Shows the current number of acquired waveforms that contribute to the average, for [Acquisition mode](#) = "Average".

Remote command:

[ACQUIRE:AVERage?](#) on page 967

Interpolation

Selects the interpolation method.

If the defined sample rate ("Sample rate") is higher than the ADC sample rate, interpolation adds points between the captured samples of the waveform by various mathematical methods. All captured and interpolated points are used in measurements, and they are included in exports. If interpolation of samples is active, it is indicated by "Sample rate (IT)" and "Resolution (IT)".

"Linear"	Two adjacent ADC sample points are connected by a straight line, the interpolated points are located on the line. You see a polygonal waveform similar to the real signal, and also the ADC sample points as vertexes.
"sin (x)/x"	Two adjacent ADC sample points are connected by a sin(x)/x curve, and also the adjoining sample points are considered by this curve. The interpolated points are located on the resulting curve. This interpolation method is precise and shows the best signal curve.
"Sample/Hold"	The ADC sample points are displayed like a histogram. For each sample interval, the voltage is taken from the sample point and considered as constant, and the intervals are connected with vertical lines. Thus, you see the discrete values of the ADC - the measured samples.

Visual interpolation of the waveforms and zoom waveforms on the display is independent of the calculated sample interpolation, and it is not indicated.

Remote command:


[ACquire:INTerpolate](#) on page 967

6.2.3 Segmentation settings

Access: "Menu" > "Acquisition" > "Segmented" tab.

You can acquire a limited number of segments, or the maximum number.

In the R&S ScopeStudio software, acquisition settings and functions that need an acquisition take effect if the channel source is a simulated waveform, created by the generator. If the channel source is loaded from a file, the acquisition-related settings can be imported with the data from the oscilloscope, either as a saveset, or included in a session. Changing imported acquisition-related settings has no effect.



Acquire maximum

The setting takes effect for N-single acquisitions ("Run single"). During continuous acquisition ("Run / stop"), the history is used completely.

If "On", "Segments (N-single)" is set to the maximum number of available segments. Thus, the history is filled completely with an N-single acquisition. "Segments (N-single)" is read-only, you cannot change the value. The number of available segments depends on current the number of active channels, sample rate, record length, and other settings.

If "Off", set the number of segments in "Segments (N-single)", which is the same setting as "N-single/avg count" on the "Setup" tab. Thus you can acquire a fast segmentation acquisition series and history of defined length with "Run single".

You can stop the running acquisition before the series is completed.

The number of acquired waveforms is shown in the "History" dialog, when the history is active.

Remote command:

[ACQUIRE:SEGMENTED:MAX](#) on page 1002

Fast segmentation

If fast segmentation is enabled, the acquisitions are performed as fast as possible, without processing and displaying the waveforms. When acquisition has been stopped, the data is processed and the latest waveform is displayed. Older waveforms are stored in segments. You can display and analyze the segments using the history.

Remote command:

[ACQUIRE:SEGMENTED:STATe](#) on page 1002

Segments (N-single)

See "[N-single/avg count](#)" on page 127.

Max available

Shows the maximum number of segments that can be captured with current sample rate and record length settings.

6.2.4 High definition mode

The high definition mode increases the numeric resolution of the waveform signal by using digital filtering, leading to reduced noise. The higher vertical resolution reduces quantization noise and acquires waveforms of higher accuracy with finer details of the signal to be seen. The high definition is also applied to the digital trigger, thus the MXO 5C can trigger with the same high resolution with which they can display signals.

The maximum numeric resolution in high definition mode is 18 bit. The actual value depends on the selected bandwidth. Increasing the bandwidth reduces the resulting digital resolution. For dependencies and details, refer to the MXO 5C specifications.

The number of vertical resolution bits defines the number of vertical levels that the acquisition samples are mapped to (quantization). For example, 16 bits of resolution represent 65536 voltage quantization levels, while 8 bits of resolution represent only

256 voltage levels. The waveform values are recorded with a word length of 16 bit, except for peak detect decimation.

6.2.4.1 High definition settings

Access: "Menu" > "Acquisition" > "HD" tab.



High definition is a special acquisition mode of the oscilloscope. This mode has only two settings - the filter bandwidth and the filter type.

State

Enables high definition mode, which increases the numeric resolution of the waveform signal.

Remote command:

[HDEFinition:STATE](#) on page 1003

Bandwidth

Sets the filter bandwidth for the high definition mode.

Increasing the bandwidth reduces the resulting digital resolution. For dependencies and details, refer to MXO 5C specifications.

Remote command:

[HDEFinition:BWIDth](#) on page 1003

Filter characteristics

Selects the filter that is used to reduce the bandwidth:

"Gaussian"	Gaussian filter
"Bessel"	Bessel-Thomson filter, which has maximally flat group delay. It preserves the waveform shape of signals. Bessel filters are preferred in applications requiring high fidelity and timing accuracy.
"Brickwall"	Rectangular filter with full transmission in the pass band and complete attenuation in the stop band.

Resolution in bits

Displays the resulting vertical resolution in high definition mode. The higher the filter bandwidth, the lower the resolution.

Remote command:

[HDEFinition:RESolution?](#) on page 1003

6.2.5 History settings

The history settings are described in [Section 9.3.2, "History setup"](#), on page 236.

6.2.6 Speed

Access: "Menu" > "Acquisition" > "Speed" tab.



The "Speed" dialog shows information on the current acquisition performance values of the MXO 5C.

You can see the number of "Acquisitions per second", "Average blind time" and the "Percentage of time captured".

6.3 Vertical setup

The controls and parameters of the vertical system adjust the vertical scale and position of the waveform, and the waveform display. The probe settings also belong to the vertical setup.

The signal icons at the bottom of the display show the most important actual settings for each channel.

The signal icon also indicates if the incoming data is clipped before processing, i.e. the input range of the ADC is exceeded.

There are several ways to adjust vertical settings:

- Use the "Vertical" dialog to adjust all vertical settings. See:

- [Section 6.3.2, "Vertical Setup settings"](#), on page 133
- [Section 6.3.3, "Bandwidth settings"](#), on page 136
- [Section 6.4, "Probes"](#), on page 138
- [Section 6.3.5, "Other vertical settings"](#), on page 137
- On the touchscreen, you can adjust the vertical settings directly on the screen:
 - Drag one finger vertically on the screen to change the position of the selected channel waveform.
 - Spread or pinch two fingers in vertical direction to change the vertical scale of the selected waveform.

6.3.1 About the vertical system

The controls and parameters of the vertical system are used to scale and position the waveform vertically.

Vertical scale and resolution

Vertical scale and vertical position directly affect the resolution of the waveform amplitude. The vertical scale corresponds to the ADC input range. To get the full resolution of the ADC, set up the waveforms to cover most of the height of the diagram.

With an MXO 5C, you work with multiple diagrams, and each diagram obtains the full vertical resolution, no matter where the diagram is placed. Therefore, use a separate diagram for each waveform instead of the traditional setup that arranges the waveforms side by side in one diagram.

Bandwidth

For analog applications, the highest signal frequency determines the required oscilloscope bandwidth. The oscilloscope bandwidth should be higher than the maximum frequency included in the analog test signal to measure the amplitude with very little measurement error. To avoid aliasing, the oscilloscope bandwidth should be at least 3 times higher than the maximum frequency included in the signal.


Most test signals are more complex than a simple sine wave and include several spectral components. A digital signal, for example, is built up of several odd harmonics. For digital signals, the oscilloscope bandwidth should be at least 5 times higher than the clock frequency to be measured.

The oscilloscope is not a stand-alone system. You need a probe to measure the signal of interest, and the probe has a limited bandwidth, too. The combination of oscilloscope and probe creates a system bandwidth. To reduce the effect of the probe on the system bandwidth, the probe bandwidth should exceed the bandwidth of the oscilloscope, the recommended factor is 1.5 x oscilloscope bandwidth.

6.3.2 Vertical Setup settings

Access: "Menu" > "Vertical" > "Setup" tab

The "Setup" tab provides all basic vertical settings. The channels are listed in horizontal subtabs. Make sure to select the correct channel tab before you enter the settings.



Show channel

Switches the selected channel signal on or off.

The signal icon opens on the signal bar. The waveform of the last acquisition is displayed in the diagram.

Remote command:

[CHANnel<ch>:STATe](#) on page 972

Signal flow (graphical button)

Opens a dialog that shows the signal flow as currently configured. In addition, the main settings are shown for information.

Vertical scale

Sets the vertical scale, which defines the displayed amplitude of the selected waveform.

The unit depends on the connected probe.

The current value is shown in the signal icon. Vertical scale directly affects the resolution of the waveform amplitude. To get the best resolution of the ADC, set the waveforms to cover most of the height of the diagram.

Remote command:

[CHANnel<ch>:SCALe](#) on page 972

Offset

Sets the offset voltage, which corrects an offset-affected signal. The vertical center of the selected channel is shifted by the offset value and the signal is repositioned within the diagram.

To set the offset automatically, use [Autoset]. The current value is shown in the signal icon.

Use the offset to measure small AC voltages that are overlaid by higher DC voltages. Unlike AC coupling, the DC part of the signal is not lost with offset setting.

If an active probe is connected, the offset limit is defined by the probe. Refer to the documentation of the probe for allowed values.

If a Rohde & Schwarz differential probe is connected, the "Offset" is the common-mode offset. Set the common-mode offset to compensate for a common DC voltage applied to both input sockets (referenced to the ground socket). Thus, you can measure on differential signals with high common mode levels. You can measure the common mode input voltage using the R&S ProbeMeter.

Remote command:

[CHANnel<ch>:OFFSet](#) on page 973

Position

Moves the selected signal up or down in the diagram. While the offset sets a voltage, position is a graphical setting given in divisions. The visual effect is the same as for offset.

Remote command:

[CHANnel<ch>:POSition](#) on page 973

Coupling

Sets the filter for the input signal. The coupling determines what part of the signal is used for waveform analysis and triggering.

The selected coupling is shown in the signal icon.

"DC" Passes both DC and AC components of the signal.

"AC" Connection through DC capacitor, removes DC and very low-frequency components. AC coupling is useful if the DC component of a signal is of no interest. The waveform is centered on zero volts. AC coupling is available with termination 1 M Ω .

If AC coupling is set, the attenuation of passive probes has no effect, and voltage is applied to the instrument with factor 1:1. Observe the voltage limits, otherwise you can damage the instrument.

Remote command:

[CHANnel<ch>:COUpling](#) on page 974

Termination

Selects the input impedance of the channel input according to the connected probe.

Connection with 50 Ω termination is used to connect, for example, active probes. Connection with 1 M Ω termination is used to connect standard passive probes.

Remote command:

[CHANnel<ch>:COUPling](#) on page 974

Invert channel

Turns the inversion of the signal amplitude on or off. To invert means to reflect the voltage values of all signal components against the ground level.

Inversion is indicated in the signal icon by a line above the channel name.

If the inverted channel is the trigger source, the instrument triggers on the inverted signal. You can use inversion, for example, to switch the polarity of a differential signal without changing the probe connections.

Remote command:

[CHANnel<ch>:INVert](#) on page 974

Label

Defines a label text. The label is shown on the signal icon. Characters and label length are not restricted.

Remote command:

[DISPlay:SIGNal:LABel](#) on page 974

Skew

Sets a skew value to compensate for the delay of the measurement setup or from the circuit specifics that the instrument cannot compensate automatically. It affects only the selected input channel.

Delay differences between channels are caused by the different length of cables, probes, and other sources. Correct deskew values are important for accurate triggering. Signals that are routed over lines with different lengths have a different propagation delay. This delay can lead to a non-synchronous waveform display.


Remote command:

[CHANnel<ch>:SKEW:TIME](#) on page 975

6.3.3 Bandwidth settings

Access: "Menu" > "Vertical" > "Bandwidth" tab

The "Bandwidth" tab provides all settings that affect the bandwidth of the measurement system. The channels are listed in horizontal subtabs. Make sure to select the correct channel tab before you enter the settings.



Bandwidth

Sets the bandwidth limit. The specified bandwidth indicates the range of frequencies that the instrument can acquire and display accurately with less than 3 dB attenuation. Frequencies above the limit are removed from the signal, and noise is reduced.

The selected bandwidth is shown on the signal icon.

For basic information, see also: ["Bandwidth"](#) on page 133.

"Full" At full bandwidth, all frequencies in the instrument's frequency range are acquired and displayed. Full bandwidth is used for most applications. However, at full bandwidth, the displayed bandwidth can be less than the instrument bandwidth depending on the connected probe, the number of active channels and other settings.

"xx MHz" Frequencies above the selected limit are removed to reduce noise.

Remote command:

[CHANnel<ch>:BANDwidth](#) on page 975

Probe type, Probe bandwidth

Shows the type of the connected probe and its bandwidth. The probe is recognized automatically, or selected in the "Probe" tab. See [Section 6.4.1, "Common probe settings"](#), on page 139.

Effective bandwidth


Shows the effective bandwidth of probe and oscilloscope system.

6.3.4 Probe settings

See [Section 6.4, "Probes"](#), on page 138.

6.3.5 Other vertical settings

Access: "Menu" > "Vertical" > "Other" tab



External Attenuation: Scale, Attenuation

Consider a voltage divider that is part of the DUT before the measuring point. The external attenuation is included in the measurement, and the instrument shows the results that would be measured before the divider. External attenuation can be used with all probes.

"Scale" Select linear or logarithmic attenuation scale.

"Attenuation" Enter the attenuation of the voltage divider according to the selected scale. The conversion from linear to logarithmic values depends on the "Vertical unit" of the probe:
 For voltage-based unit (V and A):
 $attenuation (dB) = 20 * \log_{10}(attenuation factor)$
 For power-based unit (W):
 $attenuation (dB) = 10 * \log_{10}(attenuation factor)$

Remote command:

[CHANnel<ch>:EATScale](#) on page 976

[CHANnel<ch>:EATTenuation](#) on page 976

Impedance

Sets the impedance of the connected probe for power calculations and measurements. The value is used, for example, for scale calculation in the spectrum diagram.

Remote command:

[CHANnel<ch>:IMPedance](#) on page 977

6.4 Probes

With MXO oscilloscopes, you can use various probe types. Mostly these probes are passive and active voltage probes. The instrument can detect many probes and read out the probe-specific parameters, for example, bandwidth and attenuation.

You find all settings that are relevant for the connected probe in the "Vertical" > "Probe" tab. The settings on the "Probe" tab change according to the type of the attached


probe. Probes with Rohde & Schwarz probe interface (probe box), and also many other passive voltage probes, are recognized by the instrument. The oscilloscope reads out the main characteristics of the probe and displays them. Other probes cannot be detected, but their characteristics are known to the instrument. These known probes are called "Predefined probes". Probes that are not recognized automatically and not predefined are unknown probes, they require manual setting of measurement unit and attenuation.

The complete characteristic of the connected probe is shown on the "Vertical" > "Probe Info" tab.

6.4.1 Common probe settings

Access: "Menu" > "Vertical" > "Probe" tab

Most the settings in the "Probe" tab are available for all probes. For some probe types, additional settings are needed. These settings are described in the sections for the individual probe types.



An external attenuation can be set on the "Other" tab, see [Section 6.3.5, "Other vertical settings"](#), on page 137.

The common probe settings are:

Predefined probe, Type and Name of the probe	139
Probe bandwidth	140
Offset	140
Vertical unit	140
Attenuation	140
Set offset to mean	140
AutoZero, Use AutoZero	141

Predefined probe, Type and Name of the probe

The model name and type of a detected probe are shown in the dialog.

If the instrument cannot recognize the probe, "None" is indicated in the "Type" and "Predefined probe" lists. Select the used probe "Type", and then the used model in "Predefined probe". The corresponding bandwidth, and attenuation or gain are shown.

If the probe is not detected and not listed as predefined probe, it is an unknown probe. To configure these probes, set "Type" to "User defined". Then select the attenuation or gain in "Predefined probe". You can also adjust the [Vertical unit](#) and [Attenuation](#) separately.

Remote command:

[PROBe<ch>:SETup:NAME?](#) on page 981

[PROBe<ch>:SETup:TYPE?](#) on page 982

[PROBe<ch>:SETup:STATe?](#) on page 982

[PROBe<ch>:SETup:ATTenuation:DEFProbe](#) on page 979

Probe bandwidth

Shows the bandwidth of the connected probe. For probes that are not detected or predefined, set the bandwidth manually.

Remote command:

[PROBe<ch>:SETup:BANDwidth?](#) on page 980

Offset

Channel offset that is also set on "Vertical" > "Setup" tab. See ["Offset"](#) on page 135.

Vertical unit

Shows the unit of the connected probe if the probe is detected or predefined. For unknown probes, select the unit that the probe can measure.

Remote command:

[PROBe<ch>:SETup:ATTenuation:UNIT](#) on page 980

Attenuation

Shows the attenuation of the connected probe if the probe is detected or predefined. If the probe is unknown to the instrument, set the correct attenuation of the probe in "Manual attenuation".

The vertical scaling and measured values are multiplied by this factor so that the displayed values are equal to the actual measured signal values.

Make sure to set the attenuation factor on the instrument according to the probe being used. Otherwise, the measurement results do not reflect the actual voltage level, and you might misjudge the actual risk.

Remote command:

[PROBe<ch>:SETup:ATTenuation\[:AUTO\]?](#) on page 978

[PROBe<ch>:SETup:ATTenuation:MANual](#) on page 978

Set offset to mean

Compensates automatically for a DC component of the input signal using the result of a background mean measurement.

The result is shown in "Offset". The function is probe-independent and supports quick and convenient measurements of input signals with different DC offsets. It detects offset values even when the signal is out of the current measurement range. It also sets the zero level to the determined DC offset in the middle of the screen and thus prevents clipping of the waveform.

Remote command:

`PROBe<ch>:SETup:OFFSet:TOMean` on page 980

AutoZero, Use AutoZero

Voltage probes can have a zero error. The zero error is the voltage appearing at the probe output when nothing is connected to the probe. If a zero error occurs, it results in an external offset and the waveform is not displayed around 0 V.

To correct the zero error of voltage probes, short the signal pin and the ground pin together. Then select "AutoZero". While the alignment is running, the instrument switches to DC coupling to display the waveform correctly.

To correct the zero error, enable "Use AutoZero".

If a current probe is connected, the function demagnetizes the probe's sensor head and sets the waveform to zero position.

Remote command:

`PROBe<ch>:SETup:OFFSet:AZERo` on page 981

`PROBe<ch>:SETup:OFFSet:USEautozero` on page 981

6.4.2 Setup for passive probes

Passive probes are the most widely used probes for voltage measurements with oscilloscopes. If a passive probe is connected, the probe attenuation is read out and shown in the "Probe" tab.

Passive probes require compensation, see [Section 6.4.9, "Adjusting passive probes"](#), on page 160.




Figure 6-3: Passive probe R&S RT-ZP11, detected by the oscilloscope

The settings for passive probes are common settings, which are available for all probe types. See [Section 6.4.1, "Common probe settings"](#), on page 139 for description of the settings.

For R&S RT-ZP11, a special setting is available.

ZP11 mode

Enable if R&S RT-ZP11 is connected to adjust the probe bandwidth to 700 MHz.

If you use 500 MHz passive probe, e.g. R&S RT-ZP10, disable the setting.

6.4.3 Setup for active voltage probes

Active voltage probes with Rohde & Schwarz probe interface have an integrated data memory that contains identification data and individual probe correction parameters. The MXO 5C can detect these probes and read out the data. Furthermore, the Rohde & Schwarz probe interface provides special features: the micro button and the ProbeMeter.

Active voltage probes that are offered by Rohde & Schwarz but not equipped with a Rohde & Schwarz probe interface are known to the MXO 5C as predefined probes.

6.4.3.1 Settings for the Rohde & Schwarz probe interface

The Rohde & Schwarz probe interface provides special features: the micro button and the ProbeMeter.

MicroButton

The micro button is located on the probe head. Pressing this button, you initiate an action on the instrument directly from the probe. The button is disabled during internal automatic processes, for example, during self-alignment, autoset, and level detection.

Select the action that you want to start from the probe.

"Run continuous"	Starts or stops the acquisition (same as Run / Stop key).
"Run single"	Starts a defined number of acquisitions (same as [Single] key).
"Autoset"	Starts the autoset procedure (same as Autoset key).
"Auto zero"	Starts an auto zero measurement.
"Offset to mean"	Performs an automatic compensation for a DC component of the input signal using the result of a background mean measurement.
"Save image to file"	Saves the current display as image according to the image settings.
"No action"	Select this option to prevent unwanted actions due to unintended usage of the micro button.
"Find trigger level"	Sets the trigger level automatically to $0.5 * (MaxPeak - MinPeak)$.
"Probe mode"	Only available if a R&S RT-ZM modular probe is connected. Sets the measurement mode of the modular probe.
"Probe setup"	Opens the probe setup on the screen.

Remote command:

[PROBe<ch>:SETup:MODE](#) on page 983

ProbeMeter

Activates the integrated R&S ProbeMeter on probes with Rohde & Schwarz probe interface.

The R&S ProbeMeter is a voltmeter. It measures DC voltages between the probe tip and ground connection or between the probe tips with very high precision. The measurement runs continuously and in parallel to the measurements of the oscilloscope.

If a single-ended or power rail probe is connected, the ProbeMeter measures DC voltages between the probe tip and ground connection and enables ground-referenced measurements of voltages.

If a differential probe is connected, you can select if the ProbeMeter measures differential and common mode voltages, or single-ended voltages. See ["Display"](#) on page 145.

Remote command:

[PROBe<ch>:PMETer:STATe](#) on page 985

[PROBe<ch>:PMETer:RESults:SINGLE?](#) on page 985

[PROBe<ch>:PMETer:RESults:COMMON?](#) on page 986

[PROBe<ch>:PMETer:RESults:DIFFerential?](#) on page 986

[PROBe<ch>:PMETer:RESults:NEGative?](#) on page 987

[PROBe<ch>:PMETer:RESults:POSitive?](#) on page 987

6.4.3.2 Setup for R&S RT-ZD differential probes

Setup	Detected: RT-ZD30	Type: active different...
Bandwidth	Probe Bandwidth:	Offset
Probe	3 GHz	16.352 mV
Probe Info	RT-ZA15 attenuator ☐ Off	CM offset 0 V
Other	Manual attenuation: 1 V/V	Set offset to mean
	AutoZero	Use AutoZero ☐
	ProbeMeter ☐ Off	Display Differential / C... ▼
	MicroButton Run continuous ▼	

Figure 6-4: Probe setup for active differential probe R&S RT-ZD30

Most settings are common settings, which are available for all probe types. See [Section 6.4.1, "Common probe settings"](#), on page 139 for description of these settings.

R&S RT-ZD differential probes have the Rohde & Schwarz probe interface and support its functions. For details, see [Section 6.4.3.1, "Settings for the Rohde & Schwarz probe interface"](#), on page 142.

The "Offset" is the differential offset, see ["Offset"](#) on page 135.

Specific settings for R&S RT-ZD probes are the following:

CM offset

Sets the common-mode offset to compensate for a common DC voltage that is applied to both input sockets (referenced to the ground socket). The setting is available for Rohde & Schwarz differential probes and for modular probes in CM measurement mode.

Offset compensation is particularly helpful for measurements on differential signals with high common mode levels, for example, current measurements using a shunt resistor. You can measure the common mode input voltage using the R&S ProbeMeter.

Remote command:

`PROBe<ch>:SETup:CMOffset` on page 984

RT-ZA15 attenuator

If you use the external attenuator R&S RT-ZA15 together with one of the differential active probes R&S RT-ZD10/20/30, enable "RT-ZA15 attenuator" to include the external attenuation in the measurements.

Remote command:

`PROBe<ch>:SETup:ZAXV` on page 985

Display

Selects the voltage to be measured by the ProbeMeter of differential active probes:

- "Differential / Common Mode":
Differential voltage is the voltage between the positive and negative signal sockets. Common mode voltage is the mean voltage between the signal sockets and the ground socket. It measures the voltage level relative to ground, for example, to check the operating voltage window.
- "Single Ended Pos/Neg":
Measures the voltage between the positive/negative signal socket and the ground. The ProbeMeter always measures the common mode and differential voltages. Single-ended voltages are calculated values:
$$V_p = V_{cm} + 0.5 * V_{in} \text{ and } V_n = V_{cm} - 0.5 * V_{in}$$

Remote command:

`PROBe<ch>:SETup:DISPlaydiff` on page 984

6.4.3.3 Setup for R&S RT-ZPR power rail probes

R&S RT-ZPR power rail probes are designed for power integrity measurements. They can measure small signals in the millivolt range with large DC-offset components.

R&S RT-ZPR power rail probes have the Rohde & Schwarz probe interface and support the ProbeMeter, but not the micro button. For details, see [Section 6.4.3.1, "Settings for the Rohde & Schwarz probe interface"](#), on page 142.

R&S RT-ZPR probes require 50 Ω input termination.

Setup	Detected: RT-ZPR20 Type: active single-e...	
Bandwidth	Probe Bandwidth:	Offset
Probe	2 GHz	16.352 mV
Probe Info	Vertical unit:	AC Coupling
Other	Volt	☐ Off
	Manual attenuation:	Set offset to mean
	1 V/V	
	AutoZero	Use AutoZero
	ProbeMeter	Display
	☐ Off	Single Ended P... ▼
	MicroButton	ProbeMeter to offset
	Run continuous ▼	

Figure 6-5: Probe setup for power rail probe R&S RT-ZPR20

Most settings are common settings, which are available for all probe types. See [Section 6.4.1, "Common probe settings"](#), on page 139 for description of these settings.

The "Offset" is the channel offset, see ["Offset"](#) on page 135.

Specific settings for R&S RT-ZPR probe are the following:

AC Coupling

Enables AC coupling in R&S RT-ZPR power rail probes, which removes DC and very low-frequency components. The R&S RT-ZPR probe requires 50 Ω input termination, for which the channel AC coupling is not available. The probe setting allows AC coupling also at 50 Ω inputs.

Remote command:

[PROBe<ch>:SETup:ACCoupling](#) on page 984

ProbeMeter to offset

Sets the measured ProbeMeter value as offset. Thus, the value is considered in measurements.

Remote command:

[PROBe<ch>:SETup:OFFSet:TOPMeter](#) on page 995

6.4.3.4 Setup for R&S RT-ZHD high-voltage differential probes

R&S RT-ZHD high-voltage differential probes are designed to measure safely high-voltage floating circuits using a grounded oscilloscope. They extend the measurement capability of oscilloscopes to measure electronic power converters, inverters, motor speed controls, switch mode power supplies and many other applications.

Setup	Detected: RT-ZHD07 Type: active different...	
Bandwidth	Bandwidth Limit	Offset
Probe	☐ Off	16.352 mV
Probe Info	Vertical unit: Volt	
Other	Range	Set offset to mean
	High ▼	
	AutoZero	Use AutoZero ☐
	ProbeMeter ☐ Off	Display Single Ended P... ▼
	MicroButton Run continuous ▼	Audible Overrange ☒ On

Figure 6-6: Setup for high-voltage differential probe R&S RT-ZHD07

Most settings are common settings, which are available for all probe types. See [Section 6.4.1, "Common probe settings"](#), on page 139 for description of these settings.

Bandwidth and attenuation values are indicated on the probe control box. The "Offset" is the differential offset, see ["Offset"](#) on page 135.

R&S RT-ZHD high-voltage differential probes have the Rohde & Schwarz probe interface and support its functions. For details, see [Section 6.4.3.1, "Settings for the Rohde & Schwarz probe interface"](#), on page 142.

Specific settings for R&S RT-ZHD probes are the following:

Bandwidth limit

Activates the lowpass filter in the probe control box. The filter frequency depends on the probe type and is indicated on the probe control box.

You can set the filter on the probe control box or at the oscilloscope.

Remote command:

[PROBe<ch>:SETup:ADVanced:FILTer](#) on page 988

Range

Sets the voltage range of an R&S RT-ZHD probe. You can set the range on the probe control box or at the oscilloscope.

"Auto"	The voltage range is set only at the oscilloscope with "Vertical scale".
"Low"	Sets the lower voltage range of the connected probe. The range values depend on the probe type and are indicated on the probe control box.
"High"	Sets the higher voltage range of the connected probe. The range values depend on the probe type and are indicated on the probe control box.

Remote command:

[PROBe<ch>:SETup:ADVanced:RANGe](#) on page 988

Audible overrange

Activates the acoustic overrange warning in the probe control box. You can also activate the sound directly on the probe control box.

Remote command:

[PROBe<ch>:SETup:ADVanced:AUDioverload](#) on page 987

6.4.4 Setup for current probes

The setup and adjustment of current probes depends on the output connector of the probe: BNC or Rohde & Schwarz probe box.

Current probes R&S RT-ZCxx

The current probes **R&S RT-ZCxx** have BNC connectors. They are known to the MXO 5C as predefined probes, see ["Predefined probe, Type and Name of the probe"](#) on page 139. Demagnetizing and zero adjustment is done on the probe, see the probe's User Manual for details. Make sure to demagnetize and adjust the probe before taking measurements.

Current probes R&S RT-ZCxxB

Current probes **R&S RT-ZCxxB** have a Rohde & Schwarz probe interface; they are powered and remotely controlled by the oscilloscope.

When the probe is connected, demagnetization is performed automatically.

Setup	Detected: RT-ZC05B Type: active current	
Bandwidth	Probe Bandwidth:	
Probe	2 MHz	
Probe Info	Offset	
	0 A	
Other	Vertical unit:	Zero adjust
	Ampere	0 %
	Manual gain:	Set offset to mean
	1 V/V	
	AutoZero	DeGauss
	Save to probe	

Figure 6-7: Setup for current probe R&S RT-ZC05B

Most settings are common settings, which are available for all probe types. See [Section 6.4.1, "Common probe settings"](#), on page 139 for description of these settings.

Current probes are adjusted by the following functions.

Gain, Manual gain

Shows the gain of the connected probe if the probe is detected or predefined. For unknown current probes, set the correct gain of the probe.

The vertical scaling and measured values are multiplied by this factor so that the displayed values are equal to the actual measured signal values.

Remote command:

[PROBe<ch>:SETup:GAIN:AUTO?](#) on page 993

[PROBe<ch>:SETup:GAIN:MANual](#) on page 993

DeGauss

Demagnetizes the core if it has been magnetized by switching the power on and off, or by an excessive input. Always carry out demagnetizing before measurement.

The demagnetizing process takes about one second. During demagnetizing, a demagnetizing waveform is displayed.

Demagnetizing is done automatically when R&S RT-ZCxxB is connected to the oscilloscope, or when "AutoZero" is performed.

Remote command:

[PROBe<ch>:SETup:DEGauss](#) on page 993

Zero adjust

Zero adjust corrects the effect of an offset caused by temperature drift, and compensates for the remanence. The setting is only available if DC coupling is set.

To set the waveform to zero level by the instrument, use "AutoZero". The detected value is displayed.

Alternatively, you can adjust the value manually until the waveform is set to zero level. Make sure to demagnetize the probe before zero adjustment.

The value is given in percent of the maximum range, which is internally defined. The actual setup range depends on the temperature drift, the measured current and other variables, and it can change over time. If you measure high currents, the probe core magnetizes, which impairs the measurement results. Therefore, repeat "AutoZero" before the measurement.

Remote command:

[PROBe<ch>:SETup:OFFSet:ZADJust](#) on page 994

Save to probe

Saves the zero adjust value in the probe box. If you connect the probe to another channel or to another Rohde & Schwarz oscilloscope, the value is read out again, and you can use the probe without further adjustment.

Remote command:

[PROBe<ch>:SETup:OFFSet:STProbe](#) on page 994

6.4.5 Modular probes

The probes of the R&S RT-ZM family are modular probes. They have a probe head and a probe amplifier connected by a cable, and various probe tip modules and tip cables for different applications. R&S RT-ZM probes are equipped with Rohde & Schwarz probe interface, and provide special features: R&S ProbeMeter, micro button, and a wide offset compensation range.

The following common probe settings are available:

- ["Probe bandwidth"](#) on page 140
- ["Vertical unit"](#) on page 140
- ["Attenuation"](#) on page 140
- ["AutoZero, Use AutoZero"](#) on page 141

The R&S RT-ZM probes support the following features of the Rohde & Schwarz probe interface:

- ["MicroButton"](#) on page 143
- ["ProbeMeter"](#) on page 143

Setup	Detected:	Type:
	RT-ZM130	active modular
Bandwidth	Probe Bandwidth:	DM offset
Probe	13 GHz	0 V
Probe info	Vertical unit:	
	Volt	
Other	Attenuation:	Probe mode
	10 V/V	DM
	AutoZero	Use AutoZero
	ProbeMeter	Termination
	Off	
	Micro button	Deembedding
	Run continuous	

The specific functions of modular probes are described in the following sections:

- [Setup parameters of modular probes](#).....151
- [Termination voltage with R&S RT-ZMA40 SMA module](#)..... 152

6.4.5.1 Setup parameters of modular probes

Access: "Menu" > "Vertical" > "Probe" tab, and R&S RT-ZM probe is connected to the channel

Probe mode

Sets the measurement mode of modular probes.

The modular probes of the R&S RT-ZM family have a multimode function. You can switch between single-ended, differential and common mode measurements without reconnecting or resoldering the probe. You can set the probe mode in the dialog, and you can assign the probe mode setting to the micro button.

If you use the R&S RT-ZMA30 browser module, only DM measurements are possible because this module has no ground connector.

The measurement modes are:

"DM" Differential-mode input voltage (V_{dm}), the voltage between the positive and negative input terminal.

$$V_{dm} = V_p - V_n$$

"CM" Common-mode input voltage (V_{cm}), the mean voltage between the positive and negative input terminal vs. ground.

$$V_{cm} = \frac{V_p + V_n}{2}$$

"P" Positive single-ended input voltage (V_p). The voltage between the positive input terminal and the ground.

"N" Negative single-ended input voltage (V_n). The voltage between the negative input terminal and the ground.

Remote command:

[PROBe<ch>:SETup:PRMode](#) on page 989

DM offset, CM offset, P offset, N offset

Compensate offset voltages. The dialog shows the offset of the selected probe mode.

The offset of the selected probe mode is used as the channel offset and considered automatically for correction. For example, in CM mode, the common mode offset is used as the channel offset.

"DM Offset" Compensates a DC voltage applied between the positive (V_p) and the negative (V_n) input terminal at the probe tip.

"CM Offset" Compensates a DC voltage applied to both input terminals referenced to ground.

"P Offset" Compensates a DC voltage applied to the positive input terminal (V_p) referenced to ground.

"N Offset" Compensates a DC voltage applied to the negative input terminal (V_n) referenced to ground.

Remote command:

[PROBe<ch>:SETup:DMOffset](#) on page 990

[PROBe<ch>:SETup:CMOffset](#) on page 984

[PROBe<ch>:SETup:NOFFset](#) on page 990

[PROBe<ch>:SETup:POFFset](#) on page 991


6.4.5.2 Termination voltage with R&S RT-ZMA40 SMA module

Access: "Menu" > "Vertical" > "Probe" tab > "Termination"

Termination voltage is relevant if you use the R&S RT-ZMA40 SMA module. The SMA module applies a termination voltage (± 4 V) to the DUT to enable measurements against a common mode DC voltage instead of ground. This measurement is required for many digital signal standards.

The termination voltage can be controlled at the oscilloscope. Therefore, connect the V_T terminal of the R&S RT-ZM probe amplifier to the V_T terminal of the R&S RT-ZMA40

SMA module using the red DC lead (see R&S RT-ZM User Manual). The required termination voltage is measured and adjusted automatically, but can also be set manually.



State

Activates control of the termination voltage.

Remote command:

[PROBe<ch>:SETup:TERM:STAtE](#) on page 992

Mode

Selects the voltage that is used for termination.

In auto mode, the instrument uses the measured common mode voltage for termination. In manual mode, you can enter the voltage to be used for termination. Use the manual mode if you know the common mode voltage of the DUT.

Remote command:

[PROBe<ch>:SETup:TERM:MODE](#) on page 992

Adjustment

Sets the voltage to be used for termination correction in manual termination mode.

Remote command:

[PROBe<ch>:SETup:TERM:ADJust](#) on page 991

Measurement

Shows the measured common mode voltage.

Remote command:

[PROBe<ch>:SETup:TERM:MEASure?](#) on page 991

6.4.6 Setup for optical isolated probe systems

The R&S RT-ZISO is an optical isolated probe system. It consists of the probe head with exchangeable tip module, probe receiver, and scope connector cable. The probe head is permanently connected to the probe receiver by an optical cable, which is an optical isolated cable with multifiber system. To connect the probe receiver to the MXO 5C, the scope connector cable is used. This cable provides the required supply voltage and transmits the measurement data and control signals simultaneously.

The power consumption of the probes is monitored by the power monitor. See [Section 6.4.8.1, "Power monitor"](#), on page 159 for details.

6.4.6.1 Setup parameters of optical isolated probes

Access: "Menu" > "Vertical" > "Probe" tab > select channel with connected R&S RT-ZISO probe.

Setup	Detected: RT-ZISO	Type: active isolated
Bandwidth	Probe Bandwidth: 500 MHz	Offset 0 V
Probe	Select input unit. V ▼	Coupling DC ▼
Probe info	Attenuation: 10 V/V	Set offset to ProbeMeter value
Other	AutoZero	Use AutoZero ☐
	ProbeMeter Off	Alignment ▶
	Laser state:	Power supply:
	Internal supply sufficient	

Most settings are common settings, which are available for all probe types. See [Section 6.4.1, "Common probe settings"](#), on page 139 for description of these settings.

The dialog also shows some vertical settings

- "Offset". See ["Offset"](#) on page 135 for details.
- "Coupling". See ["Coupling"](#) on page 135 for details.

Set the vertical scale in the "Setup" tab. The probe adjusts its attenuation automatically.

Select input unit

Sets the unit of the R&S RT-ZISO signal.

Remote command:

[PROBe<ch>:SETup:ADVanced:UNIT](#) on page 994

Set offset to ProbeMeter value

Sets the measured R&S ProbeMeter value as offset. Thus, the value is considered in measurements.

The function is available if [ProbeMeter](#) is active.

Remote command:

[PROBe<ch>:SETup:ADVanced:PMToffset](#) on page 988

Alignment

Opens the "Alignment" dialog. See [Section 6.4.6.2, "Alignment"](#), on page 155.

Laser state

The color indicates the current status of the laser:

- Green: the laser is working.
- Yellow: the laser needs service, but is still working.
- Red: defective laser, send it to your Rohde & Schwarz service center.

Remote command:

[PROBe<ch>:SETup:LASer:STATe?](#) on page 995

Power supply

Indicates whether the power supply of the R&S RT-ZISO is sufficient.

Details on power consumption are given in the power monitor. See [Section 6.4.8.1, "Power monitor"](#), on page 159.


If you use an MXO 5C with more than four R&S RT-ZISO probes, an external power supply is needed. Refer to the documentation of the R&S RT-ZISO probe.

6.4.6.2 Alignment

Access: "Menu" > "Vertical" > "Probe" tab > select channel with connected R&S RT-ZISO probe > "Alignment".

The dialog provides functions to correct the zero point and gain errors.

Align the probe before first use, and when the ambient conditions have been changed, for example, when strong temperature changes occur ($> 5^{\circ}$).



The progress of the alignment process is shown in a progress bar below the buttons.

Zero-error alignment

Performs a self-alignment and corrects the zero point error of the R&S RT-ZISO probe.

Tip modules are not affected by the alignment. Attaching or removing the tip module does not change the process or result.

The alignment can take about a minute, the progress is shown in the dialog. Wait until the process has been finished. After successful alignment, the correction data is automatically written to the non-volatile flash of the probe.

Remote command:

`PROBe<ch>:SETup:ALIGnment:ZERO:EXECute` on page 996

Gain/Zero-error alignment

Corrects the zero point error and the gain error of the R&S RT-ZISO probe.

Tip modules are not affected by the alignment. Attaching or removing the tip module does not change the process or result.

The alignment can take about a minute, the progress is shown in the dialog. Wait until the process has been finished. After successful alignment, the correction data is automatically written to the non-volatile flash of the probe.

Remote command:

`PROBe<ch>:SETup:ALIGnment:GAIN:EXECute` on page 995

Restore default values

Resets the zero point and gain error correction to the factory default values.

Remote command:

`PROBe<ch>:SETup:ADVanced:RDEFaults` on page 996

6.4.6.3 Tip info dialog

Access: "Menu" > "Vertical" > "Probe" > select channel with connected R&S RT-ZISO probe > "Tip info"

The dialog shows the characteristics of the tip modules that are connected to the probes.

Back	Probe tip info	
	Name	ZISO-Z301
	Type	BROWSER
	Part number	1803.4500.02
	Serial number	100611
	Input min [V]	-300 V
	Input max [V]	300 V
	Offset min [V]	-300 V
	Offset max [V]	300 V
	Attenuation	10
	Bandwidth	500 MHz
	Input impedance	10 MΩ
	Input capacity	12 pF


Remote commands:

- `PROBe<ch>:SETup:TIPModel:NAME?` on page 997
- `PROBe<ch>:SETup:TIPModel:INFO?` on page 997

6.4.7 Probe adapter R&S RT-Z2T


Using the R&S RT-Z2T probe interface adapter, you can connect selected Tektronix active probes with TekProbe BNC™ level II interface.

1. Connect the R&S RT-Z2T adapter to the channel input.
2. Connect the probe to the adapter.
The instrument identifies the adapter.
3. Select "Menu" > "Vertical" > "Probe" tab.




The dialog shows that the R&S RT-Z2T probe interface adapter is connected, and supported Tektronix probes are listed as "Predefined probe".

4. Select the "Predefined probe" in the "Probe" tab.



See also: ["Predefined probe, Type and Name of the probe"](#) on page 139.

The power consumption of the R&S RT-Z2T probe interface adapter in the "Power monitor": "Vertical" > "Probe Info" > "Power monitor".



6.4.8 Probe info

The dialog shows general information on the connected probe, for example, type, serial number, and part number. Below, electrical characteristics are shown, like bandwidth, attenuation, input capacitance and impedance, voltage and DC offset range.

For a specification of the probe parameters, refer to the specifications document.

Setup	Name	RT-ZISO
	Ext. attenuator	
Bandwidth	Serial no.	100000
	Part number	1804.5000.02
	Software version	3.2.26154.22063
Probe	Input unit	V
	Probe bandwidth	1 GHz
Probe info	Input capacitance	10 pF
	Input impedance	1 M Ω
Other	Dynamic DC range max	60 V
	Dynamic DC range min	10 mV
	Offset range max	30 V
	Offset range min	-30 V
	Sensitivity	1 mV
	OVW upper value	-60 kV
	OVW lower value	60 kV

Tip info ▶


Power Monitor ▶

Remote commands: [Section 18.9.6.7, "Probe attributes"](#), on page 998.

6.4.8.1 Power monitor

The power monitor informs about the connected probes and their power consumption. The maximum available power per rail and per single channel are also shown.

If you use several R&S RT-ZISO probes, the power of the instrument can be insufficient to power all probes. The power monitor notifies you of insufficient power. To solve the problem, you can remove redundant probes, or use the external power supplies to power the R&S RT-ZISO probes.



6.4.8.2 Tip info


The "TIP info" button and dialog are available if an R&S RT-ZISO probe is connected to the channel. See [Section 6.4.6.3, "Tip info dialog"](#), on page 156 for details.

6.4.9 Adjusting passive probes

When using a passive probe, you have to compensate it when you connect it to the instrument the first time. Compensation matches the probe cable capacitance to the oscilloscope input capacitance to assure good amplitude accuracy from DC to upper bandwidth limit frequencies. A poorly compensated probe reduces the performance of the probe-oscilloscope system and introduces measurement errors resulting in distorted waveforms and inaccurate results.

Two connector pins are located on the front panel. The  pin is on ground level. The  pin supplies a square wave signal with 1 kHz for low frequency probe compensation.

1. Connect the BNC connector of the probe to one of the channel inputs.
2. Connect the probe's ground connector to the ground compensation pin, and the probe tip to the signal pin.
3. Press [Autoset].
A square wave appears on the display.
4. Adjust the compensation trimmer of the probe to optimum square wave response.
For details, refer to the documentation of your probe.



7 Trigger

This section describes the trigger capabilities of the MXO 5C.

• Basics of triggering	161
• Common trigger settings	163
• Trigger sequence	165
• Trigger types	167
• Trigger mode / holdoff	190
• Hysteresis	192
• Channel filter	194
• Actions on trigger	195
• Zone trigger	197

7.1 Basics of triggering

Triggering means to capture the interesting part of the relevant waveforms, and the trigger point is the determining point in the waveform record. Choosing the right trigger type and configuring all trigger settings correctly allows you to detect various incidents in analog, digital, and protocol signals.

How the oscilloscope triggers

A trigger occurs if the complete set of trigger conditions is fulfilled. The instrument acquires continuously and keeps the sample points to fill the pre-trigger part of the waveform record. When the trigger occurs, the instrument continues acquisition until the post-trigger part of the waveform record is filled. Then it stops acquiring and waits for the next trigger. When a trigger is recognized, the instrument does not accept another trigger until the acquisition is complete and the holdoff time has expired.

Trigger setup on the oscilloscope

A simple trigger setup includes:

- Source of the trigger signal
- Trigger type selection and setup
- Horizontal position of the trigger, see: [Section 6.1.1, "About the horizontal system"](#), on page 117
- Trigger mode

The MXO oscilloscopes provide various trigger types for troubleshooting and signal analysis, for example, edge trigger, glitch trigger, interval trigger, pattern trigger, and much more.

For complex tasks like verifying and debugging designs, advanced trigger settings are available:

- Filter to remove high or low frequencies from the trigger signal.
- Hysteresis to avoid unwanted trigger events caused by noise.
- Holdoff to define exactly which trigger event causes the trigger.

- Trigger sequences to combine several event conditions.

Action on trigger

A trigger can initiate one or more actions, for example, a trigger out signal, saving a screenshot or saving waveform data. All available actions can be initiated at the same time.

Trigger sequence

A trigger sequence joins two or more separate trigger conditions with an optional delay time and an optional reset time or reset condition. Similar setups are also known as multi-step triggers or A/B trigger.

7.1.1 Trigger information

Information on the most important trigger settings is shown in the trigger label above the diagram. If you tap the trigger label, the "Trigger" dialog opens.

If you trigger on a single event, the trigger label shows:

- Trigger source
- Trigger type
- Trigger level
- Trigger mode
- Edge or polarity, and important trigger-type specific settings
- Trigger state




Figure 7-1: Trigger label on the toolbar

- 1 = Trigger source
- 2 = Trigger type
- 3 = Trigger level
- 4 = Trigger mode
- 5 = Trigger state
- 6 = Trigger type specific settings
- 7 = Trigger slope

If you trigger on a sequence, the trigger label shows:


- Sequence type
- Trigger mode
- Trigger state

7.2 Common trigger settings

Access: "Menu" > "Trigger" > "Setup" tab

The common trigger settings are the trigger sequence, trigger source, the trigger type, and the trigger level. To set the trigger level automatically, use "Find level".

These common settings are set once for a single event. In a trigger sequence, they are specific for each condition.



Depending on the trigger type, additional settings are needed. They are explained in the trigger-type specific sections, see [Section 7.4, "Trigger types"](#), on page 167.

Trigger on	163
Source	163
Type	164
Level	164
Find level	165

Trigger on

Selects, if you want to trigger on a single event, or on a series of events.

Remote command:

[TRIGger:MEVents:MODE](#) on page 1006

Source

Selects the source of the trigger signal for the selected trigger event. The trigger source works even if it is not displayed in a diagram.

Available sources depend on the trigger sequence setting. If you trigger on a single event, all inputs can be used as trigger source. If you trigger on a sequence, only analog channels can be set as trigger source for A, B, and R-events.

The trigger source can be:

- Channel <n>: an analog input channel
- Extern: external analog signal connected to the external trigger input. For the external trigger source, the analog edge trigger is available.

- **Line:** The instrument generates the trigger from the AC power input and synchronizes the signal to the AC power frequency. Use this source if you want to analyze signals related to the power line frequency, such as lighting equipment and power supply devices. For the line trigger source, the edge trigger type is available.
- **Digital channels D0 to D15**
Requires option R&S MXO5C-B1. Digital channels are only available for triggering on single event. Available trigger types are: edge, width, timeout, state and pattern.
- **Serial buses**
If one or more serial protocol options are installed, you can trigger on various conditions in the bus signal. If the hardware trigger is supported for a protocol, triggering on single event is possible. For all protocols, the software trigger is supported in a "A → Serial bus". hardware and software trigger have different trigger settings.

For the state trigger, this source is the "Clock source", the clock signal.

For the setup & hold trigger, this source is the "Data source", the data signal.

Remote command:

`TRIGger:EVENT<ev>:SOURce` on page 1008

Type

Selects the trigger type. In a trigger sequence, the trigger type is set for each condition.

The current trigger type is shown on the button and in the trigger label above the diagram.

The following trigger types are available:

- [Edge trigger, see page 168](#)
- [Glitch trigger, see page 170](#)
- [Width trigger, see page 172](#)
- [Runt trigger, see page 173](#)
- [Window trigger, see page 175](#)
- [Timeout trigger, see page 177](#)
- [Interval trigger, see page 178](#)
- [Slew rate trigger, see page 180](#)
- [Setup & Hold, see page 182](#)
- [State trigger, see page 184](#)
- [Pattern trigger, see page 185](#)

If the external trigger input is used as the trigger source, the analog edge trigger is the only available trigger type.

For digital channels, the edge, width, timeout, state and pattern trigger are available.

Remote command:

`TRIGger:EVENT<ev>:TYPE` on page 1007

Level

Sets the voltage level or threshold for the trigger.

You can also drag the trigger level marker on the display, or turn the [Level] knob. To set the trigger level to 50% of the signal amplitude, press the [Level] knob.

For the setup & hold trigger, this level sets the voltage level for the data signal. At this level, the setup and hold time are measured.

For the timeout trigger, the trigger level is the threshold for the high and low signal states.

Runt, window and slew rate triggers require two trigger levels (upper and lower), which are defined as specific settings.

Remote command:

`TRIGger:EVENT<ev>:LEVel<n>[:VALue]` on page 1007

`TRIGger:ANEDge:LEVel` on page 1011 (for external trigger source)

Find level

Sets the trigger level automatically to $0.5 * (MaxPeak - MinPeak)$.

In a trigger sequence, "Find level" affects all active events of the sequence (A, B, and R event).

The function is not available for trigger sources "Extern" and "Line".

Remote command:

`TRIGger:FINDlevel` on page 1007

7.3 Trigger sequence

With MXO 5C, you can trigger on a single trigger event, or on a sequence of events. A trigger sequence consists of at least two event conditions and additional conditions defining when the trigger occurs.

All trigger sequences require that analog input channels C<n> are set as trigger source for the A-trigger. The instrument checks all trigger settings for compatibility and adjusts them if they do not fit.

The following trigger types are only available for triggering on single event:

- Setup & Hold
- State
- Pattern

A → B → R sequence

The trigger sequence "A → B → R", for example, consists of two subsequent events: A-trigger and B-trigger with optional B-trigger delay and count. In addition, an optional reset condition R can be configured: timeout or R-trigger condition. A-, B-, and R-triggers are configured in the same way.

After the A-trigger conditions have been met, and an optional delay has passed, the B-trigger with independent conditions is enabled. The instrument waits until one or a specified number of B-trigger conditions occur. If the reset condition is not fulfilled, the latest B-trigger causes the trigger event, and then the sequence starts again. The B-trigger can only cause the trigger event if it occurs after the A-trigger and after the delay time.

If you expect, for example, an irregular B-trigger, you can configure a reset condition to restart the sequence. The reset condition can be a simple timeout, and/or a reset event that is defined in the same way as the A- and B-trigger conditions.

7.3.1 Sequence setup

Access: "Menu" > "Trigger" > "Setup" tab > "Trigger on" = "Sequence"




Figure 7-2: Trigger setup dialog with selected A → B → R sequence

Trigger sequence

Selects the type of the trigger sequence.

- "A → B → R" Triggers if all conditions of A- and B-events, as well as additional delay and count, and optional reset timeout and/or R-event conditions are fulfilled.
B-trigger and R-trigger are configured in the same way as the A-trigger. You can configure a delay between the A- and B-trigger, and define a number of fulfilled B-trigger conditions to be ignored. The reset condition R can be a timeout or a trigger condition, or a combination of both.
- "A → Zone Trigger" Triggers if the conditions of the A-event and the zone trigger are fulfilled.
See [Section 7.9, "Zone trigger"](#), on page 197

"A → Serial bus" Triggers if the conditions of the A-event and the serial bus are fulfilled.

See [Section 14.1.5, "Trigger"](#), on page 485.

Remote command:

[TRIGGER:MEVENTS:AEVENTS](#) on page 1008

Delay

Sets the time that the instrument waits after an A-trigger until it recognizes B-triggers.

Remote command:

[TRIGGER:MEVENTS:SEQUENCE<se>:DELAY](#) on page 1009

B event count

Sets the number of B-trigger conditions to be fulfilled after an A-trigger. The last B-trigger causes the trigger event. The waiting time for B-triggers can be restricted with a reset condition: timeout or reset event.

Remote command:

[TRIGGER:MEVENTS:SEQUENCE<se>:COUNT](#) on page 1009

Enable reset event

If enabled, the trigger sequence is restarted by the R-trigger condition if the specified number of B-triggers does not occur before the R-trigger conditions are fulfilled.

Remote command:

[TRIGGER:MEVENTS:SEQUENCE<se>:RESET:EVENT](#) on page 1009

Enable reset by time, Reset timeout

If reset timeout is enabled, the instrument waits for the "Reset timeout" time for the specified number of B-triggers. If no trigger occurs during that time, the sequence is restarted with the A-trigger.

Remote command:

[TRIGGER:MEVENTS:SEQUENCE<se>:RESET:TIMEOUT\[:ENABLE\]](#) on page 1010

[TRIGGER:MEVENTS:SEQUENCE<se>:RESET:TIMEOUT:TIME](#) on page 1010

7.4 Trigger types

• Edge trigger	168
• Edge trigger on external trigger source	169
• Glitch trigger	170
• Width trigger	172
• Runt trigger	173
• Window trigger	175
• Timeout trigger	177
• Interval trigger	178
• Slew rate trigger	180
• Setup & Hold	182


- [State trigger](#).....184
- [Pattern trigger](#)..... 185
- [Line trigger](#)..... 190

7.4.1 Edge trigger

Access: "Menu" > "Trigger" > "Setup" tab > "Type = Edge"

The edge trigger is the most common trigger type. The trigger occurs when the signal from the trigger source passes the trigger level in the specified direction (slope).

This section describes the trigger-type specific settings. For settings that apply to all trigger types, see [Section 7.2, "Common trigger settings"](#), on page 163.



Level
See "[Level](#)" on page 164.

Remote command:
[TRIGger:EVENT<ev>:LEVel<n>\[:VALue\]](#) on page 1007

Slope
Sets the edge direction for the trigger.

"Positive"	Selects the rising edge, which is a positive voltage change.
"Negative"	Selects the falling edge, which is a negative voltage change.
"Either"	Selects the rising and falling edge. After starting an acquisition, the instrument triggers on the first identified edge.


Remote command:
[TRIGger:EVENT<ev>:EDGE:SLOPe](#) on page 1011

7.4.2 Edge trigger on external trigger source

Access: "Menu" > "Trigger" > "Setup" tab > "Source" = "Extern" > "Type = Analog Edge"

If an external trigger signal is connected to the Trigger In connector, and the trigger source is set to "Extern", the analog edge trigger is available. Triggering on an external source is only possible if you trigger on a single event but not for sequences.

This section describes the trigger-type specific settings. For settings that apply to all trigger types, see [Section 7.2, "Common trigger settings"](#), on page 163.



The "Slope" and "Level" are the same settings as for the edge trigger, see:

- ["Level"](#) on page 164
- ["Slope"](#) on page 168

Specific settings for the analog edge trigger are the following:

Coupling

Sets the connection of the external trigger signal, i.e. the input impedance and a termination. The coupling determines what part of the signal is used for triggering.

"DC 50 Ω "	Connection with 50 Ω termination, passes both DC and AC components of the signal.
"DC 1 M Ω "	Connection with 1 M Ω termination, passes both DC and AC components of the signal.
"AC 1 M Ω "	Connection with 1 M Ω termination through DC capacitor, removes DC and very low-frequency components. The waveform is centered on zero volts.

Remote command:

[TRIGger:ANEDge:COUPling](#) on page 1011

Filter, Cut-off

Selects the filter mode for the external trigger signal, and sets the cut-off frequency.

"Off"	The trigger signal is not filtered.
"LF reject"	Frequencies lower than the "Cut-off" frequency are rejected, higher frequencies pass the filter.
"RF reject"	Frequencies higher than the "Cut-off" frequency are rejected, lower frequencies pass the filter.

Remote command:

[TRIGger:ANEDge:FILTer](#) on page 1012

[TRIGger:ANEDge:CUToff:HIGHPass](#) on page 1012

[TRIGger:ANEDge:CUToff:LOWPass](#) on page 1012

Trigger noise reject

Enables an automatic hysteresis on the trigger level to avoid unwanted trigger events caused by noise.

Remote command:


[TRIGger:ANEDge:NREJect](#) on page 1012

7.4.3 Glitch trigger

Access: "Menu" > "Trigger" > "Setup" tab > "Type = Glitch"

The glitch trigger detects pulses shorter or longer than a specified time. It identifies deviation from the nominal data rate and helps to analyze causes of even rare glitches and their effects on other signals.

This section describes the trigger-type specific settings. For settings that apply to all trigger types, see [Section 7.2, "Common trigger settings"](#), on page 163.

**Level**

See ["Level"](#) on page 164.

Remote command:

[TRIGger:EVENT<ev>:LEVel<n>\[:VALue\]](#) on page 1007

Polarity

Sets the polarity of a pulse, which is the direction of the first pulse slope.

"Positive" Selects positive going pulses, the width is defined from the rising to the falling slopes.

"Negative" Selects negative going pulses, the width is defined from the falling to the rising slopes.

"Either" Selects both positive and negative going pulses.

Remote command:

[TRIGger:EVENT<ev>:GLITCh:POLarity](#) on page 1013

[TRIGger:EVENT<ev>:RUNT:POLarity](#) on page 1016

Range

Selects how the time limit of the runt pulse is defined.

Remote command:

[TRIGger:EVENT<ev>:GLITCh:RANGe](#) on page 1013

Width

Sets the length of a glitch. The instrument triggers on pulses shorter or longer than this value, depending on the value set with "Range".

You need to know the expected pulse widths of the circuit to set the glitch width correctly.

Remote command:


`TRIGger:EVENT<ev>:GLITCh:WIDTh` on page 1013

7.4.4 Width trigger

Access: "Menu" > "Trigger" > "Setup" tab > "Type = Width"

The width trigger compares the pulse width (duration) with given time limits. It detects pulses with an exact pulse width, pulses shorter or longer than a given time, and also pulses inside or outside the allowable time range. The pulse width is measured at the trigger level.

This section describes the trigger-type specific settings. For settings that apply to all trigger types, see [Section 7.2, "Common trigger settings"](#), on page 163.



Level

See "[Level](#)" on page 164.

Remote command:

`TRIGger:EVENT<ev>:LEVel<n>[:VALue]` on page 1007

Polarity

Sets the polarity of a pulse, which is the direction of the first pulse slope.

- "Positive" Selects positive going pulses, the width is defined from the rising to the falling slopes.
- "Negative" Selects negative going pulses, the width is defined from the falling to the rising slopes.
- "Either" Selects both positive and negative going pulses.

Remote command:

[TRIGger:EVENT<ev>:WIDTH:POLarity](#) on page 1014

Range

Selects how the range of a pulse width is defined.

- "Longer" Triggers on pulses longer than the given "Width".
- "Shorter" Triggers on pulses shorter than the given "Width".
- "Within" Triggers on pulses inside a given range. The range of the pulse width is defined by " $\pm\Delta$ " related to "Width".
- "Outside" Triggers on pulses outside a given range. The range definition is the same as for "Within" range.

Remote command:

[TRIGger:EVENT<ev>:WIDTH:RANGE](#) on page 1014

Width

For the ranges "Within" and "Outside", the width defines the center of a range which is defined by the limits " $\pm\Delta$ ".

For the ranges "Shorter" and "Longer", the width defines the maximum and minimum pulse width, respectively.

Remote command:

[TRIGger:EVENT<ev>:WIDTH:WIDTH](#) on page 1015

 $\pm\Delta$

Defines a range around the width value.

The combination "Range" = "Within" and " $\pm\Delta$ " = 0 triggers on pulses with a pulse width that equals "Width".

The combination "Range" = "Outside" and " $\pm\Delta$ " = 0 means to trigger on pulse widths $\neq$ "Width".

Remote command:

[TRIGger:EVENT<ev>:WIDTH:DELTA](#) on page 1014

7.4.5 Runt trigger

Access: "Menu" > "Trigger" > "Setup" tab > "Type = Runt"

A runt is a pulse lower than normal in amplitude. The amplitude crosses the first threshold twice in succession without crossing the second one. For example, this trig-

ger can detect logic, digital, and analog signals remaining below a specified threshold amplitude because I/O ports are in undefined state.

This section describes the trigger-type specific settings. For settings that apply to all trigger types, see [Section 7.2, "Common trigger settings"](#), on page 163.



Polarity

Sets the polarity of a pulse, which is the direction of the first pulse slope.

"Positive" Selects positive going pulses, the width is defined from the rising to the falling slopes.

"Negative" Selects negative going pulses, the width is defined from the falling to the rising slopes.

"Either" Selects both positive and negative going pulses.

Remote command:

[TRIGger:EVENT<ev>:GLITCh:POLarity](#) on page 1013

[TRIGger:EVENT<ev>:RUNT:POLarity](#) on page 1016

Upper level

Sets the upper voltage limit.

Remote command:

[TRIGger:EVENT<ev>:LEVel<n>:RUNT:UPPer](#) on page 1016

Lower level

Sets the lower voltage limit.

Remote command:

[TRIGger:EVENT<ev>:LEVel<n>:RUNT:LOWer](#) on page 1015

Range

Selects how the time limit of the runt pulse is defined.

"Any runt"	Triggers on all runts fulfilling the level condition, without time limitation.
"Longer"	Triggers on runts longer than the given "Runt width".
"Shorter"	Triggers on runts shorter than the given "Runt width".
"Within"	Triggers if the runt length is inside a given time range. The range is defined by "Runt width" and " $\pm\Delta$ ".
"Outside"	Triggers if the runt length is outside a given time range. The range definition is the same as for "Within" range.

Remote command:

[TRIGger:EVENT<ev>:RUNT:RANGe](#) on page 1017

Runt width

For the ranges "Shorter" and "Longer", the runt width defines the maximum and minimum pulse width, respectively.

For the ranges "Within" and "Outside", the runt width defines the center of a range which is defined by " $\pm\Delta$ ".

Remote command:

[TRIGger:EVENT<ev>:RUNT:WIDTh](#) on page 1017

$\pm\Delta$

Defines a range around the runt width value.

Remote command:

[TRIGger:EVENT<ev>:RUNT:DELTA](#) on page 1016


7.4.6 Window trigger

Access: "Menu" > "Trigger" > "Setup" tab > "Type = Window"

The window trigger checks the signal run in relation to a "window". The window is formed by the upper and lower voltage levels. The trigger condition is fulfilled, if the waveform enters or leaves the window, or if the waveform stays inside or outside for a time longer or shorter than specified.

With the window trigger, you can display longer transient effects.

This section describes the trigger-type specific settings. For settings that apply to all trigger types, see [Section 7.2, "Common trigger settings"](#), on page 163.



Vertical condition

Selects how the signal run is compared with the window.

- "Enter" Triggers when the signal crosses the upper or lower level and thus enters the window made up of these two levels.
- "Exit" Triggers when the signal leaves the window.
- "Stay within" Triggers if the signal stays between the upper and lower level for a specified time. The time is defined in various ways by the "Time condition".
- "Stay outside" Triggers if the signal stays above the upper level or below the lower level for a specified time. The time is also defined by the "Time condition".

Remote command:

[TRIGger:EVENT<ev>:WINDow:RANGe](#) on page 1019

Upper level

Sets the upper voltage limit.

Remote command:

[TRIGger:EVENT<ev>:LEVel<n>:WINDow:UPPer](#) on page 1018

Lower level

Sets the lower voltage limit.

Remote command:

[TRIGger:EVENT<ev>:LEVel<n>:WINDow:LOWer](#) on page 1018

Time condition

Available for "Vertical condition" = "Stay within"/"Stay outside".

Selects how the time limit of the window is defined.

"Within"	Triggers if the signal stays inside or outside the vertical window limits at least for the time <i>Width - Delta</i> and for <i>Width + Delta</i> at the most.
"Outside"	"Outside" is the opposite definition of "Within". The instrument triggers if the signal stays inside or outside the vertical window limits for a time shorter than <i>Width - Delta</i> or longer than <i>Width + Delta</i> .
"Shorter"	Triggers if the signal crosses vertical limits before the specified "Width" time is reached.
"Longer"	Triggers if the signal crosses vertical limits after the specified "Width" time is reached.

Remote command:

[TRIGger:EVENT<ev>:WINDow:TIME](#) on page 1020

Width

For the ranges "Within" and "Outside", the width defines the center of a time range which is defined by the limits " $\pm\Delta$ ".

For the ranges "Shorter" and "Longer", it defines the maximum and minimum time lapse, respectively.

Remote command:

[TRIGger:EVENT<ev>:WINDow:WIDTh](#) on page 1020

 $\pm\Delta$

Defines a range around the width value.

Remote command:


[TRIGger:EVENT<ev>:WINDow:DELTa](#) on page 1019

7.4.7 Timeout trigger

Access: "Menu" > "Trigger" > "Setup" tab > "Type = Timeout"

The timeout trigger checks if the signal stays above or below the threshold voltage for a specified time lapse. In other words, the trigger occurs if the trigger source does not have the expected transition within the specified time.

This section describes the trigger-type specific settings. For settings that apply to all trigger types, see [Section 7.2, "Common trigger settings"](#), on page 163.

**Level**

Sets the threshold for the high and low signal states.

Remote command:

[TRIGger:EVENT<ev>:LEVel<n>\[:VALue\]](#) on page 1007

Range

Sets the relation of the signal level to the trigger level for the timeout trigger.

"Stays high" The signal level stays above the trigger level.

"Stays low" The signal level stays below the trigger level.

"High or low" The signal level stays above or below the trigger level.

Remote command:

[TRIGger:EVENT<ev>:TIMEout:RANGe](#) on page 1021

Time

Sets the time limit for the timeout at which the instrument triggers.

Remote command:

[TRIGger:EVENT<ev>:TIMEout:TIME](#) on page 1021


7.4.8 Interval trigger

Access: "Menu" > "Trigger" > "Setup" tab > "Type = Interval"

The interval trigger analyzes the time between two pulses.

The interval trigger can analyze either rising or falling edges, but searching for an interval is also possible for both edges at the same time ("Either").

This section describes the trigger-type specific settings. For settings that apply to all trigger types, see [Section 7.2, "Common trigger settings"](#), on page 163.



Level

See ["Level"](#) on page 164.

Remote command:

[TRIGger:EVENT<ev>:LEVel<n>\[:VALue\]](#) on page 1007

Slope

Sets the edge for the trigger. You can analyze the interval between positive edges or between negative edges.

Remote command:

[TRIGger:EVENT<ev>:INTerval:SLOPe](#) on page 1023

Range

Selects how the range of an interval is defined:

- "Within" Triggers on pulse intervals inside a given range. The range is defined by "Interv. width" and "±Delta".
- "Outside" Triggers on intervals outside a given range. The range definition is the same as for "Within" range.

"Shorter" Triggers on intervals shorter than the given "Interv. width".

"Longer" Triggers on intervals longer than the given "Interv. width".

Remote command:

[TRIGger:EVENT<ev>:INTerval:RANGe](#) on page 1022

Interv. width

Sets the time between two pulses for the interval trigger.

Remote command:

[TRIGger:EVENT<ev>:INTerval:WIDTh](#) on page 1023

±Delta

Defines a range around the "Interv. width" value.

Remote command:

[TRIGger:EVENT<ev>:INTerval:DELTA](#) on page 1022


7.4.9 Slew rate trigger

Access: "Menu" > "Trigger" > "Setup" tab > "Type = Slew rate"

The slew rate trigger is also known as transition trigger. It triggers if the transition time from the lower to higher voltage level (or vice versa) is shorter or longer as defined, or outside or inside a specified time range.

The slew rate trigger finds slew rates faster than expected or permissible to avoid overshooting and other interfering effects. It also detects slow edges violating the timing in pulse series.

This section describes the trigger-type specific settings. For settings that apply to all trigger types, see [Section 7.2, "Common trigger settings"](#), on page 163.



Slope

Sets the edge direction for the trigger.

- "Positive" Selects the rising edge, which is a positive voltage change.
- "Negative" Selects the falling edge, which is a negative voltage change.
- "Either" Selects the rising and falling edge. After starting an acquisition, the instrument triggers on the first identified edge.

Remote command:

[TRIGger:EVENT<ev>:SLEW:SLOPe](#) on page 1025

Upper level

Sets the upper voltage threshold. When the signal crosses this level, the slew rate measurement starts or stops depending on the selected slope.

Remote command:

[TRIGger:EVENT<ev>:LEVel<n>:SLEW:UPPer](#) on page 1024

Lower level

Sets the lower voltage threshold. When the signal crosses this level, the slew rate measurement starts or stops depending on the selected slope.

Remote command:

[TRIGger:EVENT<ev>:LEVel<n>:SLEW:LOWer](#) on page 1023

Range

Selects how the time limit for the slew rate is defined. The time measurement starts when the signal crosses the first trigger level - the upper or lower limit depending on the selected slope. The measurement stops when the signal crosses the second level.

"Within"	Triggers on slew rates inside a given time range. The range is defined by "Slew rate" and " $\pm\Delta$ ".
"Outside"	Triggers on slew rates outside a given time range. The range definition is the same as for "Within" range.
"Shorter"	Triggers on slew rates shorter than the given "Slew rate" limit.
"Longer"	Triggers on slew rates longer than the given "Slew rate" limit.

Remote command:

[TRIGger:EVENT<ev>:SLEW:RANGe](#) on page 1024

Slew rate

For the ranges "Within" and "Outside", the slew rate defines the center of a range which is defined by the limits " $\pm\Delta$ ".

For the ranges "Shorter" and "Longer", the slew rate defines the maximum and minimum slew rate limits, respectively.

Remote command:

[TRIGger:EVENT<ev>:SLEW:RATE](#) on page 1025

$\pm\Delta$

Defines a time range around the given slew rate.

Remote command:

[TRIGger:EVENT<ev>:SLEW:DELTA](#) on page 1024


7.4.10 Setup & Hold

Access: "Menu" > "Trigger" > "Setup" tab > "Type = Setup & Hold"

The setup & hold trigger analyzes the relative timing between two signals: a data signal and the synchronous clock signal. Many systems require, that the data signal must be steady for some time before and after the clock edge, for example, the data transmission on parallel interfaces. With this trigger type, you can also test the time correlation of sideband and in-band signals.

The setup & hold trigger is also known as Data2Clock trigger.

This section describes the trigger-type specific settings. For settings that apply to all trigger types, see [Section 7.2, "Common trigger settings"](#), on page 163.

**Data source**

Selects the input channel of the data signal.

Remote command:

[TRIGger:EVENT<ev>:SOURce](#) on page 1008

Level

Sets the voltage level for the data signal. At this level, the setup and hold time are measured.

Remote command:

[TRIGger:EVENT<ev>:LEVel<n>\[:VALue\]](#) on page 1007

Clock source

Selects the input channel of the clock signal.

Remote command:

[TRIGger:EVENT<ev>:SETHold:CSOURce\[:VALue\]](#) on page 1027

Clock edge

Sets the edge of the clock signal. Edge and level define the time reference point.

"Positive"	Rising edge, a positive voltage change.
"Negative"	Falling edge, a negative voltage change.
"Both"	Both the rising and the falling edge.

Remote command:

[TRIGger:EVENT<ev>:SETHold:CSOURCE:EDGE](#) on page 1026

Clock level

Sets the voltage level for the clock signal.

Both the clock level and the clock edge define the starting point for calculation of the setup and hold time.

Remote command:

[TRIGger:EVENT<ev>:SETHold:CSOURCE:LEVEL](#) on page 1026

Setup time

Sets the minimum time **before** the clock edge while the data signal must stay steady above or below the data level.

Remote command:

[TRIGger:EVENT<ev>:SETHold:STIME](#) on page 1027

Hold time

Sets the minimum time **after** the clock edge while the data signal must stay steady above or below the data level.

Remote command:


[TRIGger:EVENT<ev>:SETHold:HTIME](#) on page 1027

7.4.11 State trigger

Access: "Menu" > "Trigger" > "Setup" tab > "Type = State"

The state trigger verifies if the channel states match the defined pattern at the clock edge. The trigger occurs if the logical combination of the input channels is true at the crossing point of the selected clock edge and the trigger level.

This section describes the trigger-type specific settings. For settings that apply to all trigger types, see [Section 7.2, "Common trigger settings"](#), on page 163.



1. Select the "Clock source" and the "Slope".
2. Tap "Set state".
See [Section 7.4.12.2, "Settings for state and pattern trigger of analog channels"](#), on page 187 for setting details.

Slope

Sets the edge direction for the trigger.

- "Positive" Selects the rising edge, which is a positive voltage change.
- "Negative" Selects the falling edge, which is a negative voltage change.
- "Either" Selects the rising and falling edge. After starting an acquisition, the instrument triggers on the first identified edge.

Remote command:


[TRIGger:EVENTt<ev>:STATe:SLOPe](#) on page 1028

7.4.12 Pattern trigger

Access: "Menu" > "Trigger" > "Setup" tab > "Type = Pattern"

The pattern trigger works like a logic trigger. It provides logical combinations of the input channels and can be used for verifying the operation of digital logic. If the channel states match the desired pattern, the pattern trigger occurs.

This section describes the trigger-type specific settings. For settings that apply to all trigger types, see [Section 7.2, "Common trigger settings"](#), on page 163.



- ▶ Tap "Set pattern".
See [Section 7.4.12.2, "Settings for state and pattern trigger of analog channels"](#), on page 187 for setting details.

7.4.12.1 General settings

State sources

Selects if the source of the trigger for the pattern type is an "Analog" or "Digital" channel.

Remote command:

[TRIGger:EVENT<ev>:PATTern:QUALify:SOURces](#) on page 1031

Set pattern

Opens a dialog for setting the pattern by defining the channel stated and logic operator..

For analog channels, see [Section 7.4.12.2, "Settings for state and pattern trigger of analog channels"](#), on page 187.

For digital channels, see [Section 7.4.12.3, "Settings for state and pattern trigger of digital channels"](#), on page 189.

Find level

Sets the trigger level automatically to $0.5 * (MaxPeak - MinPeak)$.

In a trigger sequence, "Find level" affects all active events of the sequence (A, B, and R event).

The function is not available for trigger sources "Extern" and "Line".

Remote command:
[TRIGger:FINDlevel](#) on page 1007

7.4.12.2 Settings for state and pattern trigger of analog channels

Access for state trigger: "Menu" > "Trigger" > "Setup" tab > "Type = State" > "Set state"

Access for pattern trigger: "Menu" > "Trigger" > "Setup" tab > "Type = Pattern" > "Set pattern"




Figure 7-3: Detailed settings for state trigger




Figure 7-4: Detailed settings for pattern trigger

Source: channel states

Set the state for each channel. For the state trigger, the clock source is indicated and does not get a state.

Remote command:

[TRIGger:EVENT<ev>:STATe:QUALify:ANALog:CHAN<n>:HLX](#) on page 1028

[TRIGger:EVENT<ev>:PATTern:QUALify:ANALog:CHAN<n>:HLX](#) on page 1030

Threshold

Set the threshold for each channel.

Remote command:

[TRIGger:EVENT<ev>:LEVel<n>\[:VALue\]](#) on page 1007

Set all

Sets all channels to the selected state.

Logic Operator

Defines the logic combination of the channels and their states.

- "AND": logical AND, conjunctive combination
- "OR": logical OR, disjunctive combination

Remote command:

[TRIGger:EVENT<ev>:STATe:QUALify:LOGic](#) on page 1028

[TRIGger:EVENT<ev>:PATTern:QUALify:LOGic](#) on page 1030

[TRIGger:EVENT<ev>:PATTern:QUALify:DIGital:LOGic](#) on page 1031

[TRIGger:EVENT<ev>:STATe:QUALify:DIGital:LOGic](#) on page 1029

7.4.12.3 Settings for state and pattern trigger of digital channels

Access: "Menu" > "Trigger" > "Setup" tab > "Type = Pattern" > "Set pattern"

The screenshot shows the 'Trigger' setup window. On the left is a 'Back' button. The main area is divided into 'Source' and 'Threshold' sections. The 'Source' section lists digital channels D15 through D5. Each channel has three buttons: '1', '0', and 'X'. The '1' and '0' buttons are currently selected (highlighted in blue). Below the channel list is a 'Set all' button. The 'Threshold' section shows 'D15 - D0' and '1.65 V'. At the bottom right, there is a 'State Operator' dropdown menu currently set to 'AND'.

Source: channel states

Set the state for each channel.

Remote command:

[TRIGger:EVENT<ev>:PATTern:QUALify:DIGital:CHAN<n>:HLX](#) on page 1030

[TRIGger:EVENT<ev>:STATe:QUALify:DIGital:CHAN<n>:HLX](#) on page 1029

Set all

Sets all channels to the selected state.

Logic Operator

Defines the logic combination of the channels and their states.

- "AND": logical AND, conjunctive combination
- "OR": logical OR, disjunctive combination

Remote command:

[TRIGger:EVENT<ev>:STATe:QUALify:LOGic](#) on page 1028

[TRIGger:EVENT<ev>:PATtern:QUALify:LOGic](#) on page 1030

[TRIGger:EVENT<ev>:PATtern:QUALify:DIGital:LOGic](#) on page 1031

[TRIGger:EVENT<ev>:STATe:QUALify:DIGital:LOGic](#) on page 1029

7.4.13 Line trigger

Access: "Menu" > "Trigger" > "Setup" tab > "Source" = "Line"

The line trigger is an edge trigger that triggers on the AC power input and synchronizes the signal to the AC power frequency. It is not a trigger type but rather a special trigger source. Use the line source if you want to analyze signals related to the power line frequency, such as lighting equipment and power supply devices.

Slope

Selects the rising or falling edges of the AC power input.


Remote command:

[TRIGger:EVENT<ev>:EDGE:SLOPe](#) on page 1011

7.5 Trigger mode / holdoff

Access: "Trigger" menu > "Mode / holdoff" tab

Holdoff conditions define a waiting time after the current trigger until the next trigger can be recognized.



Trigger mode

Sets the trigger mode which determines the behavior of the instrument if no trigger occurs. The current setting is shown on the trigger label.

In a trigger sequence, the trigger mode affects only the A-trigger.

To toggle quickly between "Auto" and "Normal" mode, use the [Auto Norm] key on the front panel (in "Trigger" section).

"Auto"	The instrument triggers repeatedly after a time interval if the trigger conditions are not fulfilled. If a real trigger occurs, it takes precedence. This mode helps to see the waveform even before the trigger conditions are set correctly. The waveform on the screen is not synchronized, and successive waveforms are not triggered at the same point of the waveform. The time interval depends on the time-base settings.
"Normal"	The instrument acquires a waveform only if a trigger occurs, that is, if all trigger conditions are fulfilled. If no trigger occurs, no waveform is acquired and the last acquired waveform is displayed. If no waveform was captured before, none is displayed. When no trigger has been found for longer than one second, a message box appears that shows the time elapsed since the last trigger.
"Free run"	The instrument starts acquisition immediately and triggers after a short time interval independent of the timebase settings and faster than in "Auto" mode. Real triggers are ignored. Use this mode if the "Auto" mode is too slow.

Remote command:

[TRIGger:MODE](#) on page 1031

Force trigger

Provokes an immediate single acquisition. Force the trigger if the acquisition is running in normal mode and no valid trigger occurs. Thus, you can confirm that a signal is available and use the waveform display to determine how to trigger on it.

Remote command:

[TRIGger:FORCe](#) on page 1032

Holdoff mode

Selects the method to define the holdoff condition.

The trigger holdoff defines when the next trigger after the current will be recognized. Thus, it affects the next trigger to occur after the current one. Holdoff helps to obtain stable triggering when the oscilloscope is triggering on undesired events.

Holdoff settings are not available if the trigger source is an external trigger input or serial bus, and if you trigger on a sequence of events.

Example:

For example, you want to analyze the first pulse in a burst of several pulses. At first, you select a sufficiently slow time base to display the entire burst. Then, you set the holdoff time a little longer than the length of the burst. Now, each trigger corresponds to the first pulse in successive bursts, and you can change the time base to display the waveform in more detail.

The following methods are available:

"Time"	Defines the holdoff directly as a time period. The next trigger occurs only after the "Holdoff time" has passed.
"Events"	Defines the holdoff as a number of trigger events. The next trigger only occurs when this number of events is reached. The number of triggers to be skipped is defined in "Holdoff events".
"Random"	Defines the holdoff as a random time limited by "Minimum time" and "Maximum time". For each acquisition cycle, the instrument selects a new random holdoff time from the specified range. Random holdoff prevents synchronization to discover effects invisible with synchronized triggering, for example, the features of a pulse train.
"Auto"	The holdoff time is calculated automatically based on the current horizontal scale. "Auto time scaling" defines the factor that the horizontal scale is multiplied with. "Auto time" shows the resulting holdoff time: <i>Auto time = Auto time scaling * Horizontal scale</i> .
"Off"	No holdoff

Remote command:

[TRIGger:HOLDoff:MODE](#) on page 1032

[TRIGger:HOLDoff:TIME](#) on page 1034

[TRIGger:HOLDoff:EVENTs](#) on page 1034

[TRIGger:HOLDoff:MAX](#) on page 1034


[TRIGger:HOLDoff:MIN](#) on page 1034

[TRIGger:HOLDoff:AUTotime?](#) on page 1033

[TRIGger:HOLDoff:SCALing](#) on page 1033

7.6 Hysteresis

Access: "Menu">"Trigger" > "Hysteresis"



The rejection of noise by setting a hysteresis avoids unwanted trigger events caused by noise oscillation around the trigger level. You can select the hysteresis mode and value for each channel separately.

HW hysteresis

Displays the hysteresis that is set by the instrument in automatic hysteresis mode.

Remote command:

[TRIGger:NOISe<m>:EFFective?](#) on page 1035

Hysteresis mode

Selects how the hysteresis is set.

"Auto" Automatic mode is the recommended mode. The hysteresis is set by the instrument to reject the internal noise of the instrument.

"Manual" The hysteresis is defined directly in absolute or relative values.

Remote command:

[TRIGger:NOISe<m>:MODE](#) on page 1036

Size mode

Selects whether the hysteresis is defined in absolute or relative values. The setting is available only in manual hysteresis mode.

Remote command:

[TRIGger:NOISe<m>:MODE](#) on page 1036

Absolute hysteresis

Defines a range in absolute values around the trigger level. If the signal oscillates inside this range and thus crosses the trigger level, no trigger event occurs.

Remote command:

[TRIGger:NOISe<m>:ABSolute](#) on page 1035

Relative hysteresis

Defines a range in divisions around the trigger level in division or as percentage. If the signal oscillates inside this range and thus crosses the trigger level, no trigger event occurs.


Remote command:

[TRIGger:NOISe<m>:PERDivision](#) on page 1036

[TRIGger:NOISe<m>:RELative](#) on page 1036

7.7 Channel filter

Access: "Menu">"Trigger" > "Channel filter"

**Trigger filter mode**

Selects the filter mode for the trigger channel.

- "Off" The trigger signal is not filtered.
- "LF reject" Frequencies lower than the "LF reject BW" are rejected, higher frequencies pass the filter.
- "RF reject" Frequencies higher than the "RF reject BW" are rejected, lower frequencies pass the filter.

Remote command:

[TRIGger:FILTermode](#) on page 1037

LF reject BW

Sets the limit frequency limit for the highpass filter of the trigger signal. Frequencies lower than this value are rejected, higher frequencies pass the filter.

Remote command:

[TRIGger:LFRejeCt](#) on page 1038

RF reject BW


Sets the limit frequency limit for the lowpass filter of the trigger signal. Frequencies higher than this value are rejected, lower frequencies pass the filter.

Remote command:

[TRIGger:RFReject](#) on page 1038

7.8 Actions on trigger

Access: "Menu" > "Trigger" > "Action" tab



The action settings define what happens when a trigger occurs. All available actions can be initiated at the same time. To activate an action, set it to "On trigger".

Beep

Generates a beep sound.

Remote command:

[TRIGger:ACTions:BEEP](#) on page 1038

Stop acq

Stops the acquisition when a trigger occurs.

Remote command:

[TRIGger:ACTions:STOP](#) on page 1040

Save wfm

Saves the waveform data to a file according to the folder, filename and extension settings in the "Menu" > "Save/recall" > "Save" > "Waveform" dialog.

To select the waveforms and adjust the file path, tap the settings icon .

See also [Section 13.4.2, "Saving waveforms"](#), on page 450.

Remote command:

[TRIGger:ACTions:WFMSave](#) on page 1040

Screenshot

Saves a screenshot according to the settings in the "Menu" > "Save/recall" > "Save" > "Screenshot" dialog.

To adjust the screenshot settings, tap the settings icon .

See also [Section 13.8, "Screenshots"](#), on page 469.

Remote command:

[TRIGger:ACTions:SCReenshot](#) on page 1040

Trigger out pulse

Selects, if a pulse is provided to the [Trigger Out] connector on the rear panel. The trigger-out signal is used to synchronize the measurements of other instruments.


To adjust the outgoing signal, tap the settings icon .

Remote command:

[TRIGger:ACTions:OUT:STATe](#) on page 1039

Settings for the trigger out pulse

In this dialog you can adjust the trigger out pulse.

**Signal source ← Settings for the trigger out pulse**

Defines when the trigger out signal is initiated: at the trigger point, when waiting for the trigger, or when the post-trigger time is finished.

Remote command:

[TRIGger:ACTions:OUT:SOURce](#) on page 1039

Polarity ← Settings for the trigger out pulse

Sets the polarity of the trigger out pulse, which is the direction of the first pulse edge.

Remote command:

[TRIGger:ACTions:OUT:POLarity](#) on page 1040

Delay ← Settings for the trigger out pulse

Defines the delay of the first pulse edge to the trigger point. The minimum delay is 600 ns.

Remote command:

[TRIGger:ACTions:OUT:DELay](#) on page 1039

Pulse length ← Settings for the trigger out pulse

Sets the length of the trigger out pulse.

Remote command:

[TRIGger:ACTions:OUT:PLENgtH](#) on page 1039

7.9 Zone trigger

The zone trigger triggers on the intersection or non-intersection of the signal and one or more zones. The zone can be applied to any active input signal like the normal hardware trigger, and also to math waveforms, XY-plots and normal spectrum traces. So, the zone trigger works in the time domain and in the frequency domain.

You can use the zone trigger, for example, to solve the following tasks:

- Triggering on differential math signals.




Figure 7-5: Zone trigger on math

- Trigger if a peak in the spectrum occurs: define a zone in the spectrum diagram to filter amplitude peaks.




Figure 7-6: Zone trigger on spectrum

- Separate rising and falling edges: define a zone around the base or top of the digital signal.




Figure 7-7: Zone trigger on digital serial pattern

- Zoom on a trigger event, even when capturing large amounts of time.




Figure 7-8: Zoom on a zone trigger in the mV and ns range

- Filter events in the history after the acquisition has finished.

The zone trigger is the second step of the "A → ZoneTrigger" trigger sequence and acts like a filter on previous acquisitions. The A-trigger condition and then the zone condition must be fulfilled independently.

Note that the trigger mode applies only to the A-trigger. If only the zone trigger conditions are relevant for the trigger, you can set the trigger mode to "Free run". Thus, you can use the zone trigger to trigger on a spectrum trace without triggering on a signal in the time domain, or you can analyze DC signals.

When an acquisition fulfills the complete trigger definition including the zone trigger, the acquisition is kept in the history memory. Otherwise, the acquisition is discarded. Moreover, you can apply the zone trigger to stored history waveforms that were acquired without zone trigger and thus filter the history waveforms on replay.

Trigger zone definition

With the MXO 5C, you can define up to 4 trigger zones. A zone consists of up to 8 areas associated with a single source. In total, 32 areas can be defined.




Figure 7-9: 1 trigger zone with 8 areas

The zone is applied to the diagram onto which it is drawn and has the color of the source. All areas of the zone have to be in the same diagram. If a zone is shown in a diagram for which it is not applied, for example in a zoom diagram, it is shown in a gray color.




Figure 7-10: Trigger zone and a zoom diagram

Trigger zones can be applied to different sources, for example, the source of zone 1 is channel 1, and the source of zone 2 is a math signal. For the zone trigger condition, the zones are combined by Boolean operators: AND, OR, XOR, NOT. Thus, you can trigger on different waveform types simultaneously.

Trigger area definition

An area is a graphical shape on the screen, defined by pixels. It is a part of the zone for a trigger. The area has the following characteristics:

- An area is a polygon that is applied against a captured waveform. All areas of the same zone have the same source.




Figure 7-11: 1 area of a trigger zone

- An area can be defined from 3 up to 16 sides.



Figure 7-12: Area sizes

- 1 = 3 point area with "Intersection" = "Must not"
 2 = 16 point area with "Intersection" = "Must"

- A zone area can have only one range in y-direction at a certain time point. If a shape is not valid, the invalid point is marked red, and an attention symbol is shown at the area name.




Figure 7-13: Invalid zone area (left) and valid zone area (right)

To check the validity in remote control, use `ZONE<m>:AREA<n>:VALid?` and `ZONE<m>:AREA<n>:POINT<o>:VALid?`.

- Next to each point, the number of the point and the horizontal and vertical values are shown.



Figure 7-14: Area point definition

- 1 = Number of the point
- 2 = Horizontal and vertical values of the point

- An area has a defined intersect condition, defining if the signal must intersect the area to allow the instrument to trigger, or if it must not intersect the area. On the screen, an area that fulfills a "Must" condition has a solid fill in the color of the source channel. An area that fulfills a "Must not" also has the same color as the source channel, but is striped.

7.9.1 Using trigger zones and areas

You can define the trigger zones on the display through the toolbar:

To add trigger zones and areas

- Tap the "Add zone trigger" icon on the toolbar.



The trigger zone toolbar opens.



2. Select the "Source" of the zone, the signal to which the zone condition is applied.
3. Select if the signal must violate the zone to cause a trigger ("Intersect" = "Must"), or vice versa ("Intersect" = "Must not").
4. Tap "Add zone".
5. Draw a rectangle in the diagram to create the first area of a new zone trigger.
6. To add more areas to the zone, tap "Add Area".




7. Draw a rectangle in the same diagram to add a new trigger area.
8. Select if the signal must violate the area to cause a trigger (must intersect), or vice versa (must not intersect).
9. You can add more areas and further more zones to the zone trigger.

Make sure to draw them in the correct diagram because zones affect only the diagram where they were defined.

To edit an existing area

1. Tap an existing zone area.
2. To change the shape of the zone area, tap the corner points of the zone on the SmartGrid.
3. Move the point to the required coordinates on the SmartGrid.
4. If necessary, add more points to the zone area:
 - a) In the toolbar, tap "Add point".



- b) Tap outside of the area to add the new point.
- c) If necessary, add more points.
- d) If necessary to change the coordinates of a point, tap on it and move it.

To delete an area or point

1. Tap an existing zone area.
2. In the "Edit area" toolbar, tap the delete icon.
3. Tap on the area that you want to delete or edit.




Delete icons appear at the area points and in the middle of the area.


4. To delete a point from the area, tap on the "Delete" icon on top of the point.
5. To delete the whole area, tap the "Delete" icon in the middle of the area next to the area "Label".

7.9.2 Zone trigger settings

Access: "Menu" > "Trigger" > "Setup" tab > select sequence with zone trigger > "Setup Z trigger" > "Setup" tab, or: Toolbar > "Add zone trigger" icon > "Advanced setup".

In this dialog, you can add zones and areas to your zone trigger and adjust their shapes.



**Add zone, +**

Adds a new trigger zone. You can add up to four zones.

Remote command:

`ZONE<m>:ADD` on page 1041

Display

Enables the display of the zone on the screen.

Remote command:

`ZONE<m>[:VISible]` on page 1047

Source

Sets the source of the zone trigger. The zone can be applied to any active input signal, math waveform, XY-plot, normal spectrum trace and power waveforms.

Reference waveforms are not supported as a source for the zone trigger. Thus, also math waveforms are not supported if they are calculated on reference waveforms.

Remote command:

`ZONE<m>:SOURce` on page 1047

Area

Defines the area and its condition for the zone.

`" +Area "` Adds a new area to the zone. You can add up to 8 areas.

"Intersect"	Defines if the signal must intersect the area to allow the instrument to trigger, or if it must not intersect the area.
"Label"	Defines a label for the selected area.
"Combination"	Sets the logic combination that applies to all areas in a zone. Available are "AND" or "OR". Example: If three areas are defined and the combination is "OR", then the Boolean state of the zone is Zone1 = Area1 OR Area2 OR Area3..

Remote command:

[ZONE<m>:AREA<n>:ADD](#) on page 1042

[ZONE<m>:AREA<n>:COUNT?](#) on page 1042

[ZONE<m>:AREA<n>:INTERsect](#) on page 1043

[ZONE<m>:AREA<n>:LABel](#) on page 1043

[ZONE<m>:ACOMbination](#) on page 1042

Delete icon

Enables the removal of areas of the zone.

You can also delete all current areas with "Delete All".


Remote command:

[ZONE<m>:REMove](#) on page 1047

[ZONE<m>:AREA<n>:REMove](#) on page 1046

7.9.3 Logic operator settings

Access: "Menu" > "Trigger" > "Setup" tab > select sequence with zone trigger > "Setup Z trigger" > "Logic operator" tab.




Trigger condition

Sets a logical expression for the trigger condition between different defined zones.

If all required zones are defined, you can type the logical expression directly, or use the trigger condition editor.

Double-tap the "Trigger condition" field to open the editor:



The keys of the "Trigger condition" editor are described in [Trigger condition keys](#).


Table 7-1: Trigger condition keys

Icon	Description
and	And
not	Must not intersect
or	Or
xor	Exclusive or
Zone	Selects the zone
Clr	Clear expression in editor
(	Left bracket to enclose operands
)	Right bracket to enclose operands
←	Moves cursor to beginning
←	Moves cursor 1 step to the left
→	Moves cursor 1 step to the right
→	Moves cursor to end

Remote command:
`TRIGger:ZONE:EXPRession[:DEFine]` on page 1042

7.9.4 History settings

Access: "Menu" > "Trigger" > "Setup" tab > select sequence with zone trigger > "Setup Z trigger" > "History" tab.



When a zone trigger is defined, the history saves only acquisitions that fulfill the complete trigger condition including the zone trigger condition. On the other hand, you can use the current zone trigger definition to filter the history replay.

Apply zone trigger to history

If enabled, the instrument applies the zone trigger condition to the acquisitions that are stored in the history memory. Tap "History" to open the history player and analyze the filtered waveforms.

Using "Apply zone trigger to history", you can:

- Acquire waveforms with high speed and filter them afterwards in the history.
- Change the zone trigger condition after acquisition.

Remote command:

`TRIGger:ZONE:HISTory` on page 1047

8 Signal configuration

8.1 Reference level setup

Some measurements and analysis tasks require reference levels to obtain the measurement points, e.g. time measurements or timing reference. You can define 8 sets of reference levels. During configuration of the analysis task, you select which set of reference levels is used.

Access: "Menu" > "Apps" > "General" tab > "Signal config" > "Reference level" tab

The screenshot displays the 'Reference level' configuration screen. On the left, a sidebar contains a 'Reference level' button. The main area is divided into two columns. The left column is for 'RL1' and the right for 'RL2'. At the top right are '+' and trash icons. The 'Level mode' is set to 'Relative' with a dropdown arrow. The 'Relative levels' section has a 'User-defined' dropdown. The 'Upper level' is set to 90 % and the 'Lower level' is set to 10 %. The 'Hysteresis' is set to 10 %. The 'Middle level' is set to 50 %.

RL1	RL2
Level mode Relative	Relative levels User-defined
Upper level 90 %	Middle level 50 %
Lower level 10 %	
Hysteresis 10 %	

Figure 8-1: Relative reference level settings




Figure 8-2: Absolute reference level settings

RLx

Select the correct reference level tab before you enter the settings.

You can add up to 8 reference levels.

Remote command:

[REFLevel<rl>:ENABLE](#) on page 1048

Level mode

Defines if the reference level is set in absolute or relative values.

Remote command:

[REFLevel<rl>:LMODE](#) on page 1049

Absolute Level mode

In the absolute mode, the reference values are set in absolute values with the unit of the vertical axis.

Upper level, Middle level, Lower level ← Absolute Level mode

Set the lower, middle and upper reference signal levels.

Remote command:

[REFLevel<rl>:ABSolute:LLEVEL](#) on page 1049

[REFLevel<rl>:ABSolute:MLEVEL](#) on page 1049

[REFLevel<rl>:ABSolute:ULEVEL](#) on page 1050

Relative Level mode

In the relative mode, the reference values are set as percentages of the signal amplitude.

Relative levels ← Relative Level mode

Selects the lower, middle and upper reference levels, defined as percentages of the signal amplitude.

Available relative levels:

- 5/50/95
- 10/50/90
- 20/50/80
- User defined: Enter "Upper level", "Middle level", and "Lower level".

For example, for "5/50/95" the levels are set to the following values:

- Lower level = 5% of the signal amplitude
- Middle level = 50% of the signal amplitude
- Upper level = 95% of the signal amplitude

Remote command:

[REFLevel<rl>:RELative:MODE](#) on page 1051

Upper level, Middle level, Lower level ← Relative Level mode

Define the reference levels in percent, if "Level mode" is set to "User-defined".

Remote command:

[REFLevel<rl>:RELative:LOWer](#) on page 1050

[REFLevel<rl>:RELative:MIDDle](#) on page 1051

[REFLevel<rl>:RELative:UPPer](#) on page 1052

Hysteresis

Defines a hysteresis for the middle reference level. A rise or fall from the middle reference value that does not exceed the hysteresis is rejected as noise.

Remote command:

[REFLevel<rl>:ABSolute:HYSTeresis](#) on page 1049

[REFLevel<rl>:RELative:HYSTeresis](#) on page 1050


8.2 Gate setup

Gate areas limit various measurements to a user-defined range of the waveform.

You can define up to 8 separate gates. You can define absolute or relative limit values, or use an existing zoom, cursor set or spectrum as a gate.

Then, you assign the gates to analysis tasks, for example, to measurements or power analysis.

Access: "Menu" > "Apps" > "General" tab > "Signal config" > "Gate" tab



+ Add

Creates a new gate.

Remote command:

[GATE<g>:ENABle](#) on page 1053

Coupling mode

The gate coupling mode selects how the gate area is defined.

"Manual"	Manually define the gate with a user-defined start and stop values.
"Cursor"	Cursor coupling is available if a cursor is defined. The gate area is defined by the cursor lines of an active cursor measurement. If several cursor measurements are enabled, select the "Cursor" to be used for gating. The start and stop values of the gate are adjusted to the values of the cursor line positions. The measurement is limited to the part of the waveform between the cursor lines.
"Zoom"	Zoom coupling is available if a zoom is defined. The gate area is defined identically to the zoom area - if you change the zoom, the gate changes as well. If several zoom diagrams are defined, select the "Zoom" diagram to be used for gating. The start and stop values of the gate are adjusted to the values of the zoom positions.
"Spectrum"	Spectrum coupling is available if a spectrum is enabled. If several spectrums are enabled, select the "Spectrum" diagram to be used for gating.

Remote command:

[GATE<g>:GCoupling](#) on page 1053

[GATE<g>:CURSor](#) on page 1054

[GATE<g>:ZDiagram](#) on page 1054

Mode, Start, Stop

Selects if the gate settings are configured using absolute or relative values.

"Absolute"	The gate is defined by absolute start and stop values with "Start" and "Stop".

"Relative" The gate's start and stop values are defined by a percentage of the value range with "Relative start" and "Relative stop".

Lightning symbols in the value fields indicate that the gate is not yet assigned to any measurement.

Remote command:

[GATE<g>:MODE](#) on page 1054

[GATE<g>:ABSolute:START](#) on page 1055

[GATE<g>:ABSolute:STOP](#) on page 1055

[GATE<g>:RELative:START](#) on page 1055

[GATE<g>:RELative:STOP](#) on page 1055

8.3 Timing reference

The timing reference is the clock that is used for jitter measurements, for example. You can configure up to 4 timing references. The clock can be a captured clock signal, or it can be recovered from the data signal by software CDR.

8.3.1 General settings of the timing reference

Access: "Menu" > "Apps" > "General" tab > "Signal config" > "Timing reference".

Type

Defines the origin of the clock signal - either an existing clock signal or waveform, or a clock generated by clock data recovery (CDR).

"Explicit clock" The clock is an existing clock signal.

"Software CDR" The clock is generated by a software algorithm.

Remote command:

[TREReference<m>:TYPE](#) on page 1063

Reference levels

Selects the set of reference levels that is used for the timing reference measurements.

Remote command:

[TREReference<m>:RFLSet](#) on page 1062

8.3.2 Explicit clock signal

Access: "Menu" > "Apps" > "General" tab > "Signal config" > "Timing reference" > "Type" = "Explicit clock".

The screenshot shows a configuration window for a timing reference, labeled 'TR1'. On the left is a sidebar with a 'Timing reference' tab selected. The main area contains the following settings:

- Type:** Explicit Clock (dropdown)
- Source:** Channel 1 (dropdown)
- Gate:** None (dropdown)
- Reference Levels:** 1 (dropdown)
- Reference level:** Middle (dropdown)
- Clock frequency:** 500 MHz
- Clock multiplier:** 1
- Clock edges:** Either (dropdown)
- Symbol rate:** 1 GBd
- Clock offset:** 0 UI

Reference level

Selects the reference level that is used for the timing reference measurement if the clock is an existing clock signal.

Remote command:

[TRReference<m>:CLK:REFLevel](#) on page 1060

Source

Selects the clock source if the clock is an existing clock signal.

Remote command:

[TRReference<m>:SOURce](#) on page 1062

Clock frequency

Sets the frequency of the clock signal. The setting is relevant if the clock is an explicit clock signal.

Remote command:

[TRReference<m>:CLK:FREQuency](#) on page 1059

Clock multiplier

Sets a value for the clock multiplier, which is the ratio of an internal clock rate to the externally supplied clock. It defines the number of samples per clock interval. The setting is relevant if the clock is an explicit clock signal.

Remote command:

`TREference<m>:CLK:FACTOR` on page 1059

Clock edges

Sets the clock edges that are used for measurements. The setting is relevant if the clock is an explicit clock signal.

"Positive" The positive clock slope can be used, for example, for single data rate (SDR) signals with bit start at the positive clock edge.

"Negative" The negative clock slope can be used, for example, for SDR signals with bit start at the negative clock edge.

"Either" Both edges can be used for double data rate (DDR) signals.

Remote command:

`TREference<m>:EDGE` on page 1060

Symbol rate

Shows the symbol rate of the data signal. The setting is relevant if the clock is an explicit clock signal.

$SymbolRate = ClockFrequency * Multiplier * EdgeCount$, where $EdgeCount = 2$ for either slope and $EdgeCount = 1$ for positive and negative slopes.

Remote command:

`TREference<m>:SYMRate` on page 1063

Clock offset

Sets the offset between the clock edge and the data edge in unit intervals. The setting is relevant if the clock is an explicit clock signal.


Remote command:

`TREference<m>:CLK:OFFSet` on page 1060

8.3.3 Clock data recovery by software CDR

Access: "Menu" > "Apps" > "General" tab > "Signal config" > "Timing reference" > "Type" = "Software CDR".

If "Type" is set to "Software CDR", you need to set up the algorithm for the clock data recovery.



Data edges

Selects the edges of the data stream that are used for the clock recovery.

- "Either": Both positive and negative edges are used.
- "Positive" or "Negative": Only one edge direction is used. Use one of these settings if the other edge delivers unreliable results.

Remote command:

[TREReference<m>:EDGE](#) on page 1060

Symbol rate

Sets the quiescent frequency of the PLL. It corresponds to the data rate of the data stream from which the clock is to be recovered.

Remote command:

[TREReference<m>:SYMRate](#) on page 1063

Estimate symbol rate

Starts a software algorithm to detect the symbol rate for the selected source automatically.

Remote command:

[TREFerence<m>:CDR:SOFTware:SREStimate](#) on page 1058

Algorithm

Sets the software algorithm that is used for software clock data recovery.

Back	Algorithm PLL (lock at acq. start)	
	Bandwidth 599.88 kHz	Rel. bandwidth 1667
	Order 2nd order	Damping 0.7

"Constant freq."

CDR uses the nominal symbol rate to generate the clock signal. The method assumes that the frequency of the signal is constant during the complete acquisition.

"PLL"

PLL is the phase-locked loop control system. It can follow slow deviations in the frequency of the data stream. Thus, it acts as a highpass filter regarding the jitter that remains on the signal.

"Feed Forward"

The feed-forward algorithm is a mathematical optimization method used for clock data recovery. It is faster than PLL, i.e., the settling time is shorter. Feed forward is also more precise than PLL.

"PLL (lock at acq. start)"

Phase-locked loop control system, which is locked at the acquisition start.

Remote command:

[TREFerence<m>:CDR:SOFTware:ALGorithm](#) on page 1056

Clock resync

Enables continuous synchronization of the clock with the data signal. At constant clock frequency without resync, the clock starts at the first detected edge and clocks with the given or estimated bit rate or symbol rate. With synchronization, the clock searches for the next edge and synchronizes to this edge. Thus, the sampling points are not exactly at constant frequency but aligned to the defined edges of the data signal.

Remote command:

[TREFerence<m>:CDR:SOFTware:CFRequency:CRSYnc](#) on page 1057

Bandwidth

Sets the PLL bandwidth. It defines the part of the spectrum that the PLL can follow during synchronization. The PLL bandwidth is usually defined by the transmission standard.

Remote command:

[TREFerence<m>:CDR:SOFTware:BWIDth](#) on page 1057

Rel. bandwidth

Sets the relative bandwidth, which is the ratio of the nominal bit rate to the PLL bandwidth.

Remote command:

[TREFerence<m>:CDR:SOFTware:RELBwidth](#) on page 1058

Order

Sets the order of the PLL: first or second order. PLL of higher order can compensate for more complex jitter behavior.

Remote command:

[TREFerence<m>:CDR:SOFTware:PLL:ORDer](#) on page 1058

Damping

Sets the damping factor, which is only relevant for second order PLL.

Remote command:

[TREFerence<m>:CDR:SOFTware:PLL:DAMPing](#) on page 1057

Initial phase sync

Available for "Algorithm" = "PLL".

Defines the phase reference for the first clock edge.

"First data edge" The first clock edge matches the first edge of the data signal.

"First sample" The first clock edge matches the first sample of the waveform at the left border of the display.

Remote command:

[TREFerence<m>:CDR:SOFTware:PLL:SYNC](#) on page 1058

Selected results

Available for "Algorithm" = "PLL".

The PLL requires some time to synchronize to the phase of the data stream. You can select when the CDR algorithm returns clock edges:

"All" All clock edges are used.

"After initial sync." The clock edges of the synchronization time are discarded; results are gathered after initial synchronization of the CDR. Thus, meaningful TIE measurement results can be obtained.

Remote command:

[TREFerence<m>:CDR:SOFTware:SELResults](#) on page 1059

9 Waveform analysis

This chapter describes general methods to check and analyze waveforms. These are:

• Zoom	219
• Mathematics	223
• History	235
• Reference waveforms	241
• Waveform histograms	250

9.1 Zoom

The zoom magnifies a part of the waveform to view more details. The zoom is applied to all waveforms that are visible in a diagram.

For each diagram, you can define one zoom area.

- You can define the zoom by drawing, moving and adjusting the zoom area on the touchscreen.
- You can precisely define the size of the zoom area by entering start and stop values in a dialog box.


Zoomed waveforms are shown in separate zoom diagrams, in addition to the waveform diagrams. On the original waveform diagram, a rectangle indicates the zoomed section of the waveform - this is the zoom area. You can modify the zoom area by moving the rectangle as a whole, and by moving its edges. To toggle between these modes, tap the zoom area. You can also set exact positions.

Zoom areas can be used for gating, for example, to define a measurement gate. You can set the gate exactly to the limits of the zoom.

9.1.1 Zoom settings

Access: "Menu" > "Horizontal" > "Zoom" tab.

The "Zoom" tab allows you to specify start and stop values for the x- and y-axes. The acquired data within these ranges is zoomed.

**Tabx**

Selects one of the enabled SmartGrid layouts.

Zx

Selects the zoom window. You can add up to 8 different zooms.

State

Enables the zoom.

Remote command:

[LAYout<ly>:ZOOM<zo>\[:ENABle\]](#) on page 1065

Diagram

Indicates which of the waveform diagrams is selected for zooming. The number is displayed on the screen in the middle of each diagram.

Remote command:

[LAYout<ly>:ZOOM<zo>:SOURce](#) on page 1069

Start Stop, Position range

Selects how the window for the zoom diagram is defined. You can select between defining "Start Stop" values or "Position range".

Start Stop

The "Start Stop" tab allows you to specify start and stop values for the x- and y-axes. The acquired data within these ranges is zoomed.

According to the selected "Mode", absolute or relative values are used.

"Start", "Relative start"

Defines the lower limit of the zoom area on the axis.

"Stop", "Relative stop"

Defines the upper limit of the zoom area on the axis.

Remote command:

[LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:START](#) on page 1066

[LAYout<ly>:ZOOM<zo>:HORizontal:RELative:START](#) on page 1068

[LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:STOP](#) on page 1066

[LAYout<ly>:ZOOM<zo>:HORizontal:RELative:STOP](#) on page 1069

[LAYout<ly>:ZOOM<zo>:VERTical:RELative:START](#) on page 1072

[LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:START](#) on page 1070

[LAYout<ly>:ZOOM<zo>:VERTical:RELative:STOP](#) on page 1072

[LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:STOP](#) on page 1071

Position range

If "Position range" is selected, you specify the x and y position of center point of the zoom area plus a range for the x- and y-axes. The area defined by that point and the ranges is zoomed. You can set absolute values or relative values (in percent of the screen, depending on the "Mode" selection.

"Range" Defines the width or height of the zoom area.

"Position" Defines the x or y value of the centerpoint of the zoom area.

Remote command:

[LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:POSition](#) on page 1065

[LAYout<ly>:ZOOM<zo>:HORizontal:RELative:POSition](#) on page 1067

[LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:SPAN](#) on page 1066

[LAYout<ly>:ZOOM<zo>:HORizontal:RELative:SPAN](#) on page 1068

[LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:POSition](#) on page 1070

[LAYout<ly>:ZOOM<zo>:VERTical:RELative:POSition](#) on page 1071

[LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:SPAN](#) on page 1070

[LAYout<ly>:ZOOM<zo>:VERTical:RELative:SPAN](#) on page 1072

Set to screen

Sets the zoom area to the whole screen.

Remote command:

[LAYout<ly>:ZOOM<zo>:SSCreen](#) on page 1073

Mode

Defines if absolute or relative values are used to specify the "Horizontal" (x-axis) and the "Vertical" (y-axis) values.

Remote command:

LAYout<ly>:ZOOM<zo>:HORizontal:MODE on page 1067

LAYout<ly>:ZOOM<zo>:VERTical:MODE on page 1071

9.1.2 Zooming for details

To define the zoom area on the touchscreen

For graphical zooming, you use your finger on the screen.

1. On the toolbar, tap the "Add zoom" icon.



The zoom overlay menu opens.



2. Draw a rectangle in the diagram that defines the zoomed area.
While you drag your finger on the screen, a dotted rectangle indicates the current zoom area.

The indicated area is magnified in a new zoom diagram. The original diagram shows the zoom area as a rectangle.
3. If the position of the zoom area is not correct, drag the rectangle in the overview to the correct position.
4. If the size of the zoom area is not yet ideal, tap the rectangle in the overview diagram.
Now, 4 white lines indicate the edges of the zoom area. A dashed white line indicates the selected edge, which you can adjust.
5. Touch the edge that you want to move. Drag it to the required position.

To create a zoom using the zoom dialog box

- If you want to create a new, unconfigured zoom, tap the "Add" icon.



To define the zoom area numerically using start/stop values

1. Open "Menu" > "Horizontal".
2. In the "Zoom" tab, select "Start Stop".

3. Select a value for "Mode" > "Horizontal" to define "Absolute" or "Relative" x-axis values. Relative values cause the zoom area to adapt to the input values dynamically.
4. For "X", define the "Relative start" and "Relative stop" values. They define the lower and upper borders of the zoom area on the x-axis.
5. Select the "Mode" > "Vertical" to define "Absolute" or "Relative" y-axis values.
6. For "Y", define the "Relative start" and "Relative stop" values. They define the lower and upper borders of the zoom area on the y-axis.

When you close the dialog box, the specified area is magnified in a new zoom diagram. The original diagram is displayed with the zoom area indicated as a rectangle.

To define the zoom area numerically using position and range values

1. Open "Menu" > "Horizontal".
2. In the "Zoom" tab, select "Position range".
3. Select "Mode" > "Horizontal" to define "Absolute" or "Relative" x-axis values. Relative values cause the zoom area to adapt to the input values dynamically.
4. Under "X" > "Position", define the x-value of the center point of the zoom area.
5. Under "X" > "Range", define the width of the zoom area.
6. Select the "Mode" > "Vertical" to define "Absolute" or "Relative" y-axis values.
7. Under "Y" > "Position", define the y-value of the center point of the zoom area.
8. Under "Y" > "Range", define the height of the zoom area.

When you close the dialog box, the specified area is magnified in a new zoom diagram. The original diagram is displayed with the zoom area indicated as a rectangle.

9.2 Mathematics

Math waveforms are calculated waveforms. You can define up to 8 math waveforms and display them on the screen, and use it as source for further analysis.

It is calculated out of one or two analog channels, or another math waveform using several predefined operations. You can define up to 5 equations. The complete configuration is called equation set and can be saved for later use.

Activating math waveforms reduces the available memory.

You can analyze math waveforms in the same way as channel waveforms: use zoom, perform automatic and cursor measurements, and save as reference waveform.

You can store a math waveform as a reference waveform and restore it later. See [Section 9.4, "Reference waveforms"](#), on page 241.

9.2.1 Creating math waveforms

Math waveforms are created and displayed in addition to the channel and other waveforms. They can also be used for analysis, e.g. measurements, even if the math waveform is not active.

1. Open "Menu" > "Math" > "Setup".
Alternatively, press the [Math] key.
2. Define the mathematic operation with one of the following methods:
 - Use basic operations in "Operator" subtab.
 - Define a filtered waveform in the "Filter" subtab.
 - Create a mathematic equation in the formula editor on the "Equation" subtab.

3. Enable "Display".

The math waveform is displayed on the screen. A green dot in the math waveform tab indicates that the waveform is active.




4. To change the vertical scaling of the math waveform, open the "Scale" tab.
5. Set the "Scale mode" to "Manual".
6. Enter the "Vertical scale" factor (per division). If necessary, add a "Vertical offset".
Default is the automatic scaling.
7. Close the "Math" dialog box.

9.2.2 General math waveforms settings

Access: "Menu" > "Math" > "Setup" tab


You can define up to 8 different math waveforms. Each waveform is defined in a separate tab in the "Math" dialog.

You can find a summary of the state and operations of all math waveforms in the "All" tab.



This section describes the general settings in the "Setup" tab. The subtabs for the definition of the mathematic operation are explained separately:

- [Section 9.2.3, "Operator settings"](#), on page 225
- [Section 9.2.4, "Filter settings"](#), on page 227
- [Section 9.2.5, "Equations"](#), on page 229



Display

Activates the selected Math channel and displays the defined math waveforms.

Remote command:

`CALCulate:MATH<m>:STATe` on page 1073

Label

Defines a label for the selected math waveform.


Remote command:

`CALCulate:MATH<m>:LABel` on page 1075

9.2.3 Operator settings

Access: "Menu" > "Math" > "Setup" tab > "Operator".

To create simple math waveforms, use the settings in the "Operator" subtab. It provides common math functions.



Operator

Defines the type of operation to be performed on the selected signal sources.

The following functions are available:

"+"	Adds the values of 2 sources (channel or math waveform).
"-"	Subtracts source 2 from source 1.
"x"	Multiplies the two sources.
"/"	Divides source 1 by source 2.
"1/x"	Calculates the reciprocal of the source.
"- x"	Calculates the negative value of the source.
" x "	Determines the absolute value of the source.
" $\Delta x / \Delta t$ "	Differentiates the source value relating to the time value. Not possible on envelope waveforms and waveforms with "Peak detect" decimation.
"Integral"	Calculates the definite integral of the source.
"log(x)"	Calculates the logarithm of the source value based on 10.
"ln(x)"	Calculates the natural logarithm of the source value (based on e).
"ld(x)"	Calculates the binary logarithm of the source value (binary logarithm, based on 2).
"x ² "	Squares the source. If the source contains negative values that have been clipped, then the result contains positive clipping.
" $\sqrt{x}$ "	Calculates the square root of the source. Note that the square root of a negative number is undefined and the result is clipped.

"Rescale" Rescaling of x.

Remote command:

[CALCulate:MATH<m>\[:EXPRESSiON\]\[:DEFine\]](#) on page 1073

Source 1, Source 2

Defines the signal source to be evaluated by the math function.

a, b

Define the values for the rescale function, if "Operator" = "Rescale"

"a" Multiplication factor

"b" Offset of the signal source on the y-axis.

Noise reject

Only available for "Operator" = " $\Delta x/\Delta t$ ".

Sets the number of neighboring samples that are skipped for differentiation.

To suppress noise effects during differentiation, it can be useful not to consider two directly neighboring points to calculate dx ($x_n - x_{n-1}$). Instead, some samples in-between are skipped and a point a few samples further is used (e.g. $x_n - x_{n-3}$).

Envelope wfm selection

Selects the upper or lower part of the input waveform for mathematic calculation, or a combination of both.

Remote command:

[CALCulate:MATH<m>:ENVSelection](#) on page 1076

9.2.4 Filter settings

Access: "Menu" > "Math" > "Setup" > "Filter" tab

The finite impulse response filter is a filter to create filtered math waveforms with low-pass, highpass, or bandpass. The filter requires additional settings.

You can set up the filter in the "Filter" tab, or enter the filter formula in the formula editor. For details, see [Table 9-3](#).

You can also define the filter coefficients in a CSV file and use the file for filtering. See ["Bandpass and bandstop FIR filter with CSV file"](#) on page 228.

In remote control, filter settings are defined in the expression string, see [CALCulate:MATH<m>\[:EXPRESSiON\]\[:DEFine\]](#) on page 1073.

Operator	Filter	Equation
Type	Lowpass	Source
	▼	Channel 1
Cut-off	50 MHz	Characteristics
		▼
		Gaussian

Bandpass and bandstop FIR filter with CSV file

To define a bandpass or bandstop, you need a CSV file that contains the comma-separated filter coefficients in one row. The maximum number of filter coefficients is 100 000 taps. No other parameters are allowed in the file.

To create the CSV file, we recommend using the MATLAB Filter Design & Analysis tool. In the tool, enter the filter type, filter order and filter frequencies. Alternatively, you can create the filter and the CSV file with Python.

Make sure to set the sample frequency in MATLAB or Python and the sample rate at the oscilloscope to the same value. If the values differ, the filter is shifted in frequency.

On the MXO 5C, select "Menu" > "Math" > "Setup" > "Filter", the filter "Type" = "User defined", and load the CSV file.

Operator	Filter	Equation
Type	User defined	Source
	▼	Channel 1
Filter file		
/Analysis/Filters/bandpass.csv		
 Open		

All settings on the "Filter" tab are explained below.

Type

Selects if the filter is a highpass, lowpass, or user-defined filter (bandpass/bandstop filter defined in a CSV file).

Source 1

Selects the input channel of the signal.

Cut-off

Sets the limit frequency for the filter.

Cutoff frequency for lowpass filter

The cutoff frequency depends on the horizontal resolution and the filter characteristics. The cutoff frequency range for the lowpass filter is:

$$f_c = (0.01 \dots 0.2) * f_a \text{ for Gaussian FIR filter}$$

$$f_c = (0.01 \dots 0.4) * f_a \text{ for rectangular FIR filter}$$

Cutoff frequency for highpass filter

The highpass filter is always rectangular. The cutoff frequency range for the highpass filter is:

$$f_c = (0.01 \dots 0.4) * f_a$$

Where: f_c = cutoff frequency to be set for the lowpass filter, and f_a = reciprocal of the resolution, or sample rate of the postprocessing system (including, for example, interpolation).

Characteristics

Selects if a Gaussian or a rectangular shape is used for the lowpass filter. The highpass filter always uses a rectangular shape.

Filter file, Open

If the "User defined" filter type is selected, choose the file with the filter coefficients. Select "Filter file" to type the path and filename, or tap "Open" to select the file in the file browser.

For information on filter files, see ["Bandpass and bandstop FIR filter with CSV file"](#) on page 228.

9.2.5 Equations

In the "Equation" tab, you can enter complex formulas to define a math waveform. The formula editor helps to enter formulas easily with correct syntax, using a large selection of operators and signal sources.

1. In the "Math" dialog, open the "Equation" tab.
2. Double-tap on "Math formula" to display the formula editor.

9.2.5.1 Math formula editor

Using the formula editor you can define math functions freely, using a selection of operators and signal sources.

[9-1](#) shows an overview of the math formula dialog and its different sections. The separate functions are described below.

For a procedure to create equations, see [Section 9.2.5.2, "Defining a formula in the formula editor"](#), on page 233.




Figure 9-1: Math formula editor overview

- 1 = Math expression
- 2 = Numeric
- 3 = Unit
- 4 = Source
- 5 = Filters
- 6 = Algebra
- 7 = Math punctuation
- 8 = "Enter": press to complete the equation entry . The button is grayed out if the expression is not valid.
- 9 = Information display: additional information about the selected function is displayed.
- 10 = Cursor keys

Math expression

Use the various buttons of the editor to assemble the equation. If you know the exact syntax, you can also type the equation. You can see immediately whether the input is complete and correct.

We recommend connecting a keyboard to type the equations.




Figure 9-2: Math expression line

- 1 = Indicates the math waveform that is configured, e.g "Math 1" = "M1"
- 2 = Math expression input field
- 3 = Displays the status of the current expression: valid or not
- 4 = Displays a list of the last 20 used expressions

Buttons of the formula editor and their usage

Table 9-1: Source

Unit	Description
Analog channels	All analog channel waveforms of the device
Other math waveforms	All math waveforms of the device
Track channels	All track waveforms of a device
Reference	All reference waveforms of the device for which the source of reference is an analog channel (e.g. R3)

Table 9-2: Unit

Unit	Description
A	Ampere: the unit for electrical current.
V	Volt: the unit for electrical difference of potential
W	Watt: the unit for power. It is used to quantify the rate of energy transfer.
Ohm	Ohm: the unit for electrical resistance
Siemens	Siemens: the unit for electrical conductance
S	Second: the unit for time
Hz	Hertz: the unit for frequency, the number of occurrences of a repeating event per second.
dBm	dBm: the unit for power level. dBm is expressed in decibels (dB) with reference to 1 milliwatt (mW).
dB	dB: the unit for power gain, expressed in the base-10 logarithm of the ratio between two power levels.
dBμV	dBμV: the unit for voltage level. dBμV is expressed in decibels (dB) relative to 1μV across 50Ω resistance.
dBV	dBV: the unit for voltage level. dBV is expressed in decibels (dB) relative to 1V across 50Ω resistance
Degree	Degree: the unit for an angle. A degree is a measure of angle equal to 1/360 of a full rotation.
rad	Radian: the unit for an angle. 2π radians make up a full rotation.

If you type the unit, put it in square brackets, for example $C1[A]*C3[V]$. Additional parentheses are required if you want to assign the unit to the result of the equation, for example $(C1*C3)/[W]$

Table 9-3: Filters

Value	Usage/Comment <i>FormulaEditor</i> expression
FIR highpass	<i>FIR(highpass,source,limit,shape)</i>: source = input channel of the signal, limit = cutoff frequency shape = rectangle for the highpass filter Example: <i>FIR(highpass,C2,3e+09,rectangle)</i> Sets a rectangle highpass filter on Channel 2 with a 3 GHz cutoff frequency
FIR lowpass	<i>FIR(lowpass,source,limit,shape)</i> source = input channel of the signal limit = cutoff frequency shape = Gaussian or rectangle for the lowpass filter Example: <i>FIR(lowpass,C1,1e+07,gaussian)</i> Sets a Gaussian lowpass filter on Channel 1 with a 10 MHz cutoff frequency
FIR user defined	<i>FIR(userdef,source,path)</i> source = input channel of the signal path = string containing the path and filename of the filter file. The file contains the comma-separated filter coefficients. Example: <i>FIR(userdef,Ch1,"run/media/usb/<MyDriveName>//bandpass.csv")</i> Sets a bandpass on channel 1 with filter coefficients saved in the <code>bandpass.csv</code> file.

Table 9-4: Numeric

Icon	Description	Usage/Comment <i>FormulaEditor</i> expression
0...9	Numeric characters	
 Backspace	Erases the character before the cursor	
Clr	Clear expression in editor	Restart editing
e	Math. constants, Euler number	Euler number: 2.7182...
π	Math. constants, Pi	Pi: 3.14159...
.	Decimal point	
±	Changes the sign of the equation	

Table 9-5: Algebra

Icon	Description	Usage/Comment <i>FormulaEditor</i> expression
+	Addition	
-	Subtraction	
*	Multiplication	

Icon	Description	Usage/Comment <i>FormulaEditor expression</i>
/	Division	
a^b	Exponentiation with base a	a: base, b: exponent a^b
$ x $	Absolute x value	$abs(x)$
$\sqrt{x}$	Square root of x	$sqrt(x)$
x^2	$x*x$	$pow(x)$
$1/x$	Reciprocal of x	$1/(x)$
d/dx	Derivation of x	$Derivation(x,y)$ With x = waveform and y = number of skipped samples (noise reject)
$\int x dx$	Integral of x	$integral(x)$
$ax+b$	Scaling of x	$Rescale(x,a,b)$ With x = waveform, a= gain factor, and b= constant
$\log_{10}$	Decimal logarithm (base 10)	$log(x)$
$\log_e$	Natural logarithm (base e)	$ln(x)$
$\log_2$	Binary logarithm (base 2)	$ld(x)$

Table 9-6: Math punctuation

Icon	Description	Usage/Comment <i>FormulaEditor expression</i>
(	Left bracket	Enclose operands
)	Right bracket	Enclose operands
,	Comma	Separates operands
[	Left square bracket	Enclose unit
]	Right square bracket	Enclose unit

Table 9-7: Cursor keys

Icon	Description
←	Moves cursor to beginning
←	Moves cursor 1 step to the left
→	Moves cursor 1 step to the right
→	Moves cursor to end

9.2.5.2 Defining a formula in the formula editor

1. Open the "Menu" > "Math" dialog.


2. Select the "Equation" tab.
3. Double-tap the editing area.
The "Formula Editor" is displayed.
4. Enter the math formula including all required signal sources and operators by selecting the corresponding keys in the editor. For details on the available keys, see [Section 9.2.5.1, "Math formula editor"](#), on page 229.
5. To perform a rescaling function, proceed as follows:
 - a) Select the rescaling function using the "ax+b" key.
 - b) Behind the left bracket, insert the signal source using one of the following keys:
 - "Cx" for a channel
 - "Mx" for a math function
 - "Rx" for a reference waveform
 - c) After the first comma, insert the "a" value, i.e. the scaling factor, using the number keys.
 - d) After the second comma, insert the "b" value, i.e. the scaling offset, using the number keys.

The resulting expression could be, for example: `rescale (C1, 3, 4)`

6. To insert a unit, press "Unit". Select a value from the list.
If you type the unit, put it in square brackets, for example `C1[A]*C3[V]`. Additional parentheses are required if you want to assign the unit to the result of the equation, for example `(C1*C3)[W]`

9.2.6 Scale settings for math waveforms

Access: "Menu" > "Math" > "Scale" tab



Scale mode

By default, the vertical scale is adapted to the current measurement results automatically to provide an optimal display. However, if necessary, you can define scaling values manually to suit your requirements.

"Manual" Enter the required values for "Vertical scale" and "Vertical offset".

"Auto" "Vertical scale" and "Vertical offset" are read-only.

Remote command:

`CALCulate:MATH<m>:VERTical:SCALE:MODE` on page 1076

Vertical scale

Sets the scale of the y-axis in the math function diagram. The value is defined as "<unit> per division", e.g. *50 mV/div*. In this case, the horizontal grid lines are displayed in intervals of 50 mV.

If [Scale mode](#) is set to "Auto", this setting is read-only.

Remote command:

`CALCulate:MATH<m>:VERTical:SCALE[:VALue]` on page 1075

Vertical offset

Sets a voltage offset to adjust the vertical position of the math function on the screen. Negative values move the waveform up, positive values move it down.

If [Scale mode](#) is set to "Auto", this setting is read-only.

Remote command:

`CALCulate:MATH<m>:VERTical:OFFSet` on page 1075

Unit

Sets a user-defined unit for the math operation.

Remote command:

`CALCulate:MATH<m>:UNIT` on page 1075

9.3 History

The history accesses the data of previous acquisitions and provides them for further analysis.

9.3.1 About history

If a continuous acquisition runs, the captured data is stored in the sample memory and the current acquisition is processed and shown on the display. After the acquisition is stopped, the history accesses the captured samples that were stored, displays these samples as history waveforms, and makes them available for further analysis. It considers all channels that were enabled during the running acquisition.

When a new single acquisition is started, the memory is cleared and written anew. In continuous acquisition, stopping and starting the acquisition does not clear the memory, and the history memory is continued. When the memory is full, new acquisitions are stored, and the oldest are removed (first in, first out). The history memory is cleared when the acquisition parameters are changed. To clear the history memory on demand, use the "Clear" tool on the toolbar.




Figure 9-3: History memory. In this example, the memory can store 10 waveforms.

The number of stored history waveforms depends on the memory size, the number of enabled channels, and the record length. The shorter the record length, the less the number of channels, and the larger the memory, the more history waveforms are saved.

You can work with history waveforms in the same way as with the waveform of the latest acquisition: use zoom, cursors, measurements, create math waveforms and so on. You can also save a single history waveform for further analysis.


9.3.2 History setup

The "History" dialog contains the complete functionality on history viewing and information.

The most important information and functions are also provided in the quick-access history dialog box.

In the R&S ScopeStudio software, acquisition settings and functions that need an acquisition take effect if the channel source is a simulated waveform, created by the generator. If the channel source is loaded from a file, the acquisition-related settings can be imported with the data from the oscilloscope, either as a saveset, or included in a session. Changing imported acquisition-related settings has no effect.

Access: "Menu" > "Acquisition" > "History" tab.



Show history.....	237
Player.....	238
Start acq.....	238
Stop acq.....	238
Current acq.....	238
Overlay.....	238
Display time.....	238
Time stamp.....	239

Show history
Enables the history mode and allows you to save history waveforms to file.
The history display is enabled automatically when you press the [History] button.

To disable the history, you can also close the quick-access "History" dialog box.

Remote command:

[ACQUIRE:HISTORY\[:STATe\]](#) on page 1081

Player

The player can be used to control the playback of the history waveforms.

	Sets the oldest acquisition in the sample memory as "Start acq" and "Current acq".
	Starts and stops the replay of the history waveforms from "Start acq" to "Stop acq".
	Sets the newest acquisition in the sample memory as "Stop acq" and "Current acq". This acquisition always has the index "0".
	"Auto repeat": If selected, the playback of the selected history segments repeats automatically. See also: "Auto repeat" on page 240.

Remote command:

[ACQUIRE:HISTORY:PLAY](#) on page 1079

Start acq

Sets the index of the first (oldest) acquisition to be displayed or exported. The index is always negative.

Remote command:

[ACQUIRE:HISTORY:START](#) on page 1079

Stop acq

Sets the index of the last (newest) acquisition to be displayed or exported. The newest acquisition of the complete acquisition series always has the index "0".

Remote command:

[ACQUIRE:HISTORY:STOP](#) on page 1079

Current acq

Accesses a particular acquisition in the memory to display it, or to save it. The newest acquisition always has the index "0". Older acquisitions have a negative index.

If a history replay is running, the field shows the number of the currently shown acquisition.

Remote command:

[ACQUIRE:HISTORY:CURREnt](#) on page 1078

Overlay

Displays the segments with infinite persistence. Thus, you can see all data points of all displayed segments of a player cycle.

It is the same setting as ["Infinite persistence"](#) on page 102.

Display time

Sets the display time for one acquisition. The shorter the time, the faster the replay is.

The setting takes effect for usual history replay and the display of a fast segmentation series via the history.

Remote command:
[ACQuire:HISTory:TPACq](#) on page 1080

Time stamp

The time stamp shows the time of the currently displayed history acquisition. Thus, the time relation between acquisitions is always available.

The time stamp "Mode" can be absolute or relative:

- In "Absolute" mode, the instrument shows the date and the daytime of the current acquisition.
- In "Relative" mode, the time difference to the newest acquisition (index = 0) is shown.


During history replay, the time value is displayed and updated if the replay speed ("Display time") is slow enough, that is 40 ms or slower.

The quick-access history dialog box always shows the time according to the "Mode" that is selected in the "Acquisition" > "History" tab.

Remote command:
[ACQuire:HISTory:TSDate?](#) on page 1080
[ACQuire:HISTory:TSABsolute?](#) on page 1080
[ACQuire:HISTory:TSRelative?](#) on page 1080
[ACQuire:HISTory:TSRReference?](#) on page 1081

9.3.3 Quick access history dialog

The quick access history dialog is visible when the history is active. Closing the dialog disables the history display ("Show history" = "Off")



Available acqs	239
Current acq	240
Time	240
Auto repeat	240
▶ Play	240

Available acqs

Number of acquisitions that is saved in the memory and available for history viewing. It is also the number of acquisitions in a fast segmentation acquisition series.

Remote command:
[ACQuire:AVailable?](#) on page 966

Current acq

Index of the current acquisition, same as [Current acq](#) in the history setup.

Time

Shows the timestamp of the current acquisition. See ["Time stamp"](#) on page 239.

Auto repeat

If selected, the playback of the selected history segments repeats automatically.

Remote command:

[ACQuire:HISTory:REPLay](#) on page 1079

▶ Play

Starts and stops the replay of the history waveforms. See also: ["Player"](#) on page 238.

9.3.4 Using history

You can access the history of waveforms in two ways:

- Display a particular acquisition.
- Replay all or a part of the saved waveforms to track the signal run.

To open the history and get information

1. Press the [History] key on the front panel.


A running acquisition is stopped, the history mode is enabled and the quick-access "History" dialog box is displayed. The [History] key lights up as long as the history mode is active.

2. Open the full configuration dialog box:
 - Tap the  icon.
 - Open "Menu" > "Acquisition" dialog > "History" tab.

To display a particular acquisition

You can analyze a selected history waveform, and save it to a file.

- ▶ In the quick-access "History" dialog, enter the number of the required acquisition in the "Current acq" field. The newest acquisition always has the index "0", older acquisitions have a negative index.



Alternatively, you can configure and start the history display from the "History" configuration dialog:

1. Open the "History" configuration tab.
2. If the history mode is off (the [History] key is not illuminated), select "Show history".
3. Drag the slider to the required acquisition. The current number is shown in the "Current acq" field.
Alternatively, enter the number of the required acquisition in the "Current acq" field.

To save a single history waveform

1. Select and display the required history waveform as described in ["To display a particular acquisition"](#) on page 240.
2. Save the selected waveform using "Save/recall" > "Save" tab > "Waveform". For details, see [Section 13.4, "Waveform data"](#), on page 445.

To replay history waveforms

If you want to see the complete acquisition series without any setup, simply tap in the quick-access "History" dialog box. For specific analysis of history data, use the history "Viewer" setup.

1. Open the "History" configuration dialog tab.
2. If the history mode is off, enable "Show history".
3. Tap  to start.

To exit the history

- ▶ Choose one of the following ways:
 - Close the quick-access "History" dialog box.
 - In the "History" configuration tab, disable "Show history".
 - Start the acquisition.

9.4 Reference waveforms

Reference waveforms can be displayed in addition to the signal waveforms, saved to a file, and loaded back for further analysis.

You can configure up to 8 reference waveforms to display stored waveforms. Various waveform types can be used as reference waveforms, for example, analog signals, math waveforms, or spectrum.

Supported file formats

Reference waveforms can be loaded from REF, BIN and CSV files.

BIN is supported for waveforms that were saved on RTO2000, RTO6, RTE or RTP in BIN format.

Loading from CSV is supported under the following conditions:

- One analog channel waveform is stored in the CSV file. Envelope values are supported.
Other waveform types than analog channels are not supported.
Multichannel CSV files are not supported.
- The trigger time is not reconstructed, the trigger is always in the middle of the waveform.
- Clipping detection on measurements on a reference waveform from CSV is not supported.

9.4.1 Working with reference waveforms

- ["To open the "Reference waveform" dialog"](#) on page 242
- ["To load a reference waveform"](#) on page 242
- ["To display and configure a reference waveform"](#) on page 242
- ["To save a reference waveform"](#) on page 243

To open the "Reference waveform" dialog

- ▶ There are several ways to open the "Reference waveform" dialog:
 - In the "Menu" > "Apps" > "General" tab, select "Reference".
 - Select the "+ Ref" signal activator on the signal bar.
 - Press the [Ref] key

To load a reference waveform

Note: Reference waveforms can be loaded from REF files and CSV files with single channel waveforms.

1. Open the "Reference waveform" dialog as described in ["To open the "Reference waveform" dialog"](#) on page 242.
2. Select the tab for the reference waveform that you want to load ("R1/2/3/4/5/6/7/8").
3. In the "Setup" tab, select "Open".
4. In the file browser dialog, select the "File type": "*.ref" or "*.csv".
5. Select the file.
6. Tap "Open".

The selected waveform is loaded to the specified reference waveform.

To display and configure a reference waveform

1. Open the "Reference waveform" dialog as described in ["To open the "Reference waveform" dialog"](#) on page 242.
2. Select the tab for the reference waveform that you want to display, e.g. "R1".

3. Load a stored reference waveform as described in [To load a reference waveform](#). Alternatively, select a source that you want to display as a reference:
 - a) In the "Setup" tab, select "Source".
 - b) Select the "Source" from the selection list. The list shows all active waveforms that you can save as references.
 - c) Tap the "Create/Update" button to update the current reference waveform with the source data.
4. Tap the "Show" button.

The reference waveform is displayed on the screen.
5. A reference waveform can have its own scaling settings or it can be scaled according to the source settings. By default, the scaling of the reference waveform is coupled to the source settings. Also, you can stretch it or compress it in vertical and horizontal directions.

If necessary, change the settings on the "Vertical" and "Rescale" tabs of the "Reference waveform" dialog.

To restore the original settings, tap the "Set to original" in the "Vertical" tab.

For a description of the scaling settings, see [Section 9.4.2.4, "Rescale settings"](#), on page 248.

To save a reference waveform

1. Open the "Reference waveform" dialog as described in ["To open the "Reference waveform" dialog"](#) on page 242.
2. Select the tab for the reference waveform that you want to store, e.g. "R1".
3. Display and configure the reference waveform as described in ["To display and configure a reference waveform"](#) on page 242.
4. Tap "File extension" to select the file format.

Note that reference waveforms can be loaded from REF files and CSV files only.
5. To save the waveform, tap "Save as".
6. Enter a filename and select the directory. The file type is defined according to the selection in the previous steps.

The source settings of the reference waveform and the current scaling settings are stored to the specified file.

9.4.2 Settings for reference waveforms


To compare waveforms and analyze differences between waveforms, you can use up to 8 reference waveforms.

You can save an unlimited number of reference waveforms and load them for further use.

The display of a reference waveform is independent from the display of the source waveform; you can move, stretch and compress the curve vertically and horizontally.

9.4.2.1 Reference waveform setup

Access: "Menu" > "Apps" > "General" tab > "Reference" > "Setup" tab



In the "Setup" tab, you select the target reference waveform and its source.

R1/2/3/4/5/6/7/8

Each tab contains the settings for one of the available reference waveforms.

Show

Enables the display of the reference waveform in the diagram. Before you can display it, create the reference waveform.

Remote command:

[REFCurve<rc>:STATe](#) on page 1084

Source

Selects the source waveform from the active waveforms, e.g. input channels, math waveforms, or spectrum.

Remote command:

[REFCurve<rc>:SOURce](#) on page 1084

Create/Update

Copies the selected source waveform with all its settings to the memory of the reference waveform. If there is a previously defined reference waveform in this memory, it is updated by the current source waveform. If the acquisition is running, the reference waveform is a snapshot.

A progress bar informs you about the process.

Remote command:

[REFCurve<rc>:UPDate](#) on page 1085

Clear

Deletes the selected reference waveform. It disappears from the display, and its memory is deleted.

Remote command:

[REFCurve<rc>:CLEar](#) on page 1082

File extension

Selects the file format.

Save as

Saves the reference waveform. The complete reference waveform is stored in a file and can be reloaded later.

A progress bar informs you about the process.

See also:

- [Section 13.4, "Waveform data"](#), on page 445
- [Section 13.4.3, "Waveform export files"](#), on page 452

Remote command:

[REFCurve<rc>:NAME](#) on page 1082

[REFCurve<rc>:SAVE](#) on page 1083

To abort the saving, use [REFCurve<rc>:ABORt](#) on page 1082.

Open

Opens a file selection dialog box and loads the selected reference waveform file.

See ["Supported file formats"](#) on page 241.

Remote command:

[REFCurve<rc>:OPEN](#) on page 1083

9.4.2.2 Reference waveform properties

Access: "Menu" > "Apps" > "General" tab > "Reference" > "Properties" tab

Setup	Time scale	12.42 ns/div
	Reference point	50 %
	Record length	1 kpts
Properties	Horizontal position	-31.05 ns
	Vertical scale	50 mV
Vertical	Vertical offset	0 V
	Vertical position	0 div
	Enhancement mode	Interpolated time
Rescale	Interpolation	sin(x)/x
	Waveform arithmetic	Off
Restore settings		

A reference waveform can be scaled, stretched and positioned in the diagram. The "Properties" tab shows the original settings of the reference waveform, which are stored together with the waveform data.

The following settings are displayed:

- [Time scale](#)
- [Reference point](#)
- [Record length](#)
- [Position](#)
- [Vertical scale](#)
- [Offset](#)
- [Position](#)
- [Enhancement mode](#)
- [Interpolation](#)
- [Waveform arithmetic](#)

Enhancement mode

The enhancement mode is taken from the source waveform of the reference. The enhancement mode is set automatically by the instrument and depends on the sample rate. As long as the waveform sample rate is not higher than the ADC sample rate, the instrument works automatically in real time mode (RT). At higher waveform sample rates, the instrument changes to interpolated time mode (IT), where interpolation adds waveform points between the captured ADC samples by various mathematical methods, see [Interpolation](#).

Waveform arithmetic

The waveform arithmetic is taken from the source waveform of the reference, and it cannot be changed for the reference. Waveform arithmetic builds the resulting waveform from several consecutive acquisitions of the signal. The arithmetic methods are envelope and average, which are set in the [Acquisition mode](#).

Restore settings


Applies the original settings of the reference waveform to the horizontal and vertical settings of the selected waveform.

Remote command:

[REFCurve<rc>:REStore](#) on page 1083

9.4.2.3 Vertical settings for reference waveforms

Access: "Menu" > "Apps" > "General" tab > "Reference" > "Vertical" tab

**Vertical mode**

Selects the type of vertical settings:

"Coupled to source" Vertical position and scale of the source are used.

"Independent" Scaling and position can be set specific to the reference waveform.

Remote command:

[REFCurve<rc>:VMODE](#) on page 1089

Set to original

Available, if "Vertical mode" = "Independent".

Restores the original vertical settings of the reference waveform.

Remote command:

[REFCurve<rc>:TOORiginal](#) on page 1089

Vertical scale

Available, if "Vertical mode" = "Independent".

Sets the vertical scale, which defines the displayed amplitude of the selected waveform.

The unit of the reference is the same as the unit of the source waveform.

Remote command:

[REFCurve<rc>:SCALE](#) on page 1085

Vertical offset

The vertical offset moves the reference waveform vertically. Enter a value with the unit of the waveform.

Remote command:

[REFCurve<rc>:OFFSet](#) on page 1083

Vertical position

Available, if "Vertical mode" = "Independent".


Moves the reference waveform up or down in the diagram.

Remote command:

[REFCurve<rc>:POSition](#) on page 1086

9.4.2.4 Rescale settings

Access: "Menu" > "Apps" > "General" tab > "Reference" > "Rescale" tab



In the "Rescale" tab you can adjust the vertical and horizontal scaling of the reference waveform.

Vertical

Stretching and offset change the display of the waveform independent of the vertical scale and position.

Enable ← Vertical

If enabled, the vertical offset and factor are applied to the reference waveform.

Remote command:

[REFCurve<rc>:RESCale:VERTical:STATe](#) on page 1088

Scale factor ← Vertical

Sets the vertical scale factor. A factor greater than 1 stretches the waveform vertically, a factor lower than 1 compresses the curve.

Remote command:

[REFCurve<rc>:RESCale:VERTical:FACTOR](#) on page 1088

Vertical offset ← Vertical

The vertical offset moves the reference waveform vertically. Enter a value with the unit of the waveform.

Like vertical offset of a channel waveform, the offset of a reference waveform is subtracted from the measured value. Negative values shift the waveform up, positive values shift it down.

Remote command:

[REFCurve<rc>:RESCale:VERTical:OFFSet](#) on page 1088

Horizontal

Stretching and offset change the display of the waveform independent of the horizontal settings of the source waveform and of the horizontal diagram settings.

Mode ← Horizontal

Selects the type of horizontal settings:

"Original scaling"	Horizontal scaling and reference point of the source waveform are used.

"Adjust to X Axis"	The current horizontal settings of the diagram are used.

Remote command:

[REFCurve<rc>:HMODE](#) on page 1086

Enable ← Horizontal

If enabled, the horizontal offset and factor are applied to the reference waveform.

Remote command:

[REFCurve<rc>:RESCale:HORizontal:STATe](#) on page 1087

Scale factor ← Horizontal

Sets the horizontal scale factor. A factor greater than 1 stretches the waveform horizontally, a factor lower than 1 compresses the curve.

Remote command:

[REFCurve<rc>:RESCale:HORizontal:FACTOR](#) on page 1087

Horizontal offset ← Horizontal

Moves the waveform horizontally. Enter a value with a time unit suitable for the time scale of the diagram.

Positive values shift the waveform to the right, negative values shift it to the left.

Remote command:

`REFCurve<rc>:RESCale:HORizontal:OFFSet` on page 1087

9.5 Waveform histograms

Histograms are used to plot density of data. They show graphically how often which signal values occur. The histogram accumulates the measured y-values (vertical histogram), or the occurrence of a sample at a given time on the x-axis (horizontal histogram). The data is accumulated during the running acquisition cycle.

You can analyze the complete waveform by a histogram, or a part of it by defining a histogram window. The maximum count of a waveform value is assigned to the full height (histogram peak). All other count values are displayed relative to the maximum.

You can define up to 8 histograms. They are created quickly using the toolbar icon and overlay menu, or in the "Histogram" app dialog.




Figure 9-4: Full histogram




Figure 9-5: Histogram window


9.5.1 Histogram settings

Access: "Menu" > "Apps" > "General" tab > "Histogram".

The general histogram setup is done in the "Setup" tab. To analyze a part of the waveform, use the "Window" tab.

9.5.1.1 Setup for histograms

Access: "Menu" > "Apps" > "General" tab > "Histogram" > "Setup" tab



State

Enables or disables the histogram evaluation and display. The histogram settings are kept until the histogram is deleted.

Remote command:

[HISTogram<m>:ENABle](#) on page 1092

Source

Defines the source, the waveform that is analyzed by the histogram. Any analog channel waveform, math or reference waveform can be selected.

Remote command:

[HISTogram<m>:SOURce](#) on page 1093

Diagram size

Defines the size of the histogram in percent of the diagram width or height.

Mode

Defines the type of histogram.

A vertical histogram has horizontal bars that show the occurrence of the vertical values.

A horizontal histogram has vertical bars that show the occurrence of a sample at a given time on the x-axis. This histogram type is in particular relevant for histogram windows.

Remote command:

[HISTogram<m>:MODE](#) on page 1092

Tab

If several tabs are available in the diagram, you can select the tab that displays the histogram.

The histogram is always in the same diagram as the source waveform is. If the source waveform is not displayed in the tab selected for the histogram, the source is automatically enabled in this tab, together with the histogram. If you delete a tab with a histogram, the histogram is deleted also.

Reset

Restarts the calculation of the selected histogram.


To reset all histograms and measurements, select "Clear" on the toolbar.

Remote command:

[HISTogram<m>:RESet](#) on page 1093

9.5.1.2 Window settings for histograms

Access: "Menu" > "Apps" > "General" tab > "Histogram" > "Window" tab



Use window

When you use a histogram window, the analyzed part of the source waveform is limited vertically and horizontally.

Remote command:

[HISTogram<m>:WINDow:ENABLE](#) on page 1094

Start Stop | Position Range

Select whether you want to use start and stop values to limit the histogram window, or the center position and range of the window. The selections can be different for the vertical and horizontal limit.

Mode

Defines whether the window limits are entered as absolute or relative values.

Remote command:

[HISTogram<m>:WINDow:HORizontal:MODE](#) on page 1094

[HISTogram<m>:WINDow:VERTical:MODE](#) on page 1094

Start, Stop, Range, Position

Set the horizontal window limits as absolute values: start and stop, or center position and range of the window.

Remote command:

[HISTogram<m>:WINDow:HORizontal:ABSolute:START](#) on page 1094

[HISTogram<m>:WINDow:HORizontal:ABSolute:STOP](#) on page 1094

[HISTogram<m>:WINDow:HORizontal:ABSolute:POSition](#) on page 1094

[HISTogram<m>:WINDow:HORizontal:ABSolute:SPAN](#) on page 1094

Relative start, Relative stop, Relative range, Relative position

Set the horizontal window limits as relative values in % of the diagram width: start and stop, or center position and range of the window.

Remote command:

[HISTogram<m>:WINDow:HORizontal:RELative:START](#) on page 1095

[HISTogram<m>:WINDow:HORizontal:RELative:STOP](#) on page 1095

[HISTogram<m>:WINDow:HORizontal:RELative:POSition](#) on page 1095

[HISTogram<m>:WINDow:HORizontal:RELative:SPAN](#) on page 1095

Start, Stop, Range, Position

Set the vertical window limits as absolute values: start and stop, or center position and range of the window. The values remain unchanged if you change the unit of the y-axis.

Remote command:

[HISTogram<m>:WINDow:VERTical:ABSolute:START](#) on page 1095

[HISTogram<m>:WINDow:VERTical:ABSolute:STOP](#) on page 1095

[HISTogram<m>:WINDow:VERTical:ABSolute:POSition](#) on page 1095

[HISTogram<m>:WINDow:VERTical:ABSolute:SPAN](#) on page 1095

Start, Stop, Range, Position

Set the vertical window limits as relative values in % of the diagram height: start and stop, or center position and range of the window. The values remain unchanged if you change the unit of the y-axis.

Remote command:

[HISTogram<m>:WINDow:VERTical:RELative:START](#) on page 1095

[HISTogram<m>:WINDow:VERTical:RELative:STOP](#) on page 1095

[HISTogram<m>:WINDow:VERTical:RELative:POSition](#) on page 1095

[HISTogram<m>:WINDow:VERTical:RELative:SPAN](#) on page 1095

9.5.2 Creating histograms

To create a histogram quickly with toolbar icons

1. Select the waveform for which you need a histogram.
2. Tap the histogram icon on the toolbar.
3. Select the histogram type on the overlay menu: vertical or horizontal. See ["Mode"](#) on page 252.
4. Tap the diagram with the waveform to be measured, or draw a rectangle on the screen to define the window for histogram calculation.

The histogram range is shown in the diagram and a histogram with the selected waveform as a source is defined and displayed.

5. To adjust the histogram range:
 - a) Double-tap the histogram.
 - b) Tap "Setup" on the overlay menu.
 - c) Adjust the start and stop values.

To create and configure a histogram in the dialog box

1. Select "Menu" > "Apps" > "General" tab > "Histogram".



2. To create a histogram, tap the "Add" icon in the upper right corner of the dialog box.
3. Select a "Source" for the histogram. The source can be any analog input signal, math or reference waveform.
4. Define the histogram "Mode": vertical for an amplitude, horizontal for a time-based histogram.
5. If you need to evaluate only a part of the waveform:
 - a) Select the "Window" tab.
 - b) Enter the start value and the stop value in x and in y direction, either as absolute or relative values. Alternatively, you can enter the center position of the window, and its range.
 - c) Enable "Use window".
6. On the "Setup" tab, enable the histogram.

9.5.3 Exporting histograms

You can export histogram data, see [Section 13.5, "Histogram data export"](#), on page 461.

10 Measurements

Using the MXO 5C you can perform and display different measurements simultaneously, based on the active signal or math waveforms. The color of the results in the result table corresponds with the source waveform color.

10.1 Cursor measurements

- [Cursors and results of cursor measurements](#)..... 256
- [Using cursors](#)..... 257
- [Settings for cursor measurements](#)..... 259

10.1.1 Cursors and results of cursor measurements

Cursor measurements determine the results at the current cursor positions. The cursors can be positioned manually, or can be configured to follow the waveform. You can measure on one waveform, on two different waveforms, or on multiple different waveforms (sources).

Up to 4 cursor sets can be configured and displayed. Each cursor set consists of a pair of horizontal or vertical cursor lines, or both. Cursor lines can be coupled so that the initially defined distance is always maintained.

The cursors are displayed in the diagrams of the source waveform only, or in all diagrams. For each measurement, labels can be defined for the cursors. By default, the cursor lines are labeled as Cu1.1 and Cu1.2.

How to set up cursor measurements is described in [Section 10.1.2, "Using cursors"](#), on page 257. The [Section 10.1.3, "Settings for cursor measurements"](#), on page 259 provides a detailed description of all settings.

For details on using the result table, see [Section 4.13, "Displaying results"](#), on page 76.

10.1.1.1 Cursor measurements on time-based waveforms

The cursor for measurement on time-based waveforms returns the following results. The results are displayed automatically when a cursor measurement is enabled.

C1	X1	-50 ns	X2	14.226 ns	Y1: 0.5 mV	Y2: 1.5 mV
	dx:	64.226 ns		1/dx: 15.5700 MHz	dy: 1 mV	dy/dx: 15.216 2 kV...

Label	Description
"X1, X2"	Time at the position of the vertical cursors.
"Y1, Y2"	Vertical values of the waveform at the position of the horizontal cursors in V or A.

Label	Description
" Δx "	Difference between the vertical cursor (time) values
" $1/\Delta x$ "	Inverse time difference
" Δy "	Difference between the horizontal cursor values
" $\Delta y/\Delta x$ "	Slope of the waveform between the cursors (if measured on one source)

For measurements on multiple waveforms, the Y-values are measured on each source waveform.

With option R&S MXO5C-K136, these values are also measured with cursors in eye diagrams. The unit of the results corresponds to the selected "Time units" of the eye. See also: [Section 12.7, "Eye analysis \(option R&S MXO5C-K136\)"](#), on page 432.

10.1.2 Using cursors

You can start cursor measurements in the toolbar, or using the [Cursor] key. For detailed configuration, use the "Cursor" dialog.

10.1.2.1 Starting a simple cursor measurement

To add cursors using the toolbar

1. Tap the "Add cursor" icon on the toolbar.



2. Select the channel that you want to apply the cursor to.
Tap the waveform that you want to measure. Alternatively, you can draw a rectangle in the diagram to position the cursor lines.

The cursor lines appear and the cursor results are displayed in the result table.

To display cursors using the [Cursor] key

1. Select the waveform that you want to measure.
2. Press the [Cursor] key.

The cursor lines and the measurement results are displayed.

10.1.2.2 Configuring a cursor measurement

To modify the position of the cursor lines, you can drag the lines on the screen. In addition, various settings are possible to refine the measurement.

The complete configuration of cursor measurements is provided in the "Cursor" dialog. The settings of the dialog are described in [Section 10.1.3, "Settings for cursor measurements"](#), on page 259.

1. To open the "Cursor" dialog, use one of these ways:
 - Select "Menu" > "Cursor".
 - Press the [Cursor] key.
 - Double-tap in the results table (but not on a result).
2. Select the "Setup" tab.
3. Select the subtab for the cursor set that you want to use.
4. Select the [Source mode](#).
5. Depending on the selected "Source mode", select one, two or several sources - the measured waveforms. Available sources are shown in the source list.
6. For single source and second source mode, select the "Type": X (vertical), Y (horizontal), or XY (both).
7. If the acquisition mode is set to "Envelope" or "Peak detect", select which horizontal cursor is positioned to the maximum and which to the minimum envelope values.
8. Define the exact position of the cursor lines:
 - a) Enter the X-position for each vertical cursor.
 - b) To position the horizontal cursors automatically, select "Track waveform". The Y-position follows the waveforms.

In this case, Cu 1.1 indicates the current maximum, Cu 1.2 indicates the current minimum. If both horizontal and vertical cursor lines are displayed, the horizontal cursors are placed at the crossing points of the vertical cursor lines with the waveform. If you adjust the vertical cursor lines, the horizontal cursors follow.
 - c) If "Track waveform" is off, enter the Y-position for each horizontal cursor.
9. To display the cursor in all diagrams that are in the same domain as the selected source (time or spectrum), enable "Show in all diagrams" in the "Advanced" tab.
10. To keep the distance between the vertical cursors when one cursor is moved, enable "X" or "Y" in the "Advanced" tab.
11. To set the cursors for a spectrum measurement to peak values, select the "Peak search" tab.

Tap one of the buttons to place the cursors on the selected peak value. For details, see [Section 10.1.3.3, "Peak search tab"](#), on page 264.
12. Tap "Show cursor" in the "Setup" tab to activate the cursor measurement.

The cursors lines and the results are displayed. For details on cursor measurement results, see [Section 10.1.1, "Cursors and results of cursor measurements"](#), on page 256.

10.1.2.3 Configuring the cursor display

By default, the cursors are displayed as lines in the diagrams and labeled according to the syntax: Cu<cursor set number>.<1|2>

For example, the cursors for the cursor set 2 are labeled 2.1 and 2.2. The horizontal and the vertical cursors lines have the same labels.

You can change the default cursor display and labels.

To set the cursor style

1. Select "Menu" > "Cursor".
2. Select the subtab for the cursor set you want to configure.
3. Select the "Setup" tab.
4. Select the "Cursor style". See also: ["Cursor style"](#) on page 260.

To add labels to cursor lines

1. Select "Menu" > "Cursor".
2. Select the subtab for the cursor set you want to configure.
3. Select the "Advanced" tab.
4. Enter a label for "Vertical cursor 1", "Vertical cursor 2", "Horizontal cursor 1", "Horizontal cursor 2".
5. Enable "Show label".

10.1.3 Settings for cursor measurements

Cursor measurements are configured in the "Cursor" dialog.

10.1.3.1 Setup tab

Access: "Menu" > "Cursor" > "Setup" tab

You can define up to 4 cursor sets (or cursor measurements). Each cursor set is configured on a separate tab.

Setup Advanced Peak search	Show cursor	Cursor style
	☒ On	Lines
	Type	Source mode
	X&Y	Use 2nd source
	Source	Source 2
	C1	C2
	Envelope 1	Envelope 2
	Minimum	Maximum
X1 position	X2 position	
-50 ns	50 ns	
Y1 position	Y2 position	
-125 mV	125 mV	
Place on display		Track waveform

Show cursor

Enables the selected cursor measurement.

Remote command:

`CURSor<cu>:STAt` on page 1145

Cursor style

Defines how the cursor is displayed in the diagram.

"Lines" The cursors are displayed as lines.

"Line & Rhombus"

The cursors are displayed as lines. The intersections of the cursors with the waveforms are displayed by rhombus-shaped points.

"VLine & Rhombus"

Vertical line and rhombus: the cursors are displayed as vertical lines. The intersections of the cursors with the waveforms are displayed by rhombus-shaped points.

"Rhombus"

The intersections of the cursors with the waveforms are displayed by rhombus-shaped points.

Remote command:

`CURSor<cu>:STYLe` on page 1157

Type

Defines the cursor type to be used for the measurement.

"X" (vertical cursors)

Both vertical cursor lines are set automatically to the trigger position, and you can reposition them manually. Not available for measurements on multiple sources.

"Y" (horizontal cursors)

Horizontal cursors are positioned automatically along the waveform and can be adjusted manually. Not available for measurements on multiple sources.

"X&Y" (both vertical and horizontal cursors)

Horizontal cursors are positioned automatically along the waveform and vertical cursors are set to the trigger position. You can reposition all cursor lines manually.

Remote command:

[CURSor<cu>:FUNction](#) on page 1145

Source mode

Selects the number of sources that you want to measure. The dialog adapts to the selected mode.

"Single source" The cursor lines are set on one waveform.

"Use 2nd source" The cursor lines are set on two waveforms. The second cursor lines Cu2 are set on the second source to measure differences between the two waveforms.

"Multiple sources" Several waveforms are selected to be measured with one cursor set. The cursor type is always "X&Y", and "Track waveform" is active. For each waveform, the Y-value at the position of the vertical cursor line is measured.

Remote command:

[CURSor<cu>:SMODE](#) on page 1146

Source

Defines the source of the cursor measurement. Various waveform types can be measured. The available sources are listed.

With option R&S MXO5C-K136, eyes also can be measured. If an eye is selected as a source, the second source is also an eye. The eye source is not available if you measure on multiple sources.

Remote command:

[CURSor<cu>:SOURCE](#) on page 1146

Source 2

Selects a second source for the cursor measurement if "Source mode" is set to "Use 2nd source". The second cursor lines Cu2 measure on the second source. Using a second source, you can measure differences between two channels with cursors.

Remote command:

[CURSor<cu>:SSource](#) on page 1148

Select sources

Select the waveforms to be measured if "Source mode" is set to "Multiple sources". The selection dialog lists all possible active sources.

Remote command:

[CURSor<cu>:SOURce](#) on page 1146

Envelope 1, Envelope 2

Define which horizontal cursor is positioned to the maximum and which to the minimum envelope values.

Envelope selection is effective under the following conditions:

- The acquisition mode of the cursor source waveform is set to envelope or peak detect, see [Acquisition mode](#).
- Both horizontal and vertical cursors are enabled ([Type](#) = "X&Y").
- [Track waveform](#) is enabled.

"Minimum" The horizontal cursor is set to the crossing point of the vertical cursor line with the minimum waveform envelope.

"Maximum" The horizontal cursor is set to the crossing point of the vertical cursor line with the maximum waveform envelope.

Remote command:

[CURSor<cu>:X1ENvelope](#) on page 1153

[CURSor<cu>:X2ENvelope](#) on page 1153

X1 position, X2 position

Define the left and right position of the vertical cursor lines.

Remote command:

[CURSor<cu>:X1Position](#) on page 1148

[CURSor<cu>:X2Position](#) on page 1148

Y1 position, Y2 position

Define the upper and lower position of the horizontal cursor lines.

If [Track waveform](#) is enabled, the user setting is disabled and the Y-position is determined by the instrument.

Remote command:

[CURSor<cu>:Y1Position](#) on page 1149

[CURSor<cu>:Y2Position](#) on page 1150

Track waveform

If enabled, the horizontal cursor lines track the waveform. If the waveform changes, e.g. during a running measurement, the cursors move along with it.

The function is available if both horizontal and vertical cursors are displayed. The horizontal cursor lines are positioned to the crossing points of the vertical cursors with the waveform. For cursor measurements on multiple sources, tracking is always active.

Tracking disables the Y-coupling (coupling horizontal cursor lines) and the Y-position settings.

In envelope or peak detect acquisition mode, the envelope is tracked.

The function is not available for measurements on eyes (R&S MXO5C-K136).

Remote command:

[CURSor<cu>:TRACking\[:STATe\]](#) on page 1150

Place on display

Resets the cursors to their initial positions. Reset is helpful if the cursors have disappeared from the display or need to be moved for a larger distance.


Remote command:

[CURSor<cu>:SSCReen](#) on page 1150

10.1.3.2 Advanced settings

Access: "Menu" > "Cursor" > "Advanced" tab

The settings in the "Advanced" cursor tab configure the behavior and display of cursor lines, and labels for the lines.



X, Y

Couple the horizontal or vertical cursor lines so that the distance between the two lines remains the same if one cursor is moved. "X" couples the vertical cursor lines, and "Y" couples the horizontal cursor lines.

Remote command:

[CURSor<cu>:XCoupling](#) on page 1152

[CURSor<cu>:YCoupling](#) on page 1152

Show in all diagrams

Shows the enabled cursor measurements in all active diagrams of the time domain.

In the spectrum domain, the setting is disabled. The cursors are shown only on the source spectrum of the measurement.

Remote command:

`CURSor<cu>:SIAD` on page 1152

Show label

Shows the cursor labels in the diagram.

Remote command:

`CURSor<cu>:LABel` on page 1150

Show values

Shows the measured values in the cursor labels.

Remote command:

`CURSor<cu>:DISPlay:VALues` on page 1151

Vertical cursor 1, Vertical cursor 2

Defines the label to be displayed with the vertical cursor lines. By default, the cursors are labeled as Cu1.1, Cu1.2, Cu2.1, ...

Remote command:

`CURSor<cu>:VERTical<n>:LABel` on page 1151

Horizontal cursor 1, Horizontal cursor 2

Defines the label to be displayed with the horizontal cursor lines. By default, the cursors are labeled as Cu1.1, Cu1.2, Cu2.1, ...


Remote command:

`CURSor<cu>:HORizontal<n>:LABel` on page 1151

10.1.3.3 Peak search tab

Access: "Menu" > "Cursor" > "Peak search" tab

The settings on this tab are only available in spectrum mode, i.e. the source of the cursor measurement is a spectrum. In this case, the cursors can indicate the results of a peak search on the waveform. Changing the noise reject settings, you can define which peaks are detected.

**Absolute peak**

Sets both cursors to the absolute peak value.

Remote command:

[CURSor<cu>:MAXimum\[:PEAK\]](#) on page 1156

Next peak

Cursor 2 is set to the next smaller absolute peak from the current position.

Remote command:

[CURSor<cu>:MAXimum:NEXT](#) on page 1156

Next peak left

Cursor 2 is set to the next peak to the left of the current position.

Remote command:

[CURSor<cu>:MAXimum:LEFT](#) on page 1156

Next peak right

Cursor 2 is set to the next peak to the right of the current position.

Remote command:

[CURSor<cu>:MAXimum:RIGHT](#) on page 1156

Center frequency

Sets the vertical cursor line Cu1 to the center frequency.

Remote command:

[CURSor<cu>:FFT:TOCenter](#) on page 1155

Set center frequency to

Sets the center frequency to the frequency value that is measured at cursor line Cu1.

Remote command:

[CURSor<cu>:FFT:SETCenter](#) on page 1155

Threshold

Sets an absolute threshold as an additional condition for the peak search. Only peaks that exceed the threshold are detected.

This setting is only available for spectrum waveforms. It is valid for cursor measurements, spectrum measurements and peak search.

Remote command:

[CALCulate:SPECTrum<sp>:THReshold](#) on page 1164


Peak excursion

Defines a minimum level value by which the waveform must drop left and right of the local maximum to be listed as a peak. Enter a peak excursion value to omit close by peaks and list just the highest peak.

This setting is only available for spectrum waveforms. It is valid for cursor measurements, spectrum measurements and peak search.

Example:

In the figure below, 2 peaks are shown, that rise above the defined "Threshold". Peak 1 fulfills the defined "Peak excursion" value and is counted as a peak. Peak 2 does not fulfill the defined "Peak excursion" value on the right and is not counted as a peak.



Remote command:

[CALCulate:SPECTrum<sp>:PEXCursion](#) on page 1164

[CURSor<cu>:PEXCursion](#) on page 1156

10.2 Automatic measurements

You can perform up to 24 different measurements simultaneously. Available sources and measurement types depend on the selected category. For most measurement types, specific settings are available for configuration.

10.2.1 Measurement setup in general

10.2.1.1 Starting an automatic measurement

There are several methods to start a measurement, each with slightly different effects:

- Using the "Measure" icon on the toolbar:
See: ["To start a measurement using the toolbar icon"](#) on page 267.
- Pressing the [Measure] key on the front panel.
- Using the "Measurement" dialog.
See: ["To add a new measurement in the measurement dialog"](#) on page 267.

To start a measurement using the toolbar icon

1. Tap the "Measure" icon on the toolbar.



The measurement overlay menu opens.



2. Select the "Category".
3. Tap the measurements that you want to perform. You can scroll left and right through the measurement list to view all available measurements for the selected "Category".
4. Select the source that you want to apply the measurement on.
5. If needed, click "Setup" to configure further measurements.

The measurement results are displayed.

To add a new measurement in the measurement dialog

1. Press the [Measure] key to open the measurement dialog.
2. In the "Setup" tab, press "+ Add".
A dialog opens to select the measurements.
3. Select the "Source" for the measurement.
4. Select the "Category" of the measurement that you want to add, e.g. "Horizontal".

All available measurements for this category are displayed. For more details on the available measurement types, see the corresponding section.

5. Tap a measurement on the list to select it.
Selected measurements are marked with a blue check mark in their checkbox.

Rise time ☒	Fall time ☒
Pos. pulse ☐	Neg. pulse ☐

6. The measurements of some categories are listed on several tabs. To switch between the tabs, tap the points at the bottom of the list.

Category	Source
Horizontal	Channel 1


Select Measurements

Rise time ☒	Fall time ☒
Pos. pulse ☐	Neg. pulse ☐
Period ☐	Frequency ☐
Pos. duty cycle ☐	Neg. duty cycle ☐
Delay ☐	Phase ☐
Burst width ☐	Delay to trigger ☐

→ ☒ ☐ ☐

Add

7. Tap "Add" to add the selected measurements.
All selected measurements are active by default.




8. To deactivate a measurement while leaving it in the measurement list, deselect the checkmark.
9. To configure a measurement, select the  (settings icon).

To delete a measurement

1. Press the [Measure] key to open the measurement dialog.
2. In the "Setup" tab, tap .

A delete icon appears in the selection button of each measurement.




3. Tap the button of the measurement that you want to delete. Alternatively, tap "Delete All" to delete all measurements.

10.2.1.2 Setup tab

Access: "Menu" > "Measurement" > "Setup" tab.

The "Setup" tab shows the selected measurements. You can activate or deactivate the measurements. Tap the  "Settings" icon to open the specific settings for the measurement type.



+ Add

Opens a dialog to select the measurements. See [Section 10.2.1.3, "Add measurement dialog"](#), on page 270.

Delete icon


Enables the removal of measurements. You can delete a single measurement by tapping the "Delete" icon next on it.

You can also delete all current measurements with "Delete All".

10.2.1.3 Add measurement dialog

Access: "Menu" > "Measurement" > "Setup" tab > "+ Add".

In this dialog, you select the category and the measurements to be done.



Category

Selects the measurement category. Some measurements are listed in more than one category.

The following categories are available:

- Amp/time: amplitude and time measurements, includes the categories "Horizontal", "Vertical" and "Count"
- Jitter measurements (available if the jitter option is installed)
- Histogram: measurements on waveform histograms
- Protocol: advanced analysis of serial protocols with option R&S MXO5C-K500

Remote command:

In remote control, the measurements are selected directly. A preselection of the category is not necessary.

Source

Sets the source of the measurement.

Available sources depend on the selected category. For example, histogram measurements require a waveform histogram as source, and protocol measurements require a serial bus.

The source is applied to all measurements that are selected in the dialog. You can change it later for the individual measurement.

Remote command:

[MEASurement<mg>:SOURce](#) on page 1118

Select measurements

Select the required measurements of the selected category. The list can have several pages, which are represented by dots at the bottom of the list. Tap a dot to change the page.

Remote command:

[MEASurement<mg>:MAIN](#) on page 1120

Add

Adds the selected measurements and returns to the "Setup" tab.

The measurements are listed and activated by default. You can deactivate single measurements in the "Setup" tab.

Remote command:

[MEASurement<mg>\[:ENABle\]](#) on page 1118


[MEASurement<mg>:ACTive](#) on page 1118

10.2.1.4 Configuration of measurement types: common settings

When you select the settings icon of a measurement in the "Setup" tab, a dialog with more setting opens. Some of these settings are common for many or all measurement types, independent of their category, others are specific for the selected measurement type.

For category and type-specific settings, see:

- [Section 10.2.4.2, "Settings for amplitude/time measurements"](#), on page 280
- [Section 10.2.6.2, "Settings for jitter measurements"](#), on page 288
- [Section 10.2.5.2, "Settings for measurements on histograms"](#), on page 286
- [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301



This section describes the common settings.

Specific type

Selects the type of measurement that you want to define the settings for. The list provides all measurement types of the same category.

Remote command:

[MEASurement<mg>:MAIN](#) on page 1120

Source

Sets the source of the measurement.

Available sources depend on the category of the measurement. For example, histogram measurements require a waveform histogram as source, and protocol measurements require a serial bus.

In setup/hold measurements, this source is the "Data source".

Remote command:

[MEASurement<mg>:SOURce](#) on page 1118

Reference levels

Selects the set of reference levels that is used for the measurement and for the first measurement source. Each source of the measurement can have its own reference level set. For most measurements, one source is needed. For delay measurements, for example, two measurement sources are required, and each source can have its own reference levels.

Only the numbers of defined reference level sets are listed. Define the reference level set before you select it, see [Section 8.1, "Reference level setup"](#), on page 209.

Remote command:

`MEASurement<mg>:REFLevel<rl>:REFerence` on page 1125

Gate

Assigns a gate to the selected measurement to limit the measurement range. Define a gate before you select it, see [Section 8.2, "Gate setup"](#), on page 211.

Alternatively, you can assign the gates to measurements in the "Gate" tab, see [Section 10.2.3, "Gate settings for measurements"](#), on page 275.

Remote command:

`MEASurement<mg>:GATE` on page 1121


Label

Adds a user-defined label to the measurement.

10.2.2 Reference levels for measurements

Access: "Menu" > "Measurement" > "Reference level" tab

Measurements require reference levels to obtain the measurement points, e.g. time measurements or pulse count. The dialog shows the definition of the selected reference level set and all active measurements. If no reference level set has been defined before, or the correct definition is missing, select "RL setup" and configure the reference level set before you assign it. See [Section 8.1, "Reference level setup"](#), on page 209 for details.



1. Select the RL subtab, e.g. "RL1".
2. Select the measurements that use the selected reference level set.


Remote command: [MEASurement<mg>:REFLevel<rl>:REFerence](#) on page 1125

10.2.3 Gate settings for measurements

Access: "Menu" > "Measurement" > "Gate" tab.

You can limit the measurements to a user-defined range of the waveform. The dialog shows the limits of the selected gate and all active measurements. If no gate has been defined before, or the correct gate is missing, select "Gate setup" and configure the gate before you assign it. See [Section 8.2, "Gate setup"](#), on page 211 for details.

1. Select the gate subtab, e.g. "G1".
2. Select the measurements to be limited by the selected gate.



Remote command: [MEASurement<mg>:GATE](#) on page 1121.




10.2.4 Amplitude/time measurements

10.2.4.1 Overview of amplitude/time measurements

The MXO 5C provides many measurement types in the "Amp/time" category to measure time, amplitude and area characteristics, and to count pulses and edges.






Horizontal measurements (time)

Meas. type	Label	Description	Formula, graphic
Rise Time	RTime	Rise time of the first rising edge, the time it takes the signal to rise from the lower reference level to the upper reference level. Measurement of all events in the acquisition is possible.	
Fall Time	FTime	Fall time of the first falling edge, the time it takes the signal to fall from the upper reference level to the lower reference level. Measurement of all events in the acquisition is possible.	
Pos. pulse	PPuls	Duration of the first positive pulse: time between a rising edge and the following falling edge measured on the middle reference level. Measurement of all events in the acquisition is possible.	
Neg. pulse	NPuls	Duration of the first negative pulse: time between a falling edge and the following rising edge measured on the middle reference level. Measurement of all events in the acquisition is possible.	
Period	T	Time between the first two consecutive waveform edges of the same direction, measured on the middle reference level. The measurement requires at least one complete period of a triggered signal. Measurement of all events in the acquisition is possible.	
Frequency	Freq	Frequency of the signal, reciprocal value of the measured period.	
Delay	Delay	Time difference between two slopes of the same or different waveforms, measured on the middle reference level. A negative result indicates that the slope of the second source comes before the slope of the first source.	

Meas. type	Label	Description	Formula, graphic
Phase	Phs in °	Phase difference between two waveforms, measured on the middle reference level.	$\text{Phase} = \text{Delay} / \text{Period} * 360$ 
Burst width	Bst	Duration of one burst. The burst is measured on the middle reference level from the first edge to the last edge, regardless of whether these edges rise or fall.	
Setup Hold Setup/Hold time	Setup Hold SHT	Setup and Hold time measurements with positive and/or negative clock edge, measured on the middle reference level. See "Setup/Hold time measurement" on page 282.	
Setup/Hold ratio	SHR	Setup/Hold ratio measurement with positive and/or negative clock edge.	$\text{SHR} = \text{Setup} / (\text{Setup} + \text{Hold})$
Delay to trigger	DTO	Time between the trigger point and the next signal slope, measured on the middle reference level. Slope direction can be selected. If the edge is to the left of the trigger (before trigger), the result is negative.	
Slew rate rising	SRRise in V/s = V*Hz	Steepness of the rising edge: voltage difference between the lower and higher reference level, divided by the rise time.	$\text{SRRise} = \Delta V / \Delta t$ 
Slew rate falling	SRFall in V/s = V*Hz	Steepness of the falling edge: voltage difference between the higher and lower reference level, divided by the fall time.	$\text{SRFall} = \Delta V / \Delta t$ 
Pos. duty cycle	PDCyc	Width of the first positive pulse in relation to the period in %.	$\text{PDCyc} = \frac{T_{\text{PosPulse}}}{T_{\text{Period}}} \times 100\%$
Neg. duty cycle	NDCyc	Width of the first negative pulse in relation to the period in %.	$\text{PDCyc} = \frac{T_{\text{NegPulse}}}{T_{\text{Period}}} \times 100\%$

Vertical measurements (amplitude)

The unit of most amplitude measurement results depends on the measured source.

Meas. type	Label	Description	Formula, graphic
High	High	High level of the displayed waveform - the upper maximum of the sample distribution, or the mean value of the high level of a square wave without overshoot. The measurement requires at least one complete period of the signal. Also known as top level.	
Low	Low	Low level of the displayed waveform - the lower maximum of the sample distribution, or the mean value of the low level of a square wave without overshoot. The measurement requires at least one complete period of the signal. Also known as base level.	
Amplitude	Amp	Difference between the high level and the low level of the signal. The measurement requires at least one complete period of the signal.	
Max	Max	Maximum value within the displayed waveform.	
Min	Min	Minimum value within the displayed waveform.	
Peak to peak	PTP	Difference of maximum and minimum values.	
Mean	Mean	Arithmetic average of the complete displayed waveform.	$Mean = \frac{1}{N} \sum_{k=1}^N x^k$
RMS	RMS	RMS (root mean square) value of the voltage of the complete displayed waveform.	$RMS = \sqrt{\frac{1}{N} \sum_{k=1}^N x_k^2}$
σ (S-dev/AC-RMS)	σ	Standard deviation of one cycle, usually of the first, left-most signal period.	$\sigma = \sqrt{\frac{1}{N-1} \sum_{k=1}^N (x_k - Mean)^2}$

Meas. type	Label	Description	Formula, graphic
Crest factor	Crest	The crest factor is also known as the peak-to-average ratio. It is the maximum value divided by the RMS value of the displayed waveform.	$Crest = \frac{Max x_k }{RMS}$
Pos. Overshoot	P.OS	Overshoot of a square wave after a rising edge. It is calculated from measurement values High, local Max and Amplitude.	$OS_{pos} = \frac{Max_{local} - High}{Amplitude} \times 100\%$
Neg. Overshoot	N.OS	Overshoot of a square wave after a falling edge. It is calculated from measurement values Low, local Min and Amplitude.	$OS_{neg} = \frac{Low - Min_{local}}{Amplitude} \times 100\%$
Cycle Amp	CAmp	Amplitude of one cycle	
Cycle mean	CMean	Mean value of one cycle	
Cycle RMS	CRMS	RMS (root mean square) value of one cycle	
Cycle σ (S-dev)	Cyc σ	Standard deviation of one cycle	
Cycle max	CMax	Maximum value of one cycle	
Cycle min	CMin	Minimum value of one cycle	
Cycle peak to peak	CPTP	Peak-to-peak value of one cycle: the difference of CMax and CMin	
Cycle crest	CCrest	Crest factor of one cycle	

Area and cycle measurements

All cycle measurements require that at least one complete period of the signal is acquired. Cycle measurements can be found in the "Amp/time" category.

Meas. type	Label	Description/result	
Area	Area	Area between the waveform and ground. T_{Eval} : evaluation time, time of a full waveform or limited by a gate	$Area = \frac{T_{Eval}}{N_{Eval}} \times \sum_{k=1}^{N_{Eval}} x(k)$
Cycle area	CArea	Area between the waveform and ground, measured for one period, see also "Area" measurement.	


Counting

Meas. type	Label	Description/result	
Pulse count	PCount	The number of positive or negative pulses of the waveform, or of both positive and negative pulses. The mean value of the signal is determined. If the signal passes the mean value, an edge is counted. A positive pulse is counted if a rising edge and a following falling edge are detected. A negative pulse is counted if a falling edge and a following rising edge are detected.	
Edge count	EdCo	The number of positive or negative edges, or of both positive and negative edges. The mean value of the signal is determined, and an edge is counted every time the signal passes the mean value.	

10.2.4.2 Settings for amplitude/time measurements

You can define additional parameters for some measurements.

Access: "Menu" > "Measurement" > "Setup" tab > add amplitude/time measurement > settings of a measurement.



For a description of common measurement settings, see:

- ["Specific type"](#) on page 273
- ["Source"](#) on page 273
- ["Reference levels"](#) on page 273
- ["Gate"](#) on page 274
- ["Label"](#) on page 274

Envelope

This setting is only available for measurements on envelope waveforms, see [Acquisition mode](#).

"Both" The upper and the lower envelope are used in measurements. For time measurements, the averages of min and max values are used, that is, the measurement is performed on the average waveform built from the upper and lower envelope.

"Maximum" Measurements are performed on the upper envelope.

"Minimum" Measurements are performed on the lower envelope.

Remote command:

[MEASurement<mg>:ENVSelect](#) on page 1121

Display result lines

Enables the measurement annotations for the selected measurement. These annotations are, for example, periods, maximum and minimum values, relevant reference levels, and more.

See also: [Section 10.2.9, "Annotation for measurements"](#), on page 304.

Remote command:

[MEASurement<mg>:DISPlay:RESults](#) on page 1121

Pulse count

Available, if "Specific type" is set to "Pulse train".

Sets the number N of positive pulses for the "Pulse train" measurement. This measurement measures the duration of N pulses, measured from the selected edge of the first pulse to the opposite edge of the N-th pulse.

Remote command:

[MEASurement<mg>:AMPTime:PTCount](#) on page 1123

Pulse slope

Available, if "Specific type" is set to "Pulse count" or "Pulse train".

Sets the first slope of the pulses to be counted.

"Positive" Positive pulses are counted.

"Negative" Negative pulses are counted.

"Either" Both positive and negative pulses are counted.

Remote command:

[MEASurement<mg>:AMPTime:PSLope](#) on page 1123

Edges slope

Available, if "Specific type" is set to "Edge count".

Sets the edge direction to be used for the selected measurement: positive, negative, or either edge.

Remote command:



[MEASurement<mg>:AMPTime:ESLope](#) on page 1123

Setup/Hold time measurement

Setup/Hold measurements analyze the relative timing between two signals: a data signal and the synchronous clock signal. Setup time is the time that the data signal is steady before the clock edge. Hold time is the time that the data signal is steady after the clock edge.

"Setup/Hold time" measures and displays the setup and hold durations. "Setup/Hold ratio" measurements return the ratio of the setup time to the sum of hold and setup time: $T_{Setup} / (T_{Setup} + T_{Hold})$.

The clock edge can be defined, the polarity of the data signal does not matter.



Source 2, Clock source ← Setup/Hold time measurement

Sets the waveform used as the clock for the setup/hold measurement, or the second source waveform for delay and phase measurements.

Remote command:

[MEASurement<mg>:SSRC](#) on page 1119

Clock slope ← Setup/Hold time measurement

Sets the edge of the clock from which the setup and hold times are measured: positive, negative, or either of them. If "Either" is selected, the clock edges next to the data edge are considered regardless of the clock slope.

Remote command:

[MEASurement<mg>:AMPTime:CSLope](#) on page 1122


Data source ← Setup/Hold time measurement

Sets the source for the data signal. See also: "[Source](#)" on page 273.

Delay and phase measurement

The specific settings for delay measurement allow you to measure the time between any two slopes at any reference level. Therefore, the reference levels and the slopes must be defined for each source individually. The measurement result is negative if the edge of the second source comes before the edge of the first source.

To measure the phase difference between two waveforms, you also set the slope, direction and reference level for each source individually. You can also specify the phase unit.

**Slope ← Delay and phase measurement**

Available, if "Specific type" is set to "Phase" or "Delay".

Sets the edge direction to be used for the selected measurement: positive, negative, or either edge.

Remote command:

[MEASurement<mg>:AMPTime:DElay<n>:SLOPe](#) on page 1124

Direction ← Delay and phase measurement

Selects the direction for counting slopes for each source: from the beginning of the waveform, or from the end.

Remote command:

[MEASurement<mg>:AMPTime:DElay<n>:DIRection](#) on page 1124

Phase unit ← Delay and phase measurement


Selects the unit of the phase: degrees or radians.

Remote command:

[MEASurement<mg>:AMPTime:PHASe:UNIT](#) on page 1125

Delay to trigger measurement settings

Delay to trigger measures the time between the trigger point and the following slope of a waveform. The delay between the trigger and the slope can be high compared to the accuracy of the acquisition, and the trigger point can even be outside of the current acquisition.



To configure the trigger conditions, use the trigger setup.

"Edges slope" Sets the edge direction to be used for delay measurement: positive, negative, or either edge.

Remote command:

[MEASurement<mg>:AMPTime:DTOTrigger<n>:SLOPe](#) on page 1124

Unit (slew rate measurements)

Sets the denominator of the unit for slew rate measurements.

10.2.5 Histogram measurements

You can perform measurements on waveform histograms.






Note that graphical changes on the display, e.g. changing the diagram size or the size of the result table, reset the histogram measurements in run mode and also in stop mode.






10.2.5.1 Overview of measurements on histograms

The specific measurement types for waveform histograms are provided in the "Histogram" category. To see these measurement types, an active waveform histogram is required.

To select and activate measurements in remote control, use:


- `MEASurement<mg>:MAIN` on page 1120
- `MEASurement<mg>[:ENABLE]` on page 1118
- `MEASurement<mg>:ACTIVE` on page 1118

Meas. type	Label	Description, result	Graphic
Histogram peak	HPeak	The maximum sample value in the histogram.	
Histogram samples	HSamp	The number of samples from all acquisitions included in the current histogram.	
Maximum	HMax	The highest signal value with a probability > 0.	
Mean	HMean	The weighted arithmetic average of the histogram.	
Minimum	HMin	The lowest signal value with a probability > 0.	
Max - Min	MxMn	The range of signal values with a probability > 0.	

Meas. type	Label	Description, result	Graphic
Median	Med	The signal value for which half the samples lie above, the other half below in the histogram. The sample count of one signal value after the other are accumulated until half the total number of samples in the histogram is reached. The signal value for which 50% of the samples are accumulated is the median.	
Peak value	Peak	The signal value at the histogram peak.	
Lower peak value	LPeak	The signal value at the maximum sample value in the lower half of the histogram.	
Upper peak value	UPeak	The signal value at the maximum sample value in the upper half of the histogram.	
σ (S-dev)	H σ	Standard deviation of the sample numbers.	
Mean $\pm \sigma$	Mn $\pm\sigma$	Percentage of samples in the range between (mean value + standard deviation) and (mean value - standard deviation).	
Mean $\pm 2 * \sigma$	Mn $\pm 2*\sigma$	Percentage of samples in the range between (mean value + 2 * standard deviation) and (mean value - 2 * standard deviation)	
Mean $\pm 3 * \sigma$	Mn $\pm 3*\sigma$	Percentage of samples in the range between (mean value + 3* standard deviation) and (mean value - 3* standard deviation)	
Waveform count	WCount	The number of waveforms the histogram is based on.	

10.2.5.2 Settings for measurements on histograms

Access: "Menu" > "Measurement" > "Setup" tab > add histogram measurement >  settings of a measurement.



For most measurements on histograms, only common settings are required.

For a description of common measurement settings, see:

- "Specific type" on page 273
- "Source" on page 273
- "Label" on page 274

10.2.6 Basic jitter analysis (option R&S MXO5C-K12)

10.2.6.1 Overview of basic jitter measurements





The specific measurements for basic jitter analysis are provided in the "Jitter" category.

To select and activate measurements in remote control, use:

- `MEASurement<mg>:MAIN` on page 1120
- `MEASurement<mg>[:ENABLE]` on page 1118
- `MEASurement<mg>:ACTIVE` on page 1118

Table 10-1: Jitter measurements

Meas. type	Label	Description	Formula, graphic
Cycle-cycle duty cycle	CCDCyc	Difference between the duty cycle of two adjacent cycles. The measurement is based on the duty cycle measurement. You can select the pulse polarity for the duty cycle measurement.	$\Delta R_{Cyc\ k} = R_{Cyc\ k+1} - R_{Cyc\ k}$ for $k = 1, \dots, K-1$
Cycle-cycle width	CCWid	Difference between the pulse width of two adjacent cycles. The measurement is based on the pulse width measurement. You can select the pulse polarity to be measured.	$\Delta T_{Pulse\ k} = T_{Pulse\ k+1} - T_{Pulse\ k}$ for $k = 1, \dots, K-1$

Meas. type	Label	Description	Formula, graphic
Cycle-cycle jitter	CCJit	Difference between the periods of two adjacent cycles. The measurement is based on the period measurement. You can select the slope and the reference level on which the period is measured.	$\Delta T_{Period\ k} = T_{Period\ k+1} - T_{Period\ k}$ for $k = 1, \dots, K-1$ $\Delta T_1 = T_2 - T_1 \quad \Delta T_2 = T_3 - T_2$ 
N-cycle jitter	NCJit	Difference between the time of two adjacent groups of N cycles (periods) each. You can select the slope and the reference level on which the time is measured, and the number of periods in the groups.	$\Delta T_{Ncycle\ k} = T_{Ncycle\ k+1} - T_{Ncycle\ k}$ for $k = \text{cycle group index}$ $\Delta T_{Ncycle1} = T_{Ncycle2} - T_{Ncycle1}$ 
Time interval error	TIE	Time difference between the slope of the input signal and the slope of a reference signal. The reference signal can be a captured clock waveform, or a clock generated by clock data recovery (CDR, software algorithm or hardware generation). You can select the slope and the reference level on which the TIE is measured.	$TIE_k = t_{Signal\ k} - t_{Clock\ k}$ for $k = 1, \dots, K$ 
Unit interval	UI	Period of the clock signal. If no clock signal is available, it is recovered by CDR. The period is calculated as the time difference between two consecutive clock edges of the same polarity.	$UI_k = t_{Clock\ k+1} - t_{Clock\ k}$ for $k = 1, \dots, K-1$
Data rate	DR	Frequency of the clock signal. If no clock signal is available, it is recovered by CDR. The measurement is based on the unit interval measurement.	$R_{Clock\ k} = 1 / UI_k$ for $k = 1, \dots, K-1$
Skew delay	SkwD	Delay between the edges of two interdependent waveforms. The measurement is a simplified variant of the "Delay" measurement assuming that both sources are similar except for the delay.	$\text{Skew delay} = \Delta t_k = t_{Source2} - t_{Source1}$ for $k = 1, \dots, K$ 
Skew phase	SkwP	Phase difference between the edges of two waveforms.	$\text{Skew phase} = \text{Skew delay} / \text{Period} * 360^\circ = \Delta t_k / \Delta T_{Period\ k} * 360^\circ$

10.2.6.2 Settings for jitter measurements

Access: "Menu" > "Measurement" > "Setup" tab > add jitter measurement >  settings of a measurement.

For a description of common measurement settings, see:

- "Specific type" on page 273
- "Source" on page 273
- "Reference levels" on page 273
- "Gate" on page 274
- "Label" on page 274

Settings for cycle-cycle measurement

The cycle-cycle measurements are used to analyze the quality of clock signals. They require a few additional settings for period and pulse width measurement.

The screenshot shows a dark-themed settings menu. At the top is a 'Measurement' header. Below it is a 'Back' button. The main settings are organized into sections: 'Specific type' (set to 'Cycle-cycle dut...'), 'Source' (set to 'Channel 1'), and 'Reference levels' (set to '1'). A section titled 'Measurement specific properties:' contains 'Cycle begin' (set to 'First edge') and 'Reference level' (set to 'Middle'). Below this is 'Pulse polarity' (set to 'Positive'). Another section titled 'Other properties:' contains 'Gate' (set to 'None') and an empty 'Label' field.

Figure 10-1: Setup for cycle-cycle duty cycle measurement

Cycle begin, Slope

For cycle-cycle jitter, N-cycle jitter, and cycle-cycle duty cycle measurements, "Cycle begin" selects the slope at which the periods and thus the jitter is measured: first edge, positive, negative or either.

For time-interval error measurements, "Slope" sets the edges of the data signal that are used for measurements: positive, negative or either.

"First edge"	Measures the period from the first edge that is found, no matter of its direction.
"Positive"	Measures the period at positive going edges.
"Negative"	Measures the period at negative going edges.
"Either"	Measures the period at both positive and negative going edges. This option is useful, for example, to check the clock stability of a double data rate clock.

Remote command:

[MEASurement<mg>:JITTer:SLOPe](#) on page 1128

Pulse polarity

For cycle-cycle width and the cycle-cycle duty cycle measurements, "Pulse polarity" sets the polarity of pulses for which the pulse width is measured: positive or negative.

For skew delay and skew phase measurements, "Edge polarity" sets the edge of the first waveform from which the measurements starts: positive, negative or either.

Remote command:

[MEASurement<mg>:JITTer:POLarity](#) on page 1126

Reference level

Selects the reference level that is used for time measurements.


Remote command:

[MEASurement<mg>:JITTer:REFLevel<rl>](#) on page 1126

Number of cycles

Sets the number of periods (cycles) that are accumulated to measure the N-cycle jitter.

$$\Delta T_{Ncycle1} = T_{Ncycle2} - T_{Ncycle1}$$



Remote command:

[MEASurement<mg>:JITTer:NCYCles](#) on page 1126

Settings for delay measurements

Skew delay and skew phase measurements are intended to measure the time difference between the edges of two waveforms. The measurements are simplified variants of the "Delay" and "Phase" measurements assuming that both sources are similar except for the delay.

Source 1, Source 2

"Source 1" is the reference signal, and "Source 2" is the signal compared to the reference signal.

$$\text{Skew delay} = \Delta t_k = t_{\text{Source2}} - t_{\text{Source1}} \quad \text{for } k = 1, \dots, K$$

See also: ["Clock slope"](#) on page 283.

Remote command:

[MEASurement<mg>:SOURce](#) on page 1118

Edge polarity

See ["Pulse polarity"](#) on page 290.

Relative polarity

Sets the edge of the second waveform relative to the first waveform.

"Matching" Measures from positive to positive edge or from negative to negative edge.

"Inverse" Measures from positive to negative edge or from negative to positive edge.

Remote command:

[MEASurement<mg>:JITTer:RELPolarity](#) on page 1127

Reference level

Selects the reference level that is used for time measurements on "Source 2".

Remote command:

[MEASurement<mg>:JITTer:REFLevel<rl>](#) on page 1126

Settings for data measurements

The following measurements are intended to analyze serial data:

- Time interval error
- Unit interval
- Data rate

The clock can be a captured clock signal, or it can be recovered from the data signal. The clock or CDR is configured in the "Timing reference" dialog, see [Section 8.3, "Timing reference"](#), on page 213.




Figure 10-2: Setup for unit interval measurement

Slope

Sets the edges of the data signal that are used for measurements. The setting is relevant for time-interval error measurements.

See also: "[Cycle begin, Slope](#)" on page 289.

Timing reference

Selects the timing reference, which is one of the available clock configurations.

For configuration of the timing reference, see [Section 8.3, "Timing reference"](#), on page 213.

Remote command:

`MEASurement<mg>:JITTer:TREF` on page 1128

Unit

Sets the unit to bps (bit per second), or to Hz for analysis of radar signals. The setting is available for data rate measurements.

Remote command:

`MEASurement<mg>:JITTer:UNIT` on page 1129

10.2.7 Eye measurements (option R&S MXO5C-K136)

The measurements on eye diagrams are used for evaluation of signal quality and show the combined effects of channel noise and intersymbol interference. By creating histograms of the eye diagram, important jitter parameters can be determined. See also: [Section 12.7.1, "Calculation and display of eye diagrams"](#), on page 432.

Eye measurements are done on active configured eye diagrams. For configuration, see [Section 12.7.2, "Eye diagram setup"](#), on page 433.

The following characteristic values can be determined:




Figure 10-3: Basic eye diagram characteristics

Eye top = Mean of the upper vertical histogram

σ_{top} = Standard deviation of the upper vertical histogram

Eye base = Mean of the lower vertical histogram

σ_{base} = Standard deviation of the lower vertical histogram
 $T_{crossing}$ = First and second mean of the horizontal histogram
 $\sigma_{crossing}$ = Standard deviation of the horizontal histogram

10.2.7.1 Overview of eye measurements

The specific measurement types for eye diagrams are provided in the "Eye" category. To see these measurement types, an active eye diagram is required.

To select and activate measurements in remote control, use:

- [MEASurement<mg>:MAIN](#) on page 1120
- [MEASurement<mg>\[:ENABLE\]](#) on page 1118
- [MEASurement<mg>:ACTive](#) on page 1118

Table 10-2: Eye measurements


Meas. type	Description/Result
Extinction ratio (%)	The extinction ratio is an indication of efficiency. It describes the ratio of the power used to transmit a logic level 1, to the energy used to transmit a logic level 0. The MXO 5C provides extinction ratio measurements as a percentage, and in decibels. $ER(\%) = Eye\ base / Eye\ top * 100$ Prerequisite: $Eye\ base > 0$ and $Eye\ top > 0$ because the extinction ratio is defined only for positive values.
Extinction ratio (dB)	Extinction ratio in decibels. The fraction is inverted in comparison to ER(%). $ER(dB) = 10\log (Eye\ top / Eye\ base)$
Eye height	The vertical eye opening indicates the sensitivity of the transmission to noise. With algorithm "Three sigma": $(Eye\ top - 3 * \sigma_{top}) - (Eye\ base + 3 * \sigma_{base})$ With algorithm "Actual": eye height is calculated in a user-defined window, in % of the eye period.
Eye width	The horizontal eye opening indicates the time range during which the sampling of the logical state is possible. With algorithm "Three sigma": $(T_{crossing2} - 3 * \sigma_{crossing2}) - (T_{crossing1} - 3 * \sigma_{crossing1})$
Eye top	Mean of the upper vertical histogram, mean value of a logic 1 inside a window defined in the measurement defaults. The default window is 40% – 60% of the eye period. The eye top is also known as level 1.
Eye base	Mean of the lower vertical histogram, mean value of a logic 0 inside a window defined in the measurement defaults. The default window is 40% – 60% of the eye period. The eye base is also known as level 0.
Q factor	$Q\ factor = (Eye\ amplitude) / (\sigma_{top} + \sigma_{base})$
Noise (RMS)	Quadratic mean of the noise of eye top and eye base. $Noise(RMS) = (\sigma_{top} + \sigma_{base})/2$
S/N ratio	Signal-to-noise ratio $SNR = 10\log (Eye\ amplitude / Noise(RMS))$

Meas. type	Description/Result
Duty cycle distortion	Difference of mean time of rising and falling edges at a user defined level relative to the difference of crossing times. The default level is 50% of the amplitude.
Eye rise time	Duration for signal to rise from 10% to 90% of the high signal level.
Eye fall time	Duration for signal to fall from 90% to 10% of the high signal level.
Eye bit rate	Frequency between two crossings. <i>Eye bit rate = 1 / difference of crossing times</i>
Eye amplitude	<i>Eye amplitude = Eye top - Eye base</i>
Jitter (peak to peak)	Average of the jitter for both crossing points. <i>Jitter = ($\sigma_{crossing1}$ + $\sigma_{crossing2}$) / 2</i>
Jitter (6 * σ)	<i>Jitter (6 * σ) = Jitter (RMS) * 6</i>
Jitter (RMS)	Standard deviation of a histogram around crossing time at crossing level or at a user defined level.
Crossing points (%)	Percentage of points crossing the eye. <i>Eye crossing = 100 * (Crossing level - Eye base) / (Eye top - Eye base)</i>

10.2.7.2 Settings for eye measurements

Common settings for all eye measurement types

Access: "Menu" > "Measurement" > "Setup" tab > add eye measurement >  settings of a measurement.



Specific type

Selects the specific measurement type of eye measurements.

Source

See "[Source](#)" on page 273.

Default settings

Selects the default measurement configuration.


Remote command:

[MEASurement<mg>:EYE:DEFSettings](#) on page 1132

Default settings for all eye measurement types

The settings in the "Defaults" tab are relevant for all eye measurements. You can define up to 8 sets of default measurement configurations.

Access: "Menu" > "Measurement" > "Defaults" tab



Type

Selects the category for which the default settings take effect.

Start, Stop

Define the global start and stop times for the eye measurements.

Remote command:

[MDEfaults:SETTings<m>:EYE:RELative:STARt](#) on page 1130

[MDEfaults:SETTings<m>:EYE:RELative:STOP](#) on page 1130

Algorithm

Selects the algorithm, which defines how to compute the top and base levels and the corresponding sigma values.

"Mean"	Mean value of the histogram. The Sigma value is the standard deviation of the histogram.
"Peak"	Maximum peak of the histogram. Only values corresponding to this peak are used to compute sigma.
"Inner peak"	Inner peak of the histogram. Only values corresponding to this peak are used to compute sigma.

"Outer peak" Outer peak of the histogram. Only values corresponding to this peak are used to compute sigma.

Remote command:

[MDEfaults:SETTings<m>:EYE:ALGorithm](#) on page 1129

Threshold

Sets the threshold that is used to separate peaks. Two peaks are separated if they are split by a valley of height $Threshold * Maximal\_histogram\_value$.

The threshold is only relevant for the peak algorithms.

Remote command:

[MDEfaults:SETTings<m>:EYE:THReshold](#) on page 1130

Specific settings for eye measurement types

Access: "Menu" > "Measurement" > "Setup" tab > add eye measurement >  settings of a measurement.




Figure 10-4: Settings for eye height measurement. The same settings are used for eye width measurements.

The screenshot shows the 'Measurement' settings menu. On the left is a 'Back' button. The main menu has 'Specific type' set to 'Eye rise time'. Below it, 'Source' is set to 'Eye 1' and 'Default settings' is set to '1'. A section titled 'Measurement specific properties:' is highlighted with an orange border. It contains 'Reference levels' set to '1', 'Start' set to '40 %', and 'Stop' set to '60 %'. At the bottom of this section is the text: 'The offset percentages refer to one unit interval.'

Measurement		
Back	Specific type Eye rise time	
	Source Eye 1	Default settings 1
Measurement specific properties:		
	Reference levels 1	
	Start 40 %	Stop 60 %
The offset percentages refer to one unit interval.		

Figure 10-5: Settings for eye rise and fall time measurements

The screenshot shows the 'Measurement' settings menu. On the left is a 'Back' button. The main menu has 'Specific type' set to 'Jitter (peak to ...)'. Below it, 'Source' is set to 'Eye 1' and 'Default settings' is set to '1'. A section titled 'Measurement specific properties:' is highlighted with an orange border. It contains 'Use level' set to 'On' (indicated by a blue toggle) and 'Level' set to '50 %'.

Measurement		
Back	Specific type Jitter (peak to ...)	
	Source Eye 1	Default settings 1
Measurement specific properties:		
	Use level On	Level 50 %

Figure 10-6: Settings for jitter measurements




Figure 10-7: Settings for duty cycle measurement

Algorithm (for eye height, eye width)

Selects the algorithm for the measurement of the eye height and eye width.

"Three sigma" The eye height is measured with the settings defined in the "Defaults" tab:

$$\text{Eye height} = (\text{Eye top} - 3\sigma_{\text{top}}) - (\text{Eye base} + 3\sigma_{\text{base}})$$

The eye width is measured at the crossing level:

$$\text{Eye width} = (T_{\text{crossing2}} - 3\sigma_{\text{crossing2}}) - (T_{\text{crossing1}} + 3\sigma_{\text{crossing1}})$$

"Actual" The actual height is the vertical distance between the top and the bottom of the eye opening at the sampling point. It represents the range of levels over which the signal can reliably distinguish between logical 1 and logical 0. The default window is 40% - 60% of the eye period. Specific start and stop values are used for calculation.

"Maximum" The maximum height is the theoretical maximum vertical distance between the highest possible 1 level and the lowest possible 0 level. The default measurement window is 40% - 60% of the eye period. The maximum width of an eye diagram is the maximum horizontal distance between the points where the ideal eye opening crosses the decision threshold level. Perfect signal timing, no jitter and no distortions are assumed. Specific start and stop values are used for maximum calculation.

"Crossing level" The eye width is measured at the crossing level.

"Meas. window" The eye width is measured as the horizontal distance between the points where the eye opening crosses the threshold level. Specific start and stop values are used for calculation.

Remote command:

[MEASurement<mg>:EYE:ALGorithm](#) on page 1132

Mode (for eye height, eye width)

Selects between absolute and relative values for the measurement-specific start and stop values.

Remote command:

[MEASurement<mg>:EYE:MODE](#) on page 1133

Start, Stop (for eye height, eye width)

Set the absolute start and stop values for the selected algorithm.

Remote command:

[MEASurement<mg>:EYE:ABSolute:START](#) on page 1131

[MEASurement<mg>:EYE:ABSolute:STOP](#) on page 1131

Start, Stop (eye height and width, rise/fall time)

Set the relative start and stop values for the selected algorithm of eye height and eye width measurements.

For rise time and fall time eye measurements, the settings define the offset before and after the first eye crossing. Only values inside the specified horizontal range are considered for the measurements.

Remote command:

[MEASurement<mg>:EYE:RELative:START](#) on page 1133

[MEASurement<mg>:EYE:RELative:STOP](#) on page 1134

Use level (jitter)

If enabled, you can define a user-defined level for the jitter measurements on eye diagrams ("Jitter (peak to peak)", "Jitter (RMS)", "Jitter ($6 \cdot \sigma$)").

Remote command:

[MEASurement<mg>:EYE:USELevel](#) on page 1134

Level (jitter, duty cycle)

Defines the relative level for the jitter measurements on eye diagrams if "Use level" is on. The setting also defines the level for duty cycle distortion measurement.

Remote command:

[MEASurement<mg>:EYE:LEVel](#) on page 1133







10.2.8 Protocol measurements (option R&S MXO5C-K500)




10.2.8.1 Overview of protocol measurements

The specific measurement types for protocol measurements are provided in the "Protocol" category. To see these measurement types, an active serial bus is required.

To select and activate measurements in remote control, use:

- [MEASurement<mg>:MAIN](#) on page 1120
- [MEASurement<mg>\[:ENABLE\]](#) on page 1118
- [MEASurement<mg>:ACTive](#) on page 1118

Meas. type	Label	Description/result	
Frame/frame	F2F	The time from the start of one frame to the start of the next frame.	
Trig/frame	T2F	The time from a trigger event to the start of the next frame.	
Frame/trig	F2T	The time from the start of a frame to the next trigger event.	
Field value	FVal	The value of a selected field in a frame.	
Main bit rate	BPS	The nominal bits per second (bps) in a selected frame. The measurement ignores, for example, gaps in a LIN frame or a bus park bit in an RFFE or SPMI frame.	
2nd bit rate	BPS2	Like main bit rate, but optional for protocols with multiple bit rates, e.g. CAN/CAN-XL, SPMI or RFFE write / read.	
Bus idle	Idle	Percentage of idle times between all frames in an acquisition.	
Gap	Gap	The gap time (not necessarily idle) between two frames.	

Meas. type	Label	Description/result	
Frame count	FCnt	The number of complete frames in an acquisition.	
Frame errors	FECnt	The number of erroneous frames in an acquisition.	
FER	FER	The frame error rate, hence the percentage of erroneous frames in an acquisition.	
Cons FER	CFER	The frame error rate (percentage) of two or more consecutive erroneous frames.	
RS errors	RSErr	Available only in the 1000BASE-T1 protocol: The number of transmission errors in a PHY frame, in which the forward error correction algorithm of the Reed-Solomon decoder can correct up to 25 errors.	

10.2.8.2 Settings for protocol measurements

You can define additional parameters for some protocol measurements.

Access: "Menu" > "Measurement" > "Setup" tab > add protocol measurement >  settings of a measurement.

Available only, if "Source" = "Serial Bus N".

For a description of common measurement settings, see:

- ["Specific type"](#) on page 273
- ["Source"](#) on page 273
- ["Label"](#) on page 274

Frame Identification or From

"Frame Identification" is available only for the measurement types "Frame/trig", "Trig/frame" and "Field value". "Frame Identification" specifies where the measurement is executed.

"From" is available only for the measurement type "Frame/frame", which requires a "From" - "To" condition. "From" specifies where the measurement starts.

All other measurement types do not require these settings.

Frame Type ← Frame Identification or From

In a "Frame Identification", this setting specifies the type of the frame at which the measurement is executed.

In a "From" - "To" condition, this setting specifies the type of the frame at which the measurement starts.

Remote command:

[MEASurement<mg>:PROTOCOL:FNAME](#) on page 1135

Field Type ← Frame Identification or From

In a "Frame Identification", this setting specifies the type of the field at which the measurement is executed.

In a "From" - "To" condition, this setting specifies the type of the field at which the measurement starts.

Remote command:

[MEASurement<mg>:PROTocol:FDName](#) on page 1135

Field Value ← Frame Identification or From

In a "Frame Identification", this setting specifies the value of the field at which the measurement is executed.

In a "From" - "To" condition, this setting specifies the value of the field at which the measurement starts.

Remote command:

[MEASurement<mg>:PROTocol:FDValue](#) on page 1135

To

"To" is available only for the measurement type "Frame/frame", which requires a "From" - "To" condition. "To" specifies where the measurement ends.

Frame Type ← To

Specifies the type of the frame at which the "Frame/frame" measurement ends.

Remote command:

[MEASurement<mg>:PROTocol:F2Name](#) on page 1136

Field Type ← To

Specifies the type of the field at which the "Frame/frame" measurement ends.

Remote command:

[MEASurement<mg>:PROTocol:FD2Name](#) on page 1136 (used also for [Tracked](#))

Field Value ← To

Specifies the value of the field at which the "Frame/frame" measurement ends.

Remote command:

[MEASurement<mg>:PROTocol:FD2Value](#) on page 1136

Tracked

Available only for the measurement type "Field value". This setting selects the field type to be displayed.


Remote command:

[MEASurement<mg>:PROTocol:FD2Name](#), the same command is used for [Field Type](#).

10.2.9 Annotation for measurements

Measurement annotations mark the significant places in the diagram, for example, periods, maximum and minimum values, relevant reference levels, and more. The lines help understand the measurement results.

In the "Annotation" tab, you can select the measurements to be annotated. Alternatively, you can enable "Display result lines" in the "Setup" of a selected measurement. See ["Display result lines"](#) on page 281.



The "Check measurements to enable annotations" list shows all active measurements. The list is empty if no measurement is active. Configure and activate the measurements first, then select them for annotation.




Figure 10-8: Example of annotations for cycle measurements

10.2.10 Measurement results

The measurement results are shown in a table below the grid.

Measure	Statistics
1 C1 Amp.: 3.418 mV	2 C1 Min: -2.443 mV
3 C1 Max: 3.054 mV	4 C1 PTP: 5.497 mV

Dashes (---) indicate that no valid waveform is available, for example, if the source waveform is off.

For further analysis of measurement results, the following evaluations are available:

- [Section 10.2.11.1, "Statistics"](#), on page 306
- [Section 10.2.11.2, "Track"](#), on page 307

You can save the measurement results to file, see [Section 13.6, "Results"](#), on page 464.

10.2.11 Analysis of measurement results

The behavior of measurement results over time can be evaluated in different ways, for example, with statistics and tracks.

- [Statistics](#).....306
- [Track](#)..... 307

10.2.11.1 Statistics


In addition to the current measurement results, you can enable a statistical evaluation. It returns the current, minimum and maximum measurement values, the average and standard deviation, and the number of measured waveforms. The results are shown in a separate tab below the grid. If the cursor measurement is active simultaneously, its results are shown beside the statistics results.

If statistics are enabled, the following results are calculated. .

Label	Description
Max	Positive peak value (maximum)
Min	Negative peak value (minimum)
Mean	Arithmetic mean (average)
RMS	Root mean square
σ (S-dev)	Standard deviation
Rel. σ	Relative standard deviation (<i>S-dev / Mean</i>)
Event count	Number of measured events (e.g. rising edges, pulses etc.)
Wave count	Number of waveforms (acquisitions) the measurement is based on

Measure	Current	Max	Min	Mean	RMS	σ (S dev)	Event count	Wave count
1 C1 Amp.	4.88 mV	7.81 mV	1.46 mV	3.8 mV	3.91 mV	938.01 μ V	2847	2847
2 C1 Min	-2.44 mV	-1.71 mV	-4.76 mV	-2.59 mV	2.71 mV	365.09 μ V	2283	2283
3 C1 Max	3.66 mV	5.25 mV	2.32 mV	3.29 mV	3.31 mV	356.83 μ V	2283	2283
4 C1 PTP	6.11 mV	8.18 mV	4.76 mV	5.98 mV	6 mV	480.81 μ V	2283	2283

Access: "Menu" > "Measurement" > "Statistics" tab.



Statistics

Activates or deactivates the statistical evaluation for the measurement.

Remote command:

[MEASurement<mg>:STATistics\[:ENABle\]](#) on page 1140

Clear results

Deletes the statistical results for all measurements including the histogram, and starts a new statistical evaluation.

Remote command:

[MEASurement<mg>:STATistics:ARESet](#) on page 1140

To delete results of individual measurements, use [MEASurement<mg>:CLEar](#) on page 1140 or [MEASurement<mg>:STATistics:RESet](#) on page 1140.

Measure all events

Normally, only one measurement is performed for each acquired waveform to get best performance. If "Measure all events" is enabled, more than one result is taken from one acquired waveform and the results are included in evaluation. For example, the rise time is measured on all pulses in the waveform, not only on the first.

The result table shows only the first result of the waveform, the following results are used only for evaluation. The number of considered results can be restricted: see [Max. No. of events](#).

Measuring all events is useful when calculating statistics and histograms. It can also be useful when generating tracks; however, it reduces the performance of the instrument.

The setting affects all measurements, it is a global setting. However, if a track is enabled for a selected measurement, all results are considered for this measurement, independent from the global setting.

Remote command:

[MEASurement<mg>:MULTiple](#) on page 1140

Max. No. of events

Sets the maximum number of measured events per acquisition.

Remote command:

[MEASurement<mg>:MNOMeas](#) on page 1141

10.2.11.2 Track

A track shows the measurement results over time for an acquired waveform. The track is the graphical interpretation of all measurement values of a single acquisition. Furthermore, the track reveals trends of change in the analysis and preserves the timing relationship of the measurement results to the signal.

Tracks can be enabled for each active measurement. Enabling the track also enables "Measure all events" for the selected measurement.

To analyze tracks, you can use cursor measurements, zoom, mathematics and spectrum.

Track activation

Access: "Menu" > "Measurement" > "Track" tab.




Figure 10-9: Measurement selection for tracks

Check measurements to enable track

The list shows all active measurements. The list is empty if no measurement is active. Enable the measurements first, then select them for track analysis.

Select the checkbox of a measurement to enable the track for this measurement. See also: "State" on page 309.

Tap the button to open the track settings.

Track settings

Access: "Menu" > "Measurement" > "Track" tab > tap measurement button.




Figure 10-10: Track settings

State

Enables or disables the track for the selected measurement.

Enabling the track also enables "Measure all events" for the selected measurement.

Remote command:

[MEASurement<mg>:TRACk\[:STATe\]](#) on page 1141

Auto scale

Performs an automatic scaling whenever the track does not fit in the diagram during the measurement period.

Remote command:

[MEASurement<mg>:TRACk:CONTiunous](#) on page 1142

Fit to screen

Sets the vertical scale and the offset of the track, so that the complete height of the diagram is used.

Remote command:

[MEASurement<mg>:TRACk:AUTO](#) on page 1141

Meas scale

Defines the vertical scale of the track diagram. If "Auto scale" is on, the current scale value is displayed.

You can also select the track waveform and use the vertical [Scale] knob to change the scale.

Remote command:

[MEASurement<mg>:TRACk:SCALE](#) on page 1142

Meas offset

Defines the offset of the track waveform. If "Auto scale" is on, the current offset value is displayed.

You can also select the track waveform and use the vertical [Position] knob to change the offset.

Remote command:

[MEASurement<mg>:TRACk:OFFSet](#) on page 1142

Examples of track usage

The examples in this section provide ideas on how you can use tracks for waveform analysis.

Tracks with math functions



Figure 10-11: Tracks used in math functions

The example is set up as follows:

- Waveform on channel 1
- 3 measurements on C1: positive duty cycle, period and positive pulse width
- Enable track for each measurement: Track 1 (positive duty cycle), Track 2 (period), Track 3 (positive pulse width)
- Math1 = Trk1 * Trk2
- Math2 = Math1 / 100
Expected values: Period * Pos. duty cycle / 100 = Positive pulse width, i.e. Math2 = Trk3
- Math3 = Math2 - Trk3
Expected values = 0

Spectrum on tracks



Figure 10-12: Track and spectrum on this track. C1 is not in the diagram.

The example is set up as follows:

- Waveform on channel 1
- Period measurement on C1
- Enable track for the period measurement: Track 1
- Spectrum with "Source" = Track 1
- Enable "Peak list" > "Peak on waveform"

Zoom on tracks




Figure 10-13: Track and C1 in the upper diagram, zoom below

The example is set up as follows:

- Waveform on channel 1
- Period measurement on C1
- Enable track for the period measurement: Track 1.
- Drag and drop the track on the channel waveform.
- Create zoom.

11 Spectrum analysis


The MXO 5C provides an easy way to set up a spectrum analysis. The spectrum settings are independent of the time domain settings but the time and frequency domains are time-correlated.

You can analyze spectrum traces in various ways:

- Use peak lists.
- Use zoom.
- Perform cursor measurements.
- Export the spectrum data to files.
- Retrieve and transmit spectrum data for further analysis using remote commands.

11.1 Fundamentals of spectrum analysis

During spectrum analysis, a signal in the time domain is converted to a spectrum of frequencies. As a result, either the magnitude or the phase of the determined frequencies can be displayed. Spectrum analysis can be restricted to an extract of the original time base, and the results display can be restricted to a specified frequency range.




Frames in FFT

By default, one FFT per acquisition is calculated. The MXO 5C can calculate multiple FFTs per acquisition by dividing one record length into several *frames*. Thus, the MXO 5C can visualize how the frequency content of a signal changes over time which helps to detect intermittent or sporadic signal details. Furthermore, the MXO 5C allows consecutive frames to overlap. This is especially useful in conjunction with window functions since it enables a gap-free frequency analysis of the signal.

The overlapping factor can be set freely. The higher the overlap factor, the more frames are used. This leads to more individual results and improves detection of transient signal effects. However, it also extends the duration of the calculation. The size of

the frame depends on the number of input signal values (record length), the overlap factor, and the number of samples used for FFT calculation.



Window functions


Each frame is multiplied with a specific window function after sampling in the time domain. Windowing helps minimize the discontinuities at the end of the measured signal interval and thus reduces the effect of spectral leakage, increasing the frequency resolution.

There are several window functions that can be used in FFT analysis. Each of the window functions has specific characteristics, including some advantages and some trade-offs. Consider these characteristics carefully to find the optimum solution for the measurement task.

For details, see ["Window type"](#) on page 320.

Gating functions

You can restrict the time base of the input signal for which spectrum analysis is to be performed. You can define start and stop times for the time base extract.



Restricting the result range

You can restrict the results of the spectrum analysis to a specified frequency range. The frequency range can be defined in two ways:

- Define a center frequency and frequency span
- Define start and stop frequencies

Dependencies between spectrum parameters

Spectrum analysis in the MXO 5C is highly configurable. Several parameters, including the resolution bandwidth, frequency span and center frequency, can be defined according to your requirements. Note, however, that several parameters are correlated and not all can be configured independently of the others.

The **resolution bandwidth** defines the minimum frequency separation at which the individual components of a spectrum can be distinguished. Small values result in high precision, as the distance between two distinguishable frequencies is small. Higher values decrease the precision, but increase measurement speed.

The minimum achievable RBW depends on the integration time which is equivalent to the number of samples available for calculation. If a higher spectral resolution is

required, the number of samples must be increased by using a higher sample rate or longer record length. To simplify operation, some parameters are coupled and automatically calculated, such as record length and RBW.

The **frequency span** and **center frequency** define the start and stop frequency of the spectral diagram. By default, a suitable frequency range according to the resolution bandwidth is selected, in respect to performance and precision. Span and RBW settings are coupled, so that the parameters can be adjusted automatically as necessary.

With a **Span/RBW ratio** of 100 and a screen resolution of 1000 pixels, each frequency in the spectrum is displayed by 10 pixels. A span/RBW ratio of 1000 provides the highest resolution. For full flexibility, the span/RBW coupling can also be disabled. Note, however, that a higher span/RBW ratio (i.e. low RBW values and large frequency spans) result in large amounts of data and extend the duration of the calculation.

11.2 Configuring spectrum waveforms


During spectrum analysis, a signal in the time domain is converted to a spectrum of frequencies. A basic spectrum waveform can be displayed quickly. By defining additional parameters, the waveform can be configured in more detail.

To display a basic spectrum waveform

1. Press the [FFT] key.

The "Setup" tab of the "Spectrum" dialog box opens.

2. Set the "Source" to the input signal.
3. Enable "Display".



4. If necessary, edit the spectrum waveform parameters as described in the following procedures.

To configure the spectrum

By default, a suitable frequency range for the expected horizontal values according to the resolution bandwidth is selected, in respect to performance and precision. Span and RBW settings are coupled. If a more precise evaluation is required, for example for postprocessing in a different application, disable the coupling and change the frequency ranges and resolution bandwidth values as required.

1. Press the [FFT] key.

The "Setup" tab of the "Spectrum" dialog box opens.

2. In the "Setup" tab, specify the frequency range you want to display using one of the following methods:
 - Select "CF span". Enter a "Center" and a "Span" that define the spectrum.
 - Select "Start Stop". Enter a "Start" and "Stop" frequencies that define the spectrum.
 - Tap the "Full span" button to display the complete spectrum resulting from the FFT analysis.

3. Define the resolution bandwidth for the spectrum result.

The resolution bandwidth defines how precise the results are, i.e. how close together the individual frequencies can be. Small values result in high precision, as the distance between two distinguishable frequencies is small. Higher values decrease the precision, but increase performance.

You can define the RBW manually, or couple it to other settings. Do one of the following:

- To couple the RBW to the span, enable "Auto RBW". Define the "Span/RBW" ratio, the smaller the ratio, the higher the RBW becomes to display the same frequency span.
- Disable "Auto RBW". Enter the "RBW" manually.

4. Tap "Advanced".
5. Select the most suitable "Window type" for your source data. Window functions are multiplied with the input values and thus can improve the spectrum display. For details, see ["Window type"](#) on page 320.

To restrict the input values (gating)


You can restrict the time range for which the FFT is calculated, resulting in a restricted spectrum.

1. Open "Menu" > "Spectrum" > "Gate" tab.
2. Enter the "Start" and the "Stop" times that define the gate area.
3. Set the "Position" and the "Width".

The spectrum waveform displays the spectrum for the specified time span.

11.3 Spectrum setup

Access: "Menu" > "Spectrum" > "Setup" tab.



In this tab, you define the settings for the spectrum window. The display can be restricted to the results for a certain time base extract and to a specified frequency range.



The settings in this dialog are greyed out and cannot be changed, if "Coupling" is enabled in the "Scale" tab.

Display

Enables the spectrum.

Remote command:

[CALCulate:SPECTrum<sp>:STATe](#) on page 1163

Source

Selects the source for the spectrum.

Remote command:

[CALCulate:SPECTrum<sp>:SOURce](#) on page 1163

Full span

Displays the full frequency span.

CF span, Start Stop

Selects if the frequency span is defined through a "Center"/"Span" pair or through the "Start"/"Stop".

Center

Defines the position of the displayed frequency range, which is $(\text{Center} - \text{Span}/2)$ to $(\text{Center} + \text{Span}/2)$. The width of the range is defined using the frequency span setting.

Remote command:

[CALCulate:SPECTrum<sp>:FREQuency:CENTer](#) on page 1159

Span

The span is specified in Hertz and defines the width of the displayed frequency range, which is $(\text{Center} - \text{Span}/2)$ to $(\text{Center} + \text{Span}/2)$. The position of the span is defined using the "Center" setting.

Remote command:

[CALCulate:SPECTrum<sp>:FREQuency:SPAN](#) on page 1160

Start

Defines the start frequency of the displayed frequency span.

Remote command:

[CALCulate:SPECTrum<sp>:FREQuency:START](#) on page 1160

Stop

Sets the stop frequency of the displayed frequency span.

Remote command:

[CALCulate:SPECTrum<sp>:FREQuency:STOP](#) on page 1161

Auto RBW

Couples the frequency span to the "RBW" setting.

If span and RBW values are coupled, changing the span also changes the RBW.

Remote command:

[CALCulate:SPECTrum<sp>:FREQuency:BANDwidth\[:RESolution\]:AUTO](#)
on page 1158

Span/RBW

Defines the coupling ratio for Span/RBW.

This setting is only available if "Auto RBW" is enabled.

Remote command:

[CALCulate:SPECTrum<sp>:FREQuency:BANDwidth\[:RESolution\]:RATIo](#)
on page 1159

RBW

Defines the resolution bandwidth. Note that the resolution bandwidth is correlated with the span, record length and acquisition time. If a constant record length is to be used, the RBW can be adapted if the required number of samples cannot be acquired.

Remote command:

`CALCulate:SPECTrum<sp>:FREQuency:BANDwidth[:RESolution][:VALue]`

on page 1159

Window type

Selects the window type. Windowing helps minimize the discontinuities at the end of the measured signal interval and thus reduces the effect of spectral leakage, increasing the frequency resolution.

Various different window functions are provided in the MXO 5C to suit different input signals. Each of the window functions has specific characteristics, including some advantages and some trade-offs. Consider these characteristics carefully, to find the optimum solution for the measurement task.

Window type	Frequency resolution	Magnitude resolution	Measurement recommendation
Rectangular	Best	Worst	Separation of two tones with almost equal amplitudes and a small frequency distance
Hamming Hann	Good	Poor	Frequency response measurements, sine waves, periodic signals and narrow-band noise
Blackman Harris (default)	Good	Good	Mainly for signals with single frequencies to detect harmonics Accurate single-tone measurements Best compromise of frequency and magnitude resolutions
Gaussian	Good	Good	Weak signals and short duration
FlatTop2	Poor	Best	Accurate single-tone measurements
Kaiser Bessel	Poor	Good	Separation of two tones with differing amplitudes and a small frequency distance

Remote command:

`CALCulate:SPECTrum<sp>:FREQuency:WINDow:TYPE` on page 1161

Traces

Spectrum analysis can only be performed on a maximum number of values at once. If more values must be calculated, the input signal is divided into segments, each of which is calculated separately. The segments need not to be disjunct. In this case, the arithmetic mode defines how the final result is calculated from the individual results.

The following methods are available:

- "Norm" The data of only one segment is considered. In effect, no arithmetics are processed.
- "Min hold" Determines the minimum result for each input value from the data of the current acquisition and the acquisitions before.

"Max hold" Determines the maximum result for each input value from the data of the current acquisition and the acquisitions before.

"Average" The average is calculated over the number of segments set with "Average count".

Remote command:

`CALCulate:SPECTrum<sp>:WAVEform:AVERage:ENABle` on page 1165

`CALCulate:SPECTrum<sp>:WAVEform:AVERage:COUNt` on page 1164

`CALCulate:SPECTrum<sp>:WAVEform:MAXimum:ENABle` on page 1165

`CALCulate:SPECTrum<sp>:WAVEform:MINimum:ENABle` on page 1165

`CALCulate:SPECTrum<sp>:WAVEform:NORMal[:ENABle]` on page 1165

Spectrum preset


Presets the spectrum measurement.

Remote command:

`CALCulate:SPECTrum<sp>:PRESet` on page 1163

11.4 Spectrum scale

Access: "Menu" > "Spectrum" > "Scale".



Scale mode

By default, the vertical scale is adapted to the current measurement results automatically to provide an optimal display. However, if necessary, you can define scaling values manually to suit your requirements.

Note: When you change the scaling values manually using the [Scale] rotary knob, the scale mode is set to "Manual" temporarily.

"Manual" Enter the required values for "Vertical maximum" and "Vertical range".

"Auto" "Vertical maximum" is read-only.

Magnitude unit

Sets the unit for the y-axis.

The display values are calculated for the termination impedance that is set in "Vertical" > "Other" tab > "Impedance".

Remote command:

`CALCulate:SPECTrum<sp>:MAGNitude:SCALe` on page 1162

Vertical maximum

Sets the maximum displayed value on the vertical scale.

Remote command:

`CALCulate:SPECTrum<sp>:MAGNitude:LEVel` on page 1162

Vertical range

Sets the range of the spectrum values to be displayed.

Remote command:

`CALCulate:SPECTrum<sp>:MAGNitude:RANGe` on page 1162

Frequency axis

Defines the scaling method for the frequency axis (x-axis) of the spectrogram.

Available are logarithmic and linear scaling.

Remote command:

`CALCulate:SPECTrum<sp>:FREQuency:SCALe` on page 1160

Coupling, Couple from

If the coupling is enabled, the settings of the current spectrum are coupled to the spectrum selected with "Couple from".

11.5 Spectrum gate

Access: "Menu" > "Spectrum" > "Gate"

S1		
Setup	Start -950 ns	Stop 950 ns
Scale	Position	Width
Gate	0 s	1.9 μ s

Spectrum gating restrict the spectrum analysis to a user-defined region of the captured time domain signal.

Start

Sets the starting value for the gate.

Remote command:

[CALCulate:SPECTrum<sp>:GATE:START](#) on page 1166

Stop

Sets the end value for the gate.

Remote command:

[CALCulate:SPECTrum<sp>:GATE:STOP](#) on page 1166

Position

Sets the position of the displayed frequency range.

The width of the gate is defined using the "Width" setting.

Remote command:

[CALCulate:SPECTrum<sp>:GATE:POSition](#) on page 1166

Width

Defines the width of the displayed gate.

The position of the span is defined using the "Position" setting.


Remote command:

[CALCulate:SPECTrum<sp>:GATE:WIDTh](#) on page 1167

11.6 Spectrum peak list

A peak list measurement detects all peaks above a user-definable threshold and optionally indicates the peaks in the spectrum diagram.

Access: "Menu" > "Spectrum" > "Peak list".



In the peak list dialog, you can define various criteria for a peak search. The peaks can be indicated in the frequency diagram by peak boxes, and the measured peak frequencies and magnitudes are listed in the peak list table.

The number of determined peaks can be defined. You can sort the results by frequency or power value, and the peak labels are adjusted accordingly.



Also, you can adjust some of the display settings, see [Section 5.3.4, "Peak list"](#), on page 101.

To analyze the peaks in a spectrum, you can also use cursors on the spectrum waveform and peak search functions. For details, see [Section 10.1.3.3, "Peak search tab"](#), on page 264.

Remote commands query peak results and to change the results display:

- [CALCulate:SPECTrum<sp>:PLIST:RESult\[:VALue\]? on page 1169](#)
- [CALCulate:SPECTrum<sp>:PLIST:SORT:COLumn on page 1169](#)
- [CALCulate:SPECTrum<sp>:PLIST:SORT:ORDer on page 1170](#)
- [CALCulate:SPECTrum<sp>:PLIST:LAbel:INVert on page 1170](#)

Peak table

Enables the display of the peak table.



Remote command:

[CALCulate:SPECTrum<sp>:PLIST\[:STATe\] on page 1168](#)

Peak on waveform

Displays a box with a description for each detected peak in the spectrum, including the magnitude. If "Show frequency" is enabled, the frequency values are also displayed.

If this option is disabled, the peaks are marked on the diagram only with a point marker.

"Peak on waveform" > "Off"	"Peak on waveform" > "On"
	

Remote command:

[CALCulate:SPECTrum<sp>:PLIST:SPOW on page 1169](#)

Threshold

Sets an absolute threshold as an additional condition for the peak search. Only peaks that exceed the threshold are detected.

This setting is only available for spectrum waveforms. It is valid for cursor measurements, spectrum measurements and peak search.

Remote command:

[CALCulate:SPECTrum<sp>:THReshold on page 1164](#)


Peak excursion

Defines a minimum level value by which the waveform must drop left and right of the local maximum to be listed as a peak. Enter a peak excursion value to omit close by peaks and list just the highest peak.

This setting is only available for spectrum waveforms. It is valid for cursor measurements, spectrum measurements and peak search.

Example:

In the figure below, 2 peaks are shown, that rise above the defined "Threshold". Peak 1 fulfills the defined "Peak excursion" value and is counted as a peak. Peak 2 does not fulfill the defined "Peak excursion" value on the right and is not counted as a peak.



Remote command:

[CALCulate:SPECTrum<sp>:PEXCursion](#) on page 1164

[CURSor<cu>:PEXCursion](#) on page 1156

Max results

Sets the maximum number of measurement results that are listed in the result table.

Remote command:

[CALCulate:SPECTrum<sp>:PLISt:MAXCount](#) on page 1168

Result mode

Selects how the measurement results are displayed.

"Absolute" The peaks are shown in absolute value, dBm.

"Relative" The level of the carrier is shown in absolute value dBm. The values of the peaks are shown relatively to the carrier in dBc.

Remote command:

[CALCulate:SPECTrum<sp>:PLIST:MODE](#) on page 1168

Show frequency

Includes the frequency of the detected peak in the diagram labels.

Remote command:

[CALCulate:SPECTrum<sp>:PLIST:LABel:FREQuency\[:STATe\]](#) on page 1170

Source

Selects the source of the peak table. You can select one of the traces that is enabled with [Traces](#).


Remote command:

[CALCulate:SPECTrum<sp>:PLIST:SOURce](#) on page 1168

11.7 Spectrum overlap

Access: "Menu" > "Spectrum" > "Setup" tab.

For an description of the basic principles of FFT frames and overlapping, see ["Frames in FFT"](#) on page 313.



Enable

Activates the use of frames and overlap to create the FFT spectrum.

Remote command:

[CALCulate:SPECTrum<sp>:OVERlap:ENABle](#) on page 1171

Limit # of FFTs

Limits the number of FFTs that are done per acquisition.

If limitation is off, the firmware sets the number of FFTs automatically to the maximum number that fit in the width of the overview window. It is possible, that some data at the left and the right of the display does not fit in the frames. The gate is set automatically and cannot be changed.

If limitation is active, you can set the number of frames ("[FFTs per acq.](#)" on page 328). You can change the gate, which changes the frame width, too.

Remote command:

[CALCulate:SPECTrum<sp>:OVERlap:FCOunt:LIMit:ENABle](#) on page 1172

FFTs per acq.

Sets the number of frames to be used for FFT with active limitation. The frame width remains unchanged, and the resulting gate width is *frame width * FFTs per acq.*

Remote command:

[CALCulate:SPECTrum<sp>:OVERlap:FCOunt:VALue](#) on page 1173

[CALCulate:SPECTrum<sp>:OVERlap:FCOunt:ADJusted?](#) on page 1173

Overlap factor

Defines the minimum factor by which two neighboring frames overlap. Depending on the settings, the system adjusts the value upward.

The higher the overlap factor, the more frames are used. This leads to more detailed results and improves detection of transient signal effects. However, it also extends the duration of the calculation.

Remote command:

[CALCulate:SPECTrum<sp>:OVERlap:FACTor:VALue](#) on page 1172

[CALCulate:SPECTrum<sp>:OVERlap:FACTor:ADJusted?](#) on page 1172

Frame width

Shows the current frame width.

Increasing the RBW increases the frame width, and vice versa. With active limitation of the frame number, changing the gate results in adjustment of the frame width.

Remote command:

[CALCulate:SPECTrum<sp>:OVERlap:FWIDth?](#) on page 1173

12 Applications

All available applications are provided in the "Apps" dialog.

- ▶ To open an application, press the [Apps] key.

Some applications are described in other sections. See:

- [Section 9.4, "Reference waveforms"](#), on page 241
- [Section 9.5, "Waveform histograms"](#), on page 250
- [Section 16, "Waveform generator \(option R&S MXO5C-B6\)"](#), on page 859
- [Section 13.9, "File browser dialog"](#), on page 474
- [Section 14, "Protocol analysis"](#), on page 476
- "Add scope": [Section 17.2, "ScopeSync"](#), on page 878

Also the "Demo" is available in the "Apps" dialog. It is for demonstration purposes of the functionalities of MXO 5C.

12.1 Mask testing

12.1.1 About mask testing

Masks are used to determine whether the signal remains within specified limits, e.g. to uncover signal anomalies or test compliance and stability of digital signals. The limits are specified as "mask", which is laid over the input signal in the display. Thus you can easily detect where the signal violates the mask.

Mask testing with MXO 5C is hardware accelerated. It's the industry's fastest mask test with hardly any impact on the acquisition rate, thus mask violations are detected fast and reliably.

With MXO 5C, you can define your own masks easily. Specific actions can be executed when mask violations occur. For error analysis, you can stop the acquisition on a failed test and use the history to look at the previous waveforms.

Mask test

A mask test consists of:

- Mask definition
- Waveform to be tested
- Actions to be taken on violation or successful completion

Mask Definition

A mask can have one or more segments. Each segment has a predefined shape: rectangle, square, diamond, hexagon or octagon. You can change the shape by moving

the edge points on the screen or change the numerical values. You can also add and remove single edge points.

A mask segment can have only one range in y-direction at a certain time point. If a shape is not valid, the invalid point is marked red, and an attention symbol is shown at the segment name.




Figure 12-1: Invalid mask segment (left) and valid mask segment (right)

To check the validity in remote control, use `MTESt<m>:SEGMENT<n>:VALid?` and `MTESt<m>:SEGMENT<n>:POINT<o>:VALid?`.

12.1.1.1 Results of a mask test

A mask test shows the following test results:

Mask1 - C1	
Total Acq.:	243 295 080
Passed Acq.:	238 507 186
Failed Acq.:	4 787 894
Fail rate:	1.968 %
Result	Fail

Total acq.

Number of tested acquisitions.

Remote command:

`MTESt<m>:RESult:COUNT:WAVEforms?` on page 1185

Passed acq.

Number of acquisitions that passed the test.

Remote command:

`MTESt<m>:RESult:COUNT:PWAVEforms?` on page 1185

Failed acq.

Number of failed acquisitions.

Remote command:

[MTESt<m>:RESult:COUNT:FWAVEforms?](#) on page 1185

Fail rate

Ratio of failed acquisitions to the number of tested acquisitions.

Remote command:

[MTESt<m>:RESult:FRATe?](#) on page 1186

Result


A test has failed if at least one acquisition violated the mask.

Remote command:

[MTESt<m>:RESult\[:RESult\]?](#) on page 1186

12.1.2 Mask test setup: general settings

Access: "Menu" > "Apps" > "General" tab > "Masks" > "Setup" tab



+ Add mask

Adds a mask test and opens the subtab to configure the new test.

Remote command:

[MTESt<m>:ADD](#) on page 1176

Enable test

Activates or deactivates the mask test.

If the acquisition is running, the test starts immediately. Otherwise, the test starts when acquisition is started. The testing is stopped when acquisition is stopped, or if a stop action is configured.

Remote command:

[MTESt<m>:STATe](#) on page 1178

Display

Displays all mask segments of the selected mask in the diagrams, or hides them.

Remote command:

[MTESt<m>:VISible](#) on page 1179

Source

Selects the waveform to be tested against the mask.

All analog channel waveforms, math waveforms, XY-plots and norm traces of spectrums can be tested.

Remote command:

[MTESt<m>:SOURce](#) on page 1178

Edit segments

Opens a dialog to add and configure the segments of the mask. See [Section 12.1.3, "Mask test setup: segment definition"](#), on page 333 for description.

Save mask

Opens a dialog to define the storage location and filename, and save the mask.

"<Folder>"	Opens a file explorer where you can select the directory where the file is saved.
"File name base"	Sets a name for the file, without extension. The name is extended with a time stamp when the file is saved. Thus, multiple "Save" actions are possible without changing the filename.
"File extension"	The format of the mask file is always <code>.xml</code> .
"Save"	Saves the file in the defined folder using the "File name base". If the specified file already exists, it is overwritten with the new data.
"Save As"	Opens a file explorer where you select the folder, the file type, enter the filename and save the file.

Remote command:

[MTESt<m>:IMEXport:NAME](#) on page 1177

[MTESt<m>:IMEXport:SAVE](#) on page 1178

Load mask

Opens a file explorer to select a previously stored mask file. The selected mask is loaded and used for test.


Remote command:

[MTESt<m>:IMEXport:NAME](#) on page 1177

[MTESt<m>:IMEXport:OPEN](#) on page 1177

12.1.3 Mask test setup: segment definition

"Menu" > "Apps" > "General" tab > "Masks" > "Setup" tab > "Edit segments"



Shape

Selects the shape of the user-defined mask: rectangle, diamond, hexagon, octagon.

Add segment

Adds a new segment with the selected shape to the mask.

Remote command:

[MTESt<m>:SEGMENT<n>:ADD](#) on page 1179

Edit segments

Dialog to edit the mask segment. For each segment, you define the coordinates of the corner points. You can add and remove points and define the shape as needed.

Point	X	Y
1	-65.627 ns	116.543 mV
2	-65.627 ns	-42.089 mV
3	-25.013 ns	-42.089 mV
4	-25.013 ns	116.543 mV

Point, X, Y ← Edit segments

The table shows the horizontal and vertical positions of the corner points. You can change each value.

Remote command:

[MTESt<m>:SEGMent<n>:POINT<o>:X](#) on page 1181

[MTESt<m>:SEGMent<n>:POINT<o>:Y](#) on page 1182

[POWER<m>:SOA:MTESt<n>:SEGMent<o>:POINT<p>:X](#) on page 1260

[POWER<m>:SOA:MTESt<n>:SEGMent<o>:POINT<p>:Y](#) on page 1260

Add + ← Edit segments

Appends a new point to the segment. You cannot change the order of the points.

Remote command:

[MTESt<m>:SEGMent<n>:POINT<o>:ADD](#) on page 1180

[MTESt<m>:SEGMent<n>:POINT<o>:COUNT?](#) on page 1180

Segment name ← Edit segments

Enter a name for the selected mask segment.

Delete, Delete all

 switches to the delete mode. You can delete single segments or single points by selecting the delete icon in the table row. You can also delete all segments or points with "Delete all". To leave the delete mode, tap the blue delete icon.


Remote command:

[MTESt<m>:SEGMENT<n>:POINT<o>:REMove](#) on page 1181

[MTESt<m>:SEGMENT<n>:REMove](#) on page 1182

12.1.4 Actions on mask test results

Access: "Menu" > "Apps" > "General" tab > "Masks" > "Action" tab



The action settings define what happens when an acquisition passes the mask test successfully, or when it hits the mask. All available actions can be initiated at the same time.

Beep

Generates a beep sound.

Remote command:

[MTESt<m>:ONViolation:BEEP](#) on page 1183

[POWER<m>:SOA:MTESt<n>:ONViolation:BEEP](#) on page 1261

Stop acq

Stops the acquisition on completion or violation.

Remote command:

[MTESt<m>:ONViolation:STOP](#) on page 1183

[POWER<m>:SOA:MTESt<n>:ONViolation:STOP](#) on page 1262

Save wfm

Saves the waveform data to a file according to the folder, filename and extension settings in the "Menu" > "Save/recall" > "Save" > "Waveform" dialog.

To select the waveforms and adjust the file path, tap the settings icon .

See also [Section 13.4.2, "Saving waveforms"](#), on page 450.

Remote command:

[MTESt<m>:ONViolation:WFMSave](#) on page 1184

[POWER<m>:SOA:MTESt<n>:ONViolation:WFMSave](#) on page 1263

Screenshot

Saves a screenshot according to the settings in the "Menu" > "Save/recall" > "Save" > "Screenshot" dialog.

To adjust the screenshot settings, tap the settings icon .

See also [Section 13.8, "Screenshots"](#), on page 469.

Remote command:

[MTESt<m>:ONViolation:SCReenshot](#) on page 1183

[POWER<m>:SOA:MTESt<n>:ONViolation:SCReenshot](#) on page 1261

Trigger out pulse

Selects, if a pulse is provided to the [Trigger Out] connector on the rear panel. The trigger-out signal is used to synchronize the measurements of other instruments.

To adjust the outgoing signal, tap the settings icon .

Remote command:

[MTESt<m>:ONViolation:TRIGgerout](#) on page 1184

[POWER<m>:SOA:MTESt<n>:ONViolation:TRIGgerout](#) on page 1262

12.1.5 Working with masks

This section explains step by step how mask tests are configured. For the explanation of the individual settings, see [Section 12.1.2, "Mask test setup: general settings"](#), on page 331.

12.1.5.1 Working with masks using the toolbar

To create a mask graphically using the toolbar

1. Select the "Add mask" icon on the toolbar. If the icon is not visible, configure the toolbar as described in [Section 4.6.2, "Configuring the toolbar"](#), on page 62.



2. In the "Add mask" overlay menu, select the channel that you want to test against the mask.



3. In the overlay menu, the "Add mask" function is selected. Draw the diagonal of the rectangle on the screen.
4. Now, the "Add segment" function is selected in the overlay menu. Draw another segment on the screen.
5. If you need another mask, select "Add mask". Draw the first segment of the new mask.
6. To finish the mask definition, close the overlay menu.

The mask test is enabled by default. If the acquisition is running, the mask test starts automatically and immediately. Otherwise, start the acquisition to start the test.

To modify a mask using the toolbar

You already have created a mask and want to change its shape and add segments.


1. Select the mask segment in the diagram.

The segment is marked and the overlay menu opens. One of the points is selected by default, and its coordinates are shown.



2. In the diagram, you can change the shape of the mask segment:
 - To move the segment, tap in the segment, hold and move it.
 - To move an edge, tap and hold the edge and move it.
 - To move a point, tap and hold the point and move it.
3. The overlay menu provides more functions.
To add a point to the selected segment:
 - a) Select "Add point" in the overlay menu.
 - b) Tap outside the segment, hold and move the point to the required position.
4. To delete a segment or point:

- a) Select "Delete" in the overlay menu.



- b) To delete a point, tap its delete icon.
 c) To delete the segment, tap the "Delete" icon inside the segment.
5. To enter the exact coordinates of a point:
- a) Select the mask segment and the point in the diagram.
 b) In the overlay menu, change the X- and Y-values.
6. To change the waveform to be tested, select "Source" in the overlay menu.

12.1.5.2 Working with masks using the dialog

- Open the "Mask test" dialog: "Menu" > "Apps" > "General" tab > "Masks" > "Setup" tab.
If there is already at least one defined mask, tap its result table to open the dialog.
- Select "Delete mask" to create the first mask. To create more masks, use the icon.
- Select the "Source", the waveform to be tested.
- Select "Edit segments".
- Select the "Shape" of the new segment.
- Select "Add segment".
The new segment is listed in the dialog and shown in the diagram.
- Under "Edit segments", select the segment.
- Change the X- and Y-values as needed.
- To name the segment, select "Segment name". Enter the name.
- To add more points, use "Add +".
- To delete points:
 - Select .
 - To delete one point, select the delete icon in its table row.

- c) To delete all points, select "Delete all"
 - d) To leave the delete mode, tap the blue delete icon.
12. Select "Back" twice to finish the segment setup.
 13. In the "Setup" tab, enable the test if it is off.
 14. If the acquisition is running, the mask test starts automatically and immediately. Otherwise, start the acquisition to start the test.

12.1.5.3 Setting up a mask test

In addition to the mask definition, you can define the actions to be taken if a test has failed or completed successfully.

1. Open the "Mask test" dialog: "Menu" > "Apps" > "General" tab > "Masks".
2. Select the "Action" tab.
3. For each action, select when the action will be executed:
 - No action
 - On successful completion
 - On violation of the mask
4. For the actions "Save wfm" and "Trigger out pulse", tap the  icon and configure the settings.

12.1.5.4 Running a mask test

You can perform continuous testing with "Run / stop" or test a specified number of acquisitions with "Run single". If the test is enabled in the "Setup" tab, the test starts when the acquisition starts. The test runs until the acquisition is stopped.

12.1.5.5 Saving and loading masks

Mask definitions are remained until they are changed or deleted, or a preset is performed. If you want to keep a mask definition, you can save and reload it.

To save a mask

1. Open "Menu" > "Apps" > "General" tab > "Masks" > "Setup" tab.
2. Select "Save mask".
3. Select "Save as".
4. In the file browser, select the directory and enter the filename. The format of the mask file is always `.xml`.
5. Select "Save". If the specified file already exists, it is overwritten with the new data.

To load a mask

1. In the "Masks" > "Setup" tab, select "Load mask".
2. In the file browser, select the mask file.
3. Select "Open".

12.1.5.6 Mask testing on history waveforms

In the same way as for running acquisitions, you can set up and perform the mask testing on history waveforms.

1. Perform and finish the acquisition.
2. Define the mask, and enable the test. See [Section 12.1.5.1, "Working with masks using the toolbar"](#), on page 336 and [Section 12.1.5.2, "Working with masks using the dialog"](#), on page 338.
3. Set up the test actions. See [Section 12.1.5.3, "Setting up a mask test"](#), on page 339.
4. Select "Menu" > "Acquisition" > "History".
5. Activate "Show history".
6. Select  "Play".

12.2 Frequency response analysis (option R&S MXO5C-K36)

The frequency response analysis (FRA) option lets you perform low-frequency response analysis on your oscilloscope. It characterizes the frequency response of a variety of electronic devices, including passive filters and amplifier circuits. For switched-mode power supplies, it measures the control loop response (CLR) and power supply rejection ratio (PSRR).

The FRA option uses the oscilloscope's built-in waveform generator (option R&S MXO5C-B6) to create stimulus signals ranging from 10 mHz to 100 MHz. Measuring the ratio of the stimulus signal and the output signal of the DUT at each test frequency, the oscilloscope plots gain and phase logarithmically.

Having both time and frequency domain views allows you to monitor if the injected signal causes distortion that leads to errors in the measurement.

12.2.1 About the frequency response analysis plot

FRA plot display

The FRA plot display is divided into several sections.



Figure 12-2: FRA plot display

- 1 = Toolbar
- 2 = Progress bar
- 3 = FRA result table
- 4 = Marker value table
- 5 = Margin value table
- 6 = Exit app button
- 7 = Inactive waveforms
- 8 = Active waveforms and plots
- 9 = FRA controls
- 10 = FRA plot diagram, gain: blue color; phase: red color; amplitude: green color; reference: white color
- 11 = Channel diagram

Progress bar

Displays the current status of the measurement: how many points have already been displayed and the total set number of points.

FRA plot diagram

The FRA plot diagram has the frequency presented on the x-axis. The gain (blue color waveform in the image) and phase (red color waveform) scales are on the y-axis. The

gain plot represents the ratio between input and output. The phase plot shows the phase shift between input and output.

For better visibility and distinguishability, FRA waveforms and their reference waveforms have their own color category in "Settings" > "Appearance" > "Colors" > "Category". You can change the color assignment and assign another color or a color table to FRA waveforms. See [Section 5.3.1, "Colors"](#), on page 95 for details.

FRA plot result table

In the FRA plot result table, all sample points are displayed with the respective value for the frequency, gain, phase and amplitude. If you select a sample in the table, the respective points in the FRA plot are highlighted by a white vertical helper line on the gain and the phase curve.



Marker value table

There are two markers available for the FRA plot. They are highlighted on the FRA plot diagram by a white line and the respective marker number 1 or 2. You can move the markers as needed.

In the marker table you can see the frequency, phase and gain values for both of them.

Remote commands:

- [FRANalysis:MARKer<m>:FREQuency](#) on page 1202
- [FRANalysis:MARKer<m>:GAIN?](#) on page 1202
- [FRANalysis:MARKer<m>:PHASe?](#) on page 1202

Margin value table

The margin value displays the gain and the phase margin frequency and value of the system. Higher margin values are an indicator for higher stability of the system.

Remote commands:

- `FRANalysis:MARGin:STATe` on page 1200
- `FRANalysis:MARGin:GAIN:FREQuency?` on page 1201
- `FRANalysis:MARGin:GAIN:VALue?` on page 1201
- `FRANalysis:MARGin:PHASe:FREQuency?` on page 1201
- `FRANalysis:MARGin:PHASe:VALue?` on page 1201

Vertical position and size of the waveforms

To set the position and the vertical scaling of the gain, phase or amplitude waveforms, select the waveform and use the vertical [Scale] and [Position] (upper knob) knobs.

The remote commands for setting the position and scales of the are described in [Section 18.17.2.4, "Frequency response analysis diagram settings"](#), on page 1196.

12.2.2 Using a frequency response analysis

Connecting the test setup




To avoid measurement uncertainties, make sure that the cables connecting the input and the output of your DUT to the oscilloscope are of similar length.

Starting the FRA


1. Press the  [Apps] key.
2. In the "General" tab, tap "FRA".

The FRA window opens. Only the settings relevant for the FRA setup are visible in the "Menu". The menu includes access to the following dialogs: "Setup", "Vertical", "Horizontal", "Settings", "Save/recall".



Closing the FRA

- ▶ Tap the "Exit FRA" button at the bottom-right corner of the display.



12.2.3 Dependencies of the measurement setup

When performing the FRA measurement, consider the following dependencies on parameters from the "Vertical" menu.


- **Coupling:**
 - For frequencies smaller than 10 Hz, the "Coupling" on page 135 is set to DC.
 - For frequencies higher than 10Hz, you can select a Coupling manually. The default set value is AC.
- The bandwidth value is changed to a higher value, if the selected bandwidth is smaller than double the stop frequency.
- If the bandwidth of the connected probe is lower than the "Stop" frequency, a warning is shown.

12.2.4 Settings for frequency response analysis

The following sections describe the settings that you can define for the frequency response analysis.

12.2.4.1 Setup

Access: [Apps] > "General" > "FRA" > "Setup".



The "Setup" tab provides the analysis settings and access to the generator setup and advanced settings.

Input

Sets the channel for the input signal of the DUT.

Remote command:

[FRANalysis:INPut\[:SOURce\]](#) on page 1190

Output

Sets the channel for the output signal of the DUT.

Remote command:

[FRANalysis:OUTPut\[:SOURce\]](#) on page 1192

Start, Stop

Set the start and stop frequency of the sweep.

Remote command:

[FRANalysis:FREQuency:STARt](#) on page 1188

[FRANalysis:FREQuency:STOP](#) on page 1189

Frequency mode

Selects between single frequency and sweep analysis.

"Sweep" Set the start and stop frequency, the points measurement mode and the number of points.

"Single" Set the signal frequency in "Start", and the number of points. The points define the scale of the horizontal axis.

Remote command:

[FRANalysis:FREQuency:MODE](#) on page 1188

Generator

See [Section 12.2.4.2, "Generator settings"](#), on page 346.

Points

Selects if the number of points is measured as total or per decade and sets the number of points.

Remote command:

[FRANalysis:POINTs:TOTal](#) on page 1193

[FRANalysis:POINTs:MODE](#) on page 1192

[FRANalysis:POINTs:LOGarithmic](#) on page 1192

Run

Starts the frequency response analysis.

Remote command:

[FRANalysis:STATe](#) on page 1187

Repeat


Repeats the measurement, using the same parameters.

Remote command:

[FRANalysis:REPeat](#) on page 1193

12.2.4.2 Generator settings

Access: [Apps] > "General" > "FRA" > "Setup" > "Generator".



The dialog provides the settings for the generator.

Generator

Selects the built-in generator to start a frequency sweep for a defined frequency range.

Remote command:

[FRANalysis:GENerator\[:CHANnel\]](#) on page 1189

Amplitude mode

Selects, if the amplitude is a constant value ("Amplitude") or is defined as an amplitude profile.

Remote command:

[FRANalysis:AMPLitude:MODE](#) on page 1188

Amplitude

Sets a fixed amplitude for the frequency response analysis.

Remote command:

[FRANalysis:GENerator:AMPLitude](#) on page 1189

Amplitude profile

Opens a dialog to set the amplitude profile. See [Section 12.2.4.3, "Amplitude profile"](#), on page 348.

You can then define different amplitudes for different frequencies. The amplitude profile is useful when testing sensitive circuits, where the amplitude gets too high. In this case, distortion can occur.

If this function is enabled, a green-colored diagram of the amplitudes for the different frequencies can be displayed on the screen.

Remote command:

[FRANalysis:AMPLitude:MODE](#) on page 1188

[FRANalysis:AMPLitude:ENABLE](#) on page 1198

User load


Selects the generator voltage display for 50Ω or high impedance load.

Remote command:

[FRANalysis:GENerator:LOAD](#) on page 1189

12.2.4.3 Amplitude profile

Access: [Apps] > "General" > "FRA" > "Setup" > "Amplitude profile".



Opens a dialog to set the amplitude profile. You can then define different amplitudes for different frequency, and also the number of points (steps) in the profile. The amplitude profile is useful when testing sensitive circuits, where the amplitude gets too high. In this case distortion can occur.



Step start freq, Amplitude

Set the frequency and amplitude values for the selected step.

Remote command:

[FRANalysis:AMPLitude:PROFile:POINt<m>:AMPLitude](#) on page 1195

[FRANalysis:AMPLitude:PROFile:POINt<m>:FREQuency](#) on page 1195

Voltage change

Selects if the voltage change is done as a single step or as a ramp.

Remote command:

[FRANalysis:AMPLitude:PROFile:MODE](#) on page 1195

Add

Adds a new step to the amplitude profile.

Remote command:

[FRANalysis:AMPLitude:PROFile:APOint](#) on page 1194

[FRANalysis:AMPLitude:PROFile:COUNt](#) on page 1194

Sort


Sorts the steps in the amplitude table by frequency, starting with the lowest frequency.

Remote command:

[FRANalysis:AMPLitude:PROFile:SORT](#) on page 1194

Delete

If enabled, a delete icon appears next to each step in the amplitude profile table. Tap the icon to delete the step.




Remote command:

[FRANalysis:AMPLitude:PROFile:POINt<m>:REMOve](#) on page 1194

12.2.4.4 Advanced

Access: [Apps] > "General" > "FRA" > "Setup" > "Advanced".



Maximum phase

Sets the upper boundary of the vertical phase window.

The lower boundary is given by "Maximum phase" - 360°.

By default, the "Maximum phase" is set to 180° for a phase window ranging from -180° to 180° accordingly.

Remote command:

[FRANalysis:PHASe:MAXimum](#) on page 1193

Meas. delay mode, Delay time, Delay period

Selects the type of delay that the system waits before measuring the next point of the plot. Delay is helpful in systems that need more time to adapt to the new frequency, for example if filters with significant time group delays are present. You can select a time delay and set the "Delay time", or a period delay and set the "Delay period".

Remote command:

[FRANalysis:MEASurement:DELAy:STATe](#) on page 1190

[FRANalysis:MEASurement:DELAy:MODE](#) on page 1190

[FRANalysis:MEASurement:DELAy\[:TIME\]](#) on page 1191

[FRANalysis:MEASurement:DELAy:PERiod\[:NUMBer\]](#) on page 1191

RBW

Sets the resolution bandwidth, which determines the number of measurements that are used for creating the plot.

"High (fast)" A high RBW value is useful for obtaining a general understanding of a system's behavior over a wide frequency range. The accuracy of the measurement is not as good, but the measurement is completed fast.

Frequency response analysis (option R&S MXO5C-K36)

- "Medium" A medium RBW value is a compromise between the measurement time and measurement accuracy.
- "Low (slow)" A low RBW value allows for a more detailed analysis of the system. Since more data needs to be collected, the measurement time can increase significantly.

Remote command:

[FRANalysis:MEASurement:RBW](#) on page 1192

Auto scale

If enabled, the vertical scaling of input and output channel is done automatically for every new measurement frequency point.

That guarantees a non-disturbed signal and a maximum of measurement resolution.

For [Coupling](#) = "DC", the channel offset is also changed to compensate the signal offset.

The function is disabled if calibration is active.

Remote command:

[FRANalysis:AUToscale](#) on page 1188

HD mode

Disables the HD mode, which is active by default. In particular, disable the HD mode if you analyze switching peaks.


The frequency in HD mode must be at least 3 times the current frequency. The bandwidth filter of the channel is adjusted automatically to the generator frequency.

Remote command:

[FRANalysis:HDEFinition\[:ENABLE\]](#) on page 1190

12.2.4.5 Display

Access: [Apps] > "General" > "FRA" > "Display".



In this dialog, you can select which elements are displayed in the FRA diagram.

Display points

Enables the display of the measurement points for the frequency response analysis.

Remote command:

[FRANalysis:MEASurement:POINT\[:DISPlay\]](#) on page 1191

Result table

Enables the display of the result table for the FRA.

Remote command:

[FRANalysis:RESult:STATe](#) on page 1200

Markers

Enables the display of the marker table for the FRA.

Remote command:

[FRANalysis:MARKer<m>:STATe](#) on page 1201

Margin

Enables the display of the margin table for the FRA.

Remote command:

[FRANalysis:MARGIN:STATe](#) on page 1200

12.2.4.6 Scale

Access: [Apps] > "General" > "FRA" > "Scale".




Figure 12-3: Scale dialog for Mode = Gain/Phase

Vertical scale

Sets the scale of the y-axis in the function diagram.

Remote command:

[FRANalysis:PHASe:SCALE](#) on page 1197

[FRANalysis:GAIN:SCALE](#) on page 1198

Vertical offset

Sets a voltage offset to adjust the vertical position on the screen.

Remote command:


[FRANalysis:PHASe:OFFSet](#) on page 1197

[FRANalysis:GAIN:OFFSet](#) on page 1197

12.2.4.7 Calibration

Calibration is used to compensate the electrical parameter of probes, cables, connectors or fixtures.

Access: [Apps] > "General" > "FRA" > "Calibration".



Test setup considerations

[Example of a calibration test setup](#) shows an example of a test setup, where the input probe is connected to [C1] and the output probe is connected to [C2]. The input is also connected to the ARB generator.




Figure 12-4: Example of a calibration test setup

Input = [C1], [Gen1]

Output = [C2]

Consider also the following:

- Calibration for FRA is only possible with probes connected to the input and output channels.
- For best FRA calibration results, shorten the DUT and place the probe tips as near as possible to each other.
- If there is a fixture for the DUT, it should be part of the calibration setup.
- If the DUT needs a termination, it is to be conducted with an external termination direct on DUT output / input.

Calibration state

Once the calibration is started, a label is shown in the toolbar.



The calibration label displays the status of the calibration. The following states are available:

- "Valid": calibration values are used
- "Invalid": device settings changed
- "Running": a calibration cycle is running
- "None": not performed or no data

Settings influencing calibration

Calibration is only valid for the settings that are active during its execution. If one of the following settings is changed, the calibration becomes "Invalid":

- "Input" and "Output" channel
- "Channel coupling" and "Bandwidth"
- "Channel scaling"

- "Generator"
- "User load"
- "Amplitude mode"
- "Amplitude profile"
- "Amplitude profile" > "Voltage change"
- "Start" frequency
- "Stop" frequency
- "Points" mode and total points
- "Meas. delay mode"
- "Delay time"
- "RBW"

If calibration is active, "Auto scale" is disabled.

To perform a calibration

1. Enable "Use calibration data".
2. Set the FRA settings close to the test parameters.
3. Select the [Input](#) and [Output](#) source.
4. Ensure that the probe settings are correct.

The following settings are available for the calibration:

Use calibration data

If enabled, the user calibration data is used for the frequency response analysis.

Remote command:

[FRANalysis:CALibration:STAt](#) on page 1196

Save/recall

Opens the "Save/recall" dialog. You can save the instrument setting in a saveset, and load existing savesets. For details, see [Section 13.3, "General and measurement settings: savesets"](#), on page 441.

The saveset includes the calibration data. If you load a saveset, the current calibration values are overwritten.

Restore calibration settings

Restores the FRA settings to the values that were selected during the calibration process. Restore allows you to perform further measurements with a valid calibration state. See also ["Settings influencing calibration"](#) on page 354.

To keep and restore calibration settings in remote control, set up and calibrate the frequency analysis, and save the instrument settings in a saveset. When you load this saveset later, the calibration data is restored together with the instrument settings.

Start calibration

Starts the calibration. The button is only enabled if there is a valid test setup.

The state of the calibration process is displayed in the calibration label in the toolbar.

After a calibration is performed successfully, the calibration values are saved automatically.


Remote command:

[FRANalysis:CALibration:CALibration](#) on page 1196

[FRANalysis:CALibration:RESult?](#) on page 1196

12.2.5 Saving results of frequency response analysis

Access: [Apps] > "General" > "FRA" > "Setup" > "Save/recall" > "Results".



FRA results

In this dialog, you can select which result values you want to include in your FRA export results file.

The following options are available:

- "FRA results": includes the frequency, gain, phase and amplitude
- "Marker results": includes the marker frequency and gain

- "Margin results": includes the margin gain and phase

Remote command:

`EXPort:RESult:SElect:FRA:MARGIn` on page 1208

`EXPort:RESult:SElect:FRA:MARKer` on page 1208

`EXPort:RESult:SElect:FRA:RESult` on page 1208

12.2.6 Reference waveforms of FRA curves

To compare the results of frequency resonance analysis and analyze differences between them, you can use up to 4 specific reference waveforms. These references can be created from gain and phase curves, and from other references.. The type of the source waveform is included in the reference waveform data.


You can save an unlimited number of reference waveforms and load them for further use. Markers are also set on these reference waveforms.

The display of a reference waveform is independent from the display of the source waveform; you can move, stretch and compress the curve vertically. A loaded reference waveform is restored when you leave the FRA mode and enter it again with no preset inbetween. Reference waveforms are aligned horizontally to the actual start and stop position in the waveform diagram.

When a FRA reference waveform is selected, you can change scale and position using the knobs on the front panel.

12.2.6.1 Reference waveform setup

Access: perform a frequency response analysis and display resulting waveforms > select the "+ Ref" signal activator > "Setup" > select reference waveform



In the "Setup" tab, you select the source of the reference waveform and create the reference.

Display

Enables the display of the reference waveform in the diagram. Before you can display it, create the reference waveform.

Remote command:

[FRANalysis:REFCurve<rc>:ENABLE](#) on page 1206

Source

Selects the source waveform of the reference from the existing frequency response waveforms, e.g. gain, phase or an other reference.

Remote command:

[FRANalysis:REFCurve<rc>:SOURCE](#) on page 1206

Create/Update

Copies the selected source waveform with all its settings to the memory of the reference waveform. If there is a previously defined reference waveform in this memory, it is updated by the current source waveform.

A progress bar informs you about the process.

Remote command:

[FRANalysis:REFCurve<rc>:UPDate](#) on page 1207

Clear

Deletes the selected reference waveform. It disappears from the display, and its memory is deleted.

Remote command:

[FRANalysis:REFCurve<rc>:CLEar](#) on page 1204

File extension

Shows the file format. Currently, only CSV files are supported.

Save as

Opens a file explorer where you select the folder, enter the filename and save the file. The complete reference waveform is stored in a CSV file and can be reloaded later.

A progress bar informs you about the process.

Remote command:

[FRANalysis:REFCurve<rc>:NAME](#) on page 1204

[FRANalysis:REFCurve<rc>:SAVE](#) on page 1205

Open


Opens a file selection dialog box and loads the selected reference file.

Remote command:

[FRANalysis:REFCurve<rc>:OPEN](#) on page 1205

12.2.6.2 Reference waveform properties

Access: perform a frequency response analysis and display resulting waveforms > select the "+ Ref" signal activator > "Properties" tab > select reference waveform




A FRA reference waveform can be vertically scaled and positioned in the diagram. The "Properties" tab shows the original settings of the reference waveform, which are stored together with the waveform data.

The following settings are displayed:

- Type of the source waveform
- Vertical scale and offset that are defined in the "Scale" tab ([Section 12.2.4.6, "Scale"](#), on page 352)

12.2.6.3 Vertical settings for reference waveforms

Access: perform a frequency response analysis and display resulting waveforms > select the "+ Ref" signal activator > "Vertical" tab > select reference waveform



Vertical mode

Selects the type of vertical settings:

"Coupled to source" Vertical position and scale of the source are used.

"Independent" Scaling and position can be set specific to the reference waveform.

Remote command:

[FRANalysis:REFCurve<rc>:VMODE](#) on page 1207

Set to original

Available, if "Vertical mode" = "Independent".

Restores the original vertical settings of the reference waveform.

Remote command:

[FRANalysis:REFCurve<rc>:TOORiginal](#) on page 1206

Vertical scale

Available, if "Vertical mode" = "Independent".

Sets the vertical scale, which defines the displayed amplitude of the selected waveform.

The unit of the reference is the same as the unit of the source waveform.

Remote command:

`FRANalysis:REFCurve<rc>:SCALE` on page 1206

Vertical offset

The vertical offset moves the reference waveform vertically. Enter a value with the unit of the waveform.

Remote command:

`FRANalysis:REFCurve<rc>:OFFSet` on page 1205

12.3 Power analysis (option R&S MXO5C-K31)

With the MXO 5C and option R&S MXO5C-K31, you can perform power analysis measurements.



For best measurement results, we recommended setting channel **Bandwidth** = 20 MHz.

If using the HD mode, we recommended setting **Bandwidth** = 100 MHz.

12.3.1 Power analysis initial settings

In the main "Power analysis" dialog, you select the required power measurements, align the channels and set the offset compensation to get correct measurements.

12.3.1.1 Select power measurements


In the "Analysis" tab, you select the power analysis measurements.

You can add up to 6 power analysis measurements, including several instances of the same measurement.

From here, you can access the settings for the enabled power analysis measurements.


To add a new power measurement

1. Select "Menu" > "Apps" > "General" tab > "Power".
2. In the "Analysis" tab, select "+ Add".



3. Select a power measurement on the list to enable it.
4. Select "+ Add" to add the selected measurements.


All selected measurements are enabled.



To delete a measurement

1. Select the "Menu" > "Apps" > "General" tab > "Power", to open the power measurement dialog.
2. In the "Analysis" tab, select

A delete icon appears in the selection button of each measurement.



3. Select the power measurement that you want to delete. Alternatively, select "Delete All" to delete all measurements.

+ Add

Opens a dialog to select the power analysis measurements. See ["To add a new power measurement"](#) on page 361.

Remote command:

`POWer<m>[:ENABle]` on page 1210

`POWer<m>:TYPE` on page 1210


12.3.1.2 Deskew

In the dialog box you can perform a deskew of your current and voltage probes.

Required equipment:

- R&S RT-ZF20 power deskew fixture
- Rohde & Schwarz voltage probe
- Rohde & Schwarz current probe

Deskew settings



Skew channel

Sets user-defined skew settings for the channel connected to the current probe. Alternatively, you can start an "Auto deskew".

Auto deskew

Starts an auto deskew. It is used to determine the trigger and scaling properties.

For an auto deskew, only Rohde & Schwarz probes are supported.

Make sure that the probes are configured correctly before you start the deskewing.

After the deskew, the result values are written in the "Skew" value of the corresponding channel.


If there are more than two active channels, you can perform automatic deskew step by step and exchange the probes connected fixture between the steps.

Remote command:

`POWer<m>:ASkew[:EXECute]` on page 1211

12.3.1.3 Offset compensation

The offset compensation adjustments are applied to all 3-phase power analysis measurements.



Channel

Select the channel for the offset compensation.

Remote command:

[PROBe<ch>:SETup:OFFSet:ZADJust](#) on page 994

AutoZero, Use AutoZero

Voltage probes can have a zero error. The zero error is the voltage appearing at the probe output when nothing is connected to the probe. If a zero error occurs, it results in an external offset and the waveform is not displayed around 0 V.

To correct the zero error of voltage probes, short the signal pin and the ground pin together. Then select "AutoZero". While the alignment is running, the instrument switches to DC coupling to display the waveform correctly.

To correct the zero error, enable "Use AutoZero".

If a current probe is connected, the function demagnetizes the probe's sensor head and sets the waveform to zero position.

Remote command:

[PROBe<ch>:SETup:OFFSet:AZERo](#) on page 981

[PROBe<ch>:SETup:OFFSet:USEautozero](#) on page 981

12.3.2 Power quality

In an electric circuit power is a measure for the rate of flow of energy at a certain point of the circuit. The active power of a circuit is the portion of energy that is transferred in one direction over a complete cycle of the AC waveform. The active power is the energy that can be used for work. In AC circuits, however, inductive and capacitive elements can store energy temporarily. This portion of the power flow known as reactive power is then returned to the source without doing any work.

The power quality analysis measurements include the active power, the reactive power, the apparent power and the power factor. The crest factors and the phase angle between the current and voltage are also measured. These properties describe the

power transfer in the system and allow you to characterize the power quality of the system.


Required probes:

- Differential voltage probe
- Current probe

12.3.2.1 Configuring power quality

For details of the configuration settings, see [Section 12.3.1.1, "Select power measurements"](#), on page 361.

1. Add a new power quality measurement as described in ["To add a new power measurement"](#) on page 361.
2. Connect the differential voltage probe and the current probe to the oscilloscope.
3. Deskew the probes as described in [Section 12.3.1.2, "Deskew"](#), on page 363.
4. Connect the probes to the DUT:




- a) Connect the positive (+) signal socket of the differential voltage probe to the line of the AC input.
 - b) Connect the negative (-) signal socket of the differential voltage probe to the neutral of the AC input.
 - c) Connect the current probe to the line of the AC input.
5. In the "Analysis" tab, tap the "Quality" measurement.
The "Quality" setup dialog opens.
 6. Select the correct channels for the "Voltage" and the "Current" probes.
 7. Set the "Fund. frequency" according to your signal.

8. If necessary, enable "Statistics".

On the screen, you can see the measurement waveforms of the current, the voltage and the power. Also, the result table with numeric measurement results is shown. For details, see [Section 12.3.2.7, "Power quality results"](#), on page 370.

12.3.2.2 Power quality settings

Access: "Menu" > "Apps" > "Power" > "+ Add" > "Quality" > select "Quality" > "Setup".



In the "Setup" tab, you configure the power quality measurement: select the sources, the fundamental frequency, and enable statistics.

Voltage

Selects the voltage source waveform. Analog channels and math waveforms can be used.

Remote command:

[POWER<m>:QUALity:SOURce\[:VOLTage\]](#) on page 1213

Current

Selects the current source waveform. Analog channels and math waveforms can be used.

Remote command:

[POWER<m>:QUALity:SOURce:CURREnt](#) on page 1212

Fund. frequency

Selects the input frequency of the source signal.

Remote command:

`POWER<m>:QUALity:FREQuency[:VALue]` on page 1213

`POWER<m>:QUALity:FREQuency:USER` on page 1213

Cycle source

Selects the source of the period measurement. This period is the reference for related measurements and calculations.

Remote command:

`POWER<m>:QUALity:SOURce:CYCLe` on page 1213

Statistics

Activates or deactivates the statistical evaluation for the selected power measurement. If statistics are enabled, the following results are calculated:

Label	Description
Current	Current value
Max	Maximum value
Min	Minimum value
Mean	Average
RMS	Root mean square
σ (S-dev)	Standard deviation
Event count	Number of measured events
Wave count	Number of waveforms (acquisitions)

Remote command:

`POWER<m>:QUALity:STATistics[:ENABle]` on page 1211

`POWER<m>:QUALity:STATistics:WFMCounT?` on page 1212

`POWER<m>:SWITChing:STATistics:ENABle` on page 1211

`POWER<m>:SWITChing:STATistics:WFMCounT?` on page 1212

`POWER<m>:EFFiciency:STATistics[:ENABle]` on page 1211

`POWER<m>:EFFiciency:STATistics:WFMCounT?` on page 1212

Clear results

Resets the statistical results for the respective power measurements, and starts a new statistical evaluation if the acquisition is running.

Remote command:

`POWER<m>:QUALity:STATistics:RESet` on page 1211

`POWER<m>:SWITChing:STATistics:RESet` on page 1211

`POWER<m>:EFFiciency:STATistics:RESet` on page 1211

12.3.2.3 Power quality display

Access: "Menu" > "Apps" > "Power" > "+ Add" > "Quality" > select "Quality" > "Display".

In this dialog, you select the power quality analysis measurements that you want to display. For more details on the different measurements, see [Section 12.3.2.7, "Power quality results"](#), on page 370.

Setup	Check measurements to be displayed	
Reference level	Voltage RMS ☒	Current RMS ☒
Gate	Voltage peak ☒	Current peak ☒
Display	Voltage crest ☒	Current crest ☒
Power waveform	Voltage freq. ☒	Apparent power ☒
	Active power ☒	Reactive power ☒
	Phase ☒	Power factor ☒

Remote commands

- [POWER<m>:QUALity:DISPlay:CURRent:CREStfactor](#) on page 1214
- [POWER<m>:QUALity:DISPlay:CURRent:PEAK](#) on page 1214
- [POWER<m>:QUALity:DISPlay:CURRent:RMS](#) on page 1215
- [POWER<m>:QUALity:DISPlay:POWer:ACTive](#) on page 1215
- [POWER<m>:QUALity:DISPlay:POWer:APParent](#) on page 1215
- [POWER<m>:QUALity:DISPlay:POWer:PFACTOR](#) on page 1215
- [POWER<m>:QUALity:DISPlay:POWer:PHASe](#) on page 1216
- [POWER<m>:QUALity:DISPlay:POWer:REACTive](#) on page 1216
- [POWER<m>:QUALity:DISPlay:VOLTage:CREStfactor](#) on page 1216
- [POWER<m>:QUALity:DISPlay:VOLTage:FREQuency](#) on page 1216
- [POWER<m>:QUALity:DISPlay:VOLTage:PEAK](#) on page 1217
- [POWER<m>:QUALity:DISPlay:VOLTage:RMS](#) on page 1217

12.3.2.4 Reference level

See [Section 12.3.8.1, "Reference level"](#), on page 402.

12.3.2.5 Gate

See [Section 12.3.8.2, "Gate settings for power measurements"](#), on page 405.

12.3.2.6 Power waveform

For a description of the power waveform scaling, see [Section 12.3.8.3, "Power waveform"](#), on page 406.

12.3.2.7 Power quality results



The results of power quality measurements are provided in two ways:

- The diagram shows the graphical presentation of:
 - The voltage waveform
 - The current waveform
 - The power waveform, which is the product of the current and voltage waveforms.
- The result table displays the numeric measurement results:

Voltage and current results

The voltage and current results are defined as follows:

Result	Description
Current RMS, voltage RMS	Square root of the mean of the square of the current or voltage averaged over N cycles
Voltage frequency	Frequency of the signal
Current cycle crest factor, voltage cycle crest factor	Peak value / RMS value

Power results

The power in a system is described by several physical quantities:

Result	Unit	Formula	Description
Apparent power, S	VA	$ S = V_{RMS} \cdot I_{RMS}$ (averaged over N cycles)	S is the magnitude of the vector sum of active and reactive power (the complex power S).
Reactive power, Q	VAR (Volt-Ampere reactive)	$Q = S \sin \varphi$	Power flow that is temporally stored in a system because of the inductive and capacitive elements.
Power factor, P_{Factor}	-	$P_{Factor} = P / S $	Measure of the system efficiency. The value varies between -1 and 1.
Active power, P	W	$P = V_{INSTANTENEOUS} \cdot I_{INSTANTENEOUS}$ (averaged over N cycles)	Energy of the system that can be used to do work.
Phase, φ	°	$\varphi = \arccos(P_{Factor})$	Phase angle between the current and the voltage sine waves.

Remote commands: ["Power quality results"](#) on page 1217.

12.3.3 Power harmonics

Current harmonics appear in an electric power system due to nonlinear electric loads. The harmonics can be ejected back into the AC line and disturb other equipment on the grid. To avoid this disturbance, there are often standards of compliance that consumer or industry end-products must meet.

The "Harmonics" analysis tests the devices according to the precompliance standards EN 61000-3-2, MIL-STD-1399 and RTCA DO-160.

Required probes:


- Differential voltage probe
- Current probe

12.3.3.1 Configuring power harmonics

For details of the configuration settings, see [Section 12.3.3.2, "Power harmonic settings"](#), on page 372.

1. Add a new power quality measurement as described in [Section 12.3.1.1, "Select power measurements"](#), on page 361.
2. Connect the differential voltage probe and the current probe to the oscilloscope.
3. Deskew the probes as described in [Section 12.3.1.2, "Deskew"](#), on page 363.

4. Connect the probes to the DUT:



- Connect the positive (+) signal socket of the differential voltage probe to the line of the AC input.
 - Connect the negative (-) signal socket of the differential voltage probe to the neutral of the AC input.
 - Connect the current probe to the line of the AC input.
- In the "Analysis" tab, tap the "Harmonics" measurement.
The "Harmonics" setup dialog opens.
 - Select the correct channels for the "Voltage" and the "Current" probes.
 - Select the "Standard".
 - Select the "Fund. frequency" according to your signal.

On the screen, you can see the measurement of the current, the voltage and the power. Also there is a table giving information about important measurement parameters. For details, see [Section 12.3.3.6, "Power harmonic results"](#), on page 377.

12.3.3.2 Power harmonic settings

In this tab, you configure the current harmonic measurement parameters and display settings.

PA2 harmonics			
Setup	Voltage	Channel 1	Current
Reference level	Standard	EN 61000 -3-2 A	Revision
Bar graph			Revision 2019
Power waveform	Fund. frequency	Automatic	

Figure 12-5: Power harmonic setup for EN 61000-3-2 A / EN 61000-3-2 B

PA2 harmonics			
Setup	Voltage	Channel 1	Current
Reference level	Standard	EN 61000 -3-2 C	Revision
Bar graph			Revision 2019
Power waveform	Fund. frequency	Automatic	
	Power factor	User	Power factor
			100 %
			Phase & current parameters

Figure 12-6: Power harmonic setup for EN 61000-3-2 C




Figure 12-7: Power harmonic setup for EN 61000-3-2 D




Figure 12-8: Power harmonic setup for MIL-STD-1399/ RTCA DO-160

Voltage

Selects the voltage source waveform. Analog channels and math waveforms can be used.

Remote command:

[POWER<m>:HARMonics:SOURce\[:VOLtage\]](#) on page 1225

Current

Selects the current source waveform. Analog channels and math waveforms can be used.

Remote command:

[POWER<m>:HARMonics:SOURce:CURRent](#) on page 1225

Standard

Select the standard in use.

For EN 61000-3-2 you can also select which "Revision" of the standard is used, "Revision 2011" or "Revision 2019".

Table 12-1: Current harmonic precompliance standards

Standard	Application
EN 61000-3-2 Class A	Balanced 3-phase equipment, household appliances (excluding equipment identified as class D), tools (excluding portable tools), dimmers for incandescent lamps, audio equipment
EN 61000-3-2 Class B	Portable tools, not professional arc welding equipment
EN 61000-3-2 Class C ¹⁾	Lighting equipment
EN 61000-3-2 Class D	PC, PC monitors, radio, or TV receivers with an input power less than or equal to 600W
MIL-STD-1399	Military shipboard user equipment
RTCA DO-160	Environmental tests of avionics hardware
¹⁾ The EN 61000-3-2 defines different limits for EN 61000-3-2 Class C equipment with an input power smaller or equal than 25W either. The limits that are implemented in the MXO 5C firmware comply with the limits of table 3 (column two) of the EN 61000-3-2 standard.	

Remote command:

`POWer<m>:HARMonics:STANdard` on page 1226

`POWer<m>:HARMonics:REVision` on page 1226

Fund. frequency

Selects the frequency of the input signal. The available frequencies depend on the selected [Standard](#).

Remote command:

`POWer<m>:HARMonics:FREQuency:EN` on page 1226

`POWer<m>:HARMonics:FREQuency:MIL` on page 1227

`POWer<m>:HARMonics:FREQuency:RTCA` on page 1227

Power factor

Available only for "Standard" = EN 61000-3-2 Class C.

Selects if the power factor is defined automatically, or a user-defined value ("Power factor") is used.

Remote command:

`POWer<m>:HARMonics:PFACTOR[:MODE]` on page 1230

`POWer<m>:HARMonics:PFACTOR:USER` on page 1229

Phase & current parameters

Shows a graphical explanation of the relative phase angle and current parameters for "Standard" = EN 61000-3-2 Class C.

Real power, Power

Available only for "Standard" = EN 61000-3-2 Class D.

Selects if the real power is defined automatically, or a user-defined value ("Power") is used.

Remote command:

`POWER<m>:HARMonics:RPOWER[:MODE]` on page 1228


`POWER<m>:HARMonics:RPOWER:USER` on page 1229

12.3.3.3 Reference level

See [Section 12.3.8.1, "Reference level"](#), on page 402.

12.3.3.4 Bar graph

In this tab you can configure the bar graph display.



State

Shows the bar graph in the diagram.

Scale type

Selects a logarithmic or linear scale for the display for the harmonics bar graph.

Remote command:

`POWER<m>:HARMonics:DISPlay:BARGraph:VERTical:SCALE:TYPE`
on page 1228

Displ. harmonics

Selects which harmonics are displayed in the bar graph: all, odd even or depending on the standard definition.

Remote command:

`POWER<m>:HARMonics:DISPlay:HARMonics[:DISPlay]` on page 1227

Start harmonic, Max harmonic

Set the first and last harmonic to be shown in the bar graph.

Remote command:

`POWER<m>:HARMonics:DISPlay:HARMonics:START[:VALue]` on page 1228


`POWER<m>:HARMonics:DISPlay:HARMonics:STOP[:VALue]` on page 1228

12.3.3.5 Power waveform

A power waveform is available if "Standard" is set to EN 61000-3-2 Class C or EN 61000-3-2 Class D.

For a description of the power waveform scaling, see [Section 12.3.8.3, "Power waveform"](#), on page 406.

12.3.3.6 Power harmonic results



The results of the harmonic measurements are provided in two ways:

- The diagram shows the graphical presentation of the voltage waveform, the current waveform and the power waveform.
- The results are a bar chart and a table with the numerical measurement results. The number of displayed harmonics depends on the standard definition. When you tap on a harmonic in the bar chart, the corresponding row in the result table is highlighted.

The current harmonic results displayed in the result table are defined as follows:

Result table	Bar chart match	Description
THD RMS	-	Total harmonic distortion relative to the RMS amplitude
THD fundamental	-	Total harmonic distortion relative to the fundamental
Harmonic index	Value of the x-axis	The harmonic order
Frequency	-	The frequency value of the signal

Result table	Bar chart match	Description
Magnitude (%)	Value of the y-axis	The present value of the current harmonic
Magnitude (RMS)		The measured RMS value of the magnitude
Limit	Dark orange line	The maxim allowed value according to the selected standard
Margin		Sets the upper limit for the display of the Y scale.
Status	Bar for magnitude below limit has the color of the channel (pass) Bar for magnitude outside limit is orange (fail)	Displays, if the harmonics is within the defined limit (pass) or not (fail).


12.3.4 Switching loss

The switching loss analysis measures the power and energy losses of a switching device. The losses occur during the switching phases and the conduction phase of the switching transistor.

Required probes:

- Differential voltage probe
- Current probe

Phases of the switching cycle




Phase	Definition Points	Description
Turn on	The area between "t ₁ " and "t ₂ "	The time after switching on the device, during which the current rises until it reaches the saturation current level.
Conduction	The area between "t ₂ " and "t ₃ "	The time during which the voltage is at the transistors saturated minimum and the current flows.

Phase	Definition Points	Description
Turn off	The area between " t_3 " and " t_4 "	The time during which after a short delay the voltage rises until it reaches its final value.
Non conduction	The area between " t_4 " and " t_5 "	The time when the current does not flow. The losses during this period should be theoretically zero.

12.3.4.1 Configuring switching loss measurements

For details of the configuration settings, see [Section 12.3.4.2, "Switching loss setup"](#), on page 380.

1. Add a switching loss measurement as described in [Section 12.3.1.1, "Select power measurements"](#), on page 361.
2. Connect the differential voltage probe and the current probe to the oscilloscope.
3. Deskew the probes as described in [Section 12.3.1.2, "Deskew"](#), on page 363.
4. Connect the probes to the DUT:




- a) Connect the positive (+) signal socket of the differential voltage probe to the drain of the transistor.
 - b) Connect the negative (-) signal socket of the differential voltage probe to the source of the transistor.
 - c) Connect the current probe to the source of the transistor.
5. Measure the time points of the switching cycle, for example, using cursor measurements.
 6. In the signal bar, tap twice the signal icon of the switching loss power measurement to open its settings dialog.
 7. Select the correct channels for the "Voltage" and the "Current" probes.
 8. Set the "Unit" for the trace: power or energy.

9. Set the "T<n> position" values.
10. Enable statistics.
11. Select the "Display" tab.
12. Select the measurements that you want to see. You can also change the color of the partial measurements.
13. Select the "Power waveform" tab.
14. Adjust the scale and offset of the resulting trace if necessary.

On the screen, you can see the measurement waveforms of the current, the voltage and the power. Also, the result table with numeric measurement results is shown. For details, see [Section 12.3.4.5, "Switching loss results"](#), on page 383.

12.3.4.2 Switching loss setup

Access: "Menu" > "Apps" > "Power" > "+ Add" > "Switching loss" > select "Switching loss" > "Setup".



In the "Setup" tab, you configure the switching loss measurement: select the sources, the time points of the switching loss cycle, and if you want to measure either power or energy.

Voltage

Selects the voltage source waveform. Analog channels and math waveforms can be used.

Remote command:

`POWer<m>:SWITChing:SOURce[:VOLTagE]` on page 1234

Current

Selects the current source waveform. Analog channels and math waveforms can be used.

Remote command:

`POWer<m>:SWITChing:SOURce:CURRent` on page 1234

Unit

Selects the measurement type: power or energy.

Remote command:

`POWer<m>:SWITChing:DISPlay:TYPE` on page 1235

T<n> position

T1 to T5 define the time points in the switching cycle. You can use cursor measurements to get the time values.

- T1: Start of the turn-on area, and start of the total switching cycle.
- T2: End of the turn-on area, and start of the conduction area.
- T3: End of the conduction area, and start of the turn-off area.
- T4: End of the turn-off area, and start of the non-conduction area.
- T5: End of non-conduction area, and end of the total switching cycle.

See "[Phases of the switching cycle](#)" on page 378.

Remote command:

`POWer<m>:SWITChing:REGion:TOTal[:STARt]` on page 1235 (T1)

`POWer<m>:SWITChing:REGion:TON[:STARt]` on page 1235 (T1)

`POWer<m>:SWITChing:REGion:TON:STOP` on page 1235 (T2)

`POWer<m>:SWITChing:REGion:CONduction[:STARt]` on page 1235 (T2)

`POWer<m>:SWITChing:REGion:CONduction:STOP` on page 1236 (T3)

`POWer<m>:SWITChing:REGion:TOFF[:STARt]` on page 1236 (T3)

`POWer<m>:SWITChing:REGion:TOFF:STOP` on page 1236 (T4)

`POWer<m>:SWITChing:REGion:NCONduction[:STARt]` on page 1236 (T4)

`POWer<m>:SWITChing:REGion:NCONduction:STOP` on page 1236 (T5)


`POWer<m>:SWITChing:REGion:TOTal:STOP` on page 1236 (T5)

Statistics, Clear results

See "[Statistics](#)" on page 368 and "[Clear results](#)" on page 368.

12.3.4.3 Switching loss display

Access: "Menu" > "Apps" > "Power" > "+ Add" > "Switching loss" > select "Switching loss" > "Display".



In the "Display" dialog, you select which measurements are performed. The results are displayed in the result table. You can change the colors of the cycle areas in the diagram.

Turn on

Enables the measurements of the turn-on area, and selects the display color.

Remote command:

`POWER<m>:SWITching:DISPlay:TON[:ENABle]` on page 1237

`POWER<m>:SWITching:DISPlay:TON:COLor` on page 1237

Conduction

Enables the measurements of the conduction area, and selects the display color.

Remote command:

`POWER<m>:SWITching:DISPlay:CONDUction[:ENABle]` on page 1237

`POWER<m>:SWITching:DISPlay:CONDUction:COLor` on page 1237

Turn off

Enables the measurements of the turn-off area, and selects the display color.

Remote command:

`POWER<m>:SWITching:DISPlay:TOFF[:ENABle]` on page 1237

`POWER<m>:SWITching:DISPlay:TOFF:COLor` on page 1237

Non-conduction

Enables the measurements of the non-conduction area, and selects the display color.

Remote command:

`POWer<m>:SWITChing:DISPlay:NCONduction[:ENABle]` on page 1237

`POWer<m>:SWITChing:DISPlay:NCONduction:COLor` on page 1237

Total

Enables the measurements of the total switching cycle.

Remote command:

`POWer<m>:SWITChing:DISPlay:TOTal[:ENABle]` on page 1238

Area label

Displays the names of the switching cycle areas.

Remote command:

`POWer<m>:SWITChing:DISPlay:LABel[:ENABle]` on page 1238

12.3.4.4 Power waveform


For a description of the power waveform display and scaling, see [Section 12.3.8.3, "Power waveform"](#), on page 406.

12.3.4.5 Switching loss results

The results of switching loss measurements are:

- Voltage waveform
- Current waveform
- Power waveform, which is the product of the current and voltage waveforms.
- Numeric measurement results of the selected measurement type (power or energy). The results are given for each phase of the switching cycle.


See ["Phases of the switching cycle"](#) on page 378 for an explanation of the switching cycle.



Remote commands are described in ["Switching loss results"](#) on page 1238.

12.3.5 Turn on/off time

The turn-on/off time analysis measures the time that a power supply takes to reach a certain output threshold when turned on or turned off. The output thresholds are usually a percentage of the steady state output level: 90% for turn-on, and 10% for turn-off time.



Required probes:

- AC input: differential voltage probe
- DC input: passive or differential voltage probe
- DC output: passive or differential voltage probe

You can measure several outputs in parallel. The maximum number of output connections depends on the number of channels on the instrument: 3 outputs (4-channel instrument) or 7 outputs (8-channel instrument).

12.3.5.1 Configuring turn on/off time measurements

For details of the configuration settings, see [Section 12.3.5.2, "Turn on/off setup"](#), on page 386.

1. Add a turn on/off time measurement as described in [Section 12.3.1.1, "Select power measurements"](#), on page 361.
2. Connect all voltage probes to the oscilloscope.
3. Connect the probes to the DUT:




Figure 12-9: Connection with AC input





Figure 12-10: Connection with DC input

- a) AC input:
Connect the positive (+) signal socket of the differential voltage probe to the line (L) of the AC input.
Connect the negative (-) signal socket of the differential voltage probe to the neutral (N) of the AC input.
 - b) DC input:
Connect the passive or differential voltage probe to the DC input of the power supply.
 - c) Outputs:
Connect the passive or differential voltage probes to the DC outputs of the power supply.
4. In the "Analysis" tab, tap the "Turn on/off time" measurement.
 5. Configure the input settings:
 - a) Select the correct channel for the "Input source".
 - b) Select the "Mode" (turn on or turn off) and the "Input type" (AC or DC).
 - c) Enter the threshold. The measurement starts when the input signal crosses this threshold.
 6. Use the  to add the required number of outputs
 7. Configure the outputs. For each output:
 - a) Select the correct channel for the "Output source".
 - b) Enter the threshold. The measurement stops when the output signal crosses this threshold.
 - c) Enable the output signal to see the waveform and the results.
 8. Select the "Display" tab.
 9. Select the outputs for which you want to see the result lines.

On the screen, you can see the waveforms of the input and the outputs. Also, the result table with numeric measurement results is shown. For details, see [Section 12.3.5.4, "Turn on/off results"](#), on page 389.

12.3.5.2 Turn on/off setup

Access: "Menu" > "Apps" > "Power" > "+ Add" > "Turn on/off time" > select "Turn on/off time" > "Setup".



In the "Setup" tab, you configure the turn-on/off time measurement: select the sources, the thresholds, and the measurement.

Input source

Selects the channel of the input signal. Analog channels and math waveforms can be used.

Remote command:

[POWER<m>:ONOFF:INPut\[:SOURce\]](#) on page 1245

Input type

Selects whether the input signal is AC or CD.

Remote command:

[POWER<m>:ONOFF:INPut:TYPE](#) on page 1245

Mode

Selects the turn-on or turn-off measurement.

Remote command:

[POWER<m>:ONOFF\[:TYPE\]](#) on page 1247

DC threshold

Sets the threshold for the DC input signal.

The time starts when the first edge exceeds a positive threshold value, or falls below a negative threshold value.

Remote command:

[POWER<m>:ONOFF:INPut:DC:ABSolute\[:VALue\]](#) on page 1245

AC threshold

Sets the threshold for the AC input signal. You set the absolute value, the instrument uses the positive and negative values of the given absolute value.

The time starts when the signal crosses either the positive threshold value, or the negative value - the first crossing point is considered.

Remote command:

`POWer<m>:ONOff:INPut:AC:ABSolute[:VALue]` on page 1244

Output source

Selects the channel of the output signal. Analog channels except for the input channel and math waveforms can be used.

You can set up several outputs in parallel. The maximum number of output connections depends on the number of channels on the instrument.

Remote command:

`POWer<m>:ONOff:OUTPut<n>[:SOURce]` on page 1246

DC threshold

Sets the threshold for the selected output signal.

When the output signal crosses this threshold, the turn-on time ends, or the turn-off time starts.

Remote command:

`POWer<m>:ONOff:OUTPut<n>:DC:ABSolute[:VALue]` on page 1246

Enable output


Activates the selected output line.

Remote command:

`POWer<m>:ONOff:OUTPut<n>:DISPlay:RESult[:ENABle]` on page 1246

12.3.5.3 Turn on/off display

For better understanding, you can display result lines for each output separately.



Result line <n>

Enables the display of result lines and threshold for the selected output. Result lines are only visible if the threshold is within the signal amplitude. Start and stop time are displayed with vertical dashed lines.

Remote command:


`POWer<m>:ONOff:OUTPut<n>:DISPlay:RLINE[:ENABle]` on page 1247

12.3.5.4 Turn on/off results

The results of turn-on/off time measurements are:

- Input waveform
- Output waveforms
- Measured values of turn-on or turn-off time for each input-output pair.

You can visualize the measured points on the waveform, see [Section 12.3.5.3, "Turn on/off display"](#), on page 388.



Remote commands are described in ["Turn on/off results"](#) on page 1247.

12.3.6 Power efficiency

Power efficiency analysis assesses how effectively a device converts input power into useful output power. It measures the input voltage and current and the output voltage and current, calculates the input and the output power, and the ratio of output power to input power. This ratio percentage is the power efficiency.

Required probes:


- Input: current probe and differential voltage probe
- Output: current probe and differential voltage probe

If your MXO oscilloscope has more than 4 channels, you can measure several outputs in parallel and obtain the total power and efficiency of the DUT. The maximum number of output lines is $\text{Number of channels} / 2 - 1$.

12.3.6.1 Configuring power efficiency measurements

For details of the configuration settings, see [Section 12.3.6.2, "Power efficiency setup"](#), on page 391.

1. Add a power efficiency measurement as described in [Section 12.3.1.1, "Select power measurements"](#), on page 361.
2. Connect the differential voltage probes and the current probes to the oscilloscope.
3. Deskew the probes as described in [Section 12.3.1.2, "Deskew"](#), on page 363.
4. Connect the probes to the DUT:



- a) Connect the positive (+) signal socket of the differential voltage probe to the line of the input.
 - b) Connect the negative (-) signal socket of the differential voltage probe to the neutral of the input.
 - c) Connect the current probe to the line of the input.
 - d) Connect a differential voltage probe and a current probe to each output to be measured.
5. In the signal bar, tap twice the signal icon of the efficiency measurement to open its settings dialog.
 6. Select the correct channels for the "Voltage" and the "Current" probes of the input and the output.
 7. Selects the type of the current flow for input and output: AC or DC: "Input type" and "Output type".

8. Enable statistics.
9. Select the "Display" tab.
10. Select the measurements that you want to see.
11. Select the "Power waveform" tab.
12. Adjust the scale and offset of the resulting waveforms if necessary.

On the screen, you can see the selected measurement waveforms of the input power and the output power. If your instrument has more than 4 channels and the DUT several outputs, you can see all output power waveforms and the total power if selected. Also, the result table with numeric measurement results is shown. For details, see [Section 12.3.6.7, "Efficiency results"](#), on page 395.

12.3.6.2 Power efficiency setup

Access: "Menu" > "Apps" > "Power" > "+ Add" > "Efficiency" > select "Efficiency" > "Setup".




Figure 12-11: Efficiency measurement setup of a 4-channel instrument




Figure 12-12: Efficiency measurement setup of an 8-channel instrument

In the "Setup" tab, you configure the efficiency measurement: select the sources for input and outputs and select whether they are AC or DC. Using several outputs requires more than 4 input channels. You also enable statistics here.

Voltage (Input)

Selects the voltage source waveform of the input line. Analog channels and math waveforms can be used.

Remote command:

`POWER<m>:EFFiciency:INPut<n>:VOLTagE[:SOURce]` on page 1248

Current (Input)

Selects the current source waveform of the input line. Analog channels and math waveforms can be used.

Remote command:

`POWER<m>:EFFiciency:INPut<n>:CURRent[:SOURce]` on page 1248

Input type

Selects the type of the current flow: AC or DC.

Remote command:

`POWER<m>:EFFiciency:INPut<n>[:TYPE]` on page 1249

Voltage (Output)

Selects the voltage source waveform of the selected output line. Analog channels and math waveforms can be used.

Using several outputs requires more than 4 input channels.

Remote command:

`POWer<m>:EFFiciency:OUTPut<n>:VOLTagE[:SOURce]` on page 1250

Current (Output)

Selects the current source waveform of the selected output line. Analog channels and math waveforms can be used.

Using several outputs requires more than 4 input channels.

Remote command:

`POWer<m>:EFFiciency:OUTPut<n>:CURRent[:SOURce]` on page 1249

Output type

Selects the type of the current flow: AC or DC.

Using several outputs requires more than 4 input channels.

Remote command:

`POWer<m>:EFFiciency:OUTPut<n>[:TYPE]` on page 1250

Statistics, Clear results

See ["Statistics"](#) on page 368 and ["Clear results"](#) on page 368.

12.3.6.3 Reference level

See [Section 12.3.8.1, "Reference level"](#), on page 402.

Separate reference level settings are available for input and output. The reference levels take effect only for the AC input and output types.

12.3.6.4 Gate

See [Section 12.3.8.2, "Gate settings for power measurements"](#), on page 405.

12.3.6.5 Power efficiency display

In this dialog, you select the power efficiency measurements that you want to display. For more details on the different measurements, see [Section 12.3.6.7, "Efficiency results"](#), on page 395.




Figure 12-13: Display settings of an 4-channel instrument




Figure 12-14: Display settings of an 8-channel instrument

Remote commands:

- `POWer<m>:EFFiciency:DISPlay:RESult:OUTPut<n>:EFFiciency[:ENABLE]` on page 1251
- `POWer<m>:EFFiciency:DISPlay:RESult:OUTPut<n>:POWer[:ENABLE]` on page 1251
- `POWer<m>:EFFiciency:DISPlay:RESult:TOTal<n>:EFFiciency[:ENABLE]` on page 1251
- `POWer<m>:EFFiciency:DISPlay:RESult:TOTal<n>:OPOWer[:ENABLE]` on page 1251

12.3.6.6 Power waveform

You can enable and scale the input, output and total waveforms individually.



Figure 12-15: Waveform settings of an 4-channel instrument




Figure 12-16: Waveform settings of an 8-channel instrument

For a description of the power waveform display and scaling, see [Section 12.3.8.3, "Power waveform"](#), on page 406.

12.3.6.7 Efficiency results

The results of efficiency measurements are:

- Input current and voltage waveforms
- Output current and voltage waveforms
- Input power waveform, which is the product of the input current and input voltage waveforms.
- Output power waveforms, which are the products of the corresponding output current and output voltage waveforms.
Using several outputs requires more than 4 input channels.
- Total power waveform, which is the sum of the output power values.

Total power requires more than 4 input channels.

- Numeric measurement results of input power, output power, total power and efficiencies. The total efficiency is the ratio of input power to the sum of output power values.

If the input or output type is set to AC, the period is measured on the AC voltage source. If one of these measurements fails, the efficiency result is invalid.

If statistics are enabled, every period for an AC source is analyzed. Without statistics, only the first period is analyzed.

Remote commands are described in section ["Efficiency results"](#) on page 1251.

12.3.7 Safe operating area (SOA)

The safe operating area (SOA) analysis is defined by the voltage and current conditions over which a power semiconductor device is expected to operate without self-damage. The safe operating area analysis provides a diagram of the safe operating conditions of your DUT.

In parallel to the time domain diagram, an XY-plot is created, with voltage points on the x-axis, while current is shown on the y-axis. The XY-plot is tested against a mask, which represents the safe operating area.


Required probes:

- Differential voltage probe
- Current probe

12.3.7.1 Configuring SOA measurements

For details of the configuration settings, see [Section 12.3.7.2, "SOA setup"](#), on page 397 and [Section 12.3.7.3, "SOA masks"](#), on page 399.

1. Add a SOA measurement as described in [Section 12.3.1.1, "Select power measurements"](#), on page 361.
2. Connect the differential voltage probes and the current probes to the oscilloscope.
3. Deskew the probes as described in [Section 12.3.1.2, "Deskew"](#), on page 363.
4. Connect the probes to the DUT:




- a) Connect the positive (+) signal socket of the differential voltage probe to the drain of the transistor.
 - b) Connect the negative (-) signal socket of the differential voltage probe to the source of the transistor.
 - c) Connect the current probe to the source of the transistor.
5. In the signal bar, tap twice the signal icon of the SOA measurement to open its settings dialog.
 6. Select the correct channels for the "Voltage" and the "Current" probes.
 7. If a SOA mask is already available, select "Open" and load the mask.
 8. If no mask is available, select "Edit segments". Create the mask segments, either under "Predefined" or "Limit".
Both segment types can be combined in one mask. For more information on predefined masks, see also [Section 12.1.4, "Actions on mask test results"](#), on page 335.
 9. "Save mask" if you want to keep it for further tests.
 10. Select the "Action" tab.
 11. Select the actions to be initiated on mask violation or successful completion of the test. You can select several actions.
 12. Run the acquisitions.

On the screen, you can see the voltage and current waveforms and the XY-diagram with the mask. Also, the result table with numeric measurement results and the test status is shown. For details, see [Section 12.3.7.5, "SOA results"](#), on page 401.

12.3.7.2 SOA setup

Access: "Menu" > "Apps" > "Power" > "+ Add" > "SOA" > select "SOA" > "Setup".



In the "Setup" tab, you configure the SOA measurement: select the sources, load and save the mask, and start creating a mask.

Voltage

Selects the voltage source waveform. Analog channels and math waveforms can be used.

In the SOA diagram, voltage points are plotted on the x-axis.

Remote command:

[POWER<m>:SOA:SOURce:VOLTag](#) on page 1256

Current

Selects the current source waveform. Analog channels and math waveforms can be used.

In the SOA diagram, current is plotted on the y-axis.

Remote command:

[POWER<m>:SOA:SOURce:CURRent](#) on page 1256

Edit segments

Opens a dialog to create and configure the SOA mask. See [Section 12.3.7.3, "SOA masks"](#), on page 399.

Save mask

Define the storage location and filename, and save the mask.

"<Folder>"	Opens a file explorer where you can select the directory where the file is saved.
"File name base"	Sets a name for the file, without extension. The name is extended with a time stamp when the file is saved. Thus, multiple "Save" actions are possible without changing the filename.
"File extension"	The format of the mask file is always <code>.xml</code> .

"Save" Saves the file in the defined folder using the "File name base". If the specified file already exists, it is overwritten with the new data.

"Save As" Opens a file explorer where you select the folder, the file type, enter the filename and save the file.

Remote command:

`POWer<m>:SOA:MTEST<n>:IMEXport:NAME` on page 1255

`POWer<m>:SOA:MTEST<n>:IMEXport:SAVE` on page 1255

Open

Opens a file explorer to select a previously stored mask file. The selected mask is loaded.

Remote command:

`POWer<m>:SOA:MTEST<n>:IMEXport:NAME` on page 1255

`POWer<m>:SOA:MTEST<n>:IMEXport:OPEN` on page 1255


12.3.7.3 SOA masks

Access: "Menu" > "Apps" > "Power" > "+ Add" > "SOA" > select "SOA" > "Setup" > "Edit segments".

You can define and edit 1 mask with up to 4 segments.

Predefined

To create a predefined mask, you select the shape of a mask segment, add it and then edit the positions of the corner points.



Shape ← Predefined

Selects the shape of the SOA mask: rectangle, diamond, hexagon, octagon.

Add segment ← Predefined

Adds a new segment with the selected shape to the mask. To adjust the size and position of the mask segment, select the segment and configure it. The procedure is the same as in the mask test application. See ["Add segment"](#) on page 333 and ["Edit segments"](#) on page 334.

Remote command:

`POWer<m>:SOA:MTEST<n>:SEGMENT<o>:ADD` on page 1258

`POWer<m>:SOA:MTEST<n>:SEGMENT<o>:COUNT?` on page 1258

`POWer<m>:SOA:MTEST<n>:SEGMENT<o>:POINT<p>:ADD` on page 1258

`POWer<m>:SOA:MTEST<n>:SEGMENT<o>:POINT<p>:COUNT?` on page 1259

`POWer<m>:SOA:MTEST<n>:SEGMENT<o>:POINT<p>:REMOVE` on page 1259

`POWer<m>:SOA:MTEST<n>:SEGMENT<o>:POINT<p>:VALID?` on page 1259


`POWer<m>:SOA:MTEST<n>:SEGMENT<o>:POINT<p>:X` on page 1260

`POWer<m>:SOA:MTEST<n>:SEGMENT<o>:POINT<p>:Y` on page 1260

`POWer<m>:SOA:MTEST<n>:SEGMENT<o>:REMOVE` on page 1261

Limit

You can use the values $I_{\max}$, $V_{\max}$ and $P_{\max}$ from the transistor specification to calculate a mask. $I_{\max}$, $V_{\max}$ and $P_{\max}$ must be positive values. The result is a mask segment in the first quadrant of the XY-diagram. You can change the generated segment like other segments: move, add and remove points.

**U max ← Limit**

Sets the maximum voltage for the mask. The value must be positive.

Remote command:

`POWer<m>:SOA:LIMit:VMAX` on page 1257

I max ← Limit

Sets the maximum current for the mask. The value must be positive.

Remote command:

`POWer<m>:SOA:LIMit:IMAX` on page 1257

P max ← Limit

Sets the maximum power for the mask. The value must be positive.

Remote command:

[POWer<m>:SOA:LIMit:PMAX](#) on page 1257

Generate mask ← Limit


Generates a mask using the given maximum values. The result is a mask segment in the first quadrant of the XY-diagram.

Remote command:

[POWer<m>:SOA:LIMit:APPLY](#) on page 1256

12.3.7.4 SOA actions

The safe operating analysis uses the same actions as the general mask test. For details, see [Section 12.1.4, "Actions on mask test results"](#), on page 335.

**12.3.7.5 SOA results**

The results of safe operating area measurements are provided in the following ways:

- Voltage source waveform and current source waveform in the diagram
- A logarithmic or linear XY-diagram of the voltage (x-axis) and current (y-axis) waveforms. This XY-diagram is a graphical representation of the power handling capability of the DUT under various conditions.
- If a power waveform in the XY diagram violates a mask, the violation is marked.
- The result table provides the numeric results of the SOA mask test.

Table 12-2: Results of the SOA test

Result	Description
Total acq.	Number of tested acquisitions (waveforms)
Passed acq.	Number of acquisitions that have passed the mask test, i.e. they are within the defined safe operating area mask
Failed acq.	Number of acquisitions that have failed the mask test, i.e. they are out of the defined safe operating area mask
Fail rate	Ratio of failed acquisitions to the number of tested acquisitions in %
Result	Summary test status: Pass or Fail

Remote commands are described in ["SOA results"](#) on page 1263.


12.3.8 Common functions for power measurements

12.3.8.1 Reference level

Some power analysis measurements require reference levels to obtain the measurement points. Power analysis uses its own reference level set, which is independent from other measurements and is used for all power measurements.

To ensure that the correct value for the period is used for the measurements, the period is determined on a voltage channel first. This period value is then applied wherever it is required to the current waveform and to the power (Math) waveform.

In power efficiency measurements, separate reference level settings are available for input and outputs. The reference levels take effect only for the AC input and output types.

**Figure 12-17: Relative reference level**




Figure 12-18: Absolute reference level

Level mode

Defines if the reference level is set in absolute or relative values.

Remote command:

`POWER<m>:EFFiciency:INPut<n>:REFLevel<rl>:LMODE` on page 1270

`POWER<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:LMODE` on page 1270

`POWER<m>:HARMonics:REFLevel<rl>:LMODE` on page 1270

`POWER<m>:QUALity:REFLevel<rl>:LMODE` on page 1270

`P3PHase<m>:HARMonics:REFLevel<rl>:LMODE` on page 1305

`P3PHase<m>:QUALity:REFLevel<rl>:LMODE` on page 1305

Absolute Level mode

In the absolute mode, the reference values are set as voltages, in absolute values.

Upper level, Middle level, Lower level ← Absolute Level mode

Sets the low, middle and upper reference signal levels.

Remote command:

`POWER<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:LLEVEL`
on page 1269

`POWER<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:MLEVEL`
on page 1269

`POWER<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:ULEVEL`
on page 1270

`POWER<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:LLEVEL`
on page 1269

`POWER<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:MLEVEL`
on page 1269

`POWER<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:ULEVEL`
on page 1270

`POWER<m>:HARMonics:REFLevel<rl>:ABSolute:LLEVEL` on page 1269

[POWER<m>:HARMonics:REFLevel<rl>:ABSolute:MLeVel](#) on page 1269
[POWER<m>:HARMonics:REFLevel<rl>:ABSolute:ULeVel](#) on page 1270
[POWER<m>:QUALity:REFLevel<rl>:ABSolute:LLeVel](#) on page 1269
[POWER<m>:QUALity:REFLevel<rl>:ABSolute:MLeVel](#) on page 1269
[POWER<m>:QUALity:REFLevel<rl>:ABSolute:ULeVel](#) on page 1270
[P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:LLeVel](#) on page 1304
[P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:MLeVel](#) on page 1305
[P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:ULeVel](#) on page 1305
[P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:LLeVel](#) on page 1304
[P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:MLeVel](#) on page 1305
[P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:ULeVel](#) on page 1305

Relative Level mode

In the relative mode, the reference values are set as percentages of the signal amplitude.

Relative levels ← Relative Level mode

Selects the lower, middle and upper reference levels, defined as percentages of the signal amplitude.

Available relative levels:

- 5/50/95
- 10/50/90
- 20/50/80
- User defined: Enter "Upper level", "Middle level", and "Lower level".

For example, for "5/50/95" the levels are set to the following values:

- Lower level = 5% of the signal amplitude
- Middle level = 50% of the signal amplitude
- Upper level = 95% of the signal amplitude

Remote command:

[POWER<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:MODE](#)
on page 1272

[POWER<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:MODE](#)
on page 1272

[POWER<m>:HARMonics:REFLevel<rl>:RELative:MODE](#) on page 1272

[POWER<m>:QUALity:REFLevel<rl>:RELative:MODE](#) on page 1272

[P3PHase<m>:HARMonics:REFLevel<rl>:RELative:MODE](#) on page 1307

[P3PHase<m>:QUALity:REFLevel<rl>:RELative:MODE](#) on page 1307

Upper level, Middle level, Lower level ← Relative Level mode

Define the reference levels in percent, if "Level mode" is set to "User-defined".

Remote command:

[POWER<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:LOWer](#)
on page 1271

[POWER<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:MIDDLE](#)
on page 1271

[POWER<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:UPPer](#)
on page 1273

`POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:LOWer`

on page 1271

`POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:MIDDLE`

on page 1271

`POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:UPPer`

on page 1273

`POWer<m>:HARMonics:REFLevel<rl>:RELative:LOWer` on page 1271

`POWer<m>:HARMonics:REFLevel<rl>:RELative:MIDDLE` on page 1272

`POWer<m>:HARMonics:REFLevel<rl>:RELative:UPPer` on page 1273

`POWer<m>:QUALity:REFLevel<rl>:RELative:LOWer` on page 1271

`POWer<m>:QUALity:REFLevel<rl>:RELative:MIDDLE` on page 1272

`POWer<m>:QUALity:REFLevel<rl>:RELative:UPPer` on page 1273

`P3PHase<m>:HARMonics:REFLevel<rl>:RELative:LOWer` on page 1306

`P3PHase<m>:HARMonics:REFLevel<rl>:RELative:MIDDLE` on page 1307

`P3PHase<m>:HARMonics:REFLevel<rl>:RELative:UPPer` on page 1308

`P3PHase<m>:QUALity:REFLevel<rl>:RELative:LOWer` on page 1306

`P3PHase<m>:QUALity:REFLevel<rl>:RELative:MIDDLE` on page 1307

`P3PHase<m>:QUALity:REFLevel<rl>:RELative:UPPer` on page 1308

Hysteresis

Defines a hysteresis for the middle reference level. A rise or fall from the middle reference value that does not exceed the hysteresis is rejected as noise.

Remote command:

`POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:HYSTeresis`

on page 1268

`POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:HYSTeresis`

on page 1270

`POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:HYSTeresis`

on page 1268

`POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:HYSTeresis`

on page 1270

`POWer<m>:HARMonics:REFLevel<rl>:RELative:HYSTeresis` on page 1271

`POWer<m>:HARMonics:REFLevel<rl>:ABSolute:HYSTeresis` on page 1268

`POWer<m>:QUALity:REFLevel<rl>:RELative:HYSTeresis` on page 1271

`POWer<m>:QUALity:REFLevel<rl>:ABSolute:HYSTeresis` on page 1268

`P3PHase<m>:HARMonics:REFLevel<rl>:RELative:HYSTeresis` on page 1306

`P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:HYSTeresis` on page 1304


`P3PHase<m>:QUALity:REFLevel<rl>:RELative:HYSTeresis` on page 1306

`P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:HYSTeresis` on page 1304

12.3.8.2 Gate settings for power measurements

Access: Select power measurement > "Gate".

You can limit the some power measurement to a user-defined range of the waveform. In the "Gate" tab, you select the gate to be used for the selected power analysis. If no gate has been defined before, or the correct gate is missing, select "Gate setup" and configure the gate. See [Section 8.2, "Gate setup"](#), on page 211 for details.




Remote commands:

- `POWER<m>:EFFiciency:GATE` on page 1250
- `POWER<m>:QUALity:GATE` on page 1214
- `P3PHase<m>:QUALity:GATE` on page 1300

12.3.8.3 Power waveform

Some power analysis measurements create a power waveform as one of the measurement results.

In the "Power waveform" dialog, you can change the scaling of the power waveform.



Display

Displays or hides the power waveform.

Remote command:

`POWER<m>:EFFiciency:DISPlay:WAVEform:INPut<n>:POWER[:ENABle]`
on page 1265

`POWER<m>:EFFiciency:DISPlay:WAVEform:OUTPut<n>:POWER[:ENABle]`
on page 1265

`POWER<m>:EFFiciency:DISPlay:WAVEform:TOTal<n>:OPower[:ENABle]`
on page 1265

`POWER<m>:HARMonics:DISPlay:POWER:WAVEform:ENABle` on page 1265

3-phase power analysis (option R&S MXO5C-K333)

`POWER<m>:QUALity:DISPlay:POWer:WAVEform:ENABle` on page 1265

`POWER<m>:SWITChing:DISPlay:POWer:WAVEform[:ENABle]` on page 1265

Scale mode

Selects the scaling mode for display of the resulting waveform. By default, the instrument selects the most appropriate scale. In "Manual" mode, you can change the vertical scale and offset.

Remote command:

`POWER<m>:EFFiciency:INPut<n>:POWer:VERTical:SCALE:MODE` on page 1266

`POWER<m>:EFFiciency:OUTPut<n>:POWer:VERTical:SCALE:MODE`

on page 1266

`POWER<m>:EFFiciency:TOTal<n>:OPOWer:VERTical:SCALE:MODE`

on page 1266

`POWER<m>:HARMonics:POWer:VERTical:SCALE:MODE` on page 1266

`POWER<m>:QUALity:POWer:VERTical:SCALE:MODE` on page 1266

`POWER<m>:SWITChing:POWer:VERTical:SCALE:MODE` on page 1266

Scale

Sets the vertical scale of the resulting power waveform if "Scale mode" is set to "Manual".

Remote command:

`POWER<m>:EFFiciency:INPut<n>:POWer:VERTical:SCALE[:VALue]`

on page 1267

`POWER<m>:EFFiciency:OUTPut<n>:POWer:VERTical:SCALE[:VALue]`

on page 1267

`POWER<m>:EFFiciency:TOTal<n>:OPOWer:VERTical:SCALE[:VALue]`

on page 1267

`POWER<m>:HARMonics:POWer:VERTical:SCALE[:VALue]` on page 1267

`POWER<m>:QUALity:POWer:VERTical:SCALE[:VALue]` on page 1267

`POWER<m>:SWITChing:POWer:VERTical:SCALE[:VALue]` on page 1267

Offset

Sets the offset of the resulting power waveform if "Scale mode" is set to "Manual".

Remote command:

`POWER<m>:EFFiciency:INPut<n>:POWer:VERTical:OFFSet` on page 1266

`POWER<m>:EFFiciency:OUTPut<n>:POWer:VERTical:OFFSet` on page 1266

`POWER<m>:EFFiciency:TOTal<n>:OPOWer:VERTical:OFFSet` on page 1266

`POWER<m>:HARMonics:POWer:VERTical:OFFSet` on page 1266

`POWER<m>:QUALity:POWer:VERTical:OFFSet` on page 1266

`POWER<m>:SWITChing:POWer:VERTical:OFFSet` on page 1266

12.4 3-phase power analysis (option R&S MXO5C-K333)

With the MXO 5C and option R&S MXO5C-K333, you can perform 3-phase measurements.



For best measurement results, we recommended setting channel **Bandwidth** = 20 MHz.

If using the HD mode, we recommended setting **Bandwidth** = 100 MHz.

12.4.1 3-phase power analysis initial settings

In the main "3-phase" dialog, you select the required power measurements, align the channels and set the offset compensation to get correct measurements.

12.4.1.1 Select 3-phase measurements


In the "Analysis" tab, you select the 3-phase measurements.

You can add up to 6 3-phase measurements, including several instances of the same measurement.

From here, you can access the settings for the enabled 3-phase measurements.


To add a new 3-phase measurement

1. Select the "Menu" > "Apps" > "General" tab > "3-phase".
2. In the "Analysis" tab, select "+ Add".



3. Select a 3-phase measurement on the list to enable it.
4. Select "+ Add" to add the selected measurements.


All selected measurements are enabled.



To delete a 3-phase measurement

1. Select the "Menu" > "Apps" > "General" tab > "3-phase", to open the 3-phase measurement dialog.
2. In the "Analysis" tab, select .

A delete icon appears next to each measurement.



3. Select the power measurement that you want to delete. Alternatively, select "Delete All" to delete all measurements.

+ Add

Opens a dialog to select the 3-phase measurements. See ["To add a new 3-phase measurement"](#) on page 408.

Remote command:

`P3PHase<m>[:ENABle]` on page 1275

`P3PHase<m>:TYPE` on page 1275

12.4.1.2 Deskew

See [Section 12.3.1.2, "Deskew"](#), on page 363.

12.4.1.3 Offset compensation

See [Section 12.3.1.3, "Offset compensation"](#), on page 365.

12.4.2 3-phase power quality

Expanding on single-phase power quality principles, three-phase systems require dedicated analysis due to inherent phase shifts and potential imbalances. See also [Section 12.3.2, "Power quality"](#), on page 365. While active, reactive, and apparent powers remain key metrics, three-phase assessment focuses on inter-phase relationships.

The power quality analysis measurement provides per-phase data ("C1"- "C6") alongside total system values ("V", "A"), see [Section 12.4.2.8, "3-phase power quality results"](#), on page 414. Evaluating these metrics for each phase helps identify imbalan-

ces or anomalies. Optimal systems exhibit minimal inter-phase variations and low harmonic distortion.

Required probes:


- 3x differential voltage probes (one for each phase)
- 3x current probes (one for each phase)

12.4.2.1 Configuring 3-phase power quality

For details of the configuration settings, see:

- [Section 12.4.2.2, "3-phase power quality setup"](#), on page 411.
- [Section 12.4.2.3, "3-phase power sources"](#), on page 412


1. Add a new power quality measurement as described in [Section 12.4.1, "3-phase power analysis initial settings"](#), on page 408.
2. Connect the differential voltage and the current probes to the oscilloscope.
3. Deskew the probes as described in [Section 12.3.1.2, "Deskew"](#), on page 363.
4. In the "Analysis" tab, select the "P3 quality" measurement.
The "P3 quality" setup dialog opens.
5. Select the "Fund. frequency" according to your signal.
6. Set a "User Frequency" to set the horizontal timebase.
7. Select the "Sources" tab.
8. Select the "Wiring" to configure how your probes are connected to the three-phase device.
9. Select if you have an "Input/output" setup.
10. Select "Config".
11. Assign the correct channels for the "Voltage" and the "Current" probes.
12. Select the required "Bandwidth" for signal acquisition. Select "Apply to Sources" to apply the configured bandwidth setting to all sources.
13. Select "Back".
14. Connect the probes to the DUT according to the visualization of the setup. For example a "3V3A" wiring:



On the screen, you can see the measurement waveforms of the current, the voltage and the power. Also, the result table with numeric measurement results is shown. For details, see [Section 12.4.2.8, "3-phase power quality results"](#), on page 414.

12.4.2.2 3-phase power quality setup

Access: "Menu" > "Apps" > "3-phase" > "+ Add" > "P3 quality" > select "P3 quality" > "Setup".



In the "Setup" tab, you configure the frequencies.

Fund. frequency

Selects the input frequency of the source signal.

- "50 Hz": Standard power grid frequency in Europe, Asia, and parts of Africa
- "60 Hz": Standard power grid frequency in North America and parts of South America
- "400 Hz": Used in aerospace and submarine applications and some industrial equipment
- "User": Custom fundamental frequency value
- "Automatic": Automatic detection of the fundamental frequency of the input signal

Remote command:

`P3PHase<m>:QUALity:FREQuency[:VALue]` on page 1276

User Frequency

Sets the horizontal timebase to control the time scale of the waveform display.

Remote command:

[P3Phase<m>:QUALity:FREQuency:USER](#) on page 1276

12.4.2.3 3-phase power sources

See [Section 12.4.4.1, "3-phase power sources"](#), on page 423.

12.4.2.4 3-phase power reference level

See [Section 12.3.8.1, "Reference level"](#), on page 402.

12.4.2.5 3-phase power gate

See [Section 12.3.8.2, "Gate settings for power measurements"](#), on page 405.

12.4.2.6 3-phase power waveform

For a description of the power waveform scaling, see [Section 12.4.4.2, "3-phase power waveform"](#), on page 426.

12.4.2.7 3-phase phasor diagram

Access: "Menu" > "Apps" > "3-phase" > "+ Add" > "P3 quality" > select "P3 quality" > "Phasor diagram".



In the "Phasor diagram" tab, you configure the display of the phasor diagram.

State

Displays or hides the phasor diagram.

Remote command:

`P3PHase<m>:QUALity:PHASor[:ENABle]` on page 1277

Voltage range, Current range

Configures the voltage and current ranges of the phasor diagram.

Offset ← Voltage range, Current range

Sets the inner point of the phasor diagram.

Remote command:

`P3PHase<m>:QUALity:PHASor:VOLTage:OFFSet` on page 1278

`P3PHase<m>:QUALity:PHASor:CURREnt:OFFSet` on page 1278

Maximum ← Voltage range, Current range

Sets the outer circumference of the phasor diagram.

Remote command:

`P3PHase<m>:QUALity:PHASor:VOLTage:MAXimum` on page 1278

`P3PHase<m>:QUALity:PHASor:CURREnt:MAXimum` on page 1278

Fit to Screen

The instrument selects the most appropriate scale for the voltage and current phasors.

Remote command:

`P3PHase<m>:QUALity:PHASor:FSCreen` on page 1278

12.4.2.8 3-phase power quality results



The results of power quality measurements are provided as follows:

- The waveform diagram shows the graphical presentation of:
 - The voltage waveform of the individual and total phases
 - The current waveform of the individual and total phases
 - The power waveform of the individual and total phases, The power waveform is the product of the current and voltage waveforms.
 See also [Section 12.4.4.2, "3-phase power waveform"](#), on page 426.
- Results are visualized in a phasor diagram, which graphically displays the magnitude and phase angles of each phase voltage and current. In a balanced 3-phase system, phase shifts between voltage and current are typically 120 degrees. See also [Section 12.4.2.7, "3-phase phasor diagram"](#), on page 412.
- The result table displays the numeric measurement results:

Result table	Description
Cycle source	Selected channel (voltage source) to serve as the timing reference.
Cycle source frequency	Nominal frequency of the power system.
Input, output	Selected lines in the source configuration
Current RMS, voltage RMS	Square root of the mean of the square of the current or voltage. Represents the effective value of the AC waveform.
Current cycle crest factor, voltage cycle crest factor	Ratio of the peak (maximum absolute value) to the RMS value of the waveform. Indicates the level of waveform distortion.
Current maximum, voltage maximum	Highest measured value of the current or voltage

3-phase power analysis (option R&S MXO5C-K333)

Result table	Description
Active power	Energy of the system that can be used to do work.
Power factor	Measure of the system efficiency. The value varies between -1 and 1.
Reactive power	Power flow that is temporally stored in a system because of the inductive and capacitive elements.
Apparent power	Magnitude of the vector sum of active and reactive power
Phase	Phase differences between the current and the voltage sine waves of the different phases.

Remote commands: ["3-phase power quality results"](#) on page 1282.

12.4.3 3-phase power harmonics

Harmonic currents generated by nonlinear loads in 3-phase systems can impact power quality by affecting other equipment on the grid, see [Section 12.3.3, "Power harmonics"](#), on page 371. Unlike single-phase systems, harmonics in a 3-phase environment can exist with different phase angles and magnitudes on each line, requiring analysis of both individual harmonic components and their relationships to each other. To ensure power quality and prevent interference, industry and regulatory bodies have established compliance standards for end-products.

The power harmonics analysis tests the devices according to the precompliance standard EN 61000-3-2.

Required probes:

- 3x differential voltage probes (one for each phase)
- 3x current probes (one for each phase + optionally a neutral current probe)


12.4.3.1 Configuring 3-phase power harmonics

For details of the configuration settings, see:

- [Section 12.4.3.2, "3-phase power harmonics setup"](#), on page 416
- [Section 12.4.3.3, "3-phase power sources"](#), on page 419

1. Add a new power quality measurement as described in [Section 12.4.1, "3-phase power analysis initial settings"](#), on page 408.
2. Connect the differential voltage and the current probes to the oscilloscope.
3. Deskew the probes as described in [Section 12.3.1.2, "Deskew"](#), on page 363.
4. Connect the probes to the DUT:
 - a) Connect the positive (+) signal socket of the differential voltage probe to the line of the AC input.
 - b) Connect the negative (-) signal socket of the differential voltage probe to the neutral of the AC input.

- c) Connect the current probe to the line of the AC input.
5. In the "Analysis" tab, select the "P3 harmonics" measurement.
The "P3 harmonics" setup dialog opens.
6. Select the "Standard".
7. Select the "Fund. frequency" according to your signal.
8. Select the "Sources" tab.
9. Select the "Wiring" to configure how your probes are connected to the three-phase device.
10. Select if you have an "Input/output" setup.
11. Select "Config".
12. Assign the correct channels for the "Voltage" and the "Current" probes.
13. Select the desired "Bandwidth" for signal acquisition. Select "Apply to Sources" to apply the configured bandwidth setting to all sources.
14. Select "Back".
15. Connect the probes to the DUT according to the visualization of the setup. For example a "3V3A" wiring:



On the screen, you can see the measurement waveforms of the current, the voltage and the power. Also, the result table with numeric measurement results is shown. For details, see [Section 12.4.3.7, "3-phase power harmonic results"](#), on page 421.

12.4.3.2 3-phase power harmonics setup

Access: "Menu" > "Apps" > "3-phase" > "+ Add" > "P3 harmonics" > select "P3 harmonics" > "Setup".




Figure 12-19: 3-phase power harmonic setup for EN 61000-3-2 A / EN 61000-3-2 B




Figure 12-20: 3-phase power harmonic setup for EN 61000-3-2 C




Figure 12-21: 3-phase power harmonic setup for EN 61000-3-2 D

Standard, Revision

Select the standard in use, including which "Revision" of the standard is used, "Revision 2011" or "Revision 2019".

Table 12-3: Current harmonic precompliance standards

Standard	Application
EN 61000-3-2 Class A	Balanced 3-phase equipment, household appliances (excluding equipment identified as class D), tools (excluding portable tools), dimmers for incandescent lamps, audio equipment
EN 61000-3-2 Class B	Portable tools, not professional arc welding equipment
EN 61000-3-2 Class C ¹⁾	Lighting equipment
EN 61000-3-2 Class D	PC, PC monitors, radio, or TV receivers with an input power less than or equal to 600W
¹⁾ The EN 61000-3-2 defines different limits for EN 61000-3-2 Class C equipment with an input power smaller or equal than 25W either. The limits that are implemented in the MXO 5C firmware comply with the limits of table 3 (column 2) of the EN 61000-3-2 standard.	

Remote command:

[P3Phase<m>:HARMonics:STANdard](#) on page 1291

[P3Phase<m>:HARMonics:REVisiOn](#) on page 1291

Fund. frequency

Selects the frequency of the input signal. The available frequencies depend on the selected [Standard](#), [Revision](#).

Remote command:

[P3Phase<m>:HARMonics:FREQuency:EN](#) on page 1291

Power factor

Available only for "Standard" = EN 61000-3-2 Class C.

Selects if the power factor is defined automatically, or a user-defined value ("Power factor") is used.

Remote command:

`P3Phase<m>:HARMonics:PFACTOR:MODE` on page 1292

`P3Phase<m>:HARMonics:PFACTOR:USER` on page 1292

Phase & current parameters

Shows a graphical explanation of the relative phase angle and current parameters.

Real power, Power

Available only for "Standard" = EN 61000-3-2 Class D.

Selects if the real power is defined automatically, or a user-defined value ("Power") is used.

Remote command:

`P3Phase<m>:HARMonics:RPOWER:MODE` on page 1292

`P3Phase<m>:HARMonics:RPOWER:USER` on page 1293

12.4.3.3 3-phase power sources

See [Section 12.4.4.1, "3-phase power sources"](#), on page 423.


12.4.3.4 3-phase power reference level

See [Section 12.3.8.1, "Reference level"](#), on page 402.

12.4.3.5 3-phase power bar graph

Access: "Menu" > "Apps" > "3-phase" > "+ Add" > "P3 harmonics" > select "P3 harmonics" > "Bargraph".

In this tab you can configure the scale for the bar graph display.



State

Displays or hides the bar graph.

Remote command:

`P3Phase<m>:HARMonics:DISPlay:BARGraph[:ENABle]` on page 1293

Scale type

Selects a logarithmic or linear scale for the display for the harmonics bar graph.

Remote command:

`P3Phase<m>:HARMonics:DISPlay:BARGraph:VERTical:SCALE:TYPE`
on page 1294

Displ. harmonics

Selects which harmonics are displayed in the bar graph: all, odd even or depending on the standard definition.

Remote command:

`P3Phase<m>:HARMonics:DISPlay:HARMonics[:DISPlay]` on page 1294

Start harmonic

Sets the start frequency of a bar graph display. At least three bars are displayed.

Remote command:

`P3Phase<m>:HARMonics:DISPlay:HARMonics:START[:VALue]` on page 1294

Max harmonic

Sets the stop frequency of the bar graph display. The maximum value is defined by standard and fundamental frequency.

Remote command:

`P3Phase<m>:HARMonics:DISPlay:HARMonics:STOP[:VALue]` on page 1294

12.4.3.6 3-phase power waveform

For a description of the power waveform scaling, see [Section 12.4.4.2, "3-phase power waveform"](#), on page 426.

12.4.3.7 3-phase power harmonic results



The results of the harmonic measurements are provided as follows:

- The waveform diagram shows the graphical presentation of:
 - The voltage waveform of the individual and total phases
 - The current waveform of the individual and total phases
 - The power waveform of the individual and total phases. The power waveform is the product of the current and voltage waveforms.
 See also [Section 12.4.4.2, "3-phase power waveform"](#), on page 426.
- The results are visualized in a bar graph. The number of displayed harmonics depends on the standard definition. When you select a harmonic in the bar chart, the corresponding row in the result table is highlighted. See also [Section 12.4.3.5, "3-phase power bar graph"](#), on page 419.
- The result table displays the numeric measurement results:

Result table	Description
THD RMS	Total harmonic distortion (THD) relative to the RMS amplitude
THD fundamental	Total harmonic distortion relative to the fundamental
Harmonic index	Harmonic order. Represents the multiple of the fundamental frequency. Value of the x-axis in the bar graph
Frequency	Nominal frequency of the power system.
Phase	Phase differences between the current and the voltage sine waves of the different phases.


3-phase power analysis (option R&S MXO5C-K333)

Result table	Description
Magnitude (%)	Present value of the current harmonic expressed as a percentage of the fundamental component. Value of the y-axis in the bar graph
Magnitude (RMS)	Measured RMS value of the harmonic component.
Limit	Maximum allowed value according to the selected standard. Visually represented by a dark orange line in the bar graph.
Margin	Sets the upper limit for the display of the Y scale.
Status	Displays whether the harmonic's magnitude is within the limit (pass - green bar) or exceeds the limit (fail - orange bar).

Remote commands: ["3-phase power harmonics results"](#) on page 1295.

12.4.4 Common functions for 3-phase power measurements

12.4.4.1 3-phase power sources



Source config

Select a source configuration previously defined for another 3-phase power measurement.

Copy

Copies the selected source configuration to the current configuration.

Wiring

Configures how your probes are connected to the three-phase device. It allows you to visualize the connections for proper setup. If you can only measure on four channels, select the "2V2A" wiring.

- "2V2A": The current is measured on line 1 and line 2, voltage is measured between lines 1 and 3 and lines 2 and 3. The other values are calculated.

3-phase power analysis (option R&S MXO5C-K333)

- "3V3A": The voltages are measured between two lines and the currents in the individual phases.
- "3VN3A": The voltages are measured against the neutral line and the currents in the individual phases.

Remote command:

[P3PHase<m>:QUALity:SOURce:WIRing](#) on page 1298

[P3PHase<m>:HARMonics:SOURce:WIRing](#) on page 1298

Input/output

Configures whether the oscilloscope is configured to receive signals (input) for analysis, or to generate signals (output) as a source for testing.

Remote command:

[P3PHase<m>:QUALity:SOURce:INOut](#) on page 1298

[P3PHase<m>:HARMonics:SOURce:INOut](#) on page 1298

Select lines

Select the configuration for your probe setup. The visualization is adapted accordingly. This setting is only available for "Wiring"="2V2A".


Remote command:

[P3PHase<m>:QUALity:SOURce:LINes:W2V2a](#) on page 1299

[P3PHase<m>:HARMonics:SOURce:LINes:W2V2a](#) on page 1299

Config

Opens the "Source config" dialog.

**Voltage ← Config**

Selects the voltage source waveform. Analog channels and math waveforms can be used.

Remote command:

[P3Phase<m>:QUALity:SOURce:VOLTage:W2V2a](#) on page 1299

[P3Phase<m>:QUALity:SOURce:VOLTage:W3V3a](#) on page 1299

[P3Phase<m>:QUALity:SOURce:VOLTage:W3VN3a](#) on page 1299

[P3Phase<m>:HARMonics:SOURce:VOLTage:W2V2a](#) on page 1299

[P3Phase<m>:HARMonics:SOURce:VOLTage:W3V3a](#) on page 1300

[P3Phase<m>:HARMonics:SOURce:VOLTage:W3VN3a](#) on page 1300

Current ← Config

Selects the current source waveform. Analog channels and math waveforms can be used.

Remote command:

[P3Phase<m>:QUALity:SOURce:CURREnt:W2V2a](#) on page 1299

[P3Phase<m>:QUALity:SOURce:CURREnt:W3V3a](#) on page 1299

[P3Phase<m>:QUALity:SOURce:CURREnt:W3VN3a](#) on page 1299

[P3Phase<m>:HARMonics:SOURce:CURREnt:W2V2a](#) on page 1299

[P3Phase<m>:HARMonics:SOURce:CURREnt:W3V3a](#) on page 1299

[P3Phase<m>:HARMonics:SOURce:CURREnt:W3VN3a](#) on page 1299

Bandwidth ← Config

If a warning message appears indicating differing bandwidths on the input channels, verify and adjust the bandwidth settings to match across all channels.

Apply to Sources ← Config

Applies the configured bandwidth setting to all sources.

Source ← Config

Selects the channel (voltage source) to serve as the timing reference for data calculations across all sources when the periods are not aligned on the x-axis.


Remote command:

[P3Phase<m>:QUALity:SOURce:CYCLe](#) on page 1300

[P3Phase<m>:HARMonics:SOURce:CYCLe](#) on page 1300

Cut-off ← Config

Configures a bandwidth limitation. The adjustable filter frequency is linked to the sample rate. To access a wider range of frequencies not achievable with the current configuration, configure the sample rate in "Menu" > "Acquisition".

12.4.4.2 3-phase power waveform

In the "Power waveform" dialog, you can change the display and scaling of the power waveform of the single and total phases.

Display individual phases

Displays or hides the power waveform of the individual phases.

For harmonics analysis, a power waveform is available if "Standard" is set to EN 61000-3-2 Class C or EN 61000-3-2 Class D.

Remote command:

`P3PHase<m>:QUALity:DISPlay:POWer<n>:WAVEform[:ENABle]` on page 1301

`P3PHase<m>:HARMonics:DISPlay:POWer<n>:WAVEform[:ENABle]`

on page 1301

Scale individual phases

Configures the scaling of the individual phases.

Mode ← Scale individual phases

Selects the scaling mode for display of the resulting waveform. By default, the instrument selects the most appropriate scale. In "Manual" mode, you can change the vertical scale and offset.

Remote command:

`P3PHase<m>:QUALity:POWer<n>:VERTical:SCALE:MODE` on page 1302

`P3PHase<m>:HARMonics:POWer<n>:VERTical:SCALE:MODE` on page 1302

Scale ← Scale individual phases

Sets the vertical scale of the resulting power waveform if "Mode" is set to "Manual".

Remote command:

`P3PHase<m>:QUALity:POWer<n>:VERTical:SCALE[:VALue]` on page 1303

`P3PHase<m>:HARMonics:POWer<n>:VERTical:SCALE[:VALue]` on page 1303

Offset ← Scale individual phases

Sets the offset of the resulting power waveform if "Mode" is set to "Manual".

Remote command:

`P3PHase<m>:QUALity:POWer<n>:VERTical:OFFSet` on page 1301

`P3PHase<m>:HARMonics:TOTal:POWer:VERTical:OFFSet` on page 1302

Total phase

Configures the display and the scaling of the total phase.

Display ← Total phase

Enables the display of the total phase.

Remote command:

`P3PHase<m>:QUALity:DISPlay:TOTal:POWer:WAVEform[:ENABle]`

on page 1301

`P3PHase<m>:HARMonics:DISPlay:TOTal:POWer:WAVEform[:ENABle]`

on page 1301

Mode ← Total phase

Selects the scaling mode for display of the resulting waveform. By default, the instrument selects the most appropriate scale. In "Manual" mode, you can change the vertical scale and offset.

Remote command:

`P3PHase<m>:QUALity:TOTal:POWer:VERTical:SCALE:MODE` on page 1302

`P3PHase<m>:HARMonics:TOTal:POWer:VERTical:SCALE:MODE` on page 1302

Scale ← Total phase

Sets the vertical scale of the resulting power waveform if "Mode" is set to "Manual".

Remote command:

`P3PHase<m>:QUALity:TOTal:POWer:VERTical:SCALE[:VALue]` on page 1303

`P3PHase<m>:HARMonics:TOTal:POWer:VERTical:SCALE[:VALue]`

on page 1303

Offset ← Total phase

Sets the offset of the resulting power waveform if "Mode" is set to "Manual".

Remote command:

`P3PHase<m>:QUALity:TOTal:POWer:VERTical:OFFSet` on page 1302

`P3PHase<m>:HARMonics:TOTal:POWer:VERTical:OFFSet` on page 1302

12.5 Digital voltmeter

The software-based voltmeter features AC RMS, DC and DC RMS voltage measurements on a specific analog channel.

12.5.1 Using the digital voltmeter

To start a digital voltmeter measurement

1. Tap the "Menu" > "Apps" > "General" tab > "DVM", to open the digital voltmeter measurement dialog.



2. Select the channel for your measurement.
3. Select a "Filter bandwidth" from the list.
4. Set a "Measurement time".
5. Tap on a measurement to enable it. Available are "DC", "DC RMS", "AC RMS".

The measurement results of all enabled measurements are displayed in the result table.



12.5.2 Settings of the digital voltmeter

Access: "Menu" > "Apps" > "General" tab > "DVM".

**C<n>**

Selects the channel which is measured by the digital voltmeter.

Filter bandwidth

Selects the filter bandwidth.

Remote command:

[METER:BANDwidth](#) on page 1310

Measurement time

Sets the measurement time. The time begins in the moment that a measurement is enabled.

Remote command:

[METER:MTIME](#) on page 1313

Measurements

Enables the voltmeter measurements. When a measurement is enabled, the voltmeter is turned on automatically.

"DC" Enables the DC voltage measurement.

"DC RMS" Enables the DC RMS voltage measurement.

"AC RMS" Enables the AC RMS voltage measurement.

Remote command:

[METER:DVMeter<m>:ACRMs:ENABle](#) on page 1311

[METER:DVMeter<m>:ACRMs:RESult?](#) on page 1311

[METER:DVMeter<m>:DC:ENABle](#) on page 1312

[METER:DVMeter<m>:DC:RESult?](#) on page 1312

[METER:DVMeter<m>:DCRMs:ENABle](#) on page 1312

[METER:DVMeter<m>:DCRMs:RESult?](#) on page 1313

All on, All off

Enables/disables all voltmeter measurements.


12.6 XY-plot

XY-plots combine the voltage levels of two waveforms in one diagram. They use the voltage level of a second waveform as the x-axis, rather than a time base. This allows you to perform phase shift measurements, for example. You can display up to four different XY-plots.

You can analyse XY-plots, for example, with cursor and automatic measurements, zone trigger and mask test. Available analysis methods depend on the selected sources of the XY-plot.

12.6.1 Settings for XY-plots

Access: "Menu" > "Apps" > "General" tab > "XY"



You can display up to four different XY-plots that use the voltage level of a waveform as the x-axis, rather than a time base.



Make sure to select the tab of the required XY-plot.

Display

If activated, the XY-waveform is active and shown in a diagram, or it is minimized in a signal icon.

Remote command:

`XY<m> [:STATe]` on page 1314

X-source, Y-source

Define the signal sources that supply the x-values and y-values of the XY-diagram.

Select from the active waveforms:

- Analog channel waveform
- Reference waveform
- Math waveform
- Track waveform (mask test and zone trigger on the resulting XY-plot is not possible)

Remote command:

`XY<m>:XSOurce` on page 1314

`XY<m>:YSOurce` on page 1314

Swap XY

Replaces the source of the x-axis with the source of the y-axis and vice versa.

Remote command:

`XY<m>:SWAP` on page 1313

12.6.2 Displaying an XY-diagram

To set up an XY-plot

1. Select "Menu" > "Apps".
2. In the > "General" tab, tap "XY".
3. In the "X-source" field, define the signal source that supplies the x-values of the XY-diagram.
4. In the "Y-source" field, define the signal source that supplies the y values of the XY-diagram.
5. Enable the "Display".
6. To switch the x- and y-values quickly, tap the "Swap XY" button.

12.7 Eye analysis (option R&S MXO5C-K136)

The main application of eye diagrams is the analysis of signal integrity and signal quality. In particular, eye diagram analysis is used for serial communication standards, for both high-speed serial protocols (e.g. USB) and low-speed serial protocols (e.g. CAN).

12.7.1 Calculation and display of eye diagrams

The MXO 5C can generate eye diagrams. To build the eyes, the oscilloscope acquires a long waveform containing many bits. The instrument uses a timing reference (clock signal or CDR) to cut the waveform into slices of 1-bit length, and superimposes the

individual slices. The superimposed slices of consecutive bits build the eye. The timing reference defines the position of the individual data bits on the time axis, and so it provides the necessary timing marks to align and superimpose the waveform slices.

The method combines consecutive bits in the eye diagram and does not miss any bit of the acquisition. Eye generation also offers time control over the waveform slices contributing to the eye diagram. For example, you can select the bits contributing to the eye using a gate.

You can define up to 8 eye diagrams and configure them independently. Each eye has its own signal icon. You can move and minimize eye diagrams like any waveform diagram and analyze all eye diagrams in parallel.

The analysis functions for eye diagrams are described in [Section 12.7.3, "Analysis of eye diagrams"](#), on page 437.

12.7.2 Eye diagram setup

The configuration of an eye diagram consists of the selection and setup of the input source and timing reference. You can also adjust display settings and restrict the slices that contribute to the eye generation.

You can define up to 8 eye diagrams and configure them independently.

12.7.2.1 Basic setup

Access: "Menu" > "Apps" > "General" tab > "Eye Analysis" > "Setup" tab

In the "Setup" tab, you configure the source, the reference levels, the timing reference and other eye definition settings.

Enable

Activates or deactivates the eye diagram.

Remote command:

[EYE<e>:STAtE](#) on page 1319

Source

Selects the waveform from which the eye diagram is generated. You can select analog channels, reference and math waveforms. For analog channels, peak detect, envelope, and average waveforms are not supported.

If the source waveform is minimized or hidden, no measurement results for the eye diagram are shown.

Remote command:

[EYE<e>:SOURce](#) on page 1319

Reference levels

Selects the reference level set that defines the timestamps for slicing the data waveform. A timestamp is set each time when the selected slope of the timing waveform crosses the selected reference level.

Remote command:

[EYE<e>:RFLSet](#) on page 1318

Reference level

Opens the "Reference level" dialog, where you can configure the reference level sets. See [Section 8.1, "Reference level setup"](#), on page 209 for details.

Timing reference

Selects the timing reference, which defines the reference signal and the method that are used to obtain the timing information required to slice the data source waveform.

Remote command:

[EYE<e>:TREFerence](#) on page 1319

Timing reference

Opens the "Timing reference" tab, where you can configure the timing definitions using an explicit clock or clock data recovery. See [Section 8.3, "Timing reference"](#), on page 213 for details.

Sampling time

Sets a sampling time for the clock signal, an offset for the clock edge in relation to the bit start. A unit interval typically corresponds to a bit in the input data signal. The clock edge sets the beginning of the unit interval. The sampling time is a number between 0 and 1. Value 0 sets the clock edge to the beginning of the bit period; value 0.5 sets the clock edge to the middle of the bit period.

Remote command:

[EYE<e>:SAMTime](#) on page 1319

Slices per acquisition

Sets the number of waveform slices for a single acquisition.

Remote command:

[EYE<e>:MSLices](#) on page 1318

12.7.2.2 Scale settings

Access: "Menu" > "Apps" > "General" tab > "Eye Analysis" > "Scale" tab

Time units

Sets the method to define the horizontal scale of the eye diagram: as absolute time, or in unit intervals. You can use a unit interval, if the nominal frequency of the clock signal is known.

Indirectly, the horizontal scale determines the size of one waveform slice. The waveform slice must be fully contained in the waveform acquisition to contribute to the eye diagram.

The time units value effects the following parameters:

- The units of the "Eye diagram".
- The position of cursor lines in the eye diagram.
- The X-position of segment points in mask tests on eye.

Remote command:

[EYE<e>:HORizontal:UNIT](#) on page 1317

Range

Sets the time range that is covered by the eye diagram in absolute time values or unit intervals.

Remote command:

[EYE<e>:HORizontal:ABSolute:RANGe](#) on page 1316

[EYE<e>:HORizontal:UINterval:RANGe](#) on page 1317

Position

Defines the position of the zero point in the diagram, in seconds or unit intervals. The zero point is the alignment point on which the slice timestamps are superimposed.

Remote command:

[EYE<e>:HORizontal:ABSolute:POSition](#) on page 1316

[EYE<e>:HORizontal:UINterval:POSition](#) on page 1317

Couple to source

If enabled, the vertical position and scale of the source are used.

Remote command:

[EYE<e>:VERTical:COUPle](#) on page 1320

Vertical scale

Defines the vertical scale in Volts per division if the vertical settings are independent of the source settings. Increasing the scale compresses the display of the eye.

Remote command:

[EYE<e>:VERTical:SCALE](#) on page 1321

Vertical offset

Sets the offset voltage of the eye if the vertical settings are independent of the source settings.

Remote command:

[EYE<e>:VERTical:OFFSet](#) on page 1320

Vertical position

Moves the selected eye up or down in the diagram if the vertical settings are independent of the source settings.

Remote command:

[EYE<e>:VERTical:POSition](#) on page 1320

12.7.2.3 Display settings

Access: "Menu" > "Apps" > "General" tab > "Eye Analysis" > "Display" tab

Each eye diagram has its specific persistence settings, independent of the general waveform persistence.

Enable

If enabled, each new data point in the diagram area remains on the screen for the duration that is defined using [Time](#), or as long as [Infinite persistence](#) is selected.

If disabled, the waveform points are displayed only for the current acquisition.

Remote command:

[EYE<e>:DISPlay:PERSiStence:STAtE](#) on page 1315

Infinite persistence

If infinite persistence is enabled, each new waveform point remains on the screen until this option is disabled, or the display is reset. Use infinite persistence to display rare events in the signal.

Remote command:

[EYE<e>:DISPlay:PERSiStence:INFinite](#) on page 1315

Time

Sets the time how long the eye points remain on the display.

Remote command:

[EYE<e>:DISPlay:PERSiStence:TIME](#) on page 1316

Reset

Resets the display, removing all waveform points.

Remote command:

[EYE<e>:DISPlay:PERSiStence:RESet](#) on page 1315

Edit color table

Like any other waveform, you can show the eye waveform in solid color, or apply a color table.

For a description of the color table settings, see [Section 5.3.1, "Colors"](#), on page 95.

12.7.2.4 Qualify settings

Access: "Menu" > "Apps" > "General" tab > "Eye Analysis" > "Qualify" tab

Gate

Selects the gate, which restricts the contributing slices in horizontal direction. Only the timestamps within the defined horizontal interval qualify for eye generation.

Remote command:

[EYE<e>:QUALify:GATE](#) on page 1318

Gates

Opens the "Gate" dialog, where you can configure the gates. See [Section 8.2, "Gate setup"](#), on page 211 for details.

12.7.3 Analysis of eye diagrams

To analyze eye diagrams, you can use the following functions of the MXO 5C:

- **Zoom**

You can zoom into eye diagrams using the zoom functions.

For details, see [Section 9.1, "Zoom"](#), on page 219.

- **Cursor measurements**

Cursors can be used on eye diagrams in the usual way. "Envelope 1", "Envelope 2" and "Track waveform" are not supported.

For details, see [Section 10.1, "Cursor measurements"](#), on page 256.

- **Mask testing**

You can test the created signal eye against a mask. Using this mask test, you can test data signals against eye shapes that are required in the standards. You can select and modify the shape of the eye and enter the position of the corner points. For details, see [Section 12.1, "Mask testing"](#), on page 329.

13 Data and file management

This section describes how to manage general and measurement settings, waveform data, measurement results, and screenshots.

13.1 Accessing, retrieving and handling data

Depending on the origin and content, this description distinguishes between the following data types:

- Operational data
- Non-operational data

Operational data (data for intended use)

The MXO 5C uses and creates this data because of its intended use and according to the settings and configuration you have made. Thus, this data makes up most of the data that the MXO 5C creates, such as user files that contain user-defined configurations or data, like instrument settings or measurement data.

You can access, retrieve and delete user files, see [Section 13.2, "Save/recall dialog"](#), on page 439.

Non-operational data (usage data)

The MXO 5C creates this data during and through its use. Such data is collected e.g. for troubleshooting, to help our customer support center find solutions quickly.

The MXO 5C does not generate this data continuously and in real-time; this data is saved on the product. You can store the data on a remote server, for example via a network connection.

The MXO 5C generates the following data:

- User and authentication data
- Security and access control
- Network and communication data
- Software and firmware update data
- Diagnostic and troubleshooting data
- Environmental conditions
- Hardware component metadata.

Only when you create a service report, this data is stored in a ZIP file, see [Section 19.4, "Information for technical support"](#), on page 1898. The ZIP file contains files in TXT, XML, LOG, and CSV format, as well as binary database formats for the diagnostic and troubleshooting data. The volume of the non-operational data depends on the usage of the product and typically amounts to about 20 MB.

For additional information on the different memory types of your product and on how to protect sensitive data, see [Section 19.5, "Data security"](#), on page 1899.

13.2 Save/recall dialog

The "Save/recall" dialog provides functions for saving and restoring data.

Access to save settings and data: "Menu" > "Save/recall" > "Save" tab.




Figure 13-1: Save tab

Access to load settings and data: "Menu" > "Save/recall" > "Recall" tab.




Figure 13-2: Recall tab

Using the "Save/recall" dialog, you can store or load various data to files for further usage, analysis and reporting:

- General settings: [Section 13.3, "General and measurement settings: savesets"](#), on page 441
- Waveforms: [Section 13.4, "Waveform data"](#), on page 445
- Reference waveforms: [Section 13.4, "Waveform data"](#), on page 445 and [Section 9.4, "Reference waveforms"](#), on page 241
- Histograms: [Section 13.5, "Histogram data export"](#), on page 461
- Measurement results: [Section 13.6, "Results"](#), on page 464
- Sessions: [Section 13.7, "Sessions"](#), on page 466
- Screenshots: [Section 13.8, "Screenshots"](#), on page 469
- Decode results of serial buses: [Section 14.1.7, "Export protocol results"](#), on page 490

The [Camera] key can be configured to save or set up screenshots.

Storage locations

You can store data locally, or to a USB flash drive. For local storage, the path is always `/home/storage/userData`. The path has subdirectories to organize the data. For storage on USB flash drive, the default path is `/run/media/usb/<MyDriveName>/`. On both storage media, you can create directories to organize the data. You can also copy, paste and delete data.

On USB flash drives, the following file systems are supported: FAT32, FAT16, exFAT and NTFS.



The operating system differentiates between relative and absolute paths.

A relative path starts with your current directory and does not start with a /, e.g. `userData`.

An absolute path defines the location from the root directory, e.g. `/home/storage/userData`.

13.3 General and measurement settings: savesets

To repeat measurements at different times or perform similar measurements with different test data, you can save the used settings and load them again later. Furthermore, you can refer to the settings of a particular measurement when analyzing the results. Optionally, the current toolbar and dialog configuration can be included into the save-set.

Access: "Menu" > "Save/recall" > "Save" tab > "Saveset".

If you often save and load settings, try the following shortcuts:

- The "Save setup" toolbar icon saves the current settings to a file according to the settings in "Save/recall" > "Save".
- The "Recall" toolbar icon opens the dialog to select and load a setup.
- You can assign a saveset to the [Preset] key and the "Preset" function on the toolbar.

See [Section 5.6, "Preset setup"](#), on page 106.

13.3.1 Using savesets

Savesets contain the complete general and measurement configuration. You can save an unlimited number of setting files.

To save settings to a saveset file

1. Open "Menu" > "Save/recall".
2. In the "Save" tab, tap the "Saveset" button.
The save "Saveset" dialog opens.




Figure 13-3: Save saveset dialog

3. If needed, enable "Toolbar, color and diagram settings".
4. Check the path on the "<Folder>" button. If the path does not fit, tap the button. Navigate to the folder, where you want to save the settings file.
5. Tap "Save to file".
Alternatively, select "Save As" and select the destination folder and file name in the file selection dialog.

The current settings are saved to the selected file.

To load settings from a saveset file

1. Open "Menu" > "Save/recall".
2. In the "Recall" tab, press the "Saveset" button.

The recall "Saveset" dialog opens.




Figure 13-4: Recall saveset dialog

3. Tap "Open".
4. Navigate to the required saveset.

The saved settings are loaded to the MXO 5C.

Remote commands:

- [SAVeset:CONFig:UPReferences](#) on page 1104
- [MMEMory:SAV](#) on page 1102
- [MMEMory:RCL](#) on page 1103

13.3.2 Waveform generator saveset

Generator savesets store the instruments generator configuration.

To save settings to a saveset file

1. Open "Menu" > "Save/recall".
2. In the "Save" tab, press the "Generator" button.
The save "Gen saveset" dialog opens.




Figure 13-5: Save generator saveset dialog

3. Tap "Browse"

The current settings are saved to the selected file.

To load settings from a saveset file

1. Open "Menu" > "Save/recall".
2. In the "Recall" tab, press the "Generator" button.

The recall "Gen saveset" dialog opens.




Figure 13-6: Recall generator saveset dialog

3. Tap "Open".

4. Navigate to the saveset.

The saved settings are loaded to the MXO 5C.

Remote commands:

- [GENerator:SAV](#) on page 1105
- [GENerator:RCL](#) on page 1104

13.4 Waveform data

You can save waveform data to files, and reload the data of REF files as reference waveforms.

13.4.1 Save waveforms: settings

Access: "Menu" > "Save/recall" > "Save" tab > "Waveform".

In this dialog, you define the storage settings for waveform data.

Save/recall

Back

Save waveform

Stores one or more selected waveforms. Can be recalled as reference waveform.

Source

C1

▼

Multi waveform

Off

Export mode

Manual

▼

Start

10 ms

Stop

10 ms

▼

Waveforms

File name base

Waveform

Extension

*.ref

▼

Save

Save as

Figure 13-7: Save a single waveform




Figure 13-8: Save multiple waveforms

Source

Selects the waveform to be exported with single waveform export. The list shows all active waveforms that are available for export.

Analog and digital channels, math and reference waveforms, tracks and spectrum traces can be exported.

Remote command:

[EXPort:WAVeform:SOURce](#) on page 1108

Multi waveform

If set to "On", you can export several waveforms at once. Use [Select sources](#) to define the waveforms for data export. The following export formats are supported:


- REF files: One REF file per waveform is created. All REF files are combined in a ZIP file.
- HDF5 files: All data are written in one .h5 file.
- CSV files: Multiple analog channels can be saved in one CSV file. Other waveform types are not supported.

For details, see [Section 13.4.3, "Waveform export files"](#), on page 452.

Select sources

The selection dialog provides all active waveforms. You can select or deselect all available waveforms at once with "All on" or "All off" on top of the dialog. You can also select or deselect all waveforms of a waveform group, using the button to the right of the group.

Analog and digital channels, math and reference waveforms, tracks and spectrum traces can be exported. Note that in CSV files, only multiple analog channels can be saved.



Remote command:

[EXPort:WAVeform:SOURce](#) on page 1108

Export mode

Defines the part of the waveform record that has to be stored.

"Display"	Saves the waveform data that is displayed in the diagram.
"All data"	Saves the complete waveform record.
"Cursor"	Saves the data between the cursor lines if at least one cursor measurement is defined for the source waveform. If several cursor sets are defined, select the "Cursor set" to be used for export.
"Gate"	Saves the data included in the measurement gate if a gated measurement is defined for the source waveform. Select the "Gate" to be used for export.
"Manual"	Saves the data between user-defined "Start" and "Stop" values.

Remote command:

[EXPort:WAVeform:SCOPE](#) on page 1107

[EXPort:WAVeform:CURSOrset](#) on page 1106

[EXPort:WAVeform:GATE](#) on page 1106

[EXPort:WAVeform:START](#) on page 1109

[EXPort:WAVeform:STOP](#) on page 1109

Save settings

You define the details of the filename, extension and directory, and save the file.

A progress bar informs you about the process.

<Folder> ← Save settings

Opens a file explorer where you can select the directory where the file is saved.

The setting is used for automatic saving actions, for example, saving on trigger or mask violation. It has **no** effect on [EXPort:WAVeform:SAVE](#).

Remote command:

[EXPort:WAVeform:AUTonaming:PATH](#) on page 1106

File name base ← Save settings

Sets a name for the file, without extension. The name is extended with a time stamp when the file is saved. Thus, multiple "Save" actions are possible without changing the filename.

The setting is used for automatic saving actions, for example, saving on trigger or mask violation. It has **no** effect on [EXPort:WAVeform:SAVE](#).

Remote command:

[EXPort:WAVeform:AUTonaming:NAME](#) on page 1105

File extension ← Save settings

Selects the format of the exported file.

You can select between "*.csv" (Excel format), "*.ref" (Reference Waveform Format) and "*.h5" (HDF5 format). REF files can be reloaded as reference waveforms. See: [Section 13.4.3, "Waveform export files"](#), on page 452. If you have selected multiple waveforms other than analog channels, CSV is not available.

The setting is used for automatic saving actions, for example, saving on trigger or mask violation. It has **no** effect on [EXPort:WAVeform:SAVE](#).

Remote command:

[EXPort:WAVeform:AUTonaming:TYPE](#) on page 1106

Save ← Save settings

Saves the file in the defined folder using the "File name base". If the specified file already exists, it is overwritten with the new data.

Save As ← Save settings

Opens a file explorer where you select the folder, the file type, enter the filename and save the file.

Remote command:

[EXPort:WAVeform:NAME](#) on page 1107

[EXPort:WAVeform:SAVE](#) on page 1107

13.4.2 Saving waveforms

To save a single waveform

1. Open "Menu" > "Save/recall".
2. On the "Save" tab, tap "Waveform".




Figure 13-9: Save waveform dialog

3. Select the "Source".
4. Select the "Export mode" to define the exported part of the waveform.
5. If necessary, define the cursor, gate or start/stop values for the data.
6. Select the format of the export file: "File extension".
7. Set the "File name base".
8. Tap "Save" or "Save As".

The selected waveform is saved to the specified file. A progress bar informs you about the saving process.

To save multiple waveforms

1. Open "Menu" > "Save/recall".
2. In the "Save" tab, tap "Waveform".
3. Enable "Multi waveform"





Figure 13-10: Save multiple waveforms dialog

4. Tap "Select sources".
5. Select the waveforms for export.



6. Tap "Back".
7. Select the "Export mode" to define the exported part of the waveform.
8. If necessary, define the cursor, gate or start/stop values for the data.
9. Select the format of the export file: "File extension".
10. Set the "File name base".
11. Tap "Save" or "Save As".

The selected waveforms are saved to the specified file. A progress bar informs you about the saving process.

13.4.3 Waveform export files

You can store the waveform data in several formats:

- CSV (comma-separated values): ASCII-based format, easy access with Excel or text tools. See [Section 13.4.3.1, "CSV files"](#), on page 452.
- REF (reference waveform): binary data with XML header, can be reloaded as reference waveforms. See [Section 13.4.3.2, "REF files"](#), on page 456.
- HDF5 (.h5): binary container format for external processing of waveform data.

13.4.3.1 CSV files

A CSV file is a comma-separated values (CSV) text file, the waveform is stored in a table. The values are separated by commas.

You can convert the comma-separated text to columns. If you convert the data, take care of the correct number conversion, depending on the tool in use.

Content of waveform files

Header and data are written into one file. The first lines of the file contain header data, for example, time scale, vertical scale, vertical and horizontal positions. Header data is required to interpret the waveform data, and to analyze the data values of the data file.

Below the header, the waveform data follows. For each sample, one line is written. The first value is the X-value (time or frequency), the next is the Y-value in the unit indicated in the header data. For envelope or peak detect waveforms, two Y-values (minimum and maximum) are written for each sample.

	A	B	C	D	E	F
1	Model,MXO54					
2	SerialNumber,101416					
3	,					
4	SourceType,CHANNEL_TRACE					
5	SignalSource,Ch1Wfm1					
6	Resolution,2e-10					
7	RecordLength,1000					
8	HWRecordLength,1000					
9	HorizontalPosition,0					
10	TraceArithmetics,SINGLE					
11	BaseUnit,LEVEL_V					
12	BaseUnitRelative,OFF					
13	Impedance,50					
14	UserTermination,1M_OHM					
15	XStart,-1.0000000000000001e-07					
16	XStop,1.0000000000000001e-07					
17	TimebaseScale,2e-08					
37	TIME,C1					
38	-1e-07,0.0031761544099682382					
39	-9.98e-08,0.002565355484974346					
40	-9.959999999999999e-08,0.000977278279990227					
41	-9.939999999999999e-08,0.0008551184949914487					
42	-9.919999999999999e-08,0.00036647935499633513					
43	-9.899999999999999e-08,-0.0010994380649890054					
44	-9.879999999999998e-08,-0.0018323967749816759					
45	-9.859999999999998e-08,-0.0020767163449792324					
46	-9.839999999999998e-08,-0.002321035914976789					
47	-9.819999999999998e-08,-0.001954556559980454					
48	-9.799999999999998e-08,-0.0008551184949914487					

Figure 13-11: CSV file of a time waveform, opened in Excel

	A	B	C	D	E
1	Model,MXO54				
2	SerialNumber,101416				
3	,				
4	SourceType,SPECTRUM				
5	SignalSource,SPECTRUM1_NORMAL				
6	BaseUnit,LEVEL_V				
7	BaseUnitRelative,OFF				
8	Impedance,50				
9	UserTermination,1M_OHM				
10	VerticalPosition,0				
11	VerticalScale,10				
12	VerticalOffset,-45				
13	BaseYStart,0				
14	BaseYStop,0				
15	ViewUnit,LEVEL_DBM				
16	ViewUnitRelative,OFF				
17	ViewReferenceLevel,0				
18	NumericFormat,DECIMAL				
19	CenterFreq,1000000000.0000001				
20	FreqSpan,2000000000				

33	FREQUENCY,SPECNORM1				
34	-213623.27970552444,-49.02157013180808				
35	549316.1734194754,-49.769556105402145				
36	1312255.6265444753,-53.96493039074978				
37	2075195.079669475,-61.57760265043916				
38	2838134.532794475,-70.19729413316635				
39	3601073.985919475,-73.24404760765583				
40	4364013.439044475,-75.68197528968501				
41	5126952.892169475,-91.81643862397064				

Figure 13-12: CSV file of a spectrum waveform, opened in Excel

If you export multiple analog channels at once, one column per channel is written. For envelope or peak detect waveforms, two values per channel are written.

1	Model	MXO54C						
2	SerialNumber	100864						
3								
4	SourceType	CHANNEL_TRACE		CHANNEL_TRACE		CHANNEL_TRACE		CHANNEL_TRACE
5	SignalSource	Ch1Wfm1		Ch2Wfm1		Ch3Wfm1		Ch4Wfm1
6	Resolution	2.00E-10		2.00E-10		2.00E-10		2.00E-10
7	RecordLength	1000		1000		1000		1000
8	HWRecordLength	1000		1000		1000		1000
9	HorizontalPosition	0		0		0		0
10	TraceArithmetics	ENVELOPE		ENVELOPE		ENVELOPE		ENVELOPE
11	BaseUnit	LEVEL_V		LEVEL_V		LEVEL_V		LEVEL_V
12	BaseUnitRelative	OFF		OFF		OFF		OFF
13	Impedance	50		50		50		50
14	UserTermination	1M_OHM		1M_OHM		1M_OHM		1M_OHM
15	XStart	-1.00E-07		-1.00E-07		-1.00E-07		-1.00E-07
16	XStop	1.00E-07		1.00E-07		1.00E-07		1.00E-07

37	TIME	C1 MAX	C1 MIN	C2 MAX	C2 MIN	C3 MAX	C3 MIN	C4 MAX	C4 MIN
38	-1.00E-07	0.00586367	-0.006352309	0.002565355	-0.005130711	0.003786953	-0.005008551	0.003542634	-0.004275592
39	-9.98E-08	0.008551185	-0.003664794	0.002687515	-0.005252871	0.003542634	-0.004642072	0.003664794	-0.003909113
40	-9.96E-08	0.010750061	-0.000732959	0.003053995	-0.005008551	0.003176154	-0.00561935	0.003420474	-0.004275592
41	-9.94E-08	0.013804056	0.001588077	0.002931835	-0.005252871	0.003298314	-0.005375031	0.003786953	-0.004031273
42	-9.92E-08	0.016247251	0.004519912	0.003053995	-0.005130711	0.003053995	-0.005008551	0.003786953	-0.004764232
43	-9.90E-08	0.019179086	0.007451747	0.002565355	-0.005130711	0.003420474	-0.004764232	0.003909113	-0.004397752
44	-9.88E-08	0.021133643	0.010017102	0.002687515	-0.005130711	0.002931835	-0.004764232	0.004519912	-0.004397752
45	-9.86E-08	0.023576839	0.012582458	0.003420474	-0.004886391	0.003664794	-0.004397752	0.004275592	-0.004519912
46	-9.84E-08	0.025897874	0.015392133	0.003053995	-0.005130711	0.003664794	-0.004397752	0.004153433	-0.004031273

Figure 13-13: CSV file of four analog channels, envelope acquisition mode, opened in Excel and converted to columns

Header data

The header lines contain the following properties, depending on the type of the exported waveform (time or frequency):

Table 13-1: Header file properties in CSV files

Value	Description	Time	Frequency
Model	Model of the instrument	X	X
SerialNumber	Serial number of the instrument	X	X
SourceType	Type of the exported waveform	X	X
SignalSource	Source of the exported waveform	X	X
Resolution	Time between two samples <i>Resolution = 1 / Sample Rate</i>	X	
RecordLength	Number of samples in a waveform record of one acquisition	X	
HWRecordLength	Equivalent to the RecordLength	X	
HorizontalPosition	Horizontal position of the waveform in divisions	X	
TraceArithmetics	Arithmetic of the waveform: off, envelope, or average	X	
BaseUnit	Base unit of a mathematic waveform, for example, linear unit	X	X
BaseUnitRelative	Base unit, if a relative unit (e.g. dB) is enabled	X	X
Impedance	Input impedance, used for power calculation	X	X
UserTermination	User-defined load impedance connected to the probe	X	X
XStart	Horizontal start value of the waveform (time or frequency), as defined in the export settings	X	
XStop	Horizontal stop value of the waveform (time or frequency), as defined in the export settings	X	
TimebaseScale	Horizontal scale in seconds per division	X	
ReferencePoint	Position of the zero point in % of the screen	X	
VerticalPosition	Vertical position of the waveform in divisions	X	X
VerticalScale	Vertical scale of the waveform	X	X
VerticalOffset	Vertical offset of the waveform in Volts, or other unit	X	X
BaseYStart	Vertical start value of the waveform	X	X
BaseYStop	Vertical stop value of the waveform	X	X
ViewUnit	User-selected unit of a waveform, for example, logarithmic unit for a spectrum.	X	X
ViewUnitRelative	Indication of a relative unit. It is true if the ViewUnit implies a reference level, for example dB.	X	X
ViewReferenceLevel	Reference level for a relative unit. The value is only valid if the unit is relative (ViewUnitRelative = ON).	X	X
NumericFormat	Number format of bus values and digital channel data (bit pattern format)	X	X
EnhancementMode	Method to increase the sample rate if the required sample rate is higher than the ADC sample rate.	X	

Value	Description	Time	Frequency
InterpolationMode	Interpolation method. The value is relevant when the enhancement mode is interpolated time.	X	
CenterFreq	Center frequency of the spectrum		X
FreqSpan	Frequency span of the spectrum		X
ResolutionBW	Resolution bandwidth of the spectrum		X
FrequencyStart	Start frequency of the spectrum		X
FrequencyStop	Stop frequency of the spectrum		X
WindowType	Window used for the spectrum computation		X
GateRBWCoupling	Indication whether the record length or the resolution bandwidth is a constant for the spectrum computation		X
XAxisMode	Indicates a linear or logarithmic x-axis		X
HorizontalDivisionCount	Number of horizontal divisions	X	X
VerticalDivisionCount	Number of vertical divisions	X	X
FirmwareVersion	Firmware version that is installed on the MXO 5C	X	X
DecimationMode	Method to reduce the number of data samples to achieve the required sample rate: Sample, peak detect, HiRes, RMS	X	

13.4.3.2 REF files

The REF format is a specific format, which allows you to reload the waveform data as a reference waveform. The data is saved in a zipped file that contains two files per waveform. One file is a binary file (BIN file) and contains the waveform data values. The second file is an XML file and contains the header data in several data groups. Header data is required to reload the waveform from data, or to analyze the data values of the data file.

```

<?xml version="1.0" encoding="UTF-8"?>
<Group Name="SignalExportBase">
  <Group Name="SignalAttributes">
    <Prop Name="SourceType" Value="CHANNEL_TRACE" UserValue="NONE" />
    <Prop Name="SignalSource" Value="Ch1Wfm1" />
    <Prop Name="Resolution" Value="2.0000000000000001e-10" />
    <Prop Name="RecordLength" Value="1000" />
    <Prop Name="HWRecordLength" Value="1000" />
    <Prop Name="HorizontalPosition" Value="0" />
    <Prop Name="TraceArithmetics" Value="SINGLE" UserValue="SINGLE" />
    <Prop Name="BaseUnit" Value="LEVEL_V" UserValue="LEVEL_V" />
    <Prop Name="BaseUnitRelative" Value="OFF" UserValue="OFF" />
    ...
  </Group>
  <Group Name="PostProcessingBufferSampleCounts">
    <Prop Name="DeltaPreSamples" Value="25" />
    <Prop Name="PreSamples" Value="500" />
    <Prop Name="PostSamples" Value="500" />
    <Prop Name="DeltaPostSamples" Value="29" />
  </Group>
</Group>

```

Figure 13-14: Header file in XML format, part of the REF file container

Table 13-2: Header file properties in REF files

Value	Description
SignalAttributes	
Same values as in CSV files, except for Model and SerialNumber. See Table 13-1 .	
SignalAttributesPostProcessing	
SignalFormat	Format of the data values in the BIN file: INT8BIT, INT16BIT, INT32BIT, FLOAT, DOUBLE
Origin	WFM_EXPORT: export of one acquisition or export of multiple acquisitions
ByteOrder	Byte order of the values in the BIN file • LSB first: little endian, least significant byte first • MSB first: big endian, most significant byte first
NumberOfWaveforms	Number of waveforms. always = 1
TimestampState	OFF
Timestamp	Absolute time of the waveform recording in ISO 8601 format
DecimationMode	Method to reduce the number of data samples to achieve the required sample rate
IsMinMax	If ON, then min and max values are saved for each sample. For envelope and peak detect waveforms.
IsComplex	If ON, then two values are saved for each sample (I and Q value).
TriggerOffsetToPostSampleInSec- onds	Offset between the exact trigger position and the first sample after the trigger
SignalRecordLength	Number of samples in the BIN file. If the signal is a spectrum, the value indicates the number of FFT bins. The value can differ from RecordLength and HWRecordLength because the data file has additional samples before and after the record to consider interpolation and other waveform parameters and their dependencies.

Value	Description
SignalXStart	Time of the first sample in the acquired data. Different from XStart because the data file has additional samples before and after the record, and if only part of the data is exported.
SignalXStop	Time of the last sample in the data acquired. Different from XStop because the data file has additional samples before and after the record, and if only part of the data is exported.
AdjustedResolutionBW	Actual resolution bandwidth of a spectrum waveform. Only valid if the exported waveform is a spectrum.
NoiseBandwidth	Noise bandwidth of a spectrum waveform, required for power calculation. Only valid if the exported waveform is a spectrum.
ValuesPerSample	Number of y-values saved at each sampling time. The value is usually 1. The value is 2, if min and max values are saved for each sample, for example, for envelope waveforms.
NofQuantisationLevels	Number of quantization levels of y values
TOADone	If ON, then TriggerOffsetToPostSampleInSeconds is compensated.
SignalResolution	Time between two samples in this waveform. The value can differ from Resolution if the source is, for example, a spectrum. The value is determined automatically considering the waveform parameters and their dependencies. If the signal is a spectrum, the value indicates the frequency range of FFT bins.
HorizontalDomain	Domain of the x-axis (time or frequency)
PostProcessingVerticalAxisAttributes	
Range	Range of the signal in y-direction
Offset	Center of the y-range
Resolution	Resolution of the y-axis
IsLogarithmic	Indicates if the y-axis is logarithmic (ON or OFF)
PostProcessingSampleFormatAttributes	
ValueStorage	Interpretation of the data: is integer or float (floating point data)
ValueInterpretation	Indicates if the data is saved as binary ADC values (BINARY), or physical values (PHYSICAL)
SampleBitSize	Value size in bit, as used in processing
ValueBitSize	Value size of ADC data in bit
LsbExtensionBits	Number of bits the ADC value is shifted to the left in the CPU sample size
AdcValueBitSize	Number of bits of the ADC that was used to sample the signal. It does not include any additionally gained bits due to high definition mode.
IsSigned	Signed values (ON) or unsigned values (OFF)

Value	Description
PostProcessingBufferSampleCounts	
[DeltaPreSamples PreSamples PostSamples DeltaPostSamples]	Indicates the distribution of the samples. marks the trigger time. The sum of PreSamples and PostSamples matches the requested record length. DeltaSamples are additional samples that are needed for computation but they are not measured or displayed.




Figure 13-15: Main header properties at the waveform

Note: FractionalBits was removed in FW version 1.3.x. Reference waveforms created with older FW versions are compatible and can be reloaded.

13.4.3.3 HDF5 files

An HDF5 (.h5) file is a container format that contains attributes and waveform data. The format can be read by different programming languages with existing libraries. HDF5 stores binary data, thus the file size is smaller than CSV files.

Use the HDF5 format to export data from the MXO 5C and analyze the waveforms with external software.

You can save one or more waveforms in one HDF5 file.

The HDF5 file consists of several groups in a hierarchical structure. The data samples are float32 values of the physical values. No conversion is needed. For envelope and peak detect waveforms, two Y-values are written for each sample ("min" and "max").

Table 13-3: Contents and structure of the HDF5 file

Group	Subgroup	Attribute, example values, data	Description
/FileType			Type of the HDF5 file.
		Rohde&Schwarz: "MXO"	Instrument family.
		Version: "1.0"	Version of the HDF5 format.

Group	Subgroup	Attribute, example values, data		Description
/Frame				Export information.
		DateTime: "<ISO time stamp>"		Date and time of the file export.
		FirmwareVersion: "2.5.0.60"		Version of the instrument firmware.
		Model: "MXO44"		Instrument model.
		SerialNumber: "100000"		Serial number of the exporting instrument.
/Waveforms				Attributes and data.
	/Waveforms/C1			One subgroup for each waveform.
		Count: 1		Number of acquisitions, always = 1.
		NumPoints: 1000		Number of exported samples (record length of the exported waveform).
		XInc: 2e-10		Resolution, the time between two samples.
		XOrg: -1.0e-7		Horizontal start value of the waveform, time of the first sample.
		XUnit: "Time"		Unit of the horizontal axis (Time, Frequency).
		YUnit: "V"		Unit of the vertical axis.
		/Waveforms/C1/C1 Additional Info		Subgroup with further information. See "Additional info (/Waveforms/C1/C1 Additional Info)" on page 460.
		DataSet(/Waveforms/C1/C1 Data)		Data values.
			DateTime: "<ISO time stamp>"	Date and time of the trigger of this acquisition.
			TriggerOffsetToPostSampleInSeconds: 1.1e-12	Offset between the trigger time and the first sample after the trigger, in seconds.
		DataSet(/Waveforms/C1/C1 PreData)		Additional samples before the samples in DataSet, are used to settle the filters.
		DataSet(/Waveforms/C1/C1 PostData)		Additional samples after the samples in DataSet, are used to settle the filters.
	/Waveforms/C2	Analogous to /Waveforms/C1		
	/Waveforms/C3	Analogous to /Waveforms/C1		

Additional info (/Waveforms/C1/C1 Additional Info)

The `/Waveforms/C1/C1 Additional Info` group provides additional information on the waveform, which is not essential to interpret the waveform data. Most of this information is also available in the header of CSV or REF files.

Field	Description	Identical to CSV	Identical to REF
DecimationMode	Method to reduce the number of data samples to achieve the required sample rate.	X	
EnhancementMode	Method to increase the sample rate if the required sample rate is higher than the ADC sample rate.	X	
HorizontalPosition	Horizontal position of the waveform in divisions.	X	
Impedance	Input impedance, used for power calculation.	X	
InterpolationMode	Interpolation method. The value is relevant when the enhancement mode is interpolated time.	X	
Label	Channel label, currently empty.		
NofQuantisationLevels	Number of quantization levels of y values.		X
ReferencePoint	Position of the zero point in % of the screen.	X	
SignalSource	Source of the exported waveform.	X	
SourceType	Type of the exported waveform.		X
TOADone	If ON, then TriggerOffsetToPostSampleInSec-onds is compensated.	X	
TimebaseScale	Horizontal scale in seconds per division.	X	
TraceArithmetics	Arithmetic of the waveform: off, envelope, or average.	X	
UserTermination	User-defined load impedance connected to the probe.	X	
VerticalOffset	Vertical offset of the waveform in Volts, or other unit.	X	
VerticalPosition	Vertical position of the waveform in divisions.	X	
VerticalScale	Vertical scale of the waveform.	X	
XDispOrigin	X value on the left border of the screen.		
XDispRange	X value range that is shown on the screen.		
YDispOrigin	Y value of the bottom border of the screen.		
YDispRange	Y value range that is shown on the screen.		
YInc	Value of the quantization level of the Y values.		

13.5 Histogram data export

You can export the data of waveform histograms to file.

13.5.1 Histogram export files

Data of histograms is saved to one CSV file, which starts with header data followed by normalized or absolute histogram values.

The header has the following information:

- Name of the histogram
- Source waveform of the histogram
- Histogram mode: vertical or horizontal
- Normalization on or off
 - On: Data values are float values that represent the ratio of samples in a given bin to the sum of all samples. The sum of all normalized values is 1.
 - Off: Data values are integer values that represent the number of samples in a given bin.
- Histogram range: start and end values.
 - Vertical histograms: the values are given in the unit of the vertical axis
 - Horizontal histograms: the unit is s.

Example of file content

Table 13-4: Content of histogram CSV file

Normalization on	Normalization off	Number of the data row for value calculation
HistogramName,Hist1	HistogramName,Hist1	
HistogramSource,Ch1Wfm1	HistogramSource,Ch1Wfm1	
HistogramType,VERTICAL	HistogramType,VERTICAL	
Normalization,OFF	Normalization,ON	
HistogramStart,-0.25024431956999754	HistogramStart,-0.25024431956999754	
HistogramEnd,0.25012215978499874	HistogramEnd,0.25012215978499874	
,	,	
,	,	
,	,	
DATA	DATA	
0	0	1
0	0	2
100	0.1	3
800	0.8	4
100	0.1	5
0	0	6
0	0	7
0	0	8

Data conversion

Using the header data, you can calculate the waveform value to which a histogram value belongs. The calculation is valid for vertical and horizontal histograms.

A histogram bin covers a domain of this width:

$$\text{BinWidth} = (\text{HistogramStart} - \text{HistogramEnd}) / \text{NumberOfHistogramBins}$$

BinIndex is the index of the histogram bin of interest, starting with 1. It is the number of the DATA row in the CSV file.

The center value corresponding to a histogram bin is:

$$\text{Value} = (\text{HistogramStart} - \text{HistogramEnd}) * (\text{BinIndex} - 0.5) / \text{NumberOfHistogramBins} + \text{HistogramStart}$$

The domain covered by the histogram bin is: $\text{Value} \pm 0.5 * \text{BinWidth}$.

For the example in [Table 13-4](#), the voltage value that corresponds to the histogram value 800 or 0.8 (histogram bin number 4) is:

$$(0.25 - (-0.25)) * (4 - 0.5) / 8 - 0.25 = -0.03125 \text{ V}$$


The bin width in this example is $(0.25 - (-0.25)) / 8 = 0.0625 \text{ V}$.

The 4th bin with value 800 covers a voltage domain of

$$-0.03125 + 0.5 * 0.0625 = 0 \text{ V} \quad \text{to} \quad -0.03125 - 0.5 * 0.0625 = -0.0625 \text{ V}$$

13.5.2 Settings for histogram export

Access: "Menu" > "Save/recall" > "Save" tab > "Histogram".



Select histogram

Select the histogram that you want to save.

Normalization

If normalization is off, the number of samples in a given bin is exported as integer values. With normalization, the ratio of samples in a given bin to the sum of all samples is exported as float value. The sum of all normalized values is 1.

Remote command:

[EXPort:HISTogram<m>:NORMalize](#) on page 1110

Source, X, Y

Show the basic settings of the selected histogram for information: waveform source, start and end values on the x and y-axis.

Save settings

Define the filename and storage location, and start the saving process.

"<Folder>"	Opens a file explorer where you can select the directory where the file is saved.
"File name base"	Sets a name for the file, without extension. The name is extended with a time stamp when the file is saved. Thus, multiple "Save" actions are possible without changing the filename.
"File extension"	The format of the histogram file is always .CSV.
"Save"	Saves the file in the defined folder using the "File name base". If the specified file already exists, it is overwritten with the new data.
"Save As"	Opens a file explorer where you select the folder, the file type, enter the filename and save the file.

A progress bar informs you about the process.


Remote command:

[EXPort:HISTogram<m>:NAME](#) on page 1111

[EXPort:HISTogram<m>:SAVE](#) on page 1111

13.6 Results

You can select the result tables to be saved, and define the storage settings.



To save results

1. Open "Menu" > "Save/recall".
2. In the "Save" tab, press the "Results" button.
The save "Results" dialog opens.
3. Select the results to be saved. The "Save results" results list shows all result tables that are currently open. All results are written into one file.
4. Under "Location", enter a "File name base" and select "Save". Alternatively, select "Save As" and define the target directory and file name in the file selection dialog.
The current results are saved to the selected file.

Remote commands:

- [EXPort:RESult:SElect:CURSor](#) on page 1113
- [EXPort:RESult:SElect:MEASurement](#) on page 1114
- [EXPort:RESult:NAME](#) on page 1113
- [EXPort:RESult:SAVE](#) on page 1113

13.7 Sessions

Sessions store the general and measurement settings and the data of active channel waveforms and reference waveforms together in a ZIP file. The user-specific display settings for the toolbar, waveform colors and diagrams can also be included.

13.7.1 Save a session

Access: "Menu" > "Save/recall" > "Save" tab > "Session"

The session file includes active channel and reference waveforms and the current measurement setup. Before saving the session, consider where you want to use the session data.

- In R&S ScopeStudio, included waveforms and settings can be recalled. If both analog and digital channels are active, only digital channels are saved in the session file and can be loaded.
- When recalling on an MXO oscilloscope, channel waveforms are not imported. Therefore, if you want to recall the session on an instrument, save channel waveforms as references and change the sources of analysis functions to these references before saving the session.




Figure 13-16: Save session dialog

Toolbar, color and diagram settings

If selected, the user-specific display settings for the toolbar, waveform colors and diagram settings are included in the session file.

Remote command:

[SESSion:USERpref](#) on page 1113

Channel waveforms

Select if you want to include channel waveform data in the session file.

Remote command:

[SESSion:SAVE:CHANnel](#) on page 1112

Reference waveforms

Select if you want to include reference waveform data in the session file.

Remote command:

[SESSion:SAVE:REFerence](#) on page 1112

Save settings

Defines the filename and storage location.

"<Folder>"	Opens a file explorer where you can select the directory where the file is saved.
"File name base"	Sets a name for the file, without extension. The name is extended with a time stamp when the file is saved. Thus, multiple "Save" actions are possible without changing the filename.
"File extension"	The format of the session file is always .zip.
"Save"	Saves the file in the defined folder using the "File name base". If the specified file already exists, it is overwritten with the new data.
"Save As"	Opens a file explorer where you select the folder, the file type, enter the filename and save the file.

A progress bar informs you about the process.

Remote command:

[SESSion:SAVE\[:EXECute\]](#) on page 1112

[SESSion:SAVE:ABORt](#) on page 1112

13.7.2 Load a session

Access: "Menu" > "Save/recall" > "Recall" tab > "Session"

When you recall a session, the settings and the reference waveforms (if included in the session file) are restored. You can also restore some user-specific display settings: toolbar, waveform colors, and diagram settings. Channel waveforms are not imported even if they are included in the session file. Therefore, save channel waveforms as references and change the sources of analysis functions to these references before saving the session.




Figure 13-17: Recall session dialog

Toolbar, color and diagram settings

If selected, the user-specific display settings for the toolbar, waveform colors and diagram settings are included in the session file.

Remote command:

[SESSion:USERpref](#) on page 1113

Open

Opens the file browser dialog. Select the required session file and tap "Open".

Remote command:

[SESSion:LOAD\[:EXECute\]](#) on page 1111

13.8 Screenshots

To store the graphical results of the measurement, you can save a screenshot of the graphic area. To document current settings, the open dialog box can be included in the screenshot.

If you often save screenshots, try the following shortcuts:

- The "Screenshot" toolbar icon saves the current display to a file according to the settings in "Menu" > "Save/recall" > "Save" tab > "Screenshot".
- You can configure the [Camera] key to save screenshots by a single keypress. See also "[Camera hardkey action](#)" on page 105.

If a USB flash drive is connected, the default path of the user data directory is set to the USB flash drive. Thus, you save data to USB flash drive automatically, and you can change the directory in the file explorer at any time.

Screenshots on a computer using the Web interface

If the MXO 5C is connected to a LAN, you can create and save screenshots of the instrument's display on a computer. See [Section 17.3.2.3, "Web control"](#), on page 893.

Meta information in screenshots

The metadata of the screenshot also contains instrument information. In PNG and JPEG files, meta information is saved as EXIF information and can be read, for example, using the ExifTool.

Example:

Reading meta information using the ExifTool.


Command: # `exif C:\Screenshot_2020-07-14_0_110551.png`

Result:

```
ExifTool Version Number      : 10.20
File Name                    : Screenshot_2016-07-14_0_110551.png
Directory                   : C:/
File Size                    : 37 kB
File Modification Date/Time  : 2020:07:14 11:05:51+02:00
File Access Date/Time       : 2020:07:14 11:05:51+02:00
File Creation Date/Time     : 2020:07:14 11:05:51+02:00
...
Instrument Firmware Version  : 3.30.0.46
Instrument Material Number   : 1329.7002k44
Instrument Serial Number     : 123456
Image Size                  : 1280x800
Megapixels                  : 1.0
```

13.8.1 Screenshot settings

Access: "Menu" > "Save/recall" > "Save" tab > "Screenshot"



In the "Screenshot" dialog box, you configure the image to be saved or included in a report. You select the storage location for screenshot files. The image is created when you open the dialog box, and can be updated at any time.

You can also edit the colors of the image before saving it, and include an open dialog box or the sidebar in the image.

Preview.....	472
Update.....	472
Show setup dialog.....	472
White background.....	472
Include signal bar.....	472
Inverse color.....	472
Save settings.....	472
L <Folder>.....	473
L File name base.....	473

L	File extension	473
L	Save	473
L	Save As	473

Preview

Shows a preview of the screenshot. The image is created when the dialog box opens.

Update

Updates the preview of the screenshot with the current display view, e.g. after changes to the settings have been made, or an additional channel has been activated.

Show setup dialog

If enabled, the currently open dialog box is included in the screenshot.

Remote command:

[HCOPY:SSD](#) on page 1116

White background

Inverts the background color, so you can picture waveforms with normal waveform colors on white background.

If both "White background" and "Inverse color" are enabled, the background is inverted twice, and it appears black.

"White background"	"Inverse color"	Background	Waveform and results
On	Off	White	Screen colors
Off	On	White	Inverted colors
On	On	Black	Inverted colors
Off	Off	Black	Screen colors

Remote command:

[HCOPY:WBKG](#) on page 1117

Include signal bar

If enabled, the screenshot shows the signal bar below the diagram area.

Remote command:

[HCOPY:ISBA](#) on page 1116

Inverse color

Inverts the colors of the output, i.e. a dark waveform is shown on a white background.

Remote command:

[HCOPY:DEVIce<m>:INVerse](#) on page 1115

Save settings

You define the details of the filename, extension and directory, and save the screenshot.

A progress bar informs you about the process.

<Folder> ← Save settings

Opens a file explorer where you can select the directory where the file is saved.

The setting is used for automatic saving actions, for example, saving on trigger or mask violation.

Remote command:

[HCOPY:DESTination<m>](#) on page 1114

File name base ← Save settings

Sets a name for the file, without extension. The name is extended with a time stamp when the file is saved. Thus, multiple "Save" actions are possible without changing the filename.

The setting is used for automatic saving actions, for example, saving on trigger or mask violation.

Remote command:

[MMEMory:NAME](#) on page 1115

File extension ← Save settings

Selects the format of the exported file.

You can save the screenshot as *.jpg or *.png file.

The setting is used for automatic saving actions, for example, saving on trigger or mask violation.

Remote command:

[HCOPY:DEvice<m>:LANGuage](#) on page 1115

Save ← Save settings

Saves the file in the defined folder using the "File name base". If the specified file already exists, it is overwritten with the new data.

Remote command:

[HCOPY:IMMediate<m>:NEXT](#) on page 1115

[HCOPY:IMMediate<m>](#) on page 1116

Save As ← Save settings

Opens a file explorer where you select the folder, the file type, enter the filename and save the file.

13.8.2 Configuring and saving screenshots

You can select which elements are shown in the screenshot, invert the colors and the background color. A preview of the current image is shown for reference.

1. Open the "Menu" > "Save/recall" > "Save" tab > "Screenshot".
2. To enhance the images for later print on white paper, enable "White background" or "Inverse color". If you print this image later on a monochrome printer, you get a grayscale picture. The contrast of the gray lines depends on waveform colors and the printer used.

3. To change the directory, tap "<Folder>", and configure the path.

The symbols of often used target folders are listed on the left of the file explorer. By default, screenshots are saved in the `/home/storage/userData/ScreenShots` directory.

4. Select the "File extension".

5. Tap "Save".

The file is saved with an automatic name in the specified folder.

6. To save further screenshots, use one of the following ways:

- Configure the [Camera] key. Press the key to save a screenshot. See also [Camera hardkey action](#).
- Add the "Screenshot" icon to the toolbar. Tap the icon to save an image. See [Section 4.6.2, "Configuring the toolbar"](#), on page 62.
- Tap "Save" in the "Screenshot" dialog. The filename contains a number, which is automatically counted up.
- To save the image with a dedicated filename or to another directory, tap "Save As" in the "Screenshot" dialog. Select the path, enter a filename, and tap "Save".

13.8.3 Image viewer

You can look at the saved screenshots directly, without transferring them to a computer or using a dedicated software.


1. Add the "Image viewer" icon to the toolbar.
2. To view the saved screenshots, select the icon.

You can scroll the images, browse in other folders, and use the "Auto play" function for viewing.

13.9 File browser dialog

The file browser dialog provides a file explorer from which you can select a file to load or to save data to. You can also manage your files in this dialog.

Access: "Menu" > "Apps" > "File browser".



Path

Navigate the path elements to change the current folder. The default folder is defined in [Section 5.8.1, "Autonaming"](#), on page 114.

You can save the data in a local folder, to an external storage device (usually a USB flash drive), or to a folder on a connected network drive. The path list provides all available drives and folders.

On the left, shortcut icons provide access to often used folders.

Toolbar

The toolbar on the top provides various functions for file management.

"Filter"	Displays only the files and folders that match the current search term.
"Delete"	Deletes the selected file or folder.
"New folder"	Creates new folder in the current directory.
"Rename"	Renames the selected file.
"Find"	Searches for files within the current folder.
"Copy"	Copies the selected file.
"Paste"	Pastes the file.

File name

The file name to be loaded or stored to. Tap the file name, or tap the keyboard icon to enter the file name using the online keyboard.

The default file name for new files is defined in the "Autonaming" tab, see [Section 5.8.1, "Autonaming"](#), on page 114.

File type

The file extension of the file to be loaded or stored to.

Save, Select

Selects the specified file for the open or save operation and closes the dialog box.

Cancel

Closes the dialog box without selecting a file.

14 Protocol analysis

Using the serial protocol options for the MXO 5C, you can analyze various serial protocols.



• Basics of protocol analysis.....	477
• SPI bus (IC electronics, option R&S MXO5C-K510).....	492
• QUAD-SPI bus (IC electronics, option R&S MXO5C-K510).....	510
• I ² C (IC electronics, option R&S MXO5C-K510).....	529
• I3C (IC electronics, option R&S MXO5C-K550).....	551
• UART (IC electronics, option R&S MXO5C-K510).....	568
• NRZ clocked & unclocked (option R&S MXO5C-K510).....	584
• Manchester (option R&S MXO5C-K510).....	609
• CAN (automotive electronics, option R&S MXO5C-K520).....	635
• LIN (automotive electronics, option R&S MXO5C-K520).....	666
• SENT (automotive electronics, option R&S MXO5C-K520).....	683
• ARINC 429 (aerospace electronics, option R&S MXO5C-K530).....	703
• SpaceWire (aerospace communications, option R&S MXO5C-K530).....	716
• MIL-1553 (aerospace electronics, option R&S MXO5C-K530).....	729
• SPMI (mobile electronics, option R&S MXO5C-K550).....	744
• RFFE (mobile electronics, option R&S MXO5C-K550).....	758
• 10BASE-T1S (automotive Ethernet, option R&S MXO5C-K560).....	775
• 100BASE-T1 (automotive Ethernet, option R&S MXO5C-K560).....	791
• 1000BASE-T1 (automotive Ethernet, option R&S MXO5C-K560).....	804
• USB 1.1 (option R&S MXO5C-K570).....	820
• USB 2.0 (option R&S MXO5C-K570).....	838

14.1 Basics of protocol analysis

With the MXO 5C oscilloscope, you can decode selected protocols.

With dual-path protocol analysis, you can set the instrument sample rate for the waveform path and the oscilloscope automatically uses another internal decoupled sample rate for the decoding path. Even with very slow sample rates, the protocol data is correctly decoded.

With the MXO 5C, you can use deep memory to capture more packets. The oscilloscope can capture long time periods where the cause and result are distanced in time. Over the entire capture, signal detail is time-correlated with packet content for fast debug.

Before you can analyze a serial signal, the bus has to be configured according to the protocol and specifics of the signal. The configuration contains:


- Assignment of the data and clock lines to the input channels
- Logical thresholds
- Protocol-specific settings

Serial data can be analyzed in several ways:

- Triggering: You can trigger on various events that are typical for the selected protocol type, for example, on start and stop of messages, or on specified data patterns in the message.
Triggering on a trigger event sequence is not supported, and holdoff settings are not available.
- Protocol decoding: The digitized signal data is displayed on the screen together with the decoded content of the messages in readable form, and the decode results are listed in a table.

14.1.1 Setup - general settings

For all protocols, configuration starts with the selection of the serial bus and the protocol.



Configuration settings are protocol-specific. They are described in the related sections.



Make sure that the tab of the correct serial bus is selected.

SB1 /SB2 /SB3 /SB4

Select the correct bus tab before you enter the settings.

+ Add serial bus, 🗑 Delete serial bus

Use the icons on the upper right to add a new bus, or to delete the selected serial bus.

Remote command:

[SBUS<sb>:RMSBus](#) on page 1324 (delete)

Protocol type

Selects the protocol type to be decoded.

Remote command:

[SBUS<sb>:TYPE](#) on page 1322

State


Enables the decoding of the selected bus. The signal icon of the bus appears on the signal bar.

Remote command:

[SBUS<sb>\[:STATe\]](#) on page 1322

14.1.2 Thresholds

In the "Thresholds" tab, you can set values for the threshold and hysteresis of the signal.

**Show threshold lines**

Enables the display of the threshold lines in the diagram.

The label of the threshold line is set according to the signal that it is referring to. It is displayed in the color of the signal channel.

Example:

When you enable "Show threshold lines", the threshold lines are shown on the display, and also the hysteresis ranges are shown for a few seconds. Afterwards only the threshold lines are visible. When you click the diagram near or on a threshold line, its hysteresis is shown again briefly.




Figure 14-1: Threshold lines, shortly after enabling Show threshold lines

Remote command:
[SBUS<sb>:THReshold](#) on page 1325


14.1.3 Display

The following subsections describe the display settings and its zoom-coupling features.

- [Display settings](#).....480
- [Display synchronization](#).....482

14.1.3.1 Display settings

For all protocols, you can select how to display the decoded signal and its results table along with the waveform diagram.



Show decode table

Opens a table with decoded data of the serial signal. The function requires the option for the analyzed protocol.

Decode results are protocol-specific.

Remote command:

`SBUS<sb>:REsult` on page 1324

Decode layer

Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display.

The available values are protocol-specific. For example:

"Off"	Disables the display of the decode layer.
"Edges"	Enables the display of all edges.
"Bits"	Enables the display of all bits.
"Words"	Enables the display of all words.

Data format

Sets the data format for the values displayed in the decode table and in the combs of the decoded signal.

Available formats are: hex, octal, binary, ASCii, signed, unsigned.

For more information on the available formats, see [Section 14.1.8, "Bit pattern editor"](#), on page 491.

Remote command:

`SBUS<sb>:FORMat` on page 1323

Zoom coupling

Available only, if [Show decode table](#) is enabled. If you enable "Zoom coupling", the software synchronizes the decode zoom window with the result tables, as described in [Section 14.1.3.2, "Display synchronization"](#), on page 482.

Remote command:

`SBUS<sb>:ZCOupling` on page 1325

Symbols

Symbol lists are protocol-specific and not available for all protocols. Symbols are described in the respective configuration section of the protocol. For finding symbols in the decode table, enable ""Show symbols"". See also [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The RC commands for this function are also protocol-specific, for example in the I²C protocol: `SBUS<sb>:I2C:SYMBols` enables symbols, and `SBUS<sb>:I2C:NEWList` loads the symbols translation file.

14.1.3.2 Display synchronization

This section describes the synchronization (or coupling) of the following components in the display:

- The waveform diagram and its zoom window
- Decode results table with decoded frames
- Frame details table with fields of selected frame




Figure 14-2: Main components in the decoded results display, here for the CAN protocol

- 1 = Waveform diagram, it shows an overview of some part of the acquisition, or even all of it
- 2 = Zoom window, it shows the zoom area selected in the waveform diagram
- 3 = Decode results table, it lists all frames of the acquisition
- 4 = Frame details table, it lists all fields of the frame selected in the results table

Prerequisites for synchronizing displayed results:

- [State](#) is enabled in the "Setup" tab
- [Show decode table](#) is enabled in the "Display" tab
- [Zoom coupling](#) is enabled in the "Display" tab
- Decoded results are available.
The dialog shows the results for frames in the results table and for fields in the details table.

When you select a row in one of the tables, hence a decoded frame or field, the software automatically synchronizes the zoom window to display this frame or field on the screen with a margin at each side. For details of the synchronization and margin, see [Figure 14-3](#) and [Figure 14-4](#). The software synchronizes also the waveform diagram with the zoom window.

When you move the zoom window to the left or right, the software updates the results table to highlight the window's center frame, without resizing.



Figure 14-3: Zoom coupling of selected frame (left table)

Pink arrow = Selected frame covers 90% of the zoom window's width (red scale), centered on the screen
Yellow arrows = Zoom segment, automatically selected in the diagram, covers the full zoom window's width




Figure 14-4: Zoom coupling of selected field (right table)

Pink arrow = Selected field covers 20% of the zoom window's width (red scale), centered on the screen
 Yellow arrows = Zoom segment, automatically selected in the diagram, covers the full zoom window's width

14.1.4 Filter

In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.




The settings are protocol-specific and are described in the corresponding protocol section.

14.1.5 Trigger

The "Trigger" tab provides functionality to quickly setup protocol triggers and navigate to the "Trigger" dialogs for further settings.

A trigger is a function that determines when the instrument starts capturing a signal. There are two primary types of triggers on the MXO 5C, depending on the selected protocol: software trigger and hardware trigger.



14.1.5.1 Hardware trigger

A HW trigger is a trigger that is generated by the oscilloscope's hardware circuitry.

The protocol hardware trigger is available only for the few protocols that support it (listed below). A single click of the "Setup Hardware Trigger" button in the protocol dialog is equivalent with the following actions in the "Trigger" dialog:

1. "Trigger on" > "Single event".
2. "Source" > selects the active serial bus, for example "Serial bus 1".
3. "Type" > selects the most simple protocol-specific trigger type:
 - I²C: "Start"
 - SPI: "Start of frame"
 - UART: "Start bit"
 - LIN: "Start of frame"
 - CAN: "Start of frame"

This action also executes the "Type" command and resets the trigger settings.

Optionally proceed with the trigger settings in the "Trigger" dialog.

14.1.5.2 Software trigger

The protocol software trigger is a sequence "A → Serial bus" of events. Hence, it consists of two subsequent events: A-trigger and a serial bus trigger.



Loss of settings

If you have already configured the SW trigger, do not click "Software Trigger" in the protocol dialog, because it overwrites your settings. Instead, use the "Trigger" dialog.


For an initial configuration, a single click of the "Software Trigger" button is equivalent with the following actions in the "Trigger" dialog:

1. "Trigger on" > "Sequence".
2. "Trigger sequence" > "A → Serial bus"
3. Configures the 1st event:
 - a) Sets the "1st event" ("A trigger") to a protocol-specific trigger that is most suited for this protocol, for example "Edge".
 - b) Sets the "Level" to the threshold level defined in the protocol dialog.
 - c) Sets other parameters, depending on the event type and protocol requirements, for example "Slope" for "Edge", or "Time" for "Timeout".
4. Configures the software trigger:

Preselects recommended frame types and error types, which you can change later.

After the A-trigger conditions have been met, the serial bus trigger with independent conditions is enabled. The oscilloscope waits until one or a specified number of serial bus trigger conditions occur. The serial bus trigger can only cause the trigger event if it occurs after the A-trigger.

All trigger sequences require that analog input channels C<n> are set as trigger sources for all events. The oscilloscope checks all trigger settings for compatibility and adjusts them if they do not fit.



To indicate the 1st (main, general) trigger position in the captured signal, the top of the display shows a triangular trigger marker (1 in Figure 14-5). If you enable displaying the results table (see ["Show decode table"](#) on page 481), the triggered frame is marked in the table by the letter "T" left of the frame index (2 in Figure 14-5):




Figure 14-5: Trigger markers

- 1 = Triangular main trigger marker at the top of the waveform display, indicates the position of the single trigger or the position of the 1st trigger event of a trigger sequence
- 2 = Triangular secondary trigger marker with bold line in the zoom diagram of the decoded signal, indicates the 2nd event trigger position, hence the software trigger
- 3 = Letter "T" marks the 2nd event trigger position (the triggered frame) in the decode results table

The following scenarios are possible:

- 1st case, triggering on a *single event* while the source is a serial bus:
 - The main trigger marker indicates the single event trigger position.
 - There is no secondary trigger marker in the decoded signal diagram.
 - The "T" trigger marker in the protocol decode results table corresponds to the main trigger marker.

This scenario uses the hardware trigger, which is not available for all protocols.
- 2nd case, triggering on a *single event* while the source is *not* a serial bus:
 - The main trigger marker indicates the single event trigger position.
 - There is no secondary trigger marker in the decoded signal diagram.

- There is no "T" trigger marker in the protocol decode results table.
- 3rd case, triggering on a *sequence* of "Trigger A" and "serial bus event":
 - The main trigger marker indicates the 1st event trigger position.
 - The secondary trigger marker indicates the 2nd event trigger position (software trigger).
 - The "T" trigger marker in the protocol decode results table corresponds to the 2nd event trigger position (software trigger).

Figure 14-6 shows an example of these markers.




Figure 14-6: Example of sequence trigger in I2C signal with "Trigger A" (interval > 1 ms) and software trigger (first "Read" frame)

See also "Source" on page 163.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

- "Check all" Enables the filter for all available frames and error types.
- "Clear" Disables the filter for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
- "Preset" Presets the state of the selected frames and error types.

Remote command:

The remote control commands for these functions are protocol-specific. Refer to the descriptions of the software trigger setup for each individual protocol.


14.1.6 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8, "Protocol measurements \(option R&S MXO5C-K500\)"](#), on page 299.

14.1.7 Export protocol results

In the "Export results" tab, you can export the results and all details of the selected protocol.



Include details

If enabled, includes the detailed results for all frames in the export result file.

Remote command:

[SBUS<sb>:EXPResult:DETail](#) on page 1325

Include timing

If enabled, includes the frame timing in the export result file.

Remote command:

[SBUS<sb>:EXPResult:TIME](#) on page 1326

File type

Selects the file format.

"HTML"	Saves the results as a webpage in hypertext markup language for display in a browser.
"CSV"	Saves the results as comma-separated values in a ".csv" file.

"XML" Saves the results in a file compatible with an extended markup language.

"Python" Saves the results in a Python-compatible ".py" file format.

Remote command:

[SBUS<sb>:EXPResult:EXTension](#) on page 1326

Save as

Opens a dialog box where you can select a filename and a path for the export results file.


Remote command:

[SBUS<sb>:EXPResult:SAVE](#) on page 1326

[SBUS<sb>:EXPResult:PATH](#) on page 1327

14.1.8 Bit pattern editor

If you want to enter a specified address or data pattern, the pattern editor helps you to enter the pattern in various formats - decimal, hexadecimal, octal, binary and ASCII.



The editor at the top displays the pattern in two columns. The left column always shows binary data. For the right column, you can select the "Format". The default depends on the data specifics. You can edit data in the left or right column. The keypad adapts itself to the column format and only keys appropriate to the format are enabled.

The data is grouped and converted in bit groups. The size of a bit group depends on the address or data specifics and is set by the instrument. Groups are automatically separated by blanks. The maximum size of a bit group is 64 bit, the most common group size is 1 byte.

Format-specific information:

- Binary: 0, 1 and X (do not care) is allowed.
- Octal: Each digit represents 3 bit.
- Hex: most common format in the right column.
- ASCII: In the ASCII column, "X" is the character X. The binary X (do not care) is not allowed. If an X is included in the binary value in the left column, the ASCII column displays "\$" to indicate that the value is not defined.
- Unsigned: Decimal data format without a sign for positive or negative numbers. 3 digits are grouped, and the next group is separated by a comma, e.g. 653,848.
- Signed: Decimal format with a sign for positive or negative numbers. 3 digits are grouped, where the first bit represents the sign. You can use the 2's complement format. After a group of 3 digits the next group is separated by a comma, e.g. -653,848.

14.2 SPI bus (IC electronics, option R&S MXO5C-K510)

The Serial Peripheral Interface SPI is used for communication with slow peripheral devices, in particular, for transmission of data streams.



For basic information on SPI, you can also refer to a video, available on the Rohde & Schwarz YouTube channel: [Understanding SPI](#).

Requirements

For performing SPI decode measurements, you need the following:

- MXO 5C with 4 channels. The channels can be a combination of the following:
 - Analog channels (C1-C4)
 - Logic channels (D0-D15) (requires option R&S MXO5C-B1)
- Option R&S MXO5C-K510
- [About the SPI protocol](#)..... 492
- [SPI configuration](#)..... 493
- [SPI filter](#)..... 497
- [SPI hardware trigger](#)..... 499
- [SPI software trigger](#)..... 501
- [Measure](#)..... 504
- [SPI decode results](#)..... 504
- [Performing SPI decoding](#)..... 506

14.2.1 About the SPI protocol

A 4-channel instrument is required for full support of the SPI protocol, or the MSO option R&S MXO5C-B1.

The Serial Peripheral Interface SPI is used for communication with slow peripheral devices, in particular, for transmission of data streams.

The main characteristics of SPI are:

- Main-subnode communication
- No device addressing. The sub is accessed by a chip select, or sub select line.
- No acknowledgment mechanism to confirm receipt of data
- Duplex capability

Most SPI buses have four lines, two data and two control lines:

- Clock line to all subs (SCLK)
- Sub select or Chip select line (SS or CS)
- Main data output, sub data input (MOSI or SDI)
- Main data input, sub data output (MISO or SDO)

When the main generates a clock and selects a sub device, data can be transferred in either or both directions simultaneously.




Figure 14-7: Simple configuration of SPI bus

The data bits of a message are grouped by the following criteria:

- A word contains several successive bits. The word length is defined in the protocol configuration.
- A frame contains several successive words, at least one word.


14.2.2 SPI configuration

14.2.2.1 SPI configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "SPI" > "Setup".



Make sure that the tab of the correct serial bus is selected.

**Protocol type**

Selects the protocol type to be decoded.

Remote command:

[SBUS<sb>:TYPE](#) on page 1322

State

Enables the decoding of the selected bus. The signal icon of the bus appears on the signal bar.

Remote command:

[SBUS<sb>\[:STATe\]](#) on page 1322

SCLK,MOSI,MISO,CS

Sets the input channel for the respective line:

- SCLK: clock line
- MOSI line
- MISO line
- CS: chip select

Alternatively, digital channels can be used if MSO option R&S MXO5C-B1 is installed. Digital and analog channels cannot be used at the same time.

For triggering on a serial bus, analog or digital channel sources are required.

Remote command:

[SBUS<sb>:SPI:MISO:SOURce](#) on page 1330

[SBUS<sb>:SPI:MOSI:SOURce](#) on page 1331

[SBUS<sb>:SPI:SCLK:SOURce](#) on page 1332

[SBUS<sb>:SPI:CSElect:SOURce](#) on page 1329

Clock polarity

Two settings define the clock mode: the clock polarity and the clock phase. Together, they determine the edges of the clock signal on which the data are driven and sampled.

A main/subnode pair must use the same parameter pair values to communicate. The clock phase defines the slope. It selects if data is stored with the rising or falling slope of the clock. The slope marks the begin of a new bit.

Polarity: MOSI, MISO, CS

Selects if the transmitted signal for the respective line is active high (high = 1) or active low (low = 1).

For triggering on a serial bus, analog or digital channel sources are required.

Remote command:

[SBUS<sb>:SPI:MISO:POLarity](#) on page 1330

[SBUS<sb>:SPI:MOSI:POLarity](#) on page 1331

[SBUS<sb>:SPI:CSElect:POLarity](#) on page 1329

Bit order

Selects the bit order, which determines if the data of the messages starts with MSB (most significant bit) or LSB (least significant bit).

Remote command:

[SBUS<sb>:SPI:BORDER](#) on page 1328

Word length

Sets the word length (or symbol size), which is the number of bits in a message. The maximum word length is 32 bit.

Remote command:

[SBUS<sb>:SPI:WSize](#) on page 1333

Timeout

Sets the minimum clock idle time if a timeout on the clock line SCLK is used as limiter between two frames.


This setting is only available, for "CS" = "None".

Remote command:

[SBUS<sb>:SPI:TIMEout](#) on page 1333

14.2.2.2 Threshold settings

Access: "Menu" > "Apps" > "Protocol" tab > "SPI" > "Thresholds".



Threshold

Sets the threshold for the SCLK, MOSI and MISO channels. Enter the value directly in the fields.

Additional to the threshold, you can also set a hysteresis.

If the signal value on the line is higher than the threshold, the signal state is high. Otherwise, the signal state is considered low if the signal value is below the threshold.

The interpretation of high and low is defined by the "[Polarity: MOSI, MISO, CS](#)" on page 495.

Remote command:

[SBUS<sb>:SPI:MISO:HYSTeresis](#) on page 1330

[SBUS<sb>:SPI:MOSI:HYSTeresis](#) on page 1331

[SBUS<sb>:SPI:SCLK:HYSTeresis](#) on page 1332

[SBUS<sb>:SPI:CSElect:HYSTeresis](#) on page 1328

[SBUS<sb>:SPI:MISO:THReshold](#) on page 1330

[SBUS<sb>:SPI:MOSI:THReshold](#) on page 1332

[SBUS<sb>:SPI:SCLK:THReshold](#) on page 1332

[SBUS<sb>:SPI:CSElect:THReshold](#) on page 1329

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.

The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:


`SBUS<sb>:THReshold` on page 1325

14.2.2.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.

14.2.3 SPI filter

Access: "Menu" > "Apps" > "Protocol" tab > "SPI" > "Filter" tab



In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

- "Check all" Enables the filter for all available frames and error types.
- "Clear" Disables the filter for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

"Preset" Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:SPI:FILTer:CHKall](#) on page 1335

[SBUS<sb>:SPI:FILTer:CLR](#) on page 1335

[SBUS<sb>:SPI:FILTer:INVert](#) on page 1335

[SBUS<sb>:SPI:FILTer:RST](#) on page 1336

Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

The available frames are "MOSI", "MISO" and "MOSI/MISO".


Remote command:

[SBUS<sb>:SPI:FILTer:FRAMe<fr>:ENABle](#) on page 1338

[SBUS<sb>:SPI:FILTer:FRENable](#) on page 1338

Edit

Opens a dialog to define the details of the selected frame.



"Field" Enables the field type that you want to filter on for the selected frame. The available fields are "MOSI Pattern" and "MISO Pattern".

Remote command:

[SBUS<sb>:SPI:FILTer:FIENable](#) on page 1338

[SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:ENABle](#) on page 1338

"Condition"	Displays the value condition for the selected field. Remote command: SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:BIT on page 1336
"Data"	The data setup consists of a comparison condition and one or two data patterns. Remote command: SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:DMAX on page 1336 SBUS<sb>:SPI:FILTer:DMAX on page 1336 SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:DMIN on page 1337 SBUS<sb>:SPI:FILTer:DMIN on page 1337 SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:DOPerator on page 1337 SBUS<sb>:SPI:FILTer:DOPerator on page 1337
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:IMAX on page 1338 SBUS<sb>:SPI:FILTer:IMAX on page 1338 SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:IMIN on page 1339 SBUS<sb>:SPI:FILTer:IMIN on page 1339 SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:IOPerator on page 1339 SBUS<sb>:SPI:FILTer:IOPerator on page 1339

Edit

Opens a dialog to define the details of the selected frame.

Error type

Enables filtering on the selected error type.


Available error types are "Void", "Length error" and "Incomplete".

Remote command:

[SBUS<sb>:SPI:FILTer:ERRor<n>:ENABle](#) on page 1337

14.2.4 SPI hardware trigger

Access: "Menu" > "Apps" > "Protocol" tab > "SPI" > "Trigger" tab > "Setup Hardware Trigger"



Type

Selects the trigger type for SPI analysis.

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.

"Start of frame" Sets the trigger to the beginning of the frame.

"End of frame" Sets the trigger to the end of the frame.

"MOSI" Sets the trigger to a specified data pattern expected on the MOSI line.
Available, if there is a channel assigned to the "MOSI" line in the "Setup" tab.


"MISO" Sets the trigger to a specified data pattern expected on the MISO line.
Available, if there is a channel assigned to the "MISO" line in the "Setup" tab.

Remote command:

[TRIGger:SBHW:SPI:TYPE](#) on page 1340

Data conditions

The trigger on MOSI and MISO patterns is defined in the same way:



Search mode ← Data conditions

Defines how the specified data pattern is searched.

"Bit-aligned" Bit-by-bit: the pattern can start at any position in the message.

"Word-aligned" The pattern is matched only at word boundaries.

Remote command:

[TRIGger:SBHW:SPI:PALignment](#) on page 1340

Data ← Data conditions

Selects the operator condition for the data pattern and sets the data pattern.

Remote command:

[TRIGger:SBHW:SPI:FCONdition](#) on page 1341

[TRIGger:SBHW:SPI:DMINpattern](#) on page 1341

Position ← Data conditions

Sets the number of bits or words to be ignored before the first bit or word of interest.

Remote command:

[TRIGger:SBHW:SPI:DPOSition](#) on page 1341


14.2.5 SPI software trigger

14.2.5.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.2.5.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "SPI" > "Trigger" tab > "Setup Software Trigger" > "Setup SB Trigger".



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

"Check all"	Enables the software trigger for all available frames and error types.
"Clear"	Disables the software trigger for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:SPI:CHKall](#) on page 1342

[TRIGger:SBSW:SPI:CLR](#) on page 1342

[TRIGger:SBSW:SPI:INVert](#) on page 1342

[TRIGger:SBSW:SPI:RST](#) on page 1343

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frames are available: "MISO", "MOSI" and "MISO/MOSI".


Remote command:

[TRIGger:SBSW:SPI:FREnable](#) on page 1343

[TRIGger:SBSW:SPI:FRAMe<fr>:ENABle](#) on page 1343

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



"Field" Enables the field type that you want to trigger on for the selected frame.

The following fields are available: "MOSI" and "MISO".

Remote command:

[TRIGger:SBSW:SPI:FIENable](#) on page 1345

[TRIGger:SBSW:SPI:FRAMe<fr>:FLD<fl>:ENABle](#) on page 1345

"Condition" Displays the value condition for the selected field.

Remote command:

[TRIGger:SBSW:SPI:BIT](#) on page 1343

[TRIGger:SBSW:SPI:FRAMe<fr>:FLD<fl>:BIT](#) on page 1343

"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: TRIGger:SBSW:SPI:DMAX on page 1343 TRIGger:SBSW:SPI:FRAMe<fr>:FLD<fl>:DMAX on page 1343 TRIGger:SBSW:SPI:DMIN on page 1344 TRIGger:SBSW:SPI:FRAMe<fr>:FLD<fl>:DMIN on page 1344 TRIGger:SBSW:SPI:DOPerator on page 1344 TRIGger:SBSW:SPI:FRAMe<fr>:FLD<fl>:DOPerator on page 1344
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: TRIGger:SBSW:SPI:IMAX on page 1345 TRIGger:SBSW:SPI:FRAMe<fr>:FLD<fl>:IMAX on page 1345 TRIGger:SBSW:SPI:IMIN on page 1345 TRIGger:SBSW:SPI:FRAMe<fr>:FLD<fl>:IMIN on page 1345 TRIGger:SBSW:SPI:IOperator on page 1346 TRIGger:SBSW:SPI:FRAMe<fr>:FLD<fl>:IOperator on page 1346

Error type

Enables triggering on the selected error type.

The following error types are available: "Void" and "Length error".

Remote command:

[TRIGger:SBSW:SPI:ERENable](#) on page 1346

[TRIGger:SBSW:SPI:ERRor<m>:ENABLE](#) on page 1346

14.2.6 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.2.7 SPI decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.

Decode results table

The "Decode results" table contains information about all decoded frames.




Figure 14-8: Decoded SPI signal

The decode results table contains information about all decoded frames.

Table 14-1: Content of the decode results table

Column	Description
Index	Index of the decoded frame
State	Overall state of the frame
Start	Times of frame start
Count	Number of words in the frame
MOSI values	Value of the MOSI data words. Select the data format in the "Display" tab.
MISO values	Value of the MISO data words. Select the data format in the "Display" tab.
Bit rate	Value of the bit rate

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-2: Content of the frame details table

Column	Description
Index	Index of the field
MOSI	Values of the MOSI fields
MISO	Values of the MISO fields

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- `SBUS<sb>:FORMat` on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.2.5, "Decode results"](#), on page 1347.

To query the MOSI and MISO values, use the remote command `SBUS<sb>:SPI:FRAME<fr>:DATA?`.

14.2.8 Performing SPI decoding

This section explains step by step how to configure and decode the SPI bus.


For more information on decoding SPI, you can also refer to the video, available on the Rohde & Schwarz YouTube channel: [Decoding SPI with MXO Series Oscilloscopes](#).

14.2.8.1 Configuring SPI signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.


For details on configuration settings, see [Section 14.2.2, "SPI configuration"](#), on page 493.

1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: "SPI".
4. Tap on "State" to enable the decoding.


An SPI shortcut appears at the bottom left of the screen. Tap on the shortcut for a quick access to the "SPI" dialog settings.



5. Tap on each active wire and select the correct channels: "SCLK", "MOSI", "MISO", "CS".
6. Set "Bit order" to "MSB" or "LSB first".
7. Set "Clock polarity" to "Rising edge" (CPOL = 0) or "Falling edge" (CPOL = 1).
8. Set "MOSI polarity"/"MISO polarity" to "Active high"(CPHA = 0) or "Active low"(CPHA = 1).
9. Set "CS polarity" to "Active high" or "Active low".
The typical value is "Active low", which means that the line is pulled low on message start.
10. Set the "Word length". The typical value is 8.
11. Check that the signals are on the screen.
If not, try adjusting the vertical and horizontal settings.



12. Set the logical thresholds:
 - a) Tap the "Thresholds" tab.
 - b) For each wire, set the threshold value. A typical value is 1.65 V.
 - c) If necessary, set the hysteresis value for the wires.
 - d) Optionally, tap on "Show threshold lines".



14.2.8.2 Triggering on SPI

Prerequisites: A bus is configured for the SPI signal to be analyzed. See [Section 14.2.8.1, "Configuring SPI signals"](#), on page 506.

For details on configuration settings, see [Section 14.2.2, "SPI configuration"](#), on page 493.

1. Open "Menu" > "Trigger".
2. Set "Trigger on" to "Single event".
3. Ensure that the "Source" is set to the configured serial bus, e.g. "Serial bus 1".
4. Select the "Type".
5. Define additional settings for more complex trigger types ("MOSI"/ "MISO"):
 - a) Tap on "Set details".
 - b) Set the "Search mode".
 - c) Set the "Data pattern" or a data range.

In the following example a decode for triggering on "MOSI" triggered on "Data pattern" = 0x41.



Figure 14-9: Trigger on Type= MOSI, Data pattern = 41

14.2.8.3 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the SPI and decoded.

1. Tap on the "SPI" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".
5. Select the "File type".

An export file is saved in the selected directory.

The SPI export file contains the following fields:

- A list of all decoded frames:
 - Index
 - Start
 - Stop
 - Source
 - State
 - Bit rate
- The details frame includes the following fields:
 - Index
 - Start time
 - Stop time
 - MOSI values
 - MISO values

Example SPI export file

```
Index,Start,Stop,State,Count,BitRate
1,-2.9e-05,-2.872e-05,'OK',2,50000000
2,-2.844e-05,-2.83e-05,'OK',1,50000000
3,-2.816e-05,-2.788e-05,'OK',2,50000000
4,-2.76e-05,-2.746e-05,'VOID',0,---
```

Details frame 1

```
Index,Start Time,Stop Time,MOSI Values,MISO Values
1,-2.9e-05,-2.886e-05,AFh,---
2,-2.886e-05,-2.872e-05,FEh,---
```

Details frame 2

```
Index,Start Time,Stop Time,MOSI Values,MISO Values
1,-2.844e-05,-2.83e-05,---,34h
```

Details frame 3

```
Index,Start Time,Stop Time,MOSI Values,MISO Values
```

```
1, -2.816e-05, -2.802e-05, CAh, F0h
2, -2.802e-05, -2.788e-05, 05h, 0Dh
```

14.3 QUAD-SPI bus (IC electronics, option R&S MXO5C-K510)

QUAD-SPI also known as QSPI is a protocol that extends the standard SPI by using four data lanes instead of one. This protocol enables a faster data transfer.

Requirements

For performing QUAD-SPI decode measurements, you need the following:

- MXO 5C with 4 channels. The channels can be a combination of the following:
 - Analog channels (C1-C4)
 - Logic channels (D0-D15) (requires option R&S MXO5C-B1)
- Option R&S MXO5C-K510

• About the QUAD-SPI protocol	510
• QUAD-SPI configuration	511
• QUAD SPI filter	519
• QUAD SPI software trigger	522
• Measure	525
• QUAD-SPI decode results	525
• Performing QUAD-SPI decoding	527

14.3.1 About the QUAD-SPI protocol

Quad Serial Peripheral Interface is an extension of the standard Serial Peripheral Interface (SPI). It enhances the data transfer capabilities by utilizing four data lines instead of the single data line used in traditional SPI. This expansion significantly increases the data throughput, making it ideal for applications requiring rapid data exchange, such as memory devices, display controllers, and sensors.

Key features

Key features of Quad SPI are:

- **Increased Data Throughput:** By using four data lines (IO0, IO1, IO2, IO3), QSPI can achieve higher data transfer rates compared to standard SPI. This makes it suitable for high-speed applications.
- **Enhanced Flexibility:** Quad SPI supports various modes of operation, including single, dual, and quad modes, allowing for flexible communication tailored to specific needs.
- **Memory Mapping:** one of the standout features of QSPI is its ability to map external flash memory directly into the memory space of a microcontroller, enabling efficient and seamless data access.

QUAD SPI builds upon the traditional SPI protocol but adds complexity and speed.

Communication Lines

QUAD SPI uses six primary lines:

- SCLK (serial clock): generates the clock signal
- CS (chip select): selects the device for communication
- IO0-IO3, data lines: four lines for data transfer.

14.3.2 QUAD-SPI configuration

14.3.2.1 QUAD-SPI configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "QUAD-SPI" > "Setup".



Make sure that the tab of the correct serial bus is selected.

Protocol type

Selects the protocol type to be decoded.

Remote command:

[SBUS<sb>:TYPE](#) on page 1322

State

Enables the decoding of the selected bus. The signal icon of the bus appears on the signal bar.

Remote command:

[SBUS<sb>\[:STATe\]](#) on page 1322

CS, SCLK, IO n

Sets the input channel for the respective line:

- CS: chip select
- SCLK: clock line
- IO0, IO1, IO2, IO3, IO4: data lines

Remote command:

[SBUS<sb>:QSPI:CSEL:SOURce](#) on page 1353

[SBUS<sb>:QSPI:IOONe:SOURce](#) on page 1355

[SBUS<sb>:QSPI:IOTHree:SOURce](#) on page 1357

[SBUS<sb>:QSPI:IOTWo:SOURce](#) on page 1358

[SBUS<sb>:QSPI:IOZero:SOURce](#) on page 1360

[SBUS<sb>:QSPI:SCLK:SOURce](#) on page 1361

SCLK SDR Polarity

Selects if the transmitted signal for the respective line is rising or falling.

Remote command:

[SBUS<sb>:QSPI:SCLK:POLarity](#) on page 1361

Polarity: CS, IOx

Selects if the transmitted signal for the respective line is active high (high = 1) or active low (low = 1).

Remote command:

[SBUS<sb>:QSPI:CSEL:POLarity](#) on page 1353

[SBUS<sb>:QSPI:IOONe:POLarity](#) on page 1354

[SBUS<sb>:QSPI:IOTHree:POLarity](#) on page 1356

[SBUS<sb>:QSPI:IOTWo:POLarity](#) on page 1358

[SBUS<sb>:QSPI:IOZero:POLarity](#) on page 1359

Instruction

Selects the instruction mode that defines how many lanes are used to transmit data.


"Single"	Only one data line is used, IO0.
"Dual"	Two lines are used for data transmission IO0 and IO1. This mode doubles the data rate compared to a single mode, as it can send or receive 2 bits per clock cycle.
"Quad"	Four lines are used for data transmission IO0, IO1, IO2 and IO3. This mode provides the highest data transfer rate. This mode quadruples the data transfer rate compared to a single mode, as it can send or receive 4 bits per clock cycle.

Remote command:

[SBUS<sb>:QSPI:INSTruction](#) on page 1354

14.3.2.2 Threshold settings

Access: "Menu" > "Apps" > "Protocol" tab > "QUAD-SPI" > "Thresholds".



CS/SCLK/IO threshold

Set the threshold for each signal channel. Enter the value directly in the fields.

Remote command:

[SBUS<sb>:QSPI:CSEL:THReshold](#) on page 1354
[SBUS<sb>:QSPI:IOONe:THReshold](#) on page 1355
[SBUS<sb>:QSPI:IOTWo:THReshold](#) on page 1359
[SBUS<sb>:QSPI:IOTHree:THReshold](#) on page 1357
[SBUS<sb>:QSPI:IOZero:THReshold](#) on page 1360
[SBUS<sb>:QSPI:SCLK:THReshold](#) on page 1361

CS/SCLK/IO hysteresis

Set the hysteresis for each signal channel. Enter the value directly in the fields.

Remote command:

[SBUS<sb>:QSPI:CSEL:HYSTeresis](#) on page 1353
[SBUS<sb>:QSPI:IOONe:HYSTeresis](#) on page 1354
[SBUS<sb>:QSPI:IOTWo:HYSTeresis](#) on page 1357
[SBUS<sb>:QSPI:IOTHree:HYSTeresis](#) on page 1356
[SBUS<sb>:QSPI:IOZero:HYSTeresis](#) on page 1359
[SBUS<sb>:QSPI:SCLK:HYSTeresis](#) on page 1361

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.

The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:

[SBUS<sb>:THReshold](#) on page 1325

14.3.2.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.

Decode layer


Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display.

"Off"	Disables the display of the decode layer.
"Edges"	Enables the display of all edges for each lane.
"Bits"	Enables the display of all bits for each lane.
"Merged bits"	Enables the display of the bits merged across multiple lanes.
"Words"	Enables the display of all words.

14.3.2.4 Format

Access: "Menu" > "Apps" > "Protocol" tab > "QUAD-SPI" > "Format".



In the "Format" tab, you can define the opcode file.

Opcode is a specific command byte sent from the microcontroller to the QUAD-SPI device to initiate a particular action, such as reading, writing or erasing data. The opcodes vary by device manufacturer and memory model.

Opcode files are in JSON format, and contain frame descriptions for each hexadecimal opcode value.

The following is an example from a JSON file:

```
{
  "Firmware Version": "2.2.0.0",
  "Description": "Rohde Schwarz Inc. oscilloscope Quadspi Opcode data",
  "Opcode Version": 1,
  "Opcodes": {
    "0x05,RDSR1": [
      {
        "name": "data",
        "bytes": 0,
        "ddr": false,
        "lanes": 1
      }
    ]
  }
}
```

```

],
"0x07,RDSR2": [
  {
    "name": "data",
    "bytes": 0,
    "ddr": false,
    "lanes": 1
  }
],
"0x35,RDCR1": [
  {
    "name": "data",
    "bytes": 0,
    "ddr": false,
    "lanes": 1
  }
],
"0x0D,DDRFAS READ": [
  {
    "name": "address",
    "bytes": 3,
    "ddr": true,
    "lanes": 1
  },
  {
    "name": "data",
    "bytes": 0,
    "ddr": true,
    "lanes": 1
  }
]
}

```

Add

Adds a new item to the opcode list.

Remote command:

[SBUS<sb>:QSPI:OPCode:APPend](#) on page 1362

Delete

Deletes the currently selected opcode from the list.

Remote command:

[SBUS<sb>:QSPI:OPCode:DELeTe](#) on page 1362

Delete all

Deletes all defined opcodes from the list.

Remote command:

[SBUS<sb>:QSPI:OPCode:DALL](#) on page 1362

Open, Save as

Opens a dialog box where you can select a filename and a path for the export results file.

Remote command:

[SBUS<sb>:QSPI:LDOPCode](#) on page 1363


[SBUS<sb>:QSPI:SVOP](#) on page 1367

Preset

Resets the opcode fields to the predefined values.

Remote command:

[SBUS<sb>:QSPI:OPCode:RESet](#) on page 1363

Opcode settings

You can define the following settings for each opcode separately:

Opcode ← Opcode settings

Sets the opcode value.

Remote command:

[SBUS<sb>:QSPI:OPCode:ITEM<n>:CODE](#) on page 1365

Name ← Opcode settings

Sets the name for the opcode.

Remote command:

[SBUS<sb>:QSPI:OPCode:ITEM<n>:NAME](#) on page 1366

DDR ← Opcode settings

If enabled, the data is transferred on both the rising and falling edges of the clock signal. This method effectively doubles the data transfer rate compared to a single data rate (SDR), which transfers data only on one clock edge.

Remote command:

[SBUS<sb>:QSPI:OPCode:ITEM<n>:DDR](#) on page 1365

Address Bytes ← Opcode settings

Sets the address byte. It specifies the location in the flash memory where the operation (e.g., read, write) is performed.

Remote command:

[SBUS<sb>:QSPI:OPCode:ITEM<n>:ADBytes](#) on page 1364

Address Lanes ← Opcode settings

Selects how many lines or lanes are used to send the address bytes to the flash memory.

"Single" Address is sent over one serial line.

"Dual" Address is sent over two lines.

"Quad" Address is sent over four lines.

Remote command:

[SBUS<sb>:QSPI:OPCode:ITEM<n>:ADLanes](#) on page 1364

Alternative Field ← Opcode settings

Enable, if an "Alt" field is available. The alternative field can be implemented according to the preferences of the manufacturer of the device under test, for example a flash memory device.

Remote command:

[SBUS<sb>:QSPI:OPCode:ITEM<n>:ALT](#) on page 1364

Dummy Cycles ← Opcode settings

Sets the number of dummy cycles. Dummy cycles are clock cycles inserted after the address or other command sequences but before data transfer begins. These cycles allow the flash memory device additional time to perform internal operations or latch onto the correct data to ensure accurate read or write operations.

Remote command:

[SBUS<sb>:QSPI:OPCode:ITEM<n>:DMCYcles](#) on page 1366

Data ← Opcode settings

Enable, if data is being transferred in the opcode operation.

Remote command:

[SBUS<sb>:QSPI:OPCode:ITEM<n>:DATA](#) on page 1365

Data Lanes ← Opcode settings

Selects how many lanes are used for the data transfer.

The data lanes refer to the physical connections through which data is transmitted between the main (typically a microcontroller) and the secondary (typically a flash memory device). QUADSPI can utilize multiple data lines to increase the speed and efficiency of data transfer.

"Single" Data is sent over one serial line.

"Dual" Data is sent over two lines.


"Quad" Data is sent over four lines.

Remote command:

[SBUS<sb>:QSPI:OPCode:ITEM<n>:DTLanes](#) on page 1366

14.3.3 QUAD SPI filter

Access: "Menu" > "Apps" > "Protocol" tab > "QUAD-SPI" > "Filter" tab



In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

"Check all" Enables the filter for all available frames and error types.

"Clear" Disables the filter for all available frames and error types.

"Invert" Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

"Preset" Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:QSPI:FILTer:CHKall](#) on page 1368

[SBUS<sb>:QSPI:FILTer:CLR](#) on page 1368

[SBUS<sb>:QSPI:FILTer:INVert](#) on page 1368

[SBUS<sb>:QSPI:FILTer:RST](#) on page 1368

Frame type


Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

Available frame is "Data".

Edit

Opens a dialog to define the details of the selected frame.



"Field"	Enables the field type that you want to filter on for the selected frame. The available fields are: • "Opcode" • "Addr" • "Alt" • "Dummy" • "Data" Remote command: SBUS<sb>:QSPI:FILTer:FIENable on page 1372 SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:ENABLE on page 1372
"Condition"	Displays the value condition for the selected field. Remote command: SBUS<sb>:QSPI:FILTer:BIT on page 1369 SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:BIT on page 1369
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: SBUS<sb>:QSPI:FILTer:DMAX on page 1369 SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:DMAX on page 1369 SBUS<sb>:QSPI:FILTer:DMIN on page 1369 SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:DMIN on page 1369 SBUS<sb>:QSPI:FILTer:DOPerator on page 1370 SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:DOPerator on page 1370
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: SBUS<sb>:QSPI:FILTer:IMAX on page 1370 SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:IMAX on page 1370 SBUS<sb>:QSPI:FILTer:IMIN on page 1370 SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:IMIN on page 1370 SBUS<sb>:QSPI:FILTer:IOPerator on page 1371 SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:IOPerator on page 1371

Error type

Enables filtering on the selected error type.

Available error types are "Length error", "Opcode error", "Incomplete".

Remote command:

[SBUS<sb>:QSPI:FILTer:ERENable](#) on page 1371

[SBUS<sb>:QSPI:FILTer:ERRor<n>:ENABLE](#) on page 1371


14.3.4 QUAD SPI software trigger

14.3.4.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.3.4.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "QUAD-SPI" > "Trigger" tab > "Setup Software Trigger"



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

QUAD-SPI bus (IC electronics, option R&S MXO5C-K510)

"Check all"	Enables the software trigger for all available frames and error types.
"Clear"	Disables the software trigger for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:QSPI:CHKall](#) on page 1373

[TRIGger:SBSW:QSPI:CLR](#) on page 1373

[TRIGger:SBSW:QSPI:INVert](#) on page 1373

[TRIGger:SBSW:QSPI:RST](#) on page 1374

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The available frame is "Data".


Remote command:

[TRIGger:SBSW:QSPI:FRENable](#) on page 1374

[TRIGger:SBSW:QSPI:FRAME<fr>:ENABLe](#) on page 1374

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



- "Field" Enables the field type that you want to trigger on for the selected frame.
The following fields are available: "Opcode", "Addr", "Alt", "Dummy" and "Data".
Remote command:
[TRIGger:SBSW:QSPI:FIENable](#) on page 1376
[TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:ENABLE](#) on page 1376
- "Condition" Displays the value condition for the selected field.
Remote command:
[TRIGger:SBSW:QSPI:BIT](#) on page 1374
[TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:BIT](#) on page 1374
- "Value" The data setup consists of a comparison condition and one or two data patterns.
Remote command:
[TRIGger:SBSW:QSPI:DMAX](#) on page 1374
[TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:DMAX](#) on page 1374
[TRIGger:SBSW:QSPI:DMIN](#) on page 1375
[TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:DMIN](#) on page 1375
[TRIGger:SBSW:QSPI:DOPerator](#) on page 1375
[TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:DOPerator](#) on page 1375

QUAD-SPI bus (IC electronics, option R&S MXO5C-K510)

"Index" The index setup consists of a comparison condition and one or two index values.

Remote command:

[TRIGger:SBSW:QSPI:IMAX](#) on page 1376

[TRIGger:SBSW:QSPI:FRAME<fr>:FLD<fl>:IMAX](#) on page 1376

[TRIGger:SBSW:QSPI:IMIN](#) on page 1376

[TRIGger:SBSW:QSPI:FRAME<fr>:FLD<fl>:IMIN](#) on page 1376

[TRIGger:SBSW:QSPI:IOperator](#) on page 1377

[TRIGger:SBSW:QSPI:FRAME<fr>:FLD<fl>:IOperator](#) on page 1377

Error type

Enables triggering on the selected error type.

The following error types are available: "Length error" and "Opcode error".

Remote command:

[TRIGger:SBSW:QSPI:ERENable](#) on page 1377

[TRIGger:SBSW:QSPI:ERROR<m>:ENABLE](#) on page 1377

14.3.5 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.3.6 QUAD-SPI decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.

Column	Description
State	State of the field
Value	Value of the field

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- `SBUS<sb>:FORMat` on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.3.5, "Decode results"](#), on page 1378.

14.3.7 Performing QUAD-SPI decoding


This section explains step by step how to configure and decode the QUAD-SPI bus.

14.3.7.1 Configuring QUAD-SPI signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.


For details on configuration settings, see [Section 14.3.2, "QUAD-SPI configuration"](#), on page 511.

1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: "QUAD-SPI".
4. Tap on "State" to enable the decoding.

A "QUAD-SPI" shortcut appears at the bottom left of the screen. Tap on the shortcut for a quick access to the "QUAD-SPI" dialog settings.



5. Check that the signals are on the screen.

If not try adjusting the vertical and horizontal settings.

6. Set the logical thresholds:
 - a) Tap the "Thresholds" tab.
 - b) For each wire, set the threshold value. A typical value is 0.8 V.
 - c) If necessary, set the hysteresis value for the wires.
 - d) Optionally, tap on "Show threshold lines".

14.3.7.2 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the QUAD-SPI and decoded.

1. Tap on the "QUAD-SPI" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".
5. Select the "File type".

An export file is saved in the selected directory.

The QUAD-SPI export file contains the following fields:

- A list of all decoded frames:
 - Index
 - Start
 - Stop
 - State
 - Opcode
 - Address
 - Alt
 - Count
 - Bit rate
- The details frame includes the following fields:
 - Index
 - Data

Example QUAD-SPI export file

```
Index,Start,Stop,State,Opcode,Address,Alt,Count,Bit rate
1,-7.04e-05,-5.28e-05,'OK',0Ah,12345678h,0Ch,4,5000000
2,-5.28e-05,-3.52e-05,'OK',0Ah,12345678h,0Ch,4,5000000
3,-3.52e-05,-1.76e-05,'OK',0Ah,12345678h,0Ch,4,5000000
4,-1.76e-05,0,'OK',0Ah,12345678h,0Ch,4,5000000
```

Details frame 1

Index,Data

1,52h

2,53h

3,54h

4,55h

Details frame 2

Index,Data

1,56h

2,57h

3,58h

4,59h

14.4 I²C (IC electronics, option R&S MXO5C-K510)

The Inter-Integrated Circuit is a simple, low-bandwidth, low-speed protocol used for communication between on-board devices, for example, in LCD and LED drivers, RAM, EEPROM, and others.



For basic information on I²C, you can also refer to a video, available on the Rohde & Schwarz YouTube channel: [Understanding I²C](#).

Requirements

For performing I²C decode measurements, you need the following:

- MXO 5C with 2 available channels. The channels can be a combination of the following:
 - Analog channels (C1-C4)
 - Logic channels (D0-D15) (requires option R&S MXO5C-B1)
- Option R&S MXO5C-K510
- [About the I²C protocol](#)..... 530
- [I²C configuration](#)..... 532
- [I²C filter](#)..... 536
- [I²C hardware trigger](#)..... 538
- [I²C software trigger](#)..... 542
- [Measure](#)..... 545
- [I²C decode results](#)..... 546
- [Performing I²C decoding](#)..... 547

14.4.1 About the I²C protocol

This section provides an overview of protocol characteristics, data format, address types and trigger possibilities. For detailed information, read the "I²C-bus specification and user manual" available on the NXP manuals webpage at <http://www.nxp.com/>.

I²C characteristics

The main characteristics of I²C are:

- Two-wire design: serial clock (SCL) and serial data (SDA) lines
- Controller/ target communication: the controller generates the clock and addresses the targets. Targets receive the address and the clock. Both controller and targets can transmit and receive data.
- Addressing scheme: each target device is addressable by a unique address. Multiple target devices can be linked together and can be addressed by the same controller.
- Read/write bit: specifies if the controller reads (=1) or writes (=0) the data.
- Acknowledge: takes place after every byte. The receiver of the address or data sends the acknowledge bit to the transmitter.

The MXO 5C supports all operating speed modes: high-speed, fast mode plus, fast mode, and standard mode.

Data transfer

The format of a simple I²C message (frame) with 7-bit addressing consists of the following parts:

- Start condition: a falling slope on SDA while SCL is high
- 7-bit address of the target device that is either written to or read from
- R/W bit: specifies if the data is written to or read from the target
- ACKnowledge bits: is issued by the receiver of the previous byte if the transfer was successful
Exception: At read access, the controller terminates the data transmission with a NACK bit after the last byte.
- Data: several data bytes with an ACK bit after every byte
- Stop condition: a rising slope on SDA while SCL is high




Figure 14-11: I²C write access with a 7-bit address

Address types: 7-bit and 10-bit

Target addresses can be 7 bits or 10 bits long. A 7-bit address requires 1 byte, 7 bits for the address followed by the R/W bit.

A 10-bit address for write access requires 2 bytes: the first byte starts with the reserved sequence 11110, followed by the two MSB of the address and the write bit. The second byte contains the remaining 8 LSB of the address. The target acknowledges each address byte.



Figure 14-12: 10-bit address, write access

A 10-bit address for read access requires 3 bytes. The first 2 bytes are identical to the write access address. The third byte repeats the address bits of the first byte and sets the read bit.




Figure 14-13: 10-bit address, read access

Trigger

The MXO 5C can trigger on various parts of I²C messages. You must connect the data and clock lines to the input channels; triggering on math and reference waveforms is not possible.


You can trigger on:

- Start or stop condition
- Repeated start condition
- Transfer direction (read or write)
- Bytes with missing acknowledge bit
- Specific data pattern in the message

14.4.2 I²C configuration

14.4.2.1 I²C configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "I²C" > "Setup".



Make sure that the tab of the correct serial bus is selected.

Protocol type

Selects the protocol type to be decoded.

Remote command:

`SBUS<sb>:TYPE` on page 1322

State

Enables the decoding of the selected bus. The signal icon of the bus appears on the signal bar.

Remote command:

[SBUS<sb> \[:STATe\]](#) on page 1322

SDA source

Sets the source channel to which the data line is connected.

Remote command:

[SBUS<sb>: I2C: SDA: SOURce](#) on page 1385

SCL source


Selects the source channel to which the clock line is connected.

Remote command:

[SBUS<sb>: I2C: SCL: SOURce](#) on page 1384

14.4.2.2 Threshold settings

Access: "Menu" > "Apps" > "Protocol" tab > "I2C" > "Thresholds".

**SDA/SCL threshold, SDA/SCL hysteresis**

Set the threshold for the SDA and SCL channels. Enter the value directly in the fields.

Additional to the threshold, you can also set a hysteresis for each channel.

Remote command:

[SBUS<sb>:I2C:SCL:THReshold](#) on page 1385

[SBUS<sb>:I2C:SDA:THReshold](#) on page 1386

[SBUS<sb>:I2C:SCL:HYSTeresis](#) on page 1384

[SBUS<sb>:I2C:SDA:HYSTeresis](#) on page 1385

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.


The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:

[SBUS<sb>:THReshold](#) on page 1325

14.4.2.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.



Decode layer

Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display.

See ["Decode layer"](#) on page 481.

Data format

See ["Data format"](#) on page 481.

Zoom coupling

See ["Zoom coupling"](#) on page 482.

Show symbols

Symbol lists are protocol-specific. Label lists for I²C are available in CSV format.

For details, see [I²C symbols](#).

Remote command:

[SBUS<sb>:I2C:SYMBOLs](#) on page 1386

[SBUS<sb>:I2C:NEWLlist](#) on page 1387

14.4.2.4 I²C symbols

For the I²C protocol, you can upload symbol lists containing IDs and a symbolic name for each node. You can load a file in one of the supported formats. Symbol lists for I²C are available in CSV format.

An I²C label file contains three values for each address:

- Address type, 7-bit or 10-bit long
- Address value
- Symbolic label: name of the address, specifying its function in the bus network.

Example: I²C CSV file


```
# -----
@FILE_VERSION = 1.00
@PROTOCOL_NAME = i2c
# -----
# Labels for I2C protocol
#   Column order: Identifier type, Identifier value, Label
# -----
7,0x1E,Voltage
7,38h,Pressure
7,2Ah,Temperature
7,16h,Speed
7,118,Acceleration
7,07h,HighSpeed_Master_0x3
7,51h,EEPROM
10,3A2h,DeviceSetup
10,1A3h,GatewayStatus
```

```
10,06Eh,LeftSensor
```

```
# -----
```

14.4.3 I²C filter

Access: "Menu" > "Apps" > "Protocol" tab > "I²C" > "Filter" tab



In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

- "Check all" Enables the filter for all available frames and error types.
- "Clear" Disables the filter for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
- "Preset" Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:I2C:FILTer:CHKall](#) on page 1388

[SBUS<sb>:I2C:FILTer:CLR](#) on page 1388

[SBUS<sb>:I2C:FILTer:INVert](#) on page 1388

[SBUS<sb>:I2C:FILTer:RST](#) on page 1388

Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.


Remote command:

[SBUS<sb>:I2C:FILTer:FREnable](#) on page 1389

[SBUS<sb>:I2C:FILTer:FRAMe<fr>:ENABLE](#) on page 1389

Edit

Opens a dialog to define the details of the selected frame.



"Field"

Enables the field type that you want to filter on for the selected frame. The available fields are "Address", "R/W", "ACK_A", "ACK_A2", "Data", and "ACK_D".

Remote command:

[SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:ENABLE](#)
on page 1392

[SBUS<sb>:I2C:FILTer:FIENable](#) on page 1392

"Condition"	Displays the value condition for the selected field. Remote command: SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:BIT on page 1392
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:DMAX on page 1389 SBUS<sb>:I2C:FILTer:DMAX on page 1389 SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:DMIN on page 1389 SBUS<sb>:I2C:FILTer:DMIN on page 1389 SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:DOPerator on page 1390 SBUS<sb>:I2C:FILTer:DOPerator on page 1390
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:IMAX on page 1390 SBUS<sb>:I2C:FILTer:IMAX on page 1390 SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:IMIN on page 1391 SBUS<sb>:I2C:FILTer:IMIN on page 1391 SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:IOPerator on page 1391 SBUS<sb>:I2C:FILTer:IOPerator on page 1391

Error type

Enables filtering on the selected error type.


Remote command:

[SBUS<sb>:I2C:FILTer:ERENable](#) on page 1390

[SBUS<sb>:I2C:FILTer:ERRor<n>:ENABle](#) on page 1390

14.4.4 I²C hardware trigger

Access: "Menu" > "Apps" > "Protocol" tab > "I2C" > "Trigger" tab > "Setup Hardware Trigger"

**Type**

Selects the trigger type for I²C analysis.

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.

Remote command:

[TRIGger:SBHW:I2C:TYPE](#) on page 1393

Start ← Type

Sets the trigger to the start of the message. The start condition is a falling edge on SDA while SCL is high. The trigger instant is the falling edge of the SDA line.

You can change the SDA and SCL lines here if necessary.

Repeated start ← Type


Sets the trigger to a repeated start - when the start condition occurs without previous stop condition. Repeated start conditions occur when a controller exchanges multiple messages with a target device without releasing the bus.

Stop ← Type


Sets the trigger to the end of the message. The stop condition is a rising slope on SDA while SCL is high.

No Ack ← Type


Missing acknowledge bit: the instrument triggers if the data line remains HIGH during the clock pulse following a transmitted byte.

**Address ← Type**

Sets the trigger to one specific address condition or a combination of address conditions. The trigger time is the falling clock edge of the acknowledge bit after the address.

**Data ← Type**

Sets the trigger to one specific data condition or a combination of address conditions.

**Address and data ← Type**

Sets the trigger to a combination of address and data condition.

Trigger				
Back	Address type	7 bit	R/W bit	Either
	Address	In range	From	To
	Data	Less or equal	Value	Position
			00	00
			00	1

No Ack conditions

Selects which missing acknowledge bits is detected if the trigger type is set to "No Ack".

"Address Nack"

No secondary recognizes the address.

"Data write Nack"

The addressed secondary does not accept the data.

"Data read Nack"

Marks the end of the read process when the primary reads data from the secondary. This Nack is sent according to the protocol definition, it is not an error.

Remote command:

[TRIGger:SBHW:I2C:ADNack](#) on page 1394

[TRIGger:SBHW:I2C:DWNack](#) on page 1396

[TRIGger:SBHW:I2C:DRNack](#) on page 1396

Address type

Sets the address length to be triggered on: 7 bit or 10 bit.

Remote command:

[TRIGger:SBHW:I2C:AMODe](#) on page 1395

R/W bit

Toggles the trigger condition between read and write access of the primary. Select "Either" if the transfer direction is not relevant for the trigger condition.

Remote command:

[TRIGger:SBHW:I2C:ACCess](#) on page 1393

Address

The trigger address setup consists of a comparison condition and one or two address patterns.

Defines the bit pattern of the secondary device address. The length of the entry is adjusted to the selected address type.

"Condition" Sets the comparison condition to a specific value or a range.

"From"	Specifies the value or sets the start value of a range.
"To"	Sets the maximum value of a range for "Condition" = "In range"/"Out of range".

Remote command:

[TRIGger:SBHW:I2C:ADDRess](#) on page 1394

[TRIGger:SBHW:I2C:ADDTo](#) on page 1394

Data

Specifies the trigger conditions for the data bit pattern.

"Condition"	Sets the comparison condition to a specific value or a range.
"Value"	Specifies the value or sets the start value of a range. Enter the bytes in msb first bit order. The maximum pattern length is 64 bit. Waveform data is compared with the pattern byte-by-byte.

Remote command:

[TRIGger:SBHW:I2C:DCONdition](#) on page 1395

[TRIGger:SBHW:I2C:DMIN](#) on page 1395

Position

Sets the number of data bytes to be skipped after the address.

Remote command:

[TRIGger:SBHW:I2C:DPOSition](#) on page 1395


14.4.5 I²C software trigger

14.4.5.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.4.5.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "I2C" > "Trigger" tab > "Setup Software Trigger" > "Setup SB Trigger"



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

- "Check all" Enables the software trigger for all available frames and error types.
- "Clear" Disables the software trigger for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
- "Preset" Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:I2C:CHKall](#) on page 1397

[TRIGger:SBSW:I2C:CLR](#) on page 1397

[TRIGger:SBSW:I2C:INVert](#) on page 1397

[TRIGger:SBSW:I2C:RST](#) on page 1397

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frames are available: "Write", "Read", "10 Bit Write", "10 Bit Read".


Remote command:

[TRIGger:SBSW:I2C:FREnable](#) on page 1398

[TRIGger:SBSW:I2C:FRAMe<fr>:ENABle](#) on page 1398

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



"Field"	Enables the field type that you want to trigger on for the selected frame. The available fields are "Address", "ACK-A", "ACK-A2", "Data", "ACK-D". Remote command: TRIGger:SBSW:I2C:FIENable on page 1399 TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:ENABLE on page 1399
"Condition"	Displays the value condition for the selected field. Remote command: TRIGger:SBSW:I2C:BIT on page 1398 TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:BIT on page 1398
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: TRIGger:SBSW:I2C:DMAX on page 1398 TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:DMAX on page 1398 TRIGger:SBSW:I2C:DMIN on page 1399 TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:DMIN on page 1399 TRIGger:SBSW:I2C:DOPerator on page 1399 TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:DOPerator on page 1399
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: TRIGger:SBSW:I2C:IMAX on page 1400 TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:IMAX on page 1400 TRIGger:SBSW:I2C:IMIN on page 1400 TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:IMIN on page 1400 TRIGger:SBSW:I2C:IOPerator on page 1401 TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:IOPerator on page 1401

Error type

Enables triggering on the selected error type.

Remote command:

[TRIGger:SBSW:I2C:ERENable](#) on page 1401

[TRIGger:SBSW:I2C:ERRor<m>:ENABLE](#) on page 1401

14.4.6 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.4.7 I²C decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.




Figure 14-14: Decoded I²C signal

The decode results table contains information about all decoded frames.

Table 14-5: Content of the decode results table

Column	Description
Index	Index of the decoded frame
State	Overall state of the frame. "Insufficient waveform length" indicates that the frame is not completely contained in the acquisition. Change the horizontal scale, or move the reference point to the left to get a longer acquisition.

Column	Description
Start	Time of frame start
Symbol	Symbolic label of the frame. Available only, if "Show symbols" is enabled in the "Display" tab and a symbols list is loaded.
Address type	Address length, 7 bit or 10 bit
Address	Hexadecimal value of the address
RW bit	Value of the read/write bit
Value	The actual data payload values. Select the data format in the "Display" tab.
Data rate	Value of the data rate

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-6: Content of the frame details table

Item	Description
Index	Number of the decoded field
Label	Label (name) of each word of the data field
State	State of each word of the data field, for example "OK" or "Incomplete"
Value	Value of each word of the data field

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- `SBUS<sb>:FORMat` on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.4.5, "Decode results"](#), on page 1402.

14.4.8 Performing I²C decoding

This section explains step by step how to configure and decode the I²C bus.


For more information on decoding I²C, you can also refer to the video, available on the Rohde & Schwarz YouTube channel: [Decoding I2C with MXO Series Oscilloscopes](#).

14.4.8.1 Configuring I²C signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.4.2, "I²C configuration"](#), on page 532.

1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: "I²C".
4. Tap on "State" to enable the decoding.


An I²C shortcut appears at the bottom left of the screen. Tap on the shortcut for a quick access to the "I²C" dialog settings.



5. Tap on each active wire and select the correct channels: "SDA source" and "SCL source".
6. Check that the signals are on the screen.
If not try adjusting the vertical and horizontal settings.



7. Set the logical thresholds:
 - a) Tap the "Thresholds" tab.
 - b) For each wire, set the threshold value. A typical value is 1.65 V.
 - c) If necessary, set the hysteresis value for the wires.
 - d) Optionally, tap on "Show threshold lines".



14.4.8.2 Hardware triggering on I²C

Prerequisites: A bus is configured for the I²C signal to be analyzed. See [Section 14.4.8.1, "Configuring I²C signals"](#), on page 547.

1. Open "Menu" > "Trigger".
2. Set "Trigger on" to "Single event".
3. Ensure that the "Source" is set to the configured serial bus, e.g. "Serial bus 1".
4. Select the "Type".
5. Define additional settings for more complex trigger types: "No Ack", "Address", "Data", "Address + Data".
 - a) Tap on "Set details".
 - b) Set the "Data" condition and "Value".
 - c) Set the "Position".

In the following example a decode for triggering on triggered on "Data" = 0x75, "Position" = 1.



Figure 14-15: Trigger on Type=Data, Data=0x75 and Position=1

14.4.8.3 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the I²C and decoded.

1. Tap on the "I2C" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".
5. Select the "File type".

An export file is saved in the selected directory.

The I²C export files contain the following fields:

- A list of all decoded frames:
 - Index
 - Start
 - Stop
 - State
 - Address type
 - Address value
 - R/W bit
 - Bit rate
- The details frames include the following fields:
 - Index
 - Formatted data
 - ACK bit start
 - ACK bit

Example of an I²C export file

```
Index,Start,Stop,State,Address type,Address value,R/W bit,Bit rate
1,-0.25,-0.24945,'OK','BIT10',188h,'WRIT',100000
2,-0.24944,-0.249,'OK','BIT10',1h,'READ',100000
3,-0.24899,-0.24866,'OK','BIT7',5Bh,'READ',100000
4,-0.24865,-0.24821,'OK','BIT7',4Ah,'WRIT',100000
5,-0.2482,-0.24765,'OK','BIT10',188h,'WRIT',100000
6,-0.24764,-0.2472,'OK','BIT10',1h,'READ',100000
```

Details frame 1

```
Index,Formatted data,Ack bit start,Ack bit
1,DEh,-0.2497,'ACK'
2,C2h,-0.24959,'ACK'
3,B3h,-0.24948,'ACK'
```

Details frame 2

```
Index,Formatted data,Ack bit start,Ack bit
1,E1h,-0.24925,'ACK'
```

```

2,C2h,-0.24914,'ACK'
3,B3h,-0.24903,'ACK'

Details frame 3
Index,Formatted data,Ack bit start,Ack bit
1,E1h,-0.2488,'ACK'
2,C2h,-0.24869,'ACK'

Details frame 4
Index,Formatted data,Ack bit start,Ack bit
1,F1h,-0.24846,'ACK'
2,C4h,-0.24835,'ACK'
3,B3h,-0.24824,'NACK'

Details frame 5
Index,Formatted data,Ack bit start,Ack bit
1,DEh,-0.2479,'ACK'
2,C2h,-0.24779,'ACK'
3,B3h,-0.24768,'ACK'

```

14.5 I3C (IC electronics, option R&S MXO5C-K550)

The Improved Inter-Integrated Circuit (I3C) is a low-speed MIPI protocol used for communication between chips and signaling patterns by a 2-wire serial data bus.

Requirements

For performing I3C decode measurements, you need the following:

- MXO 5C with 2 available channels. The channels can be a combination of the following:
 - Analog channels (C1-C4)
 - Logic channels (D0-D15) (requires option R&S MXO5C-B1)
- Option R&S MXO5C-K550

• About the I3C protocol	552
• I3C configuration	553
• I3C filter	557
• I3C software trigger	560
• Measure	563
• I3C decode results	563
• Performing I3C decoding	565

14.5.1 About the I3C protocol

This section provides an overview of protocol characteristics, data format, address types and trigger possibilities. For detailed information, read the "MIPI I3C and I3C Basic" specifications, available at www.mipi.org/groups/I3C.

I3C characteristics

The Improved Inter-Integrated Circuit (I3C) protocol is a high-speed, low-power, and low-latency interface standard. Typical applications are mobile devices, IoT devices and automotive systems, for example. It incorporates the capabilities of I²C and SPI, while offering several advantages over these protocols.

The main characteristics of I3C are:

- Significantly lower energy consumption and higher data rate than I²C, but backward compatible with it.
- 2-wire operation with a serial clock line (SCL) and a serial data line (SDA) simplifies data exchange at low pin count and reduced signal paths.
- Supports multiple devices on the same bus, enabling a multi-drop topology.
- Optional messaging modes (HDR-DDR or HDR ternary) with high data rate up to 33.33 Mbit/s.
- In-band interrupt support without requiring a separate interrupt line.
- Hot-join support for dynamic device attachment and detachment.
- Synchronous timing support and asynchronous time stamping.
- Broadcast transactions allow sending commands or data to all devices on the bus simultaneously.

The MXO 5C supports all operating speed modes: legacy I²C modes (see [I²C characteristics](#)), SDR standard mode, DDR mode and ternary mode.

Data transfer

An I3C transaction consists of the following phases:

- **Start condition:** The controlling device sends a start condition to initiate the transaction.
- **Device addressing:** The controlling device sends the address of the responding device to select the target device.
- **Command:** The controlling device sends a command to the responding device, specifying the operation to be performed (e.g., read or write).
- **Data transfer:** The responding device responds with the requested data or sends data to the controlling device.
- **Stop condition:** The controlling device sends a stop condition to terminate the transaction.

The address format is the same as in I²C: 7 bits of address, 1 bit of RnW, and 1 bit of ACK/NACK. See [Section 14.4.1, "About the I²C protocol"](#), on page 530.




Figure 14-16: Example of using I3C coding SDR

Trigger

The MXO 5C can trigger on various parts of I3C messages. You must connect the data and clock lines to the input channels. Triggering on math and reference waveforms is not possible.


You can trigger on:

- Start or stop condition
- Repeated start condition
- Transfer direction (read or write)
- Bytes with missing acknowledge bit
- Specific target address or address range
- Specific data pattern in the message

14.5.2 I3C configuration

14.5.2.1 I3C configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "I3C" > "Setup".



Make sure that the tab of the correct serial bus is selected.

Protocol type

Selects the protocol type to be decoded.

Remote command:

`SBUS<sb>:TYPE` on page 1322

State

Enables the decoding of the selected bus. The signal icon of the bus appears on the signal bar.

Remote command:

`SBUS<sb>[:STATe]` on page 1322

SDA source

Sets the source channel to which the data line is connected.

Remote command:

`SBUS<sb>:I3C:SDA:SOURce` on page 1412

SCL source

Selects the source channel to which the clock line is connected.

Remote command:

`SBUS<sb>:I3C:SCL:SOURce` on page 1411

Require min gap

If enabled, the application requires a minimum gap on the left-hand side of the screen before the 1st decoded frame. Enabling this feature can prevent errors due to truncation of an HDR-type frame.

Remote command:

[SBUS<sb>:I3C:MINGap:SElect](#) on page 1412

Min gap width


Specifies the minimum gap width in units of time of the [Require min gap](#), if enabled.

Remote command:

[SBUS<sb>:I3C:MINGap:WIDTh](#) on page 1412

14.5.2.2 Threshold settings

Access: "Menu" > "Apps" > "Protocol" tab > "I2C" > "Thresholds".

**SDA/SCL threshold, SDA/SCL hysteresis**

Set the threshold for the SDA and SCL channels. Enter the value directly in the fields.

Additional to the threshold, you can also set a hysteresis for each channel.

Remote command:

[SBUS<sb>:I3C:SCL:THReshold](#) on page 1411

[SBUS<sb>:I3C:SDA:THReshold](#) on page 1412

[SBUS<sb>:I3C:SCL:HYSTeresis](#) on page 1411

[SBUS<sb>:I3C:SDA:HYSTeresis](#) on page 1411

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.


The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:

`SBUS<sb>:THReshold` on page 1325

14.5.2.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.



Decode layer

Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display.

See ["Decode layer"](#) on page 481.

Data format

See ["Data format"](#) on page 481.

Zoom coupling

See ["Zoom coupling"](#) on page 482.

Show symbols

Symbol lists are protocol-specific. Label lists for I3C are available in CSV format.

For details, see [I3C symbols](#).

Remote command:

[SBUS<sb>:I3C:SYMBOLs](#) on page 1413

[SBUS<sb>:I3C:NEWList](#) on page 1414

14.5.2.4 I3C symbols

For the I3C protocol, you can upload symbol lists containing IDs and a symbolic name for each node. You can load a file in one of the supported formats. Symbol lists for I3C are available in CSV format.

For each address, an I3C label file contains three values (or optionally two values, see ["Address type"](#) on page 557):

- Address type, 7-bit or 10-bit long
- Address value
- Symbolic label: name of the address, specifying its function in the bus network.

Example: I3C CSV file

```
# -----
@FILE_VERSION = 1.00
@PROTOCOL_NAME = i3c
# -----
# Labels for I3C protocol
# Column order: Identifier type, Identifier value, Label
# -----
7,0x1E,Voltage
7,38h,Pressure
7,2Ah,Temperature
7,16h,Speed
7,118,Acceleration
7,07h,HighSpeed_Master_0x3
7,51h,EEPROM
10,3A2h,DeviceSetup
10,1A3h,GatewayStatus
10,06Eh,LeftSensor
# -----
```




Address type

You can omit the address type, because I3C addresses are always 7-bit. Hence, the firmware also supports lines with only two entries: address value and symbolic label. For example, instead of "7, 0x1E, Voltage", also "0x1E, Voltage" is valid.

14.5.3 I3C filter

Access: "Menu" > "Apps" > "Protocol" tab > "I2C" > "Filter" tab

I3C (IC electronics, option R&S MXO5C-K550)



In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

- "Check all" Enables the filter for all available frames and error types.
- "Clear" Disables the filter for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
- "Preset" Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:I3C:FILTer:CHKall](#) on page 1415

[SBUS<sb>:I3C:FILTer:CLR](#) on page 1415

[SBUS<sb>:I3C:FILTer:INVert](#) on page 1415

[SBUS<sb>:I3C:FILTer:RST](#) on page 1415

Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.


Remote command:

[SBUS<sb>:I3C:FILTer:FRENAble](#) on page 1416

[SBUS<sb>:I3C:FILTer:FRAMe<fr>:ENABle](#) on page 1416

Edit

Opens a dialog to define the details of the selected frame.



"Field" Enables the field type that you want to filter on for the selected frame. The available fields are "ACK", "Address", "CCC", "Command", "CRC", "Data", "Def Byte", "P", "R/W" and "Reserved".

Remote command:

`SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:ENABLE`

on page 1419

`SBUS<sb>:I3C:FILTer:FIENable` on page 1419

"Condition" Displays the value condition for the selected field.

Remote command:

`SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:BIT`

on page 1419

"Value" The data setup consists of a comparison condition and one or two data patterns.

Remote command:

`SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:DMAX`

on page 1416

`SBUS<sb>:I3C:FILTer:DMAX` on page 1416

`SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:DMIN`

on page 1416

`SBUS<sb>:I3C:FILTer:DMIN` on page 1416

`SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:DOPerator`

on page 1417

`SBUS<sb>:I3C:FILTer:DOPerator` on page 1417

"Index" The index setup consists of a comparison condition and one or two index values.

Remote command:

[SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:IMAX](#)

on page 1417

[SBUS<sb>:I3C:FILTer:IMAX](#) on page 1417

[SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:IMIN](#)

on page 1418

[SBUS<sb>:I3C:FILTer:IMIN](#) on page 1418

[SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:IOPerator](#)

on page 1418

[SBUS<sb>:I3C:FILTer:IOPerator](#) on page 1418

Error type

Enables filtering on the selected error type.

Remote command:

[SBUS<sb>:I3C:FILTer:ERENable](#) on page 1417

[SBUS<sb>:I3C:FILTer:ERRor<n>:ENABLE](#) on page 1417


14.5.4 I3C software trigger

14.5.4.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.5.4.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "I3C" > "Trigger" tab > "Setup SB Trigger"



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

"Check all"	Enables the software trigger for all available frames and error types.
"Clear"	Disables the software trigger for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:I3C:CHKall](#) on page 1420

[TRIGger:SBSW:I3C:CLR](#) on page 1420

[TRIGger:SBSW:I3C:INVert](#) on page 1420

[TRIGger:SBSW:I3C:RST](#) on page 1421

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frames are available: "CCC Broadcast", "CCC Direct", "HDR-DDR", "HDR-Ternary", "I3C Probe", "Read" and "Write".

Remote command:

[TRIGger:SBSW:I3C:FREnable](#) on page 1421

[TRIGger:SBSW:I3C:FRAME<fr>:ENABLE](#) on page 1421

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.

The screenshot shows a configuration interface for I3C protocol analysis. On the left is a 'Back' button. The main area is titled 'Read' and contains a table with columns 'AND', 'Field', and 'Condition'. There are four rows:

	AND	Field	Condition
1	☐	Address	
2	☐	R/W	
3	☐	ACK	
4	☒	Data	= 52h [24 TO 255]

Below this table is a 'Data' section with two rows:

	Value	Index
Value	Equal ▼	52
Index	In range ▼	24 255

"Field" Enables the field type that you want to trigger on for the selected frame.

The available fields are "ACK", "Address", "CCC", "Command", "CRC", "Data", "Def Byte", "P", "R/W" and "Reserved".

Remote command:

[TRIGger:SBSW:I3C:FIENable](#) on page 1423

[TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:ENABLE](#) on page 1423

"Condition" Displays the value condition for the selected field.

Remote command:

[TRIGger:SBSW:I3C:BIT](#) on page 1421

[TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:BIT](#) on page 1421

"Value" The data setup consists of a comparison condition and one or two data patterns.

Remote command:

[TRIGger:SBSW:I3C:DMAX](#) on page 1422

[TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:DMAX](#) on page 1422

[TRIGger:SBSW:I3C:DMIN](#) on page 1422

[TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:DMIN](#) on page 1422

[TRIGger:SBSW:I3C:DOPerator](#) on page 1422

[TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:DOPerator](#) on page 1422

"Index" The index setup consists of a comparison condition and one or two index values.

Remote command:

[TRIGger:SBSW:I3C:IMAX](#) on page 1423

[TRIGger:SBSW:I3C:FRAMe<fr>:FLD<fl>:IMAX](#) on page 1423

[TRIGger:SBSW:I3C:IMIN](#) on page 1424

[TRIGger:SBSW:I3C:FRAMe<fr>:FLD<fl>:IMIN](#) on page 1424

[TRIGger:SBSW:I3C:IOPerator](#) on page 1424

[TRIGger:SBSW:I3C:FRAMe<fr>:FLD<fl>:IOPerator](#) on page 1424

Error type

Enables triggering on the selected error type.

Remote command:

[TRIGger:SBSW:I3C:ERENable](#) on page 1424

[TRIGger:SBSW:I3C:ERRor<m>:ENABle](#) on page 1424

14.5.5 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.5.6 I3C decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.




Figure 14-17: Decoded I3C signal

Purple = Address byte
 Blue = R/W bit
 Cyan = ACK bit
 Red = NACK bit
 Gold = Data byte
 Turquoise = Write frame
 Green = Read frame
 Crimson red = Incomplete frame

The decode results table contains information about all decoded frames.

Table 14-7: Content of the decode results table

Column	Description
Index	Index of the decoded frame
State	Overall state of the frame. "Incomplete" indicates that the frame is not completely contained in the acquisition. Change the horizontal scale, or move the reference point to the left to get a longer acquisition.
Start	Time of frame start
Type	Frame type
Symbol	Symbolic label of the frame. Available only, if "Show symbols" is enabled in the "Display" tab and a symbols list is loaded.
Address	Value of the address field of the frame, if available
Command	Value of the command field of the frame, if available
RW bit	Value of the read/write bit
Data values	The actual data payload values. Select the data format in the "Display" tab.
Bit rate	Calculated bit rate for this frame

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-8: Content of the frame details table

Item	Description
Index	Number of the decoded field
Label	Label (name) of each word of the data field
State	State of each word of the data field, for example "OK" or "Incomplete"
Value	Value of each word of the data field

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- [SBUS<sb>:FORMat](#) on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.5.4, "Decode results"](#), on page 1425.

14.5.7 Performing I3C decoding

This section explains step by step how to configure and decode the I3C bus.


For more information on decoding I3C, you can also refer to the video, available on the Rohde & Schwarz YouTube channel: [Decoding I2C with MXO Series Oscilloscope](#).

14.5.7.1 Configuring I3C signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.5.2, "I3C configuration"](#), on page 553.

1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: "I3C".
4. Tap on "State" to enable the decoding.

I3C (IC electronics, option R&S MXO5C-K550)

An I3C shortcut appears at the bottom left of the screen. Tap on the shortcut for a quick access to the "I3C" dialog settings.



5. Tap on each active wire and select the correct channels: "SDA source" and "SCL source".
6. Check that the signals are on the screen.
If not, try adjusting the vertical and horizontal settings.




Figure 14-18: Top (C2, green): serial data line (SDA), below (C1, yellow): serial clock line (SCL)

7. Set the logical thresholds:
 - a) Tap the "Thresholds" tab.
 - b) For each wire, set the threshold value. A typical value is 1.65 V.
 - c) If necessary, set the hysteresis value for the wires.
 - d) Optionally, tap on "Show threshold lines".



14.5.7.2 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for I3C and decoded.

1. Tap on the "I3C" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".
5. Select the "File type".
6. Tap "Save as".

A dialog opens for saving the export file in a selected directory.

The I3C export files contain the following fields:

- A list for all decoded frames:
 - "Index"
 - "Start"
 - "Stop"
 - "State" of the frame
 - "Type" of the frame
 - "Address", the value of the address field of that frame
 - "Command", the value of the command field of that frame
 - "RWBit", the value of the R/W bit of that frame
 - "CRC", the cyclic redundancy check value
 - "Bit-rate", the bit rate of the frame
- The frame details include the following fields:
 - "Label", the name of the field
 - "State", the state of the field

- "Value", the data value of the field

Example of an I3C export file

```
Index,Start,Stop,State,Type,Address,Command,RWBit,CRC,Bit-rate
1,-4.38003e-05,-3.19206e-05,'OK','BRDC',7Eh,00h,'WRIT',---,1000000
2,3.45864e-08,8.9946e-06,'OK','PROB',7Eh,---,'WRIT',---,1000000
3,1.14144e-05,1.54345e-05,'OK','WRIT',00h,---,'WRIT',---,12070000
4,3.62096e-05,4.58891e-05,'OK','BRDC',7Eh,20h,'WRIT',---,1000000
5,4.58891e-05,4.87292e-05,'OK','HDDR',66h,04h,---,05h,25170000
6,4.9079e-05,5.19291e-05,'OK','HDDR',11h,04h,---,1Fh,22270000
7,5.2279e-05,5.59291e-05,'OK','HDDR',55h,04h,---,1Bh,22280000
```

Details frame 1

```
Index,Label,State,Value
1,'Data: 1','OK',12h
2,'Data: 2','OK',34h
3,'Data: 3','OK',56h
```

Details frame 3

```
Index,Label,State,Value
1,'Data: 1','OK',ABh
2,'Data: 2','OK',CDh
```

Details frame 5

```
Index,Label,State,Value
1,'Data: 1','OK',1020h
2,'Data: 2','OK',ABCDh
```

Details frame 6

```
Index,Label,State,Value
1,'Data: 1','OK',EFF0h
2,'Data: 2','OK',1D2Eh
```

Details frame 7

```
Index,Label,State,Value
1,'Data: 1','OK',0123h
2,'Data: 2','OK',4567h
3,'Data: 3','OK',FEDCh
```

14.6 UART (IC electronics, option R&S MXO5C-K510)

The Universal Asynchronous Receiver/Transmitter UART converts a word of data into serial data, and vice versa. It is the base of many serial protocols such as RS-232.



For basic information on UART, you can also refer to a video, available on the Rohde & Schwarz YouTube channel: [Understanding UART](#).

Requirements

For performing UART decode measurements, you need the following:

- MXO 5C with 2 available channels. The channels can be a combination of the following:
 - Analog channels (C1-C4)
 - Logic channels (D0-D15) (requires option R&S MXO5C-B1)
- Two probes
- Option R&S MXO5C-K510

• About the UART / RS-232 interface	569
• UART configuration	570
• UART filter	573
• UART hardware trigger	575
• UART software trigger	576
• Measure	579
• UART decode results	579
• Performing UART decoding	581

14.6.1 About the UART / RS-232 interface

The UART uses only one line, or two lines for transmitter and receiver.

Data transfer

The data is transmitted in words, also referred to as symbols or characters. Each word consists of a start bit, several data bits, an optional parity bit, and one or more stop bits. Several words can form a package, or frame. The end of a package is marked with a reserved word or by a pause between two words.

Start	Data0	Data1	Data2	Data3	Data4	[Data5]	[Data6]	[Data7]	[Data8]	[Parity]	Stop

Figure 14-19: Bit order in a UART word (symbol)

- The start bit is a logic 0.
- The stop bits and the idle state are always logic 1.

The UART protocol has no clock for synchronization. The receiver synchronizes by the start and stop bits, and the bit rate that must be known to the receiver.

Trigger


The MXO 5C can trigger on specified parts of UART serial signals:

- Start bit
- Packet start
- Parity errors, and breaks
- Stop errors
- A serial pattern at any or a specified position

14.6.2 UART configuration

14.6.2.1 UART configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "UART / RS232" > "Setup".



Protocol type

Selects the protocol type to be decoded.

Remote command:

`SBUS<sb>:TYPE` on page 1322

State

Enables the decoding of the selected bus. The signal icon of the bus appears on the signal bar.

Remote command:

`SBUS<sb>[:STATe]` on page 1322

Source: Tx, Rx

Select the input channels for the transmitter and receiver signals.

Do not combine a reference waveform with a channel or math waveform because the time correlation of these waveforms can differ.

Remote command:

[SBUS<sb>:UART:TX:SOURce](#) on page 1438

[SBUS<sb>:UART:RX:SOURce](#) on page 1437

Bit order

Selects the bit order, which determines if the data of the messages starts with MSB (most significant bit) or LSB (least significant bit).

Remote command:

[SBUS<sb>:UART:BORDER](#) on page 1435

Polarity

Defines the logic levels of the bus. The idle state corresponds to a logic 1. The start bit corresponds to a logic 0. "Idle high" (high=1) is used, for example, for control signals, while "Idle low" (low=1) is defined for data lines (RS-232).

Remote command:

[SBUS<sb>:UART:POLarity](#) on page 1436

Bit rate

Sets the number of transmitted bits per second.

Remote command:

[SBUS<sb>:UART:BITRate](#) on page 1435

Stop bits

Sets the number of stop bits: 1 or 1.5 or 2 stop bits are possible.

Remote command:

[SBUS<sb>:UART:SBIT](#) on page 1437

Data bits

Sets the number of data bits of a word in a range from 5 bits to 8 bits. If no parity bit is used, then 9 data bits are possible.

Remote command:

[SBUS<sb>:UART:SSIZE](#) on page 1437

Parity

Defines the optional parity bit that is used for error detection.

"None"	No parity bit is used.
"Odd"	The parity bit is set to "1" if the number of data bits set to "1" is even.
"Even"	The parity bit is set to "1" if the number of data bits set to "1" is odd.
"Mark"	The parity bit is always a logic 1.
"Space"	The parity bit is always a logic 0.
"Don't care"	The parity is ignored.

Remote command:

[SBUS<sb>:UART:PARity](#) on page 1436

Packets

Allows you to define packets of several words in the data stream.

"None" Packets are not considered.

"Timeout" Defines a timeout between a stop bit and the next start bit. Enter the minimum time that marks the end of a packet.
A new packet starts with the first start bit after the timeout.


Remote command:

[SBUS<sb>:UART:PACKets](#) on page 1435

[SBUS<sb>:UART:TOUT](#) on page 1438

14.6.2.2 Threshold settings

Access: "Menu" > "Apps" > "Protocol" tab > "UART / RS232" > "Thresholds".



Threshold

Sets the threshold for the TX and RX channels. Enter the value directly in the fields.

Additional to the threshold, you can also set a hysteresis.

Remote command:

[SBUS<sb>:UART:RX:HYSTeresis](#) on page 1436

[SBUS<sb>:UART:RX:THReshold](#) on page 1437

[SBUS<sb>:UART:TX:HYSTeresis](#) on page 1438

[SBUS<sb>:UART:TX:THReshold](#) on page 1439

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.

The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:


[SBUS<sb>:THReshold](#) on page 1325

14.6.2.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.

14.6.3 UART filter

Access:"Menu" > "Apps" > "Protocol" tab > "UART / RS232" > "Filter" tab



In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

"Check all"	Enables the filter for all available frames and error types.
"Clear"	Disables the filter for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:UART:FILTer:CHKall](#) on page 1441

[SBUS<sb>:UART:FILTer:CLR](#) on page 1441

[SBUS<sb>:UART:FILTer:INVert](#) on page 1441

[SBUS<sb>:UART:FILTer:RST](#) on page 1441

Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

The available frames are "Tx", "Rx".


Remote command:

[SBUS<sb>:UART:FILTer:FRAMe<fr>:ENABle](#) on page 1445

[SBUS<sb>:UART:FILTer:FRENAble](#) on page 1445

Edit

Opens a dialog to define the details of the selected frame.



UART (IC electronics, option R&S MXO5C-K510)

"Field"	Enables the field type that you want to filter on for the selected frame. The available field is "Data". Remote command: SBUS<sb>:UART:FIleTer:FIENable on page 1445 SBUS<sb>:UART:FIleTer:FRAMe<fr>:FLD<fl>:ENABle on page 1445
"Condition"	Displays the value condition for the selected field. Remote command: SBUS<sb>:UART:FIleTer:FRAMe<fr>:FLD<fl>:BIT on page 1444
"Data"	The data setup consists of a comparison condition and one or two data patterns. Remote command: SBUS<sb>:UART:FIleTer:FRAMe<fr>:FLD<fl>:DMAX on page 1444 SBUS<sb>:UART:FIleTer:DMAX on page 1444 SBUS<sb>:UART:FIleTer:FRAMe<fr>:FLD<fl>:DMIN on page 1443 SBUS<sb>:UART:FIleTer:DMIN on page 1443 SBUS<sb>:UART:FIleTer:FRAMe<fr>:FLD<fl>:DOPerator on page 1443 SBUS<sb>:UART:FIleTer:DOPerator on page 1443
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: SBUS<sb>:UART:FIleTer:FRAMe<fr>:FLD<fl>:IMAX on page 1442 SBUS<sb>:UART:FIleTer:IMAX on page 1442 SBUS<sb>:UART:FIleTer:FRAMe<fr>:FLD<fl>:IMIN on page 1442 SBUS<sb>:UART:FIleTer:IMIN on page 1442 SBUS<sb>:UART:FIleTer:FRAMe<fr>:FLD<fl>:IOPerator on page 1442 SBUS<sb>:UART:FIleTer:IOPerator on page 1442

Error type

Enables filtering on the selected error type.


Available error types are "Start error", "Stop error", "Parrrity error", "Break".

Remote command:

[SBUS<sb>:UART:FIleTer:ERRor<n>:ENABle](#) on page 1443

14.6.4 UART hardware trigger

Access: "Menu" > "Apps" > "Protocol" tab > "UART / RS232" > "Trigger" tab > "Setup Hardware Trigger"

**Data conditions**

Specify the data conditions if the trigger type is set to "Data".

Data ← Data conditions

Selects the operator for the "Data" pattern.

Remote command:

[TRIGger:SBHW:UART:FCONdition](#) on page 1446

Value ← Data conditions

Specifies the data pattern to be found on the specified trigger source. Enter the words in MSB first bit order.

Remote command:

[TRIGger:SBHW:UART:DATA](#) on page 1446

Position ← Data conditions

Sets the number of words before the first word of interest. These offset words are ignored.

The setting is available if packet detection is enabled in the protocol configuration.

Remote command:

[TRIGger:SBHW:UART:DPOSition](#) on page 1446


14.6.5 UART software trigger

14.6.5.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.6.5.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "UART / RS232" > "Trigger" tab > "Setup Software Trigger" > "Setup SB Trigger".



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

"Check all"	Enables the software trigger for all available frames and error types.
"Clear"	Disables the software trigger for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:UART:CHKall](#) on page 1448

[TRIGger:SBSW:UART:CLR](#) on page 1448

[TRIGger:SBSW:UART:INVert](#) on page 1448

[TRIGger:SBSW:UART:RST](#) on page 1448

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frames are available: "Tx" and "Rx".


Remote command:

[TRIGger:SBSW:UART:FRAME<fr>:ENABLE](#) on page 1449

[TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:ENABLE](#) on page 1450

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



"Field"

Enables the field type that you want to trigger on for the selected frame.

The available field is "Data".

Remote command:

[TRIGger:SBSW:UART:FIENable](#) on page 1450

[TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:ENABLE](#) on page 1450

"Condition"	Displays the value condition for the selected field. Remote command: TRIGger:SBSW:UART:BIT on page 1449 TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:BIT on page 1449
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: TRIGger:SBSW:UART:DMAX on page 1449 TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:DMAX on page 1449 TRIGger:SBSW:UART:DMIN on page 1450 TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:DMIN on page 1450 TRIGger:SBSW:UART:DOPerator on page 1450 TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:DOPerator on page 1450
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: TRIGger:SBSW:UART:IMAX on page 1451 TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:IMAX on page 1451 TRIGger:SBSW:UART:IMIN on page 1451 TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:IMIN on page 1451 TRIGger:SBSW:UART:IOPerator on page 1452 TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:IOPerator on page 1452

Error type

Enables triggering on the selected error type.

The following error types are available: "Start error", "Stop error", "Parity error", "Break".

Remote command:

[TRIGger:SBSW:UART:ERENable](#) on page 1452

[TRIGger:SBSW:UART:ERROR<m>:ENABLE](#) on page 1452

14.6.6 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.6.7 UART decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.

2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.



Figure 14-20: Decoded UART signal

The decode results table contains information about all decoded frames.

Table 14-9: Content of the decode results table

Column	Description
Index	Number of the decoded frames
State	Decoding state of the word. "Insufficient waveform length" indicates that the word is not completely contained in the acquisition. Change the horizontal scale, or move the reference point to the left to get a longer acquisition.
Start	Time of the word start (start bit)
Stop	Time of the word stop (stop bit)
Tx value	Value of the Tx word. Select the data format in the "Display" tab.

Column	Description
Rx value	Value of the Rx word. Select the data format in the "Display" tab.
Data rate	Value of the data rate

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- `SBUS<sb>:FORMat` on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.6.5, "Decode results"](#), on page 1453.

14.6.8 Performing UART decoding

This section explains step by step how to configure and decode the UART bus.


For more information on decoding UART, you can also refer to the video, available on the Rohde & Schwarz YouTube channel: [Decoding UART with MXO Series Oscilloscopes](#).

14.6.8.1 Configuring UART signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.

For details on configuration settings, see [UART configuration](#).


1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: "UART".
4. Tap on "State" to enable the decoding.

An SPI shortcut appears at the bottom left of the screen. Tap on the shortcut for a quick access to the "UART / RS232" dialog settings.


UART (IC electronics, option R&S MXO5C-K510)



5. Select the correct channels for each active line: "Tx" and "Rx".
6. Set the "Bit rate".
7. Set the "Data bits". Typical value is 7 or 8.
8. Set the "Stop bits". Typical value is 1.
9. Set the "Parity" to "None", "Odd" or "Even".
10. Set "Bit order" to "MSB" or "LSB first".
11. Set the "Packets".
12. Set the "Timeout".
13. Set the "Polarity" to "Idle high" or "Idle low".
14. Check that the signals are on the screen.
If not try adjusting the vertical and horizontal settings.



15. Set the logical thresholds:
 - a) Tap the "Thresholds" tab.
 - b) For each line, set the threshold value. A typical value is 2.5 V.
 - c) If necessary, set the hysteresis value for the wires.
 - d) Optionally, tap on "Show threshold lines".



14.6.8.2 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the UART and decoded.

1. Tap on the "UART / RS232" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".
5. Select the "File type".

An export file is saved in the selected directory.

The UART export files contain the following fields:

- Index
- Start
- Stop
- Source
- State
- TX value
- RX value
- Bit rate

Example UART export file

```
Index,Start,Stop,Source,State,Tx value,Rx value,Bit rate
1,-0.0629961,-0.0629531,'TX','OK',33h,---,256000
2,-0.0629453,-0.0629023,'RX','OK',---,F5h,256000
3,-0.0628945,-0.0628516,'TX','STER',C8h,---,256000
4,-0.0628438,-0.0628008,'RX','SPER',---,28h,256000
5,-0.062793,-0.06275,'TX','PRER',A8h,---,256000
```

14.7 NRZ clocked & unclocked (option R&S MXO5C-K510)


NRZ is a communication protocol for triggering at data rates up to 50 Mbit/s. It is suited for fast eye-diagram mask testing.

The NRZ protocol can either be **clocked** or **unclocked**. NRZ unclocked signals require a user-defined bit rate and gap time setting for triggering and decoding.

• NRZ basics	584
• NRZ configuration	584
• NRZ filter	588
• NRZ frame format configuration	592
• NRZ software trigger	601
• Measure	605
• Performing NRZ decoding	605
• NRZ decode results	607

14.7.1 NRZ basics

In this line coding scheme, NRZ stands for "non-return-to-zero": The logical 1 is represented by a high voltage level, and the logical 0 is represented by a low voltage level:



The voltage remains at the same level for the entire bit period, without returning to a zero voltage level between bits. The voltage level changes only when the data bit changes.

Therefore, NRZ is an efficient protocol for high-speed serial data transmission. Its simplicity and low overhead make it a good choice for applications where data integrity and reliability are critical. It requires only half the bandwidth of the related Manchester code, which uses phase-shift keying.

14.7.2 NRZ configuration

14.7.2.1 NRZ configuration settings

Access:

- "Menu" > "Apps" > "Protocol" tab > "NRZ Clocked" > "Setup".
- "Menu" > "Apps" > "Protocol" tab > "NRZ Unclocked" > "Setup".

NRZ clocked & unclocked (option R&S MXO5C-K510)




Figure 14-21: Setup dialog, left: clocked version, right: unclocked version of NRZ

Data source

Selects the source for the data signal.

Remote command:

[SBUS<sb>:NRZC:DATA:SOURce](#) on page 1457

[SBUS<sb>:NRZU:DATA:SOURce](#) on page 1484

Clock source

Available only for "NRZ Clocked".

Selects the source for the clock signal.

Remote command:

[SBUS<sb>:NRZC:CLK:SOURce](#) on page 1457

Data polarity

Selects the polarity for the data signal.

Remote command:

[SBUS<sb>:NRZC:DATA:POLarity](#) on page 1458

[SBUS<sb>:NRZU:DATA:POLarity](#) on page 1485

Clock polarity

Available only for "NRZ Clocked".

Selects the polarity for the clock signal.

Remote command:

[SBUS<sb>:NRZC:CLK:POLarity](#) on page 1457

Enable source

Selects the source of the enable signal.

If you select any source other than "None", the "Enable polarity" becomes available, which selects the polarity of the enable signal.

Remote command:

[SBUS<sb>:NRZC:ENABle:SOURce](#) on page 1458

[SBUS<sb>:NRZC:ENABle:POLarity](#) on page 1458

[SBUS<sb>:NRZU:ENABle:SOURce](#) on page 1485

[SBUS<sb>:NRZU:ENABle:POLarity](#) on page 1485

Check gap time

Enables the detection of the minimum idle time between two frames during decoding. Also enables setting the "Min gap time". If you set it, the decoder considers any longer idle time a gap.

Remote command:

[SBUS<sb>:NRZC:MINGap:SElect](#) on page 1459

[SBUS<sb>:NRZU:MINGap:SElect](#) on page 1486

[SBUS<sb>:NRZC:MINGap:WIDTh](#) on page 1459

[SBUS<sb>:NRZU:MINGap:WIDTh](#) on page 1486

Check bit rate

Available only for "NRZ Unclocked".

Enables setting the "Bit rate".

- If you define a bit rate, it is used for triggering and decoding.
- If you disable this option, the decoder calculates the bit rate.

Remote command:

[SBUS<sb>:NRZU:BITRate:SElect](#) on page 1486

[SBUS<sb>:NRZU:BITRate:WIDTh](#) on page 1487

14.7.2.2 Thresholds

Access:

- "Menu" > "Apps" > "Protocol" tab > "NRZ Clocked" > "Thresholds"
- "Menu" > "Apps" > "Protocol" tab > "NRZ Unclocked" > "Thresholds"

NRZ clocked & unclocked (option R&S MXO5C-K510)




Figure 14-22: Thresholds dialog, left: clocked version, right: unclocked version of NRZ

Enter the values directly in the fields.

Data threshold, Data hysteresis

Sets the middle threshold and the hysteresis for the data source channel.

Remote command:

[SBUS<sb>:NRZU:DATA:THReshold](#) on page 1487

[SBUS<sb>:NRZU:DATA:HYSTeresis](#) on page 1487

[SBUS<sb>:NRZC:DATA:THReshold](#) on page 1460

[SBUS<sb>:NRZC:DATA:HYSTeresis](#) on page 1460

Clock threshold, Clock hysteresis

Available only for "NRZ Clocked".

Sets the middle threshold and the hysteresis for the clock source channel.

Remote command:

[SBUS<sb>:NRZC:CLK:THReshold](#) on page 1459

[SBUS<sb>:NRZC:CLK:HYSTeresis](#) on page 1460

Enable threshold, Enable hysteresis

Available only, if you have selected a source for the enable signal. See ["Enable source"](#) on page 586.

Sets the middle threshold and the hysteresis for the enable source channel.

Remote command:

[SBUS<sb>:NRZC:ENABLE:THReshold](#) on page 1460

[SBUS<sb>:NRZC:ENABLE:HYSTeresis](#) on page 1461

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.

The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:

`SBUS<sb>:THReshold` on page 1325

14.7.2.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.

Decode layer

Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display.

"Off" Disables the display of the decode layer.

"Edges" Enables the display of all edges.

"Bits" Enables the display of all encoded bits.

Data format

See ["Data format"](#) on page 481.

14.7.2.4 NRZ symbols

There is no symbolic translation for NRZ protocols, because of the custom frame definitions.


14.7.3 NRZ filter

Access:

- "Menu" > "Apps" > "Protocol" tab > "NRZ Clocked" > "Filter" tab
- "Menu" > "Apps" > "Protocol" tab > "NRZ Unclocked" > "Filter" tab

Although NRZ has a free format description according to [section 14.7.4, "NRZ frame format configuration"](#), on page 592, we provide a dynamic filter solution that can adapt to custom frames and fields in the decoded events.

In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.



Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

- "Check all" Enables the filter for all available frames and error types.
- "Clear" Disables the filter for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
- "Preset" Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:NRZC:FILTer:CHKall](#) on page 1462

[SBUS<sb>:NRZU:FILTer:CHKall](#) on page 1489

[SBUS<sb>:NRZC:FILTer:CLR](#) on page 1462

[SBUS<sb>:NRZU:FILTer:CLR](#) on page 1489

[SBUS<sb>:NRZC:FILTer:INVert](#) on page 1462

[SBUS<sb>:NRZU:FILTer:INVert](#) on page 1489

[SBUS<sb>:NRZC:FILTer:RST](#) on page 1463

[SBUS<sb>:NRZU:FILTer:RST](#) on page 1490

Enable

Enables the filtering on NRZ frames. Only the frames that match the selected filter conditions are displayed.

Remote command:

[SBUS<sb>:NRZC:FILTer:FREnAbLe](#) on page 1465

[SBUS<sb>:NRZC:FILTer:FRAMe<fr>:ENABLe](#) on page 1465

[SBUS<sb>:NRZU:FILTer:FREnAbLe](#) on page 1492

[SBUS<sb>:NRZU:FILTer:FRAMe<fr>:ENABLe](#) on page 1492

Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

The only frame type available by default is "Undescribed", because the NRZ protocols support custom coding.

However, the frame formats that you define appear in this list, too. See [Section 14.7.4, "NRZ frame format configuration"](#), on page 592.

Edit

Opens a dialog to define the details of the selected frame.

Serial bus:
NRZ Clocked

SB1

Back

Undescribed

	AND	Field	Condition
1	☒	Word	< 25h [1 TO 65535]

Word

Value
Less than ▼ 25

Index
In range ▼ 1 65535

"Field"	Enables the field type that you want to filter on for the selected frame. For the default "Undescribed" frame, the only available field type is "Word", which is the payload component of an undescribed frame. See "Frame type" on page 590. However, the field formats that you define appear in this list, too. See Section 14.7.4, "NRZ frame format configuration", on page 592. Remote command: SBUS<sb>:NRZC:FILTer:FIENable on page 1465 SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:ENABLE on page 1465 SBUS<sb>:NRZU:FILTer:FIENable on page 1492 SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:ENABLE on page 1492
"Condition"	Displays the value condition for the selected field. Remote command: SBUS<sb>:NRZC:FILTer:BIT on page 1463 SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:BIT on page 1463 SBUS<sb>:NRZU:FILTer:BIT on page 1490 SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:BIT on page 1490
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: SBUS<sb>:NRZC:FILTer:DMax on page 1464 SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:DMax on page 1464 SBUS<sb>:NRZU:FILTer:DMax on page 1491 SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:DMax on page 1491 SBUS<sb>:NRZC:FILTer:DMin on page 1464 SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:DMin on page 1464 SBUS<sb>:NRZU:FILTer:DMin on page 1491 SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:DMin on page 1491 SBUS<sb>:NRZC:FILTer:DOPerator on page 1464 SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:DOPerator on page 1464 SBUS<sb>:NRZU:FILTer:DOPerator on page 1491 SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:DOPerator on page 1491

"Index"

The index setup consists of a comparison condition and one or two index values.

Remote command:

`SBUS<sb>:NRZC:FILTer:IMAX` on page 1466

`SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:IMAX`
on page 1466

`SBUS<sb>:NRZU:FILTer:IMAX` on page 1492

`SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:IMAX`
on page 1492

`SBUS<sb>:NRZC:FILTer:IMIN` on page 1466

`SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:IMIN`
on page 1466

`SBUS<sb>:NRZU:FILTer:IMIN` on page 1493

`SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:IMIN`
on page 1493

`SBUS<sb>:NRZC:FILTer:IOPerator` on page 1466

`SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:IOPerator`
on page 1466

`SBUS<sb>:NRZU:FILTer:IOPerator` on page 1493

`SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:IOPerator`
on page 1493

Error type

Enables filtering on the selected error type.

The available error types are "Length error", "CRC error", "Parity error", "Incomplete".

Remote command:

`SBUS<sb>:NRZC:FILTer:ERENable` on page 1463


`SBUS<sb>:NRZC:FILTer:ERRor<n>:ENABle` on page 1463

`SBUS<sb>:NRZU:FILTer:ERENable` on page 1490

`SBUS<sb>:NRZU:FILTer:ERRor<n>:ENABle` on page 1490

14.7.4 NRZ frame format configuration

This dialog enables you to describe the generic format and logical structure of your NRZ protocol. To do so, you can create customized frame descriptions of various structures and lengths.



A frame format description (or *frame description*, for short) is represented by one line in the frame format description list (or *frame list*, for short). Describing a frame format requires assigning it a name and specifying field descriptions, which must be sequential and complete. No gaps are allowed, because the field descriptions are used to calculate the start position of the next frame.

See also:

- ["Frame name"](#) on page 596
- ["Frame Color"](#) on page 597

The frame identification is executed top down, in the order in which the frame formats are described in the frame list. This provides a hierarchy of criteria for identifying frames. A frame is identified when all user-defined conditions of the field descriptions are met. See ["Condition"](#) on page 598. These conditions can be regarded as related by the Boolean **AND** operator.

A condition can also locate a synchronization pattern, specified by the equal operator in the field. For example, if you define a "Preamble" field with the condition `=FFFFFFFF`, the decoder scans the data for this pattern, and then synchronizes to it.

If no frame description is suitable to identify an incoming frame, by default such a "missed" frame is reproduced as "Undescribed Bits" in the honeycomb display. These bits are not shown in the results table.

If you have not defined an "equal" operator for any field of a frame description, you can use this description to positively identify each kind of frame. Hence, it "catches" every frame, even if there are other frame descriptions to follow in the frame list. Therefore, if

you use a "catch all" frame description, we recommend to place it at the end of the frame list, otherwise it overwrites any subsequent frame description. However, instead of using a "catch all" frame description, consider using the default "Undescribed Bits" display mentioned above.


It is in your responsibility to define unambiguous descriptions for each frame type.

Add Frame

Creates a new **frame description** and adds it to the end of the frame list.

When you add a frame or when you click an existing entry in the frame list, a dialog opens that allows the following:

- [Add Field](#)
- [Edit List](#)
- [Frame name](#)
- [Frame Color](#)



When you return to the frame list by using the "Back" button, a dialog opens that allows the following:

- [Add Frame](#)
- [Edit List](#)
- [Open](#)
- [Save as](#)

The number of frame descriptions is limited to 100.

Remote command:

[SBUS<sb>:NRZC:FORMat:ADDFrame](#) on page 1467

[SBUS<sb>:NRZU:FORMat:ADDFrame](#) on page 1494

**Edit List**

Enables editing the frame list. If enabled, you can delete a frame description by clicking its "Delete" icon. In a list with several entries, you can move frame descriptions up or down by clicking the arrow buttons. To exit the editing mode, click "Edit List" again.

Remote command:

[SBUS<sb>:NRZC:FORMat:CLR](#) on page 1468

[SBUS<sb>:NRZU:FORMat:CLR](#) on page 1495

[SBUS<sb>:NRZC:FORMat:FCOunt?](#) on page 1468

[SBUS<sb>:NRZU:FORMat:FCOunt?](#) on page 1495

Open

Opens a dialog for loading an existing list of frame descriptions in XML file format.

Remote command:

[SBUS<sb>:NRZC:FORMat:LOAD](#) on page 1467

[SBUS<sb>:NRZU:FORMat:LOAD](#) on page 1494

Save as

Opens a dialog for saving your current list of frame descriptions to an XML file. Saved frame descriptions can support efficient and convenient working.

Remote command:

[SBUS<sb>:NRZC:FORMat:SAVE](#) on page 1468


[SBUS<sb>:NRZU:FORMat:SAVE](#) on page 1495

Add Field

Creates a new **field description** for the currently selected frame description and adds it to the end of the field list.

When you add a field or when you click an existing entry in the field list, a dialog opens that allows the following for describing a field:

- [Field name](#)
- [Field Color](#)
- [Bit count](#)
- [Condition](#)
- [Numeric format](#)
- [Bit order](#)
- [Result column](#)



When you return to the field list by using the "Back" button, a dialog opens that allows the following:

- [Add Field](#)
- [Edit List](#)
- [Frame name](#)
- [Frame Color](#)

The number of field descriptions is limited to 100.

Remote command:

[SBUS<sb>:NRZC:FORMat:FRAMe<fr>:ADDField](#) on page 1469

[SBUS<sb>:NRZU:FORMat:FRAMe<fr>:ADDField](#) on page 1495



Edit List

Enables editing the field list. If enabled, you can delete a field description by clicking its "Delete" icon. In a list with several entries, you can move field descriptions up or down by clicking the arrow buttons. To exit the editing mode, click "Edit List" again.

Remote command:

[SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLDCount?](#) on page 1469

[SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLDCount?](#) on page 1496

Frame name

Specifies an arbitrary name to label the currently selected frame description. Ideally, use speaking names according to the specifications of the applicable protocol standard. For example, MDIO (Management Data Input/Output) specifies the frames "READ", "WRITE", "ADDRESS". Frame names do not have to be unique and are only intended to support you.

Remote command:

`SBUS<sb>:NRZC:FORMat:FRAMe<fr>:NAME` on page 1469

`SBUS<sb>:NRZU:FORMat:FRAMe<fr>:NAME` on page 1496

Frame Color

Selects a color for labeling the currently selected frame description.

Remote command:

`SBUS<sb>:NRZC:FORMat:FRAMe<fr>:COLor` on page 1469

`SBUS<sb>:NRZU:FORMat:FRAMe<fr>:COLor` on page 1496

Field name

Specifies an arbitrary name for the currently selected field description. Ideally, use speaking names.

Field names do not have to be unique and are only intended to support you.

Remote command:

`SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:NAME` on page 1470

`SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLD<fl>:NAME` on page 1497

Field Color

Opens a dialog to select the color representation of different fields in the honeycomb display. Assigning specific colors can help you to interpret the decode results more easily. You can select a predefined color or specify a "User-defined color".

Remote command:

`SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:COLor` on page 1470

`SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLD<fl>:COLor` on page 1497

Bit count

Specifies the bit count and hence the length of the field represented by the currently selected field description. You can click the field to open a keypad dialog, which also displays the minimum and maximum permitted values. Its "Min", "Max" or "Reset" buttons can set the bit count to the minimum, maximum or reset value. The "Inc" or "Dec" button increases or decreases the value in steps of 1 or 10, depending on the selected step size button. The "CE" button sets the bit count to the value that was used before the keypad was displayed.

If, for a given bit count, the [Condition](#) value is longer, it is truncated. If the condition value is shorter, it is padded with 0. Both truncation and padding occur at the left side of the condition value and relate to the [Bit order](#).

Examples:

- If "Condition" is "=111000" and the "Bit order" is "MSB":
 - If "Bit count" is 4, the truncated condition is "=1000"
 - If "Bit count" is 8, the padded condition is "=00111000"
- If "Condition" is "=111000" and the "Bit order" is "LSB" (accordingly, the condition in "MSB" format would be "=000111"):
 - If "Bit count" is 4, the truncated condition is "=1000" for "LSB" and "=0001" for "MSB"
 - If "Bit count" is 8, the padded condition is "=00111000" for "LSB" and "=00011100" for "MSB"

Remote command:

`SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:BITCount` on page 1470

`SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLD<fl>:BITCount` on page 1497

Condition

Specifies a condition for the field, typically a bit sequence that is used for pattern-matching to identify the frame.

Use this text box to apply various conditions and functionalities for a field. Among others, you can use it to identify mandatory values, such as CRC checksum or ID, which help to identify a frame. The condition value must match also the [Numeric format](#) and [Bit order](#).

The following conditions are implemented:

"= (equal)"

The **equal** operator (represented by the "=" sign) defines a pattern for the field to match. Valid condition entries are characters that match the field's defined "Format", "Bit order", and "Bits". In binary format, for example, valid characters are "1", "0", "H" (high), and "L" (low).

Three cases have to be distinguished (cases A, B1, and B2), depending on the presence of a [Variable Length Array](#): `[]` in the same frame description:

- **Case A:** If there is **no** "Variable Length Array" field, then each field marked with the equal operator acts as a key to identify a frame type. Only if all these fields match up with the expected value, the frame type is identified.
- **Cases B1 and B2:** If there **is** a "Variable Length Array" field, then the equal operator has two different functionalities, depending on the position of the equal-operator field within the frame description:
 - **B1:** If the field is located *anywhere before* the "Variable Length Array" field, the condition acts as a key to identify a frame type (as in case A).
 - **B2:** If the field is located *immediately after* the "Variable Length Array" field, the condition acts as an array delimiter. (Note: If the field, which is marked with the equal operator, is located after the "Variable Length Array" field, but *not* immediately after it, the decode result is unpredictable.)

"[] (array)"

The **array** operator (represented by the "[" and "]" bracket signs) defines the number of permissible repetitions of the field.

Example: Fixed-Length Array: [n]

The length parameter "n" is a decimal number > 0 , which determines that the field is repeated n times within the frame. If, for example, the **Bit count** is 8, then the array operator identifies n fields of 8-bit length, and present them in the results table and honeycomb display with the specified name and color.

A fixed-length array is treated the same as other fields, except the real length of such an array is $n \cdot \text{bit count}$.

Example: Variable Length Array: []

This array operator with empty "[" and "]" bracket signs does not determine a fixed size array. The field could be repeated any number of times, including 0 times. As a result, the field and the frame are of unspecified length (a situation that covers typical use cases).

The length of the frame is then determined by the end of frame condition, which can be an operator or a gap.

For processing reasons, only one (1) variable length array is supported in a frame, and a delimiter must follow immediately in the next field after it. This is required to enable the software to correctly terminate the array. Otherwise the bits could not be assigned correctly, and it would not be possible to determine where a repetition starts and where it ends. With an end of frame condition, the software can calculate the length of one single array within a frame. But if there were more arrays, it would be impossible to know which array was how long.

The variable length array can also be the last field of a frame. In this case, no delimiter is required. If decoded successfully, the detailed view in the results table shows the elements of the array. If the field name of the array is "Data", then the detail view of result table displays the elements with an array index as "Data: 1", "Data: 2" ... etc. If the variable length array field is selected, it is shown as array [n], where n is the actual size detected in the waveform.

As an exception to the rule, it is permissible to assign the variable length array to consecutive fields. In this case, the fields are treated as a structure which is repeated. For example, if two consecutive fields are defined as A[] and B[], the decoder creates a sequence of ABABAB until the end condition has been detected.

Note: It is possible to combine check functions in a dynamic array. In the example above, if B[] is extended by odd(1), with "1" being the index of A[], then B checks the parity for each index of A.

"crc5usb(n-m)"	The crc 5-bit operator performs a check for a 5-bit CRC function using the polynomial as defined by the USB standard. n and m define the index range for the CRC check. For example, if the CRC shall check fields 1 to 4, the function shall be written "crc5usb(1-5)". If the range of the CRC check includes an array, all elements in the array is included in the CRC check. If the check fails, the CRC field is marked as "CRC error" in the result details and displayed in the color red in the honeycomb display. The frame that contains the field is marked in the same way, except if another higher priority error is found within this frame.
"odd(n-m), even(n-m)"	The "parity" operators perform checks on odd or even parity in the given index range n to m. Odd parity is fulfilled if the count of "1" bits in the range including the parity bit is odd. Even parity is fulfilled if the count of "1" bits in the range including the parity bit is even. If the parity check fails, the parity field is marked as "CRC error" in the result details and displayed in red color in the honeycomb display. The frame that contains the field is marked in the same way, except if another higher priority error is found within this frame.
"{Block}"	The block operator is represented by the "{" and "}" bracket signs. Consecutive fields marked with "{Block}" and using the same name are displayed in the honeycomb display as a consecutive packet of name "Block" with the first field's color. This feature is a visual effect in the honeycomb only.

Remote command:

[SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:CONDition](#) on page 1471

[SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLD<fl>:CONDition](#) on page 1498

Numeric format

Selects a numerical format for the [Condition](#) value: decimal, hex, octal or binary.

The following rules apply:

- If the condition value contains at least one "H", "h", "L", "l", "X", "x", and the remaining characters only contain "1" and/or "0", the numeric format is automatically interpreted as binary, regardless of its definition.
 - The wildcard characters "x" and "X" are supported only in binary format.
- Examples: If the numeric format is set to be "HEX":
- "=1HL111000" is valid (read as binary)
 - "=0x10101" is valid (read as binary, the "x" is interpreted here as a wild card)
 - "=1010" is valid (read as HEX, with a total of 16 bits)
 - "=0x5A" is valid (read as HEX "5A", since "0x" is a valid HEX prefix; nevertheless, it is recommended to enter "5A" instead)
 - "=5X12" is invalid
 - "=1H33" is invalid

Remote command:

[SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:FORMat](#) on page 1471

[SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLD<fl>:FORMat](#) on page 1498

Bit order

Selects, in which order the bits of a field's [Condition](#) value are evaluated:

- "LSB first": little endian, least significant bit first
- "MSB first": big endian, most significant bit first

Remote command:

[SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:BITorder](#) on page 1472

[SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLD<fl>:BITorder](#) on page 1499

Result column

Determines which field is displayed in which result column of the decode table.

- Selecting "-" (no index) means that the result is not displayed.
- Selecting "1", "2" or "3" means that the result is displayed in the 1st, 2nd or 3rd result column, that the decode table supports. Each of the three result columns has to be unique for each frame type. But to display unrelated information for different frame types, you can define different result columns.

Remote command:

[SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:CLMN](#) on page 1472

[SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLD<fl>:CLMN](#) on page 1499


14.7.5 NRZ software trigger**14.7.5.1 Setup A trigger**

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.7.5.2 Software trigger settings

Access:

- "Menu" > "Apps" > "Protocol" tab > "NRZ Clocked" > "Trigger" tab > "Setup Software Trigger"
- "Menu" > "Apps" > "Protocol" tab > "NRZ Unclocked" > "Trigger" tab > "Setup Software Trigger"



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

"Check all"	Enables the software trigger for all available frames and error types.
"Clear"	Disables the software trigger for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:NRZC:CHKall](#) on page 1474

[TRIGger:SBSW:NRZU:CHKall](#) on page 1500

[TRIGger:SBSW:NRZC:CLR](#) on page 1474

[TRIGger:SBSW:NRZU:CLR](#) on page 1501

[TRIGger:SBSW:NRZC:INVert](#) on page 1474

[TRIGger:SBSW:NRZU:INVert](#) on page 1501

[TRIGger:SBSW:NRZC:RST](#) on page 1474

[TRIGger:SBSW:NRZU:RST](#) on page 1501

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The only frame type available by default is "Undescribed", because the NRZ protocols support custom coding.

However, the frame formats that you define appear in this list, too. See [Section 14.7.4, "NRZ frame format configuration"](#), on page 592.

Remote command:

`TRIGger:SBSW:NRZC:FRENAble` on page 1474


`TRIGger:SBSW:NRZU:FRENAble` on page 1501

`TRIGger:SBSW:NRZC:FRAME<fr>:ENABLE` on page 1474

`TRIGger:SBSW:NRZU:FRAME<fr>:ENABLE` on page 1501

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



"Field"	Enables the field type that you want to trigger on for the selected frame. For the default "Undescribed" frame, the only available field type is "Word". See "Frame type" on page 603. However, the field formats that you define appear in this list, too. See Section 14.7.4, "NRZ frame format configuration", on page 592. Remote command: TRIGger:SBSW:NRZC:FIENable on page 1476 TRIGger:SBSW:NRZU:FIENable on page 1503 TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:ENABle on page 1476 TRIGger:SBSW:NRZU:FRAMe<fr>:FLD<fl>:ENABle on page 1503
"Condition"	Displays the value condition for the selected field. Remote command: TRIGger:SBSW:NRZC:BIT on page 1475 TRIGger:SBSW:NRZU:BIT on page 1501 TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:BIT on page 1475 TRIGger:SBSW:NRZU:FRAMe<fr>:FLD<fl>:BIT on page 1501
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: TRIGger:SBSW:NRZC:DMAX on page 1475 TRIGger:SBSW:NRZU:DMAX on page 1502 TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:DMAX on page 1475 TRIGger:SBSW:NRZU:FRAMe<fr>:FLD<fl>:DMAX on page 1502 TRIGger:SBSW:NRZC:DMIN on page 1475 TRIGger:SBSW:NRZU:DMIN on page 1502 TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:DMIN on page 1475 TRIGger:SBSW:NRZU:FRAMe<fr>:FLD<fl>:DMIN on page 1502 TRIGger:SBSW:NRZC:DOPerator on page 1476 TRIGger:SBSW:NRZU:DOPerator on page 1503 TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:DOPerator on page 1476 TRIGger:SBSW:NRZU:FRAMe<fr>:FLD<fl>:DOPerator on page 1503

NRZ clocked & unclocked (option R&S MXO5C-K510)

"Index" The index setup consists of a comparison condition and one or two index values.

Remote command:

[TRIGger:SBSW:NRZC:IMAX](#) on page 1476

[TRIGger:SBSW:NRZU:IMAX](#) on page 1503

[TRIGger:SBSW:NRZC:FRAME<fr>:FLD<fl>:IMAX](#) on page 1476

[TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:IMAX](#) on page 1503

[TRIGger:SBSW:NRZC:IMIN](#) on page 1477

[TRIGger:SBSW:NRZU:IMIN](#) on page 1504

[TRIGger:SBSW:NRZC:FRAME<fr>:FLD<fl>:IMIN](#) on page 1477

[TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:IMIN](#) on page 1504

[TRIGger:SBSW:NRZC:IOperator](#) on page 1477

[TRIGger:SBSW:NRZU:IOperator](#) on page 1504

[TRIGger:SBSW:NRZC:FRAME<fr>:FLD<fl>:IOperator](#) on page 1477

[TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:IOperator](#) on page 1504

Error type

Enables triggering on the selected error type.

The available error types are "Length error", "CRC error", "Parity error".

Remote command:

[TRIGger:SBSW:NRZC:ERENable](#) on page 1478

[TRIGger:SBSW:NRZU:ERENable](#) on page 1504

[TRIGger:SBSW:NRZC:ERRor<m>:ENABle](#) on page 1478

[TRIGger:SBSW:NRZU:ERRor<m>:ENABle](#) on page 1504

14.7.6 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.7.7 Performing NRZ decoding


This section explains step by step how to configure and decode the NRZ clocked or unclocked bus.

14.7.7.1 Configuring NRZ signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.7.2, "NRZ configuration"](#), on page 584.

1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: "NRZ Clocked" or "NRZ Unclocked".
4. Tap on "State" to enable the decoding.

A NRZC (clocked) or NRZU (unclocked) shortcut appears at the bottom left of the screen. Tap the shortcut for a quick access to the "NRZ Clocked" or "NRZ Unclocked" dialog settings.



14.7.7.2 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the NRZ protocol and decoded.

1. Tap on the "NRZ Clocked" or "NRZ Unclocked" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".
5. Select the "File type".

An export file is saved in the selected directory.

The NRZ export file contains the following fields:

- A list of all decoded frames:
 - Index
 - "State" of the frame
 - "Start"
 - "Frame type" of the frame
 - "Result 1", the result displayed in the 1st result column
 - "Result 2", the result displayed in the 2nd result column
 - "Result 3", the result displayed in the 3rd result column
 - "Bit rate", the bit rate of the frame
- The frame details include the following fields:

- "Index", the index of the field
- "State", the state of the field
- "Label", the name of the field
- "Value", the data value of the field

Example NRZC export file

```
Index,Start,Stop,State,Type,Result 1,Result 2,Result 3,Bit-rate
1,-0.019539,-0.014079,'OK','C22 WRITE',0Eh,11h,A57Eh,11900
2,-0.014079,-0.008619,'OK','C22 WRITE',1Ah,12h,EEFEh,11900
3,-0.008619,-0.00315997,'OK','C22 READ',13h,01h,ABCEh,11910
4,-0.00315997,0.0023,'OK','C45 READ',1Fh,0Ah,DEADh,11900
5,0.0023,0.0077608,'OK','C45 WRITE',0Eh,11h,A57Fh,11900
6,0.0077608,0.013221,'OK','C45 POST-READ',1Ah,12h,EEFCh,11900
7,0.013221,0.018681,'OK','C45 ADDRESS',0Ch,1Ah,CCAFh,11900
8,0.018681,0.0241433,'OK','C45 READ',13h,01h,ABCDh,11900
```

Details frame 1

```
Index,Label,State,Value
1,'PRE','OK',FFFFFFFFh
2,'ST','OK',1h
3,'OP','OK',1h
4,'PHYAD','OK',0Eh
5,'REGAD','OK',11h
6,'TA','OK',2h
7,'DATA','OK',A57Eh
8,'IDLE','OK',1h
```

Details frame 2

```
Index,Label,State,Value
1,'PRE','OK',FFFFFFFFh
2,'ST','OK',1h
3,'OP','OK',1h
4,'PHYAD','OK',1Ah
5,'REGAD','OK',12h
6,'TA','OK',2h
7,'DATA','OK',EEFEh
8,'IDLE','OK',1h
```

(...)

14.7.8 NRZ decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".

- In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.

Decode results table

The "Decode results" table contains information about all decoded frames.



Figure 14-23: Decoded NRZ clocked signal

The decode results table contains information about all decoded frames.

Table 14-10: Content of the decode results table

Column	Description
Index	Frame count
State	Overall state of the frame
Start	Start time of the frame
Frame type	The type of the frame

Column	Description
Result	Data displayed in the 1st, 2nd and 3rd results column. For "undescribed" frames (see Frame type), you can select the data format in the "Display" tab. For other frames, the "Format" table controls the format of each field. See Section 14.7.4, "NRZ frame format configuration" , on page 592.
Bit rate	Value of the bit rate

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-11: Content of the frame details table

Column	Description
Index	Number of the decoded field
Label	Name of the field
State	State of the field
Value	Value of the field

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- [SBUS<sb>:FORMat](#) on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.7.5, "Decode results"](#), on page 1479 (NRZ clocked) and [Section 18.18.8.5, "Decode results"](#), on page 1505 (NRZ unclocked).

14.8 Manchester (option R&S MXO5C-K510)

Manchester is a simple protocol for enhanced data integrity and reliability in serial bus communication. It is based on a self-clocked coding scheme also known as binary phase-shift keying (BPSK, or phase encoding, PE). Manchester is used in protocols such as ProfiBus (IEC 61158), DALI (Digital Addressable Lighting Interface, IEC 60929 and IEC 62386), MVB (Multifunction Vehicle Bus, part of IEC 61375 for Train Communication Networks, TCN), and Ethernet 10BASE-T (10 Mbit/s, IEEE 802.3i).

- [Manchester basics](#)..... 610
- [Manchester configuration](#)..... 612
- [Manchester filter](#)..... 616
- [Manchester frame format configuration](#)..... 619
- [Manchester software trigger](#)..... 628

• Measure	631
• Performing Manchester decoding	632
• Manchester decode results	633

14.8.1 Manchester basics

There are two opposing data polarity conventions:

- In Manchester coding (as per G. E. Thomas), a logical 0 is expressed by a low-to-high transition, while a logical 1 is represented by a high-to-low transition. These line voltage transitions occur at the middle of each bit period.
- In "Manchester II" coding (as per IEEE 802.3), the value of each bit is the Boolean exclusive disjunction (XOR) of the original data value and the clock value. Hence, it is equivalent to inverted Manchester coding: a logical 0 is represented by a high-to-low transition, a logical 1 is represented by a low-to-high transition.




Figure 14-24: Data polarity conventions for Manchester and Manchester II

Transitions at the start of a bit period are overhead and do not represent data. Because of this overhead, Manchester coding requires twice the bandwidth of the related NRZ code.

However, the frequent transitions at the beginning and middle of bit periods support clock recovery. All transitions are directly proportional to the clock rate, allowing the signal to be self-clocked. Unless idle, the voltage level is either high or low: it does not return to a zero voltage level between bits.

14.8.1.1 Special features of Manchester coding

In practical protocols, Manchester coding appears in many variations, often employing deliberate coding violations to encode special waveform features, such as unambiguous synchronization and termination patterns. To adapt to these specific Manchester implementations and handle ambiguous signals, the option R&S MXO5C-K510 uses a combination of automatic algorithms and user configurable parameters.

Quaternary Symbols

The software supports not just traditional binary symbols "0" and "1", but also arbitrary violation waveforms that use two additional symbols, yielding a total of four valid "quaternary bit" values. The two additional violation symbols are "H" (high) and "L" (low). Values of "H" correspond to a waveform lacking a transition in the center of the bit, with a physical high voltage state. Similarly, "L" violations also lack a center transition, but have a physical low voltage state. Most Manchester synchronization and termination conventions, even those containing violations, may be expressed as sequences of these four symbols. R&S MXO5C-K510 uses the quaternary notation to support Manchester patterns in the honeycomb display and to describe synchronization and termination patterns in the frame description table.

Idle Conditions

The state of the signal line in between messages is the idle condition. Manchester appears in practical standards with varying idle conditions: it can idle at the high, low, or middle voltage state. High and low idle states correspond to "biphase" Manchester, while the middle voltage (often ground) adds a third state to become "ternary" Manchester. Using ternary Manchester, option R&S MXO5C-K510 can usually establish the gaps between messages automatically. Using binary Manchester, the software has no way to automatically discriminate an idling bus from monotonic sequences of "H" or "L" violations. For these biphase situations, R&S MXO5C-K510 offers a "Gap Time" detection feature, which allows to distinguish long intervals of non-transitions between bus idling and sequences of violations. Other differences between biphase and ternary Manchester are managed automatically by the software, with no user input required.

Edge Conventions

Most Manchester encodings establish the beginning of the first bit by a first transition, hence an "overhead" edge. The center of the bit is then marked by a second transition, which is a "sampling" edge. Some Manchester implementations, however, sample the first bit on the first edge. The option R&S MXO5C-K510 attempts to automatically detect this situation. Unfortunately, it is possible to trick the algorithm with waveforms that contain many (legitimate) violations. In these situations, the user can force a "First Edge" or "Second Edge" convention for handling edges. Edge sampling according to the "First Edge" convention is more likely to appear in biphase Manchester, but the software also supports this setting for ternary Manchester situations.

Bit Rate

Typically, a single bit rate is clearly specified in Manchester protocols; however, some implementations use a variable bit rate. If you do not specify it in the "Setup" tab, R&S MXO5C-K510 by default automatically estimates it. However, with an estimated (hence, undefined) bit rate, fundamental ambiguities are possible in Manchester. In particular, sequences like "0000", "1111", "0101", "1010", and many situations involving "H" and "L" violations, cannot be decoded without it. The situation becomes even less defined with eventual Manchester coding violations. In these situations, you must provide a fixed ""Bit rate"" setting to bypass the software's estimation algorithm.

14.8.2 Manchester configuration

14.8.2.1 Manchester configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "Manchester" > "Setup".




Figure 14-25: Setup dialog, Data polarity selects "Manchester" or "Manchester II"



Make sure that the tab of the correct serial bus is selected.

Protocol type

Selects the protocol type to be decoded.

Remote command:

`SBUS<sb>:TYPE` on page 1322

State

Enables the decoding of the selected bus. The signal icon of the bus appears on the signal bar.

Remote command:

[SBUS<sb>\[:STATe\]](#) on page 1322

Data source

Selects the source for the data signal.

Remote command:

[SBUS<sb>:MANCh:DATA:SOURce](#) on page 1511

Data polarity

Selects the polarity for the data signal, and hence the data representation convention, see [Figure 14-24](#).

- "Manchester" (as per G. E. Thomas):
 - Low-to-high transition for logical 0
 - High-to-low transition for logical 1
- "Manchester II" (as per IEEE 802.3):
 - High-to-low transition for logical 0
 - Low-to-high transition for logical 1

Remote command:

[SBUS<sb>:MANCh:DATA:POLarity](#) on page 1511

Data phase

Defines the phase for the Manchester data signal. The available settings are:

- "First edge": the decoder captures data bits on the clock's rising edge (low-to-high transition).
Select this option, if the 1st transition is no overhead and needs to be sampled.
- "Second edge": the decoder captures data bits on the clock's falling edge (high-to-low transition).
Select this option, if the 1st edge is only an overhead transition from the idle state.

Note: The requirement to specify "First edge" or "Second edge" has the following background: An edge is always a transition from high to low or from low to high. In Manchester coding, however, if the signal comes from the idle state, there is right before the first valid edge always an overhead transition from idle to high or from idle to low. Some standards can regard this as a valid transition. Defining the phase avoids this potential ambiguity.

See also [Special features of Manchester coding](#).

Remote command:

[SBUS<sb>:MANCh:DATA:PHASe](#) on page 1512

Enable source

Selects the source of the enable signal.

If you select any source other than "None", the "Enable polarity" becomes available, which selects the polarity of the enable signal.

Remote command:

`SBUS<sb>:MANCh:ENABle:SOURce` on page 1512

`SBUS<sb>:MANCh:ENABle:POLarity` on page 1512

Check gap time

Enables the detection of the minimum idle time between two frames during decoding. Also enables setting the "Min gap time". Optionally, if you set it, the decoder considers any longer idle time a gap. A known minimum gap time helps the decoder with frame synchronization.

Remote command:

`SBUS<sb>:MANCh:MINGap:SElect` on page 1513

`SBUS<sb>:MANCh:MINGap:WIDTh` on page 1513

Check bit rate

Enables setting the "Bit rate".

- If you define a bit rate, it is used for triggering and decoding.
- If you disable this option, the decoder calculates the bit rate.

Remote command:

`SBUS<sb>:MANCh:BITRate:SElect` on page 1514

`SBUS<sb>:MANCh:BITRate:WIDTh` on page 1514

14.8.2.2 Thresholds

Access: "Menu" > "Apps" > "Protocol" tab > "Manchester" > "Thresholds"




Figure 14-26: Thresholds dialog

Enter the values directly in the fields.

Data upper threshold, Data lower threshold, Data hysteresis

Sets the upper and lower threshold and the hysteresis for the data source channel.

Remote command:

`SBUS<sb>:MANCh:DATA:THUPper` on page 1514

`SBUS<sb>:MANCh:DATA:THLower` on page 1514

`SBUS<sb>:MANCh:DATA:HYSTeresis` on page 1515

Enable threshold, Enable hysteresis

Available only, if you have selected a source for the enable signal. See ["Enable source"](#) on page 613.

Sets the middle threshold and the hysteresis for the enable source channel.

Remote command:

`SBUS<sb>:MANCh:ENABle:THReshold` on page 1515

`SBUS<sb>:MANCh:ENABle:HYSTeresis` on page 1515

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.

The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:

`SBUS<sb>:THReshold` on page 1325

14.8.2.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.

Decode layer

Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display.

"Off" Disables the display of the decode layer.

"Edges" Enables the display of all edges.

"Bits" Enables the display of all encoded bits.

Data format

See ["Data format"](#) on page 481.

14.8.2.4 Manchester symbols


There is no symbolic translation for the Manchester protocol, because of the custom frame definitions. See [Section 14.8.4, "Manchester frame format configuration"](#), on page 619.

14.8.3 Manchester filter

Access: "Menu" > "Apps" > "Protocol" tab > "Manchester" > "Filter" tab

Although Manchester has a free format description according to [section 14.8.4, "Manchester frame format configuration"](#), on page 619, we provide a dynamic filter solution that can adapt to custom frames and fields in the decoded events.

In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.



Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

- "Check all" Enables the filter for all available frames and error types.
- "Clear" Disables the filter for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

"Preset" Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:MANCh:FILTer:CHKall](#) on page 1517

[SBUS<sb>:MANCh:FILTer:CLR](#) on page 1517

[SBUS<sb>:MANCh:FILTer:INVert](#) on page 1517

[SBUS<sb>:MANCh:FILTer:RST](#) on page 1517

Enable

Enables the filtering on Manchester frames. Only the frames that match the selected filter conditions are displayed.

Remote command:

[SBUS<sb>:MANCh:FILTer:FREnable](#) on page 1520

[SBUS<sb>:MANCh:FILTer:FRAMe<fr>:ENABle](#) on page 1520

Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.


For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

The only frame type available by default is "Undescribed", because the Manchester protocol supports custom coding.

However, the frame formats that you define appear in this list, too. See [Section 14.8.4, "Manchester frame format configuration"](#), on page 619.

Edit

Opens a dialog to define the details of the selected frame.



"Field" Enables the field type that you want to filter on for the selected frame. For the default "Undescribed" frame, the only available field type is "Word", which is the payload component of an undescribed frame. See ["Frame type"](#) on page 617.

However, the field formats that you define appear in this list, too. See [Section 14.8.4, "Manchester frame format configuration"](#), on page 619.

Remote command:

[SBUS<sb>:MANCh:FILTer:FIENable](#) on page 1519

[SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:ENABle](#) on page 1519

"Condition" Displays the value condition for the selected field.

Remote command:

[SBUS<sb>:MANCh:FILTer:BIT](#) on page 1518

[SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:BIT](#) on page 1518

"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: SBUS<sb>:MANCh:FiLTer:DMAX on page 1518 SBUS<sb>:MANCh:FiLTer:FRAMe<fr>:FLD<fl>:DMAX on page 1518 SBUS<sb>:MANCh:FiLTer:DMIN on page 1519 SBUS<sb>:MANCh:FiLTer:FRAMe<fr>:FLD<fl>:DMIN on page 1519 SBUS<sb>:MANCh:FiLTer:DOPerator on page 1519 SBUS<sb>:MANCh:FiLTer:FRAMe<fr>:FLD<fl>:DOPerator on page 1519
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: SBUS<sb>:MANCh:FiLTer:IMAX on page 1520 SBUS<sb>:MANCh:FiLTer:FRAMe<fr>:FLD<fl>:IMAX on page 1520 SBUS<sb>:MANCh:FiLTer:IMIN on page 1521 SBUS<sb>:MANCh:FiLTer:FRAMe<fr>:FLD<fl>:IMIN on page 1521 SBUS<sb>:MANCh:FiLTer:IOPerator on page 1521 SBUS<sb>:MANCh:FiLTer:FRAMe<fr>:FLD<fl>:IOPerator on page 1521

Error type

Enables filtering on the selected error type.

The available error types are "Length error", "CRC error", "Parity error", "Incomplete".


Remote command:

[SBUS<sb>:MANCh:FiLTer:ERENable](#) on page 1518

[SBUS<sb>:MANCh:FiLTer:ERRor<n>:ENABle](#) on page 1518

14.8.4 Manchester frame format configuration

This dialog enables you to describe the generic format and logical structure of your Manchester protocol. To do so, you can create customized frame descriptions of various structures and lengths.



A frame format description (or *frame description*, for short) is represented by one line in the frame format description list (or *frame list*, for short). Describing a frame format requires assigning it a name and specifying field descriptions, which must be sequential and complete. No gaps are allowed, because the field descriptions are used to calculate the start position of the next frame.

See also:

- ["Frame name"](#) on page 623
- ["Frame Color"](#) on page 624

The frame identification is executed top down, in the order in which the frame formats are described in the frame list. This provides a hierarchy of criteria for identifying frames. A frame is identified when all user-defined conditions of the field descriptions are met. See ["Condition"](#) on page 625. These conditions can be regarded as related by the Boolean AND operator.

A condition can also locate a synchronization pattern, specified by the equal operator in the field. For example, if you define a "Preamble" field with the condition `=FFFFFFFF`, the decoder scans the data for this pattern, and then synchronizes to it.

If no frame description is suitable to identify an incoming frame, by default such a "missed" frame is reproduced as "Undescribed Bits" in the honeycomb display. These bits are not shown in the results table.

If you have not defined an "equal" operator for any field of a frame description, you can use this description to positively identify each kind of frame. Hence, it "catches" every frame, even if there are other frame descriptions to follow in the frame list. Therefore, if you use a "catch all" frame description, we recommend to place it at the end of the frame list, otherwise it overwrites any subsequent frame description. However, instead of using a "catch all" frame description, consider using the default "Undescribed Bits" display mentioned above.


It is in your responsibility to define unambiguous descriptions for each frame type.

Add Frame

Creates a new **frame description** and adds it to the end of the frame list.

When you add a frame or when you click an existing entry in the frame list, a dialog opens that allows the following:

- [Add Field](#)
- [Edit List](#)
- [Frame name](#)
- [Frame Color](#)



When you return to the frame list by using the "Back" button, a dialog opens that allows the following:

- [Add Frame](#)
- [Edit List](#)
- [Open](#)
- [Save as](#)

The number of frame descriptions is limited to 100.

Remote command:

`SBUS<sb>:MANCh:FORMat:ADDFrame` on page 1522

**Edit List**

Enables editing the frame list. If enabled, you can delete a frame description by clicking its "Delete" icon. In a list with several entries, you can move frame descriptions up or down by clicking the arrow buttons. To exit the editing mode, click "Edit List" again.

Remote command:

[SBUS<sb>:MANCh:FORMat:CLR](#) on page 1523

[SBUS<sb>:MANCh:FORMat:FCOunt?](#) on page 1523

Open

Opens a dialog for loading an existing list of frame descriptions in XML file format.

Remote command:

[SBUS<sb>:MANCh:FORMat:LOAD](#) on page 1522

Save as

Opens a dialog for saving your current list of frame descriptions to an XML file. Saved frame descriptions can support efficient and convenient working.

Remote command:

[SBUS<sb>:MANCh:FORMat:SAVE](#) on page 1522

Add Field

Creates a new **field description** for the currently selected frame description and adds it to the end of the field list.

When you add a field or when you click an existing entry in the field list, a dialog opens that allows the following for describing a field:

- [Field name](#)
- [Field Color](#)
- [Bit count](#)
- [Condition](#)
- [Numeric format](#)
- [Bit order](#)
- [Result column](#)

Serial bus: Manchester

SB1

Back

Field name

ALimit

Field Color

Bit count

8

Condition

=HLLL0101

Numeric format

Binary

Bit order

MSB first

Result column

1

When you return to the field list by using the "Back" button, a dialog opens that allows the following:

- [Add Field](#)
- [Edit List](#)
- [Frame name](#)
- [Frame Color](#)

The number of field descriptions is limited to 100.

Remote command:

[SBUS<sb>:MANCh:FORMat:FRAMe<fr>:ADDField](#) on page 1523



Edit List

Enables editing the field list. If enabled, you can delete a field description by clicking its "Delete" icon. In a list with several entries, you can move field descriptions up or down by clicking the arrow buttons. To exit the editing mode, click "Edit List" again.

Remote command:

[SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLDCount?](#) on page 1523

Frame name

Specifies an arbitrary name to label the currently selected frame description. Ideally, use speaking names according to the specifications of the applicable protocol standard. For example, a [DALI](#) frame description can specify the frames "FW-ShortAddr-directArc", "FW-ShortAddr-cmd", "FW-GrpAddr-directArc", "FW-GrpAddr-cmd", "FW-Broadcast-directArc", "FW-Broadcast-cmd", "FW-special-cmd", and "BACKWARD". Frame names do not have to be unique and are only intended to support you.

Remote command:

`SBUS<sb>:MANCh:FORMat:FRAMe<fr>:NAME` on page 1524

Frame Color

Selects a color for labeling the currently selected frame description.

Remote command:

`SBUS<sb>:MANCh:FORMat:FRAMe<fr>:COLor` on page 1524

Field name

Specifies an arbitrary name for the currently selected field description. Ideally, use speaking names.

Field names do not have to be unique and are only intended to support you.

Remote command:

`SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:NAME` on page 1524

Field Color

Opens a dialog to select the color representation of different fields in the honeycomb display. Assigning specific colors can help you to interpret the decode results more easily. You can select a predefined color or specify a "User-defined color".

Remote command:

`SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:COLor` on page 1525

Bit count

Specifies the bit count and hence the length of the field represented by the currently selected field description. You can click the field to open a keypad dialog, which also displays the minimum and maximum permitted values. Its "Min", "Max" or "Reset" buttons can set the bit count to the minimum, maximum or reset value. The "Inc" or "Dec" button increases or decreases the value in steps of 1 or 10, depending on the selected step size button. The "CE" button sets the bit count to the value that was used before the keypad was displayed.

If, for a given bit count, the [Condition](#) value is longer, it is truncated. If the condition value is shorter, it is padded with 0. Both truncation and padding occur at the left side of the condition value and relate to the [Bit order](#).

Examples:

- If "Condition" is "=100" and the "Bit order" is "MSB first":
 - If "Bit count" is 2, the truncated condition is "=00"
 - If "Bit count" is 4, the padded condition is "=0100"
- If "Condition" is "=100" and the "Bit order" is "LSB first" (accordingly, the condition in "MSB first" format would be "=001"):
 - If "Bit count" is 2, the truncated condition is "=00" for "LSB first" and "=00" for "MSB first"
 - If "Bit count" is 4, the padded condition is "=0100" for "LSB first" and "=0010" for "MSB first"

Remote command:

`SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:BITCount` on page 1525

Condition

Specifies a condition for the field, typically a bit sequence that is used for pattern-matching to identify the frame.

Use this text box to apply various conditions and functionalities for a field. Among others, you can use it to identify mandatory values, such as CRC checksum or ID, which help to identify a frame. The condition value must match also the [Numeric format](#) and [Bit order](#).

The following conditions are implemented:

"= (equal)" The **equal** operator (represented by the "=" sign) defines a pattern for the field to match. Valid condition entries are characters that match the field's defined "Format", "Bit order", and "Bits". In binary format, for example, valid characters are "1", "0", "H" (high), and "L" (low).

Three cases have to be distinguished (cases A, B1, and B2), depending on the presence of a [Variable Length Array](#): [] in the same frame description:

- **Case A:** If there is **no** "Variable Length Array" field, then each field marked with the equal operator acts as a key to identify a frame type. Only if all these fields match up with the expected value, the frame type is identified.
- **Cases B1 and B2:** If there **is** a "Variable Length Array" field, then the equal operator has two different functionalities, depending on the position of the equal-operator field within the frame description:
 - **B1:** If the field is located *anywhere before* the "Variable Length Array" field, the condition acts as a key to identify the frame type by matching the starting bits of the frame (its preamble), as in case A.
 - **B2:** If the field is located *immediately after* the "Variable Length Array" field, the condition acts as an array delimiter by matching the bit sequence immediately following the variable-length field.

(Note: If the field, which is marked with the equal operator, is located after the "Variable Length Array" field, but *not* immediately after it, the decode result is unpredictable.)

Note: Code violations. Typically, Manchester protocols use code violations for synchronization. The states "H" and "L", supported by the equal operator in binary format, mark that a transition is expected at this bit, but only a high or low signal is found.

Examples for the MVB protocol:

- Primary delimiter: "=1LH0LH000"
- Secondary delimiter: "=0000LH0LH"

For more details on the violation symbols "H" and "L", see [Section 14.8.1.1, "Special features of Manchester coding"](#), on page 610.

Also, the length of the pattern must correspond to the bit field length, otherwise the results are unpredictable.

"[] (array)"

The **array** operator (represented by the "[" and "]" bracket signs) defines the number of permissible repetitions of the field.

Example: Fixed-Length Array: [n]

The length parameter "n" is a decimal number > 0 , which determines that the field is repeated n times within the frame. If, for example, the **Bit count** is 8, then the array operator identifies n fields of 8-bit length, and present them in the results table and honeycomb display with the specified name and color.

A fixed-length array is treated the same as other fields, except the real length of such an array is $n \cdot \text{bit count}$.

Example: Variable Length Array: []

This array operator with empty "[" and "]" bracket signs does not determine a fixed size array. The field could be repeated any number of times, including 0 times. As a result, the field and the frame are of unspecified length (a situation that covers typical use cases).

The length of the frame is then determined by the end of frame condition, which can be an operator or a gap.

For processing reasons, only one (1) variable length array is supported in a frame, and a delimiter must follow immediately in the next field after it. This is required to enable the software to correctly terminate the array. Otherwise the bits could not be assigned correctly, and it would not be possible to determine where a repetition starts and where it ends. With an end of frame condition, the software can calculate the length of one single array within a frame. But if there were more arrays, it would be impossible to know which array was how long.

The variable length array can also be the last field of a frame. In this case, no delimiter is required. If decoded successfully, the detailed view in the results table shows the elements of the array. If the field name of the array is "Data", then the detail view of result table displays the elements with an array index as "Data: 1", "Data: 2" ... etc. If the variable length array field is selected, it is shown as array [n], where n is the actual size detected in the waveform.

As an exception to the rule, it is permissible to assign the variable length array to consecutive fields. In this case, the fields are treated as a structure which is repeated. For example, if two consecutive fields are defined as A[] and B[], the decoder creates a sequence of ABABAB until the end condition has been detected.

Note: It is possible to combine check functions in a dynamic array. In the example above, if B[] is extended by odd(1), with "1" being the index of A[], then B checks the parity for each index of A.

- "crc5usb(n-m)" The **crc 5-bit** operator performs a check for a 5-bit CRC function using the polynomial as defined by the USB standard. n and m define the index range for the CRC check.
For example, if the CRC shall check fields 1 to 4, the function shall be written "crc5usb(1-5)".
If the range of the CRC check includes an array, all elements in the array is included in the CRC check.
If the check fails, the CRC field is marked as "CRC error" in the result details and displayed in the color red in the honeycomb display. The frame that contains the field is marked in the same way, except if another higher priority error is found within this frame.
- "odd(n-m),
even(n-m)" The **"parity"** operators perform checks on odd or even parity in the given index range n to m.
Odd parity is fulfilled if the count of "1" bits in the range including the parity bit is odd. Even parity is fulfilled if the count of "1" bits in the range including the parity bit is even.
If the parity check fails, the parity field is marked as "CRC error" in the result details and displayed in red color in the honeycomb display. The frame that contains the field is marked in the same way, except if another higher priority error is found within this frame.

Remote command:

`SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:CONDition` on page 1525

Numeric format

Selects a numerical format for the [Condition](#) value: decimal, hex, octal or binary.

The following rules apply:

- If the condition value contains at least one "H", "h", "L", "l", "X", "x", and the remaining characters only contain "1" and/or "0", the numeric format is automatically interpreted as binary, regardless of its definition.
- The wildcard characters "x" and "X" are supported only in binary format.
Examples: If the numeric format is set to be "HEX":
 - "=1HL111000" is valid (read as binary)
 - "=0x10101" is valid (read as binary, the "x" is interpreted here as a wild card)
 - "=1010" is valid (read as HEX, with a total of 16 bits)
 - "=0x5A" is valid (read as HEX "5A", since "0x" is a valid HEX prefix; nevertheless, it is recommended to enter "5A" instead)
 - "=5X12" is invalid
 - "=1H33" is invalid

Remote command:

`SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:FORMat` on page 1526

Bit order

Selects, in which order the bits of a field's [Condition](#) value are evaluated:

- "LSB first": little endian, least significant bit first
- "MSB first": big endian, most significant bit first

Remote command:

`SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:BITorder` on page 1526

Result column

Determines which field is displayed in which result column of the decode table.

- Selecting "-" (no index) means that the result is not displayed.
- Selecting "1", "2" or "3" means that the result is displayed in the 1st, 2nd or 3rd result column, that the decode table supports. Each of the three result columns has to be unique for each frame type. But to display unrelated information for different frame types, you can define different result columns.

Remote command:

`SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:CLMN` on page 1527


14.8.5 Manchester software trigger

14.8.5.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.8.5.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "Manchester" > "Trigger" tab > "Setup Software Trigger"



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

"Check all"	Enables the software trigger for all available frames and error types.
"Clear"	Disables the software trigger for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:MANCh:CHKall](#) on page 1528

[TRIGger:SBSW:MANCh:CLR](#) on page 1528

[TRIGger:SBSW:MANCh:INVert](#) on page 1528

[TRIGger:SBSW:MANCh:RST](#) on page 1529

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The only frame type available by default is "Undescribed", because the Manchester protocol supports custom coding.

However, the frame formats that you define appear in this list, too. See [Section 14.8.4, "Manchester frame format configuration"](#), on page 619.


Remote command:

`TRIGger:SBSW:MANCh:FRENable` on page 1529

`TRIGger:SBSW:MANCh:FRAMe<fr>:ENABle` on page 1529

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



"Field" Enables the field type that you want to trigger on for the selected frame.
For the default "Undescribed" frame, the only available field type is "Word". See ["Frame type"](#) on page 629.
However, the field formats that you define appear in this list, too. See [Section 14.8.4, "Manchester frame format configuration"](#), on page 619.
Remote command:
`TRIGger:SBSW:MANCh:FIENable` on page 1531
`TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:ENABle` on page 1531

"Condition"	Displays the value condition for the selected field. Remote command: TRIGger:SBSW:MANCh:BIT on page 1529 TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:BIT on page 1529
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: TRIGger:SBSW:MANCh:DMAX on page 1530 TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:DMAX on page 1530 TRIGger:SBSW:MANCh:DMIN on page 1530 TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:DMIN on page 1530 TRIGger:SBSW:MANCh:DOPerator on page 1530 TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:DOPerator on page 1530
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: TRIGger:SBSW:MANCh:IMAX on page 1531 TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:IMAX on page 1531 TRIGger:SBSW:MANCh:IMIN on page 1532 TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:IMIN on page 1532 TRIGger:SBSW:MANCh:IOperator on page 1532 TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:IOperator on page 1532

Error type

Enables triggering on the selected error type.

The available error types are "Length error", "CRC error", "Parity error".

Remote command:

[TRIGger:SBSW:MANCh:ERENable](#) on page 1532

[TRIGger:SBSW:MANCh:ERRor<m>:ENABle](#) on page 1532

14.8.6 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.8.7 Performing Manchester decoding


This section explains step by step how to configure and decode the Manchester bus.

14.8.7.1 Configuring Manchester signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.8.2, "Manchester configuration"](#), on page 612.

1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: "Manchester".
4. Tap on "State" to enable the decoding.

A Manchester shortcut appears at the bottom left of the screen. Tap the shortcut for a quick access to the "Manchester" dialog settings.



14.8.7.2 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the Manchester protocol and decoded.

1. Tap on the "Manchester" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".
5. Select the "File type".

An export file is saved in the selected directory.

The Manchester export file contains the following fields:

- A list of all decoded frames:
 - Index

- "State" of the frame
- "Start"
- "Frame type" of the frame
- "Result 1", the result displayed in the 1st result column
- "Result 2", the result displayed in the 2nd result column
- "Result 3", the result displayed in the 3rd result column
- "Bit rate", the bit rate of the frame
- The frame details include the following fields:
 - "Index", the index of the field
 - "State", the state of the field
 - "Label", the name of the field
 - "Value", the data value of the field

Example Manchester export file

```

Index,State,Type,Result 1,Result 2,Result 3,Bit-rate
1,'OK','Cmd/Stat',3h,049h,1h,14280
2,'OK','Data',4h,1234h,0h,14290
3,'OK','Data',4h,5678h,1h,14280
4,'OK','Data',4h,9ABCh,0h,14280
5,'OK','Data',4h,DEF0h,1h,14280
6,'OK','Cmd/Stat',3h,000h,0h,14270
7,'OK','Cmd/Stat',3h,083h,1h,14280
8,'PAR','Cmd/Stat',3h,083h,0h,14280

Details frame 1
Index,Label,State,Value
1,'Sync','OK',3h
2,'RTA','OK',01h
3,'Info','OK',049h
4,'P','OK',1h

Details frame 2
Index,Label,State,Value
1,'Sync','OK',4h
2,'Data','OK',1234h
3,'P','OK',0h

(...)

```

14.8.8 Manchester decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".

- In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.

Decode results table

The "Decode results" table contains information about all decoded frames.



Figure 14-27: Decoded Manchester signal

The decode results table contains information about all decoded frames.

Table 14-12: Content of the decode results table

Column	Description
Index	Frame count
State	Overall state of the frame
Start	Start time of the frame
Frame type	The type of the frame

CAN (automotive electronics, option R&S MXO5C-K520)

Column	Description
Result	Data displayed in the 1st, 2nd and 3rd results column. For "undescribed" frames (see Frame type), you can select the data format in the "Display" tab. For other frames, the "Format" table controls the format of each field. See Section 14.8.4, "Manchester frame format configuration" , on page 619.
Bit rate	Value of the bit rate

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-13: Content of the frame details table

Column	Description
Index	Number of the decoded field
Label	Name of the field
State	State of the field
Value	Value of the field

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- [SBUS<sb>:FORMat](#) on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.9.5, "Decode results"](#), on page 1533.

14.9 CAN (automotive electronics, option R&S MXO5C-K520)

CAN is the Controller Area Network, a bus system designed by Bosch for use within automotive network architecture, for example, for brake, power train and engine management. Today, it is also used in many other systems, for example, in industrial machines, aerospace, subsea, merchant marine.

With the MXO 5C you can decode frames from some of the most common CAN protocols standards:

- Classical CAN (CAN 2.0): includes the standard frame format (11-bit identifier) and the extended frame format (29-bit identifier).
- CAN FD: CAN with flexible data rate. It is an extension of the classical CAN protocol and allows for increased data rates and payloads. It is backward compatible with CAN 2.0.

- CAN XL: an advanced version of the CAN protocol designed to handle higher data rates and larger payloads compared to classical CAN and CAN FD.

Requirements

For performing CAN decode measurements, you need the following:

- MXO 5C with 1 available channel. The channel can be:
 - Analog channels (C1-C4)
 - Logic channels (D0-D15) (requires option R&S MXO5C-B1)
- One probe
- Option R&S MXO5C-K520


• CAN configuration	636
• CAN filter	642
• CAN hardware trigger	645
• CAN software trigger	654
• Measure	658
• CAN decode results	658
• Performing CAN decoding	660

14.9.1 CAN configuration

14.9.1.1 CAN configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "CAN" > "Setup".

CAN (automotive electronics, option R&S MXO5C-K520)



Make sure that the tab of the correct serial bus is selected.

Protocol type

Selects the protocol type to be decoded.

Remote command:

[SBUS<sb>:TYPE](#) on page 1322

State

Enables the decoding of the selected bus. The signal icon of the bus appears on the signal bar.

Remote command:

[SBUS<sb>\[:STATE\]](#) on page 1322

Data

Sets the source of the selected data line.

Remote command:

[SBUS<sb>:CAN:SOURce](#) on page 1540

Type

Selects the CAN-High or CAN-Low line. CAN uses both lines for differential signal transmission.

If you measure with a differential probe, connect the probe to both CAN-H and CAN-L lines, and select the data "Type" = *CAN-H*.

If you use a single-ended probe, connect the probe to either CAN_L or CAN_H, and select the data type accordingly.

Remote command:

[SBUS<sb>:CAN:TYPE](#) on page 1539

Transceiver mode

Selects the transceiver mode for the CAN decoding.

"SIC mode" The signal improvement capability (SIC) mode supports bit rates up to 8 Mbit/s.

"FAST mode" The fast mode supports bit rates up to 20 Mbit/s.

Remote command:

[SBUS<sb>:CAN:TRCVmode](#) on page 1542

Nominal bit rate

Sets the number of transmitted bits per second.

Remote command:

[SBUS<sb>:CAN:BITRate](#) on page 1539

Sample point

Sets the position of the sample point within the bit in percent of the nominal bit time.

Remote command:

[SBUS<sb>:CAN:SAMPLEpoint](#) on page 1539

FD bit rate

Sets the number of transmitted bits per second for the CAN FD frame.

Remote command:

[SBUS<sb>:CAN:FDATa:DBITrate](#) on page 1540

FD sample point

Sets the position of the sample point within the bit in percent of the nominal bit time for the CAN FD frame.

Remote command:

[SBUS<sb>:CAN:FDATa:SAMPLEpoint](#) on page 1540

XL bit rate

Sets the number of transmitted bits per second for the CAN XL frame.

Remote command:

[SBUS<sb>:CAN:XDATa:DBITrate](#) on page 1542

XL sample point


Sets the position of the sample point within the bit in percent of the nominal bit time for the CAN XL frame.

Remote command:

[SBUS<sb>:CAN:XDATa:SAMPlepoint](#) on page 1542

14.9.1.2 Threshold settings

Access: "Menu" > "Apps" > "Protocol" tab > "CAN" > "Thresholds".

**Threshold**

Sets the threshold for the SIC and Fast channels. Enter the value directly in the fields.

Additional to the threshold, you can also set a hysteresis.

Remote command:

[SBUS<sb>:CAN:FAST:HYSTeresis](#) on page 1542

[SBUS<sb>:CAN:FAST:THReshold](#) on page 1541

[SBUS<sb>:CAN:SIC:HYSTeresis](#) on page 1541

[SBUS<sb>:CAN:SIC:THReshold](#) on page 1541

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.


The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:

[SBUS<sb>:THReshold](#) on page 1325

14.9.1.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.



Decode layer

Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display. See ["Decode layer"](#) on page 481.

Show symbols

You can load symbol lists, and activate its usage for decoding. As a result, an additional "Symbol" column appears in the "Decode results" table, containing the symbolic label.

Symbol lists for CAN are available in DBC and CSV format, see [CAN symbols](#).

Remote command:

[SBUS<sb>:CAN:SYMBOLs](#) on page 1543

[SBUS<sb>:CAN:NEWList](#) on page 1543

14.9.1.4 CAN symbols

For the CAN protocol, you can upload symbol lists containing IDs and a symbolic name for each node. You can load a file in one of the supported formats: DBC and CSV.

DBC files for CAN and CAN FD

Industry standard DBC files contain more information than CSV files and translate the abstract decode results to human language. For each frame, the frame ID and the symbolic name of the ID are given. The frames are also called messages in CAN. The data of a CAN message can consist of several "signals". The DBC file provides the label, unit, start bit, length and other indicators for each signal. For state-encoded signals, the meaning of the states is given.

In the following demo example, the message "EngineData" has the decimal ID 2,166,573,756 and consists of 8 data bytes. These 8 bytes are defined as 6 signals. The first one, "PetrolLevel", starts at bit #24, has a length of 8 bit, and the unit is liter. The signal "IdleRunning" is state-encoded. It has only one bit. The binary value 0 means "Running", and the binary value 1 means "Idle".

Example: CAN DBC file section

```
BO_ 2166573756 EngineData: 8 Engine
SG_ PetrolLevel : 24|8@1+ (1,0) [0|255] "l" ...
SG_ EngPower : 48|16@1+ (0.01,0) [0|350] "kW" ...
SG_ EngForce : 32|10@1+ (1,0) [0|1000] "N" ...
SG_ IdleRunning : 23|1@1+ (1,0) [0|1] "" ...
SG_ EngTemp : 16|7@1+ (2,-50) [-50|150] "degC" ....
SG_ EngSpeed : 0|13@1+ (1,0) [0|8000] "rpm" ...
....
VAL_ 2166573756 IdleRunning 0 "Running" 1 "Idle" ;
```

CSV files for CAN / CAN FD

Symbol list files are protocol-specific. A CSV label file for CAN protocols contains three values for each identifier:

- Identifier type, 11-bit or 29-bit long
- Identifier value
- Symbolic name of the identifier, specifying its function in the bus network.


Example: CAN CSV file

```
# -----
@FILE_VERSION = 1.00
@PROTOCOL_NAME = can
# -----
# Labels for CAN protocol
# Column order: Identifier type, Identifier value, Label
```

```
# -----
11,064h,Diag_Response
11,1E5h,EngineData
11,0A2h,Ignition_Info
11,1BCh,TP_Console
11,333h,ABSdata
11,313h,Door_Left
11,314h,Door_Right
29,01A54321h,Throttle
29,13A00FA2h,LightState
29,0630ABCDh,Engine_Status
29,03B1C002h,Airbag_Status
29,01234ABCh,NM_Gateway
# -----
```

14.9.2 CAN filter

Access: "Menu" > "Apps" > "Protocol" tab > "CAN" > "Filter" tab



In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

"Check all"	Enables the filter for all available frames and error types.
"Clear"	Disables the filter for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:CAN:FILTer:CHKall](#) on page 1545

[SBUS<sb>:CAN:FILTer:CLR](#) on page 1545

[SBUS<sb>:CAN:FILTer:INVert](#) on page 1545

[SBUS<sb>:CAN:FILTer:RST](#) on page 1545

Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

Available frames are "CBFF", "CBFF-R", "CEFF", "CEFF-R", "FBFF", "FEFF", "XLFF", "Overload" and "Error".


Remote command:

[SBUS<sb>:CAN:FILTer:FREnable](#) on page 1548

[SBUS<sb>:CAN:FILTer:FRAME<fr>:ENABLE](#) on page 1548

Edit

Opens a dialog to define the details of the selected frame.



- "Field" Enables the field type that you want to filter on for the selected frame. The available fields are "ID", "RTR", "ITE", "RLC" and "Data".
Remote command:
[SBUS<sb>:CAN:FILTER:FIENable](#) on page 1547
[SBUS<sb>:CAN:FILTER:FRAME<fr>:FLD<fl>:ENABLE](#) on page 1547
- "Condition" Displays the value condition for the selected field.
Remote command:
[SBUS<sb>:CAN:FILTER:BIT](#) on page 1545
[SBUS<sb>:CAN:FILTER:FRAME<fr>:FLD<fl>:BIT](#) on page 1545

"Value" The data setup consists of a comparison condition and one or two data patterns.

Remote command:

[SBUS<sb>:CAN:FILTer:DMAX](#) on page 1546

[SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:DMAX](#)
on page 1546

[SBUS<sb>:CAN:FILTer:DMIN](#) on page 1546

[SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:DMIN](#)
on page 1546

[SBUS<sb>:CAN:FILTer:DOPerator](#) on page 1547

[SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:DOPerator](#)
on page 1547

"Index" The index setup consists of a comparison condition and one or two index values.

Remote command:

[SBUS<sb>:CAN:FILTer:IMAX](#) on page 1548

[SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:IMAX](#)
on page 1548

[SBUS<sb>:CAN:FILTer:IMIN](#) on page 1548

[SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:IMIN](#)
on page 1548

[SBUS<sb>:CAN:FILTer:IOperator](#) on page 1549

[SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:IOperator](#)
on page 1549

Error type

Enables filtering on the selected error type.


Remote command:

[SBUS<sb>:CAN:FILTer:ERENable](#) on page 1547

[SBUS<sb>:CAN:FILTer:ERRor<n>:ENABle](#) on page 1547

14.9.3 CAN hardware trigger

Access: "Menu" > "Apps" > "Protocol" tab > "CAN" > "Trigger" tab > "Setup Hardware Trigger"




Type

Selects the trigger type for CAN analysis.

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.

- "Start of frame" Triggers on the first edge of the dominant SOF bit (synchronization bit).
- "End of frame" Triggers on the end of frame.
- "Frame type" Triggers on a specified frame type (data, remote, error, or overload). For data and remote frames, also the identifier format is considered.



"Identifier"

Sets the trigger to a specific message identifier or an identifier range.

The screenshot shows the 'Trigger' dialog box with the 'Identifier' trigger type selected. The 'ID type' is set to '11 bit'. The 'Identifier' condition is set to 'Equal'. The 'Value' field contains 'xxx'.

"Identifier + Data"

Sets the trigger to a combination of identifier and data condition. The instrument triggers at the end of the last byte of the specified data pattern.

The screenshot shows the 'Trigger' dialog box with the 'Identifier + Data' trigger type selected. The 'ID type' is set to '11 bit'. The 'Identifier' condition is set to 'Equal' with a value of 'xxx'. The 'DLC' condition is set to 'Greater or equal' with a value of '0'. The 'Data' condition is set to 'Equal' with a value of 'xx' and a position of '1'.

"Error condition"

Identifies various errors in the frame.

The screenshot shows the 'Trigger' dialog box with the 'Error condition' trigger type selected. The following error conditions are checked:

- Form error ☒
- Bit stuffing error ☒
- Stuff count error ☒
- Ack error ☒
- Checksum error ☒

Remote command:

[TRIGger:SBHW:CAN:TYPE](#) on page 1555

Frame type

CAN has different frame types which can be used as trigger condition. Depending on the selected frame, you can specify further parameters.

"CBFF" Classical base frame format data: supports a length of 11 bit for the CAN identifier. The data frame is the only frame for actual data transmission.



Figure 14-28: Settings for CBFF and CEFF frames

"CBFF-R" Classical base frame format remote: supports a length of 11 bit for the CAN identifier. The remote frame initiates the transmission of data by another node. The frame format is the same as of data frames but without the data field.



Figure 14-29: Settings for CBFF-R and CEFF-R frames

"CEFF" Classical extended frame format data: supports a length of 29 bit for the CAN identifier. The data frame is the only frame for actual data transmission.

- "CEFF-R"

Classical extended frame format remote: supports a length of 29 bit for the CAN identifier.
The remote frame initiates the transmission of data by another node. The frame format is the same as of data frames but without the data field.
- "FBFF"

FD base frame format: supports a length of 11 bit for the CAN identifier.



Figure 14-30: Settings for FBFF and FEFF frames

- "FEFF"

FD extended frame format: supports a length of 29 bit for the CAN identifier.

"XLFF"

XL frame format: supports a length of 29 bit for the CAN identifier.

Field	Condition	From	To
Frame type	XLFF		
Identifier	In range	000	7FF
DLC	Greater or equal	0	
Data	Equal	00	1
SDT	In range	00	FF
VCID	In range	00	FF
AF	In range	0000 0000	FFFF FFFF
SEC	0		

"Error"

When a node recognizes an error, it cancels transmission by sending an error frame.

The ID type is irrelevant for error frames.

"Overload"

When a node needs a delay between data and/or remote frames, it sends an overload frame.

The ID type is irrelevant for overload frames.

Remote command:

[TRIGger:SBHW:CAN:FTYPE](#) on page 1554

Identifier

Specifies the identifier pattern.

"Condition" Sets the comparison condition to a specific value or a range.

"Value"/"From" Specifies the value or sets the start value of a range.

"To" Sets the maximum value of a range for "Condition" = "In range"/"Out of range".

Remote command:

[TRIGger:SBHW:CAN:ICONdition](#) on page 1554

[TRIGger:SBHW:CAN:IMAX](#) on page 1554

[TRIGger:SBHW:CAN:IMIN](#) on page 1555

DLC

The data length code (DLC) defines the number of data bytes to be found. You can set a fixed value for the DLC or define a minimum value.

Remote command:

[TRIGger:SBHW:CAN:DLC](#) on page 1552

[TRIGger:SBHW:CAN:DLCCondition](#) on page 1552

Data pattern

Specifies the data pattern.

"Condition" Sets the comparison condition to a specific value or a range.

"Value" Specifies the value or sets the start value of a range.

Remote command:

[TRIGger:SBHW:CAN:DCondition](#) on page 1551

[TRIGger:SBHW:CAN:DMIN](#) on page 1552

ID type

Selects the length of the identifier:

"11 bit" Identifier length of the CAN base frame format. The instrument triggers on the sample point of the identifier extension flag (IDE) bit.

"29 bit" Identifier length of the CAN extended frame format. The instrument triggers on the sample point of the remote transmission request (RTR) bit.

"Any" The ID type and ID pattern are not relevant for the trigger condition. If the trigger type is "Identifier", the instrument triggers on any identifier in the specified frame type. If the trigger type is "Identifier + Data", set the "ID type" to "Any" if you want to trigger only on data.

Remote command:

[TRIGger:SBHW:CAN:ITYPE](#) on page 1555

BRS, ESI

If "Frame type" = "FBFF"/"FEFF", you can trigger on specific bits.

"BRS" The bit rate switch bit. Value 1 means that the bit rate switches from the arbitration rate to the faster data rate.

"ESI" The error state indicator bit. Set "X" if the bit is not relevant.

Remote command:

[TRIGger:SBHW:CAN:FDATa:BRS](#) on page 1552

[TRIGger:SBHW:CAN:FDATa:ESI](#) on page 1553

SDT

Specifies a value or a range for the service data unit type.

"Condition" Sets the comparison condition to a specific value or a range.

"Value"/"From" Specifies the value or sets the start value of a range.

"To" Sets the maximum value of a range for "Condition" = "In range"/"Out of range".

Remote command:

[TRIGger:SBHW:CAN:XDATA:SDT:CONDition](#) on page 1557

[TRIGger:SBHW:CAN:XDATA:SDT:MAX](#) on page 1557

[TRIGger:SBHW:CAN:XDATA:SDT:MIN](#) on page 1558

VCID

Specifies a value or a range for the virtual CAN network ID (VCID).

"Condition" Sets the comparison condition to a specific value or a range.

"Value"/"From" Specifies the value or sets the start value of a range.

"To" Sets the maximum value of a range for "Condition" = "In range"/"Out of range".

Remote command:

[TRIGger:SBHW:CAN:XDATA:VCID:CONDition](#) on page 1558

[TRIGger:SBHW:CAN:XDATA:VCID:MAX](#) on page 1559

[TRIGger:SBHW:CAN:XDATA:VCID:MIN](#) on page 1559

AF

Specifies a value or a range for the CAN XL acceptance field (AF).

"Condition" Sets the comparison condition to a specific value or a range.

"Value"/"From" Specifies the value or sets the start value of a range.

"To" Sets the maximum value of a range for "Condition" = "In range"/"Out of range".

Remote command:

[TRIGger:SBHW:CAN:XDATA:AF:CONDition](#) on page 1556

[TRIGger:SBHW:CAN:XDATA:AF:MAX](#) on page 1557

[TRIGger:SBHW:CAN:XDATA:AF:MIN](#) on page 1557

SEC


Sets a value for the simple extended content (SEC) field. It indicates, if the CAN XL data frame uses the CADsec protocol.

Remote command:

[TRIGger:SBHW:CAN:XDATA:SEC](#) on page 1558

Error conditions

If a CAN detects an error, it transmits an error flag at the next bit. The MXO 5C detects errors in the message and triggers on these errors even if no CAN node sends an error flag.



"Form error"	A form error occurs when a fixed-form bit field contains one or more illegal bits.
"Bit stuffing error"	The frame segments Start of Frame, Arbitration Field, Control Field, Data Field and CRC Sequence are coded by the bit stuffing method. The transmitter automatically inserts a complementary bit into the bitstream when it detects five consecutive bits of identical value in the bitstream to be transmitted. A stuff error occurs when the 6th consecutive equal bit level in the mentioned fields is detected.
"Stuff count error"	A stuff bit error occurs, if more than five consecutive bits of the same level occur on the bus.
"Ack error"	An acknowledgment error occurs when the transmitter does not receive an acknowledgment - a dominant bit during the ACK Slot.
"Checksum error"	CAN uses the Cyclic Redundancy Check, which is a complex checksum calculation method. The transmitter calculates the CRC and sends the result in the CRC sequence. The receiver calculates the CRC in the same way. A CRC error occurs when the calculated result differs from the received value in the CRC sequence.

Remote command:

[TRIGger:SBHW:CAN:FORMerror](#) on page 1553

[TRIGger:SBHW:CAN:BITSterror](#) on page 1550

[TRIGger:SBHW:CAN:FDATa:SCError](#) on page 1553

[TRIGger:SBHW:CAN:ACKerror](#) on page 1550

[TRIGger:SBHW:CAN:CRCErrror](#) on page 1551


14.9.4 CAN software trigger

14.9.4.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.9.4.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "CAN" > "Trigger" tab > "Setup Software Trigger" > "Setup SB Trigger".



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

"Check all"	Enables the software trigger for all available frames and error types.
"Clear"	Disables the software trigger for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:CAN:CHKall](#) on page 1560

[TRIGger:SBSW:CAN:CLR](#) on page 1560

[TRIGger:SBSW:CAN:INVert](#) on page 1560

[TRIGger:SBSW:CAN:RST](#) on page 1560

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.


Remote command:

[TRIGger:SBSW:CAN:FRENAble](#) on page 1561

[TRIGger:SBSW:CAN:FRAMe<fr>:ENABLe](#) on page 1561

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



- "Field" Enables the field type that you want to trigger on for the selected frame.
Remote command:
[TRIGger:SBSW:CAN:FIENable](#) on page 1562
[TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:ENABLE](#) on page 1562
- "Condition" Displays the value condition for the selected field.
Remote command:
[TRIGger:SBSW:CAN:BIT](#) on page 1561
[TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:BIT](#) on page 1561
- "Value" The data setup consists of a comparison condition and one or two data patterns.
Remote command:
[TRIGger:SBSW:CAN:DMAX](#) on page 1561
[TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:DMAX](#) on page 1561
[TRIGger:SBSW:CAN:DMIN](#) on page 1562
[TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:DMIN](#) on page 1562
[TRIGger:SBSW:CAN:DOPerator](#) on page 1562
[TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:DOPerator](#) on page 1562

"Index"

The index setup consists of a comparison condition and one or two index values.

Remote command:

[TRIGger:SBSW:CAN:IMAX](#) on page 1563

[TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:IMAX](#) on page 1563

[TRIGger:SBSW:CAN:IMIN](#) on page 1563


[TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:IMIN](#) on page 1563

[TRIGger:SBSW:CAN:IOperator](#) on page 1564

[TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:IOperator](#) on page 1564

Error type

Enables triggering on the selected error type.



Remote command:

[TRIGger:SBSW:CAN:ERENable](#) on page 1564

[TRIGger:SBSW:CAN:ERROR<m>:ENABLE](#) on page 1564

14.9.5 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.9.6 CAN decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.




Figure 14-31: Decoded CAN signal

The decode results table contains information about all decoded frames.

Table 14-14: Content of the decode results table

Column	Description
"Index"	Number of the decoded frame
"State"	Overall state of the frame. "Insufficient waveform length" indicates that the frame is not completely contained in the acquisition. Change the horizontal scale, or move the reference point to the left to get a longer acquisition.
"Start"	Time of frame start
"Type"	Frame type
"Symbol"	Symbolic label of the frame. Available only, if "Show symbols" is enabled in the "Display" tab and a symbols list is loaded.
"Identifier"	Identifier value in hexadecimal format. Select the data format in the "Display" tab.
"DLC"	Data length code, coded number of data bytes. Select the data format in the "Display" tab.
"Value"	Value of the data frame. Remote frames do not transmit data, therefore "- - -" is displayed. Select the data format in the "Display" tab.
"Nominal bit rate"	Number of bits per second
"Data bit rate"	Number of data bits per second

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-15: Content of the frame details table

Column	Description
"Index"	Number of the decoded field
"Label"	Field type. Values depend on the decoded frame "Type", see Table 14-16 .
"State"	Overall state of the frame
"Value"	Value of the field

Depending on the decoded type of frame, the following fields are available:

Table 14-16: Decoded fields, depending on the frame type

Frame	Fields
CBFF/CBFF-R	CRC: cyclic redundancy check
CEFF/CEFF-R	CRC: cyclic redundancy check
FBFF/FEFF	BRS: bit rate switch
	ESI: error state indicator
	SBC: stuff bit count
	CRC: cyclic redundancy check
XLFF	SBC: stuff bit count

Frame	Fields
	SDT: service data unit
	SEC: simple extended content
	VCID: virtual CAN network ID
	AF: acceptance field
	PCRC: preamble cyclic redundancy check
	FCRC: frame CRC

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- [SBUS<sb>:FORMat](#) on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.10.5, "Decode results"](#), on page 1565.

14.9.7 Performing CAN decoding


This section explains step by step how to configure and decode the CAN bus.

14.9.7.1 Configuring CAN signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.9.1, "CAN configuration"](#), on page 636.

1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: CAN.
4. Tap on "State" to enable the decoding.

A CAN shortcut appears at the bottom left of the screen. Tap on the shortcut for a quick access to the "CAN" dialog settings.



5. Tap on "Data" and select the correct channel.
6. Set the CAN "Type", depending on whether you use single-ended or differential probe:
 - a) For single-ended probes, connect the probe to either CAN-L or CAN-H. Set the "Type" accordingly.
 - b) For differential probes, connect the probe to both CAN-H and CAN-L lines. Set "Type" = "CAN-H".
7. Set the "Transceiver mode", according to your signal: "SIC mode" or "FAST mode".
8. Set the bit rate for
9. Check that the signals are on the screen.
If not try adjusting the vertical and horizontal settings.
10. Set the logical thresholds:
 - a) Tap "Threshold setup". The threshold dialog opens.
 - b) For each wire, set the threshold value.
 - c) If necessary, set the hysteresis value for the wires.
 - d) Optionally, tap on "Show threshold lines".

14.9.7.2 Triggering on CAN

Prerequisites: A bus is configured for the CAN signal to be analyzed. See [Section 14.9.7.1, "Configuring CAN signals"](#), on page 660.

1. Open "Menu" > "Trigger".
2. Set "Trigger on" to "Single event".
3. Ensure that the "Source" is set to the configured serial bus, e.g. "Serial bus 1".
4. Select the "Type".
5. For "Type" = "Frame type":

- a) Tap on "Set details".

Parameter	Operator	Value	Position
Frame type	CBFF		
Identifier	Equal	xxx	
DLC	Greater or equal	0	
Data	Equal	xx	1

- b) Select the "Frame type". According to the selected type, different settings are available.
- c) Set the "Identifier" or an identifier range.
- d) Set the "DLC" or a DLC range.
- e) Set the "Data" or a data range.
- f) Set the "ESI" value.
- g) Set the "BRS" value.
6. For "Type" = "Identifier":
- a) Tap on "Set details".

Parameter	Operator	Value
ID type	11 bit	
Identifier	Equal	xxx

- b) Select the "ID type".
- c) Set the "Identifier" or an identifier range.
7. For "Type" = "Identifier + Data":

- a) Tap on "Set details".

The screenshot shows the 'Trigger' settings window. It has a 'Back' button on the left. The main area contains four rows of settings:

Parameter	Operator	Value	Position
ID type	11 bit		
Identifier	Equal	xxx	
DLC	Greater or equal	0	
Data	Equal	xx	1

- b) Select the "ID type".
- c) Set the "Identifier" or an identifier range.
- d) Set the "DLC" or a DLC range.
- e) Set the "Data" or a data range.
8. For "Type" = "Error condition":
- a) Tap on "Set details".

The screenshot shows the 'Trigger' settings window for an error condition. It has a 'Back' button on the left. The main area contains five rows of settings, each with a checkbox:

Error Type	Checked
Form error	☒
Bit stuffing error	☒
Stuff count error	☒
Ack error	☒
Checksum error	☒

b) Select one or more error conditions that you want to trigger on:

- "Form error"
- "Bit stuffing error"
- "Stuff count error"
- "Ack error"
- "Checksum error"

14.9.7.3 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the CAN and decoded.

1. Tap on the "CAN" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".
5. Select the "File type".

An export file is saved in the selected directory.

The CAN export files contains the following fields:

- A list of all decoded frames:
 - Index
 - Start
 - Stop
 - State
 - Type
 - ID value
 - DLC
 - Nominal bit rate
 - Data bit rate
 - CRC
 - BRS
 - ESI
 - SBC
 - SDT
 - SEC
 - VCID
 - AF
 - PCRC
- The details frames include the following fields:

CAN (automotive electronics, option R&S MXO5C-K520)

- Index
- Data

Example of a CAN export file

```

Index,Start,Stop,State,Type,ID value,DLC,Nominal bit rate,Data bit rate,CRC,BRS,ESI,
SBC,SDT,SEC,VCID,AF,PCRC
1,-0.19,-0.188,'OK','XLFF',064h,7FFh,1000000,10000000,0000AABh,-,-,6h,FFh,1b,AAh,
000ABCDh,01FFh
2,-0.188311,-0.188243,'OK','CBFF',064h,3h,1000000,1000000,35CEh,-,-,-,-,-,-,-
3,-0.188239,-0.188195,'OK','CBFR',064h,3h,1000000,1000000,5AA0h,-,-,-,-,-,-,-
4,-0.188191,-0.188157,'OK','FBFF',064h,2h,1000000,5000000,035FFh,0b,1b,Eh,-,-,-,-,-
5,-0.188153,-0.188075,'OK','CEFF',01401B26h,2h,1000000,1000000,32A0h,-,-,-,-,-,-,-
6,-0.188071,-0.188008,'OK','CEFR',01900064h,3h,1000000,1000000,32AAh,-,-,-,-,-,-,-
7,-0.188004,-0.187951,'OK','FEFF',01900064h,3h,1000000,5000000,032AAh,1b,0b,Fh,-,-,-,-,-
8,-0.187947,-0.187899,'OK','XLFF',064h,046h,1000000,10000000,000032AAh,-,-,6h,03h,0b,0Ah,
0000ABCf,1FFFh
9,-0.187895,-0.187881,'INC','ERR',---,---,1000000,1000000,-,-,-,-,-,-,-
10,-0.187877,-0.187863,'UNKN','OVER',---,---,1000000,1000000,-,-,-,-,-,-,-

```

Details frame 2

```
Index,Data
```

```
1,D0h
```

```
2,E7h
```

```
3,20h
```

Details frame 4

```
Index,Data
```

```
1,D1h
```

```
2,E8h
```

Details frame 5

```
Index,Data
```

```
1,D2h
```

```
2,E9h
```

Details frame 7

```
Index,Data
```

```
1,D3h
```

```
2,EAh
```

```
3,21h
```

14.10 LIN (automotive electronics, option R&S MXO5C-K520)

The Local Interconnect Network (LIN) is a simple, low-cost bus system used within automotive network architectures. LIN is usually a subnetwork of a CAN bus. The primary purpose of LIN is the integration of uncritical sensors and actuators with low-bandwidth requirements. Common applications in a motor vehicle are the control of doors, windows, wing mirrors, and wipers.

Requirements

For performing LIN decode measurements, you need the following:

- MXO 5C with 1 available channel. The channel can be:
 - Analog channels (C1-C4)
 - Logic channels (D0-D15) (requires option R&S MXO5C-B1)
- One probe
- Option R&S MXO5C-K520
- [About the LIN protocol](#)..... 666
- [LIN configuration](#)..... 667
- [LIN filter](#)..... 670
- [LIN hardware trigger](#)..... 672
- [LIN software trigger](#)..... 675
- [Measure](#)..... 678
- [LIN decode results](#)..... 678
- [Performing LIN decoding](#)..... 680

14.10.1 About the LIN protocol

This section provides an overview of protocol characteristics, frame format, identifiers and trigger possibilities. For detailed information, order the LIN specification on <http://www.lin-subbus.org/> (free of charge).

LIN characteristics

The main characteristics of LIN are:

- Single-wire serial communications protocol, based on the UART byte-word interface
- Single primary, multiple secondaries - usually up to 12 nodes
- Primary-controlled communication: primary coordinates communication with the LIN schedule and sends the identifier to the secondaries
- Synchronization mechanism for clock recovery by secondary nodes without crystal or ceramic resonator

Data transfer

Basic communication concept of LIN:

- Communication in an active LIN network is always initiated by the primary.
- The primary sends a message header including the synchronization break, the synchronization byte, and the message identifier.
- The identified node sends the message response: one to eight data bytes and one checksum byte.
- Header and response form the message frame.




Figure 14-32: LIN frame with header and response


Data bytes are transmitted with LSB first.

The identifier byte consists of 6 bits for the frame identifier and two parity bits. This combination is known as protected identifier.

14.10.2 LIN configuration

14.10.2.1 LIN configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "LIN" > "Setup".



LIN standard

Selects the version of the LIN standard that is used in the DUT. The setting mainly defines the checksum version used during decoding.

The most common version is LIN v.2.x. For mixed networks, or if the standard is unknown, set the LIN standard to "Auto".

Remote command:

[SBUS<sb>:LIN:STANdard](#) on page 1579

Data

Sets the source waveform of the data line.

Remote command:

[SBUS<sb>:LIN:DATA:SOURce](#) on page 1578

Polarity

Defines the idle state of the bus. The idle state is the recessive state and corresponds to a logic high.

Remote command:

[SBUS<sb>:LIN:POLarity](#) on page 1579

Bit rate

Sets the number of transmitted bits per second. The maximum bit rate for LIN is 20 kbit/s.


If the [LIN standard](#) is "J2602", the bit rate is 10.417 kbit/s and cannot be changed.

Remote command:

[SBUS<sb>:LIN:BITRate](#) on page 1578

14.10.2.2 Threshold settings

Access: "Menu" > "Apps" > "Protocol" tab > "LIN" > "Thresholds".



Threshold

Sets the threshold for the data channel. Enter the value directly in the fields.

Additional to the threshold, you can also set a hysteresis.

Remote command:

[SBUS<sb>:LIN:DATA:THReshold](#) on page 1579

[SBUS<sb>:LIN:DATA:HYSTeresis](#) on page 1578

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.

The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:


[SBUS<sb>:THReshold](#) on page 1325

14.10.2.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.

14.10.3 LIN filter

Access: "Menu" > "Apps" > "Protocol" tab > "LIN" > "Filter" tab



In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

- "Check all" Enables the filter for all available frames and error types.
- "Clear" Disables the filter for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
- "Preset" Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:LIN:FILTER:CHKall](#) on page 1581

[SBUS<sb>:LIN:FILTER:CLR](#) on page 1582

[SBUS<sb>:LIN:FILTer:INVert](#) on page 1582

[SBUS<sb>:LIN:FILTer:RST](#) on page 1582

Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

Available frames are "Data", "Wake" and "Unknown".

Remote command:


[SBUS<sb>:LIN:FILTer:FREnable](#) on page 1584

[SBUS<sb>:LIN:FILTer:FRAMe<fr>:ENABLe](#) on page 1584

Edit

Opens a dialog to define the details of the selected frame.

"Field" Enables the field type that you want to filter on for the selected frame.



The available fields are "Id" and "Data".

Remote command:

[SBUS<sb>:LIN:FILTer:FIENable](#) on page 1584

[SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:ENABLe](#) on page 1584

"Condition" Displays the value condition for the selected field.

Remote command:

[SBUS<sb>:LIN:FILTer:BIT](#) on page 1582

[SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:BIT](#) on page 1582

"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: SBUS<sb>:LIN:FILTer:DMAX on page 1583 SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:DMAX on page 1583 SBUS<sb>:LIN:FILTer:DMIN on page 1583 SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:DMIN on page 1583 SBUS<sb>:LIN:FILTer:DOPerator on page 1583 SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:DOPerator on page 1583
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: SBUS<sb>:LIN:FILTer:IMAX on page 1585 SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:IMAX on page 1585 SBUS<sb>:LIN:FILTer:IMIN on page 1585 SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:IMIN on page 1585 SBUS<sb>:LIN:FILTer:IOPerator on page 1586 SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:IOPerator on page 1586

Error type

Enables filtering on the selected error type.

The available errors are "Checksum error", "Parity error", "Start error", "Sync error", "Length error" and "Incomplete".


Remote command:

[SBUS<sb>:LIN:FILTer:ERENable](#) on page 1584

[SBUS<sb>:LIN:FILTer:ERRor<n>:ENABle](#) on page 1584

14.10.4 LIN hardware trigger

Access: "Menu" > "Apps" > "Protocol" tab > "LIN" > "Trigger" tab > "Setup Hardware Trigger"




Type

Selects the trigger type for LIN analysis.

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.

"Start of frame (Sync)" Triggers on the stop bit of the sync field.

"Identifier" Sets the trigger to one specific identifier or an identifier range. Enter only the 6-bit identifier without parity bits, not the protected identifier. Description of trigger type specific settings: [Identifier setup: Condition, Frame ID min, Frame ID max](#).



"Identifier + Data" Sets the trigger to a combination of identifier and data condition. The instrument triggers at the end of the last byte of the specified data pattern.



The identifier conditions are the same as for the "Identifier" trigger type, see [Identifier setup: Condition, Frame ID min, Frame ID max](#). Data conditions are set with [Data setup: Condition, Pattern, Position](#).

"Wake-up frame" Triggers after a wake-up frame.

"Error condition" Identifies various errors in the frame, see [Error conditions](#).

Remote command:

[TRIGger:SBHW:LIN:TYPE](#) on page 1586

Identifier setup: Condition, Frame ID min, Frame ID max

The identifier setup consists of the condition and one or two identifier pattern.

Condition Sets the comparison condition to a specific value or a range.

"Frame ID min" Defines the bit pattern of the identifier. Enter only the 6-bit identifier without parity bits, not the protected identifier.

"Frame ID max" Sets the maximum value of a range for "Condition" = "In range"/"Out of range".

Remote command:

[TRIGger:SBHW:LIN:IMIN](#) on page 1587

[TRIGger:SBHW:LIN:IMAX](#) on page 1588

[TRIGger:SBHW:LIN:ICONdition](#) on page 1588

Data setup: Condition, Pattern, Position

The data setup consists of the the condition, the position of the pattern, and one data pattern.

Condition Sets the operator to define a specific data pattern ("Equal" or "Not equal") or a range smaller or bigger than a specific pattern.

"Pattern" Defines the data pattern.

"Position" Sets the number of data events that are ignored, before trigger condition check of the data starts.

Remote command:


[TRIGger:SBHW:LIN:DCONDITION](#) on page 1589

[TRIGger:SBHW:LIN:DMIN](#) on page 1588

[TRIGger:SBHW:LIN:DPOSITION](#) on page 1588

Error conditions

Triggers if one or more of the following errors occur.



"Parity error"	Parity bits are the bits 6 and 7 of the identifier. They verify the correct transmission of the identifier.
"Sync error"	Synchronization error.
"Checksum error"	The checksum verifies the correct data transmission. It is the last byte of the frame response. The checksum includes not only the data but also the protected identifier (PID).

Remote command:

[TRIGger:SBHW:LIN:IPERror](#) on page 1587

[TRIGger:SBHW:LIN:SYERror](#) on page 1587

[TRIGger:SBHW:LIN:CHKSError](#) on page 1589


14.10.5 LIN software trigger

14.10.5.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.10.5.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "LIN" > "Trigger" tab > "Setup Software Trigger"



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

"Check all"	Enables the software trigger for all available frames and error types.
"Clear"	Disables the software trigger for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:LIN:CHKall](#) on page 1590

[TRIGger:SBSW:LIN:CLR](#) on page 1590

[TRIGger:SBSW:LIN:INVert](#) on page 1590

[TRIGger:SBSW:LIN:RST](#) on page 1590

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frames are available: "Data", "Wake Up", "Unknown".


Remote command:

[TRIGger:SBSW:LIN:FREnable](#) on page 1591

[TRIGger:SBSW:LIN:FRAMe<fr>:ENABle](#) on page 1591

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



"Field" Enables the field type that you want to trigger on for the selected frame.

The following fields are available:

Remote command:

[TRIGger:SBSW:LIN:FIENable](#) on page 1592

[TRIGger:SBSW:LIN:FRAMe<fr>:FLD<fl>:ENABle](#) on page 1592

"Condition" Displays the value condition for the selected field.

Remote command:

[TRIGger:SBSW:LIN:BIT](#) on page 1591

[TRIGger:SBSW:LIN:FRAMe<fr>:FLD<fl>:BIT](#) on page 1591

"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: TRIGger:SBSW:LIN:DMAX on page 1591 TRIGger:SBSW:LIN:FRAMe<fr>:FLD<fl>:DMAX on page 1591 TRIGger:SBSW:LIN:DMIN on page 1592 TRIGger:SBSW:LIN:FRAMe<fr>:FLD<fl>:DMIN on page 1592 TRIGger:SBSW:LIN:DOPerator on page 1592 TRIGger:SBSW:LIN:FRAMe<fr>:FLD<fl>:DOPerator on page 1592
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: TRIGger:SBSW:LIN:IMAX on page 1593 TRIGger:SBSW:LIN:FRAMe<fr>:FLD<fl>:IMAX on page 1593 TRIGger:SBSW:LIN:IMIN on page 1593 TRIGger:SBSW:LIN:FRAMe<fr>:FLD<fl>:IMIN on page 1593 TRIGger:SBSW:LIN:IOPerator on page 1594 TRIGger:SBSW:LIN:FRAMe<fr>:FLD<fl>:IOPerator on page 1594

Error type

Enables triggering on the selected error type.

The following error types are available: "Checksum error", "Parity error", "Start error", "Sync error", "Length error" and "Incomplete".

Remote command:

[TRIGger:SBSW:LIN:ERENable](#) on page 1594

[TRIGger:SBSW:LIN:ERRor<m>:ENABle](#) on page 1594

14.10.6 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.10.7 LIN decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.




Figure 14-33: Decoded LIN signal

The decode results table contains information about all decoded frames.

Table 14-17: Content of the decode results table

Column	Description
Index	Index of the decoded frame
State	Overall state of the frame
Start	Time of frame start
Symbol	Symbolic label of the frame. Available only, if "Show symbols" is enabled in the "Display" tab and a symbols list is loaded.
Identifier	Identifier value
PID	Protected identifier
Checksum	Checksum value
Values	Value of the data bytes. Select the data format in the "Display" tab.
Bit rate	Value of the bit rate

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-18: Content of the frame details table

Column	Description
Index	Index of the field
Label	Name of the field
State	State of the field
Value	Value of the field

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- [SBUS<sb>:FORMat](#) on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.11, "LIN \(option R&S MXO5C-K520\)"](#), on page 1577.

14.10.8 Performing LIN decoding


This section explains step by step how to configure and decode the LIN bus.

14.10.8.1 Configuring LIN signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.10.2, "LIN configuration"](#), on page 667.

1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: LIN.
4. Tap on "State" to enable the decoding.

An SPI shortcut appears at the bottom left of the screen. Tap on the shortcut for a quick access to the "LIN" dialog settings.



5. Select the "LIN standard".
6. Select the correct channel for "Data".
7. Set the "Bit rate".
8. Check that the signals are on the screen.
If not try adjusting the vertical and horizontal settings.
9. Set the logical thresholds:
 - a) Tap "Threshold setup". The threshold dialog opens.
 - b) For each wire, set the threshold value. A typical value is 3.5 V.
 - c) If necessary, set the hysteresis value.
 - d) Optionally, tap on "Show threshold lines".

14.10.8.2 Triggering on LIN

Prerequisites: A bus is configured for the LIN signal to be analyzed. See [Section 14.10.8.1, "Configuring LIN signals"](#), on page 680.

1. Open "Menu" > "Trigger".
2. Set "Trigger on" to "Single event".
3. Ensure that the "Source" is set to the configured serial bus, e.g. "Serial bus 1".
4. Select the "Type".
5. Define additional settings for more complex trigger types: "Identifier", "Identifier +Data".
 - a) Tap on "Set details".
 - b) Set the "Identifier" condition or an identifier range.
 - c) Set the "Data" condition or a data range.

14.10.8.3 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the LIN and decoded.

1. Tap on the "LIN" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".

5. Select the "File type".

An export file is saved in the selected directory.

The LIN export file contains the following fields:

- A list of all decoded frames:
 - Index
 - Start
 - Stop
 - State
 - Identifier
 - PID
 - Checksum
 - Bit rate
- The details frames include the following fields:
 - Index
 - State
 - Value

Example of LIN export file

```
Index,Start,Stop,State,Identifier,PID,Checksum,Bit rate
1,-3.44,-3.43375,'OK',02h,C2h,D0h,20000
2,-3.43325,-3.427,'OK',22h,22h,30h,20000
3,-3.4265,-3.42025,'OK',12h,92h,B0h,20000
4,-3.41975,-3.4135,'OK',32h,72h,70h,20000
5,-3.413,-3.40675,'OK',0Ah,CAh,F0h,20000
```

```
Details frame 1
Index,State,Value
1,'OK',40h
2,'OK',C0h
3,'OK',20h
4,'OK',A0h
5,'OK',60h
6,'OK',E0h
7,'OK',10h
8,'OK',90h
```

```
Details frame 2
Index,State,Value
1,'OK',50h
2,'OK',D0h
3,'OK',30h
4,'OK',B0h
5,'OK',70h
6,'OK',F0h
```

```
7, 'OK', 08h
8, 'OK', 88h
```

14.11 SENT (automotive electronics, option R&S MXO5C-K520)

Single Ended Nibble Transmission (SENT) is a serial transmission interface protocol originally specified for the communication of sensors and control units in automotive electronics.

SENT is a protocol standard governed by the Society of Automotive Engineers (SAE J2716). For detailed information, refer to the SENT standard specification on <http://www.sae.org>.

The SENT protocol is used exclusively in automotive applications. Examples are electrical power steering, and advanced driver assistance such as parking assist or sensing of pressure, throttle position, pedal position, airflow mass, liquid level, etc.

Requirements

For performing SENT decode measurements, you need the following:

- MXO 5C with 1 available channel. The channel can be:
 - Analog channels (C1-C4)
 - Logic channels (D0-D15) (requires option R&S MXO5C-B1)
- One probe
- Option R&S MXO5C-K520

• About the SENT protocol	683
• SENT configuration	687
• SENT filter	691
• SENT software trigger	695
• Measure	698
• SENT decode results	698
• Performing SENT decoding	700

14.11.1 About the SENT protocol

This section provides an overview of the protocol characteristics, encoding scheme, identifiers and trigger possibilities.

The SENT protocol transmits signal values point-to-point from a sensor to a controller (electronic control unit ECU), unidirectional. In contrast to conventional measurements, you can receive multiple data parameters via the SENT interface in a single transmission. Nevertheless, SENT is characterized by its simplicity and yet high customizability to meet the individual requirements of the applications.

SENT operates via a three-wire connection, a signal line, a supply voltage line for the sensor and a ground line. It transmits data digitally in variable timing units and evalu-

ates the time between two falling edges (single edges). The signal is amplitude modulated with a constant amplitude voltage. Thus the influences of disturbance signals are not critical.

SENT key features

The main characteristics of SENT are:

- Serial communication protocol
- 3 wires: SENT (signal line), 5V (voltage line), GND (ground line)
- Output only, from sensor to receiver
- Point-to-point transmission, no bus
- Digital transmission
- High baud rate
- Data transmission in variable timing units of 4 bits (1 nibble) between two falling edges
- Transmitter-specific clock period (tick)
- Time measured between single falling edges

14.11.1.1 SENT transmission concept

A sensor converts the analog measured data to a digital signal, and thus transmits a series of pulses to the receiver. The receiver, e.g. an ECU processes the received signal also digitally.

The format of a SENT message frame has a fixed pulse order and a transmitter-specific clock period. The total transmission time varies depending on the clock variation of the transmitter and the transmitted data values. The data pulses embedded in the transmission sequence represent one or multiple data parameters to be communicated. The last pulses in a message frame are the CRC check pulse, allowing the receiver to perform some diagnostic tests, and an optional pause pulse.

A SENT transmission starts without a request from the receiver. Consecutive sequences are transmitted continuously after the falling edge of the last pulse.

The SENT protocol distinguishes between two channel types:

- **Fast channel:** transmits primary data, i.e. sensor readings like temperature, pressure, mass air flow, throttle position.
- **Slow channel:** transmits secondary data consisting of transfer characteristics, sensor ID, type, manufacturer diagnostic, etc.
The slow channel transmission provides two serial message formats *Short* and *Enhanced* for customizing the secondary data.

The data of both channels is transmitted simultaneously, by including two bits of a slow channel message in the message frame of the fast channel. Even though it requires many fast channel messages to complete a slow channel message, you can use this function to transmit several slow channel messages with minimal impact on the primary sensor data and the data rate.

14.11.1.2 SENT message definitions

SENT terms

See the specific terms and definitions used in the SENT protocol:

- **Tick (clock tick):** basic unit of time
 - Transmitter-specific nominal clock period
 - $3\ \mu\text{s} < \text{clock tick} < 90\ \mu\text{s}$, with max. 20 % clock variation
- **Nibble:** minimum unit of data
 - Used to transmit data
 - Variable timing units between two falling edges

SENT fast channel

The SENT protocol enables you to transmit measurements of multiple sensors in one transmission sequence with data signals of varying length. The diagram in [Figure 14-34](#) shows, for example, the encoding scheme for two 12-bit data signals.




Figure 14-34: Example of a SENT transmission sequence

The format of a SENT transmission sequence consists of the following pulses:

- **Synchronization/Calibration pulse:**
 - Initial sequence of the receiver
 - The start condition is the falling edge of the last pulse (CRC or Pause)
 - The nominal pulse period is 56 clock ticks
 - Measures the actual clock variation of the transmitter and calculates the tick timing
- **Status/Communication Pulse (Nibble)**
 - One 4 bit pulse
 - Communicates status and enables the sensor to include slow channel message bits
 - 0: (LSB) specific application
 - 1: specific application
 - 2: Serial Data message or specific application (e.g. Infineon TLE4998S)
 - 3: (MSB) 1= message start; 0=Serial Data message or specific application (e.g. Infineon TLE4998S)
 - 12 to 27 clock ticks
 - Not included in CRC frame calculation

SENT (automotive electronics, option R&S MXO5C-K520)

- **Data Pulses (Nibbles)**
 - One up to six 4 bit data nibbles
 - 12 to 27 clock ticks pulse period
 - Initial logic 0 time with ≥ 5 ticks, subsequent logical 1 with variable duration
- **CRC/Checksum**
 - One 4 bit pulse
 - Used for error checking of data nibbles (status nibble not included)
 - Detects single bit, odd number of nonconsecutive and single burst errors
- **Pause Pulse**
 - One optional pulse
 - Variable pulse length: 12 to 768 clock ticks
 - Can be used to create a transmission with a constant number of clock ticks

SENT slow channel**Short Serial Messages**

For transmission of a slow channel message, 2 bits are included in a fast channel message, see the status nibble (Bit 2,3) in [Figure 14-35](#).

A short serial message needs 16 fast channel messages until it is completely transmitted. Prerequisite for the complete transmission of the slow channel message is 16 consecutive error-free fast channel transmissions.




Figure 14-35: One serial message, composed of 16 SENT consecutive fast channel transmissions

Enhanced Serial Messages

The transmission of an enhanced serial message format requires 18 fast channel transmissions. Each slow channel message is assigned a message ID, which is transmitted with the data.


The enhanced serial message format provides two alternatives for configuring the message:

- 4-bit ID and 16-bit data
- 8-bit ID and 12-bit data


SENT (automotive electronics, option R&S MXO5C-K520)

The graphs below illustrate the variants.

Table 14-19: Enhanced serial message formats



16-bit data and 4-bit message ID




12-bit data and 8-bit message ID

14.11.2 SENT configuration

14.11.2.1 SENT configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "SENT" > "Setup".





Make sure that the tab of the correct serial bus is selected.

Protocol type

Selects the protocol type to be decoded.

Remote command:

[SBUS<sb>:TYPE](#) on page 1322

Data

Sets the source of the data line.

Remote command:

[SBUS<sb>:SENT:DATA:SOURce](#) on page 1603

Mode

Selects the operating mode of the SENT protocol.

If "Mode" = "Legacy", the "SPC" mode is not supported.

The single point calibration ("SPC") mode was introduced in the SENT 2.0 specification. If "SPC" mode is selected, the SENT protocol allows for the calibration of a sensor's output by sending a single calibrated value. It is particularly useful for applications where a sensor needs to be calibrated to ensure accurate readings. The SPC mode typically involves the transmission of a single data frame that contains the calibrated value, which can then be used by the receiving device to interpret the sensor's output correctly.

Remote command:

[SBUS<sb>:SENT:MODE](#) on page 1604

Clock period

Sets the transmitter-specific nominal clock period (clock tick).

The clock period and signal length determine the speed of transmission.

Remote command:

[SBUS<sb>:SENT:CLKPeriod](#) on page 1601

Clock tolerance

Specifies a tolerated deviation of the clock.

Remote command:

[SBUS<sb>:SENT:CLKTolerance](#) on page 1602

Data nibbles

Sets the number of data units in a single transmission sequence.

The maximum number of data nibbles is 6.

Remote command:

[SBUS<sb>:SENT:DNIBbles](#) on page 1604

Serial message

Selects if serial messages are enabled or disabled.

SENT (automotive electronics, option R&S MXO5C-K520)

Remote command:

[SBUS<sb>:SENT:SFormat](#) on page 1606

CRC version

Selects the version that the CRC check is based on.

"Legacy" Based on the CRC calculation version used earlier than 2010.

"v2010/v2016" Based on the CRC calculation version updated in 2010/2016.

Remote command:

[SBUS<sb>:SENT:CRCTVersion](#) on page 1602

CRC calculation

Selects the method for CRC calculation.

"SAE_J2716" Calculates the CRC according to the SAE standard.
For this method, the checksum is calculated over all nibbles except the communication and status nibble.

"TLE_4998X" Calculates the CRC according to the standard computing method for Infineon TLE_4998X sensors.
For this method, the checksum is calculated over all nibbles except the communication nibble.

Remote command:

[SBUS<sb>:SENT:CRCTMethod](#) on page 1602

Pause pulse

Determines whether a pause pulse is transmitted after the checksum nibble.

You can use this pulse to create a transmission with a constant number of clock ticks. The pause pulse length can be between a minimum of 12 clock ticks up to 768 (3*256) ticks at a maximum.

Remote command:

[SBUS<sb>:SENT:PPULse](#) on page 1605

Frame length

Determines the frame length in terms of ticks. The dialog displays this settings parameter, if the signal has a constant frame length.

Remote command:

[SBUS<sb>:SENT:PPFLength](#) on page 1605

14.11.2.2 Threshold settings

Access: "Menu" > "Apps" > "Protocol" tab > "SENT" > "Thresholds".

Threshold

Sets the threshold for the data channel. Enter the value directly in the fields.

Additional to the threshold, you can also set a hysteresis.

Remote command:

[SBUS<sb>:SENT:DATA:THReshold](#) on page 1603

[SBUS<sb>:SENT:DATA:HYSTeresis](#) on page 1603

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.

The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:

`SBUS<sb>:THReshold` on page 1325

14.11.2.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.

Decode layer

Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display.

Show symbols

You can load symbol lists, and activate its usage for decoding. As a result, an additional "Symbol" column appears in the "Decode results" table, containing the symbolic label.

For details, see [Section 14.11.2.4, "SENT symbols"](#), on page 690.

14.11.2.4 SENT symbols

Label lists are protocol-specific. For the SENT protocol, you can upload symbol lists as in the format shown in the following example.

Example: SENT symbols file

```
<sb:FRAME NAME="Diagnostic Error Codes" STATE="ON">
  <!-- Start of a Frame Definition -->
  <!-- This block defines the information of a Transmission Sequence
  or Serial Message:
  NAME => Symbolic Label of the Frame
  STATE [ON/OFF] => When ON, this frame Translation is taken into consideration.
                    When OFF, this frame Translation is skipped.-->
<sb:DESCRIPTION> used to diagnose the current SENT System</sb:DESCRIPTION>
  <!-- Doesn't affect the Translation -->
<sb:ID-VALUE>01</sb:ID-VALUE>
  <!-- ID Value of the Serial Message (in decimal) -->
  <!-- Absence of the ID-VALUE field implies that the current Frame Translation
  is to be used for Transmission Sequences and not for a Serial Message -->
<sb:ID-LENGTH>8</sb:ID-LENGTH>
  <!-- ID Length of the Serial Message (in bits) -->
<sb:DATA-SIZE>12</sb:DATA-SIZE>
  <!-- Data Length of the Serial Message (in bits) -->
<sb:SIGNALS>
```

SENT (automotive electronics, option R&S MXO5C-K520)

```


    <!-- This block defines the information of the Signals embedded
    in the Data Field of the Frame (Transmission Sequence or Serial Message) -->
<sb:SIGNAL ID="Diagnostic">
    <!-- Unique ID of the Signal (no effect on Translation) -->
<sb:SHORT-NAME>Diagnostic Code</sb:SHORT-NAME>
    <!-- Name of the Signal -->
<sb:DESCRIPTION></sb:DESCRIPTION>
    <!-- Info Field (no effect on Translation) -->
<sb:BIT-POSITION>11</sb:BIT-POSITION>
    <!-- Starting Bit position of the Signal
    (The whole Data Field is represented as MSB -> LSB Sequence) -->
<sb:BIT-LENGTH>12</sb:BIT-LENGTH>
    <!-- Number of Bits representing the Signal Value -->
<sb:BYTE-ORDER>MSB</sb:BYTE-ORDER>
    <!-- Byte Order of the Signal Value [MSB or LSB], Default: MSB -->
<sb:VALUE-TYPE>ENUM</sb:VALUE-TYPE>
    <!-- Representation of the Bits [ENUM, UNSIGNED_INT, INT, FLOAT, DOUBLE],
    Default: UNSIGNED_INT
    The Signal Value is calculated according to the following:
    Translated_Value = Encoded_Value * FACTOR + OFFSET -->
<sb:FACTOR>1.0</sb:FACTOR>
    <!-- Signal Factor (decimal value)-->
<sb:OFFSET>0.0</sb:OFFSET>
    <!-- Signal Offset (decimal value)-->
<sb:MIN>0</sb:MIN>
    <!-- Minimum Signal Value (decimal value) -->
<sb:MAX>4096</sb:MAX>
    <!-- Maximum Signal Value (decimal value) -->
<sb:ENUM-VALUES>
    <!-- This block is only valid (and taken into consideration)
    when the VALUE-TYPE is ENUM
    It defines the Enumeration List Translation of the Signal -->
<sb:ENUM INDEX="0" LABEL="No Error"/>
    <!-- INDEX is the Enum Value (corresponds to the Signal Value in decimal),
    LABEL is the matching Translated Signal Value -->
<sb:ENUM INDEX="1" LABEL="Channel 1 out of range high"/>
</sb:ENUM-VALUES>
    <!-- End of Signal Enumeration List Definition -->
</sb:SIGNAL>
    <!-- End of a Signal Definition -->
    <!-- More Signals can be defined here! -->
</sb:SIGNALS>
    <!-- End of list of Signals Definition -->
</sb:FRAME>
    <!-- End of Frame Definition -->

```

14.11.3 SENT filter

Access: "Menu" > "Apps" > "Protocol" tab > "SENT" > "Filter" tab

SENT (automotive electronics, option R&S MXO5C-K520)



In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

- "Check all" Enables the filter for all available frames and error types.
- "Clear" Disables the filter for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
- "Preset" Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:SENT:FILTer:CHKall](#) on page 1608

[SBUS<sb>:SENT:FILTer:CLR](#) on page 1608

[SBUS<sb>:SENT:FILTer:INVert](#) on page 1609

[SBUS<sb>:SENT:FILTer:RST](#) on page 1609

SENT (automotive electronics, option R&S MXO5C-K520)

Enable

Enables the filtering on SENT frames. Only the frames that match the selected filter conditions are displayed.

Remote command:

[SBUS<sb>:SENT:FILTer:FRENAble](#) on page 1609

[SBUS<sb>:SENT:FILTer:FRAMe<fr>:ENABLe](#) on page 1609

Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frame types are available: "Transmission Sequence", "Short Serial Msg", "Enhanced 12bit Serial Msg", "Enhanced 16bit Serial Msg", "Pause pulse", "Unknown".

Edit

Opens a dialog to define the details of the selected frame.

Serial bus:
SENT

SB1

Back

Transmission Sequence

	AND	Field	Condition
1	☐	MTP	
2	☐	Sync	
3	☐	Status	
4	☐	Data	
5	☐	CRC	

Data

Value: Equal

Index: In range

1 65535

SENT (automotive electronics, option R&S MXO5C-K520)

"Field"	Enables the field type that you want to filter on for the selected frame. The following fields are available: "MTP", "Sync", "Status", "Data", "CRC", "ID". Remote command: SBUS<sb>:SENT:FILTer:FIENable on page 1611 SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:ENABle on page 1611
"Condition"	Displays the value condition for the selected field. Remote command: SBUS<sb>:SENT:FILTer:BIT on page 1609 SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:BIT on page 1609
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: SBUS<sb>:SENT:FILTer:DMAX on page 1610 SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:DMAX on page 1610 SBUS<sb>:SENT:FILTer:DMIN on page 1610 SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:DMIN on page 1610 SBUS<sb>:SENT:FILTer:DOPerator on page 1611 SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:DOPerator on page 1611
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: SBUS<sb>:SENT:FILTer:IMAX on page 1611 SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:IMAX on page 1611 SBUS<sb>:SENT:FILTer:IMIN on page 1612 SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:IMIN on page 1612 SBUS<sb>:SENT:FILTer:IOperator on page 1612 SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:IOperator on page 1612

Error type

Enables filtering on the selected error type.

The available error types are "Sync pulse error", "Pulse period error", "CRC error", "Length error", "Form error", "Pause error", "Incomplete".

Remote command:

[SBUS<sb>:SENT:FILTer:ERENable](#) on page 1613

[SBUS<sb>:SENT:FILTer:ERRor<n>:ENABle](#) on page 1613

SENT (automotive electronics, option R&S MXO5C-K520)


14.11.4 SENT software trigger

14.11.4.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.11.4.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "SENT" > "Trigger" tab > "Setup Software Trigger" > "Setup SB Trigger"



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

- "Check all" Enables the software trigger for all available frames and error types.
- "Clear" Disables the software trigger for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

SENT (automotive electronics, option R&S MXO5C-K520)

"Preset" Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:SENT:CHKall](#) on page 1614

[TRIGger:SBSW:SENT:CLR](#) on page 1614

[TRIGger:SBSW:SENT:INVert](#) on page 1614

[TRIGger:SBSW:SENT:RST](#) on page 1614

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frame types are available: "Transmission Sequence", "Short Serial Msg", "Enhanced 12bit Serial Msg", "Enhanced 16bit Serial Msg", "Pause pulse", "Unknown".


Remote command:

[TRIGger:SBSW:SENT:FRENable](#) on page 1614

[TRIGger:SBSW:SENT:FRAME<fr>:ENABLE](#) on page 1614

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.




SENT (automotive electronics, option R&S MXO5C-K520)

"Field"	Enables the field type that you want to trigger on for the selected frame. The following fields are available: "MTP", "Sync", "Status", "Data", "CRC", "ID". Remote command: TRIGger:SBSW:SENT:FIENable on page 1615 TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:ENABLE on page 1615
"Condition"	Displays the value condition for the selected field. Remote command: TRIGger:SBSW:SENT:BIT on page 1615 TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:BIT on page 1615
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: TRIGger:SBSW:SENT:DMAX on page 1615 TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:DMAX on page 1615 TRIGger:SBSW:SENT:DMIN on page 1616 TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:DMIN on page 1616 TRIGger:SBSW:SENT:DOPerator on page 1616 TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:DOPerator on page 1616
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: TRIGger:SBSW:SENT:IMAX on page 1617 TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:IMAX on page 1617 TRIGger:SBSW:SENT:IMIN on page 1617 TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:IMIN on page 1617 TRIGger:SBSW:SENT:IOperator on page 1617 TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:IOperator on page 1617

Error type

Enables triggering on the selected error type.



The following error types are available: "Sync pulse error", "Pulse period error", "CRC error", "Length error", "Form error", "Pause error".

Remote command:

[TRIGger:SBSW:SENT:ERENable](#) on page 1618

[TRIGger:SBSW:SENT:ERROR<m>:ENABLE](#) on page 1618

14.11.5 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.11.6 SENT decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

SENT (automotive electronics, option R&S MXO5C-K520)

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.

Decode results table

The "Decode results" table contains information about all decoded frames.




Figure 14-36: Decoded SENT signal

The decode results table contains information about all decoded frames.

Table 14-20: Content of the decode results table

Column	Description
Index	Index of the decoded frame
State	Overall state of the frame
Start	Time of frame start
Frame type	The type of frame
Symbolic name	Symbolic label of the frame. Available only, if "Show symbols" is enabled in the "Display" tab and a symbols list is loaded.
Sync time	Synchronisation time
Status [bin]	Status value

SENT (automotive electronics, option R&S MXO5C-K520)

Column	Description
Data nibbles	Values of the data nibbles. Select the data format in the "Display" tab.
ID value	Identifier value
Clock rate	Value of the clock rate

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-21: Content of the frame details table

Column	Description
Index	Number of the decoded field
Label	Name of the field
State	State of the field
Value	Value of the field

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- `SBUS<sb>:FORMat` on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.12.4, "Decode results"](#), on page 1619.

14.11.7 Performing SENT decoding


This section explains step by step how to configure and decode the SENT bus.

14.11.7.1 Configuring SENT signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.11.2, "SENT configuration"](#), on page 687.

1. Tap the "+ Bus" activator in the bottom right of the screen.



SENT (automotive electronics, option R&S MXO5C-K520)

2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap "Protocol type". Select the protocol: "SENT".
4. Tap "State" to enable the decoding.

A SENT shortcut appears at the bottom left of the screen. Tap on the shortcut for a quick access to the "SENT" dialog settings.



5. Select the correct channel for "Data".
6. Set "Bit order" to "MSB" or "LSB first".
7. Set "Clock polarity" to "Rising edge" (CPOL = 0) or "Falling edge" (CPOL = 1).
8. Set "MOSI polarity"/"MISO polarity" to "Active high"(CPHA = 0) or "Active low"(CPHA = 1).
9. Set "CS polarity" to "Active high" or "Active low".
The typical value is "Active low", which means that the line is pulled low on message start.
10. Set the "Word length". The typical value is 8.
11. Check that the signals are on the screen.
If not try adjusting the vertical and horizontal settings.
12. Set the logical thresholds:
 - a) Tap "Threshold setup". The threshold dialog opens.
 - b) Set the threshold value. A typical value is 3.5 V.
 - c) If necessary, set the hysteresis value.
 - d) Optionally, tap on "Show threshold lines".

14.11.7.2 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the SENT and decoded.

1. Tap on the "SENT" shortcut.
2. Tap on the "Shortcuts" tab.
3. Tap "Export results".
4. If necessary, enable "Include details".
5. If necessary, enable "Include timing".
6. Select the "File type".

An export file is saved in the selected directory.

The SENT export files contain the following fields:

- Index
- Start
- Stop
- State
- Type
- Symbol
- Sync duration
- Status
- CRC
- ID
- MTP duration
- Sensor response time
- Bit rate

Example SENT export file

```
Index,Start,Stop,State,Type,Symbol,SyncDur,Status,CRC,ID,MTP,SensorRespTime,BR
1 -0.0534 -0.0523 'OK' 'TRSQ' 0.000280 3h Bh - - - 199900
2 -0.0521 -0.0509 'PULS' 'TRSQ' 0.000280 3h Bh - - - 199900
3 -0.050 -0.0499 'OK' 'TRSQ' 0.000280 0h Fh - - - 199900
4 -0.0496 -0.0486 'OK' 'TRSQ' 0.000280 0h 4h - - - 199900
5 -0.0483 -0.0472 'CRC' 'TRSQ' 0.000280 0h 4h - - - 199900
6 -0.0470 -0.0460 'OK' 'TRSQ' 0.000280 0h 1h - - - 199900
7 -0.0457 -0.0447 'OK' 'TRSQ' 0.000280 0h 0h - - - 199900
8 -0.0447 -0.0435 'OK' 'TRSQ' 0.000280 0h Bh - - - 199900
9 -0.0432 -0.0422 'OK' 'TRSQ' 0.000280 0h Eh - - - 199900
10 -0.041 -0.0410 'OK' 'TRSQ' 0.000280 0h 3h - - - 199900
```

Details frame 1

Index	State	Value
1	'OK'	14h
2	'OK'	15h
3	'OK'	16h
4	'OK'	17h
5	'OK'	18h
6	'OK'	19h
7	'OK'	1Ah
8	'OK'	1Bh

Details frame 2

Index	State	Value
1	'OK'	1Ch
2	'OK'	1Dh
3	'OK'	1Eh
4	'OK'	1Fh
5	'OK'	20h

6	'OK'	21h
7	'OK'	22h
8	'OK'	23h
9	'OK'	24h

14.12 ARINC 429 (aerospace electronics, option R&S MXO5C-K530)

The ARINC 429 is a specification that defines the characteristics of an avionic data bus used on commercial and transport aircraft.

- [About the ARINC 429](#).....703
- [ARINC 429 configuration](#).....704
- [ARINC 429 filter](#).....707
- [ARINC 429 software trigger](#).....710
- [Measure](#).....713
- [ARINC 429 decode results](#).....713
- [Performing ARINC 429 decoding](#).....715

14.12.1 About the ARINC 429

In an ARINC 429 system, a single transmitter/source is connected to 1 to 20 receivers/sinks on one twisted wire pair. The bus uses differential signals. The ARINC 429 standard uses a simplex communication - data may be transmitted in only one direction. The information is transmitted over the bus in defined series of words.

Word Format




Figure 14-37: Structure of an ARINC 429 word

An ARINC 429 word is 32-bits and consists of the following parts (see [Figure 14-37](#)):

- Parity: the most significant bit (MSB). Checks if there are bit errors during the transmission. The total number of logic 1 bits for the word shall be odd.
- Sign/Status Matrix (SSM): the value of these bits depends on the data type. It may be used to report the status of hardware equipment.
- Data:
 - Binary (BNR): stores the data as a binary number.
 - Binary Coded Decimal (BCD): uses 4 data field bits to represent a decimal digit.
 - Discrete data: a combination of BNR and/ or BCD or individual bits that express specific equipment conditions.

ARINC 429 (aerospace electronics, option R&S MXO5C-K530)


- Maintenance data and acknowledgment
- Williamsburg / Buckhorn protocol: a bit-oriented protocol that is used for file transfer.
- Source/Destination Identifier (SDI): indicates the intended receiver or the transmitting subsystem.
- Label: gives information about the word's data type.

For comfortable analysis, you can load an editable label list, to interpret transferred numeric values as meaningful text labels.

14.12.2 ARINC 429 configuration

14.12.2.1 ARINC 429 configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "ARINC 429" > "Setup".



Source

Sets the source of the selected data line. Usually, the source is one of the analog channels.

Remote command:

[SBUS<sb>:ARINC:SOURce](#) on page 1629

Polarity

Selects the wire on which the bus signal is measured : A Leg or B Leg. The setting affects the digitization of the signal.

Remote command:

[SBUS<sb>:ARINC:POLarity](#) on page 1629

Bit rate mode, Bit rate

Selects the number of transmitted bits per second. The value can be set to high speed (100 kbit/s) or low speed (12.0- 14.5 kbit/s).

Remote command:

[SBUS<sb>:ARINC:BRMode](#) on page 1628

[SBUS<sb>:ARINC:BRValue](#) on page 1628

Min gap time,Max gap time

The gap time defines the idle time between two words, which is needed for word synchronization. The beginning of the first bit after the gap marks the start of a new word. If "Check min gap" and/or "Check max gap" are enabled, the instrument detects the specified gaps during decoding.

You can define a minimum idle time "Min gap time", and/or a maximum time "Max gap time". The standard defines a minimum of 4-bit times to separate two subsequent words.

Remote command:

[SBUS<sb>:ARINC:MAXGap:BITS](#) on page 1630


[SBUS<sb>:ARINC:MAXGap:SElect](#) on page 1631

[SBUS<sb>:ARINC:MINGap:BITS](#) on page 1631

[SBUS<sb>:ARINC:MINGap:SElect](#) on page 1631

14.12.2.2 Thresholds

Access: "Menu" > "Apps" > "Protocol" tab > "ARINC 429" > "Thresholds".



Threshold

Sets the upper and lower threshold for the source channel. Enter the value directly in the fields.

Additional to the threshold, you can also set a hysteresis.

Remote command:

`SBUS<sb>:ARINC:THReshold:HIGH` on page 1629

`SBUS<sb>:ARINC:THReshold:LOW` on page 1630

`SBUS<sb>:ARINC:THReshold:HYSTeresis` on page 1629

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.

The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:

`SBUS<sb>:THReshold` on page 1325

14.12.2.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.

Decode layer

Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display.

"Off"	Disables the display of the decode layer.
"Ternary symbols"	Enables the display of the raw, ternary encoded symbols, consisting of the three states "-1", "0" and "+1".
"Bits"	Enables the display of all bits.
"Words"	Enables the display of all words.

Show symbols

Symbol lists are protocol-specific. Label lists for ARINC 429 are available in CSV format.

For details, see [Section 14.12.2.4, "ARINC 429 symbols"](#), on page 707.

Remote command:

`SBUS<sb>:ARINC:SYMBOLs` on page 1630

`SBUS<sb>:ARINC:NEWLlist` on page 1630

14.12.2.4 ARINC 429 symbols

Label lists are protocol-specific. An ARINC 429 label file contains two values for each identifier:

- "Arinc Label": the ARINC 429 label value that identifies the data type and the parameters associated with it. The usual data format is octal.
- "Symbolic label": symbolic name of the label, specifying its function.


Example: ARINC 429 PTT file

```
# -----
@FILE_VERSION = 1.0
@PROTOCOL_NAME = arinc429
# -----
# Labels for ARINC 429 protocol
#   Column order: Arinc Label, Symbolic Label
# -----
# ----Definition----
001o, Distance to Go
002o, Time to Go
010o, Present Position - Latitude
011o, Present Position - Longitude
014o, Magnetic Heading
015o, Wind Speed
075o, Gross Weight
125o, Universal Time Coordinated
# -----
s
```

14.12.3 ARINC 429 filter

Access: "Menu" > "Apps" > "Protocol" tab > "ARINC 429" > "Filter" tab

In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.



Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

- "Check all" Enables the filter for all available frames and error types.
- "Clear" Disables the filter for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
- "Preset" Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:ARINC:FILTER:RST](#) on page 1634

[SBUS<sb>:ARINC:FILTER:INVert](#) on page 1633

[SBUS<sb>:ARINC:FILTER:CHKall](#) on page 1633

[SBUS<sb>:ARINC:FILTER:CLR](#) on page 1633

Enable

Enables the filtering on ARINC 429 frames. Only the frames that match the selected filter conditions are displayed.

Remote command:

[SBUS<sb>:ARINC:FILTER:FREnable](#) on page 1636

[SBUS<sb>:ARINC:FILTER:FRAME<fr>:ENABLE](#) on page 1636


Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

Edit

Opens a dialog to define the details of the selected frame.



"Field" Enables the field type that you want to filter on for the selected frame. The available fields are "Label", "SDI", "Data", "SSM".

Remote command:

[SBUS<sb>:ARINC:FILTER:FIENable](#) on page 1636

[SBUS<sb>:ARINC:FILTER:FRAME<fr>:FLD<fl>:ENABLE](#) on page 1636

"Condition" Displays the value condition for the selected field.

Remote command:

[SBUS<sb>:ARINC:FILTER:BIT](#) on page 1634

[SBUS<sb>:ARINC:FILTER:FRAME<fr>:FLD<fl>:BIT](#) on page 1634

"Value" The data setup consists of a comparison condition and one or two data patterns.

Remote command:

[SBUS<sb>:ARINC:FILTER:DMAX](#) on page 1635

[SBUS<sb>:ARINC:FILTER:FRAME<fr>:FLD<fl>:DMAX](#) on page 1635

[SBUS<sb>:ARINC:FILTER:DMIN](#) on page 1635

[SBUS<sb>:ARINC:FILTER:FRAME<fr>:FLD<fl>:DMIN](#) on page 1635

[SBUS<sb>:ARINC:FILTER:DOPerator](#) on page 1635

[SBUS<sb>:ARINC:FILTER:FRAME<fr>:FLD<fl>:DOPerator](#) on page 1635

Error type

Enables filtering on the selected error type.

The available error types are "Coding error", "Parity error", "Unknown", "Incomplete", "Gap error".

Remote command:

`SBUS<sb>:ARINC:FILTER:ERENable` on page 1634

`SBUS<sb>:ARINC:FILTER:ERROR<n>:ENABLE` on page 1634


14.12.4 ARINC 429 software trigger

14.12.4.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.12.4.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "ARINC 429" > "Trigger" tab > "Setup Software Trigger"



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

"Check all"	Enables the software trigger for all available frames and error types.
"Clear"	Disables the software trigger for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:ARINC:CHKall](#) on page 1637

[TRIGger:SBSW:ARINC:CLR](#) on page 1637

[TRIGger:SBSW:ARINC:INVert](#) on page 1637

[TRIGger:SBSW:ARINC:RST](#) on page 1638

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frames are available: "ARINC429-Word".


Remote command:

[TRIGger:SBSW:ARINC:FREnable](#) on page 1638

[TRIGger:SBSW:ARINC:FRAME<fr>:ENABLE](#) on page 1638

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



"Field" Enables the field type that you want to trigger on for the selected frame.

The available fields are "Label", "SDI", "Data", "SSM".

Remote command:

[TRIGger:SBSW:ARINC:FIENable](#) on page 1640

[TRIGger:SBSW:ARINC:FRAME<fr>:FLD<fl>:ENABLE](#) on page 1640

"Condition" Displays the value condition for the selected field.

Remote command:

[TRIGger:SBSW:ARINC:BIT](#) on page 1638

[TRIGger:SBSW:ARINC:FRAME<fr>:FLD<fl>:BIT](#) on page 1638

ARINC 429 (aerospace electronics, option R&S MXO5C-K530)

"Value" The data setup consists of a comparison condition and one or two data patterns.

Remote command:

[TRIGger:SBSW:ARINC:DMAX](#) on page 1639

[TRIGger:SBSW:ARINC:FRAME<fr>:FLD<fl>:DMAX](#)
on page 1639

[TRIGger:SBSW:ARINC:DMIN](#) on page 1639

[TRIGger:SBSW:ARINC:FRAME<fr>:FLD<fl>:DMIN](#)
on page 1639

[TRIGger:SBSW:ARINC:DOPerator](#) on page 1639

[TRIGger:SBSW:ARINC:FRAME<fr>:FLD<fl>:DOPerator](#)
on page 1639

Error type

Enables triggering on the selected error type.

The available error types are "Coding error", "Parity error", "Unknown", "Gap error".

Remote command:

[TRIGger:SBSW:ARINC:ERENable](#) on page 1640

[TRIGger:SBSW:ARINC:ERRor<m>:ENABle](#) on page 1640

14.12.5 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.12.6 ARINC 429 decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.

Decode results table

The "Decode results" table contains information about all decoded frames.



Figure 14-38: Decoded ARINC429 signal

The decode results table contains information about all decoded frames.

Table 14-22: Content of the decode results table

Column	Description
Index	Frame count
State	Overall state of the frame
Start	Start time of the frame
Symbol	Symbolic label of the frame. Available only, if "Show symbols" is enabled in the "Display" tab and a symbols list is loaded.
Label	The label name
SDI	The state of the SDI bits
Data	All 32 bits of the word. Select the data format in the "Display" tab.
SSM	The state of the SSM bits
32-bit word	The value of the data bytes. Select the data format in the "Display" tab.
Data rate	Value of the data rate

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- `SBUS<sb>:FORMat` on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.13.4, "Decode results"](#), on page 1641.

14.12.7 Performing ARINC 429 decoding


This section explains step by step how to configure and decode the ARINC 429 bus.

14.12.7.1 Configuring ARINC 429 signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.12.2, "ARINC 429 configuration"](#), on page 704.

1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: "ARINC 429".
4. Tap on "State" to enable the decoding.

An ARINC 429 shortcut appears at the bottom left of the screen. Tap the shortcut for a quick access to the "ARINC 429" dialog settings.



14.12.7.2 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the ARINC and decoded.

1. Tap on the "ARINC 429" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".

5. Select the "File type".

An export file is saved in the selected directory.

The ARINC export file contains the following fields:

- A list of all decoded frames:
 - Index
 - Start
 - Stop
 - Symbol
 - State
 - Label
 - SDI
 - Data
 - SSM
 - Raw Data
 - Bit rate

Example ARINC export file

```
Index,Start,Stop,Symbol,State,Label,SDI,Data,SSM,Raw Data,Bit Rate
1,-0.103,-0.10268,---,'OK',257o,3h,72470h,01b,#HC1,#HC4,#H9F,#HF5,100000
2,-0.10268,-0.10236,---,'OK',316o,0h,22608h,00b,#H02,#H0C,#H88,#H73,100000
3,-0.10236,-0.10204,---,'OK',257o,3h,72470h,01b,#HC1,#HC4,#H9F,#HF5,100000
4,-0.10204,-0.10172,---,'OK',317o,0h,62608h,00b,#H02,#H0C,#H8C,#HF3,100000
5,-0.10172,-0.1014,---,'OK',257o,3h,72470h,01b,#HC1,#HC4,#H9F,#HF5,100000
```

14.13 SpaceWire (aerospace communications, option R&S MXO5C-K530)

The SpaceWire is a communication network standard used for spacecraft. It is based on the IEEE 1355 standard of communications and coordinated by the European Space Agency (ESA).

• SpaceWire basics	717
• SpaceWire configuration	718
• SpaceWire filter	720
• SpaceWire software trigger	723
• Measure	726
• Performing SpaceWire decoding	726
• SpaceWire decode results	728

14.13.1 SpaceWire basics

The SpaceWire links are a Point-to-point (P2P) connection between a node and another node or a router. The link is full-duplex bidirectional serial data link.

The SpaceWire has two types of characters:

- Data characters containing a parity bit, a data control flag and eight bits of data.




Figure 14-39: SpaceWire data characters

- Control characters containing a parity-bit, a data-control flag and the 2-bit control code. The data control flag is set to 1 and indicates that this is a control character.




Figure 14-40: SpaceWire control characters

Also there are two control codes:

- NULL code consisting of an Escape (ESC) and a Flow Control Token (FCT)
- Time Code consisting of an ESC followed by a single data character





Figure 14-41: SpaceWire control codes

14.13.2 SpaceWire configuration

14.13.2.1 SpaceWire configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "SpaceWire" > "Setup".



Data Source

Selects the source for the data signal. Typically, the data source is one of the analog channels.

Remote command:

[SBUS<sb>:SWIRe:DATA:SOURce](#) on page 1663

Strobe Source

Selects the source for the strobe signal. Typically, the strobe source is an analog channel different from the data source.

Remote command:

[SBUS<sb>:SWIRe:STRBe:SOURce](#) on page 1664

Min Gap

Specifies the minimum idle time between two frames, which is needed for synchronization. The beginning of the first bit after the gap marks the start of a new frame.


Remote command:

[SBUS<sb>:SWIRe:MGAP](#) on page 1665

[SBUS<sb>:SWIRe:MINGap](#) on page 1665

14.13.2.2 Thresholds

Access: "Menu" > "Apps" > "Protocol" tab > "SpaceWire" > "Thresholds".



Thresholds

Sets the middle threshold for the data source and strobe source channels. Enter the values directly in the fields.

Additional to the thresholds, you can also set the hysteresis for the data source and strobe source, respectively.

Remote command:

[SBUS<sb>:SWIRe:DATA:THReshold](#) on page 1664

[SBUS<sb>:SWIRe:DATA:HYSTeresis](#) on page 1664

[SBUS<sb>:SWIRe:STRBe:THReshold](#) on page 1665

[SBUS<sb>:SWIRe:STRBe:HYSTeresis](#) on page 1665

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.

The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:

[SBUS<sb>:THReshold](#) on page 1325

14.13.2.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.

Decode layer

Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display.

"Off" Disables the display of the decode layer.

"Edges" Enables the display of all edges.

"Binary" Enables the display of the raw, binary encoded symbols, consisting of the states "0" and "1".


Data format

See ["Data format"](#) on page 481.

14.13.3 SpaceWire filter

Access: "Menu" > "Apps" > "Protocol" tab > "SpaceWire" > "Filter" tab

In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.



Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

- "Check all" Enables the filter for all available frames and error types.
- "Clear" Disables the filter for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
- "Preset" Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:SWIRe:FILTer:CHKall](#) on page 1667

[SBUS<sb>:SWIRe:FILTer:CLR](#) on page 1667

[SBUS<sb>:SWIRe:FILTer:INVert](#) on page 1667

[SBUS<sb>:SWIRe:FILTer:RST](#) on page 1667

Enable

Enables the filtering on SpaceWire frames. Only the frames that match the selected filter conditions are displayed.

Remote command:

[SBUS<sb>:SWIRe:FILTer:FREnable](#) on page 1670

[SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:ENABLE](#) on page 1670

Frame type


Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

The available frame types are "Data", "Time", "FCT", "Null", "EOP", "EEP", "Bad Esc".

Edit

Opens a dialog to define the details of the selected frame.



"Field" Enables the field type that you want to filter on for the selected frame. The available fields are "Data", "Time", "Bad Esc".

Remote command:

[SBUS<sb>:SWIRe:FILTer:FIENable](#) on page 1669

[SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:ENABLE](#) on page 1669

"Condition" Displays the value condition for the selected field.

Remote command:

[SBUS<sb>:SWIRe:FILTer:BIT](#) on page 1667

[SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:BIT](#) on page 1667

SpaceWire (aerospace communications, option R&S MXO5C-K530)

"Value"

The data setup consists of a comparison condition and one or two data patterns.

Remote command:

`SBUS<sb>:SWIRe:FILTer:DMAX` on page 1668

`SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:DMAX`
on page 1668

`SBUS<sb>:SWIRe:FILTer:DMIN` on page 1669

`SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:DMIN`
on page 1669

`SBUS<sb>:SWIRe:FILTer:DOPerator` on page 1669

`SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:DOPerator`
on page 1669

Error type

Enables filtering on the selected error type.

The available error types are "Parity error", "Length error", "Ambiguous", "Incomplete".

Remote command:

`SBUS<sb>:SWIRe:FILTer:ERENable` on page 1668

`SBUS<sb>:SWIRe:FILTer:ERRor<n>:ENABle` on page 1668


14.13.4 SpaceWire software trigger

14.13.4.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.13.4.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "SpaceWire" > "Trigger" tab > "Setup Software Trigger"



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

- "Check all" Enables the software trigger for all available frames and error types.
- "Clear" Disables the software trigger for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
- "Preset" Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:SWIRe:CHKall](#) on page 1671

[TRIGger:SBSW:SWIRe:CLR](#) on page 1671

[TRIGger:SBSW:SWIRe:INVert](#) on page 1671

[TRIGger:SBSW:SWIRe:RST](#) on page 1671

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frames are available: "Data", "Time", "FCT", "Null", "EOP", "EEP", "Bad Esc".


Remote command:

[TRIGger:SBSW:SWIRe:FREnable](#) on page 1672

[TRIGger:SBSW:SWIRe:FRAME<fr>:ENABLE](#) on page 1672

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



"Field" Enables the field type that you want to trigger on for the selected frame.

The available fields are "Data", "Time", "Code".

Remote command:

[TRIGger:SBSW:SWIRe:FIENable](#) on page 1673

[TRIGger:SBSW:SWIRe:FRAME<fr>:FLD<fl>:ENABLE](#) on page 1673

"Condition" Displays the value condition for the selected field.

Remote command:

[TRIGger:SBSW:SWIRe:BIT](#) on page 1672

[TRIGger:SBSW:SWIRe:FRAME<fr>:FLD<fl>:BIT](#) on page 1672

SpaceWire (aerospace communications, option R&S MXO5C-K530)

"Value" The data setup consists of a comparison condition and one or two data patterns.

Remote command:

[TRIGger:SBSW:SWIRE:DMAX](#) on page 1672

[TRIGger:SBSW:SWIRE:FRAME<fr>:FLD<fl>:DMAX](#)
on page 1672

[TRIGger:SBSW:SWIRE:DMIN](#) on page 1673

[TRIGger:SBSW:SWIRE:FRAME<fr>:FLD<fl>:DMIN](#)
on page 1673

[TRIGger:SBSW:SWIRE:DOPerator](#) on page 1673

[TRIGger:SBSW:SWIRE:FRAME<fr>:FLD<fl>:DOPerator](#)
on page 1673

Error type

Enables triggering on the selected error type.

The available error types are "Parity error", "Length error".

Remote command:

[TRIGger:SBSW:SWIRE:ERENable](#) on page 1674

[TRIGger:SBSW:SWIRE:ERRor<m>:ENABle](#) on page 1674

14.13.5 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.13.6 Performing SpaceWire decoding


This section explains step by step how to configure and decode the SpaceWire bus.

14.13.6.1 Configuring SpaceWire signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.13.2, "SpaceWire configuration"](#), on page 718.


1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".

3. Tap the "Protocol type" button. Select the protocol: "SpaceWire".
4. Tap on "State" to enable the decoding.

A SpaceWire shortcut appears at the bottom left of the screen. Tap the shortcut for a quick access to the "SpaceWire" dialog settings.



14.13.6.2 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the SpaceWire and decoded.

1. Tap on the "SpaceWire" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".
5. Select the "File type".

An export file is saved in the selected directory.

The SpaceWire export file contains the following fields:

- A list of all decoded frames:
 - Data
 - Time-Code
 - Flow Control Token (FCT)
 - Null Symbol
 - End of Packet (EOP)
 - Error End of Packet (EEP)
 - Illegal Escape Code (Bad Esc)

Example SpaceWire export file

```
Index,Start,Stop,State,Type
1,-2.7928e-05,-2.6808e-05,'OK','NULL'
2,-2.6808e-05,-2.5688e-05,'OK','NULL'
3,-2.5688e-05,-2.5128e-05,'OK','FCT'
4,-2.5128e-05,-2.3728e-05,'OK','DATA'
5,-2.3728e-05,-2.2328e-05,'OK','DATA'
6,-2.2328e-05,-2.0928e-05,'OK','DATA'
7,-2.0928e-05,-1.897e-05,'OK','TCOD'
8,-1.897e-05,-1.7568e-05,'OK','DATA'
9,-1.7568e-05,-1.617e-05,'OK','DATA'
```

SpaceWire (aerospace communications, option R&S MXO5C-K530)

```
10,-1.617e-05,-1.477e-05,'OK','DATA'
11,-1.477e-05,-1.4208e-05,'OK','EEP'
```

14.13.7 SpaceWire decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.

Decode results table

The "Decode results" table contains information about all decoded frames.



Figure 14-42: Decoded SpaceWire signal

The decode results table contains information about all decoded frames.

Table 14-23: Content of the decode results table

Column	Description
Index	Frame count
State	Overall state of the frame
Start	Start time of the frame
Type	The type of the frame
Data	Value of the data byte. Select the data format in the "Display" tab.
Bit rate	Value of the bit rate

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-24: Content of the frame details table

Column	Description
Index	Number of the decoded field
Label	Name of the field
State	State of the field (OK / Not OK)
Value	Value of the field

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- [SBUS<sb>:FORMat](#) on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.15.4, "Decode results"](#), on page 1675.

14.14 MIL-1553 (aerospace electronics, option R&S MXO5C-K530)

The MIL-1553 (or MIL-STD-1553) specification defines the characteristics of a serial data bus originally designed for use in the military avionics. Nowadays it is also used in spacecraft on-board data handling.

- [About the MIL-1553 protocol](#).....730
- [MIL-1553 configuration](#).....732
- [MIL-1553 filter](#).....734
- [MIL-1553 software trigger](#).....737

- [Measure](#)..... 740
- [MIL-1553 decode results](#).....740
- [Performing MIL-1553 decoding](#).....742

14.14.1 About the MIL-1553 protocol

The MIL-1553 bus is a 2-wire bus that uses differential signals.

A MIL-1553 system consists of the following components:

- Bus Controller (BC): initiates and coordinates the data flow in the system.
- Remote Terminal (RT): interfaces various subsystems with the data bus. A system consists of up to 31 RTs and each RT can have 31 subaddresses. The subaddresses 0 and 31 refer to a mode code command.
- Bus Monitor (BM) (optional): listens to all messages and can record selected data for real-time or off-line analysis.

The information is transmitted over the bus in defined series of words using Manchester code, where each bit is transmitted as high-low for a logical 1 or a low-high for a logical 0. There are three types of words: command, data and status.

Command Word





Figure 14-43: Structure of a command word

The format of a command word consists of the following parts (see [Figure 14-43](#)):

- Sync: an invalid Manchester waveform.
- Remote Terminal (RT) Address: the unique address of the corresponding RT.
- Transmit/Receive (T/R): indicates the action required from the RT.
- Subaddress/Mode Code: indicates the RT subaddress. The subaddresses 0 and 31 signalize the transmission of a mode code.
- Data Word Count /Mode Code: indicates the number of words that are sent/received by the RT. A maximum of 32 words is allowed. This field may be used for the transmission of the mode code value.
- Parity: checks if there are bit errors during the transmission. The total number of logic 1 bits for the word (sync bits not included) shall be odd.

Data Word**Figure 14-44: Structure of a data word**

The format of a data word consists of the following parts (see [Figure 14-44](#)):

- Sync: an invalid Manchester waveform.
- Data: the transferred information (16 bit).
- Parity: checks if there are bit errors during the transmission. The total number of logic 1 bits for the word (sync bits not included) shall be odd.

Status Word**Figure 14-45: Structure of a status word**

The format of a status word consists of the following parts (see [Figure 14-45](#)):

- Sync: an invalid Manchester waveform.
- Remote Terminal (RT) Address: the unique address of the corresponding RT.
- Message error: indicates an error in the command/data word transmission from the BC. A logic 1 indicates presence of a message error and a logic 0 indicates its absence.
- Instrumentation: helps to distinguish between a status word and a command word. The logic state of this bit shall be 0.
- Service Request: indicates that the RT requires service. A logic 1 indicates a presence of a service request and logic 0 indicates its absence.
- Reserved: bits reserved for future uses.
- Broadcast Command: a logic 1 indicates that the preceding valid command word was a broadcast command and a logic 0 that it was not.

MIL-1553 (aerospace electronics, option R&S MXO5C-K530)


- **Busy:** a busy state indicates that the RT or the subsystem is not able to transfer data. A logic 1 indicates a presence of a busy condition and logic 0 indicates its absence.
- **Subsystem Flag:** flags a subsystem fault. A logic 1 indicates a presence of a flag and logic 0 indicates its absence.
- **Dynamic Bus Control Acceptance:** a logic 1 indicates acceptance of a dynamic bus control and a logic 0 a rejection.
- **Terminal Flag:** flags an RT fault condition. A logic 1 indicates a presence of a flag and logic 0 indicates its absence.
- **Parity:** checks if there are bit errors during the transmission. The total number of logic 1 bits for the word (sync bits not included) shall be odd.

For comfortable analysis, you can load an editable label list, to interpret transferred numeric values as meaningful text labels.

14.14.2 MIL-1553 configuration

14.14.2.1 MIL-1553 configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "MIL-1553" > "Setup".



Source

Sets the source of the selected data line. Usually, the source is one of the analog channels.

Remote command:

[SBUS<sb>:MILStd:SOURce](#) on page 1646

Polarity


Sets the wire on which the bus signal is measured : normal or inverted. The setting affects the digitization of the signal.

Remote command:

[SBUS<sb>:MILStd:POLarity](#) on page 1646

14.14.2.2 Threshold

Access: "Menu" > "Apps" > "Protocol" tab > "MIL-1553" > "Thresholds".

**Threshold**

Sets the upper and lower threshold for the source channel. Enter the value directly in the fields.

Additional to the threshold, you can also set a hysteresis.

Remote command:

[SBUS<sb>:MILStd:THReshold:HIGH](#) on page 1646

[SBUS<sb>:MILStd:THReshold:LOW](#) on page 1647

[SBUS<sb>:MILStd:THReshold:HYSTeresis](#) on page 1646

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.

The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:

[SBUS<sb>:THReshold](#) on page 1325

14.14.2.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.

Show symbols

Symbol lists are protocol-specific. Label lists for MIL-1553 are available in CSV format.

For details, see [Section 14.14.2.4, "MIL-1553 symbols"](#), on page 734.

14.14.2.4 MIL-1553 symbols

Label lists are protocol-specific. A MIL-1553 label file contains four values for each identifier:

- "RTA": hexadecimal remote terminal address value
- "Sub Addr": hexadecimal sub address value
- "Sub Address Label Name": the label name corresponding to the value of the sub-address.
- "Symbolic label": symbolic name of addressed device, specifying the device function, and the label of the sub address.


Example: MIL PTT file

```
# -----
# Labels for MIL.1553 protocol
# Column order: RT address, RT label, Subaddress, Subaddress Label
# -----
@PROTOCOL_NAME = mil1553
0Ah,Engine,01h,Thrust
03h,Main panel,07h,Altimeter
03h,Main panel,01h,Speed
0Eh,Only RTA
```

14.14.3 MIL-1553 filter

Access: "Menu" > "Apps" > "Protocol" tab > "MIL-1553" > "Filter" tab

In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.



Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

- "Check all" Enables the filter for all available frames and error types.
- "Clear" Disables the filter for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
- "Preset" Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:MILStd:FILTer:RST](#) on page 1649

[SBUS<sb>:MILStd:FILTer:INVert](#) on page 1649

[SBUS<sb>:MILStd:FILTer:CHKall](#) on page 1649

[SBUS<sb>:MILStd:FILTer:CLR](#) on page 1649

MIL-1553 (aerospace electronics, option R&S MXO5C-K530)

Enable

Enables the filtering on MIL-1553 frames. Only the frames that match the selected filter conditions are displayed.

Remote command:

[SBUS<sb>:MILStd:FILTer:FREnable](#) on page 1653

[SBUS<sb>:MILStd:FILTer:FRAMe<fr>:ENABLE](#) on page 1653


Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

Edit

Opens a dialog to define the details of the selected frame.



"Field"

Enables the field type that you want to filter on for the selected frame. The available fields are "RTA", "Info", "Parity", "Data".

Remote command:

[SBUS<sb>:MILStd:FILTer:FIENable](#) on page 1653

[SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:ENABLE](#) on page 1653

MIL-1553 (aerospace electronics, option R&S MXO5C-K530)

"Condition"	Displays the value condition for the selected field. Remote command: SBUS<sb>:MILStd:FILTer:BIT on page 1650 SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:BIT on page 1650
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: SBUS<sb>:MILStd:FILTer:DMAX on page 1650 SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:DMAX on page 1650 SBUS<sb>:MILStd:FILTer:DMIN on page 1651 SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:DMIN on page 1651 SBUS<sb>:MILStd:FILTer:DOPerator on page 1651 SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:DOPerator on page 1651
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: SBUS<sb>:MILStd:FILTer:IMAX on page 1651 SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:IMAX on page 1651 SBUS<sb>:MILStd:FILTer:IMIN on page 1652 SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:IMIN on page 1652 SBUS<sb>:MILStd:FILTer:IOperator on page 1652 SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:IOperator on page 1652

Error type

Enables filtering on the selected error type.

The available error types are "Sync error", "Manchester coding error", "Parity error", "Gap error", "Response timeout", "Unknown", "Incomplete".

Remote command:


[SBUS<sb>:MILStd:FILTer:ERENable](#) on page 1650
[SBUS<sb>:MILStd:FILTer:ERRor<n>:ENABle](#) on page 1650

14.14.4 MIL-1553 software trigger**14.14.4.1 Setup A trigger**

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.14.4.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "MIL-1553" > "Trigger" tab > "Setup Software Trigger"



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

"Check all"	Enables the software trigger for all available frames and error types.
"Clear"	Disables the software trigger for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:MILStd:CHKall](#) on page 1654

[TRIGger:SBSW:MILStd:CLR](#) on page 1654

[TRIGger:SBSW:MILStd:INVert](#) on page 1655

[TRIGger:SBSW:MILStd:RST](#) on page 1655

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frames are available: "Command", "Status", "Cmd/Status", "Data".


Remote command:

[TRIGger:SBSW:MILStd:FRENable](#) on page 1655

[TRIGger:SBSW:MILStd:FRAME<fr>:ENABLe](#) on page 1655

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



"Field" Enables the field type that you want to trigger on for the selected frame.

The following fields are available: "RTA", "Info", "Parity", "Data".

Remote command:

[TRIGger:SBSW:MILStd:FIENable](#) on page 1657

[TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:ENABLe](#) on page 1657

"Condition" Displays the value condition for the selected field.

Remote command:

[TRIGger:SBSW:MILStd:BIT](#) on page 1655

[TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:BIT](#) on page 1655

MIL-1553 (aerospace electronics, option R&S MXO5C-K530)

"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: TRIGger:SBSW:MILStd:DMAX on page 1656 TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:DMAX on page 1656 TRIGger:SBSW:MILStd:DMIN on page 1656 TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:DMIN on page 1656 TRIGger:SBSW:MILStd:DOPerator on page 1656 TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:DOPerator on page 1656
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: TRIGger:SBSW:MILStd:IMAX on page 1657 TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:IMAX on page 1657 TRIGger:SBSW:MILStd:IMIN on page 1658 TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:IMIN on page 1658 TRIGger:SBSW:MILStd:IOperator on page 1658 TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:IOperator on page 1658

Error type

Enables triggering on the selected error type.

The following error types are available: "Sync error", "Manchester coding error", "Parity error", "Gap error", "Response timeout".

Remote command:

[TRIGger:SBSW:MILStd:ERENable](#) on page 1658

[TRIGger:SBSW:MILStd:ERRor<m>:ENABle](#) on page 1658

14.14.5 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.14.6 MIL-1553 decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.

2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.

Decode results table

The "Decode results" table contains information about all decoded frames.



Figure 14-46: Decoded MIL-1553 signal

The decode results table contains information about all decoded frames.

Table 14-25: Content of the Decode results table

Column	Description
Index	Index of the decoded word
State	Overall state of the word
Start	Time of word start in relation to the trigger point
Symbol	Symbolic label of the frame. Available only, if "Show symbols" is enabled in the "Display" tab and a symbols list is loaded.
Type	Word type

Column	Description
Info	The hexadecimal value of the 9th to 1th bit of a command/status word
RTA	Remote terminal address
Data	The values of the data bytes. Select the data format in the "Display" tab.
Data rate	Data rate

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- [SBUS<sb>:FORMat](#) on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.14.4, "Decode results"](#), on page 1659.

14.14.7 Performing MIL-1553 decoding


This section explains step by step how to configure and decode the MIL-1553 bus.

14.14.7.1 Configuring MIL-1553 signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.14.2, "MIL-1553 configuration"](#), on page 732.

1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: "MIL-1553".
4. Tap on "State" to enable the decoding.

A MIL-1553 shortcut appears at the bottom left of the screen. Tap the shortcut for a quick access to the "MIL-1553" dialog settings.



14.14.7.2 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the MIL-1553 and decoded.

1. Tap on the "MIL-1553" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".
5. Select the "File type".

An export file is saved in the selected directory.

The MIL-1553 export file contains the following fields:

- A list of all decoded frames:
 - Index
 - Start
 - Stop
 - Type
 - State
 - RTA
 - Info
 - Data
 - Bit rate

Example MIL-1553 export file

```
Index,Start,Stop,Type,State,RTA,Info,Data,Bit Rate
1,-0.0199,-0.01988,'STAT','OK',1Dh,027h,---,1000000
2,-0.01988,-0.01986,'DATA','OK',---,---,F7C0h,1000000
3,-0.01986,-0.01984,'DATA','OK',---,---,F7CAh,1000000
4,-0.01984,-0.01982,'DATA','OK',---,---,F7D4h,1000000
5,-0.01982,-0.0198,'DATA','OK',---,---,F7DEh,1000000
```

14.15 SPMI (mobile electronics, option R&S MXO5C-K550)

The System Power Management Interface (SPMI) is a high-speed, low-latency, bi-directional, 2-wire serial bus.




For basic information on SPMI, you can also refer to a video, available on the Rohde & Schwarz YouTube channel: [Understanding SPMI](#).

• SPMI configuration	744
• SPMI filter	747
• SPMI software trigger	749
• Measure	753
• SPMI decode results	753
• Performing SPMI decoding	755

14.15.1 SPMI configuration

14.15.1.1 SPMI configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "SPMI" > "Setup".





Make sure that the tab of the correct serial bus is selected.

Protocol type

Selects the protocol type to be decoded.

Remote command:

`SBUS<sb>:TYPE` on page 1322

SDATA

Sets the source of the data line.

Remote command:

`SBUS<sb>:SPMI:SDATa:SOURce` on page 1684

SCLK

Sets the source of the clock line.

Remote command:

`SBUS<sb>:SPMI:SCLK:SOURce` on page 1683

Use GSID, GSID (hex)

Enables the use of the group sub ID (GSID). You can then enter a value for the "GSID (hex)". If the "SA" value of a frame matches this "GSID (hex)" value, the interpreter reverses the meaning of the "ACK" field: It interprets a bit value of zero in the ACK field as an error, and a bit value of one as OK.

Remote command:

`SBUS<sb>:SPMI:GSIDenable` on page 1682

`SBUS<sb>:SPMI:GIDValue` on page 1682

Glitch filter, Glitch width

A glitch filter can help to filter out short-duration voltage spikes/ glitches that can occur on the communication line.

If "Glitch filter" > "On" you can set the "Glitch width". Any signal transitions with a duration smaller than this value are considered a glitch and filtered out.


Remote command:

`SBUS<sb>:SPMI:GTCHenable` on page 1683

`SBUS<sb>:SPMI:GTWDith` on page 1683

14.15.1.2 Threshold settings

Access: "Menu" > "Apps" > "Protocol" tab > "SPMI" > "Thresholds".



Threshold

Sets the threshold for the data/clock channel. Enter the value directly in the fields.

Additional to the threshold, you can also set a hysteresis.

Remote command:

[SBUS<sb>:SPMI:SCLK:THReshold](#) on page 1684

[SBUS<sb>:SPMI:SDATa:THReshold](#) on page 1685

[SBUS<sb>:SPMI:SCLK:HYSTeresis](#) on page 1683

[SBUS<sb>:SPMI:SDATa:HYSTeresis](#) on page 1684

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.

The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:

[SBUS<sb>:THReshold](#) on page 1325

14.15.1.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.


Decode layer

Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display.

14.15.2 SPMI filter

Access: "Menu" > "Apps" > "Protocol" tab > "SPMI" > "Filter" tab



In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

- "Check all" Enables the filter for all available frames and error types.
- "Clear" Disables the filter for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

"Preset" Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:SPMI:FILTer:CHKall](#) on page 1687

[SBUS<sb>:SPMI:FILTer:CLR](#) on page 1687

[SBUS<sb>:SPMI:FILTer:INVert](#) on page 1687

[SBUS<sb>:SPMI:FILTer:RST](#) on page 1687

Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.


Remote command:

[SBUS<sb>:SPMI:FILTer:FRAMe<fr>:ENABle](#) on page 1691

[SBUS<sb>:SPMI:FILTer:FRENAble](#) on page 1691

Edit

Opens a dialog to define the details of the selected frame.



"Field" Enables the field type that you want to filter on for the selected frame. The available fields depend on the selected frame type.

Remote command:

[SBUS<sb>:SPMI:FILTer:FIENABle](#) on page 1691

[SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:ENABle](#) on page 1691

"Condition"	Displays the value condition for the selected field. Remote command: SBUS<sb>:SPMI:FILTer:BIT on page 1687 SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:BIT on page 1687
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: SBUS<sb>:SPMI:FILTer:DMAX on page 1688 SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:DMAX on page 1688 SBUS<sb>:SPMI:FILTer:DMIN on page 1688 SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:DMIN on page 1688 SBUS<sb>:SPMI:FILTer:DOPerator on page 1689 SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:DOPerator on page 1689
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: SBUS<sb>:SPMI:FILTer:IMAX on page 1690 SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:IMAX on page 1690 SBUS<sb>:SPMI:FILTer:IMIN on page 1690 SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:IMIN on page 1690 SBUS<sb>:SPMI:FILTer:IOPerator on page 1689 SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:IOPerator on page 1689
Error type	Enables filtering on the selected error type. Remote command: SBUS<sb>:SPMI:FILTer:ERRor<n>:ENABle on page 1689 SBUS<sb>:SPMI:FILTer:ERENable on page 1689


14.15.3 SPMI software trigger

14.15.3.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.15.3.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "SPMI" > "Trigger" tab > "Setup Software Trigger" > "Setup SB Trigger".



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

- "Check all" Enables the software trigger for all available frames and error types.
- "Clear" Disables the software trigger for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

"Preset" Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:SPMI:CHKall](#) on page 1692

[TRIGger:SBSW:SPMI:CLR](#) on page 1692

[TRIGger:SBSW:SPMI:INVert](#) on page 1692

[TRIGger:SBSW:SPMI:RST](#) on page 1693

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.


Remote command:

[TRIGger:SBSW:SPMI:FREnable](#) on page 1693


[TRIGger:SBSW:SPMI:FRAME<fr>:ENABLE](#) on page 1693

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



"Field"	Enables the field type that you want to trigger on for the selected frame. Remote command: TRIGger:SBSW:SPMI:FIENable on page 1695 TRIGger:SBSW:SPMI:FRAMe<fr>:FLD<fl>:ENABLE on page 1695
"Condition"	Displays the value condition for the selected field. Remote command: TRIGger:SBSW:SPMI:BIT on page 1693 TRIGger:SBSW:SPMI:FRAMe<fr>:FLD<fl>:BIT on page 1693
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: TRIGger:SBSW:SPMI:DMAX on page 1694 TRIGger:SBSW:SPMI:FRAMe<fr>:FLD<fl>:DMAX on page 1694 TRIGger:SBSW:SPMI:DMIN on page 1694 TRIGger:SBSW:SPMI:FRAMe<fr>:FLD<fl>:DMIN on page 1694 TRIGger:SBSW:SPMI:DOPerator on page 1694 TRIGger:SBSW:SPMI:FRAMe<fr>:FLD<fl>:DOPerator on page 1694
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: TRIGger:SBSW:SPMI:IMAX on page 1695 TRIGger:SBSW:SPMI:FRAMe<fr>:FLD<fl>:IMAX on page 1695 TRIGger:SBSW:SPMI:IMIN on page 1696 TRIGger:SBSW:SPMI:FRAMe<fr>:FLD<fl>:IMIN on page 1696 TRIGger:SBSW:SPMI:IOPerator on page 1696 TRIGger:SBSW:SPMI:FRAMe<fr>:FLD<fl>:IOPerator on page 1696
Error type	Enables triggering on the selected error type.



Remote command:

[TRIGger:SBSW:SPMI:ERENable](#) on page 1696

[TRIGger:SBSW:SPMI:ERRor<m>:ENABle](#) on page 1696

14.15.4 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.15.5 SPMI decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.

Decode results table

The "Decode results" table contains information about all decoded frames.




Figure 14-47: Decoded SPMI signal

The decode results table contains information about all decoded frames.

Table 14-26: Content of the decode results table

Column	Description
Index	Index of the decoded frame
State	Overall state of the frame
Start	Time of frame start
Type	The type of frame

Column	Description
SA	Secondary node address. Select the data format in the "Display" tab.
BC	Byte count value. Select the data format in the "Display" tab.
Address	Register address. Select the data format in the "Display" tab.
Symbol	Symbolic label of the frame. Available only, if "Show symbols" is enabled in the "Display" tab and a symbols list is loaded.
Data	Data value. Select the data format in the "Display" tab.
Write bit rate	Value of the write bit rate
Read bit rate	Value of the read bit rate

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-27: Content of the frame details table

Column	Description
Index	Number of the decoded field
Label	Name of the field
State	State of the field
Value	Value of the field

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- `SBUS<sb>:FORMat` on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.16, "SPMI \(option R&S MXO5C-K550\)"](#), on page 1681.

14.15.6 Performing SPMI decoding

This section explains step by step how to configure and decode the SPMI bus.


For more information on decoding SPMI, you can also refer to the video, available on the Rohde & Schwarz YouTube channel: [Decoding SPMI with MXO Series Oscilloscopes](#).

14.15.6.1 Configuring SPMI signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.


For details on configuration settings, see [Section 14.15.1, "SPMI configuration"](#), on page 744.

1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: "SPMI".
4. Tap on "State" to enable the decoding.

An SPMI shortcut appears at the bottom left of the screen. Tap on the shortcut for a quick access to the "SPMI" dialog settings.



14.15.6.2 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the SPMI and decoded.

1. Tap on the "SPMI" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".
5. Select the "File type".

An export file is saved in the selected directory.

The SPMI export file contains the following fields:

- A list of all decoded frames:
 - Index
 - Start
 - Stop
 - State
 - Type
 - SA
 - BC
 - Address

- Write bit rate
- Read bit rate
- The details frame includes the following fields:
 - Index
 - Label
 - State
 - Value

Example SPMI export file

```
Index,Start,Stop,State,Type,SA,BC,Address,Write bit rate,Read bit rate
1,-0.000405,-0.0004032,'OK','RZWR',Dh,---,---,10000000,---
2,-0.0004031,-0.0004004,'OK','RWR',Ah,---,16h,10000000,---
3,-0.0004003,-0.0003977,'OK','RRD',Bh,---,18h,10000000,10000000
4,-0.0003976,-0.0003904,'OK','ERWR',Ch,4h,77h,10000000,---
5,-0.0003903,-0.000376,'OK','ERRD',Dh,Ch,57h,10000000,10000000
```

Details frame 1

```
Index,Label,State,Value
1,'"SSC"', 'OK', '"10b"'
2,'"SA"', 'OK', '"Dh"'
3,'"ID"', 'OK', '"1b"'
4,'"Data"', 'OK', '"77h"'
5,'"P"', 'OK', '"1b"'
6,'"BP"', 'OK', '"0b"'
7,'"Ack"', 'OK', '"1b"'
8,'"BP"', 'OK', '"0b"'
```

Details frame 2

```
Index,Label,State,Value
1,'"SSC"', 'OK', '"10b"'
2,'"SA"', 'OK', '"Ah"'
3,'"ID"', 'OK', '"010b"'
4,'"Addr"', 'OK', '"16h"'
5,'"P"', 'OK', '"1b"'
6,'"Data"', 'OK', '"47h"'
7,'"P"', 'OK', '"1b"'
8,'"BP"', 'OK', '"0b"'
9,'"Ack"', 'OK', '"1b"'
10,'"BP"', 'OK', '"0b"'
```

14.16 RFFE (mobile electronics, option R&S MXO5C-K550)

Requirements

For performing RFFE decode measurements, you need the following:

- MXO 5C with 2 available channels. The channel can be:
 - Analog channels (C1-C4)
 - Logic channels (D0-D15) (requires option R&S MXO5C-B1)
- Two probes
- Option R&S MXO5C-K550

• About the RFFE protocol	758
• RFFE configuration	759
• RFFE filter	762
• RFFE software trigger	766
• Measure	770
• RFFE decode results	770
• Performing RFFE decoding	772

14.16.1 About the RFFE protocol

The RFFE interface is specified in the "MIPI® Alliance Specification for RF Front-End Control Interface". The RFFE interface is used by the radio frequency front-end interface chips in most LTE-Advanced platforms and in smart phones in general. RFFE is a replacement for existing standards like SPI and I²C that do not meet performance requirements.

Bus structure

RFFE is a two-wire, serial interface that connects up to 4 main devices (Radio Frequency IC, RFIC) to up to 15 sub devices (front-end modules, FEM) on a single RFFE bus. A sub device has read-write capability, or it is write only. Only one of the main devices is the active main device (bus owner main device, BOM), which can initiate command sequences on the bus.

The interface has two lines: one clock signal (SCLK) controlled by the main device, and a serial bidirectional data signal (SDATA). Furthermore, a VIO supply/reference voltage from a common source is applied to all components on the bus.

Command sequences

Protocol messages are called command sequences in RFFE. The standard defines various command sequences to accomplish read and write access to sub devices and to non-active main devices. Command sequences are initiated by the BOM main device on the SDATA line.

In general, a command sequence consists of:

- Sequence start condition (SSC)

Two bits: 1 followed by 0 on SDATA while SCLK is at logic level zero.

- **Command frame**
Consist of a 4-bit sub device address field (SA), followed by 8 command payload bits and a single parity bit.
- **Address and/or data frames, depending on the command sequence**
A frame consists of 8 data bits or 8 register address bits, followed by a single parity bit. The number of address and data frames varies depending on the command sequence type.
- **Bus park cycle (BP)**
A BP cycle is sent at the end of a command sequence, and when the device transfers control of SDATA to another device.

Between the end of a command sequence and the beginning of a new command sequence, the bus is in idle condition at least for 10 ns.

The bits are sent MSB first.

SSC	Command frame		Address and data frames		BP
	SA 4 bits	Command payload 8 bits + P	[Address frames] 8 bits + P	[Data frames] 8 bits + P	

Figure 14-48: General structure of a RFFE Write command sequence


SSC	Command frame		Address and data frames			BP
	SA 4 bits	Command payload 8 bits + P	[Address frames] 8 bits + P	BP	[Data frames] 8 bits + P	

Figure 14-49: General structure of a RFFE Read command sequence

14.16.2 RFFE configuration

14.16.2.1 RFFE configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "RFFE" > "Setup".



Make sure that the tab of the correct serial bus is selected.

Protocol type

Selects the protocol type to be decoded.

Remote command:

[SBUS<sb>:TYPE](#) on page 1322

State

Enables the decoding of the selected bus. The signal icon of the bus appears on the signal bar.

Remote command:

[SBUS<sb>\[:STATe\]](#) on page 1322

SDATA

Sets the source of the data line.

Remote command:

[SBUS<sb>:RFFE:DATA:SOURce](#) on page 1705

SCLK

Sets the source of the clock line.

Remote command:

[SBUS<sb>:RFFE:CLOCK:SOURce](#) on page 1704

Use glitch filter, Glitch filter width

Enables the glitch filter on the SCLK and SDATA lines to improve decode accuracy.

The "Glitch filter width" field sets the maximum glitch width to be ignored.

Remote command:

[SBUS<sb>:RFFE:GFILter](#) on page 1705

[SBUS<sb>:RFFE:GFWidth](#) on page 1706

Read mode

Selects, if the standard or synchronous read ("sRead") mode is used.

Remote command:

[SBUS<sb>:RFFE:RDMD](#) on page 1706

14.16.2.2 Threshold settings

Access: "Menu" > "Apps" > "Protocol" tab > "RFFE" > "Thresholds".

Threshold

Sets the threshold for the data and clock channel. Enter the value directly in the fields.

Additional to the threshold, you can also set a hysteresis.

Remote command:

[SBUS<sb>:RFFE:DATA:THReshold](#) on page 1705

[SBUS<sb>:RFFE:DATA:HYSTeresis](#) on page 1704

[SBUS<sb>:RFFE:CLOCK:THReshold](#) on page 1704

[SBUS<sb>:RFFE:CLOCK:HYSTeresis](#) on page 1704

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.

The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:

[SBUS<sb>:THReshold](#) on page 1325

14.16.2.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.


Decode layer

Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display.

14.16.3 RFFE filter

Access: "Menu" > "Apps" > "Protocol" tab > "RFFE" > "Filter" tab



In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

- "Check all" Enables the filter for all available frames and error types.
- "Clear" Disables the filter for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
- "Preset" Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:RFFE:FILTer:CHKall](#) on page 1707

[SBUS<sb>:RFFE:FILTer:CLR](#) on page 1708

[SBUS<sb>:RFFE:FILTer:INVert](#) on page 1708

[SBUS<sb>:RFFE:FILTer:RST](#) on page 1708

Enable

Enables the filtering on RFFE frames. Only the frames that match the selected filter conditions are displayed.

Remote command:

[SBUS<sb>:RFFE:FILTer:FREnable](#) on page 1708

[SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:ENABLE](#) on page 1710

Frame type


Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frames are available: "Register 0 Write", "Register Write", "Register Read", "Extended Register Write", "Extended Register Read", "Extended Register Write Long", "Extended Register Read Long", "Main Write", "Main Read".

Edit

Opens a dialog to define the details of the selected frame.



"Field" Enables the field type that you want to filter on for the selected frame. The following fields are available: "SA", "ID", "Data", "Addr", "BC", "MID", "Data MSB", "Data LSB".

Remote command:

[SBUS<sb>:RFFE:FILTer:FIENable](#) on page 1710

[SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:ENABle](#) on page 1710

"Condition" Displays the value condition for the selected field.

Remote command:


[SBUS<sb>:RFFE:FILTer:BIT](#) on page 1709

[SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:BIT](#) on page 1709

"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: SBUS<sb>:RFFE:FILTer:DMAX on page 1709 SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:DMAX on page 1709 SBUS<sb>:RFFE:FILTer:DMIN on page 1710 SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:DMIN on page 1710 SBUS<sb>:RFFE:FILTer:DOPerator on page 1710 SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:DOPerator on page 1710
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: SBUS<sb>:RFFE:FILTer:IMAX on page 1711 SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:IMAX on page 1711 SBUS<sb>:RFFE:FILTer:IMIN on page 1711 SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:IMIN on page 1711 SBUS<sb>:RFFE:FILTer:IOPerator on page 1712 SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:IOPerator on page 1712

Error type

Enables filtering on the selected error type.



The following error types are available: "OK", "SSC Error", "Parity error", "Length error", "Bus park error", "No response".

Remote command:

[SBUS<sb>:RFFE:FILTer:ERENable](#) on page 1712

[SBUS<sb>:RFFE:FILTer:ERRor<n>:ENABle](#) on page 1712


14.16.4 RFFE software trigger

14.16.4.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.16.4.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "RFFE" > "Trigger" tab > "Setup Software Trigger" > "Setup SB Trigger"



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

- "Check all" Enables the software trigger for all available frames and error types.
- "Clear" Disables the software trigger for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
- "Preset" Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:RFFE:CHKall](#) on page 1713

[TRIGger:SBSW:RFFE:CLR](#) on page 1713

[TRIGger:SBSW:RFFE:INVert](#) on page 1713

[TRIGger:SBSW:RFFE:RST](#) on page 1714

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frames are available: : "Register 0 Write", "Register Write", "Register Read", "Extended Register Write", "Extended Register Read", "Extended Register Write Long", "Extended Register Read Long", "Main Write", "Main Read".

Remote command:

[TRIGger:SBSW:RFFE:FRENAble](#) on page 1714

[TRIGger:SBSW:RFFE:FRAME<fr>:ENABLe](#) on page 1714

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.

The screenshot shows the "Trigger" dialog box with the "Register Write" configuration. The dialog has a "Back" button on the left. The main area is divided into two sections: "Register Write" and "Data".

Register Write

	AND	Field	Condition
1	☐	SA	
2	☐	ID	
3	☐	Addr	
4	☐	Data	

Data


Value:

RFFE (mobile electronics, option R&S MXO5C-K550)

"Field"	Enables the field type that you want to trigger on for the selected frame. The available fields are: "SA", "ID", "Data", "Addr", "BC", "MID", "Data MSB", "Data LSB". Remote command: TRIGger:SBSW:RFFE:FIENable on page 1716 TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:ENABLE on page 1716
"Condition"	Displays the value condition for the selected field. Remote command: TRIGger:SBSW:RFFE:BIT on page 1714 TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:BIT on page 1714
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: TRIGger:SBSW:RFFE:DMAX on page 1715 TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:DMAX on page 1715 TRIGger:SBSW:RFFE:DMIN on page 1715 TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:DMIN on page 1715 TRIGger:SBSW:RFFE:DOPerator on page 1715 TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:DOPerator on page 1715
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: TRIGger:SBSW:RFFE:IMAX on page 1716 TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:IMAX on page 1716 TRIGger:SBSW:RFFE:IMIN on page 1717 TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:IMIN on page 1717 TRIGger:SBSW:RFFE:IOperator on page 1717 TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:IOperator on page 1717

Error type

Enables triggering on the selected error type.



The following error types are available: "OK", "SSC Error", "Parity error", "Length error", "Bus park error", "No response".

Remote command:

[TRIGger:SBSW:RFFE:ERENable](#) on page 1717

[TRIGger:SBSW:RFFE:ERRor<m>:ENABle](#) on page 1717

14.16.5 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.16.6 RFFE decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".

3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.

Decode results table

The "Decode results" table contains information about all decoded frames.




Figure 14-50: Decoded RFFE signal

The decode results table contains information about all decoded frames.

Table 14-28: Content of the decode results table

Column	Description
Index	Index of the decoded frame
State	Overall state of the frame
Start	Times of frame start
Type	The type of command

Column	Description
SA/MID	Address of the sub device
BC	Byte count
Address	Register address
Symbol	Symbolic label of the frame. Available only, if "Show symbols" is enabled in the "Display" tab and a symbols list is loaded.
Data	Values of the data bytes. Select the data format in the "Display" tab.
Write bit rate	Value of the write bit rate
Read bit rate	Value of the read bit rate

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-29: Content of the frame details table

Column	Description
Index	Number of the decoded field
Label	Name of the field
State	State of the field
Data	Value of the field

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- [SBUS<sb>:FORMat](#) on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.17.4, "Decode results"](#), on page 1718.

14.16.7 Performing RFFE decoding


This section explains step by step how to configure and decode the RFFE bus.

14.16.7.1 Configuring RFFE signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.16.2, "RFFE configuration"](#), on page 759.

1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: "RFFE".
4. Tap on "State" to enable the decoding.

An SPI shortcut appears at the bottom left of the screen. Tap on the shortcut for a quick access to the "RFFE" dialog settings.



5. Tap on each active signal and select the correct channels: "SDATA" and "SCLK".
6. Set the polarity for each signal: "SDATA Polarity" and "SCLK Polarity".
7. Select the "Read mode"
8. Check that the signals are on the screen.
If not try adjusting the vertical and horizontal settings.
9. Set the logical thresholds:
 - a) Tap "Threshold setup". The threshold dialog opens.
 - b) For each signal, set the threshold value. A typical value is 0.8 V.
 - c) If necessary, set the hysteresis value for the signals.
 - d) Optionally, tap on "Show threshold lines".

14.16.7.2 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the RFFE and decoded.

1. Tap on the "RFFE" shortcut.
2. Tap on the "Shortcuts" tab.
3. Tap "Export results".
4. If necessary, enable "Include details".
5. If necessary, enable "Include timing".
6. Select the "File type".

An export file is saved in the selected directory.

The RFFE export files contain the following fields:

- A list of all decoded frames:
 - Index
 - Start
 - Stop
 - State
 - Type
 - SA/MID
 - BC
 - Address
 - Write bit-rate
 - Read bit-rate
- The details frame includes the following fields:
 - Index
 - Label
 - State
 - Value

Example of RFFE export file

Index	Start	Stop	State	Type	SA, BC,	Addr,	Write BR,	Read BR	
1	-0.1000402	-0.0003965	OK	MSKW	5h	---	2Eh	4376000	---
2	-0.0003957	0.00013858	OK	MCTW	0h	255	3Ah	4375000	---
3	0.00013938	0.00016396	OK	MCTR	0h	3	43h	4378000	2187000
4	0.00016464	0.00017436	OK	MWR	1h	---	1Ch	4376000	---
5	0.00017516	0.00018944	OK	MRD	1h	---	87h	4382000	2190000
6	0.00019012	0.00019824	OK	MOHO	2h	---	---	4362000	2195000
7	0.00022648	0.00023618	OK	ERWR	0h	1	34h	4367000	---
8	0.00023698	0.00030888	OK	ERRD	Fh	15	34h	4365000	2187000

Details frame 1

Index	Label	State	Value
1	'Mask'	'OK'	3Fh
2	'Data'	'OK'	15h

Details frame 3

Index	Label	State	Value
1	'Data: 1'	'OK'	55h
2	'Data: 2'	'OK'	83h
3	'Data: 3'	'OK'	00h
4	'Data: 4'	'OK'	FFh

Details frame 4

Index	Label	State	Value
1	'Data MSB'	'OK'	55h
2	'Data LSB'	'OK'	AAh

14.17 10BASE-T1S (automotive Ethernet, option R&S MXO5C-K560)

10BASE-T1S technology provides a 10 Mbit/s, multidrop transmission over a single pair physical layer. It is defined in the IEEE standard 802.3cg-2019 specification.

Requirements

For performing 10BASE-T1S decode measurements, you need the following:

- MXO 5C. One of the analog input channels is used for analysis.
- Option R&S MXO5C-K560

10BASE-T1S does not support logical channels for decoding, because it requires two thresholds, which are not available with this option.

• 10BASE-T1S basics.....	775
• 10BASE-T1S configuration.....	776
• 10BASE-T1S filter.....	781
• 10BASE-T1S software trigger.....	783
• Measure.....	786
• 10BASE-T1S decode results.....	786
• Performing 10BASE-T1S decoding.....	788

14.17.1 10BASE-T1S basics

This option provides in-demand monitor and decode functions for 10BASE-T1S, where S stands for short reach. This standard, officially IEEE 802.3cg, attracted attention even before the specification was published in 2020. It was specified with automotive requirements in mind, as an alternative to CAN, CAN-FD or LIN. Target application is short-range data transmission with data rates up to 10 Mbit/s.

10BASE-T1S supports half-duplex and full-duplex communication, providing a point-to-point direct connection between two nodes. It is also suited for using a multidrop topology with up to eight nodes, connected on a single 25 m bus segment. Typical application examples are automotive interior lighting, parking radar, active suspension, motor management, and audio connections. It also supports networks of incompatible devices and different physical hardware.

Advantages over previously established 10 Mbit/s protocols include:

- Connecting all sensors over the same unshielded twisted pair cable, which saves interfaces, connectors, and cables, hence reducing weight, cost, and complexity.
- The simplified architecture, entirely Ethernet-based, eliminates any need for gateways between the networks. The unified design is also simpler to test and maintain.
- Maximized data rate: With Physical Layer Collision Avoidance (PLCA), only the node that currently has the right to transmit can send data. Nodes with no data to transmit will be given a reduced slot to send data, increasing the available bandwidth.





Figure 14-51: Example of a decoded 10BASE-T1S signal

14.17.2 10BASE-T1S configuration

14.17.2.1 10BASE-T1S configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "10BASE-T1S" > "Setup".



Make sure that the tab of the correct serial bus is selected.

Protocol type

Selects the protocol type to be decoded.

Remote command:

[SBUS<sb>:TYPE](#) on page 1322

Source


Selects the source channel for the 10BASE-T1S protocol. Only analog channels can be used.

Remote command:

[SBUS<sb>:TNOS:SOURce](#) on page 1727

14.17.2.2 Threshold settings

Access: "Menu" > "Apps" > "Protocol" tab > "10BASE-T1S" > "Thresholds".



Threshold

Sets the threshold for the data channel. Enter the value directly in the fields.

Additional to the threshold, you can also set a hysteresis.

Remote command:

`SBUS<sb>:TNOS:THReshold:LOWer` on page 1728

`SBUS<sb>:TNOS:THReshold:UPPer` on page 1728

`SBUS<sb>:TNOS:THReshold:HYSTeresis` on page 1728

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.


The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:

`SBUS<sb>:THReshold` on page 1325

14.17.2.3 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.



Decode layer

Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display:

"Off"	Disables the display of the decode layer.
"Edges"	Enables the display of all edges.
"Bits"	Enables the display of the raw, encoded bits.
"Symbols"	Enables the display of the raw, encoded symbols.
"Descrambled bits"	Enables the display of the fully decoded and descrambled binary data, representing the original information being transmitted over the 10BASE-T1S link.

Data format

See ["Data format"](#) on page 481.

Zoom coupling

See ["Zoom coupling"](#) on page 482.

10BASE-T1S (automotive Ethernet, option R&S MXO5C-K560)

Show symbols

You can load symbol lists and activate their usage for decoding. As a result, an additional "Symbol" column appears in the "Decode results" table, containing the symbolic label.

For more details, see [Section 14.17.2.4, "10BASE-T1S symbols"](#), on page 780.

14.17.2.4 10BASE-T1S symbols

Symbol lists are protocol-specific.

A 10BASE-T1S symbol file contains two values for each Ethernet header:

- Ethernet Header display
- Symbolic label: name of the address, specifying its function in the bus network.


```
#####
# Supported MAC Address Format
# xx:xx:xx standard 24 bit manufactory header
# xx:xx:xx:xx:xx:xx/yy support other length headers
# yy should be the header length in decimal
# yy should be between 24 - 48
#####
@PROTOCOL_NAME = ethernet
00:00:0C Cisco
0:01:13 Olympus
0:01:14 KandaTsu
0:04:07 TopconPo
00:0B:64 KiebackP
00:1B:C5:06:C0:00/36 LuxconSy
00:1B:C5:06:D0:00/36 TesElect
00:1B:C5:06:E0:00/36 TwoDimen
00:1B:C5:06:F0:00/36 LlcEmzio
00:1F:BE Shenzhen
00:21:8F Avantgar
0.015625 GoliathS
0.015636574 D-Link
0.015648148 BaodingG
00:50:C2:5F:60:00/36 Cambridg
00:50:C2:5F:70:00/36 Metrolog
00:50:C2:5F:80:00/36 GrupoEpe
18:42:2F AlcatellL
0.781273148 RiavaNet
18:46:17 SamsungE
18:8E:D5 TpVision
18:E7:F4 Apple
40:D8:55:1C:80:00/36 SensataT
40:D8:55:1C:90:00/36 Andy-L
40:D8:55:1C:A0:00/36 RigelEng
40:D8:55:1C:B0:00/36 MgSRL
40:D8:55:1C:D0:00/36 YxlonInt
```


10BASE-T1S (automotive Ethernet, option R&S MXO5C-K560)

40:D8:55:1C:E0:00/36	PeterHub
40:D8:55:1C:F0:00/36	OmnikNew
40:D8:55:1D:00:00/36	WebeasyB
FC:F8:B7	TronteqE
FC:FA:F7	Shanghai
FC:FE:77	HitachiR
FF:FF:FF:FF:FF:FF/48	BroadCast

14.17.3 10BASE-T1S filter

Access: "Menu" > "Apps" > "Protocol" tab > "10BASE-T1S" > "Filter" tab



In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

"Check all"	Enables the filter for all available frames and error types.
"Clear"	Disables the filter for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

"Preset" Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:TNOS:FILTer:CHKall](#) on page 1729

[SBUS<sb>:TNOS:FILTer:CLR](#) on page 1730

[SBUS<sb>:TNOS:FILTer:INVert](#) on page 1730

[SBUS<sb>:TNOS:FILTer:RST](#) on page 1730

Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

Available frames are "MAC", "BEACON" and "Unknown".


Remote command:

[SBUS<sb>:TNOS:FILTer:FREnable](#) on page 1734

[SBUS<sb>:TNOS:FILTer:FRAMe<fr>:ENABLE](#) on page 1734

Edit

Opens a dialog to define the details of the selected frame.



"Field" Enables the field type that you want to filter on for the selected frame. The available fields are "Dest", "Src", "Len/Type" and "Data".

Remote command:

[SBUS<sb>:TNOS:FILTer:FIENable](#) on page 1732

[SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:ENABLE](#) on page 1732

10BASE-T1S (automotive Ethernet, option R&S MXO5C-K560)

"Condition"	Displays the value condition for the selected field. Remote command: SBUS<sb>:TNOS:FILTer:BIT on page 1730 SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:BIT on page 1730
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: SBUS<sb>:TNOS:FILTer:DMAX on page 1731 SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:DMAX on page 1731 SBUS<sb>:TNOS:FILTer:DMIN on page 1731 SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:DMIN on page 1731 SBUS<sb>:TNOS:FILTer:DOPerator on page 1732 SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:DOPerator on page 1732
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: SBUS<sb>:TNOS:FILTer:IMAX on page 1733 SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:IMAX on page 1733 SBUS<sb>:TNOS:FILTer:IMIN on page 1733 SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:IMIN on page 1733 SBUS<sb>:TNOS:FILTer:IOPerator on page 1734 SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:IOPerator on page 1734
Error type	Enables filtering on the selected error type. Remote command: SBUS<sb>:TNOS:FILTer:ERENable on page 1732 SBUS<sb>:TNOS:FILTer:ERRor<n>:ENABLe on page 1732


14.17.4 10BASE-T1S software trigger

14.17.4.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.17.4.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "10BASE-T1S" > "Trigger" tab > "Setup Software Trigger"



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

"Check all"	Enables the software trigger for all available frames and error types.
"Clear"	Disables the software trigger for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:TNOS:CHKall](#) on page 1735

[TRIGger:SBSW:TNOS:CLR](#) on page 1735

[TRIGger:SBSW:TNOS:INVert](#) on page 1735

[TRIGger:SBSW:TNOS:RST](#) on page 1736

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.


For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frames are available: "MAC", "COMMIT", "BEACON", "Unknown".

Remote command:
[TRIGger:SBSW:TNOS:FREnable](#) on page 1736
[TRIGger:SBSW:TNOS:FRAME<fr>:ENABLE](#) on page 1736

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



"Field" Enables the field type that you want to trigger on for the selected frame.

The following fields are available: "Dest", "Src", "Len/Type", "Data".

Remote command:
[TRIGger:SBSW:TNOS:FIENable](#) on page 1738
[TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:ENABLE](#) on page 1738

10BASE-T1S (automotive Ethernet, option R&S MXO5C-K560)

"Condition"	Displays the value condition for the selected field. Remote command: TRIGger:SBSW:TNOS:BIT on page 1736 TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:BIT on page 1736
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: TRIGger:SBSW:TNOS:DMAX on page 1737 TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:DMAX on page 1737 TRIGger:SBSW:TNOS:DMIN on page 1737 TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:DMIN on page 1737 TRIGger:SBSW:TNOS:DOPerator on page 1737 TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:DOPerator on page 1737
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: TRIGger:SBSW:TNOS:IMAX on page 1738 TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:IMAX on page 1738 TRIGger:SBSW:TNOS:IMIN on page 1739 TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:IMIN on page 1739 TRIGger:SBSW:TNOS:IOPerator on page 1739 TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:IOPerator on page 1739

Error type

Enables triggering on the selected error type.

The following error types are available: "Preamble error", "SFD error", "ESD error", "CRC error".

Remote command:

[TRIGger:SBSW:TNOS:ERENable](#) on page 1739

[TRIGger:SBSW:TNOS:ERRor<m>:ENABle](#) on page 1739

14.17.5 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.17.6 10BASE-T1S decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.

10BASE-T1S (automotive Ethernet, option R&S MXO5C-K560)

2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.

Decode results table



Figure 14-52: Decoded 10BASE-T1S signal

The decode results table contains information about all decoded frames.

Table 14-30: Content of the decode results table

Column	Description
Index	Frame count
State	Overall state of the frame: either OK or the relevant error condition (preamble, CRC or SFD)
Start	Start time of the frame
Type	Type of frame (e.g. Idle, MAC or data)
Destination	Destination address of the frame

10BASE-T1S (automotive Ethernet, option R&S MXO5C-K560)

Column	Description
Dest Symbol	Symbolic name of the destination defined in the symbol list. Available only, if "Show symbols" is enabled in the "Display" tab and a symbols list is loaded.
Source	Source address of the frame
Source Symbol	Symbolic name of the source defined in the symbol list. Available only, if "Show symbols" is enabled in the "Display" tab and a symbols list is loaded.
Type/Length	The sub-protocol (e.g. HTML, video, etc.) determines what meaning this field has. Since the content of this data area is not decoded, the interpretation of this field is ambivalent. It could either be the word type (specific for the sub-protocol) or the word length.
Data	Value of the data. Select the data format in the "Display" tab.
Bit rate	Value of the bit rate

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-31: Content of the frame details table

Column	Description
Index	Index of the decoded field
Label	Name of the field
State	State of the field (OK / not OK)
Value	Value of the field

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- [SBUS<sb>:FORMat](#) on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.18.4, "Decode results"](#), on page 1740.

14.17.7 Performing 10BASE-T1S decoding

This section explains step by step how to configure and decode the 10BASE-T1S bus.


14.17.7.1 Configuring 10BASE-T1S signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.17.2, "10BASE-T1S configuration"](#), on page 776.


10BASE-T1S (automotive Ethernet, option R&S MXO5C-K560)

1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: "10BASE-T1S".
4. Tap "State" to enable decoding.

A 10BASE-T1S shortcut appears at the bottom left of the screen. Tap the shortcut for a quick access to the "10BASE-T1S" dialog settings.



14.17.7.2 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the 10BASE-T1S and decoded.

1. Tap on the "10BASE-T1S" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".
5. Select the "File type".

An export file is saved in the selected directory.

The 10BASE-T1S export file contains the following fields:

- A list of all decoded frames:
 - Index
 - Start
 - Stop
 - State
 - Type
 - Destination
 - Dest Symbol (optional)
 - Source
 - Source Symbol (optional)
 - Type/Len

10BASE-T1S (automotive Ethernet, option R&S MXO5C-K560)

- CRC
- Bit rate
- The details frame includes the following fields:
 - Index
 - State
 - Value

Example 10BASE-T1S export file

```

Index,Start,Stop,State,Type,Destination,Dest Symbol,Source,Source Symbol,
Type/Len,CRC,Bit rate
1,-0.214999,-0.214971,'OK','MAC','00:00:0C:12:14:65',,'00:01:13:AB:C1:9C',
,00E6h,00002507h,12500000
2,-0.21497,-0.214941,'EPRM','MAC','00:01:14:06:C0:00',,'00:04:07:C6:C0:00',
,0122h,00004A04h,12500000
3,-0.21494,-0.21491,'ESFD','MAC','00:13:02:98:3C:CC',,'00:0B:64:06:C0:12',
,015Eh,00006F01h,12500000
4,-0.214909,-0.214878,'EESD','MAC','00:1B:C5:06:C0:00',,'00:1B:C5:06:D0:00',
,019Ah,000093FEh,12500000
5,-0.214877,-0.214846,'ECRC','MAC','00:1B:C5:06:E0:00',,'00:1B:C5:06:F0:00',
,01D6h,0000B8FBh,12500000

```

Details frame 1

```
Index,State,Value
```

```

1,'OK',14h
2,'OK',15h
3,'OK',16h
4,'OK',17h
5,'OK',18h
6,'OK',19h
7,'OK',1Ah
8,'OK',1Bh

```

Details frame 2

```
Index,State,Value
```

```

1,'OK',1Ch
2,'OK',1Dh
3,'OK',1Eh
4,'OK',1Fh
5,'OK',20h
6,'OK',21h
7,'OK',22h
8,'OK',23h
9,'OK',24h

```

14.18 100BASE-T1 (automotive Ethernet, option R&S MXO5C-K560)

100BASE-T1 is an Ethernet based protocol. It is specialized for the needs of the automotive industry, such as in the automotive networking applications, enabling advanced safety, comfort and infotainment features within the automobile.

100BASE-T1 is also known as BroadR-Reach Physical Layer (BR-PHY) or Open Alliance BroadR-Reach PHY (OABR PHY). For more details on the specifications, refer to opensig.org/automotive-ethernet-specifications and ieeexplore.ieee.org/document/7433918.


The 100BASE-T1 option is compatible with the MII (IEEE 802.3 Clause 22) and IEEE 802.3 MAC operating at 100 Mbit/s.

- [100BASE-T1 configuration](#).....791
- [100BASE-T1S filter](#).....794
- [100BASE-T1 software trigger](#).....796
- [Measure](#).....800
- [100BASE-T1 decode results](#).....800
- [Performing 100BASE-T1 decoding](#).....802

14.18.1 100BASE-T1 configuration

14.18.1.1 100BASE-T1 configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "100BASE-T1" > "Setup".



Make sure that the tab of the correct serial bus is selected.

Protocol type

Selects the protocol type to be decoded.

Remote command:

[SBUS<sb>:TYPE](#) on page 1322

Source

Selects the source channel.

Remote command:

[SBUS<sb>:HBT0:SOURce](#) on page 1750

Polarity

Selects the polarity of the data signal. You can select between "Normal" and "Inverted".

For "Normal" polarity, active high is defined as +1 V and active low is defined as -1 V.

For "Inverted" polarity, active high is defined as -1 V and active low is defined as +1 V.

Remote command:

[SBUS<sb>:HBT0:POLarity](#) on page 1749

Operation mode

Selects the desired direction of the full duplex signal for analysis. You can choose between "Auto", "Main" and "Subordinate".


If "Auto" is selected, the decoder automatically detects the "Main" or "Subordinate" mode.

Remote command:

[SBUS<sb>:HBT0:MODE](#) on page 1749

14.18.1.2 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.



Decode layer

Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display.

"Off"	Disables the display of the decode layer.
"Ternary symbols"	Enables the display of the raw, ternary encoded symbols, consisting of the three states "-1", "0" and "+1".
"Scrambled bits"	Enables the display of the binary bits, decoded from the ternary symbols, but still in a scrambled (pre-descrambling) state.
"Descrambled bits"	Enables the display of the fully decoded and descrambled binary data, representing the original information being transmitted over the 100BASE-T1 link.
"Reversed bits"	Enables display of the bits after a byte-wise reversal of the descrambled bits of the MAC frame.

Data format

See ["Data format"](#) on page 481.

Zoom coupling

See ["Zoom coupling"](#) on page 482.

100BASE-T1 (automotive Ethernet, option R&S MXO5C-K560)

Show symbols

Symbol lists are protocol-specific. Label lists for 100BASE-T1 are available in CSV format.

For details, see [100BASE-T1 symbols](#).

Remote command:

[SBUS<sb>:HBTO:SYMBOLs](#) on page 1750

[SBUS<sb>:HBTO:NEWList](#) on page 1750

14.18.1.3 100BASE-T1 symbols

Symbol lists are protocol-specific.


A 100BASE-T1 symbol file contains two values for each Ethernet header:

- Ethernet Header display
- Symbolic label: name of the address, specifying its function in the bus network.

For an example, see [Section 14.17.2.4, "10BASE-T1S symbols"](#), on page 780.

14.18.2 100BASE-T1S filter

Access: "Menu" > "Apps" > "Protocol" tab > "100BASE-T1" > "Filter" tab



In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

"Check all"	Enables the filter for all available frames and error types.
"Clear"	Disables the filter for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:HBT0:FILTer:CHKall](#) on page 1751

[SBUS<sb>:HBT0:FILTer:CLR](#) on page 1752

[SBUS<sb>:HBT0:FILTer:INVert](#) on page 1752

[SBUS<sb>:HBT0:FILTer:RST](#) on page 1752

Frame type


Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

Available frames are "MAC", "Fill", "Idle" and "Unknown".

Edit

Opens a dialog to define the details of the selected frame.



- "Field" Enables the field type that you want to filter on for the selected frame. The available fields are "Dest", "Src", "Len/Type" and "Data".
- "Condition" Displays the value condition for the selected field.
- "Value" The data setup consists of a comparison condition and one or two data patterns.
- "Index" The index setup consists of a comparison condition and one or two index values.

Error type
 Enables filtering on the selected error type.


14.18.3 100BASE-T1 software trigger

14.18.3.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.18.3.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "100BASE-T1" > "Trigger" tab > "Setup Software Trigger" > "Setup SB Trigger".



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

"Check all"	Enables the software trigger for all available frames and error types.
"Clear"	Disables the software trigger for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:HBTO:CHKall](#) on page 1757

[TRIGger:SBSW:HBTO:CLR](#) on page 1757

[TRIGger:SBSW:HBTO:INVert](#) on page 1757

[TRIGger:SBSW:HBTO:RST](#) on page 1757

Frame type


Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frames are available: "MAC", "Fill", "Idle", "Unknown".

Remote command:
[TRIGger:SBSW:HBTO:FREnable](#) on page 1757
[TRIGger:SBSW:HBTO:FRAME<fr>:ENABLE](#) on page 1757

Edit
Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



- "Field"

Enables the field type that you want to trigger on for the selected frame.
The following fields are available: "Dest", "Src", "Len/Type", "Data".
Remote command:
[TRIGger:SBSW:HBTO:FIENable](#) on page 1759
[TRIGger:SBSW:HBTO:FRAME<fr>:FLD<fl>:ENABLE](#) on page 1759
- "Condition"


Displays the value condition for the selected field.
Remote command:
[TRIGger:SBSW:HBTO:BIT](#) on page 1758
[TRIGger:SBSW:HBTO:FRAME<fr>:FLD<fl>:BIT](#) on page 1758

100BASE-T1 (automotive Ethernet, option R&S MXO5C-K560)

"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: TRIGger:SBSW:HBTO:DMAX on page 1758 TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:DMAX on page 1758 TRIGger:SBSW:HBTO:DMIN on page 1758 TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:DMIN on page 1758 TRIGger:SBSW:HBTO:DOPerator on page 1759 TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:DOPerator on page 1759
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: TRIGger:SBSW:HBTO:IMAX on page 1760 TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:IMAX on page 1760 TRIGger:SBSW:HBTO:IMIN on page 1760 TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:IMIN on page 1760 TRIGger:SBSW:HBTO:IOPerator on page 1760 TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:IOPerator on page 1760

Error type

Enables triggering on the selected error type.



The following error types are available: "Preamble error", "SFD error", "Length error", "CRC error", "Uncorrelated".

Remote command:

[TRIGger:SBSW:HBT0:ERENable](#) on page 1761

[TRIGger:SBSW:HBT0:ERRor<m>:ENABle](#) on page 1761

14.18.4 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.18.5 100BASE-T1 decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.

Decode results table




Figure 14-53: Decoded 100BASE-T1 signal

The decode results table contains information about all decoded frames.

Table 14-32: Content of the decode results table

Column	Description
Index	Frame count
State	Overall state of the frame: either OK or the relevant error condition (preamble, CRC or SFD)
Start	Start time of the frame
Type	Type of frame (e.g. Idle, MAC or data)
Destination	Destination address of the frame
Dest Symbol	Symbolic name of the destination defined in the symbol list. Available only, if "Show symbols" is enabled in the "Display" tab and a symbols list is loaded.
Source	Source address of the frame
Source Symbol	Symbolic name of the source defined in the symbol list. Available only, if "Show symbols" is enabled in the "Display" tab and a symbols list is loaded.
Type/Length	The subprotocol (e.g. HTML, video, etc.) determines what meaning this field has. Since the content of this data area is not decoded, the interpretation of this field is ambivalent. It could either be the word type (specific for the sub-protocol) or the word length.
Data	Value of the data. Select the data format in the "Display" tab.
Bit rate	Value of the bit rate

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-33: Content of the frame details table

Column	Description
Index	Index of the decoded field
Label	Name of the field
State	State of the field (OK / not OK)
Value	Value of the field

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- `SBUS<sb>:FORMat` on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.19.4, "Decode results"](#), on page 1762.

14.18.6 Performing 100BASE-T1 decoding


This section explains step by step how to configure and decode the 100BASE-T1 bus.

14.18.6.1 Configuring 100BASE-T1 signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.18.1, "100BASE-T1 configuration"](#), on page 791.

1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: "100BASE-T1".
4. Tap on "State" to enable the decoding.

A 100Base-T1 shortcut appears at the bottom left of the screen. Tap on the shortcut for a quick access to the "100BASE-T1" dialog settings.



14.18.6.2 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the 100BASE-T1 and decoded.

1. Tap on the "100BASE-T1" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".
5. Select the "File type".

An export file is saved in the selected directory.

The 100BASE-T1 export file contains the following fields:

- A list of all decoded frames:
 - Index
 - Start
 - Stop
 - State
 - Type
 - Destination
 - Dest Symbol (optional)
 - Source
 - Source Symbol (optional)
 - Type/Len
 - CRC
 - Bit rate
- The details frame includes the following fields:
 - Index
 - Label
 - State
 - Value

Example 100BASE-T1 export file

```
Index,Start,Stop,State,Type,Destination,Dest Symbol,Source,Source Symbol,
Type/Len,CRC,Bit rate
```

1000BASE-T1 (automotive Ethernet, option R&S MXO5C-K560)

```

1,-0.214999,-0.214971,'OK','MAC','00:00:0C:12:14:65',,'00:01:13:AB:C1:9C',
,00E6h,00002507h,12500000
2,-0.21497,-0.214941,'EPRM','MAC','00:01:14:06:C0:00',,'00:04:07:C6:C0:00',
,0122h,00004A04h,12500000
3,-0.21494,-0.21491,'ESFD','MAC','00:13:02:98:3C:CC',,'00:0B:64:06:C0:12',
,015Eh,00006F01h,12500000
4,-0.214909,-0.214878,'EESD','MAC','00:1B:C5:06:C0:00',,'00:1B:C5:06:D0:00',
,019Ah,000093FEh,12500000
5,-0.214877,-0.214846,'ECRC','MAC','00:1B:C5:06:E0:00',,'00:1B:C5:06:F0:00',
,01D6h,0000B8FBh,12500000

```

Details frame 1

Index	Label	State	Value
1	"Data: 1"	'OK'	"32h"
2	"Data: 2"	'OK'	"33h"
3	"Data: 3"	'OK'	"34h"
4	"Data: 4"	'OK'	"35h"
5	"Data: 5"	'OK'	"36h"
6	"Data: 6"	'OK'	"37h"
7	"Data: 7"	'OK'	"38h"
8	"Data: 8"	'OK'	"39h"

Details frame 2

Index	Label	State	Value
1	"Data: 1"	'OK'	"3Ah"
2	"Data: 2"	'OK'	"3Bh"
3	"Data: 3"	'OK'	"3Ch"
4	"Data: 4"	'OK'	"3Dh"
5	"Data: 5"	'OK'	"3Eh"
6	"Data: 6"	'OK'	"3Fh"
7	"Data: 7"	'OK'	"40h"
8	"Data: 8"	'OK'	"41h"
9	"Data: 9"	'OK'	"42h"

14.19 1000BASE-T1 (automotive Ethernet, option R&S MXO5C-K560)

1000BASE-T1 is a single-pair Ethernet-based protocol, specialized for the needs of the automotive industry. Main applications are in automotive networking, enabling advanced safety, comfort and infotainment features within the automobile. For specifications, refer to IEEE P802.3bp.

- [1000BASE-T1 basics](#).....805
- [1000BASE-T1 configuration](#).....805
- [1000BASE-T1 filter](#).....808
- [1000BASE-T1 software trigger](#).....811

1000BASE-T1 (automotive Ethernet, option R&S MXO5C-K560)

• Measure	815
• 1000BASE-T1 decode results	815
• Performing 1000BASE-T1 decoding	817

14.19.1 1000BASE-T1 basics

The 1000BASE-T1 has the following objectives:

- Provides a PHY that supports full duplex operating at 1000 Mbps over a pair of unshielded sheathed twisted-pair cable or better cable.
- Achieves bit error rate (BER) of less than $1e^{-10}$.
- Support for up to at least 15 meters of cable length in the automotive link segment.


To achieve the above objectives, 1000BASE-T1 uses Physical Coding Sublayer (PCS) and Physical Medium Attachment (PMA) sublayer as follows:

- Adopts full duplex communication of 1000BASE-T1 and therefore echo cancellation on a single twisted-pair channel. This feature reduces cabling while preserving the Ethernet MAC compatibility
- Adopts Pulse Amplitude Modulation (PAM-3) encoding scheme with the following encoding techniques:
 - PAM-3 is transmitted at 750 MB data rate.
 - It uses 15-bit scrambler to improve the EMC performance.
 - Data is encoded in 80B/81B blocks.
 - 396 bits of Reed-Solomon forward error correction (FEC) parity is added to each group of 45 80B/81B blocks.
 - 9-bit OAM symbol is added, then 396 bits Reed-Solomon. Together, they shape a PHY frame of 4050 bits, or 450 forward error correction (FEC) symbols of 9 bits. FEC allows for correction of up to 22 FEC symbols per PHY frame.

14.19.2 1000BASE-T1 configuration

14.19.2.1 1000BASE-T1 configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "1000BASE-T1" > "Setup".



Make sure that the tab of the correct serial bus is selected.

Protocol type

Selects the protocol type to be decoded.

Remote command:

[SBUS<sb>:TYPE](#) on page 1322

Source plus

Selects the D+ data source channel for the 1000BASE-T1 protocol. No digital channels can be used.

Remote command:

[SBUS<sb>:TBTO:SRCPlus](#) on page 1772

Source minus

Selects the D- data source channel for the 1000BASE-T1 protocol. No digital channels can be used.

Remote command:

[SBUS<sb>:TBTO:SRCMinus](#) on page 1772

Polarity

Selects the polarity of the data signal. You can select between "Normal" and "Inverted".

For "Normal" polarity, active high is defined as +1 V and active low is defined as -1 V.

For "Inverted" polarity, active high is defined as -1 V and active low is defined as +1 V.

Remote command:

[SBUS<sb>:TBTO:POLarity](#) on page 1771

Operation mode

Selects the desired direction of the full duplex signal for analysis. You can choose between "Auto", "Main" and "Subordinate".


If "Auto" is selected, the decoder automatically detects the "Main" or "Subordinate" mode.

Remote command:

[SBUS<sb>:TBTO:MODE](#) on page 1770

14.19.2.2 Display settings

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.



Decode layer

Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display:

"Off"	Disables the display of the decode layer.
"Ternary symbols"	Enables the display of the raw, ternary encoded symbols, consisting of the three states "-1", "0" and "+1".
"Scrambled bits"	Enables the display of the binary bits, decoded from the ternary symbols, but still in a scrambled (pre-descrambling) state.

1000BASE-T1 (automotive Ethernet, option R&S MXO5C-K560)

"Descrambled bits"	Enables the display of the fully decoded and descrambled binary data, representing the original information being transmitted over the 10BASE-T1S link.
"Corrected RS-FEC"	Enables the display of the corrected Reed-Solomon frame error count, which is the number of errors corrected by the Reed-Solomon recovery algorithm.

Data format

See ["Data format"](#) on page 481.

Zoom coupling

See ["Zoom coupling"](#) on page 482.

Show symbols

Symbol lists are protocol-specific. Label lists for 1000BASE-T1 are available in CSV format.

For details, see [Section 14.19.2.3, "1000BASE-T1 symbols"](#), on page 808.

Remote command:

[SBUS<sb>:TBTO:SYMBOLs](#) on page 1772

[SBUS<sb>:TBTO:NEWLlist](#) on page 1771

14.19.2.3 1000BASE-T1 symbols

Symbol lists are protocol-specific.


A 1000BASE-T1 symbol file contains two values for each Ethernet header:

- Ethernet Header display
- Symbolic label: name of the address, specifying its function in the bus network.

For an example, see [Section 14.17.2.4, "10BASE-T1S symbols"](#), on page 780.

14.19.3 1000BASE-T1 filter

Access: "Menu" > "Apps" > "Protocol" tab > "1000BASE-T1" > "Filter" tab



In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

"Check all"	Enables the filter for all available frames and error types.
"Clear"	Disables the filter for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:TBTO:FILTER:CHKall](#) on page 1773

[SBUS<sb>:TBTO:FILTER:CLR](#) on page 1773

[SBUS<sb>:TBTO:FILTER:INVert](#) on page 1774

[SBUS<sb>:TBTO:FILTER:RST](#) on page 1774

Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.


Available frames are:

- "MAC"
- "Idle"
- "OAM"

- "Reed Solomon"
- "BH"
- "CtlAddr"
- "CtlCode"
- "Ternary Zero"
- "Unknown"

Edit

Opens a dialog to define the details of the selected frame.



"Field" Enables the field type that you want to filter on for the selected frame. The available fields are "Dest", "Src", "Len/Type", "Data" and "OAM".

Remote command:

[SBUS<sb>:TBTO:FILTER:FIENable](#) on page 1776

[SBUS<sb>:TBTO:FILTER:FRAME<fr>:FLD<fl>:ENABLE](#) on page 1776

"Condition" Displays the value condition for the selected field.

Remote command:

[SBUS<sb>:TBTO:FILTER:BIT](#) on page 1774

[SBUS<sb>:TBTO:FILTER:FRAME<fr>:FLD<fl>:BIT](#) on page 1774

1000BASE-T1 (automotive Ethernet, option R&S MXO5C-K560)

"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: SBUS<sb>:TBTO:FILTer:DMAX on page 1775 SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:DMAX on page 1775 SBUS<sb>:TBTO:FILTer:DMIN on page 1775 SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:DMIN on page 1775 SBUS<sb>:TBTO:FILTer:DOPerator on page 1775 SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:DOPerator on page 1775
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: SBUS<sb>:TBTO:FILTer:IMAX on page 1777 SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:IMAX on page 1777 SBUS<sb>:TBTO:FILTer:IMIN on page 1777 SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:IMIN on page 1777 SBUS<sb>:TBTO:FILTer:IOPerator on page 1778 SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:IOPerator on page 1778

Error type

Enables filtering on the selected error type.

Remote command:

[SBUS<sb>:TBTO:FILTer:ERENable](#) on page 1776


[SBUS<sb>:TBTO:FILTer:ERRor<n>:ENABle](#) on page 1776

14.19.4 1000BASE-T1 software trigger**14.19.4.1 Setup A trigger**

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.19.4.2 Software trigger settings

Access: "Menu" > "Apps" > "Protocol" tab > "1000BASE-T1" > "Trigger" tab > "Setup Software Trigger" > "Setup SB Trigger".



In the "Software Trigger" tab, you can define the settings to trigger on the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

"Check all"	Enables the software trigger for all available frames and error types.
"Clear"	Disables the software trigger for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:TBTO:CHKall](#) on page 1779

[TRIGger:SBSW:TBTO:CLR](#) on page 1779

[TRIGger:SBSW:TBTO:INVert](#) on page 1779

[TRIGger:SBSW:TBTO:RST](#) on page 1779

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.


For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frames are available: "MAC", "Idle", "OAM", "Reed Solomon", "BH", "CtlAddr", "CtlCode", "Ternary Zero", "Unknown".

Remote command:
[TRIGger:SBSW:TBTO:FREnable](#) on page 1779
[TRIGger:SBSW:TBTO:FRAME<fr>:ENABLE](#) on page 1779

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



"Field"


Enables the field type that you want to trigger on for the selected frame.

The following fields are available: "Dest", "Src", "Len/Type", "Data", "OAM".

Remote command:
[TRIGger:SBSW:TBTO:FIENable](#) on page 1781
[TRIGger:SBSW:TBTO:FRAME<fr>:FLD<fl>:ENABLE](#) on page 1781

1000BASE-T1 (automotive Ethernet, option R&S MXO5C-K560)

"Condition"	Displays the value condition for the selected field. Remote command: TRIGger:SBSW:TBTO:BIT on page 1780 TRIGger:SBSW:TBTO:FRAME<fr>:FLD<fl>:BIT on page 1780
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: TRIGger:SBSW:TBTO:DMAX on page 1780 TRIGger:SBSW:TBTO:FRAME<fr>:FLD<fl>:DMAX on page 1780 TRIGger:SBSW:TBTO:DMIN on page 1780 TRIGger:SBSW:TBTO:FRAME<fr>:FLD<fl>:DMIN on page 1780 TRIGger:SBSW:TBTO:DOPerator on page 1781 TRIGger:SBSW:TBTO:FRAME<fr>:FLD<fl>:DOPerator on page 1781
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: TRIGger:SBSW:TBTO:IMAX on page 1782 TRIGger:SBSW:TBTO:FRAME<fr>:FLD<fl>:IMAX on page 1782 TRIGger:SBSW:TBTO:IMIN on page 1782 TRIGger:SBSW:TBTO:FRAME<fr>:FLD<fl>:IMIN on page 1782 TRIGger:SBSW:TBTO:IOperator on page 1782 TRIGger:SBSW:TBTO:FRAME<fr>:FLD<fl>:IOperator on page 1782
Error type	Enables triggering on the selected error type.



The following error types are available: "FEC error", "Zero symbol error", "Out of range error", "CRC error".

Remote command:

[TRIGger:SBSW:TBTO:ERENable](#) on page 1783

[TRIGger:SBSW:TBTO:ERRor<m>:ENABLE](#) on page 1783

14.19.5 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.19.6 1000BASE-T1 decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

1000BASE-T1 (automotive Ethernet, option R&S MXO5C-K560)

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.

Decode results table

The "Decode results" table contains information about all decoded frames.




Figure 14-54: Decoded 1000BASE-T1 signal

The decode results table contains information about all decoded frames.

Table 14-34: Content of the decode results table

Column	Description
Index	Frame count
State	Overall state of the frame: either OK or the relevant error condition (preamble, CRC or SFD)
Start	Start time of the frame
Type	Type of frame (e.g. Idle, MAC or data)
Destination	Destination address of the frame
Dest symbol	Symbolic destination name. Available only, if "Show symbols" is enabled in the "Display" tab and a symbols list is loaded.
Source	Source address of the frame
Source Symbol	Symbolic source name. Available only, if "Show symbols" is enabled in the "Display" tab and a symbols list is loaded.

1000BASE-T1 (automotive Ethernet, option R&S MXO5C-K560)

Column	Description
Type/Length	The subprotocol (e.g. HTML, video, etc.) determines what meaning this field has. Since the content of this data area is not decoded, the interpretation of this field is ambivalent. It could either be the word type (specific for the subprotocol) or the word length.
Data	Value of the data. Select the data format in the "Display" tab.
Bit rate	Value of the bit rate

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-35: Content of the frame details table

Column	Description
Index	Index of the decoded field
Label	Name of the field
State	State of the field (OK / not OK)
Value	Value of the field

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- [SBUS<sb>:FORMat](#) on page 1323

Export of decode results

1. In the protocol "Shortcuts" tab, press "Export results".
The "Export results" dialog opens.
For details, see [Section 14.1.7, "Export protocol results"](#), on page 490.
2. Select the details that you want to export and the file format.
3. Tap "Save as".
4. Key in a name and select the file format.

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.20, "1000BASE-T1 \(option R&S MXO5C-K560\)"](#), on page 1770.

14.19.7 Performing 1000BASE-T1 decoding


This section explains step by step how to configure and decode the 1000BASE-T1 bus.

14.19.7.1 Configuring 1000BASE-T1 signals

For configuration, assign the lines to the input channels, and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.19.2, "1000BASE-T1 configuration"](#), on page 805.

1. Tap the "+ Bus" activator in the bottom right of the screen.



2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: "1000BASE-T1".
4. Tap on "State" to enable the decoding.

A 1000Base-T1 shortcut appears at the bottom left of the screen. Tap on the shortcut for a quick access to the "1000BASE-T1" dialog settings.



14.19.7.2 Exporting decode results

Once a decode has been completed, you can generate an export of all decode results.

Prerequisites: A bus is configured for the 1000BASE-T1 and decoded.

1. Tap on the "1000BASE-T1" shortcut.
2. Tap on the "Export" tab.
3. If necessary, enable "Include details".
4. If necessary, enable "Include timing".
5. Select the "File type".

An export file is saved in the selected directory.

The 1000BASE-T1 export file contains the following fields:

- A list of all decoded frames:
 - Index
 - Start
 - Stop
 - State

1000BASE-T1 (automotive Ethernet, option R&S MXO5C-K560)

- Type
- Destination
- Dest Symbol (optional)
- Source
- Source Symbol (optional)
- Type/Len
- Data
- CRC
- Bit rate
- The details frame includes the following fields:
 - Index
 - Label
 - State
 - Value

Example 1000BASE-T1 export file

```
Index,Start,Stop,State,Type,Destination,Source,Type/Len,Data,CRC,Bit rate
1,-1.538e-06,1.596e-06,'OK','MAC','18:46:17:04:05:06','40:D8:55:1C:80:00',0169h,
00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10 11 12 13 14 15 16 17 18 19 1A
1B 1C 1D 1E 1F 20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F 30 31 32 33 34 35
36 37 38 39 3A 3B 3C 3D 3E 3F 40 41 42 43 44 45 46 47 48 49 4A 4B 4C 4D 4E 4F 50
51 52 53 54 55 56 57 58 59 5A 5B 5C 5D 5E 5F 60 61 62 63 64 65 66 67 68 69 6A 6B
6C 6D 6E 6F 70 71 72 73 74 75 76 77 78 79 7A 7B 7C 7D 7E 7F 80 81 82 83 84 85 86
87 88 89 8A 8B 8C 8D 8E 8F 90 91 92 93 94 95 96 97 98 99 9A 9B 9C 9D 9E 9F A0 A1
A2 A3 A4 A5 A6 A7 A8 A9 AA AB AC AD AE AF B0 B1 B2 B3 B4 B5 B6 B7 B8 B9 BA BB BC
BD BE BF C0 C1 C2 C3 C4 C5 C6 C7 C8 C9 CA CB CC CD CE CF D0 D1 D2 D3 D4 D5 D6 D7
D8 D9 DA DB DC DD DE DF E0 E1 E2 E3 E4 E5 E6 E7 E8 E9 EA EB EC ED EE EF F0 F1 F2
F3 F4 F5 F6 F7 F8 F9 FA FB FC FD FE FF 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D
0E 0F 10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20 21 22 23 24 25 26 27 28
29 2A 2B 2C 2D 2E 2F 30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F 40 41 42 43
44 45 46 47 48 49 4A 4B 4C 4D 4E 4F 50 51 52 53 54 55 56 57 58 59 5A 5B 5C 5D 5E
5F 60 61 62 63 64 65 66 67 68,AFFEAFFEh,987900000
2,1.6e-06,1.602e-06,'ERRZERO','ZEROTSYM',---,---,---,---,---,1500000000
3,1.605e-06,1.62e-06,'ERROOR','UNKN',---,---,---,---,---,1067000000
4,1.62e-06,1.629e-06,'OK','OAM',---,---,---,1EFh,---,1000000000
```

Details frame 1

```
Index,Label,State,Value
1,'"Data: 1"', 'OK', '"00h"'
2,'"Data: 2"', 'OK', '"01h"'
3,'"Data: 3"', 'OK', '"02h"'
4,'"Data: 4"', 'OK', '"03h"'
5,'"Data: 5"', 'OK', '"04h"'
6,'"Data: 6"', 'OK', '"05h"'
7,'"Data: 7"', 'OK', '"06h"'
8,'"Data: 8"', 'OK', '"07h"'
```

```

9, '"Data: 9"', 'OK', '"08h"'
10, '"Data: 10"', 'OK', '"09h"'
(...)

```

14.20 USB 1.1 (option R&S MXO5C-K570)

R&S MXO5C-K570 is a firmware option that enables the MXO 5C to analyze Universal Serial Bus (USB) protocols, by triggering and decoding them. The option is compatible with the standards USB 1.0, USB 1.1 and USB 2.0, but not with USB HSIC. It supports the data rates "Low Speed" (1.5 Mbit/s) and "Full Speed" (12 Mbit/s), both in USB 1.0 and USB 1.1, and "High Speed" (480 Mbit/s in USB 2.0).

For USB 2.0, refer to [Section 14.21, "USB 2.0 \(option R&S MXO5C-K570\)"](#), on page 838.

• USB protocol basics	820
• USB 1.1 configuration	825
• USB 1.1 filter	829
• USB 1.1 trigger	832
• Measure	836
• USB 1.1 decode results	836

14.20.1 USB protocol basics

The USB protocol was developed, starting in 1996, by the nonprofit organization USB Implementers Forum, Inc. (USB-IF), formed by Compaq, Hewlett-Packard, Intel, Lucent Technologies, Microsoft, NEC, and Philips. The purpose was to provide a common "plug-and-play" solution to replace a multitude of interfaces for the communication between computers and devices. It allows even unskilled users to connect many devices to a PC easily. USB was originally used for devices that feature low signaling rates (up to 1.5 Mbit/s), especially human interface devices like mouse, joystick or keyboard. With the release of USB 2.0 in April 2000, devices such as printers, cameras and mass storage media were enabled to exchange data at faster rates (up to 480 Mbit/s). Also, the high-speed protocol HSIC (High Speed Inter Chip) is used for the communication between on-board devices.




Figure 14-55: USB Topology: mass storage device, printer, USB hub, and mouse (human interface device) connected to a USB host

More information, including the USB specification, is available online within the web domain <http://usb.org>.

This section provides an overview of protocol characteristics, data transfer, packet structure, address and endpoint formats of USB and trigger possibilities.

USB characteristics

The main characteristics of USB are:

- Four-wire design: USB requires a shielded cable containing four wires. Two of them, called D+ and D-, form a twisted pair (for low speed, they can be non-twisted). These data lines transmit differential data signals and single-ended signal states, both referenced to a third wire: the GND or ground. The fourth wire is called VBUS (voltage bus). It carries a nominal 5 V supply, which can be used to power a device.
- Host-to-device communication: in USBs "speak-when-spoken-to" protocol, communication is always initiated by the host. Consequently, there is no direct communication between USB devices, apart from a few exceptions.
- The addressing scheme can distinguish a maximum of 127 connected devices, because a packet's address field length is limited to 7 bits. USB devices have up to 16 OUT endpoints (from host to device) and up to 16 IN endpoints (from device to host).
- USB transactions consist of two or three packets: token, data, and typically handshake
- Packet type: a packet identifier (PID) is sent as a first byte within the packet and specifies the different packet types.
- NRZI (Non Return to Zero Inverted): a zero (0) is encoded as a transition of the physical level, whereas a one (1) has no transition, thus it is represented by a steady level.




Figure 14-56: Example of an NRZI sequence

- Bit stuffing: a zero (0) is inserted after every 6 consecutive ones (111111). This insertion ensures sufficient transitions to keep the phase-locked loop (PLL) synchronized and locked onto the data stream.
- Little Endian scheme: both multiple bits and multiple bytes are transmitted with the least significant bit/byte (LSB) sent first, while the most significant bit/byte (MSB) is sent last.
- HSIC (high-speed inter-chip): an industry standard for USB chip-to-chip interconnection with a 2-signal (strobe, data) source synchronous serial interface, using 240 MHz DDR signaling to provide only high-speed (480 Mbit/s) data rate.

Table 14-36: Simplified symbolic representation from the USB standard

Bus State	Protocol	Levels
Differential "1"		D+ High, D- Low
Differential "0"		D+ Low, D- High
Data "J" State	Low speed	D+ Low, D- High (differential "0")

Bus State	Protocol	Levels
	Full speed	D+ High, D- Low (differential "1")
Data "K" State	Low speed	D+ High, D- Low (differential "1")
	Full speed	D+ Low, D- High (differential "0")

In the example in [Table 14-36](#), "High" speed can be assumed to be like "Full" speed. For a complete overview of bus states and for an electrical definition of "High" and "Low" speed, refer to section 7 of the USB specification.

Data transfer

In contrast to a conventional bus, USB is more like a network protocol, using target addresses and endpoints. However, USB features a primary on the bus, called the host. It transmits packets of data to all devices or hubs connected to the host (or connected to a device or hub, which is in turn connected to the host). All connected devices receive each data packet, but disregard it unless it carries the correct address. In reply, only the addressed device (one at a time) can send data upstream to the host.

The USB architecture supports four different kinds of data transfer: control, bulk, interrupt or isochronous transfer. For example, a "bulk OUT" transfer (from host to device) can look like this:



Figure 14-57: Example of a bulk OUT transfer. Blue: host speaks, white: device speaks

Packet structure

All packets must start with a **SYNC** field, also called **SOP** (start of packet), which indicates data transmission. It consists of "KJ" pairs, followed by one "KK". At low speed and full speed (USB 1.x), it is 8 bits long, encoded as "KJKJKJKK". At high speed (USB 2.0 and HSIC), it is up to 32 bits long, encoded as "KJKJKJKJKJKJ...KK".

The SYNC field is used to synchronize the clock of the receiver with the clock of the transmitter. The final 2 bits ("KK") indicate where the PID field starts.




Figure 14-58: Start of a high-speed packet: after an SE0, the packet starts with a SYNC field (or SOP), followed by the data packet

- SE0 = Single-ended zero, both D+ and D- wire are on low level
- 1 = High-speed SYNC field (or SOP), length up to 32 bits
- 2 = Receiver-squelched differential envelope, below 100 mV

- 3 = Differential envelope exceeds 150 mV, reception enabled with 4 symbol times
- 4 = Clock recovery must lock in time to detect the end of SYNC
- 5 = End of SYNC detected, receiver begins data recovery

After the SYNC (or SOP), USB data packets consist of (in this order):

- **PID** (packet identifier): specifies the type of packet. Examples are:
 - Token packets (IN, OUT, SETUP) are always the first packet in a USB transaction, containing the address of the device and its endpoint.
 - Token SOF packets (start of frame) are there to schedule a data transfer.
 - Handshake packets provide the status of the transaction.
 - Data packets are dedicated for the data transfer payload.
 - Various special packets provide special characteristics: for instance, SPLIT packets are used to communicate with low or full speed devices on a high-speed link.

The PID's length is 8 bit, beginning (LSB) with the fields PID0, PID1, PID2 and PID3. Those 4 bits are repeated in PID4, PID5, PID6 and PID7, but in complementary form (for integrity checking). The PID is the only part of a packet not to be covered by the CRC (see below). Packets with invalid or non-supported PID fields are rejected. For valid PIDs, see [Table 14-37](#).

- [illegible]

Table 14-37: Valid PIDs for different packet types

Packet type	Name	PID value	Meaning
Token	OUT	0xE1	Starts data transfer towards a device
	IN	0x69	Starts data transfer towards the host
	SOF	0xA5	Indicates start of frame
	SETUP	0x2D	Starts a setup transfer and sends information on this start to the device
Data	DATA0	0xC3	Data packet with data-toggle bit 0
	DATA1	0x4B	Data packet with data-toggle bit 1
	DATA2	0x87	Data packet for high speed IN isochronous transfers that require high bandwidth
	MDATA	0x0F	Data packet for high-speed OUT isochronous transfers that require high bandwidth
Handshake	ACK	0xD2	Acknowledgment of a packet received without error
	NAK	0x5A	Data not accepted, typically equivalent with some type of EAGAIN, meaning that the data needs to be resent later
	STALL	0x1E	A severe error has occurred, the target endpoint cannot be addressed until it is explicitly cleared again
	NYET	0x96	Only used in high-speed transfers, meaning ACK, but in the next interval no data can be received. Therefore the host must apply a PING first.
Special	PRE	0x3C	Starts a low speed transfer via a full speed bus
	ERR	0x3C	Indicates an error in an SPLIT transaction (using the same PID as PRE, however, these indications cannot be mistaken for each other)
	SPLIT	0x78	Starts an SPLIT transaction (thus: a low speed or full speed transfer via a high-speed bus)
	PING	0xB4	Used for monitoring high-speed data flow

- Token packets (IN, OUT, SETUP) and PING packets have the following format:

SYNC	PID	ADDR	ENDP	CRC5	EOP

- Start of frame packets (SOF) have the following format:

SYNC	PID	Frame number	CRC5	EOP

- Data packets have the following format:

SYNC	PID	Data	CRC16	EOP

- Handshake packets have the following format:

SYNC	PID	EOP

- SPLIT packets have the following format:

SYNC	PID	ADDR	SC	PORT	S	E	ET	CRC5	EOP

Trigger possibilities

Signals on the input channels can be triggered. The following trigger types are available:

- ANY Packet - Packet Sync: Triggering on the first rising slope after transmission of the packet Sync. Various lengths according to standard (in USB 2.0: 32 bit)
- Any token, OUT, IN, SOF, SETUP, AND-ing with user-defined PID check, address, endpoint, CRC5: For OUT, IN, SETUP, the endpoint and CRC5 follow from the bit order, therefore such patterns can be recognized.
- Data Selection: DATA0, DATA1, DATA2, MDATA, (for USB 1.x only: AND-ing with user-defined PID check, payload and CRC values)
- Handshake Packet Setup: Triggering on handshake packet, trigger with specific settings: ACK, NAK, NYET, STALL or ERR handshake packet
- Protocol Error: Triggering on PID/check error, CRC5 error, CRC16 (for USB 1.x only), frame length error (for USB 1.x only)
- Bus Event: Triggering on reset, resume, or suspend.

14.20.2 USB 1.1 configuration

If you need information on how to get started with configuring the USB 1.1 setup, see [Section 14.20.2.2, "Configuring USB 1.1 signals"](#), on page 827. Otherwise proceed with the configuration settings.

14.20.2.1 USB 1.1 configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "USB 1.1" > "Setup" tab



Make sure that the tab of the correct serial bus is selected.




Figure 14-59: Serial bus protocol configuration dialog for USB 1.1 LS or FS

See also: [Section 14.1.1, "Setup - general settings"](#), on page 477.

Protocol type

Selects the protocol type to be decoded.

Remote command:

[SBUS<sb>:TYPE](#) on page 1322

State

Enables the decoding of the selected bus. The signal icon of the bus appears on the signal bar.

Remote command:

[SBUS<sb>\[:STATe\]](#) on page 1322

D+ source, D- source

Defines the source settings for the D+ and the D- data signals for USB 1.1 low speed (LS) or full speed (FS) protocols.

Usually, the source is one of the analog channels. Reference and math waveforms are available as sources if the trigger source is one of the analog channels but not the serial bus.

Remote command:

[SBUS<sb>:USBone:DPLus:SOURce](#) on page 1793

[SBUS<sb>:USBone:DMINus:SOURce](#) on page 1793

Speed variant

Selects the low or full speed variant of USB:


"USB 1.1 LS"

Selects the 1.5 Mbit/s low speed (LS) protocol variant of USB 1.1.

"USB 1.1 FS"

Selects the 12 Mbit/s full speed (FS) protocol variant of USB 1.1.

Note: Instead of selecting the speed variant in this "Setup" dialog, you can select it in the protocol selection table:



To access the protocol selection table, select "Menu" > "Apps" > "Protocol", or use the "Protocol type" button in the "Setup" dialog.

Remote command:

`SBUS<sb>:USBone:MODE` on page 1793

14.20.2.2 Configuring USB 1.1 signals

For configuration, assign the lines to the input channels and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.20.2.1, "USB 1.1 configuration settings"](#), on page 825.

Serial Bus Setup

1. Tap the "+ Bus" activator in the bottom right of the screen.
2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select "Protocol type" = "USB 1.1 LS" or "USB 1.1 FS".
4. Select the waveform for the "D+ source" and "D- source" lines.
5. In the "Thresholds" tab, specify the logical thresholds: "D+ threshold" and "D- threshold".
Specify also hysteresis settings: "D+ hysteresis" and "D- hysteresis".
6. In the "Display" tab, enable "Show decode table".

14.20.2.3 Threshold settings

Access: "Menu" > "Apps" > "Protocol" tab > "USB 1.1" > "Thresholds" tab




Figure 14-60: Serial bus threshold configuration dialog for USB 1.1

Threshold and hysteresis settings

Specifies the following values:

D+ threshold ← Threshold and hysteresis settings

Sets the threshold value for the digitization of the signal on the D+ data line.

For transformation of high or low levels into J or K states of the bus, refer to [Table 14-36](#). The J and K states are transformed into bits according to the rules of non-return-to-zero inverted (NRZI) encoding.

Remote command:

[SBUS<sb>:USBone:DPLus:THReshold](#) on page 1793

D- threshold ← Threshold and hysteresis settings

Sets the threshold value for the digitization of the signal on the D- data line.

See also "[D+ threshold](#)" on page 828.

Remote command:

[SBUS<sb>:USBone:DMINus:THReshold](#) on page 1794

D+ hysteresis ← Threshold and hysteresis settings

Sets the hysteresis value for the D+ data line.

Remote command:

[SBUS<sb>:USBone:DPLus:HYSTeresis](#) on page 1794

D- hysteresis ← Threshold and hysteresis settings

Sets the hysteresis value for the D- data line.

Remote command:

[SBUS<sb>:USBone:DMINus:HYSTeresis](#) on page 1794

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.

The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:

[SBUS<sb>:THReshold](#) on page 1325

14.20.2.4 Display settings

Access: "Menu" > "Apps" > "Protocol" tab > "USB 1.1" > "Display" tab




Figure 14-61: Serial bus display configuration dialog for USB 1.1

For details about the display settings, see [Section 14.1.3.1, "Display settings"](#), on page 480.

Decode layer

Selects the decode layer.

Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display.

"Off"	Disables the display of the decode layer.
"Edges"	Enables the display of all edges.
"States"	"Enables the display of J and K states according to Table 14-36 in Section 14.20.1, "USB protocol basics" , on page 820.
"Bits"	Enables the display of the raw, binary encoded symbols, consisting of the states "0" and "1".
"Words"	Enables the display of words, which are the numerical values of the individual fields that compose each packet, like PID, ADDR, DATA or CRC.

14.20.3 USB 1.1 filter

Access: "Menu" > "Apps" > "Protocol" tab > "USB 1.1" > "Filter" tab



In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

- "Check all" Enables the filter for all available frames and error types.
- "Clear" Disables the filter for all available frames and error types.
- "Invert" Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
- "Preset" Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:USBone:FILTer:CHKall](#) on page 1796

[SBUS<sb>:USBone:FILTer:CLR](#) on page 1796

[SBUS<sb>:USBone:FILTer:INVert](#) on page 1796

[SBUS<sb>:USBone:FILTer:RST](#) on page 1796

Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

Available frames are "Data", "Token", "SOF", "Handshake", "Pre/Err" and "Unknown".


Remote command:

[SBUS<sb>:USBone:FILTer:FREnable](#) on page 1797

[SBUS<sb>:USBone:FILTer:FRAME<fr>:ENABLE](#) on page 1797

Edit

Opens a dialog to define the details of the selected frame.



"Field" Enables the field type that you want to filter on for the selected frame. The available fields are "PID", "Data", "CRC5", "CRC16", "Addr", "Endp" and "Frame No.".

Remote command:

[SBUS<sb>:USBone:FILTER:FIENable](#) on page 1800
[SBUS<sb>:USBone:FILTER:FRAME<fr>:FLD<fl>:ENABLE](#)
 on page 1800

"Condition" Displays the value condition for the selected field.

Remote command:

[SBUS<sb>:USBone:FILTER:BIT](#) on page 1800
[SBUS<sb>:USBone:FILTER:FRAME<fr>:FLD<fl>:BIT](#)
 on page 1800

"Value" The data setup consists of a comparison condition and one or two data patterns.

Remote command:

[SBUS<sb>:USBone:FILTER:DMAX](#) on page 1797
[SBUS<sb>:USBone:FILTER:FRAME<fr>:FLD<fl>:DMAX](#)
 on page 1797
[SBUS<sb>:USBone:FILTER:DMIN](#) on page 1797
[SBUS<sb>:USBone:FILTER:FRAME<fr>:FLD<fl>:DMIN](#)
 on page 1797
[SBUS<sb>:USBone:FILTER:DOPerator](#) on page 1798
[SBUS<sb>:USBone:FILTER:FRAME<fr>:FLD<fl>:DOPerator](#)
 on page 1798

"Index"

The index setup consists of a comparison condition and one or two index values.

Remote command:

`SBUS<sb>:USBone:FILTer:IMAX` on page 1798

`SBUS<sb>:USBone:FILTer:FRAME<fr>:FLD<fl>:IMAX` on page 1798

`SBUS<sb>:USBone:FILTer:IMIN` on page 1799

`SBUS<sb>:USBone:FILTer:FRAME<fr>:FLD<fl>:IMIN` on page 1799

`SBUS<sb>:USBone:FILTer:IOperator` on page 1799

`SBUS<sb>:USBone:FILTer:FRAME<fr>:FLD<fl>:IOperator` on page 1799

Error type

Enables filtering on the selected error type.

The available error types are "PID error" (packet identifier), "CRC error" (cyclic redundancy check), "Length error", "Bit stuffing error" and "Incomplete".

Remote command:

`SBUS<sb>:USBone:FILTer:ERENable` on page 1798

`SBUS<sb>:USBone:FILTer:ERRor<n>:ENABle` on page 1798

14.20.4 USB 1.1 trigger

14.20.4.1 Setup A trigger

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.20.4.2 Software trigger setup

Access: "Menu" > "Apps" > "Protocol" tab > "USB 1.1" > "Trigger" > "Setup Software Trigger" tab




Figure 14-62: Serial bus Trigger setup dialog for USB 1.1



Make sure that:

- In the "Trigger" tab (Figure 14-59):
 - The correct protocol type and speed variant are selected.
 - The correct channels are assigned to the corresponding data source of the serial bus.
- In the "Trigger" tab (Figure 14-62):
 - The "Trigger on" = "Sequence"
 - The "Trigger sequence" = "A → Serial bus"
 - The 1st event is set according to your requirements.
- In the "Setup SB Trigger" tab (Figure 14-63):
 - The trigger "Source" is set to the correct serial bus, for example "Serial bus 1".



Figure 14-63: Serial bus Software trigger setup dialog for USB 1.1

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

"Check all"	Enables the software trigger for all available frames and error types.
"Clear"	Disables the software trigger for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:USBone:CHKall](#) on page 1801

[TRIGger:SBSW:USBone:CLR](#) on page 1801

[TRIGger:SBSW:USBone:INVert](#) on page 1801

[TRIGger:SBSW:USBone:RST](#) on page 1802

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frames are available: "Data", "Token", "SOF", "Handshake" and "Pre/Err".


Remote command:

[TRIGger:SBSW:USBone:FRENable](#) on page 1802

[TRIGger:SBSW:USBone:FRAME<fr>:ENABLE](#) on page 1802

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



"Field"	Enables the field type that you want to trigger on for the selected frame. The available fields are "PID", "Data", "CRC5", "CRC16", "Addr", "Endp" and "Frame No.". Remote command: TRIGger:SBSW:USBone:FIENable on page 1804 TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:ENABLE on page 1804
"Condition"	Displays the value condition for the selected field. Remote command: TRIGger:SBSW:USBone:BIT on page 1802 TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:BIT on page 1802
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: TRIGger:SBSW:USBone:DMAX on page 1803 TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:DMAX on page 1803 TRIGger:SBSW:USBone:DMIN on page 1803 TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:DMIN on page 1803 TRIGger:SBSW:USBone:DOPerator on page 1803 TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:DOPerator on page 1803
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: TRIGger:SBSW:USBone:IMAX on page 1804 TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:IMAX on page 1804 TRIGger:SBSW:USBone:IMIN on page 1805 TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:IMIN on page 1805 TRIGger:SBSW:USBone:IOperator on page 1805 TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:IOperator on page 1805

Error type

Enables triggering on the selected error type.

The available error types are "PID error" (packet identifier), "CRC error" (cyclic redundancy check), "Length error" and "Bit stuffing error".

Remote command:

[TRIGger:SBSW:USBone:ERENable](#) on page 1805

[TRIGger:SBSW:USBone:ERRor<m>:ENABLE](#) on page 1805

14.20.5 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.20.6 USB 1.1 decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.
2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.

Decode results table

The "Decode results" table contains information about all decoded frames.




Figure 14-64: Example of a decoded USB 1.1 signal

The decode results table contains information about all decoded frames.

Table 14-38: Content of the decode results table

Column	Description
Index	Index of the decoded frame
State	Overall state of the frame
Start	Times of frame start
Type	Type of the frame
PID name	Name of the packet identifier
PID	Value of the packet identifier
Address	Address of the frame
CRC	CRC value (cyclic redundancy check)
Data	Payload data bytes
Bit rate	Value of the bit rate

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-39: Content of the frame details table

Column	Description
Index	Number of the decoded field
Label	Name of the field
State	State of the field (OK / Not OK)
Value	Value of the field

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- [SBUS<sb>:FORMat](#) on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.21.4, "Decode results"](#), on page 1806.

14.21 USB 2.0 (option R&S MXO5C-K570)

R&S MXO5C-K570 is a firmware option that enables the MXO 5C to analyze Universal Serial Bus (USB) protocols, by triggering and decoding them. The option is compatible with the standards USB 1.0, USB 1.1 and USB 2.0, but not with USB HSIC (High-Speed Inter-Chip, 480 Mbit/s). It supports the data rates "Low Speed" (1.5 Mbit/s) and "Full Speed" (12 Mbit/s), both in USB 1.0 and USB 1.1, and "High Speed" (480 Mbit/s in USB 2.0).

For USB 1.1, refer to [Section 14.20, "USB 1.1 \(option R&S MXO5C-K570\)"](#), on page 820.

• About the USB protocol	838
• USB 2.0 configuration	838
• USB 2.0 filter	842
• USB 2.0 trigger	844
• Measure	848
• USB 2.0 decode results	848

14.21.1 About the USB protocol

Refer to [Section 14.20.1, "USB protocol basics"](#), on page 820 in the [USB 1.1 \(option R&S MXO5C-K570\)](#) section.

14.21.2 USB 2.0 configuration

If you need information on how to get started with configuring the USB 2.0 setup, see [Section 14.21.2.2, "Configuring USB 2.0 signals"](#), on page 840. Otherwise proceed with the configuration settings.

14.21.2.1 USB 2.0 configuration settings

Access: "Menu" > "Apps" > "Protocol" tab > "USB 2.0" > "Setup" tab



Make sure that the tab of the correct serial bus is selected.




Figure 14-65: Serial bus protocol configuration dialog for USB 2.0 HS

See also: [Section 14.1.1, "Setup - general settings"](#), on page 477.

Protocol type

Selects the protocol type to be decoded.

Remote command:

[SBUS<sb>:TYPE](#) on page 1322

State

Enables the decoding of the selected bus. The signal icon of the bus appears on the signal bar.

Remote command:

[SBUS<sb>\[:STATe\]](#) on page 1322

Differential source

Selects the differential signal source of the data line for the USB 2.0 high speed (HS) protocol.

Usually, the source is one of the analog channels. Reference and math waveforms are available as sources if the trigger source is one of the analog channels but not the serial bus.

Remote command:

[SBUS<sb>:USBHspeed:SOURce](#) on page 1814

14.21.2.2 Configuring USB 2.0 signals

For configuration, assign the lines to the input channels and define the active states and the logical thresholds.

For details on configuration settings, see [Section 14.21.2.1, "USB 2.0 configuration settings"](#), on page 838.

Serial Bus Setup

1. Tap the "+ Bus" activator in the bottom right of the screen.
2. Select the tab of the bus that you want to set up, for example "SB1".
3. Tap the "Protocol type" button. Select the protocol: "USB 2.0 HS".
4. Select the waveform for the "Differential" source.
5. In the "Thresholds" tab, specify the upper and lower logical thresholds and the hysteresis.
6. In the "Display" tab, enable "Show decode table".

14.21.2.3 Threshold settings

Access: "Menu" > "Apps" > "Protocol" tab > "USB 2.0" > "Thresholds" tab




Figure 14-66: Serial bus threshold configuration dialog for USB 2.0

Upper threshold

Sets the upper threshold value for the digitization of the data line's differential signal.

For transformation of high or low levels into bus states, refer to [Table 14-36](#). The bus states are transformed into bits according to the rules of non-return-to-zero inverted (NRZI) encoding.

For transformation of high or low levels into J or K states of the bus, refer to [Table 14-36](#). The J and K states are transformed to bits according to the rules of non-return-to-zero inverted (NRZI) encoding.

Remote command:

[SBUS<sb>:USBHspeed:THReshold:UPPer](#) on page 1814

Lower threshold

Sets the lower threshold value for the digitization of the data line's differential signal.

See also ["Upper threshold"](#) on page 840.

Remote command:

[SBUS<sb>:USBHspeed:THReshold:LOWer](#) on page 1815

Hysteresis

Sets the hysteresis value for the data line's differential signal.

Remote command:

[SBUS<sb>:USBHspeed:THReshold:HYSTeresis](#) on page 1815

Show threshold lines

If enabled, the threshold lines are displayed in the diagram.

The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Remote command:

[SBUS<sb>:THReshold](#) on page 1325

14.21.2.4 Display settings

Access: "Menu" > "Apps" > "Protocol" tab > "USB 2.0" > "Display" tab




Figure 14-67: Serial bus display configuration dialog for USB 2.0

Decode layer

Selects the decode layer.


Decoding is performed in several steps, and the results are presented in the decode table. The decode layer selects an interim step for which the decoding result is shown in the honeycomb display.

"Off" Disables the display of the decode layer.

"Edges"	Enables the display of all edges.
"States"	"Enables the display of J and K states according to Table 14-36 in Section 14.20.1 , "USB protocol basics", on page 820.
"Bits"	Enables the display of the raw, binary encoded symbols, consisting of the states "0" and "1".
"Words"	Enables the display of words, which are the numerical values of the individual fields that compose each packet, like PID, ADDR, DATA or CRC.

14.21.3 USB 2.0 filter

Access: "Menu" > "Apps" > "Protocol" tab > "USB 2.0" > "Filter" tab



In the "Filter" tab, you can define the settings to display only the frames that match the selected filter conditions.

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to filter for. Only the frames and error types that match the selected filter conditions are displayed.

"Check all"	Enables the filter for all available frames and error types.
"Clear"	Disables the filter for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types.

Remote command:

[SBUS<sb>:USBHspeed:FILTer:CHKall](#) on page 1816

[SBUS<sb>:USBHspeed:FILTer:CLR](#) on page 1817

[SBUS<sb>:USBHspeed:FILTer:INVert](#) on page 1817

[SBUS<sb>:USBHspeed:FILTer:RST](#) on page 1817

Frame type

Selects the frame type that you want to display. You can filter all enabled frame types simultaneously.

For selected frame types, you can also specify conditions for the value of the fields in the "Edit" dialog.

Available frames are "Data", "Token", "SOF", "Handshake", "Split", "Ping", "Pre/Err", "Reserved" and "Unknown".


Remote command:

[SBUS<sb>:USBHspeed:FILTer:FREnable](#) on page 1817

[SBUS<sb>:USBHspeed:FILTer:FRAME<fr>:ENABLE](#) on page 1817

Edit

Opens a dialog to define the details of the selected frame.



"Field"

Enables the field type that you want to filter on for the selected frame. The available fields are "PID", "Data", "CRC5", "CRC16", "Addr", "Endp", "SC", "Port", "S", "E/U", "ET" and "Frame No.".

Remote command:

[SBUS<sb>:USBHspeed:FILTer:FIENable](#) on page 1821

[SBUS<sb>:USBHspeed:FILTer:FRAME<fr>:FLD<fl>:ENABLE](#) on page 1821

"Condition"	Displays the value condition for the selected field. Remote command: SBUS<sb>:USBHspeed:FILTer:BIT on page 1820 SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:BIT on page 1820
"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: SBUS<sb>:USBHspeed:FILTer:DMAX on page 1818 SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:DMAX on page 1818 SBUS<sb>:USBHspeed:FILTer:DMIN on page 1818 SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:DMIN on page 1818 SBUS<sb>:USBHspeed:FILTer:DOPerator on page 1818 SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:DOPerator on page 1818
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: SBUS<sb>:USBHspeed:FILTer:IMAX on page 1819 SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:IMAX on page 1819 SBUS<sb>:USBHspeed:FILTer:IMIN on page 1820 SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:IMIN on page 1820 SBUS<sb>:USBHspeed:FILTer:IOPerator on page 1820 SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:IOPerator on page 1820

Error type

Enables filtering on the selected error type.

The available error types are "PID error" (packet identifier), "CRC error" (cyclic redundancy check), "Length error", "Bit stuffing error" and "Incomplete".

Remote command:

[SBUS<sb>:USBHspeed:FILTer:ERENable](#) on page 1819
[SBUS<sb>:USBHspeed:FILTer:ERRor<n>:ENABLe](#) on page 1819

14.21.4 USB 2.0 trigger**14.21.4.1 Setup A trigger**

Before setting up the software trigger for the protocols, a trigger A event needs to be set up.

14.21.4.2 Software trigger setup

Access: "Menu" > "Apps" > "Protocol" tab > "USB 2.0" > "Trigger" > "Setup Software Trigger" tab




Figure 14-68: Serial bus Trigger setup dialog for USB 2.0



Make sure that:

- In the "Trigger" tab (Figure 14-65):
 - The correct protocol type is selected.
 - The correct channels are assigned to the corresponding data source of the serial bus.
- In the "Trigger" tab (Figure 14-68):
 - The "Trigger on" = "Sequence"
 - The "Trigger sequence" = "A → Serial bus"
 - The 1st event is set according to your requirements.
- In the "Setup SB Trigger" tab (Figure 14-69):
 - The trigger "Source" is set to the correct serial bus, for example "Serial bus 1".



Figure 14-69: Serial bus Software trigger setup dialog for USB 2.0

Check all, Clear, Invert, Preset

The following settings help you select the frames and errors you want to trigger on.

"Check all"	Enables the software trigger for all available frames and error types.
"Clear"	Disables the software trigger for all available frames and error types.
"Invert"	Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.
"Preset"	Presets the state of the selected frames and error types for the software trigger.

Remote command:

[TRIGger:SBSW:USBHspeed:CHKall](#) on page 1822

[TRIGger:SBSW:USBHspeed:CLR](#) on page 1822

[TRIGger:SBSW:USBHspeed:INVert](#) on page 1822

[TRIGger:SBSW:USBHspeed:RST](#) on page 1822

Frame type

Selects the frame type that you want to trigger on. You can trigger on all enabled frame types simultaneously.

For each frame type, you can also specify conditions for the value of the fields in the "Edit" dialog.

The following frames are available: "Data", "Token", "SOF", "Handshake", "Split", "Ping", "Pre/Err" and "Reserved".


Remote command:

[TRIGger:SBSW:USBHspeed:FREnable](#) on page 1823

[TRIGger:SBSW:USBHspeed:FRAME<fr>:ENABLE](#) on page 1823

Edit

Some trigger types have additional settings that can be defined. In this case, the "Set details" button appears next to "Type" the function. Open it for a detailed definition of the trigger conditions.



"Field" Enables the field type that you want to trigger on for the selected frame.
The available fields are "PID", "Data", "CRC5", "CRC16", "Addr", "Endp", "SC", "Port", "S", "E/U", "ET" and "Frame No.".

Remote command:

[TRIGger:SBSW:USBHspeed:FIENable](#) on page 1824

[TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:ENABLE](#) on page 1824

"Condition" Displays the value condition for the selected field.

Remote command:

[TRIGger:SBSW:USBHspeed:BIT](#) on page 1823

[TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:BIT](#) on page 1823

"Value"	The data setup consists of a comparison condition and one or two data patterns. Remote command: TRIGger:SBSW:USBHspeed:DMAX on page 1823 TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:DMAX on page 1823 TRIGger:SBSW:USBHspeed:DMIN on page 1824 TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:DMIN on page 1824 TRIGger:SBSW:USBHspeed:DOPerator on page 1824 TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:DOPerator on page 1824
"Index"	The index setup consists of a comparison condition and one or two index values. Remote command: TRIGger:SBSW:USBHspeed:IMAX on page 1825 TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:IMAX on page 1825 TRIGger:SBSW:USBHspeed:IMIN on page 1825 TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:IMIN on page 1825 TRIGger:SBSW:USBHspeed:IOperator on page 1826 TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:IOperator on page 1826

Error type

Enables triggering on the selected error type.

The available error types are "PID error" (packet identifier), "CRC error" (cyclic redundancy check), "Length error" and "Bit stuffing error".

Remote command:

[TRIGger:SBSW:USBHspeed:ERENable](#) on page 1826

[TRIGger:SBSW:USBHspeed:ERRor<m>:ENABle](#) on page 1826

14.21.5 Measure

The "Setup Measurement" button opens the dialog for automatic measurements in the "Protocol" category for the selected serial bus.

See [Section 10.2.8.2, "Settings for protocol measurements"](#), on page 301.

14.21.6 USB 2.0 decode results

When the configuration of the serial bus is complete, the signal can be decoded:

1. Open the "Serial Bus" dialog for the respective bus.

2. In the "Setup" tab, enable "State".
3. In the "Display" tab, enable "Show decode table".

For a description of the display settings, see also [Section 14.1.3.1, "Display settings"](#), on page 480.

For a description of how to synchronize the displayed results, see [Section 14.1.3.2, "Display synchronization"](#), on page 482.

The instrument captures and decodes the signal according to the standard definition and the configuration settings.

The color-coding of the various protocol sections and errors simplifies the interpretation of the visual display. The decode information condenses or expands, depending on the horizontal scale. Various data formats are available to show the result values.

Decode results table

The "Decode results" table contains information about all decoded frames.




Figure 14-70: Example of a decoded USB 2.0 signal

The decode results table contains information about all decoded frames.

Table 14-40: Content of the decode results table

Column	Description
Index	Index of the decoded frame
State	Overall state of the frame
Start	Times of frame start
Type	Type of the frame
PID name	Name of the packet identifier

Column	Description
PID	Value of the packet identifier
Address	Address of the frame
CRC	CRC value (cyclic redundancy check)
Data	Payload data bytes
Bit rate	Value of the bit rate

When you select a frame in the decode results table, its field content is shown in the details table to the right.

Table 14-41: Content of the frame details table

Column	Description
Index	Number of the decoded field
Label	Name of the field
State	State of the field (OK / Not OK)
Value	Value of the field

Data format

You can select various data formats for the values displayed in the decode table and in the combs of the decoded signal.

Remote command:

- [SBUS<sb>:FORMat](#) on page 1323

Remote commands

Remote commands to retrieve decode results are described in [Section 18.18.22, "USB 2.0 \(option R&S MXO5C-K570\)"](#), on page 1814.

15 Logic analysis on digital channels

The Mixed Signal Option R&S MXO5C-B1 adds logic analyzer functions to the classical oscilloscope functions. Using the MSO option, you can analyze and debug embedded systems with mixed-signal designs that use analog signals and correlated digital signals simultaneously.

The Mixed Signal Option provides 16 digital channels grouped in two logic probes (pods) with 8 channels each. The instrument ensures that analog and digital waveforms are time-aligned and synchronized so that critical timing interactions between analog and digital signals can be displayed and tested. The automatic alignment compensates the skew between the probe connectors of the analog channels and the probe boxes of the digital channels.

Trigger

You can trigger on digital channels. Digital channels are available as trigger source if you trigger on single events, but not in any trigger sequence. The level is the threshold of the digital signal, which is configured in "Logic" > "Setup". All other trigger settings are configured in the "Trigger" dialog.

The following trigger types are available for digital trigger sources:

- Edge
- Width
- Timeout
- State
- Pattern

Data export

You can export the data of digital channels to waveform files, and you can use remote commands to retrieve and transmit digital data for further analysis.

15.1 Logic configuration

Access: "Menu" > "Logic" > "Setup" tab

You can display digital channels individually, and you can group them and display as a logic group. 4 logic groups are available. Each digital channel can be assigned to one *active* logic only. Conflicting buses are disabled automatically.


For clocked buses, you can display the decoded data in a result box.



If you have configured several logic groups and you want to modify the settings, make sure that the tab of the correct logic is selected. Disable the logic before you change the settings.

15.1.1 Setup

Access: "Menu" > "Logic" > "Setup" tab



State

Enables the selected logic group. The corresponding signal icon appears on the signal bar.

If another active bus already uses the same digital channel, the instrument disables the other bus and shows a message.

Remote command:

[PBUS<pb>:STATe](#) on page 1847

Show dig. signals

If enabled, the selected digital channels are shown in the diagram. Each channel is displayed as a logic signal.


Remote command:

[PBUS<pb>:DISPlay:SHDI](#) on page 1845

Technology, Threshold

Sets the logical threshold. For each sample, the instrument compares the input voltage with the threshold value. If the input voltage is above the threshold, the signal state "1" is stored. Otherwise, the signal state "0" is stored if the input voltage is below the threshold.

To avoid the change of signal states due to noise, a hysteresis is considered.



By default, the same threshold and hysteresis value are used for all digital channels and all logic buses: "Couple thresholds" is enabled.

You can also set different thresholds for the individual channel groups. As long as the buses are disabled, you can set different thresholds for each bus. Active buses use the same threshold and hysteresis values, the settings of the last activated bus take effect.

The range of threshold levels and the minimum voltage swing is given in the specifications document.

"Threshold" Enter the value directly in the field.

"Technology" Selects the threshold voltage for various types of integrated circuits from a list and applies it to all digital channels. The value is set to "Manual" if a user-defined threshold was entered directly.

Remote command:

[PBUS<pb>:TECHnology](#) on page 1847

[PBUS<pb>:THReshold<n>](#) on page 1848

Active logic channel

Set the state of the individual digital channels.

Enable/Disable D7-D0,D15-D8

The buttons select or deselect all digital channels of a pod at once.

Advanced

Opens a dialog for advanced threshold and hysteresis settings. You can define them in addition to the "Threshold" and "Technology".

Level coupling ← Advanced

Sets the threshold and the hysteresis for all digital channels and all buses to the same value.

If level coupling is off, you can set the thresholds individually for the channel groups D0 to D3, D4 to D7, D8 to D11 and D12 to D15 in the "Setup" tab. The hysteresis for each channel group is set in the "Advanced" dialog.

Remote command:

[PBUS<pb>:THCoupling](#) on page 1847

Hysteresis ← Advanced

Defines the size of the hysteresis for the respective channels.


"Small"	The instrument sets a small value suitable for the signal and its settings. Use this setting for clean signals.
"Medium"	The instrument sets the maximum value that is possible and useful for the signal and its settings. Use this setting for noisy signals.
"Large"	Sets different hysteresis values for falling and rising edges to avoid an undefined state of the trigger system. Use this setting for very noisy signals.

Remote command:

[PBUS<pb>:HYSTeresis<n>](#) on page 1845

15.1.2 Bus

Access: "Menu" > "Logic" > "Bus" tab



Show bus

If enabled, the resulting bus signal and bus values are displayed in the diagram.

Remote command:

[PBUS<pb>:DISPlay:SHBU](#) on page 1844

Data format

Sets the data format of bus values, which are displayed in the decode table and on the comb bus display.

Available formats are: Hex, octal, binary, ASCII, string, signed, unsigned, symbolic, and auto.

Signed and Unsigned are integer data types with a maximum 16-bit length. Unsigned is used for positive integers. Signed is used for positive and negative integers.

If the target file format is BIN, you can save only signed and unsigned binary data. The data format "Signed" writes signed data; all other formats are saved as unsigned binary data.

Remote command:

[PBUS<pb>:DATA:FORMat](#) on page 1850

[PBUS<pb>:DATA:HEADer?](#) on page 1851

[PBUS<pb>:DATA\[:VALues\]?](#) on page 1851

Clocked bus

If a bus is a clocked bus, one of the digital channels serves as the clock of the bus.

For an unclocked bus, the logical state of the bus is determined for each sample. For a clocked bus, the logical state is determined only at the specified clock edges.

Bus clocked ← Clocked bus

Enable this option for a clocked bus.

Remote command:

[PBUS<pb>:CLON](#) on page 1842

Show decode table ← Clocked bus

If enabled, a result table is shown with decoded values and corresponding points in time of the bus signal. Each clock edge corresponds to one row in the table.

The decode table is only available for clocked buses to check the data words.

Remote command:

[PBUS<pb>:DECTable:SHOW](#) on page 1843

[PBUS<pb>:DECTable:COUNT?](#) on page 1843

[PBUS<pb>:DECTable:DATA?](#) on page 1844

Clock source ← Clocked bus

Selects the digital channel used as clock.

Remote command:

[PBUS<pb>:CLOCK](#) on page 1842

Clock slope ← Clocked bus


Selects the slope of the clock signal at which all digital channels of the bus are analyzed.

Remote command:

[PBUS<pb>:CLSLope](#) on page 1843

15.1.3 Label settings

Access: "Menu" > "Logic" > "Label" tab



In this tab, you can enter a name for each digital channel. The name is displayed in the diagram.

`PBUS<pb>:BIT<n>:LAbel` on page 1841

15.1.4 Skew settings

Access: "Menu" > "Logic" > "Skew" tab

L1	L2	L3	L4	
Setup	D0	0 s		
	D1	0 s		
Bus	D2	0 s		
	D3	0 s		
Label	D4	0 s		
	D5	0 s		
Skew	D6	0 s		
	D7	0 s	Skew	
	D8	0 s		0 s
	D9	0 s		
	D10	0 s		
	D11	0 s		
	D12	0 s		
	D13	0 s		
	D14	0 s		
	D15	0 s		

D0-D15

Sets an individual delay for each digital channel to time-align it with other digital channels.

The skew value compensates delays that are known from the circuit specifics or caused by the different length of cables. The skew between the probe boxes of the digital channels and the probe connectors of the analog channels is automatically aligned by the instrument.

Remote command:

[PBUS<pb>:BIT<n>:SKEW](#) on page 1841

Skew

Sets a general delay for all digital channels.

Remote command:

[PBUS<pb>:SKEW](#) on page 1846

15.2 Display

Each logic group is shown in a separate diagram, and the diagrams can be minimized and arranged as usual.

L1			
D15	D14	D13	D12
D11	D10	D9	D8
D7	D6	D5	D4
D3	D2	D1	D0

You can adjust the display of the logic bus signals and the individual digital channels to optimize the analysis of bus data:

- Select the digital channels to be displayed.
Drag the logic signals and the digital channels to the optimal position.
- Adjust the size and position of the logic signal: Tap the Lx signal or its signal icon, and use the [Position] and [Scale] knobs.
- Adjust the size and position of active digital channels: Tap one of the Dx signals, and use the [Position] and [Scale] knobs.
- Show the result table of the decoded clocked bus signal.

Remote commands:

- [PBUS<pb>:DIGSignals:POSition](#) on page 1844
- [PBUS<pb>:DIGSignals:SCALE](#) on page 1844
- [PBUS<pb>:POSition](#) on page 1846
- [PBUS<pb>:SCALE](#) on page 1846

To access and analyze one or more specific acquisitions, you can use the "History" in the common way.

Furthermore, you can zoom in digital signals and bus signal in the same way as in analog waveforms.

15.2.1 Logic bus - decode table

Decoding is available for clocked buses.

The decode table shows the decoded data words of the bus signal and the corresponding time. Each clock edge corresponds to one row in the table. Beside the table, you can select the data format of the bus values.

Result	Time	Value	Data format
			Binary

The results can be saved to a `.csv` or `.html` file.

16 Waveform generator (option R&S MXO5C-B6)

The MXO 5C includes a two-channel 100 MHz waveform generator. Each waveform generator can output simple functions, modulated sine waveform, arbitrary waveforms and sweep waveforms. It is possible to couple and synchronize the settings of the waveform generators.

The instrument preset does not affect the generator settings. Each generator has its own preset ("Default setup"). When the instrument is shut down, the waveform generator settings are stored. At the instrument start, these settings are restored but the generators are switched off. When a saveset of instrument settings is recalled, generators are also switched off but the generator settings remain unchanged.


If you often switch on and off a generator, add a generator icon to the toolbar ("Gen1", "Gen2"). Tap the icon to switch on or off the generator.

16.1 Setup of the waveform generator

Access: "Gen" signal activator > "Gen"1 or "Gen"2 > "Setup" tab.

16.1.1 General settings

The "Setup" tab provides general settings like enabling the waveform generator, and setting that depend on the selected function type.

**State**

Enables the function generator.

If you often switch on and off a generator, use the generator icon on the toolbar ("Gen1", "Gen2").

Remote command:

[WGGenerator<wg>\[:ENABLE\]](#) on page 1858

Inversion

Inverts the waveform at the offset level.

Remote command:

[WGGenerator<wg>:VOLTage:INVersion](#) on page 1856

Function type

Selects the type of waveform to be generated.

For all waveforms, you can set:

- [Frequency](#)
- [Amplitude](#)
- [Offset](#)
- [Noise level in %](#) or [DC level](#)
- [User load](#)

"Sine"	Generates a sine wave. Modulation settings and Sweep settings are available.
"Square"	Generates a square wave. You can set the Duty cycle . Modulation settings is available.
"Ramp"	Generates a ramp signal. You can set the Symmetry .
"DC"	Generates a direct current (DC) signal. You can set the DC level .
"Pulse"	Generates a pulse signal. Additional settings are the Period and the Pulse width . Modulation settings is available.
"Cardinal sine"	Generates a cardinal sine wave. No additional settings are needed.
"Cardiac"	Generates a cardiac signal. No additional settings are needed.
"Gauss"	Generates a Gaussian signal. No additional settings are needed.
"Lorentz"	Generates a Lorentz signal. No additional settings are needed.
"Haversine"	Generates a haversine function signal (great-circle distance between two points on a sphere). No additional settings are needed.
"Exp. rise"	Generates an exponential rise signal. No additional settings are needed.
"Exp. fall"	Generates an exponential fall signal. No additional settings are needed.
"Arbitrary"	Generates an arbitrary waveform, which is copied from an existing waveform, or loaded from a file. See Section 16.1.4, "Arbitrary waveforms" , on page 867.

Remote command:

`WGEnerator<wg>:FUNCTION[:SElect]` on page 1854

Frequency

Sets the frequency of the waveform.

The available frequency range depends on the selected "Function type", see [Frequency range of the function generator waveforms](#).

Table 16-1: Frequency range of the function generator waveforms

"Function type"	Min frequency	Max frequency
"Sine"	0.001 Hz	100 MHz
"Square"	0.001 Hz	30 MHz
"Ramp"	0.001 Hz	1 MHz
"DC"	-	-
"Pulse"	0.001 Hz	30 MHz
"Cardinal sine"	0.001 Hz	5 MHz
"Cardiac"	0.001 Hz	1 MHz
"Gauss"	0.001 Hz	25 MHz
"Lorentz"	0.001 Hz	10 MHz

"Function type"	Min frequency	Max frequency
"Haversine"	0.001 Hz	100 MHz
"Exp. rise"	0.001 Hz	10 MHz
"Ep. fall"	0.001 Hz	10 MHz

Remote command:

[WGNErator<wg>:FREQuency](#) on page 1853

Amplitude

Sets the amplitude of the waveform.

Remote command:

[WGNErator<wg>:VOLTagE\[:VPP\]](#) on page 1857

Offset

Sets the vertical offset of the generated waveform.

Remote command:

[WGNErator<wg>:VOLTagE:OFFSet](#) on page 1857

Arbitrary Setup

Opens a menu to configure the arbitrary waveform.

See [Section 16.1.4, "Arbitrary waveforms"](#), on page 867.

Sweep

Opens a menu to configure the sweep.

See [Section 16.1.3, "Sweep settings"](#), on page 866.

Modulation

Opens a menu to configure the modulation.

See [Section 16.1.2, "Modulation settings"](#), on page 864.

Noise level in %

Sets the level of the noise in percentage of the set "Amplitude" output of the signal.

Remote command:

[WGNErator<wg>:MODulation:NLPCent](#) on page 1863

User load

Select the user load, the load of the DUT at its connection.

You can select either a "50Ω" or a "High-Z" (high input impedance) load.

Remote command:

[WGNErator<wg>:OUTPut\[:LOAD\]](#) on page 1854

Symmetry

Sets the symmetry of a ramp waveform, the percentage of time the waveform is rising. By changing the symmetry of the ramp, you can create, for example, triangular waveforms.

50% defines symmetric triangles. Values <50% define triangles with a steeper rising edge leaned to the left. Values >50% define triangles with a steeper falling edge leaned to the right.

Remote command:

[WGGenerator<wg>:FUNCTION:RAMP\[:SYMMetry\]](#) on page 1853

Duty cycle

Sets the duty cycle for the pulse function.

The duty cycle expresses for what percentage of the period, the signal state is high.

Remote command:

[WGGenerator<wg>:FUNCTION\[:SQUare\]:DCYCLE](#) on page 1854

Pulse width

Sets the pulse width, the pulse duration of the generated pulse waveform.

Remote command:

[WGGenerator<wg>:FUNCTION:PULSe\[:WIDTh\]](#) on page 1853

Default setup

Presets the generator to a default setup. The default includes the following settings:

- "Function type" = "Sine"
- "Frequency" = "1 MHz"
- "Amplitude" = "1 Vpp"

Remote command:

[WGGenerator<wg>:PRESet](#) on page 1855

DC level

Available for "Function type" = "DC".

Sets the level for the DC signal.

Remote command:

[WGGenerator<wg>:VOLTage:DCLevel](#) on page 1856

Noise level for DC

Available for "Function type" = "DC".

Sets the level of the noise for the DC signal.

Remote command:

[WGGenerator<wg>:MODulation:NDCLevel](#) on page 1863

Period

Available for "Function type" = "Pulse".

Sets the period of the pulse waveform.

Remote command:

[WGGenerator<wg>:PERiod](#) on page 1855

16.1.2 Modulation settings

Modulation is available only for sine and square waveforms.

Access: "Gen" signal activator > "Gen"1 or "Gen"2 > "Setup" tab > "Function type" = "Sine" or "Square" > "Modulation".




Figure 16-1: Modulation setup

Modulation state

Enables or disables modulation.

Modulation is available only for "Function type" = "Sine"/"Square".

Remote command:

[WGEnerator<wg>:MODulation\[:STATe\]](#) on page 1858

Modulation type

Selects the modulation type, which defines how the carrier signal is modified.

"AM"	Amplitude modulation. The amplitude of the carrier signal is varied according to the modulation signal. Available for "Function type" = "Sine".
"FM"	Frequency modulation. The frequency of the carrier signal is varied according to the modulation signal. Available for "Function type" = "Sine".
"PWM"	Pulse width modulation. The time for which the signal is in a high state is varied according to the modulation signal. Available for "Function type" = "Square".
"FSK"	Frequency shift keying (FSK) modulation. The signal frequency switches between "Frequency 1" and "Frequency 2" at a "FSK rate". Available for "Function type" = "Sine".

Remote command:

[WGEnerator<wg>:MODulation:TYPE](#) on page 1865

Signal type

Selects the type of the modulating signal for AM, FM or PWM modulation.

Remote command:

[WGENerator<wg>:MODulation:AM\[:FUNCTION\]](#) on page 1860

[WGENerator<wg>:MODulation:FM\[:FUNCTION\]](#) on page 1862

[WGENerator<wg>:MODulation:PWM\[:FUNCTION\]](#) on page 1865

Frequency

Sets the frequency of the modulating waveform for AM/FM/PWM modulation.

Remote command:

[WGENerator<wg>:MODulation:AM:FREQuency](#) on page 1859

[WGENerator<wg>:MODulation:FM:FREQuency](#) on page 1861

[WGENerator<wg>:MODulation:PWM:FREQuency](#) on page 1864

Depth

Sets the modulation depth, the percentage of the amplitude range that is used for AM modulation.

Remote command:

[WGENerator<wg>:MODulation:AM:DEPTH](#) on page 1859

Duty cycle

Sets the duty cycle for a square waveform. The duty cycle expresses for what percentage fraction of the period, the waveform is active, i.e. the signal state is high.

Remote command:

[WGENerator<wg>:MODulation:AM:DCYCLE](#) on page 1859

[WGENerator<wg>:MODulation:FM:DCYCLE](#) on page 1861

[WGENerator<wg>:MODulation:PWM:DCYCLE](#) on page 1864

Symmetry

Sets the symmetry for the ramp modulation waveform, the percentage of time that the waveform is rising.

Remote command:

[WGENerator<wg>:MODulation:AM:SYMMetry](#) on page 1860

[WGENerator<wg>:MODulation:FM:SYMMetry](#) on page 1862

[WGENerator<wg>:MODulation:PWM:SYMMetry](#) on page 1865

Deviation

Sets the frequency deviation, the maximum difference between the FM modulated signal and the carrier signal.

Remote command:

[WGENerator<wg>:MODulation:FM:DEVIation](#) on page 1861

Modulation depth

Sets the modulation depth, the percentage of the amplitude range that is used for PWM modulation.

Remote command:

[WGENerator<wg>:MODulation:PWM:DEPTH](#) on page 1864

Frequency 1/Frequency 2

Sets the frequency of the first /second signal in FSK modulated signal.

Remote command:

[WGENerator<wg>:MODulation:FSK:FONE](#) on page 1862

[WGENerator<wg>:MODulation:FSK:FTWO](#) on page 1862

FSK rate

Sets the frequency at which signal switches between "Frequency 1" and "Frequency 2".

Remote command:

[WGENerator<wg>:MODulation:FSK\[:RATE\]](#) on page 1863

16.1.3 Sweep settings

Sweep is available only for sine waveforms.

Access: "Gen" signal activator > "Gen1" or "Gen2" > "Setup" tab > "Function type" = "Sine" > "Sweep".




Figure 16-2: Sweep setup

In the sweep mode, the MXO 5C generates a signal whose frequency gradually changes from the "Start frequency" to the "Stop frequency" for a certain "Sweep time".

For a step-by-step description of the sweep setup, see [Section 16.3.3, "Configuring a sine sweep waveform"](#), on page 874.

Sweep state

Enables or disables the sweeping.

Remote command:

[WGENerator<wg>:SWEep\[:STATe\]](#) on page 1868

Sweep type

Sets the type of the sweep, a linear or logarithmic change of the frequency.

Remote command:

`WGENerator<wg>:SWEep:TYPE` on page 1868

Start frequency

Sets the start frequency of the sweep signal.

Remote command:

`WGENerator<wg>:SWEep:FStart` on page 1869

Stop frequency

Sets the stop frequency of the sweep signal.

Remote command:

`WGENerator<wg>:SWEep:FEND` on page 1869

Sweep time

Sets the duration of the sweep.

Remote command:

`WGENerator<wg>:SWEep:TIME` on page 1869

16.1.4 Arbitrary waveforms

The arbitrary waveform generator allows you to output a user-defined waveform for testing your devices. An arbitrary waveform is loaded from a file. You can load CSV files that follow a defined structure, or saved reference waveforms.

See also: [Section 16.3.4, "Configuring an arbitrary waveform"](#), on page 874.

16.1.4.1 Arbitrary waveform files

You can load CSV files that have a Rohde & Schwarz WaveGen format.

Content and format of the Rohde & Schwarz arbitrary waveform CSV files

The waveform generator format can contain the following values:

- Rate
- Time value
- Voltage value

If all the values are defined, the file format is as follows:

```
Rate 5000000           //Sample rate of the arbitrary waveform.
0.000000E+000,-5.995   //Time value 1, Voltage value 1
1.237011E-005,-6.0     //Time value 2, Voltage value 2
.....
```

In this case, the rate is reflected in the "Sample Rate" field of the user interface. The total number of Time/Voltage values is reflected in the "Samples" of the user interface. Anything written after // is ignored as a comment.

You can define only some of the values. According to what you define, the file format looks different and is handled differently:

- With specified *Rate*:
Time values are ignored. You can specify just rate and voltage values as below:

```
Rate 5000000           //Sample rate of the arbitrary waveform
-5.995                //Voltage value 1
-6.0                  //Voltage value 2
.....
```

- Without specified *Rate* and without specified *Time* values:
The last user-defined sample rate is used to calculate the waveform. You can change the "Sample rate" in the user interface. The voltage values are then played with this sample rate.

```
-5.995                //Voltage value 1
-6.0                  //Voltage value 2
.....
```

- Without specified *Rate* and with specified *Time*:
The timing information of the first 2 time values is used to calculate the sample rate.

Example:

Consider the following file:

```
0.000000E+000,-5.995 //Time value 1, Voltage value 1
1.237011E-005,-6.0  //Time value 2, Voltage value 2
```

The sample rate is:


$\text{Sample rate} = 1 / \text{Time between first two samples} = 1 / 1.237011\text{E-}005 = 80.840\text{KSample/sec}$

16.1.4.2 Arbitrary settings

Access: "Gen" signal activator> "Gen1" or "Gen2" > "Setup" tab > "Function type" = "Arbitrary"

Access: "Gen" signal activator > "Gen"1 or "Gen"2 > "Setup" tab > "Function type" = "Arbitrary".

The following settings in the "Setup" tab and the "Arbitrary Setup" dialog are specific for generated arbitrary waveforms.



Run mode	869
Run single	869
Arbitrary Setup	869
Arb wfm source	870
Sample rate	870
Number of samples	870
Open	870

Run mode

Selects the duration for which the signal of the arbitrary generator is output after the trigger event. You can choose between a "Continuous" and "Single period" duration.

Remote command:

[WGEnerator<wg>:ARBGen:RUNMode](#) on page 1866

Run single

Generates a single period of the arbitrary waveform if "Run mode" is set to "Single period".


If you load the arbitrary waveform from a file, first load the file, and then connect the DUT. See also: ["Open"](#) on page 870.

Remote command:

[WGEnerator<wg>:ARBGen:RUNSingle](#) on page 1867

Arbitrary Setup

Opens a dialog to define the arbitrary waveform.

**Arb wfm source**

Selects the source of the arbitrary waveform.

You can load CSV files that follow a defined structure, or saved reference waveforms.

Remote command:

[WGEnerator<wg>:ARBGen\[:SOURce\]](#) on page 1868

Sample rate

Sets the sample rate for the arbitrary waveform.

If the sample rate is given in the arbitrary waveform file (CSV or REF file), the instrument displays the value here, and you can change it. If no sample rate is available in the data, you can set the required sample rate.

Remote command:

[WGEnerator<wg>:ARBGen:SRATe](#) on page 1867

Number of samples

Displays the number of samples in the loaded waveform.

Remote command:

[WGEnerator<wg>:ARBGen:SAMPles?](#) on page 1867

Open

Opens a dialog to select the saved waveform, and loads the file. The setting is available if "Arb wfm source" is set to "Saved waveform".

You can load CSV files, or REF waveforms (saved reference waveforms). See also: [Section 16.1.4.1, "Arbitrary waveform files"](#), on page 867.

When the file is loaded, the output voltage is set to the value of the first sample in the file. Therefore, if you want to output single periods of the arbitrary waveform, first load the waveform file, and then connect the DUT.


Remote command:

[WGEnerator<wg>:ARBGen:NAME](#) on page 1866

[WGEnerator<wg>:ARBGen:OPEN](#) on page 1866

16.2 Synchronize settings

Access: "Menu" > "Apps" > "Gen1" > "Synchronisation" tab.



Synchron start

Selects, which signals generated from the waveform generator are synchronized.

Selecting one of the sync options indicates that the first samples of those signals are generated at the same time, irrespective of if the generators are on or off. Selecting one of the coupling options automatically syncs the signals generated by the two waveform generators.

Remote command:

[GENerator:SYNC\[:COMBination\]](#) on page 1871

Phase Gen1 - Gen2

Sets the phase shift between the waveform of Gen1 and Gen2 when the frequency parameters of the two waveforms are coupled.

Remote command:

[WGENerator<wg>:COUpling:PHASeshift](#) on page 1871

Generator enable

Enables the coupling of the generators, with the selected set of parameters: amplitude and frequency.

Remote command:

[WGENerator<wg>:COUpling:STATe](#) on page 1870

Frequency parameters

Couples all frequency parameters of "Gen1" and "Gen2". The values are taken from the currently selected generator.

You can still change the other settings of the generators independently.

Remote command:

[WGENerator<wg>:COUPling:AMPLitude](#) on page 1870

Amplitude parameters

Couples all amplitude parameters of "Gen1" and "Gen2" including the load. The values are taken from the currently selected generator.

Remote command:

[WGENerator<wg>:COUPling\[:FREQuency\]](#) on page 1871

16.3 Configuring the waveform generator

This section explains step by step how to configure the waveform generator.

- [Configuring a function waveform](#).....872
- [Configuring a modulation waveform](#).....872
- [Configuring a sine sweep waveform](#).....874
- [Configuring an arbitrary waveform](#).....874

16.3.1 Configuring a function waveform

1. Tap the "Gen" signal activator.
2. Select the tab of the generator that you want to configure: "Gen"1 or "Gen"2.
3. In the "Setup" tab, select the "Function type" that you want to generate, e.g. "Sine".
4. Depending on the selected "Function type", configure the settings of the waveform like "Frequency" and "Amplitude".
5. If necessary, change the "User load" settings, or add "Noise level in %" to the waveform.
6. Set "State" = "On" to output the waveform at the output connector of the waveform generator.

16.3.2 Configuring a modulation waveform

Generating an AM modulated waveform

1. Tap the "Gen" signal activator.
2. Select the tab of the generator that you want to configure: "Gen"1 or "Gen"2.
3. In the "Setup" tab, set the "Function type" = "Sine".
4. Press "Modulation" to open the modulation dialog.
5. Set "Modulation type" = "AM".

6. Set the "Carrier frequency" and the "Carrier period".
7. Tap "Modulation signal", and select the required waveform.
8. Depending on the selected "Modulation signal", configure the settings of the waveform like "Modulation freq" and "Modulation depth".
9. Set "Modulation state" = "On" to enable the modulation.
10. Press "Back" to return to the "Setup" tab.
11. Set "State" = "On" to output the waveform at the output connector of the waveform generator.

Generating an FM modulated waveform

1. Tap the "Gen" signal activator.
2. Select the tab of the generator that you want to configure: "Gen"1 or "Gen"2.
3. In the "Setup" tab, set the "Function type" = "Sine".
4. Press "Modulation" to open the modulation dialog.
5. Set "Modulation type" = "FM".
6. Select the "Signal type".
7. Set the "Frequency" and the "Deviation".
8. Set "Modulation state" = "On" to enable the modulation.
9. Press "Back" to return to the "Setup" tab.
10. Set "State" = "On" to output the waveform at the output connector of the waveform generator.

Generating an FSK modulated waveform

1. Tap the "Gen" signal activator.
2. Select the tab of the generator that you want to configure: "Gen"1 or "Gen"2.
3. In the "Setup" tab, set the "Function type" = "Sine".
4. Press "Modulation" to open the modulation dialog.
5. Set "Modulation type" = "FSK".
6. Set the "Frequency 1", "Frequency 2" and the "FSK rate".
7. Set "Modulation state" = "On" to enable the modulation.
8. Press "Back" to return to the "Setup" tab.
9. Set "State" = "On" to output the waveform at the output connector of the waveform generator.

Generating a PWM modulated waveform

1. Tap the "Gen" signal activator.
2. Select the tab of the generator that you want to configure: "Gen"1 or "Gen"2.
3. In the "Setup" tab, set the "Function type" = "Square".
4. Press "Modulation" to open the modulation dialog.
5. Set "Modulation type" = "PWM".
6. Tap "Signal type", and select the required waveform.
7. Configure the settings of the waveform like "Frequency" and "Modulation depth".
8. Set "Modulation state" = "On" to enable the modulation.
9. Press "Back" to return to the "Setup" tab.
10. Set "State" = "On" to output the waveform at the output connector of the waveform generator.

16.3.3 Configuring a sine sweep waveform

1. Tap the "Gen" signal activator.
2. Select the tab of the generator that you want to configure: "Gen"1 or "Gen"2.
3. In the "Setup" tab, set "Function type" = "Sine".
4. Press "Sweep" to open the sweep dialog.
5. Select the "Sweep type".
6. Set the "Start frequency", the "Stop frequency" and the "Sweep time".
7. Set "Sweep state" = "On" to enable the sweep.
8. Press "Back" to return to the "Setup" tab.
9. Set "State" = "On" to output the waveform at the output connector of the waveform generator.

16.3.4 Configuring an arbitrary waveform

For a description of the settings, see [Section 16.1.4, "Arbitrary waveforms"](#), on page 867.

Generating an arbitrary waveform from a saved file

If you want to output single periods of the arbitrary waveform, first set up the generator, and then connect the DUT.

1. Tap the "Gen" signal activator.

2. Select the tab of the generator that you want to configure: "Gen1" or "Gen2".
3. In the "Setup" tab, set "Function type" = "Arbitrary".
4. Select "Arbitrary Setup" to open the arbitrary dialog.
5. Set the "Arb wfm source" to "Saved waveform".
6. Set the "Sample rate" if it is not defined in the file data.
7. Check "Number of samples".
8. Select "Back" to return to the "Setup" tab.
9. Select the "Run mode".
10. If "Run mode" = "Repetitive", set "State" = "On" to output the waveform at the output connector of the waveform generator.
11. If "Run mode" = "Single period":
 - a) Connect the DUT.
 - b) Set "State" = "On" to enable the output of the waveform generator.
 - c) Tap "Run single" to output one waveform.

17 Network operation

The operating system is the basis of the instrument's firmware, it provides basic functions such as logon, password protection, virus protection, and connection to a network.

In addition to working with the MXO 5C directly with the touchscreen and the keys, you can also operate the instrument from a remote PC. Various methods of remote operation and control in a LAN network are supported:

- Using the web interface
- Using a VNC client
- Remote control with SCPI commands

You can also connect and synchronize two MXO oscilloscopes together and thus extend the number of channels. If you use R&S ScopeStudio on a computer, you can connect and synchronize two oscilloscopes to the software.

• Connecting the instrument to the network (LAN)	876
• ScopeSync	878
• Web interface	889
• Remote operation with VNC client	895
• Remote control	895
• Remote control - status reporting system	898

17.1 Connecting the instrument to the network (LAN)

Network environment

Before connecting the product to a LAN, consider the following:

- Install the latest firmware to reduce security risks.
- For internet or remote access, use secured connections if applicable.
- Ensure that the network settings comply with the security policies of your company. Contact your local system administrator or IT department before connecting your product to your company LAN.
- When connected to the LAN, the product may potentially be accessed from the internet, which may be a security risk. For example, attackers might misuse or damage the product.

17.1.1 Connecting the instrument to the network

There are two methods to establish a LAN connection to the instrument:

- A non-dedicated network (Ethernet) connection from the instrument to an existing network.

Connecting the instrument to the network (LAN)

- A dedicated network connection (Point-to-point connection) between the instrument and a single computer.

To connect a LAN cable

- ▶ Connect an RJ-45 cable to the LAN connector on the rear panel, and to the LAN.

For supported LAN interfaces, refer to the specifications document.

17.1.2 Assigning the IP address

Depending on the network capacities, the TCP/IP address information for the instrument can be obtained in different ways.

- If the network supports the Dynamic Host Configuration Protocol (DHCP), the address is assigned automatically.
- If the network does not support DHCP, or if the instrument is set to use manual configuration, the addresses must be set manually.

By default, the instrument is configured to use DHCP and obtains all address information automatically. Thus it is safe to establish a physical connection to the LAN without any previous instrument configuration.

To assign the IP address manually on the instrument

1. **NOTICE!** Connection errors can affect the entire network. If your network does not support DHCP, or if you choose to disable dynamic TCP/IP configuration, you must assign valid address information before connecting the instrument to the LAN.
Contact your network administrator to obtain a valid IP address.
2. Open "Menu" > "Settings".
3. Select "System" > "Network" > "Advanced".
4. Disable "Automatic IP (DHCP)".
5. Enter the address information as obtained from the network administrator.

17.1.3 Using host names

In a LAN that uses a DNS server (Domain Name System server), each computer and instrument in the LAN can be accessed via an unambiguous host name (or computer name) instead of the IP address. The DNS server translates the host name to the IP address. Host names are useful when a DHCP server is used, as a new IP address can be assigned each time the instrument is restarted.

Each instrument is delivered with an assigned host name, but you can change this name.

The default host name is the device name, a non-case-sensitive string with the following syntax: <instrument_model>-<serial_number>.

For example, the default host name of an MXO58 with serial number 123456 is MXO58-123456.

You can find the current host name, the model and the serial number in the "Device summary", when you tap the Rohde & Schwarz logo in the upper right corner of the screen. See also: [Section 4.15, "Information and notifications"](#), on page 78.

The serial number can also be found on the rear panel of the instrument. It is the third part of the device ID printed on the barcode sticker:



To change the host name

1. Open the "Menu".
2. Select "Settings" > "System" > "Network".
3. In "Host name", enter the new host name.
4. Confirm the entry.
5. Reboot the instrument.

17.2 ScopeSync

- [ScopeSync concept](#)..... 878
- [Setting up the ScopeSync connection of two oscilloscopes](#)..... 882
- [ScopeSync settings](#)..... 884

17.2.1 ScopeSync concept

Using the ScopeSync functionality, you can extend the number of channels in analysis up to 16 synchronized analog channels, or even more. ScopeSync is useful in applications such as power sequencing, power conversion, multi-phase buck converters, 6-phase motor drives, and in automotive applications. You can use most measurement and analysis functions across all channels.




Figure 17-1: Example: analysis of multi-phase buck converter on MXO 5 with ScopeSync

The following products can be connected with ScopeSync:

- MXO 4 with 4 channels
- MXO 5 with 4 or 8 channels
- MXO 5C with 4 or 8 channels
- R&S ScopeStudio

17.2.1.1 Connections between oscilloscopes


In a ScopeSync setup, scope 1 is the leading oscilloscope, where the analysis is done. Scope 2 is the connected oscilloscope. Both oscilloscopes are set up independently, and you can use the front panel keys and the touchscreen on each instrument.

ScopeSync requires several connections:


- "Ref Out 10MHz" of scope 1 to "Ref In 10MHz" of scope 2 with BNC cable. This connection ensures the timing accuracy across the oscilloscopes.
- "Trigger Out" of scope 1 to "Trigger In" of scope 2 with BNC cable. This connection ensures trigger alignment. The trigger is set on scope 1, and scope 2 triggers when the scope 1 triggers. The trigger out delay is eliminated by a skew value that is measured during skew setup.
- LAN connection between the two oscilloscopes, either directly, via network, or using a switch. The LAN connection is for the communication of the scopes: sending commands from scope 1 to scope 2, and transferring waveforms from scope 2 to scope 1.

Synchronized waveforms on scope 1

You can select which waveforms you want to transfer from scope 2 to scope 1. When acquiring the waveforms with "Run single" or "Run/stop", you see the waveforms on scope 1 and can analyze them. Only waveforms that are based on the identical trigger event are shown simultaneously in run mode.



The channels of each oscilloscope are grouped in the signal bar. Select the channel group to open it. Channels of scope 2 are named "O2:C<n>", "O3:C<n>" and so on. They are available as sources along with the waveforms of scope 1, for example, for math, measurements, masks, serial buses.



Limitations

When working with ScopeSync and analyzing waveforms from a connected oscilloscope, some limitations exist.

- ScopeSync "Get signals" transfers only analog channels.
- You can connect one oscilloscope at a time. With a more complicated configuration, also channels of a scope 3 can be analyzed. For details, contact the Rohde & Schwarz customer support.
- Waveform persistence, measurement statistics, and other functions that require repeated acquisitions are not available on waveforms of scope 2. These waveforms are handled like reference waveforms in the background.
- Up to 16 waveforms can be displayed in one diagram. If you have more waveforms, you need a second diagram to display all.
- Triggering is possible on scope 1 signals only. Scope 2 uses the external trigger.
- You can save a session or saveset when the connection to scope 2 is active. When you recall a saveset or session in the "Recall" tab with active connection, the file is loaded, but the connection is terminated. You have to reconnect the connected oscilloscope. Recalling a session file loads the saveset and reference waveforms (if included). See [Section 13.7, "Sessions"](#), on page 466.
- The higher the record length of the signals on scope 2, the longer it takes to transfer the waveforms. The time also depends on the type of scope 1. As a rule of thumb, if scope 1 is an MXO 5, it slows down at record length > 1 Mpoint on scope 2. MXO 4 as scope 1 slows down at record length > 0.1 Mpoint on scope 2.
- The maximum record length depends on the oscilloscope model, the number of total channels, and the use of additional digital or reference waveforms on scope 1. For two MXO 5 scopes with 16 channels total, maximum record length is 100 Mpoint. For MXO 4 as scope 1 in a 12-channel configuration, maximum record length supported is 50 Mpoint.

17.2.1.2 R&S ScopeStudio connection

With R&S ScopeStudio, the oscilloscope application on a computer, you can retrieve the signals and settings from an MXO oscilloscope and analyze the waveforms on the computer. If the oscilloscope is connected to another one with ScopeSync, you can analyze the waveforms and data of both scopes.

You need a working LAN connection between the computer with R&S ScopeStudio and the scope 1, usually via the network, or a direct connection. Then you can load the data from scope 1 into R&S ScopeStudio:


- "Get signals" to load analog channel waveforms.
- "Get session" to load all settings and waveforms.

You can also load a session in the "Recall" tab when the connection to scope 1 is active. The file is loaded, but the connection is terminated. You have to reconnect the oscilloscope. Use "Get session" instead, which keeps the connection active. If there are analog and digital channels in the session file, only the digital channels are loaded.

17.2.2 Setting up the ScopeSync connection of two oscilloscopes

To set up the physical connection


1. Connect "Ref Out 10MHz" of scope 1 to "Ref In 10MHz" of scope 2 with a BNC cable.
2. Connect "Trigger Out" of scope 1 to "Trigger In" of scope 2 with a BNC cable.
3. Establish a LAN connection between the two scopes. You can connect both instruments to the network, connect them directly, or use a switch.



To configure the connection

All settings are described in [Section 17.2.3, "ScopeSync settings"](#), on page 884.

1. On scope 1, tap the "+ Scope" activator on the signal bar.
2. On the "Connect" tab, tap "+ Add".
3. Enter the "IP or hostname" of scope 2. To get the information, tap the Rohde & Schwarz logo on the display of scope 2.
4. Enter a name for scope 2.
The name is added to the default name.
5. Tap "+ Add".
The oscilloscope is added to the scope list. You can add more oscilloscopes to the list and connect them when needed.
6. To activate the connection, tap the oscilloscope in the list.
7. Tap "Connect".
8. To align the oscilloscopes, tap "Skew setup".
9. Connect two passive probes to the Probe Comp. connectors of scope 1 and to C1 on scope 1 and scope 2 as shown in the dialog.



10. Tap "Auto remote skew".

The skew is measured and the result is written to "Remote skew" and used for alignment of the channels.

11. Tap "Back" twice to return to the "Connect" tab.
12. Select the "Channel selection" tab.
13. Tap "Select active channels" to activate all channels that are active on scope 2.
Channels that were active on scope 2 at the time of connection are activated when you open the tab. You can also select the required channels individually.
14. Select the "Remote actions" tab.
15. Activate "Sync timebase".
16. To get the signals on scope 1, tap "Run single" or "Run/stop".


Now you can start the analysis of the signals.


17.2.3 ScopeSync settings

- [Connection setup](#)..... 884
- [Channel selection](#).....887
- [Remote actions](#)..... 888

17.2.3.1 Connection setup

Access: "Menu" > "Apps" > "General" tab > "Add scope" > "Connect" tab





+ Add

Opens a dialog to connect several MXO oscilloscopes.

Connect the oscilloscopes as shown in the dialog, and enter the [IP or hostname](#) and a [Device name](#). You can add up to 7 instruments to the list.

Remote command:

`SYNChronize:DEVIce<m>[:ENABle]` on page 1875

Scope list

The list shows all oscilloscopes that were added before with their device name and IP address. The active connection is indicated with a connection symbol. Select an oscilloscope to connect or disconnect it. Only one oscilloscope can be connected at a time. When connecting a new scope, first disconnect the previous one.

Device name

Enter a name for the connected oscilloscope.

Remote command:

`SYNChronize:DEVIce<m>:NAME` on page 1873

IP or hostname

Sets the IP address or the host name of the connected oscilloscope.

Remote command:

`SYNChronize:DEVIce<m>:COMMunicate:NET[:HOSTname]` on page 1872

Connect

Activates the connection between the two oscilloscopes, or between the R&S ScopeStudio software and the oscilloscope.

Remote command:

`SYNChronize:DEVIce<m>:CONNect` on page 1873

Disconnect


Terminates the active connection.

Remote command:

`SYNChronize:DISConnect` on page 1875

Skew setup

Opens a dialog to compensate for the delay between the scopes. The delay is caused by the trigger out delay and the cable length of the trigger out to trigger in connection.

**Remote skew ← Skew setup**

Shows the skew value that was measured by "Auto remote skew". If you know the skew, or measure it manually, you can also enter the value.

Remote command:

[SYNChronize:DEVICE<m>:SKEW\[:VALUE\]](#) on page 1874

Auto remote skew ← Skew setup

Determines the delay between the scopes automatically, and sets the skew. Connect the scopes as shown in the dialog, and tap "Auto remote skew".

Remote command:

[SYNChronize:DEVICE<m>:SKEW:AUTO](#) on page 1874

17.2.3.2 Channel selection

Access: "Menu" > "Apps" > "General" tab > "Add scope" > "Channel selection" tab

On the "Channel selection" tab, you select the channels of scope 2 to be synchronized, displayed and analyzed. You can select active and inactive channels.

Select active channels

Selects all channels that are active on scope 2.

Remote command:

[SYNChronize:DEVIce<m>:CHANnels](#) on page 1872

Deselect all


Deselects all selected channels at once.

Remote command:

[SYNChronize:DEVIce<m>:CHANnels](#) on page 1872

17.2.3.3 Remote actions

Access: "Menu" > "Apps" > "General" tab > "Add scope" > "Remote actions" tab



Run/stop

See ["Run/stop"](#) on page 125.

Run single

See ["Run single"](#) on page 125.

Lock controls

Locks the touchscreen and the front panel keys on the connected oscilloscope.

Remote command:

[SYNChronize:DEVIce<m>:LOCKcontrols](#) on page 1873

Sync timebase

Enables or disables the timebase synchronization.

Remote command:

[SYNChronize:DEVIce<m>:TIMEbasesync](#) on page 1874

Display update

Enables the continuous display update on the actively connected oscilloscope (scope 2) when acquisition is controlled on scope 1.

The display update allows for visual comparison of the waveforms on both scopes.

"Display update" is available if "Lock controls" is on.

Remote command:

[SYNChronize:DEVIce<m>:DISPlay](#) on page 1873

Get signals

Retrieves the waveforms of the latest acquisition from the connected oscilloscope. All selected analog channel waveforms are transferred. Digital channels and reference waveforms are not transferred.

Remote command:

[SYNChronize:LOAD\[:WAVEform\]](#) on page 1875

[SYNChronize:LOAD:ABORt](#) on page 1875

17.3 Web interface

If the MXO 5C is connected to a computer via LAN, you can operate the instrument from the computer. No additional tools are required, you need only a web browser.

17.3.1 Settings on the MXO 5C

The "Network" tab of the "System" dialog box provides network information and settings. See [Section 5.1.2, "Network settings"](#), on page 84.

17.3.2 Web browser

The instrument's web interface works with all W3C compliant browsers.

To open the instrument's web browser

1. Open a browser on a computer connected to the instrument via LAN.
2. Type the instrument's host name or IP address in the address field of the browser on your PC, e.g. "http://11.111.11.222".


The instrument homepage opens.

17.3.2.1 Instrument homepage


The instrument homepage displays the device information in read-only format, including DNS host names, IP address, and the VISA resource strings.

At the bottom of the homepage, you find the "Device Indicator". Activate the indicator to find the instrument. In the instrument GUI, above the waveform diagram, the connection status icon starts blinking.

On the MXO 5C, the "Scope Ready" LED is blinking.



The navigation menu of the instrument's browser interface has the following items.



- "LAN configuration" opens the menu with configuration pages.
- "Web control" emulates the front panel and shows the instrument display. You see a live image of the instrument, and you can operate the instrument remotely. You can use the keys, the knobs and the menus in the same way as directly on the instrument.
- "File manager" provides access to the user data that is saved on the instrument, upload and download.

17.3.2.2 LAN configuration

The LAN configuration consists of several parts:

- "General"
- "IP configuration" provides all mandatory LAN parameters.
- "Advanced configuration" provides LAN settings that are not declared mandatory by the standard.
- "Ping client" provides the ping utility to verify the connection between the instrument and other devices.

Changing the LAN parameters requires the "Web password" password, which is set on the instrument.

IP configuration

The "LAN Configuration > IP configuration" webpage displays all mandatory LAN parameters and allows their modification. Changing the LAN parameters requires the "Web password" password, which is set on the instrument.

The "IP address mode" controls how the IP address for the instrument gets assigned. For the manual configuration mode, at least the static IP address, subnet mask, and default gateway are used to configure the LAN. The automatic configuration mode uses a DHCP server or Dynamic Link Local Addressing to obtain the instrument IP address.

The same settings are available on the instrument under "Menu" > "Settings" > "System" > "Network" > "Advanced".

Advanced configuration

The "LAN Configuration > Advanced configuration" parameters are used as follows:

- mDNS and DNS-SD are two additional protocols: Multicast DNS and DNS Service Discovery. They are used for device communication in zero configuration networks working without DNS and DHCP.
- "ICMP ping" must be enabled to use the ping utility.
- "VXI-11" is the protocol that is used to detect the instrument in the LAN.

Device web > LAN configuration

Home | LAN configuration | Web control

General | IP configuration | **Advanced configuration** | Ping client

Device settings

mDNS and DNS-SD: mDNS & DNS-SD ▼

IPv4 settings

ICMP ping: ☒

VXI-11 discovery: ☐

IPv6 settings

ICMP ping: ☒

Privacy extension: ☐

✓ Apply

Ping client

Ping is a utility that verifies the connection between the instrument and another device. The ping command uses the ICMP echo request and echo reply packets to determine whether the LAN connection is functional. Ping is useful for diagnosing IP network or router failures. The ping utility is not password-protected.

Device web > LAN configuration

Home | LAN configuration | Web control

General | IP configuration | Advanced configuration | **Ping client**

Destination address:

Clear Submit

To initiate a ping between the compliant instrument and a second connected device:

1. Enable "ICMP ping" on the "Advanced configuration" page (enabled by default).
2. On the "Ping client" page, enter the IP address of the second device **without the ping command and without any further parameters** into the "Destination address" field (e.g. 11.113.11.203).
3. Click "Submit".

17.3.2.3 Web control

"Web Control" emulates the front panel and shows the instrument display. You see a live image of the instrument, and you can operate the instrument remotely. You can use the keys, the knobs and the menus in the same way as directly on the instrument.




In the upper right corner above the emulated display, you see some options:

- "Front panel" hides or shows the front panel.
- "Scaling" scales the diagram to show it completely. If disabled, the diagram is shown in its original size.
- "Read-only" disables operating, only viewing is possible.
- The camera icon saves a screenshot.
- The arrows icon hides or shows the menu.

17.3.2.4 File manager

The file manager on the instrument's webpage provides access to the user data that is stored on the instrument, or on a USB flash device connected to the instrument.



In the browser's file manager, you can organize the data:

- Create folders.
- Copy files within the instrument's file system, or from and to a USB flash device. Multiple files selection is possible.
- Move files within the instrument's file system, or from and to a USB flash device. Multiple files selection is possible.
- Rename files.
- Delete files.
- Upload files from the operating computer to the instrument. Multiple files can be uploaded at once.
- Download files from the instrument to the operating computer. Multiple files selection is possible.
- Preview file content of text files with maximum size of 500 kbyte.

Notes on USB flash devices

If no USB flash device is connected to the MXO 5C, the "USB" folder is empty but still listed. Do NOT upload files to this main "USB" folder because data will be lost. Upload files only to the subfolders of connected USB flash devices.

After attaching a USB flash device, creating a screenshot or other actions, the file manager might not display the last change:

- Click the "Refresh" icon on the right of the address field to update the display.

The "Eject" button for USB flash devices has no function when operating the instrument remotely.

17.3.2.5 Mapping the instrument's file system as a network drive

Using web based distributed authoring and versioning (WebDAV), you can access and exchange files over the internet: move, cut, copy and paste files from the instrument to the computer and vice versa. To prepare file exchange, map the instrument's file system as a network drive in the file explorer of the operating computer:

1. Check if the connection status icon in the upper right corner of the instrument's display is green.

If it is green, the instrument is connected to the LAN.

2. Open the file explorer on the operating computer.
3. In the left list, right-click "Network" or the entry of the operating computer, and select "Map network drive".


4. Enter the path to the instrument's file system:

`http://<hostname>/webdavData.`

Example: `http://MXO58-123456/webdavData`

You can find the host name in the "Device summary", which is shown when you tap the Rohde & Schwarz logo in the upper right corner of the instrument's screen. The default host name is `<instrument_model>-<serial_number>`.

5. Activate "Connect using different credentials".



6. Click "Finish".
7. Leave the "User name" and "Password" empty. Click "OK".

If there are problems with the connection, check if the "WebClient" service is running: "Task Manager" > "Services" tab. If the "WebClient" service is not running, start it.

17.4 Remote operation with VNC client

If the MXO 5C is connected to a computer via LAN, you can operate the instrument from the computer using a VNC client. Therefore, install a VNC client on the computer.

To operate the instrument via VNC client:

1. Start the VNC client.
2. Enter the hostname (device name) of the instrument. You find the name in the instrument information on the oscilloscope. Tap the Rohde & Schwarz logo to show the information.
3. Connect to the instrument.

You see the display of the oscilloscope and can use the menus, dialogs, SmartGrid and all operating means of the display.

17.5 Remote control

Remote control automates the operation of the MXO 5C using SCPI commands, scripts and programs.

For general information on remote control of Rohde & Schwarz products via SCPI, refer to www.rohde-schwarz.com/rc-via-scpi.

The following sections describe the specific basics of remote control. Definitions specified in the SCPI standard are not provided.

SCPI commands are listed and described in [Section 18, "Remote control commands"](#), on page 908.

- [Remote control interfaces and protocols](#).....896
- [Starting and stopping remote control](#).....897

17.5.1 Remote control interfaces and protocols

The MXO 5C supports different interfaces for remote control. The following table gives an overview.

Table 17-1: Remote control interfaces and protocols

Interface	Protocols, VISA address string	Remarks
Local Area Network (LAN)	Protocol HiSLIP VISA address string: TCPIP:: <host address="">:: hislip0[, <port>] [::INSTR] Protocol VXI-11 VISA address string: TCPIP::<host address="">:: inst0] [::INSTR] </host></host>	The LAN connector is located on rear panel of the instrument. The interface is based on TCP/IP and supports various protocols.

17.5.1.1 LAN interface

To be integrated in a LAN, the instrument is equipped with a LAN interface, consisting of a connector, a network interface card and protocols. The interface details are given in the specifications.

For remote control via a network, the PC and the instrument must be connected via the LAN interface to a common network with TCP/IP network protocol. They are connected using a commercial RJ-45 cable (shielded or unshielded twisted-pair category 5 or better). The TCP/IP network protocol and the associated network services are preconfigured on the instrument. Software for instrument control and the VISA program library must be installed on the controller.

For remote control via a network, the PC with MXO 5C and the controller PC must be connected to the LAN. The VISA program library must be installed on the controller.

IP address

Only the IP address or a valid DNS host name is required to set up the connection. The host address is part of the "VISA resource string" used by programs to identify and control the target application. The VISA resource string has the form:

TCPIP::::hislip0[, <port>] [::INSTR] for HiSLIP protocol

TCPIP::::inst0] [::INSTR] for VXI-11 protocol

Where:

- `host address` identifies the MXO 5C in the network, usually the IP address. If the LAN is supported by a DNS server, the host name can be used instead of the

IP address. The DNS server (Domain Name System server) translates the host name to the IP address.

- `hislip0` indicates the HiSLIP protocol.
- `inst0` is the default LAN device name. VISA supports several devices running on the instrument. On MXO 5C, only one device is configured, so the LAN device name can be omitted.
- `INSTR` specifies a VISA resource of the type INSTR. By default, the VISA resource name control is set to the INSTR class.

Example: HiSLIP

IP address is *192.1.2.3*: the valid resource string is: `TCPIP::192.1.2.3::hislip0`

Instrument name is *RSRT1*: the valid resource string is: `TCPIP::RSRT1::hislip0`.

DNS host name is *MXO 5C-123456*: the valid resource string is:

`TCPIP::MXO 5C-123456::hislip0`.

Example: VXI-11

IP address is *192.1.2.3*: the valid resource string is: `TCPIP::192.1.2.3`

Instrument name is *RSRT1*: the valid resource string is: `TCPIP::RSRT1`.

DNS host name is *MXO 5C-123456*: the valid resource string is:

`TCPIP::MXO 5C-123456`.

17.5.2 Starting and stopping remote control

17.5.2.1 Starting a remote control session

When you switch on the instrument or start the firmware, it is always in manual operation state ("local" state).

► To start remote control:

- Send a command from the controller.
- VXI-11 protocol (LAN or USB interface): Use `&GTR` interface message.

While remote control is active, the settings are optimized for maximum measurement speed; the display is switched off.

Operation via the front panel is disabled.

On the screen, two buttons appear in the upper left corner: "Local" and "View".

17.5.2.2 Using the display during remote control

You can observe the screen while a remote control script is executed. Displaying the results of script execution is helpful for program test purposes but tends to slow down

the measurement. Therefore it is recommended that you switch off the display in real measurement applications where a tested program script is to be executed repeatedly.

- ▶ To switch on the display, do one of the following:
 - Tap the "View" button in the upper left corner of the screen.
 - Use the `SYSTem:DISPlay:UPDate ON` command.
- ▶ To switch off the display, do one of the following:
 - Tap the "View" button again.
 - Use the `SYSTem:DISPlay:UPDate OFF` command.

17.5.2.3 Returning to manual operation

The MXO 5C switches back to manual operation when the remote connection is closed. Besides, you can return to manual operation manually or via remote control.

- ▶ To return to manual operation:
 - Tap the "Local" button in the upper left corner of the screen.
 - VXI-11 protocol: Use `&GTL` interface message.

17.6 Remote control - status reporting system

The status reporting system stores all information on the current operating state of the instrument, and on errors that have occurred. This information is stored in the status registers and in the error queue. Both can be queried via `STATus...` commands.

17.6.1 Hierarchy of status registers

As shown in the following figure, the status information is of hierarchical structure.




Figure 17-2: Overview of the status registers hierarchy

- **STB, SRE**

The S**T**atus B**Y**te (**STB**) register and its associated mask register Service Request Enable (**SRE**) form the highest level of the status reporting system. The **STB** provides a rough overview of the instrument status, collecting the information of the lower-level registers.

- **ESR and SCPI registers**

The **STB** receives its information from the following registers:

- The Event Status Register (**ESR**) with the associated mask register standard Event Status Enable(**ESE**).
- The **STATUS:OPERation** and **STATUS:QUESTIONable** registers are defined by SCPI and contain detailed information on the instrument.

- **Output buffer**

The output buffer contains the messages that the instrument returns to the controller. It is not part of the status reporting system but determines the value of the `MAV` bit in the `STB` and thus is represented in the overview.


All status registers have the same internal structure.

17.6.2 Structure of a SCPI status register

The `STATUS:OPERation` and the `STATUS:QUEStionable` SCPI status registers consists of five parts.

The individual bits are independent of each other, i.e. each hardware status is assigned a bit number, which is valid for all five parts. Bit 15 (the most significant bit) is set to zero for all parts. Thus, the contents of the register parts can be processed by the controller as positive integers.

Description of the five status register parts



The five parts of a SCPI status register have different properties and functions:

- CONDition**
 The `CONDition` part reflects the current instrument status. For summary bits, the `CONDition` bit mirrors the sum of the enabled `EVENT` bits of the next lower register.
 This register part can only be read, but not written into or cleared. Its contents are not affected by reading.
- PTRansition / NTRansition**
 The two transition register parts define which state transition of the `CONDition` part (none, 0 to 1, 1 to 0 or both) is stored in the `EVENT` part.
 The **Positive-Transition** part acts as a transition filter. When a bit of the `CONDition` part is changed from 0 to 1, the associated `PTR` bit decides whether the `EVENT` bit is set to 1.
 - `PTR` bit =1: the `EVENT` bit is set.
 - `PTR` bit =0: the `EVENT` bit is not set.
 All positive transitions are enabled by default.
 This part can be written into and read as required. Its contents are not affected by reading.

The **Negative-Transition** part also acts as a transition filter. When a bit of the `CONDition` part is changed from 1 to 0, the associated `NTR` bit decides whether the `EVENT` bit is set to 1.

- `NTR` bit =1: the `EVENT` bit is set.
- `NTR` bit =0: the `EVENT` bit is not set.

All negative transitions are disabled by default.

This part can be written into and read as required. Its contents are not affected by reading.

- **EVENT**

The `EVENT` part indicates whether an event has occurred since the last reading. It is the "memory" of the condition part. It allows you to detect the occurrence of events reliably, even if they have changed the state of the `CONDition` bit for a very brief interval. It only indicates events passed on by the transition filters. This part can only be read by the user. **Reading the register clears it.**

- **ENABLE**

The `ENABLE` part determines whether the associated `EVENT` bit contributes to the summary bit (see below). Each bit of the `EVENT` part is "ANDed" with the associated `ENABLE` bit (symbol '&'). The results of all logical operations of this part are passed on to the summary bit via an "OR" function (symbol '+').

`ENABLE` bit = 0: the associated `EVENT` bit does not contribute to the summary bit
`ENABLE` bit = 1: if the associated `EVENT` bit is "1", the summary bit is set to "1" as well.

This part can be written into and read by the user as required. Its contents are not affected by reading.

17.6.3 Contents of the status registers

17.6.3.1 Status byte (STB) and service request enable register (SRE)

The `STatus Byte` (STB) is already defined in IEEE 488.2. It provides a rough overview of the instrument status by collecting the pieces of information of the lower registers. A special feature is that bit 6 acts as the sum bit of the remaining bits of the status byte.

The STB can thus be compared with the `CONDition` part of an SCPI register and assumes the highest level within the SCPI hierarchy.

The STB is read using the command `*STB?` or a serial poll.

The `STatus Byte` (STB) is linked to the `Service Request Enable` (SRE) register. Each bit of the STB is assigned a bit in the SRE. Bit 6 of the SRE is ignored. If a bit is set in the SRE and the associated bit in the STB changes from 0 to 1, a service request (SRQ) is generated. The SRE can be set using the command `*SRE` and read using the command `*SRE?`.

Table 17-2: Meaning of the bits used in the status byte

Bit No.	Meaning
0...1	Not used
2	Error Queue not empty The bit is set when an entry is made in the error queue. If this bit is enabled by the SRE, each entry of the error queue generates a service request. Thus an error can be recognized and specified in greater detail by polling the error queue. The poll provides an informative error message. This procedure is to be recommended since it considerably reduces the problems involved with remote control.
3	QUESTionable status register summary bit The bit is set if an <code>EVENT</code> bit is set in the <code>QUESTionable</code> status register and the associated <code>ENABLE</code> bit is set to 1. A set bit indicates a questionable instrument status, which can be specified in greater detail by querying the <code>STATUS:QUESTionable</code> status register.
4	MAV bit (message available) The bit is set if a message is available in the output queue which can be read. This bit can be used to enable data to be automatically read from the instrument to the controller.
5	ESB bit Sum bit of the event status register. It is set if one of the bits in the event status register is set and enabled in the event status enable register. Setting of this bit indicates a serious error which can be specified in greater detail by polling the event status register.
6	MSS bit (main status summary bit) The bit is set if the instrument triggers a service request. This is the case if one of the other bits of this registers is set together with its mask bit in the service request enable register SRE.
7	STATUS:OPERation status register summary bit The bit is set if an <code>EVENT</code> bit is set in the <code>OPERation</code> status register and the associated <code>ENABLE</code> bit is set to 1. A set bit indicates that the instrument is just performing an action. The type of action can be determined by querying the <code>STATUS:OPERation</code> status register.

17.6.3.2 Event status register (ESR) and event status enable register (ESE)

The ESR is defined in IEEE 488.2. It can be compared with the `EVENT` part of a SCPI register. The event status register can be read out using command `*ESR?`.

The ESE corresponds to the `ENABLE` part of a SCPI register. If a bit is set in the ESE and the associated bit in the ESR changes from 0 to 1, the ESB bit in the STB is set.

The ESE register can be set using the command `*ESE` and read using the command `*ESE?`.

Table 17-3: Meaning of the bits used in the event status register

Bit No.	Meaning
0	Operation complete This bit is set on receipt of the command <code>*OPC</code> exactly when all previous commands have been executed.
1	Not used

Bit No.	Meaning
2	Query error This bit is set if the controller wants to read data from the instrument without having sent a query. It is also set if the controller does not fetch requested data and sends new instructions to the instrument instead. The cause is often a query that is faulty and hence cannot be executed.
3	Device-dependent error This bit is set if a device-dependent error occurs. An error message with a number between -300 and -399 or a positive error number, which denotes the error in greater detail, is entered into the error queue.
4	Execution error This bit is set if a received command is syntactically correct but cannot be performed for other reasons. An error message with a number between -200 and -300, which denotes the error in greater detail, is entered into the error queue.
5	Command error This bit is set if a command is received, which is undefined or syntactically incorrect. An error message with a number between -100 and -200, which denotes the error in greater detail, is entered into the error queue.
6	User request This bit is set when the instrument is switched over to manual control.
7	Power on (supply voltage on) This bit is set when you turn on the instrument.

17.6.3.3 STATus:OPERation register

In the `CONDition` part, this register contains information on which actions the instrument is executing. In the `EVENT` part, it contains information on which actions the instrument has executed since the last reading.

It can be read using the commands `STATus:OPERation:CONDition?` or `STATus:OPERation[:EVENT]?`, see also [Section 18.22.2, "STATus:OPERation register"](#), on page 1876.

Table 17-4: Bits in the STATus:OPERation register

Bit No.	Meaning
0	<code>CALibrating</code> This bit is set as long as the instrument is performing a self-alignment.
1	Not used
2	<code>AUToset</code> This bit is set while the instrument is performing an auto setup.
3	Not used
4	<code>MEASuring</code> The bit is set as long as an acquisition - sampling and postprocessing - is running. In run continuous mode, the bit is always set.

Bit No.	Meaning
5	WTRigger Available only for single acquisitions or the first acquisition of continuous acquisitions. The wait for trigger status bit indicates that the instrument is ready to trigger, and the pre-trigger time is expired. The bit is set for as long as a measurement is running.
6	TRiggered Available only for single acquisitions or the first acquisition of continuous acquisitions. The triggered status bit indicates that the instrument has been triggered.
7 - 15	Not used

17.6.3.4 STATus:QUEStionable register

This register contains specific information on instrument operation and signal reliability. It can be read using the commands `STATus:QUEStionable:CONDition?` and `STATus:QUEStionable[:EVENT]?`.

The remote commands for the `STATus:QUEStionable` register are described in [Section 18.22, "Status reporting"](#), on page 1875.

Table 17-5: Bits in the `STATus:QUEStionable` register

Bit No.		Meaning
0	-	For future use.
1	PPSupply	This bit is set if probe power supply overload occurs.
2	POVerload	This bit is set if a probe overload occurs.
3	COVerload	This bit is set if a questionable channel overload occurs.
4	TEMPerature	This bit is set if a questionable temperature occurs.
5	ADCState	The bit is set if the signal is clipped on the upper or lower edge of the screen overflow of the ADC occurs.
6	GOVerload	This bit is set if a generator overload occurs.
7	-	For future use.
8	NOALigndata	This bit is set if no alignment data is available - the instrument is uncalibrated.
9	LIMit	This bit is set if a limit value is violated.
10	-	For future use.
11	IMPRecise	This bit is set if the magnitude of the signal is too low to get reliable measurement results.
12	-	For future use.

Bit No.		Meaning
13	PLUnlock	This bit is set if a phase-locked loop process is unlocked. There are two reasons: - external reference is missing or defect - hardware defect of internal PLL
14	-	For future use.

17.6.3.5 Application of the status reporting system

The purpose of the status reporting system is to monitor the status of one or several instruments in a test system. In particular, it monitors continuous measurements to detect errors in the signal. The controller must receive and evaluate the information of all devices.

The following standard methods are used:

- **Service request:** An SRQ is initiated by the instrument.
- Query of a **specific register** by commands
- Query of the **error queue**

These methods are described in the following sections.

Service request

The instrument can send a service request (SRQ) to the controller. Usually, this service request initiates an interrupt at the controller, to which the control program can react appropriately.


An SRQ is initiated if one or several of bits 2, 3, 4, 5 or 7 of the STB are set and enabled in the SRE. Each of these bits combines the information of a lower-level register, the error queue or the output buffer.

The `ENABLE` parts of the status registers can be set such that arbitrary bits in an arbitrary status register initiate an SRQ. To use service requests effectively, set all bits to "1" in the mask registers SRE and ESE.

The SRQ is the only possibility for the instrument to become active on its own. Configure the instrument so that it initiates a service request if errors occur. And ensure that your program reacts appropriately to service requests.

Query of a register

The STB and ESR registers contain 8 bits, the SCPI registers 16 bits. The contents of a status register are specified and transferred as a single decimal number. Therefore, each bit is assigned a weighted value. The decimal number is calculated as the sum of the weighted values of all bits in the register that are set to 1.

**Example:**

The decimal value $40 = 32 + 8$ indicates that bits no. 3 and 5 in the status register (e.g. the `QUEStionable` status summary bit and the `ESB` bit in the `STatus` byte) are set.

17.6.4 Error queue

Each error state in the instrument leads to an entry in the error queue.

The error queue should be queried after every SRQ in the controller program as the entries describe the cause of an error more precisely than the status registers. Especially in the test phase of a controller program the error queue should be queried regularly since faulty commands from the controller to the instrument are recorded there as well.

17.6.5 Reset values of the status reporting system

The following table contains the commands and events that reset the status reporting system. Only `*RST` and `SYSTem:PRESet` change the functional instrument settings, all others do not.

`DCL` means Device clear and is a GPIB interface command. The command aborts the processing of the commands received and sets the command processing software to a defined initial state and does not change the instrument settings. In a VISA implementation, `viClear` translates to the `DCL` interface command.

All other commands are explained in the "Remote control commands" section.

Table 17-6: Resets of the status reporting system

Event	DCL (GPIB) viClear (VISA) Device clear	*RST or SYSTem: PRESet	STATus: PRESet	*CLS Clear status
Clear STB, ESR	-	-	-	yes
Clear SRE, ESE	-	-	-	-
Clear EVENT parts of the registers	-	-	-	yes
Clear ENABLE parts of all OPERATION and QUESTIONable registers; Fill ENABLE parts of all other registers with "1".	-	-	yes	-

Remote control - status reporting system

Event	DCL (GPIB) viClear (VISA) Device clear	*RST or SYSTem: PRESet	STATus: PRESet	*CLS Clear status
Fill PTRansition parts with "1"; Clear NTRansition parts	-	-	yes	-
Clear error queue	-	-	-	yes
Clear output buffer	yes	1)	1)	1)
Clear command processing and input buffer	yes	-	-	-
1) The first command in a command line that immediately follows a <PROGRAM MESSAGE TERMINA- TOR> clears the output buffer.				

18 Remote control commands

This section describes all remote commands available for MXO 5C and provides examples and information on how to use the commands.

For general information on remote control of Rohde & Schwarz products via SCPI, refer to www.rohde-schwarz.com/rc-via-scp.

See also [Section 17.5, "Remote control"](#), on page 895 and [Section 17.6, "Remote control - status reporting system"](#), on page 898 for further information on remote control.



The descriptions of the remote commands assume a MXO 5C with the highest available bandwidth and number of channels. Depending on your model, some of the available command ranges can differ from the values stated in the following sections.

18.1 Conventions used in remote command description

The basics of SCPI command structure, syntax and command parameters are explained in www.rohde-schwarz.com/rc-via-scp.

The following conventions are used in the remote command descriptions:

- *Command usage*
If not specified otherwise, commands can be used both for setting and for querying parameters.
If a command can be used for setting or querying only, or if it initiates an event, the usage is stated explicitly.
- *Parameter usage*
If not specified otherwise, a parameter can be used to set a value, and it is the result of a query.
Parameters required only for setting are indicated as "Setting parameters".
Parameters required only to refine a query are indicated as "Query parameters".
Parameters that are only returned as the result of a query are indicated as "Return values".
- *Conformity*
Commands that are taken from the SCPI standard are indicated as "SCPI confirmed". All commands used by the MXO 5C follow the SCPI syntax rules.
- *Asynchronous commands*
A command which does not automatically finish executing before the next command starts executing (overlapping command) is indicated as an "Asynchronous command".
- *Reset values (*RST)*
Default parameter values that are used directly after resetting the instrument (*RST command) are indicated as "*RST" values, if available.
- *Default unit*
The default unit is used for numeric values if no other unit is provided with the parameter.


18.2 Finding the appropriate command

In the following sections, the commands are sorted according to the menu and dialog structure.

A list of all commands in alphabetical order is given in the "List of Commands" at the end of this documentation.

To find the appropriate command for a setting easily, you can use the context help:

1. Enable the "Help" icon on the toolbar.



2. Tap the parameter for which you need information.

The "Help" window opens and displays the comprehensive description and the corresponding remote command.

3. Tap the remote command link to open the command description.

18.3 Error messages on remote commands

The system returns error codes and messages if it cannot execute a command, or if there is no valid result.

Error message	Description
-131, "Invalid suffix"	The measurement with the used suffix is not configured, and similar situations.
-221, "Settings conflict"	The command is not available with current settings. If you change the related settings, the command might work.
-394; "Overload detected"	The result is not trustworthy because the data is not in the ADC range.
-395; "Value not set"	Message is returned, e.g. for a measurement results when the acquisition isn't complete. It is the default for results after preset or when relevant settings have changed.
-396; "Invalid data"	The acquisition is complete, but some requirements are not met that are required to calculate the result.
-397; "Not available"	The command is not available due to hardware restrictions, missing option, inappropriate probe is connected, and other misfits.
-398; "Operation aborted"	
-399; "Operation failed"	

18.4 Frequently used parameters and suffixes

This chapter describes in general those parameters and suffixes that are used in several subsystems.

18.4.1 Waveform parameter

Many commands require one of the waveforms to be specified as source. The following table lists all waveforms. For each command using a waveform parameter, the available waveforms are specified in the command description.

Waveform	Description
C1 C2 ... C8 CHAN1 = C1, CHAN2 = C2, CHAN3 = C3, CHAN4 = C4, CHAN5 = C5, CHAN6 = C6, CHAN7 = C7, CHAN8 = C8	Analog channel waveforms
M1 M2 ... M8	Math waveforms
R1 R2 ... R8	Reference waveforms
XY1 XY2 XY3 XY4	XY-waveforms
SBUS1 SBUS2 SBUS3 SBUS4	Serial buses
D0 D1 D2 ... D14 D15	Digital channels
PBUS1 PBUS2 PBUS3 PBUS4	Digital buses
TRK1 TRK2 TRK3 ... TRK24	Track waveforms
O<n>C1 O<n>C2 ... O<n>C8 (<n> = 2 to 11	Analog channels of ScopeSync-connected oscilloscopes. Up to 7 oscilloscope connections can be configured: O2, O3, O4, ... , O8. One of these configurations can be activated at a time.
SPECMAXH1 SPECMINH1 SPECNORM1 SPECAVER1 SPECMAXH2 SPECMINH2 SPECNORM2 SPECAVER2 SPECMAXH3 SPECMINH3 SPECNORM3 SPECAVER3 SPECMAXH4 SPECMINH4 SPECNORM4 SPECAVER4	Spectrum traces: SPECMAXH : Spectrum max hold SPECMINH: Spectrum min hold SPECNORM: Spectrum normal SPECAVER: Spectrum average
PA1QPOWER PA2QPOWER ... PA6QPOWER	Power waveforms of power quality analysis
PA1HPOWER1 PA2HPOWER1 ... PA6HPOWER1	Power waveforms of power harmonics analysis, only available for standards EN 61000-3-2 Class C and EN 61000-3-2 Class D
PA1SPower PA2SPower ... PA6SPower	Power waveforms of switching loss analysis
PA1IPower PA2IPower ... PA6IPower	Input power waveforms of efficiency analysis
PA1OPower1 PA2OPower1 ... PA6OPower1 PA1OPower2 PA2OPower2 ... PA6OPower2 PA1OPower3 PA2OPower3 ... PA6OPower3	Output power waveforms of efficiency analysis

Waveform	Description
PA1TOPOWER PA2TOPOWER ... PA6TOP- OWER	Total power waveforms of efficiency analysis, requires more than 4 channels
PA1SOA PA2SOA ... PA6SOA	Waveform of power safe operating area (SOA) analysis
FREF1 FREF2 FREF3 FREF4	References of frequency analysis waveforms
EYE1 EYE2 ... EYE8	Eye diagrams

18.4.2 Slope parameter

The slope parameter is used with several trigger and search condition commands.

Slope	Description
POSitive	Rising edge, which is a positive voltage change.
NEGative	Falling edge, which is a negative voltage change.
EITHer	Rising as well as the falling edge.

18.4.3 Polarity parameter

The polarity parameter is used with several trigger and search condition commands.

Polarity	Description
POSitive	Positive going pulses.
NEGative	Negative going pulses.
EITHer	Both positive and negative going pulses.

18.5 Programming examples

18.5.1 SmartGrid layout with zoom

The following example uses 3 sine waves, all with frequency 20 MHz and an amplitude of ± 0.4 V. The vertical scale is 100 mV/div, the time scale is 20 ns/div.


In the example, 2 layouts are created, waveforms are assigned, and zoom and spectrum are added.

For a description of the commands, see:


- [Section 18.8.3, "SmartGrid"](#), on page 927
- [Section 18.12.1, "Zoom"](#), on page 1064

- [Section 18.16.1, "Spectrum setup"](#), on page 1157


```
//Prepare: 3 channel signals.
//Enable C1, C2 and C3.
CHAN1:STAT 1
CHAN2:STAT 1
CHAN3:STAT 1
```



```
//Create new diagrams for C2 and C3.
//Assign sources C2 and C3 to these diagrams.
LAY:DIAG2:ENAB 1
LAY:DIAG2:SOUR C2
LAY:DIAG3:ENAB 1
LAY:DIAG3:SOUR C3
//Create new node (node 2) and assign new diagrams to that node
//Place C2 on top, C3 at bottom
LAY:NODE2:ENAB 1
LAY:NODE2:CHIL1:CONT:TYPE DIAG
LAY:NODE2:CHIL1:CONT:ID 2
LAY:NODE2:CHIL2:CONT:TYPE DIAG
LAY:NODE2:CHIL2:CONT:ID 3
LAY:NODE2:STYP VERT
//Insert node 2 into the base node (initial node)
//Diagram1 is initially located at child 1
LAY:NODE1:CHIL2:CONT:TYPE NODE
LAY:NODE1:CHIL2:CONT:ID 2
//Place both nodes side by side
LAY:NODE1:STYP HOR
```



```
//Add zoom to C3. The zoom is located in diagram 3.
LAY:ZOOM:ENAB 1
LAY:ZOOM:SOUR 3
```




```
//Add a second layout with C1 and spectrum of C1.
//By default, the new layout is empty.
LAY2:ENAB 1
```




```
//Assign C1 to layout 2.
LAY2:DIAG1:SOUR C1
```




```
//Turn on spectrum of C1.
//By default, the spectrum is set below its analog source, and into the next
//free diagram (here diagram 2).
CALC:SPEC:STAT 1
CALC:SPEC:FREQ:CEN 20e6
CALC:SPEC:FREQ:SPAN 4e6
CALC:SPEC:FREQ:SCAL 15
```




```
//Set C1 and spectrum side by side by changing the split type.
LAY2:NODE1:STYP HOR
```



```
//Add zoom to spectrum. The zoom is located in layout 2, in diagram 2.
LAY2:ZOOM:ENAB 1
LAY2:ZOOM:SOUR 2
```



```
//Change zoom area.
LAY2:ZOOM:HOR:MODE REL
LAY2:ZOOM:HOR:REL:START 48
LAY2:ZOOM:HOR:REL:STOP 52
```



```
//Switch back to first layout (Tab 1).
LAY1:SACT
```



18.5.2 Creating a mask

The example creates a segment in mask 1 and defines the positions of the corner points.

```

:MTESt:ADD //Create mask 1
:MTESt:SEGMENT:ADD //Create segment 1 in mask 1
:MTESt:SEGMENT:POINT:ADD //Add 4 points at coordinate 0;0
:MTESt:SEGMENT:POINT:ADD
:MTESt:SEGMENT:POINT:ADD
:MTESt:SEGMENT:POINT:ADD
:MTESt:SEGMENT:POINT:COUNT? //Query the number of points
-->4
:MTESt:SEGMENT:POINT:X -60NS //Set the coordinates of point 1
:MTESt:SEGMENT:POINT:Y 50 MV
:MTESt:SEGMENT:POINT2:X -40NS //Set the coordinates of point 2
:MTESt:SEGMENT:POINT2:Y -50 MV
:MTESt:SEGMENT:POINT3:X -20NS //Set the coordinates of point 3
:MTESt:SEGMENT:POINT4:Y 100 MV //Set the coordinates of point 4, X = 0

```

18.5.3 Saving screenshots to file

The example saves three display images in png format to the files `Print.png`, `Print_001.png`, and `Print_002.png` on USB flash drive in the directory `/run/media/usb/<MyDriveName>`. For `<MyDriveName>`, use the name that was defined when formatting of the USB flash drive. To get a correct screenshot, turn on the display first.

Command description in: [Section 18.13.9, "Screenshots"](#), on page 1114.

In the following example `*OPC` prevents overlapping execution of asynchronous commands.

► Connect a USB flash drive.

```

SYST:DISP:UPD ON
HCOP:DEST MMEM
HCOP:DEV:LANG PNG
*OPC?
MMEM:NAME '/run/media/usb/<MyDriveName>/Print.png'
HCOP:IMMEDIATE; *OPC?
HCOP:IMM:NEXT; *OPC?
HCOP:IMM:NEXT; *OPC?

```

18.5.4 Data transfer in roll mode

The example shows the effects of `EXPort:WAVeform:SCOPE` and `ACQuire:ROLLmode:OSCapture` in roll mode.

Sample rate mode and record length mode are set to AUTO, and the record length is 10 M points.

```

ACQuire:SRATE:MODE AUTO
ACQuire:POINTS:MODE AUTO

```



```

ACQuire:POINts?
--> 10000000
ACQuire:ROLLmode:OSCapture OFF
CHANnel1:DATA:HEADer?
--> -5,4.999999,10000000,1 //10 M points of data are transferred
ACQuire:ROLLmode:OSCapture ON
EXPort:WAVeform:SCOpe DISP //Export of the displayed data
CHANnel1:DATA:HEADer?
--> -5,4.999999,10000000,1 //10 M points of data are transferred
EXPort:WAVeform:SCOpe ALL //Export of all data
CHANnel1:DATA:HEADer?
--> -31.702346,4.99999999,36702346,1 //36.7 M points of data are transferred

```

18.6 Common commands

Common commands are described in the IEEE 488.2 (IEC 625-2) standard. These commands have the same effect and are employed in the same way on different devices. The headers of these commands consist of "*" followed by three letters. Many common commands are related to the Status Reporting System.

Available common commands:

*CAL?	917
*CLS	918
*IDN?	918
*OPC	918
*OPT?	918
*RCL	918
*RST	919
*SAV	919
*SRE	919
*STB?	919
*TRG	920
*TST?	920
*WAI	920

*CAL?

Starts a self-alignment of the instrument, and then queries a status response. Return values ≠ 0 indicate an error.

Return values:

<State>	0: no error
	1: alignment failed
	2: not aligned, e.g. init
	3: device needs longer warmup time before selfalignment can start
	4: input signal connected during selfalignment

Usage: Query only

***CLS**

Clear status

Sets the status byte (STB), the standard event register (ESR) and the `EVENT` part of the `QUESTIONABLE` and the `OPERATION` registers to zero. The command does not alter the mask and transition parts of the registers. It clears the output buffer.

Usage: Setting only

***IDN?**

Identification

Returns the instrument identification.

Return values:

<ID> "Rohde&Schwarz,<device type>,<part number>/<serial number>,<firmware version>"

Example: Rohde&Schwarz,MXO5C,1802.3000k08/100222,2.1.0.2
Model assignment:

Usage: Query only

Manual operation: See ["Instrument"](#) on page 83

***OPC**

Operation complete

Sets bit 0 in the event status register when all preceding commands have been executed. This bit can be used to initiate a service request. The query writes a "1" into the output buffer when all preceding commands have been executed, which is useful for command synchronization.

***OPT?**

Option identification query

Queries the options included in the instrument. For a list of all available options and their description, refer to the specifications document.

Return values:

<Options> The query returns a list of options. The options are returned at fixed positions in a comma-separated string. A zero is returned for options that are not installed.

Usage: Query only

***RCL <Number>**

Recall

Loads the instrument settings from an intermediate memory identified by the specified number. The instrument settings can be stored to this memory using the command `*SAV` with the associated number.

The stored instrument settings do not include waveform generator settings.

It also activates the instrument settings which are stored in a file and loaded using `MMEMory:LOAD:STATe`.

***RST**

Reset

Sets the instrument to a default status. The default settings are indicated in the description of commands. Default settings are fixed, they are *not* changed by user-defined preset.

The command does not affect the waveform generator settings. To reset the generator, use `WGENerator<wg>:PRESet`.

Usage: Setting only

***SAV <Number>**

Save

Stores the current instrument settings under the specified number in an intermediate memory. The settings can be recalled using the command `*RCL` with the associated number.

Waveform generator settings are not included.

To transfer the stored instrument settings in a file, use the command `:MMEM:STOR:STAT`.

***SRE <Contents>**

Service request enable

Sets the service request enable register to the indicated value. This command determines under which conditions a service request is triggered.

Parameters:

<Contents>	Contents of the service request enable register in decimal form. Bit 6 (MSS mask bit) is always 0. Range: 0 to 255

***STB?**

Status byte query

Reads the contents of the status byte in decimal form.

Usage: Query only

***TRG**

Trigger

Triggers all actions waiting for a trigger event. In particular, *TRG generates a manual trigger signal. This common command complements the commands of the TRIGger subsystem.

*TRG corresponds to the INITiate:IMMediate command.

Usage: Event

***TST?**

Self-test query

Initiates self-tests of the instrument and returns an error code.

Return values:

<ErrorCode>	integer > 0 (in decimal format)
	An error occurred.
	0
	No errors occurred.

Usage: Query only

Manual operation: See ["Run tests"](#) on page 113

***WAI**

Wait to continue

Prevents servicing of the subsequent commands until all preceding commands have been executed and all signals have settled (see also command synchronization and [*OPC](#)).

Usage: Event

18.7 General remote settings

This section describes commands that affect many other remote commands in different applications of the MXO 5C.

FORMat[:DATA]	921
FORMat:BORDER	922
FORMat:BPATtern	922
SYSTem:DISPlay:UPDate	922
SYSTem:DISPlay:MESSage:STATe	923
SYSTem:DISPlay:MESSage[:TEXT]	923

FORMat[:DATA] [<Format>],[<Length>]

Selects the data type that is used for transmission of data from analog channels, math and reference waveforms, and some measurement results from the instrument to the controlling computer.

For INT and REAL formats, use **FORMat:BORDER** to set the byte order.

If you need physical data (e.g. in Volt or Ampere) for further analysis, use the floating point formats (REAL) for export. No data conversion is needed.

Parameters:

<Format>,<Length> ASCII | REAL,32 | REAL,64 | INT,8 | INT,16 | INT,32

ASCII

Data values are returned in ASCII format as a list of comma-separated values in floating point format. The length can be omitted. It is 0, which means that the instrument selects the number of digits to be returned. The query returns both values (ASC, 0).

REAL,32

Physical data in single precision, 32 bit floating point format. The data is stored as binary data (Definite Length Block Data according to IEEE 488.2). Each waveform value is formatted in the 32-Bit IEEE 754 floating point format.

The schema of the result string is as follows:

#41024<value1><value2>...<value n>, with:

#4 = number of digits (= 4 in the example) of the following number

1024 = number of following data bytes (= 1024 in the example)

<value> = 4-byte floating point values

For large data (≥ 1 GB), the result string starts with "#(data length)". The number inside the parentheses indicates the real data length in bytes.

REAL,64

Double precision, 64 bit floating point format.

INT,8 | INT,16 | INT,32

Signed integer data with length 8 bit, 16 bit, or 32 bit.

The result string has the same schema as the REAL format.

For INT,16, you can set the byte order using the command.

For digital channel data, math and histogram data, INT formats are not available.

*RST: ASCII

Example:

```
FORMat:DATA REAL,32
FORMat:DATA?
REAL,32
```

Usage:

SCPI confirmed

Asynchronous command

Manual operation: See "[Transfer data format](#)" on page 89

FORMat:BORDER <ByteOrder>

Sets the endianness.

The command is only relevant for data in integer and float format.

Parameters:

<ByteOrder> LSBFirst | MSBFirst
 LSB first: little endian, least significant byte first
 MSB first: big endian, most significant byte first
 *RST: LSBFirst

Example: A number in INT32 format is 439041101, which is hex 1A2B3C4D.
 With LSBFirst (default), 4D 3C 2B 1A is returned.
 With MSBFirst, 1A 2B 3C 4D is returned.

Usage: Asynchronous command

FORMat:BPATtern <BtPattFmt>

Sets the number format for remote bit pattern queries on serial protocols.

Parameters:

<BtPattFmt> DEC | HEX | OCT | BIN | ASCII | ASCii | STRG
 *RST: HEX

Usage: Asynchronous command

Manual operation: See ["Bit pattern format"](#) on page 89

SYSTem:DISPlay:UPDate <DisplayUpdate>

Defines whether the display is updated while the instrument is in the remote state. If the display is switched off, the normal GUI is replaced by a static image while the instrument is in the remote state. Switching off the display can speed up the measurement. OFF is the recommended state.

Parameters:

<DisplayUpdate> OFF | ON
 ON | 1: The display is shown and updated during remote control.
 OFF | 0: The display shows a static image during remote control.
 *RST: OFF

Example: SYSTem:DISPlay:UPDate 1
 Switch on the display update.

Usage: Asynchronous command

SYSTem:DISPlay:MESSage:STATe <DispMessSt>

Enables and disables the display of an additional text in remote control.

To define the text, use **SYSTem:DISPlay:MESSage[:TEXT]**.

Parameters:

<DispMessSt> OFF | ON
 *RST: OFF

Usage: Asynchronous command

SYSTem:DISPlay:MESSage[:TEXT] <DisplayMessage>

Defines an additional text that is displayed during remote control operation.

To enable the text display, use **SYSTem:DISPlay:MESSage:STATe**.

Parameters:

<DisplayMessage>

Usage: Asynchronous command

18.8 Instrument setup

• System	923
• Network drive mapping	926
• SmartGrid	927
• Toolbar	934
• Annotations	934
• Appearance	946
• Display	954
• Save/Recall	957
• Preset	959
• Maintenance	960

18.8.1 System

SYSTem:COMMunicate:NET[:HOSTname]	924
SYSTem:DATE	924
SYSTem:EXIT	924
SYSTem:FW:FILEpath	924
SYSTem:PRESet	925
SYSTem:SHUTdown	925
SYSTem:FW:START	925
SYSTem:TIME	925

SYSTem:COMMunicate:NET[:HOSTname] <Hostname>

Sets the host name of the instrument, which is required when configuring a network. After changing the host name, you have to reboot the instrument.

The query `SYSTem:COMMunicate:NET:HOSTname?` returns the currently defined host name.

Parameters:

<Hostname> String parameter

Usage: Asynchronous command

Manual operation: See "Host name" on page 84

SYSTem:DATE <Year>,<Month>,<Day>

Sets the date of the internal calendar.

Parameters:

<Year> Year, to be entered as a four-digit number (including the century and millennium information)
 Range: 2012 to 2099
 Increment: 1
 *RST: 2012

<Month> Range: 1 (January) to 12 (December)
 Increment: 1
 *RST: 1

<Day> Range: 1 to maximum number of days in the specified month
 Increment: 1
 *RST: 1

Example: `SYSTem:DATE?`
 Returned value: 2022,09,28

Usage: Asynchronous command

SYSTem:EXIT

Starts the shutdown of the firmware.

Usage: Setting only
 Asynchronous command

SYSTem:FW:FILEpath <FilePath>

Sets the path and the filename of the firmware installation file.

Parameters:

<FilePath> String with path and filename

Usage: SCPI confirmed
Asynchronous command

SYSTem:PRESet

Resets the instrument to the default state, has the same effect as *RST.

Usage: Setting only
SCPI confirmed
Asynchronous command

Manual operation: See "[Factory preset](#)" on page 108

SYSTem:SHUTdown

Starts the shutdown of the instrument (firmware and operating system).

Usage: Setting only
Asynchronous command

Manual operation: See "[\[Power\] key](#)" on page 41

SYSTem:FW:START

Starts the firmware update. Before starting, make sure that the correct path is set with [SYSTem:FW:FILEpath](#).

Usage: Event
SCPI confirmed
Asynchronous command

SYSTem:TIME <Hours>,<Minutes>,<Seconds>

Returns the current time of the clock.

Parameters:

<Hours> Range: 0 to 24
 Increment: 1
 *RST: 1

<Minutes> Range: 0 to 59
 Increment: 1
 *RST: 1

<Seconds> Range: 0 to 59
 Increment: 1
 *RST: 1

Usage: Asynchronous command

18.8.2 Network drive mapping

MMEMory:NDRive<m>:CONNect.....	926
MMEMory:NDRive<m>:DCONNect.....	926
MMEMory:NDRive<m>:LPATH.....	926
MMEMory:NDRive<m>:NPATh.....	926
MMEMory:NDRive<m>:PWORd.....	927
MMEMory:NDRive<m>:UNAMe.....	927

MMEMory:NDRive<m>:CONNect

Connects the remote network folder to the local folder.

Suffix:

<m> 1 to 8, index of the network drive

Usage:

Event

Asynchronous command

Manual operation: See ["Connect, Disconnect, Connection state"](#) on page 89

MMEMory:NDRive<m>:DCONNect

Disconnects the remote network folder from the local folder.

Suffix:

<m> 1 to 8, index of the network drive

Usage:

Event

Asynchronous command

Manual operation: See ["Connect, Disconnect, Connection state"](#) on page 89

MMEMory:NDRive<m>:LPATh <LocalPath>

Sets the local folder on the MXO 5, to which the network folder is mapped. With this name, you can access the connected folder on the instrument.

Suffix:

<m> 1 to 8, index of the network drive

Parameters:

<LocalPath> String with the path of the local folder

Usage:

Asynchronous command

Manual operation: See ["Local folder"](#) on page 88

MMEMory:NDRive<m>:NPATh <FilePath>

Sets the network folder that is mapped to the local folder.

Suffix:

<m> 1 to 8, index of the network drive

Parameters:

<FilePath> String with the full path in UNC syntax, for example,
 \\net1\data\team1\osc.

Usage: Asynchronous command

Manual operation: See ["Network folder"](#) on page 88

MMEMory:NDRive<m>:PWORd <Password>

Sets the password that is used to access the network folder.

Note that the SCPI protocol is NOT encrypted, so the password can be read on the network. Use the password at your own risk.

Suffix:

<m> 1 to 8, index of the network drive

Setting parameters:

<Password> String with the password

Usage: Setting only
 Asynchronous command

Manual operation: See ["User name, Password"](#) on page 88

MMEMory:NDRive<m>:UNAMe <UserName>

Sets the user name that is used to access the network folder.

Suffix:

<m> 1 to 8, index of the network drive

Parameters:

<UserName> String with the user name

Usage: Asynchronous command

Manual operation: See ["User name, Password"](#) on page 88

18.8.3 SmartGrid

The following LAYout commands configure the SmartGrid. In manual operation, you configure the SmartGrid by drag and drop. See [Section 4.9, "Rohde & Schwarz Smart-Grid"](#), on page 69.

Table 18-1: Terms and definitions of SmartGrid configuration

Term	Definition
Layout	A layout is a SmartGrid configuration. Several layouts can exist but only one layout is active. By default, layouts are named "Tab <n>" on the display.
Children	A child is an area where data (data table, result table) or waveforms (diagram) are displayed. A node can also be a child. A child can be empty.

Term	Definition
Node	A node consists of one or two children. A node is created by default with one child that has content.
Diagram	A diagram displays waveforms, the graphical visualization of data.

LAYout<ly>:COUNT?	928
LAYout<ly>[:ENABLE]	928
LAYout<ly>:ACTive	929
LAYout<ly>:SACTive	929
LAYout<ly>:LABel	929
LAYout<ly>:DIAGram<da>:COUNT?	929
LAYout<ly>:DIAGram<da>[:ENABLE]	930
LAYout<ly>:DIAGram<da>:SOURce	930
LAYout<ly>:DIAGram<da>:LABel	930
LAYout<ly>:NODE<no>:COUNT?	931
LAYout<ly>:NODE<no>[:ENABLE]	931
LAYout<ly>:NODE<no>:CHILdren<o>:CONTent<p>:ID	931
LAYout<ly>:NODE<no>:CHILdren<o>:CONTent<p>:TYPE	932
LAYout<ly>:NODE<no>:RATio	932
LAYout<ly>:NODE<no>:STYPe	932
LAYout<ly>:RESult<n>:HORizontal:RATio	933
LAYout<ly>:RESult<n>:VERTical:RATio	933
LAYout<ly>:RPOSition	933

LAYout<ly>:COUNT?

Returns the number of available layouts, i.e. SmartGrid configurations. By default, they named "Diagram Set" on the display.

You can query the maximum number of layouts with `LAYout:COUNT? MAX`.

Suffix:

<ly> Irrelevant, omit the suffix.

Return values:

<Count> Number of SmartGrid configurations

Usage:

Query only
Asynchronous command

LAYout<ly>[:ENABLE] <State>

Creates a new SmartGrid configuration and sets it active.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

Parameters:

<State> OFF | ON

Example:

See [Section 18.5.1, "SmartGrid layout with zoom"](#), on page 911.

Usage: Asynchronous command

LAYout<ly>:ACTive <ActiveKey>

Sets the active SmartGrid configuration. The query returns the index of the active layout.

Suffix:
<ly> Irrelevant, omit the suffix.

Parameters:
<ActiveKey> Index of the active layout

Usage: Asynchronous command

LAYout<ly>:SACTive

Activates the specified SmartGrid configuration. The command has the same effect as [LAYout<ly>:ACTive](#) but it has no query, and the active layout is specified by the suffix.

Suffix:
<ly> 1 to 8, index of the SmartGrid layout

Example: See [Section 18.5.1, "SmartGrid layout with zoom"](#), on page 911.

Usage: Setting only
Asynchronous command

LAYout<ly>:LABel <Label>

Defines a name for the specified layout (SmartGrid configuration).

Suffix:
<ly> 1 to 8, index of the SmartGrid layout

Parameters:
<Label> String with the layout name

Usage: Asynchronous command

LAYout<ly>:DIAGram<da>:COUNT?

Returns the number of diagrams in a specified layout.

You can query the maximum number of diagrams with
LAYout<ly>:DIAGram:COUNT? MAX.

Suffix:
<ly> 1 to 8, index of the SmartGrid layout
<da> Irrelevant, omit the suffix.

Return values:**<Count>** Number of diagrams**Usage:**Query only
Asynchronous command

LAYout<ly>:DIAGram<da>[:ENABle] <State>

Creates and displays a specified diagram in a specified layout. OFF deletes the diagram.

Suffix:**<ly>** 1 to 8, index of the SmartGrid layout**<da>** 1 to 8, index of the diagram**Parameters:****<State>** OFF | ON**Example:** See [Section 18.5.1, "SmartGrid layout with zoom"](#), on page 911.**Usage:** Asynchronous command

LAYout<ly>:DIAGram<da>:SOURce <SignalKeys>

Assigns the waveforms to a diagram.

Suffix:**<ly>** 1 to 8, index of the SmartGrid layout**<da>** 1 to 8, index of the diagram**Parameters:****<SignalKeys>** String with a comma-separated list of waveforms, e.g. "C1, C2, M1"**Example:** See [Section 18.5.1, "SmartGrid layout with zoom"](#), on page 911.**Usage:** Asynchronous command

LAYout<ly>:DIAGram<da>:LABel <Label>

Defines a name for the specified diagram in a specified layout.

Suffix:**<ly>** 1 to 8, index of the SmartGrid layout**<da>** 1 to 8, index of the diagram**Parameters:****<Label>** String with the diagram name**Usage:** Asynchronous command

LAYout<ly>:NODE<no>:COUNT?

Returns the maximum number of nodes that can be defined. This number is the maximum value for the node suffix.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout
 <no> Irrelevant, omit the suffix.

Return values:

<Count> Maximum value for the node suffix

Usage:

Query only
 Asynchronous command

LAYout<ly>:NODE<no>[:ENABLE] <State>

Creates the specified node in the specified layout. OFF deletes the node and its children.

The query returns whether the specified node exists (1) or not (0).

Suffix:

<ly> 1 to 8, index of the SmartGrid layout
 <no> Index of the node

Parameters:

<State> OFF | ON

Example:

See [Section 18.5.1, "SmartGrid layout with zoom"](#), on page 911.

Usage:

Asynchronous command

LAYout<ly>:NODE<no>:CHILdren<o>:CONTent<p>:ID <ID>

Sets the content ID, the number of the specified content type.

For example, the "Diagram5" has Type=DIAGRAM and ID=5.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout
 <no> Index of the node
 <o> 1 | 2, child index
 <p> Irrelevant, omit the suffix.

Parameters:

<ID> Numeric value

Example:

See [Section 18.5.1, "SmartGrid layout with zoom"](#), on page 911.

Usage:

Asynchronous command

LAYout<ly>:NODE<no>:CHILdren<o>:CONTent<p>:TYPE <Type>

Sets the content type for a specified child in a specified node: diagram, result table, another node, or empty.

For example, the "Diagram5" has Type=DIAGRAM and ID=5.

Suffix:

<ly>	1 to 8, index of the SmartGrid layout
<no>	Index of the node
<o>	1 2, child index
<p>	Irrelevant, omit the suffix.

Parameters:

<Type>	NONE DIAG DIAGRAM RES RESULT NODE
	DIAG = DIAGRAM, RES = RESULT
*RST:	NONE

Example: See [Section 18.5.1, "SmartGrid layout with zoom"](#), on page 911.

Usage: Asynchronous command

LAYout<ly>:NODE<no>:RATio <SplitRatio>

Sets the size ratio of the two children in the specified node.

Suffix:

<ly>	1 to 8, index of the SmartGrid layout
<no>	Index of the node

Parameters:

<SplitRatio>	Size ratio of the children. 0.5 assigns 50% of the node size to each child. 0.3 assigns 30% to child 1% and 70% to child 2.
Range:	0 to 1
Increment:	0.0001
*RST:	0.5

Usage: Asynchronous command

LAYout<ly>:NODE<no>:STYPe <SplitType>

Creates a second child (e.g. diagram) in the node if only one child exists, and sets the splitting of the node. If two children exist, only the splitting is set.

Suffix:

<ly>	1 to 8, index of the SmartGrid layout
<no>	Index of the node

Parameters:

<SplitType> HOR | HORIZontal | VERT | VERTical
 HOR = HORIZontal, VERT = VERTical
 *RST: NONE

Example: See [Section 18.5.1, "SmartGrid layout with zoom"](#), on page 911.

Usage: Asynchronous command

LAYout<ly>:RESult<n>:HORizontal:RATio <SplitRatio>

Sets the horizontal ratio between the cursor result table and the measurement result table inside the result display container if the results are displayed at the bottom.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout
 <n> Suffix is irrelevant, index of the result container

Parameters:

<SplitRatio> Range: 0 to 1
 Increment: 0.0001
 *RST: 0.8

Usage: Asynchronous command

LAYout<ly>:RESult<n>:VERTical:RATio <SplitRatio>

Sets the vertical ratio between the cursor result table and the other measurement results inside the result display container if the results are displayed on the right or left.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout
 <n> Suffix is irrelevant, index of the result container

Parameters:

<SplitRatio> Range: 0 to 1
 Increment: 0.0001
 *RST: 0.8

Usage: Asynchronous command

LAYout<ly>:RPOSition <ResultPosition>

Defines the position of the result container inside the layout.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

Parameters:

<ResultPosition> BOTT | BOTTOM | LEFT | RIGH | RIGHT
 *RST: NONE

Usage: Asynchronous command

18.8.4 Toolbar

DISPlay:TOOLbar:COUNT?	934
DISPlay:TOOLbar:DESelect	934
DISPlay:TOOLbar:REStore	934

DISPlay:TOOLbar:COUNT?

Returns the number of tools that are currently assigned to the toolbar.

Return values:

<ToolCount>	Range:	0 to 100
	Increment:	1
	*RST:	8

Usage: Query only
Asynchronous command

DISPlay:TOOLbar:DESelect

Removes all tools from the toolbar.

Usage: Setting only
SCPI confirmed
Asynchronous command

DISPlay:TOOLbar:REStore

Resets the toolbar to the factory configuration.

Usage: Setting only
SCPI confirmed
Asynchronous command


18.8.5 Annotations

The following `DISPlay:ANnotation` commands configure the annotations. With these commands you can select the type of annotation you want to add, define its value, position and color.

Defining the position of the annotation

With some of the following commands, you can define the position of the annotation on the screen. When defining the position, consider the following:

- A position is defined with two elements. The first element refers to the X dimension and the second to the Y dimension.
- The minimum position (0,0) is the lower left corner of the SmartGrid.



- The maximum position (100,100) is the upper right corner of the SmartGrid.



- The position is defined in percent with a range from 0 to 100. The minimum increment is 0.01.
- An annotation element cannot be moved outside the SmartGrid, the position is limited depending on the size of the annotation element.

Color catalog

When using annotations, you can select their color from a list of predefined colors. The following table gives an overview on the available colors and their command parameter name.

Table 18-2: Color catalog for annotations

Color	Color command parameter	Description
	WHITE	White
	LGRay	Light gray
	MGRay	Middle gray
	GRAY	Gray
	DGRay	Dark gray
	RED	Red

Color	Color command parameter	Description
	DORange	Dark orange
	ORANge	Orange
	LORange	Light orange
	YELLow	Yellow
	DGRen	Dark green
	GREen	Green
	LGRen	Light green
	LBLue	Light blue
	BLUE	Blue
	PINK	Pink
	LPINK	Light pink
	TURQuoise	Turquoise
	LPURple	Light purple
	PURPle	Purple

18.8.5.1 General settings

DISPlay:ANNotation:CLEar.....	936
DISPlay:ANNotation:COLor<m>:CATalog?.....	937
DISPlay:ANNotation:TRANsparency.....	937

DISPlay:ANNotation:CLEar

Removes all existing annotations.

Usage: Setting only
Asynchronous command

DISPlay:ANNotation:COLor<m>:CATalog?

Returns the list of possible colors, see [Color catalog for annotations](#).

Suffix:
<m> Irrelevant, omit the suffix.

Return values:
<ColorCatalog> WHITE | LGRay | MGRay | GRAY | DGRay | RED | DORange | ORANge | LORange | YELLow | DAGReen | GREen | LIGReen | LBLue | BLUE | PINK | LPINK | TURQuoise | LPURple | PURPle
Returned as comma-separated values:
WHIT,LGR,MGR,GRAY,DGR,RED,DOR,ORAN,LOR,YELL,DAG R,GRE,LIGR,LBL,BLUE,PINK,LPIN,TURQ,LPUR,PURP

Usage: Query only
Asynchronous command

DISPlay:ANNotation:TRANsparency <Transparency>

Sets a transparency of all annotations. For high transparency values, you can see the waveform display in the background. For lower transparency values, readability of the annotation improves.

Parameters:
<Transparency> Range: 0 to 90
Increment: 1
*RST: 0

Usage: Asynchronous command

18.8.5.2 Rectangle

DISPlay:ANNotation:RECTangle<m>:CLEar.....	937
DISPlay:ANNotation:RECTangle<m>:COLor.....	938
DISPlay:ANNotation:RECTangle<m>:HEIGHt.....	938
DISPlay:ANNotation:RECTangle<m>:HORizontal:POSition.....	938
DISPlay:ANNotation:RECTangle<m>:REMove.....	939
DISPlay:ANNotation:RECTangle<m>:VERTical:POSition.....	939
DISPlay:ANNotation:RECTangle<m>:WIDTh.....	939
DISPlay:ANNotation:RECTangle<m>[:VALue].....	939

DISPlay:ANNotation:RECTangle<m>:CLEar

Deletes all rectangle annotations.

Suffix:
<m> Irrelevant, omit the suffix.

Usage: Setting only
Asynchronous command

DISPlay:ANNotation:RECTangle<m>:COLor <Type>

Sets the color of the indicated rectangle annotation.

Suffix:
<m> 1 to <number of rectangle annotations>
Index of the rectangle annotation

Parameters:
<Type> WHITE | LGRay | MGRay | GRAY | DGRay | RED | DORange |
ORANGE | LORange | YELLOW | DAGReen | GREen | LIGReen |
LBLue | BLUE | PINK | LPINK | TURQuoise | LPURple | PURPLE
See [Color catalog for annotations](#).

Usage: Asynchronous command

DISPlay:ANNotation:RECTangle<m>:HEIGht <Height>

Sets the height (vertical size) of the rectangle annotation.

Suffix:
<m> 1 to <number of rectangle annotations>
Index of the rectangle annotation

Parameters:
<Height> In % of the screen.
Range: 0 to 100
Increment: 1
0 results in an invisible rectangle, 100 takes the complete height
of the screen.

Usage: Asynchronous command

DISPlay:ANNotation:RECTangle<m>:HORizontal:POSition <HorizontalPos>

Sets the horizontal position of the left edge of the rectangle annotation. See also [Defining the position of the annotation](#).

Suffix:
<m> 1 to <number of rectangle annotations>
Index of the rectangle annotation

Parameters:
<HorizontalPos> In % of the screen
Range: 0 to 99

Usage: Asynchronous command

DISPlay:ANNotation:RECTangle<m>:REMove

Removes the specified rectangle annotation from the screen.

Suffix:

<m> 1 to <number of rectangle annotations>
Index of the rectangle annotation

Usage:

Setting only
Asynchronous command

DISPlay:ANNotation:RECTangle<m>:VERTical:POSition <VerticalPos>

Sets the vertical position of the lower edge of the rectangle annotation. See also [Defining the position of the annotation](#).

Suffix:

<m> 1 to <number of rectangle annotations>
Index of the rectangle annotation

Parameters:

<VerticalPos> In % of the screen
Range: 0 to 99

Usage:

Asynchronous command

DISPlay:ANNotation:RECTangle<m>:WIDTH <Width>

Sets the width (horizontal size) of the rectangle annotation.

Suffix:

<m> 1 to <number of rectangle annotations>
Index of the rectangle annotation

Parameters:

<Width> In % of the screen
Range: 0 to 100
Increment: 1
0 results in an invisible rectangle, 100 takes the complete width of the screen.

Usage:

Asynchronous command

DISPlay:ANNotation:RECTangle<m>[:VALue] [<HorizontalPos>],[<VerticalPos>],[<Width>],[<Height>]

Adds a new rectangle annotation, or replaces the annotation if it already exists. If no parameters are defined, the default values are used.

All parameters are given in % of the screen.

Suffix:

<m> *
Index of the created rectangle annotation

Parameters:

<HorizontalPos> Range: 0 to 99
<VerticalPos> Range: 0 to 99
<Width> Range: 0 to 100
<Height> Range: 0 to 100

Usage: Asynchronous command

18.8.5.3 Arrow

DISPlay:ANNotation:ARRow<m>:CLEar.....	940
DISPlay:ANNotation:ARRow<m>:COLor.....	940
DISPlay:ANNotation:ARRow<m>:DIRection.....	941
DISPlay:ANNotation:ARRow<m>:HEIGht.....	941
DISPlay:ANNotation:ARRow<m>:HORizontal:POSition.....	941
DISPlay:ANNotation:ARRow<m>:REMove.....	941
DISPlay:ANNotation:ARRow<m>:VERTical:POSition.....	942
DISPlay:ANNotation:ARRow<m>:WIDTh.....	942
DISPlay:ANNotation:ARRow<m>[:VALue].....	942

DISPlay:ANNotation:ARRow<m>:CLEar

Deletes all arrow annotations.

Suffix:

<m> Irrelevant, omit the suffix.

Usage:

Setting only
Asynchronous command

DISPlay:ANNotation:ARRow<m>:COLor <Type>

Sets the color of the indicated arrow annotation.

Suffix:

<m> 1 to <number of arrow annotations>
Index of the arrow annotation

Parameters:

<Type> WHITe | LGRay | MGRay | GRAY | DGRay | RED | DORange |
ORANge | LORange | YELLow | DAGReen | GREen | LIGReen |
LBLue | BLUE | PINK | LPINK | TURQuoise | LPURple | PURPle
See [Color catalog for annotations](#).

Usage:

Asynchronous command

DISPlay:ANnotation:ARRow<m>:DIRection <Type>

Sets the direction of the indicated arrow annotation from starting point to arrow tip.

Suffix:

<m> 1 to <number of arrow annotations>
Index of the arrow annotation

Parameters:

<Type> TLEFt | TRIGht | BLEFt | BRIGht
TLEFt: to top left
TRIGht: to top right
BLEFt: to bottom left
BRIGht: to bottom right

Usage: Asynchronous command

DISPlay:ANnotation:ARRow<m>:HEIGht <Height>

Sets the height (vertical size) of the arrow annotation.

Suffix:

<m> 1 to <number of arrow annotations>
Index of the arrow annotation

Parameters:

<Height> In % of the screen.
Range: 0 to 100
Increment: 1
0 results in an invisible rectangle, 100 takes the complete height of the screen.

Usage: Asynchronous command

DISPlay:ANnotation:ARRow<m>:HORizontal:POSition <HorizontalPos>

Sets the horizontal position of the left point of the arrow annotation. See also [Defining the position of the annotation](#).

Suffix:

<m> 1 to <number of arrow annotations>
Index of the arrow annotation

Parameters:

<HorizontalPos> In % of the screen
Range: 0 to 99

Usage: Asynchronous command

DISPlay:ANnotation:ARRow<m>:REMOve

Removes the specified arrow annotation from the screen.

Suffix:

<m> 1 to <number of arrow annotations>
Index of the arrow annotation

Usage:

Setting only
Asynchronous command

DISPlay:ANNotation:ARRow<m>:VERTical:POSition <VerticalPos>

Sets the vertical position of the lower point of the arrow annotation. See also [Defining the position of the annotation](#).

Suffix:

<m> 1 to <number of arrow annotations>
Index of the arrow annotation

Parameters:

<VerticalPos> In % of the screen
Range: 0 to 99

Usage:

Asynchronous command

DISPlay:ANNotation:ARRow<m>:WIDTh <Width>

Sets the width (horizontal size) of the arrow annotation.

Suffix:

<m> 1 to <number of arrow annotations>
Index of the arrow annotation

Parameters:

<Width> In % of the screen
Range: 0 to 100
Increment: 1
0 results in an invisible rectangle, 100 takes the complete width of the screen.

Usage:

Asynchronous command

DISPlay:ANNotation:ARRow<m>[:VALue] [<HorizontalPos>],[<VerticalPos>],[<Width>],[<Height>]

Adds a new arrow annotation, or replaces the annotation if it already exists. If no parameters are defined, the default values are used.

All parameters are given in % of the screen.

Suffix:

<m> *
Index of the created arrow annotation

Parameters:

<HorizontalPos> Range: 0 to 99

<VerticalPos>	Range:	0 to 99
<Width>	Range:	0 to 100
<Height>	Range:	0 to 100
Usage:	Asynchronous command	

18.8.5.4 Text

DISPlay:ANNotation:TEXT<m>:CLEar.....	943
DISPlay:ANNotation:TEXT<m>:COLor.....	943
DISPlay:ANNotation:TEXT<m>:FONTsize.....	943
DISPlay:ANNotation:TEXT<m>:HORizontal:POSition.....	944
DISPlay:ANNotation:TEXT<m>:REMove.....	944
DISPlay:ANNotation:TEXT<m>:VERTical:POSition.....	944
DISPlay:ANNotation:TEXT<m>[:VALue].....	944

DISPlay:ANNotation:TEXT<m>:CLEar

Deletes all text annotations.

Suffix:

<m> Irrelevant, omit the suffix.

Usage:

Setting only
Asynchronous command

DISPlay:ANNotation:TEXT<m>:COLor <Type>

Sets the color of the indicated text annotation.

Suffix:

<m> 1 to <number of text annotations>
Index of the text annotation

Parameters:

<Type> WHITE | LGRay | MGRay | GRAY | DGRay | RED | DORange |
ORANge | LORange | YELLOW | DAGReen | GREen | LIGReen |
LBLue | BLUE | PINK | LPINK | TURQuoise | LPURple | PURPLE
See [Color catalog for annotations](#).

Usage:

Asynchronous command

DISPlay:ANNotation:TEXT<m>:FONTsize <FontSize>

Sets the font size of the text.

Suffix:

<m> 1 to <number of text annotations>
Index of the text annotation

Parameters:

<FontSize> Range: 12 to 30
 Default unit: px

Usage: Asynchronous command

DISPlay:ANNotation:TEXT<m>:HORizontal:POSition <HorizontalPos>

Sets the horizontal position of the left edge of the text annotation. See also [Defining the position of the annotation](#).

Suffix:

<m> 1 to <number of text annotations>
 Index of the text annotation

Parameters:

<HorizontalPos> In % of the screen
 Range: 0 to 99

Usage: Asynchronous command

DISPlay:ANNotation:TEXT<m>:REMove

Removes the specified text annotation from the screen.

Suffix:

<m> 1 to <number of text annotations>
 Index of the text annotation

Usage: Setting only
 Asynchronous command

DISPlay:ANNotation:TEXT<m>:VERTical:POSition <VerticalPos>

Sets the vertical position of the lower edge of the text annotation. See also [Defining the position of the annotation](#).

Suffix:

<m> 1 to <number of text annotations>
 Index of the text annotation

Parameters:

<VerticalPos> In % of the screen
 Range: 0 to 99

Usage: Asynchronous command

DISPlay:ANNotation:TEXT<m>[:VALue] [<Text>]

Adds a new text annotation or replaces the text value of an already existing text annotation.

Suffix:	
<m>	* Index of the created text annotation
Parameters:	
<Text>	String with the annotation text
Usage:	Asynchronous command

18.8.5.5 Draw

DISPlay:ANNotation:PLINe<m>:CLEar.....	945
DISPlay:ANNotation:PLINe<m>:COLor.....	945
DISPlay:ANNotation:PLINe<m>:EXTend.....	945
DISPlay:ANNotation:PLINe<m>:REMove.....	946
DISPlay:ANNotation:PLINe<m>[:VALue].....	946

DISPlay:ANNotation:PLINe<m>:CLEar

Deletes all draw annotations.

Suffix:	
<m>	Irrelevant, omit the suffix.
Usage:	Setting only Asynchronous command

DISPlay:ANNotation:PLINe<m>:COLor <Type>

Sets the color of the indicated draw annotation.

Suffix:	
<m>	1 to <number of draw annotations> Index of the drawn annotation.
Parameters:	
<Type>	WHITe LGRay MGRay GRAY DGRay RED DORange ORANge LORange YELLow DAGReen GREen LIGReen LBLue BLUE PINK LPINK TURQuoise LPURple PURPle See Color catalog for annotations .
Usage:	Asynchronous command

DISPlay:ANNotation:PLINe<m>:EXTend [<x>],[<y>]

Expands the drawn item with a segment. The x and y position of the existing endpoint is the start point of the new segment. The segments are always straight lines.

Suffix:	
<m>	1 to <number of draw annotations> Index of the draw annotation

Setting parameters:

<x> Horizontal position of the endpoint of the new segment

<y> Vertical position of the endpoint of the new segment

Usage: Setting only
Asynchronous command

DISPlay:ANNotation:PLINe<m>:REMove

Removes the specified draw annotation from the screen.

Suffix:

<m> 1 to <number of draw annotations>
Index of the draw annotation

Usage: Setting only
Asynchronous command

DISPlay:ANNotation:PLINe<m>[:VALue] <x1>,<y1>,<x2>,<y2>,<xn>

Adds a new draw annotation, or replaces the annotation if it already exists. If no parameters are defined, the default values are used.

All parameters are given in % of the screen.

Suffix:

<m> *
Index of the created draw annotation

Parameters:

<x1> Horizontal position of the start point of the new line

<y1> Vertical position of the start point of the new line

<x2> Horizontal position of the endpoint of the new line

<y2> Vertical position of the endpoint of the new line

<xn> Vertical or horizontal position of extension points. For each point, you need two values, first the horizontal and second the vertical value. All values are separated by commas.

Usage: Asynchronous command

18.8.6 Appearance

- [Waveform colors](#)..... 947
- [Grid appearance](#)..... 950
- [Dialog appearance](#)..... 952
- [Peak list appearance](#)..... 953

18.8.6.1 Waveform colors

DISPlay:COLor:SIGNal:CATalog?	947
DISPlay:COLor:SIGNal:COLor	947
DISPlay:COLor:SIGNal:ASSign	947
DISPlay:COLor:SIGNal:USE	948

DISPlay:COLor:SIGNal:CATalog?

Returns a list of valid signal names. The signal names are needed in other DISPlay:COLor commands to set the <Signal> parameter.

Return values:

<Signals> Comma-separated list of signal names, see [Section 18.4.1](#), "Waveform parameter", on page 910

Usage:

Query only
Asynchronous command

DISPlay:COLor:SIGNal:COLor <Signal>,<Value>**DISPlay:COLor:SIGNal:COLor? <Signal>**

Sets the color of the selected waveform.

Parameters:

<Value> Decimal value of the ARGB color. Use the color dialog box on the instrument to get the hex value of the color, and convert the hex value to a decimal value.
0 is fully transparent black.
4278190080 (dec) = FF000000 (hex) is opaque black.
4294967295 (dec) = FFFFFFFF (hex) is opaque white.
To reset the color to its default, use
DISPlay:COLor:SIGNal:COLor <Signal>,DEF.

Parameters for setting and query:

<Signal> Signal name as returned by [DISPlay:COLor:SIGNal:CATalog?](#).

Usage:

Asynchronous command

Manual operation: See "Color" on page 97

DISPlay:COLor:SIGNal:ASSign <Signal>,<ColorTable>**DISPlay:COLor:SIGNal:ASSign? <Signal>**

Assigns a color table to the source waveform instead of a dedicated color.

Parameters:

<ColorTable> String with the name of the color table.
Valid values are: "FalseColors", "Spectrum",
"SingleEvent" and "Temperature".

Parameters for setting and query:

<Signal> Signal name as returned by `DISPlay:COLor:SIGNal:CATalog?`.

Usage: Asynchronous command

Manual operation: See "[Assigned color table](#)" on page 96

DISPlay:COLor:SIGNal:USE <Signal>,<State>

DISPlay:COLor:SIGNal:USE? <Signal>

If enabled, the selected waveform is displayed according to its assigned color table.

If disabled, the selected color is displayed, and the intensity of the signal color varies according to the cumulative occurrence of the values.

The setting is not available for digital channels and parallel buses.

Parameters:

<State> OFF | ON

Parameters for setting and query:

<Signal> NONE | C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | FGAin | FAMplitude | FPHase | FREF1 | FREF2 | FREF3 | FREF4 | HWAVEform1 | HWAVEform2 | HWAVEform3 | HWAVEform4 | HWAVEform5 | HWAVEform6 | HWAVEform7 | HWAVEform8 | HMEas1 | HMEas2 | HMEas3 | HMEas4 | HMEas5 | HMEas6 | HMEas7 | HMEas8 | HMEas9 | HMEas10 | HMEas11 | HMEas12 | HMEas13 | HMEas14 | HMEas15 | HMEas16 | HMEas17 | HMEas18 | HMEas19 | HMEas20 | HMEas21 | HMEas22 | HMEas23 | HMEas24 | M1 | M2 | M3 | M4 | M5 | M6 | M7 | M8 | TRK1 | TRK2 | TRK3 | TRK4 | TRK5 | TRK6 | TRK7 | TRK8 | TRK9 | TRK10 | TRK11 | TRK12 | TRK13 | TRK14 | TRK15 | TRK16 | TRK17 | TRK18 | TRK19 | TRK20 | TRK21 | TRK22 | TRK23 | TRK24 | PBUS1 | PBUS2 | PBUS3 | PBUS4 | PA1QPOWER1 | PA2QPOWER1 | PA3QPOWER1 | PA4QPOWER1 | PA5QPOWER1 | PA6QPOWER1 | PA1HPOWER1 | PA2HPOWER1 | PA3HPOWER1 | PA4HPOWER1 | PA5HPOWER1 | PA6HPOWER1 | PA1SPOWER1 | PA2SPOWER1 | PA3SPOWER1 | PA4SPOWER1 | PA5SPOWER1 | PA6SPOWER1 | PA1IPOWER | PA2IPOWER | PA3IPOWER | PA4IPOWER | PA5IPOWER | PA6IPOWER | PA1OPOWER1 | PA2OPOWER1 | PA3OPOWER1 | PA4OPOWER1 | PA5OPOWER1 | PA6OPOWER1 | PA1OPOWER2 | PA2OPOWER2 | PA3OPOWER2 | PA4OPOWER2 | PA5OPOWER2 | PA6OPOWER2 | PA1OPOWER3 | PA2OPOWER3 | PA3OPOWER3 | PA4OPOWER3 | PA5OPOWER3 | PA6OPOWER3 | PA1TOPOWER | PA2TOPOWER | PA3TOPOWER | PA4TOPOWER | PA5TOPOWER | PA6TOPOWER | PA1SOA | PA2SOA | PA3SOA | PA4SOA | PA5SOA | PA6SOA | PTHREE1HPOWER1 | PTHREE2HPOWER1 | PTHREE3HPOWER1 | PTHREE4HPOWER1 | PTHREE5HPOWER1 | PTHREE6HPOWER1 | PTHREE1HPOWER2 | PTHREE2HPOWER2 | PTHREE3HPOWER2 | PTHREE4HPOWER2 | PTHREE5HPOWER2 | PTHREE6HPOWER2 | PTHREE1HPOWER3 | PTHREE2HPOWER3 | PTHREE3HPOWER3 | PTHREE4HPOWER3 | PTHREE5HPOWER3 | PTHREE6HPOWER3 | PTHREE1HTPOWER | PTHREE2HTPOWER | PTHREE3HTPOWER | PTHREE4HTPOWER | PTHREE5HTPOWER | PTHREE6HTPOWER | PTHREE1QPOWER1 | PTHREE2QPOWER1 | PTHREE3QPOWER1 | PTHREE4QPOWER1 | PTHREE5QPOWER1 | PTHREE6QPOWER1 | PTHREE1QPOWER2 | PTHREE2QPOWER2 | PTHREE3QPOWER2 | PTHREE4QPOWER2 | PTHREE5QPOWER2 | PTHREE6QPOWER2 |

PTHREE1QPOWER3 | PTHREE2QPOWER3 |
 PTHREE3QPOWER3 | PTHREE4QPOWER3 |
 PTHREE5QPOWER3 | PTHREE6QPOWER3 |
 PTHREE1QTPOWER | PTHREE2QTPOWER |
 PTHREE3QTPOWER | PTHREE4QTPOWER |
 PTHREE5QTPOWER | PTHREE6QTPOWER | R1 | R2 | R3 |
 R4 | R5 | R6 | R7 | R8 | DREF0 | DREF1 | DREF2 | DREF3 |
 DREF4 | DREF5 | DREF6 | DREF7 | DREF8 | DREF9 |
 DREF10 | DREF11 | DREF12 | DREF13 | DREF14 | DREF15 |
 SBUS1 | SBUS2 | SBUS3 | SBUS4 | SPECAVER1 |
 SPECAVER2 | SPECAVER3 | SPECAVER4 | SPECMAXH1 |
 SPECMAXH2 | SPECMAXH3 | SPECMAXH4 | SPECMINH1 |
 SPECMINH2 | SPECMINH3 | SPECMINH4 | SPECNORM1 |
 SPECNORM2 | SPECNORM3 | SPECNORM4 | XY1 | XY2 |
 XY3 | XY4 | O2C1 | O2C2 | O2C3 | O2C4 | O2C5 | O2C6 |
 O2C7 | O2C8 | O3C1 | O3C2 | O3C3 | O3C4 | O3C5 | O3C6 |
 O3C7 | O3C8 | O4C1 | O4C2 | O4C3 | O4C4 | O4C5 | O4C6 |
 O4C7 | O4C8 | O5C1 | O5C2 | O5C3 | O5C4 | O5C5 | O5C6 |
 O5C7 | O5C8 | O6C1 | O6C2 | O6C3 | O6C4 | O6C5 | O6C6 |
 O6C7 | O6C8 | O7C1 | O7C2 | O7C3 | O7C4 | O7C5 | O7C6 |
 O7C7 | O7C8 | O8C1 | O8C2 | O8C3 | O8C4 | O8C5 | O8C6 |
 O8C7 | O8C8 | O9C1 | O9C2 | O9C3 | O9C4 | O9C5 | O9C6 |
 O9C7 | O9C8 | O10C1 | O10C2 | O10C3 | O10C4 | O10C5 |
 O10C6 | O10C7 | O10C8 | O11C1 | O11C2 | O11C3 | O11C4 |
 O11C5 | O11C6 | O11C7 | O11C8 | O2R1 | O2R2 | O2R3 |
 O2R4 | O2R5 | O2R6 | O2R7 | O2R8 | O3R1 | O3R2 | O3R3 |
 O3R4 | O3R5 | O3R6 | O3R7 | O3R8 | O4R1 | O4R2 | O4R3 |
 O4R4 | O4R5 | O4R6 | O4R7 | O4R8 | O5R1 | O5R2 | O5R3 |
 O5R4 | O5R5 | O5R6 | O5R7 | O5R8 | O6R1 | O6R2 | O6R3 |
 O6R4 | O6R5 | O6R6 | O6R7 | O6R8 | O7R1 | O7R2 | O7R3 |
 O7R4 | O7R5 | O7R6 | O7R7 | O7R8 | O8R1 | O8R2 | O8R3 |
 O8R4 | O8R5 | O8R6 | O8R7 | O8R8 | O9R1 | O9R2 | O9R3 |
 O9R4 | O9R5 | O9R6 | O9R7 | O9R8 | O10R1 | O10R2 |
 O10R3 | O10R4 | O10R5 | O10R6 | O10R7 | O10R8 | O11R1 |
 O11R2 | O11R3 | O11R4 | O11R5 | O11R6 | O11R7 | O11R8 |
 TREF1 | TREF2 | TREF3 | TREF4 | TREF5 | TREF6 | TREF7 |
 TREF8 | EYE1 | EYE2 | EYE3 | EYE4 | EYE5 | EYE6 | EYE7 |
 EYE8

Signal name as returned by `DISPlay:COLor:SIGNal:CATalog?`.

Usage: Asynchronous command

Manual operation: See "Use color table" on page 96

18.8.6.2 Grid appearance

<code>DISPlay:DIAGram:CROSShair</code>	951
<code>DISPlay:DIAGram:FINegrid</code>	951
<code>DISPlay:DIAGram:GRID</code>	951

DISPlay:DIAGram:LABels.....	951
DISPlay:DIAGram:XPDivlabel.....	952
DISPlay:DIAGram:XFIXed.....	952
DISPlay:DIAGram:YFIXed.....	952

DISPlay:DIAGram:CROSShair <Crosshair>

If selected, a crosshair is displayed in the diagram area. A crosshair allows you to select a specific data point by its coordinates.

Parameters:

<Crosshair> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Show crosshair"](#) on page 99

DISPlay:DIAGram:FINegrid <ShowFineScale>

If selected, the crosshair is displayed as a ruler with scale markers. If disabled, the crosshair is shown as dashed lines.

Parameters:

<ShowFineScale> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Show fine grid scale"](#) on page 99

DISPlay:DIAGram:GRID <Show>

If selected, a grid is displayed in the diagram area. A grid helps you associate a specific data point to its exact value on the x- or y-axis.

Parameters:

<Show> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Show grid"](#) on page 98

DISPlay:DIAGram:LABels <ShowLabels>

If selected, labels mark values on the x- and y-axes in specified intervals in the diagram.

Parameters:

<ShowLabels> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Show labels"](#) on page 99

DISPlay:DIAGram:XPDivlabel <ShowDivLabelX>

If selected, the time scale value is shown at the diagram bottom instead of the horizontal grid labels. For example, 10 ns/div is shown instead of the values 0, 10, 20, 30... ns.

Parameters:

<ShowDivLabelX> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Show div label \(x\)"](#) on page 99

DISPlay:DIAGram:XFIXed <XGridFixed>

If enabled, the vertical grid lines remain in their position when the horizontal position is changed. Only the values at the grid lines are adapted.

Parameters:

<XGridFixed> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Keep X-grid fixed"](#) on page 99

DISPlay:DIAGram:YFIXed <YGridFixed>

If enabled, the horizontal grid lines remain in their position when the position of the curve is changed. Only the values at the grid lines are adapted.

Fixed horizontal grid lines correspond to the behavior of traditional oscilloscopes.

Parameters:

<YGridFixed> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Keep Y-grid fixed"](#) on page 99

18.8.6.3 Dialog appearance

DISPlay:DIALog:FONTsize	953
DISPlay:DIALog:TRANsparency	953
DISPlay:RESult:FONTsize	953

DISPlay:DIALog:FONTsize <DialogFontSize>

Sets the font size of the text in dialog boxes.

Parameters:

<DialogFontSize> Range: 16 to 25
 Increment: 1
 *RST: 21

Usage: Asynchronous command

Manual operation: See ["Font size \(Dialog\)"](#) on page 100

DISPlay:DIALog:TRANsparency <DialogTransp>

Sets the transparency of the dialog box background. For high transparency values, you can see the waveform display in the background, and possibly check the effect of the changed setting. For lower transparency values, readability in the dialog box improves.

Parameters:

<DialogTransp> Range: 0 to 70
 Increment: 1
 *RST: 0

Usage: Asynchronous command

Manual operation: See ["Transparency \(Dialog\)"](#) on page 100

DISPlay:RESult:FONTsize <ResultFontSize>

Sets the font size of the text in result tables.

Parameters:

<ResultFontSize> Range: 16 to 25
 Increment: 1
 *RST: 21

Usage: Asynchronous command

Manual operation: See ["Font size \(Result dialog\)"](#) on page 100

18.8.6.4 Peak list appearance

[CALCulate:SPECTrum<sp>:PLISt:LABel:BORDER](#).....953

CALCulate:SPECTrum<sp>:PLISt:LABel:BORDER <LabelBorder>

Defines the layout of the labels, full border or none.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<LabelBorder> NOBorder | FULL
 FULL: Full border
 *RST: FULL

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 101

18.8.7 Display

- [Persistence](#)..... 954
- [Signal](#)..... 955
- [Backlight](#)..... 956
- [Clear results](#)..... 956

18.8.7.1 Persistence

DISPlay:PERSiStence:INFinite	954
DISPlay:PERSiStence:RESet	954
DISPlay:PERSiStence:TIME	954
DISPlay:PERSiStence[:STATe]	955

DISPlay:PERSiStence:INFinite <State>

If infinite persistence is enabled, each new waveform point remains on the screen until this option is disabled. Use infinite persistence to display rare events in the signal.

Parameters:

<State> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Infinite persistence"](#) on page 102

DISPlay:PERSiStence:RESet

Resets the display, removing all persistent waveform points.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Reset"](#) on page 103

DISPlay:PERSiStence:TIME <Time>

Sets a time factor that controls how long the waveforms points fade away from the display. Thus, the MXO 5C emulates the persistence of analog phosphor screens.

Parameters:

<Time> Range: 0.05 to 50
 Increment: 0.05
 *RST: 0.05
 Default unit: s

Usage: Asynchronous command

Manual operation: See ["Time"](#) on page 103

DISPlay:PERSistence[:STATe] <State>

If enabled, each new data point in the diagram area remains on the screen for the duration defined using [DISPlay:PERSistence:TIME](#), or as long as [DISPlay:PERSistence:INFinite](#) is enabled.

If disabled, the signal value is only displayed as long as it actually occurs.

Parameters:

<State> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Enable"](#) on page 102

18.8.7.2 Signal

DISPlay:INTensity	955
DISPlay:DIAGram:STYLE	955

DISPlay:INTensity <Intensity>

The intensity determines the strength of the waveform line in the diagram. Enter a percentage between 0 (not visible) and 100% (strong). The default value is 50%.

Parameters:

<Intensity> Range: 0 to 100
 Increment: 1
 *RST: 50
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Intensity"](#) on page 103

DISPlay:DIAGram:STYLE <Style>

Selects the style in which the waveform is displayed.

Parameters:

<Style> VECTors | DOTS

VECTors

The individual data points are connected by a line.

DOTS

Only the individual data points are displayed.

*RST: VECTors

Usage: Asynchronous command

Manual operation: See ["Waveform style"](#) on page 103

18.8.7.3 Backlight

[DISPlay:BACKlight\[:BRIGtness\]](#).....956

[DISPlay:BACKlight:DIMMING](#).....956

DISPlay:BACKlight[:BRIGtness] <LCDIntensity>

Sets the background luminosity of the touchscreen.

Parameters:

<LCDIntensity> Range: 5 to 100
 Increment: 1
 *RST: 90
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Brightness"](#) on page 104

DISPlay:BACKlight:DIMMING <InactiveTime>

Selects a time, after which the monitor brightness is reduced, if the instrument was inactive. Remote control of the instrument is also considered as an activity.

Parameters:

<InactiveTime> OFF | T1Minute | T2Minutes | T3Minutes | T5Minutes |
 T10Minutes | T15Minutes | T20Minutes | T25Minutes |
 T30Minutes | T45Minutes | T1Hour | T2Hours | T3Hours |
 T4Hours
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Dimm on user inactivity"](#) on page 104

18.8.7.4 Clear results**DISPlay:CLR**

Deletes all measurement results including all waveforms and statistics.

Usage: Setting only
Asynchronous command

Manual operation: See ["Clear"](#) on page 64

18.8.8 Save/Recall

18.8.8.1 Autonoming

MMEMory:AUTonaming:PREFix	957
MMEMory:AUTonaming:TIME	957
MMEMory:AUTonaming:INDex	957
MMEMory:AUSave:ENABle	957
MMEMory:AUSave:INTerval	958
MMEMory:AUTonaming:USERtext	958
MMEMory:AUTonaming:DEFaultpath	958
MMEMory:AUTonaming:RESall	958
MMEMory:AUTonaming:RESPath	958
MMEMory:AUTonaming:TEXT	959

MMEMory:AUTonaming:PREFix <MainNmeStemSt>

MMEMory:AUTonaming:TIME <DateTime>

MMEMory:AUTonaming:INDex <NameIndex>

Includes or excludes the prefix/ date/time /index in the filename pattern for automatic filename generation. This name is used as the default filename.

The prefix indicates the type of data that is saved, for example, RefCurve, Settings.

Parameters:

<NameIndex> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Index"](#) on page 115

MMEMory:AUSave:ENABle <EnableAutosave>

Enables the automatic saving of the waveform. You can set the autosave interval with [MMEMory:AUSave:INTerval](#).

Parameters:

<EnableAutosave> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Enable autosave"](#) on page 115

MMEMory:AUSave:INTerval <AutosaveIntvl>

Defines the time interval for the automatic saving of the waveform, if [MMEMory:AUSave:ENABLE](#) is set to ON.

Parameters:

<AutosaveIntvl> Range: 1 to 360000
 Increment: 1
 *RST: 300
 Default unit: s

Usage: Asynchronous command

Manual operation: See ["Enable autosave"](#) on page 115

MMEMory:AUTonaming:USERtext <State>

If enabled, inserts the specified user text after the prefix.

You can define the text with [MMEMory:AUTonaming:TEXT](#).

Parameters:

<State> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["User text"](#) on page 114

MMEMory:AUTonaming:DEFAULTpath <Path>

Sets the path where data and settings files are stored. On the instrument, all user data is written to `/home/storage/userData`. You can create subfolders in this folder.

Parameters:

<Path> String parameter

Usage: Asynchronous command

Manual operation: See ["Default path for all file operations"](#) on page 115

MMEMory:AUTonaming:RESall

Resets all autonaming settings to the default value, including the path.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Reset path"](#) on page 115

MMEMory:AUTonaming:RESPath

Resets the path for file operations to the factory default path.

Usage: Setting only
Asynchronous command

Manual operation: See ["Reset path"](#) on page 115

MMEMory:AUTonaming:TEXT <NameString>

Defines a text that can be included in the autonaming pattern.

Parameters:
<NameString> String parameter

Usage: Asynchronous command

Manual operation: See ["User text"](#) on page 114

18.8.9 Preset

USERdefined:PRESet:NAME	959
USERdefined:PRESet:OPEN	959
USERdefined:PRESet:SAVE	959
USERdefined:PRESet[:ENABLE]	960

USERdefined:PRESet:NAME <Name>

Sets the path, the filename and the file format of the preset file.

Parameters:
<Name> String with path and filename with extension .set.

Example: `USERdefined:PRESet:NAME '/home/storage/userData/
settings/Preset_SPI.set'`

Manual operation: See ["Preset file selection"](#) on page 107

USERdefined:PRESet:OPEN

Opens and loads the preset file that is defined with [USERdefined:PRESet:NAME](#).

Usage: Event

Manual operation: See ["Preset file selection"](#) on page 107

USERdefined:PRESet:SAVE

Saves the current settings as a preset file. You define the storage location and file-name with [USERdefined:PRESet:NAME](#).

Usage: Event

Manual operation: See ["Save, Open"](#) on page 108

USERdefined:PRESet[:ENABLE] <Name>

If enabled, the settings from the selected saveset are restored when the [Preset] key is pressed.

If disabled, [Preset] sets the instrument to the factory defaults.

The saveset to be used as preset file is defined with `USERdefined:PRESet:NAME`.

Parameters:

<Name> OFF | ON
 *RST: OFF

Manual operation: See "Enable user-defined preset" on page 107

18.8.10 Maintenance

Use also:

- `*CAL?` on page 917
- `*TST?` on page 920

<code>CALibration[:ALL]</code>	960
<code>CALibration:DATE?</code>	960
<code>CALibration:TIME?</code>	961
<code>CALibration:RESult?</code>	961
<code>SERVice:REPort</code>	961
<code>SYSTem:APUP</code>	961

CALibration[:ALL]

`Calibration:ALL` starts the self-alignment process without returning status information. To get the status, use the commands of the operation status register.

`Calibration:ALL?` starts the self-alignment process and returns information on the state of the self-alignment. (Same as `*CAL?`).

The process can take several minutes. Consider your timeout settings.

Return values:

<Result> Numeric status indicator. Return values $\neq 0$ indicate an error.

Usage: Asynchronous command

CALibration:DATE?

Returns the date of the last self-alignment.

Return values:

<Date>

Usage: Query only
 Asynchronous command

Manual operation: See ["Date, Time, Overall alignment state"](#) on page 110

CALibration:TIME?

Returns the time of the last self-alignment.

Return values:

<Time>

Usage: Query only
Asynchronous command

Manual operation: See ["Date, Time, Overall alignment state"](#) on page 110

CALibration:RESult?

Returns the result of the last self-alignment and the current alignment status. In remote mode, *CAL? provides more detailed information.

Return values:

<ResultState> PASSEd | FAILEd | NOALigndata
*RST: FAILEd

Usage: Query only
Asynchronous command

Manual operation: See ["Date, Time, Overall alignment state"](#) on page 110

SERvice:REPort

Creates a service report.

The service report is a ZIP file with a complete bug report, all relevant setup information, reporting and log files, alignment files, and the instrument configuration.

If a USB flash drive is connected, the report is saved on the USB flash drive. Otherwise, the report is saved in the user data folder `/home/storage/userData`.

Usage: Event
Asynchronous command

Manual operation: See ["Create report"](#) on page 113

SYSTem:APUP <AutoPowerUp>

If enabled, the instrument powers up automatically when it is connected to the mains voltage.

Parameters:

<AutoPowerUp> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See "[Auto power up](#)" on page 112

18.9 Acquisition and waveform setup

18.9.1 Starting and stopping acquisition

Use the following commands to start and stop acquisitions.

RUNCont	962
RUN	962
RUNSingle	962
SINGLE	962
STOP	962

RUNCont

RUN

Starts the continuous acquisition.

Usage: Setting only
 Asynchronous command

Manual operation: See "[\[Run / Stop\]](#)" on page 53

RUNSingle

SINGLE

Starts a defined number of acquisition cycles. The number of cycles is set with [ACquire:COUNT](#).

Usage: Setting only
 Asynchronous command

Manual operation: See "[\[Single\]](#)" on page 53

STOP

Stops the running acquisition.

Usage: Event
 Asynchronous command

Manual operation: See "[\[Run / Stop\]](#)" on page 53

18.9.2 Horizontal setup

AUToscale.....	963
TIMEbase:SCALE.....	963
TIMEbase:RANGE.....	963
TIMEbase:DIVisions?.....	964
TIMEbase:HORizontal:POSition.....	964
TIMEbase:REFerence.....	964

AUToscale

Performs an autoset process: analyzes the enabled channel signals, and obtains appropriate horizontal, vertical, and trigger settings to display stable waveforms.

Rohde & Schwarz does not recommend using the autoset in remote control. To adjust the oscilloscope remotely, especially for automated testing applications, use the remote commands that adjust the horizontal, vertical and trigger settings.

Usage: Event
Asynchronous command

TIMEbase:SCALE <TimebaseScale>

Sets the horizontal scale, the time per division, for all waveforms in the time domain, for example, channel and math waveforms.

Parameters:

<TimebaseScale> Range: 200E-12 to 10E+3
Increment: 1E-12
*RST: 20E-9
Default unit: s/div

Usage: Asynchronous command

Manual operation: See "[Scale]" on page 55

TIMEbase:RANGE <TimebaseRange>

Sets the time of one acquisition, which is the time across the 10 divisions of the diagram: *Acquisition time = Time scale * 10 divisions.*

Parameters:

<TimebaseRange> Range: 2E-9 to 100E+3
Increment: 1E-12
*RST: 200E-9
Default unit: s

Usage: Asynchronous command

Manual operation: See "Timebase range" on page 118

TIMEbase:DIVisions?

Returns the number of horizontal divisions on the screen. The number cannot be changed.

Return values:

<HorizDivCnt> *RST: 10

Usage:

Query only
Asynchronous command

TIMEbase:HORizontal:POSition <Position>

Defines the time distance between the reference point and the trigger point, which is the zero point of the diagram. The horizontal position is also known as trigger offset.

Parameters:

<Position> Range: -9.95E+6 to 1E+26
Increment: 1E-12
*RST: 0
Default unit: s

Usage:

Asynchronous command

Manual operation: See "[Position]" on page 54

TIMEbase:REFerence <RescaleCtrPos>

Sets the position of the reference point in % of the screen. It defines which part of the waveform is shown.

Parameters:

<RescaleCtrPos> Range: 0 to 100
Increment: 1
*RST: 50
Default unit: %

Usage:

Asynchronous command

Manual operation: See "Reference point" on page 119

18.9.3 Roll mode

TIMEbase:ROLL:ENABLE.....	964
TIMEbase:ROLL:MTIME.....	965
ACQuire:ROLLmode:OSCapture.....	965
ACQuire:ROLLmode:POINTS?.....	965
TIMEbase:ROLL:STATe?.....	966

TIMEbase:ROLL:ENABLE <Mode>

Selects, if the roll mode is started automatically by the instrument or if it is turned off.

Parameters:

<Mode> AUTO | OFF
 *RST: AUTO

Usage: Asynchronous command

Manual operation: See ["Mode"](#) on page 120

TIMEbase:ROLL:MTIME <MinAcquTime>

Sets the minimum acquisition time for the automatic start of the roll mode.

Parameters:

<MinAcquTime> Range: 0.5 to 100000
 Increment: 1
 *RST: 2
 Default unit: s

Usage: Asynchronous command

Manual operation: See ["Start roll time"](#) on page 120

ACQuire:ROLLmode:OSCapture <OffScreenCapture>

If enabled, the analyzable waveform in roll mode is extended. You can run the roll mode, stop the acquisition after some time, and analyze the data that is on the display and in the invisible area on the left.

Parameters:

<OffScreenCapture> OFF | ON
 *RST: OFF

Example: See [Section 18.5.4, "Data transfer in roll mode"](#), on page 916.

Usage: Asynchronous command

Manual operation: See ["Off screen capture"](#) on page 121

ACQuire:ROLLmode:POINts?

Returns the record length of the roll mode. In roll mode, the complete record is always captured, independently of the displayed waveform.

To process and analyze the complete roll waveform, enable [ACQuire:ROLLmode:OSCapture](#).

Return values:

<RecordLength> Range: 0 to 18446744073709551615
 Increment: 1
 *RST: 0
 Default unit: pts

Usage: Query only
 Asynchronous command

Manual operation: See ["Off screen capture"](#) on page 121

TIMEbase:ROLL:STATe?

Returns the status of the roll mode.

Return values:

<State> OFF | ON
 *RST: OFF

Usage: Query only
 Asynchronous command

Manual operation: See ["Mode"](#) on page 120

18.9.4 Acquisition setup

This section describes all remote commands for acquisition.

ACQUIRE:AVAILABLE?	966
ACQUIRE:AVERAge?	967
ACQUIRE:COUNT	967
ACQUIRE:CURREnt?	967
ACQUIRE:INTerpolate	967
ACQUIRE:POINts[:VALue]	968
ACQUIRE:POINts:ARATe?	968
ACQUIRE:POINts:MAXimum	968
ACQUIRE:POINts:MODE	968
ACQUIRE:POMemory?	969
ACQUIRE:RESolution?	969
ACQUIRE:RLReal?	970
ACQUIRE:SRATe[:VALue]	970
ACQUIRE:SRATe:MINimum	970
ACQUIRE:SRATe:MODE	970
ACQUIRE:SRReal?	971
ACQUIRE:TYPE	971

ACQUIRE:AVAILABLE?

Number of acquisitions that is saved in the memory and available for history viewing. It is also the number of acquisitions in a fast segmentation acquisition series.

Return values:

<AcquisitionCount> Range: 0 to 4294967295
 Increment: 1
 *RST: 0

Usage: Query only
 Asynchronous command

Manual operation: See ["Available acqs"](#) on page 239

ACquire:AVERage?

Returns the current number of acquired waveforms that contribute to the average.

Return values:

<CurrAverageCount> Range: 0 to 4294967295
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

Manual operation: See "[Current average count](#)" on page 128

ACquire:COUnT <MaxAcqCnt>

Sets the acquisition and average count, which has a double effect:

- It sets the number of waveforms acquired with `RUNSingle`.
- It defines the number of waveforms used to calculate the average waveform.

Parameters:

<MaxAcqCnt> Range: 1 to 16777215
Increment: 1
*RST: 1

Usage: Asynchronous command

Manual operation: See "[N-single/avg count](#)" on page 127

ACquire:CURRent?

Returns the current number of acquisitions that have been acquired.

Return values:

<CurrAcqCnt> Range: 0 to 18446744073709551615
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

ACquire:INTerpolate <IntpolMd>

Selects the interpolation method.

Parameters:

<IntpolMd> SINX | LINear | SMHD

LINear

Linear interpolation between two adjacent sample points

SINX

Interpolation with a $\sin(x)/x$ function.

SMHD

Sample/Hold causes a histogram-like interpolation.

*RST: SINX

Usage: Asynchronous command

Manual operation: See ["Interpolation"](#) on page 128

ACQuire:POINts[:VALue] <RecordLength>

Sets the record length, if [ACQuire:POINts:MODE](#) is set to `MANual`.

Parameters:

<RecordLength> Range: 1000 to 1E+9
 Increment: 2
 *RST: 1000
 Default unit: pts

Usage: Asynchronous command

Manual operation: See ["Record length"](#) on page 127

ACQuire:POINts:ARATe?

Returns the sample rate of the ADC, before waveform processing. The result is the interleaved sample rate or the non-interleaved one, depending on the channel usage.

Return values:

<ADCSampleRate> Range: 5 Gsample/s (interleaved), 2,5 Gsample/s (non-interleaved)
 Default unit: Hz

Usage: Query only
 Asynchronous command

ACQuire:POINts:MAXimum <RecLengthLimit>

Sets the maximum record length, if [ACQuire:POINts:MODE](#) is set to `AUTO`.

Parameters:

<RecLengthLimit> Range: 1000 to 1E+9
 Increment: 2
 *RST: 10E+6
 Default unit: pts

Usage: Asynchronous command

Manual operation: See ["Record length limit"](#) on page 127

ACQuire:POINts:MODE <RecLengthMode>

Selects the mode of the waveform record length adjustment.

The record length is the number of waveform samples that are stored in one waveform record after processing, including interpolation. It determines the length of the displayed waveform.

Parameters:

<RecLengthMode> AUTO | MANual

AUTO

Record length is determined automatically and changes due to instrument internal adjustments.

MANual

The waveform record length is defined with [ACQUIRE:POINTS\[:VALUE\]](#).

*RST: AUTO

Usage: Asynchronous command

Manual operation: See "[RL mode](#)" on page 126

ACQUIRE:POMemory?

The command returns 1 if the memory is not sufficient to process the data with the current settings. To solve the problem, reduce the record length or use automatic record length setting.

Return values:

<OutOfMemory> OFF | ON

*RST: OFF

Usage: Query only
Asynchronous command

Manual operation: See "[Record length](#)" on page 127

ACQUIRE:RESolution? [<MIN | MAX>]

Returns the current resolution.

The resolution is the time between two waveform samples in the waveform record. It considers the processing of the captured samples including interpolation. A fine resolution with low values produces a more precise waveform record. The resolution is the reciprocal of the sample rate.

You can query the minimum and maximum values with <command>? MIN and <command>? MAX.

Return values:

<Resolution> Range: 1E-15 to 100
Increment: 1E-11
*RST: 200E-12
Default unit: s

Usage: Query only
Asynchronous command

Manual operation: See ["Resolution"](#) on page 127

ACQuire:RLReal?

Returns the internal record length used by the acquisition system.

Return values:

<HWRecordLength> Range: 2 to 4294967295
 Increment: 1
 *RST: 1000
 Default unit: pts

Usage: Query only
 Asynchronous command

ACQuire:SRATe[:VALue] <SampleRate>

Sets the number of waveform points per second if [ACQuire:SRATe:MODE](#) is set to [MANual](#).

Parameters:

<SampleRate> Range: 2 to 5E+12
 Increment: 1
 *RST: 5E+9
 Default unit: Sa/s

Usage: Asynchronous command

Manual operation: See ["Sample rate"](#) on page 126

ACQuire:SRATe:MINimum <SampleRateMin>

Sets the minimum sample rate if [ACQuire:SRATe:MODE](#) is set to [AUTO](#).

Parameters:

<SampleRateMin> Range: 2 to 5E+12
 Increment: 1
 *RST: 2
 Default unit: Sa/s

Usage: Asynchronous command

Manual operation: See ["Min. sample rate"](#) on page 126

ACQuire:SRATe:MODE <SampleRateMode>

Defines how the sample rate is set.

The sample rate considers the samples of the ADC, and the processing of the captured samples including interpolation.

Parameters:

<SampleRateMode> [AUTO](#) | [MANual](#)

AUTO

Sample rate is determined automatically and changes due to instrument internal adjustments. You can set a minimum sample rate with `ACQUIRE:SRATE:MINimum`.

MANual

The sample rate is defined with `ACQUIRE:SRATE[:VALUE]`.

*RST: AUTO

Usage: Asynchronous command

Manual operation: See "SR mode" on page 126

ACQUIRE:SRReal? [<MIN | MAX>]

Returns the sample rate of the waveform after HW processing. Interpolation is not considered. This value is shown in the acquisition label above the diagram.

You can query the minimum and maximum values with `<command>? MIN` and `<command>? MAX`.

Return values:

`<HWSampleRate>` Range: 2 to ADC sample rate
 Increment: 1
 *RST: 5E+9
 Default unit: Sa/s

Usage: Query only
 Asynchronous command

ACQUIRE:TYPE <AcquMode>

Sets how the waveform is built from the captured samples.

Parameters:

`<AcquMode>` SAMPLE | PDETECT | ENVELOPE | AVERAGE
 *RST: SAMPLE

Usage: Asynchronous command

Manual operation: See "Acquisition mode" on page 128

18.9.5 Vertical setup

The channel suffix `<ch>` selects the input channel that is affected by the command.

<code>CHANnel<ch>:STATE</code>	972
<code>CHANnel<ch>:SCALE</code>	972
<code>CHANnel<ch>:RANGE</code>	972
<code>CHANnel<ch>:OFFSET</code>	973
<code>CHANnel<ch>:POSITION</code>	973
<code>CHANnel<ch>:COUPLing</code>	974

CHANnel<ch>:INVert.....	974
DISPlay:SIGNAL:LABel.....	974
CHANnel<ch>:SKEW:TIME.....	975
CHANnel<ch>:BANDwidth.....	975
CHANnel<ch>:EATScale.....	976
CHANnel<ch>:EATTenuation.....	976
CHANnel<ch>:IMPedance.....	977

CHANnel<ch>:STATe <State>

Switches the selected channel signal on or off.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<State> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See "[C<n>]" on page 57

CHANnel<ch>:SCALE <Scale>

Sets the vertical scale, which defines the displayed amplitude of the selected waveform.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Scale> Range: 0.001 to 1
Increment: 0.001
*RST: 0.05
Default unit: Depends on the connected probe

Usage: Asynchronous command

Manual operation: See "[Scale]" on page 57

CHANnel<ch>:RANGE <Range>

Sets the voltage range across the 10 vertical divisions of the diagram. The command is an alternative to CHANnel<ch>:SCALE.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Range> Range: 0.01 to 10
 Increment: 0.01
 *RST: 0.5
 Default unit: V/div

Usage: Asynchronous command

CHANnel<ch>:OFFSet <Offset>

Sets the offset voltage, which corrects an offset-affected signal. The vertical center of the selected channel is shifted by the offset value and the signal is repositioned within the diagram.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Offset> Range: -1 to 1
 Increment: 0.01
 *RST: 0
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Position]" on page 57

CHANnel<ch>:POSition <Position>

Moves the selected signal up or down in the diagram. While the offset sets a voltage, position is a graphical setting given in divisions. The visual effect is the same as for offset.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Position> Positive values move up the waveform, negative values move it down.
 Range: -5 to 5
 Increment: 0.02
 *RST: 0
 Default unit: div

Usage: Asynchronous command

Manual operation: See "[Position]" on page 57

CHANnel<ch>:COUPling <UserCoupling>

Sets the connection of the channel signal, i.e. the input impedance (termination) and a filter (coupling). The command determines what part of the signal is used for waveform analysis and triggering.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<UserCoupling> DC | DCLimit | AC

DC

Connection with 50 Ω termination, passes both DC and AC components of the signal.

DCLimit

Connection with 1 M Ω termination, passes both DC and AC components of the signal.

AC

Connection with 1 M Ω termination through DC capacitor, removes DC and very low-frequency components. The waveform is centered on zero volts.

*RST: Instrument specific

Usage: Asynchronous command

Manual operation: See ["Coupling"](#) on page 135

CHANnel<ch>:INVert <InvertChannel>

Turns the inversion of the signal amplitude on or off. To invert means to reflect the voltage values of all signal components against the ground level.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<InvertChannel> OFF | ON

ON: inverted waveform

OFF: normal waveform

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Invert channel"](#) on page 136

DISPlay:SIGNal:LABel <Signal>,<Label>

Defines and assigns a label to the specified channel waveform.

Parameters:

<Label> String with the waveform label

Setting parameters:

<Signal> C1 | C2 | ... | C8

Usage: Asynchronous command

Manual operation: See "[Label](#)" on page 136

CHANnel<ch>:SKEW:TIME <Offset>

Sets a skew value to compensate for the delay of the measurement setup or from the circuit specifics that the instrument cannot compensate automatically. It affects only the selected input channel.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Offset> Range: -100E-9 to 100E-9
Increment: 1E-13
*RST: 0
Default unit: s

Usage: Asynchronous command

Manual operation: See "[Skew](#)" on page 136

CHANnel<ch>:BANDwidth <BandwidthLimit>

Sets the bandwidth limit. The specified bandwidth indicates the range of frequencies that the instrument can acquire and display accurately with less than 3 dB attenuation. Frequencies above the limit are removed from the signal, and noise is reduced.

To set the bandwidth, use one of the <BandwidthLimit> values. The query returns always a numeric result.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Setting parameters:

<BandwidthLimit> FULL | B20 | B50 | B100 | B200 | B350 | B500 | B700 | B1G | B1G5

Availability depends on the maximum bandwidth of the instrument and installed bandwidth extension options. Instead of the given values, you can also set the corresponding numeric value in Hz.

FULL sets the bandwidth to the maximum bandwidth of the instrument. Bandwidth extension options are considered. All other values set a bandwidth limit lower than the maximum. The number indicates the bandwidth limit in MHz.

Return values:

<Result> Numeric result in Hz

Usage: Asynchronous command

Manual operation: See ["Bandwidth"](#) on page 137

CHANnel<ch>:EATScale <ExtAttScI>

Sets the attenuation scale for an external divider: linear or logarithmic.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<ExtAttScI> LIN | LOG
*RST: LIN

Usage: Asynchronous command

Manual operation: See ["External Attenuation: Scale, Attenuation"](#) on page 138

CHANnel<ch>:EATTenuation <ExtAtt>

Consider a voltage divider that is part of the DUT before the measuring point. The external attenuation is included in the measurement, and the instrument shows the results that would be measured before the divider. External attenuation can be used with all probes.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<ExtAtt> Values depend on the selected scale ([CHANnel<ch>:EATScale](#) on page 976) and the unit of the waveform. See ["External Attenuation: Scale, Attenuation"](#) on page 138. Limits below are for linear scale.

Range: 0.005 to 1000000
 Increment: 0.01
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["External Attenuation: Scale, Attenuation"](#) on page 138

CHANnel<ch>:IMPedance <Impedance>

Sets the impedance of the connected probe for power calculations and measurements.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Impedance> Range: 0.1 to 100000
 Increment: 1
 *RST: 50
 Default unit: Ω

Usage: Asynchronous command

Manual operation: See ["Impedance"](#) on page 138

18.9.6 Probes

This section describes all remote commands for probes.

• Common probe settings	977
• Settings for active voltage probes	982
• Settings for modular probes	989
• Settings for current probes	992
• Optical isolated probes	994
• Probe adapter R&S RT-Z2T	997
• Probe attributes	998
• Probe at external trigger input	1001

18.9.6.1 Common probe settings

The probe suffix <ch> selects the input channel to which the probe is connected.

PROBe<ch>:SETup:ATTenuation[:AUTO]?.....	978
PROBe<ch>:SETup:ATTenuation:MANual.....	978
PROBe<ch>:SETup:ATTenuation:MODE.....	978
PROBe<ch>:SETup:ATTenuation:DEFProbe.....	979

PROBe<ch>:SETup:ATTenuation:UNIT.....	980
PROBe<ch>:SETup:BANDwidth?.....	980
PROBe<ch>:SETup:OFFSet:TOMean.....	980
PROBe<ch>:SETup:OFFSet:AZERo.....	981
PROBe<ch>:SETup:OFFSet:USEautozero.....	981
PROBe<ch>:SETup:NAME?.....	981
PROBe<ch>:SETup:STATe?.....	982
PROBe<ch>:SETup:TYPE?.....	982

PROBe<ch>:SETup:ATTenuation[:AUTO]?

Returns the attenuation of a detected or predefined probe.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<Attenuation> Range: 0.0002 to 1000
Increment: 0.1
*RST: 1
Default unit: V/V

Usage:

Query only
Asynchronous command

Manual operation: See ["Attenuation"](#) on page 140

PROBe<ch>:SETup:ATTenuation:MANual <Attenuation>

Sets the attenuation for an unknown probe.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Attenuation> Range: 0.0001 to 10000
Increment: 0.1
*RST: 1
Default unit: V/V

Usage:

Asynchronous command

Manual operation: See ["Attenuation"](#) on page 140

PROBe<ch>:SETup:ATTenuation:MODE <AttenuationMode>

Set the mode to MANual if the instrument does not detect the passive probe.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<AttenuationMode> AUTO | MANual
 *RST: AUTO

Usage:

Asynchronous command

PROBe<ch>:SETup:ATTenuation:DEFProbe <PredefinedProbe>

Selects one of the predefined probes, or a user-defined probe.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<PredefinedProbe> NONE | ZC10 | ZC20 | ZC30 | ZD01A100 | ZD01A1000 | HZ15 | HZ17 | RTZ25C1 | ZZ80 | ZS10L | ZD02 | ZD08 | ZC02100 | ZC021000 | ZC03 | ZD002A10 | ZD002A100 | ZD003A20 | ZD003A200 | ZC3110 | ZC311 | ZC3101 | ZH03 | ZP1X | CWT15 | CWT30 | CWTMN1 | CMN50HF3 | CMN50HF15 | CMN50HF30 | CMN50HF015 | CMN50HF06 | CWTUM015 | CWTUM06 | CWTUM1 | V1V1 | V10V1 | V100V1 | V200V1 | V1000V1 | V1A1000 | V1A100 | V1A10 | V1A1 | USER

ZC10 | ZC20 | ZC30 | ZC03

Current probes

ZD02 | ZD08 | ZD01A100 | ZD01A1000 | ZD002A10 | ZD002A100 | ZD003A20 | ZD003A200

Active differential probes, attenuation ratio according to the setting on the probe.

A100 = 100:1

A1000 = 1000:1

HZ15 | HZ17

Near field probes (EMI)

ZC02100 | ZC021000 | ZC3110 | ZC311 | ZC3101

Current probes 100 A/V or 1000 A/V according to the setting on the probe.

CWT15 | CWT30 | CWTMN1 | CWTUM015 | CWTUM06 | CWTUM1 | CMN50HF3 | CMN50HF15 | CMN50HF30 | CMN50HF015 | CMN50HF06

PEM Rogowski probes

ZZ80 | ZH03 | ZP1X |

Passive probes

V1V1 | V10V1 | V100V1 | V200V1 | V1000V1 | V1A1000 | V1A100 | V1A10 | V1A1

Common gain and attenuation settings if the probe type is not in the list.

USER

Probe is not detected and not known to the instrument. Set unit and attenuation manually.

*RST: NONE

Usage: Asynchronous command

Manual operation: See ["Predefined probe, Type and Name of the probe"](#) on page 139

PROBe<ch>:SETup:ATTenuation:UNIT <Unit>

Returns the unit of the connected probe if the probe is detected or predefined. For unknown probes, you can select the required unit.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Unit> V | A | W
Voltage probe (V), current probe (A), power probe (W)
*RST: V

Usage: Asynchronous command

Manual operation: See ["Vertical unit"](#) on page 140

PROBe<ch>:SETup:BANDwidth?

Returns the bandwidth of the connected probe.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<Bandwidth> Range: 10000 to 20000000000
Increment: 10
*RST: 1500000000
Default unit: Hz

Usage: Query only
Asynchronous command

Manual operation: See ["Probe bandwidth"](#) on page 140

PROBe<ch>:SETup:OFFSet:TOMean

Compensates automatically for a DC component of the input signal using the result of a background mean measurement.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Usage: Event
Asynchronous command

Manual operation: See ["Set offset to mean"](#) on page 140

PROBe<ch>:SETup:OFFSet:AZERo

Measures the zero error of the probe. Short the signal pin and the ground pin together, then send the command.

Suffix:
<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Usage: Event
Asynchronous command

Manual operation: See ["AutoZero, Use AutoZero"](#) on page 141

PROBe<ch>:SETup:OFFSet:USEautozero <UseAutoZeroOffset>

Corrects the zero error of the probe. The zero error is detected with [PROBe<ch>:SETup:OFFSet:AZERo](#).

Suffix:
<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:
<UseAutoZeroOffset> OFF | ON
*RST: OFF

Example:
PROB2:SET:OFFS:AZER
PROB2:SET:OFFS:USE ON
Detects the zero error and uses it for correction.

Usage: Asynchronous command

Manual operation: See ["AutoZero, Use AutoZero"](#) on page 141

PROBe<ch>:SETup:NAME?

Queries the name of the probe.

Suffix:
<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:
<Name> Name string

Usage: Query only
Asynchronous command

Manual operation: See ["Predefined probe, Type and Name of the probe"](#) on page 139

PROBe<ch>:SETup:STATe?

Queries if the probe at the specified input channel is active (detected) or not active (not detected). To switch the probe on, use [CHANnel<ch>:STATe](#).

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<State> DETected | NDETECTED
*RST: NDETECTED

Usage:

Query only
Asynchronous command

Manual operation: See ["Predefined probe, Type and Name of the probe"](#) on page 139

PROBe<ch>:SETup:TYPE?

Queries the class of the probe.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<Type> String containing the probe class, e.g. None (no probe detected), passive, current, active diff., active single-ended.

Usage:

Query only
Asynchronous command

Manual operation: See ["Predefined probe, Type and Name of the probe"](#) on page 139

18.9.6.2 Settings for active voltage probes

The probe suffix <ch> selects the input channel to which the probe is connected.

PROBe<ch>:SETup:MODE	983
PROBe<ch>:SETup:ACCOupling	984
PROBe<ch>:SETup:CMOffset	984
PROBe<ch>:SETup:DISPlaydiff	984
PROBe<ch>:SETup:ZAXV	985
PROBe<ch>:PMETer:STATe	985
PROBe<ch>:PMETer:RESults:SINGle?	985
PROBe<ch>:PMETer:RESults:COMMon?	986
PROBe<ch>:PMETer:RESults:DIFFerential?	986

PROBe<ch>:PMETer:RESults:NEGative?.....	987
PROBe<ch>:PMETer:RESults:POSitive?.....	987
PROBe<ch>:SETup:ADVanced:AUDioverload.....	987
PROBe<ch>:SETup:ADVanced:FILTer.....	988
PROBe<ch>:SETup:ADVanced:RANGe.....	988
PROBe<ch>:SETup:ADVanced:PMTOffset.....	988

PROBe<ch>:SETup:MODE <Mode>

The micro button is located on the probe head. Pressing this button, you initiate an action on the instrument directly from the probe. The button is disabled during internal automatic processes, for example, during self-alignment, autoset, and level detection.

Select the action that you want to start from the probe.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Mode> RCONtinuous | RSINgle | AUToset | AZERo | OTMean | SITFile | NOACtion | FTRiglevel | PRSetup

RCONtinuous

Run continuous: the acquisition is running as long as the probe button is pressed.

RSINgle

Run single: starts a defined number of acquisitions (same as [Single] key).

AUToset

Starts the autoset procedure.

AZERo

AutoZero: performs an automatic correction of the zero error.

OTMean

Set offset to mean: performs an automatic compensation for a DC component of the input signal.

SITFile

Save image to file: saves the display image in a file.

NOACtion

Nothing is started on pressing the micro button.

FTRiglevel

Sets the trigger level automatically to $0.5 * (MaxPeak - MinPeak)$. The function is not available for an external trigger source.

PRSetup

Opens the "Probes Setup" dialog box.

*RST: RCONtinuous

Usage:

Asynchronous command

Manual operation: See "MicroButton" on page 143

PROBe<ch>:SETup:ACCoupling <ProbeCouplingAC>

Enables AC coupling in R&S RT-ZPR power rail probes, which removes DC and very low-frequency components. The R&S RT-ZPR probe requires 50 Ω input termination, for which the channel AC coupling is not available. The probe setting allows AC coupling also at 50 Ω inputs.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<ProbeCouplingAC> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["AC Coupling"](#) on page 146

PROBe<ch>:SETup:CMOffset <CMOffset>

Sets the common-mode offset to compensate for a common DC voltage that is applied to both input sockets (referenced to the ground socket). The setting is available for Rohde & Schwarz differential probes and for modular probes in CM measurement mode.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<CMOffset> Range: -1E+26 to 1E+26
Increment: 0.001
*RST: 0
Default unit: V

Usage: Asynchronous command

Manual operation: See ["CM offset"](#) on page 144

PROBe<ch>:SETup:DISPlaydiff <DisplayDiff>

Selects the voltage to be measured by the R&S ProbeMeter of differential active probes:

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<DisplayDiff> DIFFerential | SINGleended
DIFFerential
Measures differential and common mode voltages

SINGLeended

Measures the voltage between the positive/negative signal socket and the ground.

*RST: DIFFerential

Usage: Asynchronous command

Manual operation: See ["Display"](#) on page 145

PROBe<ch>:SETup:ZAXV <AttenuationZA15>

If you use the external attenuator R&S RT-ZA15 together with one of the differential active probes R&S RT-ZD10/20/30, enable "RT-ZA15 attenuator" to include the external attenuation in the measurements.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<AttenuationZA15> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["RT-ZA15 attenuator"](#) on page 145

PROBe<ch>:PMETer:STATe <State>

Activates the integrated R&S ProbeMeter on probes with Rohde & Schwarz probe interface.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<State> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["ProbeMeter"](#) on page 143

PROBe<ch>:PMETer:RESults:SINGLE?

Returns the R&S ProbeMeter measurement result of single-ended active Rohde & Schwarz probes, the voltage measured between the probe tip and the ground.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<Result> Range: -1E+26 to 1E+26
 Increment: 0.001
 *RST: 0
 Default unit: V

Usage:

Query only
 Asynchronous command

Manual operation: See ["ProbeMeter"](#) on page 143

PROBe<ch>:PMETer:RESults:COMMon?

Returns the R&S ProbeMeter measurement result of differential active R&S probes: the common mode voltage, which is the mean voltage between the signal sockets and the ground socket.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<Result> Range: -1E+26 to 1E+26
 Increment: 0.001
 *RST: 0
 Default unit: V

Usage:

Query only
 Asynchronous command

Manual operation: See ["ProbeMeter"](#) on page 143

PROBe<ch>:PMETer:RESults:DIFFerential?

Returns the R&S ProbeMeter measurement result of differential active Rohde & Schwarz probes, the differential voltage - the voltage between the positive and negative signal sockets.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<Result> Range: -1E+26 to 1E+26
 Increment: 0.001
 *RST: 0
 Default unit: V

Usage:

Query only
 Asynchronous command

Manual operation: See ["ProbeMeter"](#) on page 143

PROBe<ch>:PMETer:RESults:NEGative?

Returns the R&S ProbeMeter measurement result of differential active R&S probes, the voltage that is measured between the negative signal socket and the ground.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<Result> Range: -1E+26 to 1E+26
Increment: 0.001
*RST: 0
Default unit: V

Usage:

Query only
Asynchronous command

Manual operation: See ["ProbeMeter"](#) on page 143

PROBe<ch>:PMETer:RESults:POSitive?

Returns the R&S ProbeMeter measurement result of differential active R&S probes: the voltage that is measured between the positive signal socket and the ground.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<Result> Range: -1E+26 to 1E+26
Increment: 0.001
*RST: 0
Default unit: V

Usage:

Query only
Asynchronous command

Manual operation: See ["ProbeMeter"](#) on page 143

PROBe<ch>:SETup:ADVanced:AUDioverload <Sound>

Activates the acoustic overrange warning in the probe control box. The command is relevant for R&S RT-ZHD probes.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Sound> OFF | ON
*RST: OFF

Usage:

Asynchronous command

Manual operation: See ["Audible overrange"](#) on page 148

PROBe<ch>:SETup:ADVanced:FILTer <State>

Activates the lowpass filter in the probe control box. The filter frequency depends on the probe type and is indicated on the probe control box.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<State> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Bandwidth limit"](#) on page 147

PROBe<ch>:SETup:ADVanced:RANGe <ProbeRange>

Sets the voltage range of an R&S RT-ZHD probe.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<ProbeRange> AUTO | MHIGH | MLOW

AUTO

The voltage range is set with [CHANnel<ch>:SCALE](#).

MHIGH

Sets the higher voltage range of the connected probe. To query the value, use [PROBe<ch>:SETup:ATTenuation\[:AUTO\]?](#).

MLOW

Sets the lower voltage range of the connected probe. To query the value, use [PROBe<ch>:SETup:ATTenuation\[:AUTO\]?](#).

*RST: AUTO

Usage: Asynchronous command

Manual operation: See ["Range"](#) on page 148

PROBe<ch>:SETup:ADVanced:PMTOffset

Sets the measured ProbeMeter value as offset. Thus, the value is considered in measurements.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Usage: Setting only
Asynchronous command

Manual operation: See ["Set offset to ProbeMeter value"](#) on page 154

18.9.6.3 Settings for modular probes

PROBe<ch>:SETup:PRMode	989
PROBe<ch>:SETup:CMOOffset	990
PROBe<ch>:SETup:DMOOffset	990
PROBe<ch>:SETup:NOFFset	990
PROBe<ch>:SETup:POFFset	991
PROBe<ch>:SETup:TERM:ADJust	991
PROBe<ch>:SETup:TERM:MEASure?	991
PROBe<ch>:SETup:TERM:MODE	992
PROBe<ch>:SETup:TERM:STATe	992

PROBe<ch>:SETup:PRMode <MeasMode>

Sets the measurement mode of modular probes.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<PrbMeasMd> DMODe | CMODe | PMODe | NMODe

DMODe

Differential mode input voltage (V_{dm}), the voltage between the positive and negative input terminal.

CMODe

Common mode input voltage (V_{cm}), the mean voltage between the positive and negative input terminal vs. ground.

PMODe

Positive single-ended input voltage (V_p). the voltage between the positive input terminal and ground.

NMODe

Negative single-ended input voltage (V_N). the voltage between the negative input terminal and ground.

*RST: DMODe

Usage: Asynchronous command

Manual operation: See ["Probe mode"](#) on page 151

PROBe<ch>:SETup:CMOffset <CMOffset>

Sets the common-mode offset to compensate for a common DC voltage that is applied to both input sockets (referenced to the ground socket). The setting is available for Rohde & Schwarz differential probes and for modular probes in CM measurement mode.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<CMOffset> Range: -1E+26 to 1E+26
Increment: 0.001
*RST: 0
Default unit: V

Usage: Asynchronous command

Manual operation: See ["CM offset"](#) on page 144

PROBe<ch>:SETup:DMOffset <DMOffset>

Sets the differential offset to compensate a DC voltage applied between the positive (V_p) and the negative (V_n) input terminal at the probe tip.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<DMOffset> Range: -1E+26 to 1E+26
Increment: 0.001
*RST: 0
Default unit: V

Usage: Asynchronous command

Manual operation: See ["DM offset, CM offset, P offset, N offset"](#) on page 152

PROBe<ch>:SETup:NOFFset <NOFFset>

Sets the negative offset to compensate a DC voltage applied to the negative input terminal (V_n) referenced to ground.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<NOFFset> Range: -1E+26 to 1E+26
Increment: 0.001
*RST: 0
Default unit: V

Usage: Asynchronous command

Manual operation: See ["DM offset, CM offset, P offset, N offset"](#) on page 152

PROBe<ch>:SETup:POFFset <POffset>

Sets the positive offset to compensate a DC voltage applied to the positive input terminal (V_p) referenced to ground.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<POffset> Range: -1E+26 to 1E+26
Increment: 0.001
*RST: 0
Default unit: V

Usage: Asynchronous command

Manual operation: See ["DM offset, CM offset, P offset, N offset"](#) on page 152

PROBe<ch>:SETup:TERM:ADJust <VoltageAdj>

Activates control of the termination voltage.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<VoltageAdj> Range: -1E+26 to 1E+26
Increment: 0.001
*RST: 0
Default unit: V

Usage: Asynchronous command

Manual operation: See ["Adjustment"](#) on page 153

PROBe<ch>:SETup:TERM:MEASure?

Returns the measured common mode voltage.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<VoltageMeas> Range: -1E+26 to 1E+26
Increment: 0.01
*RST: 0
Default unit: V

Usage: Query only
Asynchronous command

Manual operation: See ["Measurement"](#) on page 153

PROBe<ch>:SETup:TERM:MODE <Mode>

Selects the voltage that is used for termination.

Suffix:
<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:
<Mode> AUTO | MANual
AUTO: the instrument uses the measured common mode voltage for termination.
MANual: enter the voltage to be used for termination with [PROBe<ch>:SETup:TERM:ADJust](#).
*RST: AUTO

Usage: Asynchronous command

Manual operation: See ["Mode"](#) on page 153

PROBe<ch>:SETup:TERM:STATe <VoltageState>

Activates control of the termination voltage.

Suffix:
<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:
<VoltageState> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["State"](#) on page 153

18.9.6.4 Settings for current probes

The probe suffix <ch> selects the input channel to which the probe is connected.

PROBe<ch>:SETup:GAIN:AUTO?	993
PROBe<ch>:SETup:GAIN:MANual	993
PROBe<ch>:SETup:DEGauss	993
PROBe<ch>:SETup:OFFSet:ZADJust	994
PROBe<ch>:SETup:OFFSet:STPProbe	994

PROBe<ch>:SETup:GAIN:AUTO?

Returns the gain of a detected or predefined current probe.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<Gain> Range: 0.001 to 5000
Increment: 0.1
*RST: 1
Default unit: A/V

Usage:

Query only
Asynchronous command

Manual operation: See ["Gain, Manual gain"](#) on page 149

PROBe<ch>:SETup:GAIN:MANual <Gain>

Sets the gain for an unknown current probe.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Gain> Range: 0.0001 to 10000
Increment: 0.0001
*RST: 1
Default unit: V/V

Usage:

Asynchronous command

Manual operation: See ["Gain, Manual gain"](#) on page 149

PROBe<ch>:SETup:DEGauss

Demagnetizes the core if it has been magnetized by switching the power on and off, or by an excessive input. Always carry out demagnetizing before measurement.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Usage:

Event
Asynchronous command

Manual operation: See ["DeGauss"](#) on page 149

PROBe<ch>:SETup:OFFSet:ZADJust <ZeroAdjustValue>

Set the waveform to zero position. It corrects the effect of a voltage offset or temperature drift. To set the value by the instrument, use [PROBe<ch>:SETup:OFFSet:AZERo](#).

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<ZroAdjVal> Range: -100 to 100
Increment: 0.1
*RST: 0
Default unit: %

Usage: Asynchronous command

Manual operation: See ["Zero adjust"](#) on page 150

PROBe<ch>:SETup:OFFSet:STPRobe

Saves the zero adjust value in the probe box. If you connect the probe to another channel or to another Rohde & Schwarz oscilloscope, the value is read out again, and you can use the probe without further adjustment.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Usage: Event
Asynchronous command

Manual operation: See ["Save to probe"](#) on page 150

18.9.6.5 Optical isolated probes

The commands of this section are relevant for optical isolated probes. The commands are available in firmware version 2.2 and higher.

PROBe<ch>:SETup:ADVanced:UNIT	994
PROBe<ch>:SETup:OFFSet:TOPMeter	995
PROBe<ch>:SETup:LASer:STATe?	995
PROBe<ch>:SETup:ALIGNment:GAIN:EXECute	995
PROBe<ch>:SETup:ALIGNment:ZERO:EXECute	996
PROBe<ch>:SETup:ALIGNment:WRITe	996
PROBe<ch>:SETup:ADVanced:RDEFaults	996
PROBe<ch>:SETup:TIPModel:NAME?	997
PROBe<ch>:SETup:TIPModel:INFO?	997

PROBe<ch>:SETup:ADVanced:UNIT <SelectUnit>

Sets the unit of the R&S RT-ZISO signal.

Suffix:
 <ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:
 <SelectUnit> V | A | W
 *RST: V

Usage: Asynchronous command

Manual operation: See ["Select input unit"](#) on page 154

PROBe<ch>:SETup:OFFSet:TOPMeter

Sets the measured R&S ProbeMeter value as offset. Thus, the value is considered in measurements.

Suffix:
 <ch> 1..8

Usage: Event
 Asynchronous command

Manual operation: See ["ProbeMeter to offset"](#) on page 146

PROBe<ch>:SETup:LASer:STATe?

Returns the current status of the laser.

Suffix:
 <ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:
 <LaserState> 1 | 2 | 3
1
 The laser is working.
2
 The laser needs service, but is still working.
3
 Defective laser, send to your Rohde & Schwarz service center.
 *RST: 1

Usage: Query only
 Asynchronous command

Manual operation: See ["Laser state"](#) on page 155

PROBe<ch>:SETup:ALIGNment:GAIN:EXECute

Corrects the zero point error and the gain error of the R&S RT-ZISO probe.

To write the alignment result to the non-volatile flash of the probe, use `PROBe<ch>:SETup:ALIGnment:WRITe`.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Usage:

Event
Asynchronous command

Manual operation: See "[Gain/Zero-error alignment](#)" on page 156

PROBe<ch>:SETup:ALIGnment:ZERO:EXECute

Performs a self-alignment and corrects the zero point error of the R&S RT-ZISO probe.

To write the alignment result to the non-volatile flash of the probe, use `PROBe<ch>:SETup:ALIGnment:WRITe`.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Usage:

Event
Asynchronous command

Manual operation: See "[Zero-error alignment](#)" on page 156

PROBe<ch>:SETup:ALIGnment:WRITe

The command writes the alignment result to the non-volatile flash of the probe.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Usage:

Event
Asynchronous command

PROBe<ch>:SETup:ADVanced:RDEFaults

Resets the zero point and gain error correction to the factory default values.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Usage:

Event
Asynchronous command

Manual operation: See "[Restore default values](#)" on page 156

PROBe<ch>:SETup:TIPModel:NAME?

Returns the name of the tip module that is connected to the R&S RT-ZISO probe at the specified channel.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<ProbeTipModel> UNKNOWN | Z101 | Z201 | Z202 | Z203 | Z301 | Z302 | NONE
*RST: NONE

Usage:

Query only
Asynchronous command

PROBe<ch>:SETup:TIPModel:INFO?

Return detailed information on the tip module that is connected to a R&S RT-ZISO probe.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<TipInfo> Comma-separated list of tip module attributes: Name, Type, PartNumber, SerialNumber, InputCapacity, InputImpedance, InputMin, InputMax, OffsetMin, OffsetMax, Unit, Bandwidth, Attenuation.

Usage:

Query only
Asynchronous command

18.9.6.6 Probe adapter R&S RT-Z2T

PROBe<ch>:SETup:ADAPter	997
PROBe<ch>:SETup:ATTenuation:TDEFprobe	998

PROBe<ch>:SETup:ADAPter <Type>

Selects the adapter. The query returns the identified adapter type.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Type> NONE | Z2T
*RST: NONE

Usage:

Asynchronous command

PROBe<ch>:SETup:ATTenuation:TDEFprobe <TekPredefProbe>

Selects the Tektronix probe that is connected to the R&S RT-Z2T adapter.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<TekPredefProbe> NONE | P5205A50 | P5205A500 | P5210A100 | P5210A1000 | P6205 | P6241 | P6243 | P6245 | P6246A1 | P6246A10 | P6247A1 | P6247A10 | P6248A1 | P6248A10 | P6249 | P6250A5 | P6250A50 | P6251A5 | P6251A50 | P6701B | P6703B | P6711 | P6713 | TCP202
*RST: NONE

Example:

```
PROBe2:SETup:ADAPter
<-- Z2T
PROBe2:SETup:ATTenuation:TDEFprobe P5205A50
```

Checks the adapter state on channel 2, and selects the probe P5205A50.

Usage: Asynchronous command

18.9.6.7 Probe attributes

PROBe<ch>:ID:PARTnumber?	998
PROBe<ch>:ID:PRDate?	998
PROBe<ch>:ID:SRNumber?	999
PROBe<ch>:ID:SWVersion?	999
PROBe<ch>:SETup:CAPacitance?	999
PROBe<ch>:SETup:DCRange:MAX?	1000
PROBe<ch>:SETup:DCRange:MIN?	1000
PROBe<ch>:SETup:IMPedance?	1000

PROBe<ch>:ID:PARTnumber?

Queries the Rohde & Schwarz part number of the probe.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<PartNumber> Part number in a string.

Usage: Query only
Asynchronous command

PROBe<ch>:ID:PRDate?

Queries the production date of the probe.

Suffix:
<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:
<ProductionDate> Date in a string.

Usage:
Query only
Asynchronous command

PROBe<ch>:ID:SRNumber?

Queries the serial number of the probe.

Suffix:
<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:
<SerialNo> Serial number in a string.

Usage:
Query only
Asynchronous command

PROBe<ch>:ID:SWVersion?

Queries the version of the probe firmware.

Suffix:
<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:
<Softwareversion> Version number in a string.

Usage:
Query only
Asynchronous command

PROBe<ch>:SETup:CAPacitance?

Queries the input capacitance of the probe.

Suffix:
<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:
<InputCapacity> Range: 1E-13 to 1E-07
Default unit: F

Usage:
Query only
Asynchronous command

PROBe<ch>:SETup:DCRange:MAX?

Returns the maximum value of the dynamic DC range.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<DynDCrangeMax> Range: -1E+26 to 1E+26
Increment: 1E-12
*RST: 0
Default unit: V

Usage:

Query only
Asynchronous command

PROBe<ch>:SETup:DCRange:MIN?

Returns the minimum value of the dynamic DC range.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<DynDCrangeMin> Range: -1E+26 to 1E+26
Increment: 1E-12
*RST: 0
Default unit: V

Usage:

Query only
Asynchronous command

PROBe<ch>:SETup:IMPedance?

Queries the termination of the probe.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<InputImpedance> Range: 0 to 1E+9
Default unit: Ω

Usage:

Query only
Asynchronous command

18.9.6.8 Probe at external trigger input

TRProbe:SETup:ATTenuation:UNIT?	1001
TRProbe:SETup:ATTenuation[:AUTO]?	1001
TRProbe:SETup:NAME?	1001
TRProbe:SETup:STATe?	1001
TRProbe:SETup:TYPE?	1002

TRProbe:SETup:ATTenuation:UNIT?

Returns the unit of the probe that is connected to the external trigger input.

Return values:

<PrbAttUnt> V | A | W
 *RST: V

Usage: Query only
 Asynchronous command

TRProbe:SETup:ATTenuation[:AUTO]?

Returns the attenuation of the probe that is connected to the external trigger input.

Return values:

<PrbAttMdAuto> Range: 0.001 to 1000
 Increment: 0.1
 *RST: 1
 Default unit: V/V

Usage: Query only
 Asynchronous command

TRProbe:SETup:NAME?

Returns the name of the probe that is connected to the external trigger input.

Return values:

<Name> String parameter

Usage: Query only
 Asynchronous command

TRProbe:SETup:STATe?

Returns the state of the probe that is connected to the external trigger input.

Return values:

<State> DETected | NDETECTED
 *RST: NDETECTED

Usage: Query only
 Asynchronous command

TRPRobe:SETup:TYPE?

Returns the type of the probe that is connected to the external trigger input.

Return values:

<Type> String parameter

Usage:

Query only
Asynchronous command

18.9.7 Fast segmentation**ACQuire:SEGmented:MAX <MaxAcqs>**

If ON, the instrument acquires the maximum number of segments that can be stored in the memory. The maximum number depends on the current sample rate and record length settings.

If OFF, define the number of segments in a fast segmentation cycle with [ACQuire:COUNT](#).

Parameters:

<MaxAcqs> OFF | ON
*RST: OFF

Usage:

Asynchronous command

Manual operation: See ["Acquire maximum"](#) on page 130

ACQuire:SEGmented:STATe <State>

If fast segmentation is enabled, the acquisitions are performed as fast as possible, without processing and displaying the waveforms. When acquisition has been stopped, the data is processed and the latest waveform is displayed. Older waveforms are stored in segments. You can display and analyze the segments using the history.

Parameters:

<State> OFF | ON
*RST: OFF

Usage:

Asynchronous command

Manual operation: See ["Fast segmentation"](#) on page 130

18.9.8 High definition mode

HDEFinition:BWIDth	1003
HDEFinition:RESolution?	1003
HDEFinition:STATe	1003

HDEFinition:BWIDth <Bandwidth>

Sets the filter bandwidth for the high definition mode.

Parameters:

<Bandwidth>	Range:	1000 to 500E+6
	Increment:	1000
	*RST:	100E+6
	Default unit:	Hz

Usage: Asynchronous command

Manual operation: See ["Bandwidth"](#) on page 131

HDEFinition:RESolution?

Displays the resulting vertical resolution in high definition mode. The higher the filter bandwidth, the lower the resolution.

Return values:

<Resolution>	Range:	0 to 18
	Increment:	0.1
	*RST:	0
	Default unit:	bit

Usage: Query only
Asynchronous command

Manual operation: See ["Resolution in bits"](#) on page 131

HDEFinition:STATe <State>

Enables high definition mode, which increases the numeric resolution of the waveform signal.

Parameters:

<State>	OFF ON
	ON: high definition mode
	OFF: normal oscilloscope mode
	*RST: OFF

Usage: Asynchronous command

Manual operation: See ["State"](#) on page 131

18.9.9 Waveform data export

To set the export data format, see [FORMat \[:DATA\]](#).

For fast export of several waveforms at once, use `EXPort:WAVeform:DATA[:VALues]?` on page 1109.

<code>CHANnel<ch>:DATA:HEADer?</code>	1004
<code>CHANnel<ch>:DATA[:VALues]?</code>	1004

`CHANnel<ch>:DATA:HEADer?`

Returns the header of channel waveform data, the attributes of the waveform.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<XStart>	1. header value: time of the first sample in s
<XStop>	2. header value: time of the last sample in s
<RecordLength>	3. header value: record length, number of samples
<ValuesPerSample>	4. header value: number of values per sample. For most waveforms, the result is 1. For peak detect and envelope waveforms, it is 2. If the number is 2, the number of returned values is twice the number of samples (record length).

Example:

```
CHAN1:DATA:HEAD?
-1E-07,9.9800000000000001E-08,1000,1
```

Start time of the data is $-1\text{E-}07 = 100\text{ ns}$, and end time of the data is $9.9800000000000001\text{E-}08 = 99.8\text{ ns}$. The data stream has 1000 values with one value per sample.

Usage:

Query only
Asynchronous command

`CHANnel<ch>:DATA[:VALues]? [<Offset>[,<Length>]]`

Returns the data of the channel waveform points for transmission from the instrument to the controlling computer. The data can be used in MATLAB, for example.

Without parameters, the complete waveform is retrieved. Using the offset and length parameters, data can be retrieved in smaller portions, which makes the command faster. If you send only one parameter, it is interpreted as offset, and the data is retrieved from offset to the end of the waveform.

To set the export format, use `FORMat[:DATA]` on page 921.

Suffix:

<ch> 1 to 8, depending on instrument model. Index of the analog channel.

Query parameters:

<Offset> Number of offset waveform samples to be skipped.
Range: 0 to m. Limit: $n + m \leq \text{record length}$

<Length>	Number of waveform points to be retrieved. Range: 1 to n. Limit: $n + m \leq \text{record length}$
Return values:	
<Data>	List of values according to the format and content settings.
Example:	Retrieve the complete channel 1 waveform, only Y-values: FORM ASC CHAN1:DATA? <-- -0.125000,-0.123016,-0.123016,-0.123016,-0.123016,-0.123016,...
Example:	Retrieve the first 10 values of the waveform: CHANnel:DATA:VALues? 0,10 <-- -0.10079051554203,-0.098814234137535,-0.098814234137535, -0.096837945282459,-0.094861663877964,-0.094861663877964, -0.092885382473469,-0.090909093618393,-0.090909093618393, -0.088932812213898
Example:	Skip 5 samples and retrieve the next 5 samples: CHANnel:DATA:VALues? 5,5 <-- -0.094861663877964,-0.092885382473469,-0.090909093618393, -0.090909093618393,-0.088932812213898
Usage:	Query only Asynchronous command

18.9.10 Reference clock

SENSe[:ROSCillator]:OUTPut[:ENABle] <ReferenceOutput>

Sends the internal reference clock signal to the Ref Out 10MHz connector.

Parameters:

<ReferenceOutput> OFF | ON
*RST: OFF

Usage: SCPI confirmed
Asynchronous command

Manual operation: See ["Output 10 MHz ref. signal"](#) on page 122

SENSe[:ROSCillator]:SOURce <RefSource>

Selects the source of the reference clock: internal 10 MHz reference signal of the OCXO, or an external 10 MHz reference signal..

Parameters:

<RefSource> INTernal | EXTernal
*RST: INTernal

Usage: Asynchronous command

Manual operation: See ["Ref. osc. source"](#) on page 122

18.10 Trigger

Trigger commands use several suffixes.

LEVel<n>, NOISe<m>

The suffix indicates the analog channel for which the command takes effect. C1 has suffix 1, C2 has suffix 2, and so on.

Event<ev>

The suffix indicates the sequence step, for which the command takes effect when you trigger on a sequence. If you trigger on a single event, the suffix = 1 and can be omitted.

- 1 = A-trigger
- 2 = B-trigger
- 3 = R-trigger (reset event)

Asynchronous commands

Some of the commands in the following section are asynchronous. An overlapping or asynchronous command does not automatically finish executing before the next command starts executing. If overlapping commands must be executed in a defined order, e.g. to avoid wrong measurement results, they must be serviced sequentially.

To prevent an overlapping execution of commands, one of the commands *OPC, *OPC? or *WAI can be used after the command or a command set.

For more information, see:

- www.rohde-schwarz.com/rc-via-scp, section "Command sequence and synchronization"

18.10.1 Common trigger settings

TRIGger:MEVents:MODE.....	1006
TRIGger:EVENT<ev>:TYPE.....	1007
TRIGger:EVENT<ev>:LEVel<n>[:VALue].....	1007
TRIGger:FINDlevel.....	1007
TRIGger:EVENT<ev>:SOURce.....	1008

TRIGger:MEVents:MODE <Class>

Selects, if you want to trigger on a single event, or on a series of events.

Parameters:

<Class> SINGle | SEQuence
 *RST: SINGle

Usage: Asynchronous command

Manual operation: See "Trigger on" on page 163

TRIGger:EVENT<ev>:TYPE <Type>

Selects the trigger type. In a trigger sequence, the trigger type is set for each condition.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<Type> EDGE | GLITCh | WIDTH | RUNT | WINDow | TIMEout | INTerval | SLEWrate | ANEDge | SETHold | STATE | PATtern

ANEDge = analog edge trigger is the only trigger type if the extern trigger source is used.

For SETHold, also DATatoclock can be used.

*RST: EDGE

Usage: Asynchronous command

Manual operation: See "[Type](#)" on page 164

TRIGger:EVENT<ev>:LEVel<n>[:VALue] <Level>

Sets the trigger level for the specified event and source (channel).

If the trigger source is serial bus, the trigger level is set by the thresholds in the protocol configuration.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

<n> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Level> Range: -10 to 10
Increment: 0.001
*RST: 0
Default unit: V

Usage: Asynchronous command

Manual operation: See "[\[Level\]](#)" on page 53

TRIGger:FINDlevel

Sets the trigger level automatically to $0.5 * (MaxPeak - MinPeak)$.

In a trigger sequence, "Find level" affects all active events of the sequence (A, B, and R event).

Usage: Event
Asynchronous command

Manual operation: See "[Find level](#)" on page 165

TRIGger:EVENT<ev>:SOURce <SourceDetailed>

Selects the source of the trigger signal for the selected trigger event. The trigger source works even if it is not displayed in a diagram.

Available sources depend on the trigger sequence setting. If you trigger on a single event, all inputs can be used as trigger source. If you trigger on a sequence, only analog channels can be set as trigger source for A, B, and R-events.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<SourceDetailed>

C1 | C2 | ... | C8

Available for single event, and A, B and R-events in a trigger sequence

EXTeranalog | LINE |

Available for single event (suffix 1)

D0 | D1 | D2 | ... | D14 | D15

Digital channels, require MSO option. Available for single event (suffix 1)

SBUS1 | SBUS2 | SBUS3 | SBUS4

Available if one or more serial protocol options are installed. If the hardware trigger is supported for a protocol, triggering on single event is possible with hardware trigger settings. For all protocols, the software trigger is supported in a "A → Serial bus" (event 2).

*RST: C1

Usage:

Asynchronous command

Manual operation: See "Source" on page 163

18.10.2 Trigger sequence

TRIGger:MEVents:AEVents.....	1008
TRIGger:MEVents:SEquence<se>:COUNT.....	1009
TRIGger:MEVents:SEquence<se>:DElay.....	1009
TRIGger:MEVents:SEquence<se>:RESet:EVENT.....	1009
TRIGger:MEVents:SEquence<se>:RESet:TIMEout:TIME.....	1010
TRIGger:MEVents:SEquence<se>:RESet:TIMEout[ENABLE].....	1010

TRIGger:MEVents:AEVents <Type>

Selects the type of the trigger sequence.

Parameters:

<Type>

AONLY | ABR | AZ | ASB

AONLY = single event, same as TRIGger:MEVents:MODE SINGLE

ABR = sequence A → B → R

AZ = sequence A → Zone trigger

ASB = sequence A → Serial bus

*RST: AONLy

Usage: Asynchronous command

Manual operation: See ["Trigger sequence"](#) on page 166

TRIGger:MEVents:SEQuence<se>:COUnT <Events>

Sets the number of B-trigger conditions to be fulfilled after an A-trigger. The last B-trigger causes the trigger event. The waiting time for B-triggers can be restricted with a reset condition: timeout or reset event.

Suffix:

<se> 1..3
2

Parameters:

<Events> Range: 1 to 2147483647
Increment: 1
*RST: 1

Usage: Asynchronous command

Manual operation: See ["B event count"](#) on page 167

TRIGger:MEVents:SEQuence<se>:DELaY <Delay>

Sets the time that the instrument waits after an A-trigger until it recognizes B-triggers.

Suffix:

<se> 1

Parameters:

<Delay> Range: 0 to 50
Increment: 1E-12
*RST: 0
Default unit: s

Usage: Asynchronous command

Manual operation: See ["Delay"](#) on page 167

TRIGger:MEVents:SEQuence<se>:RESet:EVENt <State>

If enabled, the trigger sequence is restarted by the R-trigger condition if the specified number of B-triggers does not occur before the R-trigger conditions are fulfilled.

Suffix:

<se> 3

Parameters:

<State> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Enable reset event"](#) on page 167

TRIGger:MEVents:SEquence<se>:RESet:TIMEout:TIME <ResetTimeout>

The time the instrument waits for the number of B-events specified using [TRIGger:MEVents:SEquence<se>:COUNT](#), before the sequence is restarted with the A-trigger.

Suffix:

<se> Irrelevant, omit the suffix.

Parameters:

<ResetTimeout> Range: 0 to 50
 Increment: 1E-12
 *RST: 0
 Default unit: s

Usage: Asynchronous command

Manual operation: See ["Enable reset by time, Reset timeout"](#) on page 167

TRIGger:MEVents:SEquence<se>:RESet:TIMEout[:ENABLE] <State>

If set to ON, the instrument waits for the time defined using [TRIGger:MEVents:SEquence<se>:RESet:TIMEout:TIME](#) for the specified number of B-events. If no trigger occurs during that time, the sequence is restarted with the A-event.

Suffix:

<se> Irrelevant, omit the suffix.

Parameters:

<State> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Enable reset by time, Reset timeout"](#) on page 167

18.10.3 Edge trigger

TRIGger:EVENT<ev>:EDGE:SLOPe	1011
TRIGger:ANEDge:LEVel	1011
TRIGger:ANEDge:COUPling	1011
TRIGger:ANEDge:FILTer	1012

TRIGger:ANEDge:CUToff:HIGHpass.....	1012
TRIGger:ANEDge:CUToff:LOWPass.....	1012
TRIGger:ANEDge:NREJect.....	1012

TRIGger:EVENT<ev>:EDGE:SLOPe <Slope>

Sets the edge direction for the trigger.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<Slope> POSitive | NEGative | EITHer
*RST: POSitive

Usage: Asynchronous command

Manual operation: See "[Slope](#)" on page 168

TRIGger:ANEDge:LEVEl <ExtTrigLev>

Sets the trigger level for the external trigger source.

Parameters:

<ExtTrigLev> Range: - 5 to 5
Default unit: V

Usage: Asynchronous command

Manual operation: See "[Level](#)" on page 164

TRIGger:ANEDge:COUPLing <Coupling>

Sets the connection of the external trigger signal, i.e. the input impedance and a termination. The coupling determines what part of the signal is used for triggering.

Parameters:

<Coupling> DC | DCLimit | AC

DC

Connection with 50 Ω termination, passes both DC and AC components of the signal.

DCLimit

Connection with 1 M Ω termination, passes both DC and AC components of the signal.

AC

Connection with 1 M Ω termination through DC capacitor, removes DC and very low-frequency components. The waveform is centered on zero volts.

*RST: DCLimit

Usage: Asynchronous command

Manual operation: See "[Coupling](#)" on page 170

TRIGger:ANEDge:FILTer <Filter>

Selects the filter mode for the external trigger signal.

Parameters:

<Filter> OFF | LFReject | RFReject
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Filter, Cut-off"](#) on page 170

TRIGger:ANEDge:CUToff:HIGHpass <CutOffFreq>

Frequencies below the cutoff frequency are rejected, higher frequencies pass the filter.

Parameters:

<CutOffFreq> KHZ5 | KHZ50
KHZ5 = 5 kHz
KHZ50 = 50 kHz
*RST: KHZ50

Usage: Asynchronous command

Manual operation: See ["Filter, Cut-off"](#) on page 170

TRIGger:ANEDge:CUToff:LOWPass <CutOffFreq>

Frequencies higher than the cutoff frequency are rejected, lower frequencies pass the filter.

Parameters:

<CutOffFreq> KHZ50 | MHZ50
KHZ50 = 50 kHz
MHZ50 = 50 MHz
*RST: KHZ50

Usage: Asynchronous command

Manual operation: See ["Filter, Cut-off"](#) on page 170

TRIGger:ANEDge:NREJect <NoiseReject>

Enables an automatic hysteresis on the trigger level to avoid unwanted trigger events caused by noise.

Parameters:

<NoiseReject> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Trigger noise reject"](#) on page 170

18.10.4 Glitch trigger

TRIGger:EVENT<ev>:GLITch:POLarity.....	1013
TRIGger:EVENT<ev>:GLITch:RANGe.....	1013
TRIGger:EVENT<ev>:GLITch:WIDTh.....	1013

TRIGger:EVENT<ev>:GLITch:POLarity <Polarity>

Sets the polarity of a pulse, which is the direction of the first pulse slope.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<Polarity> POSitive | NEGative | EITHer
*RST: POSitive

Usage: Asynchronous command

Manual operation: See "Polarity" on page 171

TRIGger:EVENT<ev>:GLITch:RANGe <RangeMode>

Selects which glitches are identified: shorter or longer than the width specified using [TRIGger:EVENT<ev>:GLITch:WIDTh](#).

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<RangeMode> SHORter | LONGer

SHORter

Glitches shorter than the specified width are identified.

LONGer

Glitches longer than the specified width are identified.

*RST: SHORter

Usage: Asynchronous command

Manual operation: See "Range" on page 171

TRIGger:EVENT<ev>:GLITch:WIDTh <Width>

Sets the length of a glitch. The instrument triggers on pulses shorter or longer than this value, depending on the value set with [TRIGger:EVENT<ev>:GLITch:RANGe](#).

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<Width> Range: 1E-10 to 10000
 Increment: 0.0001
 *RST: 1E-09
 Default unit: s

Usage: Asynchronous command

Manual operation: See "[Width](#)" on page 171

18.10.5 Width trigger

TRIGger:EVENT<ev>:WIDTH:DELTA	1014
TRIGger:EVENT<ev>:WIDTH:POLarity	1014
TRIGger:EVENT<ev>:WIDTH:RANGE	1014
TRIGger:EVENT<ev>:WIDTH:WIDTH	1015

TRIGger:EVENT<ev>:WIDTH:DELTA <WidthDelta>

Defines a range around the width value.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<WidthDelta> Range: 0 to 432
 Increment: 5E-10
 *RST: 0
 Default unit: s

Usage: Asynchronous command

Manual operation: See "[±Delta](#)" on page 173

TRIGger:EVENT<ev>:WIDTH:POLarity <Polarity>

Sets the polarity of a pulse, which is the direction of the first pulse slope.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<Polarity> POSitive | NEGative | EITHer
 *RST: POSitive

Usage: Asynchronous command

Manual operation: See "[Polarity](#)" on page 173

TRIGger:EVENT<ev>:WIDTH:RANGE <RangeMode>

Selects how the range of a pulse width is defined.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<RangeMode> WITHin | OUTSide | SHORter | LONGer

*RST: WITHin

Usage:

Asynchronous command

Manual operation: See "Range" on page 173

TRIGger:EVENT<ev>:WIDTH:WIDTH <Width>

Depending on the values of **TRIGger:EVENT<ev>:WIDTH:RANGE** the width sets:

- For the ranges **Within** and **Outside**, the width defines the center of a time range which is defined by the limits " $\pm\Delta$ " (see **TRIGger:EVENT<ev>:WIDTH:DELTA**).
- For the ranges **Shorter** and **Longer**, it defines the maximum and minimum time lapse, respectively.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<Width> Range: 1E-10 to 10000

Increment: 1E-07

*RST: 5E-09

Default unit: s

Usage:

Asynchronous command

Manual operation: See "Width" on page 173

18.10.6 Runt trigger

TRIGger:EVENT<ev>:LEVel<n>:RUNT:LOWer	1015
TRIGger:EVENT<ev>:LEVel<n>:RUNT:UPPer	1016
TRIGger:EVENT<ev>:RUNT:DELTA	1016
TRIGger:EVENT<ev>:RUNT:POLarity	1016
TRIGger:EVENT<ev>:RUNT:RANGE	1017
TRIGger:EVENT<ev>:RUNT:WIDTH	1017

TRIGger:EVENT<ev>:LEVel<n>:RUNT:LOWer <Level>

Sets the lower voltage limit.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

<n> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Level> Range: -10 to 10
 Increment: 0.001
 *RST: -0.1
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Lower level](#)" on page 175

TRIGger:EVENT<ev>:LEVel<n>:RUNT:UPPer <Level>

Sets the upper voltage limit.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event
 <n> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Level> Range: -10 to 10
 Increment: 0.001
 *RST: 0.1
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Upper level](#)" on page 174

TRIGger:EVENT<ev>:RUNT:DELTA <WidthDelta>

Defines a range around the runt width specified using [TRIGger:EVENT<ev>:RUNT:WIDTH](#).

Available if [TRIGger:EVENT<ev>:RUNT:RANGE](#) is set to WITHin or OUTSide.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<WidthDelta> Range: 1E-10 to 864
 Increment: 1E-07
 *RST: 1E-10
 Default unit: s

Usage: Asynchronous command

Manual operation: See "[±Delta](#)" on page 175

TRIGger:EVENT<ev>:RUNT:POLarity <Polarity>

Sets the polarity of a pulse, which is the direction of the first pulse slope.

Suffix:
 <ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:
 <Polarity> POSitive | NEGative | EITHer
 *RST: POSitive

Usage: Asynchronous command

Manual operation: See "[Polarity](#)" on page 171

TRIGger:EVENT<ev>:RUNT:RANGe <Mode>

Defines the time limit of the runt pulse in relation to the [TRIGger:EVENT<ev>:RUNT:WIDTh](#) and [TRIGger:EVENT<ev>:RUNT:DELTA](#) settings.

Suffix:
 <ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:
 <Mode> ANY | LONGer | SHORter | WITHin | OUTSide

ANY
 Triggers on all runs fulfilling the level condition, without time limitation.

LONGer
 Triggers on runs longer than the given runt width.

SHORter
 Triggers on runs shorter than the given runt width.

WITHin
 Triggers if the runt length is inside a given time range. The range is defined by runt width and $\pm\Delta$.

OUTSide
 Triggers if the runt length is outside a given time range. The range is defined by runt width and $\pm\Delta$.

*RST: ANY

Usage: Asynchronous command

Manual operation: See "[Range](#)" on page 175

TRIGger:EVENT<ev>:RUNT:WIDTh <Width>

Defines the upper or lower voltage threshold.

It is not available if [TRIGger:EVENT<ev>:RUNT:RANGe](#) is set to ANY.

Suffix:
 <ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<Width> Range: 1E-10 to 10000
 Increment: 1E-07
 *RST: 5E-09
 Default unit: s

Usage: Asynchronous command

Manual operation: See ["Runt width"](#) on page 175

18.10.7 Window trigger

TRIGger:EVENT<ev>:LEVel<n>:WINDow:LOWer.....	1018
TRIGger:EVENT<ev>:LEVel<n>:WINDow:UPPer.....	1018
TRIGger:EVENT<ev>:WINDow:DELTA.....	1019
TRIGger:EVENT<ev>:WINDow:RANGe.....	1019
TRIGger:EVENT<ev>:WINDow:TIME.....	1020
TRIGger:EVENT<ev>:WINDow:WIDTh.....	1020

TRIGger:EVENT<ev>:LEVel<n>:WINDow:LOWer <Level>

Sets the lower voltage limit.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event
 <n> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Level> Range: -10 to 10
 Increment: 0.001
 *RST: -0.1
 Default unit: V

Usage: Asynchronous command

Manual operation: See ["Lower level"](#) on page 177

TRIGger:EVENT<ev>:LEVel<n>:WINDow:UPPer <Level>

Sets the upper voltage limit.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event
 <n> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Level> Range: 0 to 1000
 Increment: 1E-06
 *RST: 0.1
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Upper level](#)" on page 176

TRIGger:EVENT<ev>:WINDow:DELTA <WidthDelta>

Defines a range around the width value.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<WidthDelta> Range: 0 to 432
 Increment: 5E-10
 *RST: 0
 Default unit: s

Usage: Asynchronous command

Manual operation: See "[±Delta](#)" on page 177

TRIGger:EVENT<ev>:WINDow:RANGe <RangeMode>

Selects how the signal run is compared with the window.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<RangeMode> ENTer | EXIT | WITHin | OUTSide

ENTer

Triggers when the signal crosses the upper or lower level and thus enters the window made up of these two levels.

EXIT

Triggers when the signal leaves the window.

WITHin

Triggers if the signal stays between the upper and lower level for a specified time. The time is defined with [TRIGger:EVENT<ev>:WINDow:TIME](#).

OUTSide

Triggers if the signal stays above the upper level or below the lower level for a specified time. The time is defined with [TRIGger:EVENT<ev>:WINDow:TIME](#).

*RST: ENTer

Usage: Asynchronous command

Manual operation: See "Vertical condition" on page 176

TRIGger:EVENT<ev>:WINDow:TIME <TimeRangeMode>

Available for TRIGger:EVENT<ev>:WINDow:RANGe = WITHin and OUTSide.

Selects how the time limit of the window is defined.

You can specify the width with TRIGger:EVENT<ev>:WINDow:WIDTh and the delta with TRIGger:EVENT<ev>:WINDow:DELTA.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<TimeRangeMode> WITHin | OUTSide | SHORter | LONGer

WITHin

Triggers if the signal stays inside or outside the vertical window limits at least for the time *Width - Delta* and for *Width + Delta* at the most.

OUTSide

"Outside" is the opposite definition of "Within". The instrument triggers if the signal stays inside or outside the vertical window limits for a time shorter than *Width - Delta* or longer than *Width + Delta*.

SHORter

Triggers if the signal crosses vertical limits before the specified width time is reached.

LONGer

Triggers if the signal crosses vertical limits before the specified width time is reached.

*RST: WITHin

Usage: Asynchronous command

Manual operation: See "Time condition" on page 177

TRIGger:EVENT<ev>:WINDow:WIDTh <Width>

Depending on the values of TRIGger:EVENT<ev>:WINDow:RANGe the width sets:

- For the ranges *Within* and *Outside*, the width defines the center of a time range. The range is defined by the limits " $\pm\Delta$ ", see TRIGger:EVENT<ev>:WINDow:DELTA.
- For the ranges *Shorter* and *Longer*, it defines the maximum and minimum time lapse, respectively.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<Width> Range: 1E-10 to 10000
 Increment: 1E-07
 *RST: 5E-09
 Default unit: s

Usage: Asynchronous command

Manual operation: See "[Width](#)" on page 177

18.10.8 Timeout trigger

[TRIGger:EVENT<ev>:TIMEout:RANGe](#)..... 1021

[TRIGger:EVENT<ev>:TIMEout:TIME](#)..... 1021

TRIGger:EVENT<ev>:TIMEout:RANGe <TimeoutMode>

Sets the relation of the signal level to the trigger level for the timeout trigger.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<TimeoutMode> HIGH | LOW | EITHER
 HIGH = stays high, the signal level stays above the trigger level.
 LOW = stays low, the signal level stays below the trigger level.
 EITHER = stays high or low.
 *RST: HIGH

Usage: Asynchronous command

Manual operation: See "[Range](#)" on page 178

TRIGger:EVENT<ev>:TIMEout:TIME <Time>

Sets the time limit for the timeout at which the instrument triggers.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<Time> Range: 1E-10 to 10000
 Increment: 1E-07
 *RST: 1E-07
 Default unit: s

Usage: Asynchronous command

Manual operation: See "[Time](#)" on page 178

18.10.9 Interval trigger

TRIGger:EVENT<ev>:INTerval:DELTA.....	1022
TRIGger:EVENT<ev>:INTerval:RANGE.....	1022
TRIGger:EVENT<ev>:INTerval:SLOPe.....	1023
TRIGger:EVENT<ev>:INTerval:WIDTh.....	1023

TRIGger:EVENT<ev>:INTerval:DELTA <WidthDelta>

Sets a range around the interval width value specified with [TRIGger:EVENT<ev>:INTerval:WIDTh](#).

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<WidthDelta> Range: 0 to 10
Increment: 1E-07
*RST: 0
Default unit: s

Usage: Asynchronous command

Manual operation: See "[±Delta](#)" on page 180

TRIGger:EVENT<ev>:INTerval:RANGE <RangeMode>

Defines the range of an interval in relation to the interval width specified using [TRIGger:EVENT<ev>:INTerval:WIDTh](#) and [TRIGger:EVENT<ev>:INTerval:DELTA](#).

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<RangeMode> WITHin | OUTSide | SHORter | LONGer

WITHin

Triggers on pulses inside a given range. The range is defined by the interval width $\pm\delta$.

OUTSide

Triggers on pulses outside a given range. The range is defined by the interval width $\pm\delta$.

SHORter

Triggers on pulses shorter than the given interval width.

LONGer

Triggers on pulses longer than the given interval width.

*RST: OUTSide

Usage: Asynchronous command

Manual operation: See "[Range](#)" on page 179

TRIGger:EVENT<ev>:INTERval:SLOPe <Slope>

Sets the edge for the trigger. You can analyze the interval between positive edges or between negative edges.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<Slope> POSitive | NEGative | EITHer

*RST: POSitive

Usage: Asynchronous command

Manual operation: See "[Slope](#)" on page 179

TRIGger:EVENT<ev>:INTERval:WIDTh <Width>

Sets the time between two pulses for the interval trigger.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<Width> Range: 1E-10 to 10000

Increment: 1E-07

*RST: 5E-09

Default unit: s

Usage: Asynchronous command

Manual operation: See "[Interv. width](#)" on page 180

18.10.10 Slew rate trigger

TRIGger:EVENT<ev>:LEVel<n>:SLEW:LOWer	1023
TRIGger:EVENT<ev>:LEVel<n>:SLEW:UPPer	1024
TRIGger:EVENT<ev>:SLEW:DELTA	1024
TRIGger:EVENT<ev>:SLEW:RANGe	1024
TRIGger:EVENT<ev>:SLEW:RATE	1025
TRIGger:EVENT<ev>:SLEW:SLOPe	1025

TRIGger:EVENT<ev>:LEVel<n>:SLEW:LOWer <Level>

Sets the lower voltage threshold. When the signal crosses this level, the slew rate measurement starts or stops depending on the selected slope.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

<n> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Level> Range: -10 to 10
 Increment: 0.001
 *RST: -0.1
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Lower level](#)" on page 181

TRIGger:EVENT<ev>:LEVel<n>:SLEW:UPPer <Level>

Sets the upper voltage threshold. When the signal crosses this level, the slew rate measurement starts or stops depending on the selected slope.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event
 <n> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Level> Range: -10 to 10
 Increment: 0.001
 *RST: 0.1
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Upper level](#)" on page 181

TRIGger:EVENT<ev>:SLEW:DELTA <TimeDelta>

Defines a time range around the given slew rate.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<TimeDelta> Range: 0 to 10
 Increment: 1E-07
 *RST: 0
 Default unit: s

Usage: Asynchronous command

Manual operation: See "[±Delta](#)" on page 182

TRIGger:EVENT<ev>:SLEW:RANGe <RangeMode>

Selects how the time limit for the slew rate is defined. The time measurement starts when the signal crosses the first trigger level - the upper or lower limit depending on the selected slope. The measurement stops when the signal crosses the second level.

You can select the rate with `TRIGger:EVENT<ev>:SLEW:RATE` and set the delta with `TRIGger:EVENT<ev>:SLEW:DELTA`.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<RangeMode> INSRange | OUTRange | LTHan | GTHan

INSRange

Triggers on pulses inside a given range. The range is defined by the slew rate $\pm\Delta$.

OUTRange

Triggers on pulses outside a given range. The range is defined by the slew rate $\pm\Delta$.

LTHan

Triggers on pulses shorter than the given slew rate.

GTHan

Triggers on pulses longer than the given slew rate.

*RST: GTHan

Usage:

Asynchronous command

Manual operation: See "Range" on page 182

TRIGger:EVENT<ev>:SLEW:RATE <Time>

For `TRIGger:EVENT<ev>:SLEW:RATE = INSRange` and `OUTRange`, the slew rate defines the center of a range which is defined by the limits " $\pm\Delta$ ".

For `TRIGger:EVENT<ev>:SLEW:RATE = LTHan` and `GTHan`, the slew rate defines the maximum and minimum slew rate limits, respectively. When the signal crosses this level, the slew rate measurement starts or stops depending on the selected slope (see `TRIGger:EVENT<ev>:SLEW:SLOPe`).

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<Time> Range: 1E-10 to 10000
Increment: 1E-07
*RST: 1E-10
Default unit: s

Usage:

Asynchronous command

Manual operation: See "Slew rate" on page 182

TRIGger:EVENT<ev>:SLEW:SLOPe <Slope>

Sets the edge direction for the trigger.

Suffix:
 <ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:
 <Slope> POSitive | NEGative | EITHer
 *RST: POSitive

Usage: Asynchronous command

Manual operation: See "[Slope](#)" on page 181

18.10.11 Setup & Hold

TRIGger:EVENT<ev>:SETHold:CSource:EDGE.....	1026
TRIGger:EVENT<ev>:SETHold:CSource:LEVel.....	1026
TRIGger:EVENT<ev>:SETHold:CSource[:VALue].....	1027
TRIGger:EVENT<ev>:SETHold:HTIME.....	1027
TRIGger:EVENT<ev>:SETHold:STIME.....	1027

TRIGger:EVENT<ev>:SETHold:CSource:EDGE <ClockEdge>

Sets the edge of the clock signal. Edge and level define the time reference point.

Suffix:
 <ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:
 <ClockEdge> POSitive | NEGative | EITHer
 *RST: POSitive

Usage: Asynchronous command

Manual operation: See "[Clock edge](#)" on page 183

TRIGger:EVENT<ev>:SETHold:CSource:LEVel <ClockLevel>

Sets the voltage level for the clock signal.

Both the clock level and the clock edge define the starting point for calculation of the setup and hold time.

Suffix:
 <ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:
 <ClockLevel> Range: -10 to 10
 Increment: 0.001
 *RST: 0
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Clock level](#)" on page 184

TRIGger:EVENT<ev>:SETHold:CSource[:VALue] <ClockSource>

Selects the input channel of the clock signal.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<ClockSource> C1 | C2 | ... | C8

The following values are also accepted:

C1 = CHAN1 = CHANnel1, C2 = CHAN2 = CHANnel2,

C3 = CHAN3 = CHANnel3, C4 = CHAN4 = CHANnel4

*RST: C1

Usage: Asynchronous command

Manual operation: See "[Clock source](#)" on page 183

TRIGger:EVENT<ev>:SETHold:HTIME <HoldTime>

Sets the minimum time **after** the clock edge while the data signal must stay steady above or below the data level.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<HoldTime> Range: -9.9999E-08 to 1E-07

Increment: 1E-09

*RST: 0

Default unit: s

Usage: Asynchronous command

Manual operation: See "[Hold time](#)" on page 184

TRIGger:EVENT<ev>:SETHold:STIME <SetupTime>

Sets the minimum time **before** the clock edge while the data signal must stay steady above or below the data level.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<SetupTime> Range: -9.9999E-08 to 1E-07

Increment: 1E-09

*RST: 0

Default unit: s

Usage: Asynchronous command

Manual operation: See "[Setup time](#)" on page 184

18.10.12 State trigger

TRIGger:EVENT<ev>:STATe:QUALify:ANALog:CHAN<n>:HLX.....	1028
TRIGger:EVENT<ev>:STATe:QUALify:LOGic.....	1028
TRIGger:EVENT<ev>:STATe:SLOPe.....	1028
TRIGger:EVENT<ev>:STATe:QUALify:DIGital:LOGic.....	1029
TRIGger:EVENT<ev>:STATe:QUALify:DIGital:CHAN<n>:HLX.....	1029

TRIGger:EVENT<ev>:STATe:QUALify:ANALog:CHAN<n>:HLX <HLX>

Set the state for each channel. For the state trigger, the clock source is indicated and does not get a state.

Suffix:

<ev>	1 = A-trigger, 2 = B-trigger, 3 = reset event
<n>	1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<HLX>	HIGH LOW DONTcare
	State of the individual channels
*RST:	DONTcare

Example:

```
TRIG:EVENT1:SOUR C1
TRIG:EVENT1:SLOP POS
TRIG:EVENT1:STAT:QUAL:ANAL:CHAN2:HLX HIGH
TRIG:EVENT1:STAT:QUAL:ANAL:CHAN3:HLX LOW
TRIG:EVENT1:STAT:QUAL:ANAL:CHAN4:HLX HIGH
TRIG:EVENT1:STAT:QUAL:LOG AND
```

Usage: Asynchronous command

Manual operation: See ["Source: channel states"](#) on page 188

TRIGger:EVENT<ev>:STATe:QUALify:LOGic <StateOperator>

Defines the logic combination of the channels and their states.

Suffix:

<ev>	1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<StateOperator>	AND OR
*RST:	AND

Usage: Asynchronous command

Manual operation: See ["Logic Operator"](#) on page 188

TRIGger:EVENT<ev>:STATe:SLOPe <Slope>

Sets the edge direction for the trigger.

Suffix:
 <ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:
 <Slope> POSitive | NEGative | EITHer
 *RST: POSitive

Usage: Asynchronous command

Manual operation: See "[Slope](#)" on page 185

TRIGger:EVENT<ev>:STATe:QUALify:DIGital:LOGic <Logic>

Defines the logic combination of the channels and their states.

Suffix:
 <ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:
 <Logic> AND | OR
 *RST: AND

Usage: Asynchronous command

Manual operation: See "[Logic Operator](#)" on page 188

TRIGger:EVENT<ev>:STATe:QUALify:DIGital:CHAN<n>:HLX <HLX>

Sets the required state for each digital channel that is used for triggering.

Suffix:
 <ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event
 <n> 0 to 15, index of the logic channel

Parameters:
 <HLX> HIGH | LOW | DONTcare
 *RST: DONTcare

Usage: Asynchronous command

Manual operation: See "[Source: channel states](#)" on page 189

18.10.13 Pattern trigger

TRIGger:EVENT<ev>:PATtern:QUALify:ANALog:CHAN<n>:HLX..... 1030
 TRIGger:EVENT<ev>:PATtern:QUALify:DIGital:CHAN<n>:HLX..... 1030
 TRIGger:EVENT<ev>:PATtern:QUALify:LOGic..... 1030
 TRIGger:EVENT<ev>:PATtern:QUALify:DIGital:LOGic..... 1031
 TRIGger:EVENT<ev>:PATtern:QUALify:SOURces..... 1031

TRIGger:EVENT<ev>:PATTern:QUALify:ANALog:CHAN<n>:HLX <HLX>

Set the state for each channel. For the state trigger, the clock source is indicated and does not get a state.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

<n> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<HLX> HIGH | LOW | DONTcare
State of the individual channels
*RST: DONTcare

Example:

```
TRIG:EVENT1:PATT:QUAL:ANAL:CHAN1:HLX LOW
TRIG:EVENT1:PATT:QUAL:ANAL:CHAN2:HLX HIGH
TRIG:EVENT1:PATT:QUAL:ANAL:CHAN3:HLX LOW
TRIG:EVENT1:PATT:QUAL:ANAL:CHAN4:HLX HIGH
TRIG:EVENT1:PATT:QUAL:LOG AND
```

Usage: Asynchronous command

Manual operation: See ["Source: channel states"](#) on page 188

TRIGger:EVENT<ev>:PATTern:QUALify:DIGital:CHAN<n>:HLX <HLX>

Sets the required state for each digital channel that is used for triggering.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

<n> 0 to 15, index of the logic channel

Parameters:

<HLX> HIGH | LOW | DONTcare
*RST: DONTcare

Usage: Asynchronous command

Manual operation: See ["Source: channel states"](#) on page 189

TRIGger:EVENT<ev>:PATTern:QUALify:LOGic <StateOperator>

Defines the logic combination of the channels and their states.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<StateOperator> AND | OR
*RST: AND

Usage: Asynchronous command

Manual operation: See ["Logic Operator"](#) on page 188

TRIGger:EVENT<ev>:PATtern:QUALify:DIGital:LOGic <Logic>

Defines the logic combination of the channels and their states.

Suffix:

<ev> 1..3

Parameters:

<Logic> AND | OR
*RST: AND

Usage: Asynchronous command

Manual operation: See ["Logic Operator"](#) on page 188

TRIGger:EVENT<ev>:PATtern:QUALify:SOURces <StateSources>

Selects if the source of the trigger for the pattern type is an analog or digital channel.

Suffix:

<ev> 1 = A-trigger, 2 = B-trigger, 3 = reset event

Parameters:

<StateSources> ANALog | DIGital
*RST: ANALog

Usage: Asynchronous command

Manual operation: See ["State sources"](#) on page 186

18.10.14 Trigger mode, holdoff

TRIGger:MODE.....	1031
TRIGger:FORCE.....	1032
TRIGger:HOLDoff:MODE.....	1032
TRIGger:HOLDoff:AUTotime?.....	1033
TRIGger:HOLDoff:SCALing.....	1033
TRIGger:HOLDoff:EVENTs.....	1034
TRIGger:HOLDoff:MAX.....	1034
TRIGger:HOLDoff:MIN.....	1034
TRIGger:HOLDoff:TIME.....	1034

TRIGger:MODE <TriggerMode>

Sets the trigger mode which determines the behavior of the instrument with and without a trigger event.

Parameters:

<TriggerMode> AUTO | NORMal | FREerun

AUTO

The instrument triggers repeatedly after a time interval if the trigger conditions are not fulfilled. If a real trigger occurs, it takes precedence. The time interval depends on the time base.

NORMAl

The instrument acquires a waveform only if a trigger occurs.

FREerun

The instrument triggers after a very short time interval - faster than in AUTO mode. Real triggers are ignored.

*RST: AUTO

Usage: Asynchronous command

Manual operation: See "[Auto Norm]" on page 54

TRIGger:FORCe

Provokes an immediate single acquisition. Force the trigger if the acquisition is running in normal mode and no valid trigger occurs. Thus, you can confirm that a signal is available and use the waveform display to determine how to trigger on it.

Usage: Setting only
Asynchronous command

Manual operation: See "Force trigger" on page 191

TRIGger:HOLDoff:MODE <Mode>

Selects the method to define the holdoff condition.

The trigger holdoff defines when the next trigger after the current will be recognized. Thus, it affects the next trigger to occur after the current one. Holdoff helps to obtain stable triggering when the oscilloscope is triggering on undesired events.

Holdoff settings are not available if the trigger source is an external trigger input or serial bus, and if you trigger on a sequence of events.

Parameters:

<Mode>

TIME | EVENTs | RANDom | AUTO | OFF

TIME

Defines the holdoff directly as a time period. The next trigger occurs only after the holdoff time has passed, which is defined using `TRIGger:HOLDoff:TIME`).

EVENTs

Defines the holdoff as a number of trigger events. The next trigger occurs only when this number of events is reached. The number of triggers to be skipped is defined with `TRIGger:HOLDoff:EVENTs`.

RANdOm

Defines the holdoff as a random time limited by **TRIGger:HOlDoff:MIN** and **TRIGger:HOlDoff:MAX**. For each acquisition cycle, the instrument selects a new random holdoff time from the specified range.

AUTO

The holdoff time is calculated automatically based on the current horizontal scale.

OFF

No holdoff

*RST: OFF

Usage: Asynchronous command

Manual operation: See "[Holdoff mode](#)" on page 191

TRIGger:HOlDoff:AUTotime?

Returns the resulting holdoff time, if **TRIGger:HOlDoff:MODE** is set to **AUTO**: *Auto time = Auto time scaling * Horizontal scale*. The auto time scaling factor is defined with **TRIGger:HOlDoff:SCALing**.

Return values:

<AutoTime> Range: 1E-07 to 10
 Increment: 0.0002
 *RST: 0.001
 Default unit: s

Usage: Query only
 Asynchronous command

Manual operation: See "[Holdoff mode](#)" on page 191

TRIGger:HOlDoff:SCALing <AutoTimeScl>

Sets the auto time scaling factor that the horizontal scale is multiplied with, if **TRIGger:HOlDoff:MODE** is set to **AUTO**. *Auto time = Auto time scaling * Horizontal scale*

The next trigger occurs only after this time has passed.

Parameters:

<AutoTimeScl> Range: 0.001 to 1000
 Increment: 1
 *RST: 0.5

Usage: Asynchronous command

Manual operation: See "[Holdoff mode](#)" on page 191

TRIGger:HOLDoff:EVENTs <Events>

Defines the number of triggers to be skipped, if **TRIGger:HOLDoff:MODETRIGger:HOLDoff:MODE** is set to **EVENTs**. The next trigger only occurs when this number of events is reached.

Parameters:

<Events> Range: 1 to 2147483647
 Increment: 10
 *RST: 1

Usage: Asynchronous command

Manual operation: See "[Holdoff mode](#)" on page 191

TRIGger:HOLDoff:MAX <RandomMaxTime>

Defines the upper limit for the random time holdoff, if **TRIGger:HOLDoff:MODETRIGger:HOLDoff:MODE** is set to **RANDom**.

Parameters:

<RandomMaxTime> Range: 1E-07 to 10
 Increment: 0.0002
 *RST: 0.002
 Default unit: s

Usage: Asynchronous command

Manual operation: See "[Holdoff mode](#)" on page 191

TRIGger:HOLDoff:MIN <RandomMinTime>

Defines the lower limit for the random time holdoff, if **TRIGger:HOLDoff:MODETRIGger:HOLDoff:MODE** is set to **RANDom**.

Parameters:

<RandomMinTime> Range: 1E-07 to 5
 Increment: 0.0002
 *RST: 0.001
 Default unit: s

Usage: Asynchronous command

Manual operation: See "[Holdoff mode](#)" on page 191

TRIGger:HOLDoff:TIME <Time>

Defines the holdoff time period, if **TRIGger:HOLDoff:MODE** is set to **TIME**. The next trigger occurs only after this time has passed.

Parameters:

<Time> Range: 1E-07 to 10
 Increment: 0.0002
 *RST: 0.001
 Default unit: s

Usage: Asynchronous command

Manual operation: See "[Holdoff mode](#)" on page 191

18.10.15 Hysteresis

TRIGger:NOISe<m>:ABSolute	1035
TRIGger:NOISe<m>:EFFective?	1035
TRIGger:NOISe<m>:MODE	1036
TRIGger:NOISe<m>:PERDivision	1036
TRIGger:NOISe<m>:RELative	1036
TRIGger:NOISe<m>[:STATe]	1037

TRIGger:NOISe<m>:ABSolute <Absolute>

Defines a range in absolute values around the trigger level. If the signal oscillates inside this range and thus crosses the trigger level, no trigger event occurs.

Suffix:

<m> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Absolute> Range: 0 to 10000000
 Increment: 0.001
 *RST: 0
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Absolute hysteresis](#)" on page 193

TRIGger:NOISe<m>:EFFective?

Returns the hysteresis that is set by the instrument in automatic hysteresis mode.

Suffix:

<m> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<Effective> numeric value
 Range: 0 to 10000000
 Increment: 0.001
 *RST: 0
 Default unit: V

Usage: Query only
Asynchronous command

Manual operation: See ["HW hysteresis"](#) on page 193

TRIGger:NOISe<m>:MODE <Mode>

Selects whether the hysteresis is defined in absolute or relative values. The setting is available only in manual hysteresis mode.

Suffix:
<m> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:
<Mode> ABS | REL
*RST: ABS

Usage: Asynchronous command

Manual operation: See ["Hysteresis mode"](#) on page 193

TRIGger:NOISe<m>:PERDivision <InDivision>

Defines a range in divisions around the trigger level in division units. If the signal oscillates inside this range and crosses the trigger level thereby, no trigger event occurs.

Suffix:
<m> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:
<InDivision> Range: 0 to 5
Increment: 0.01
*RST: 0
Default unit: div

Usage: Asynchronous command

Manual operation: See ["Relative hysteresis"](#) on page 194

TRIGger:NOISe<m>:RELative <Relative>

Defines a range in divisions around the trigger level as percentage. If the signal oscillates inside this range and crosses the trigger level thereby, no trigger event occurs.

Suffix:
<m> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Relative> Range: 0 to 50
 Increment: 1
 *RST: 0
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Relative hysteresis"](#) on page 194

TRIGger:NOISe<m>[:STATe] <Mode>

Selects how the hysteresis is set.

Suffix:

<m> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<Mode> AUTO | MANual

AUTO

Automatic mode is the recommended mode. The hysteresis is set by the instrument to reject the internal noise of the instrument.

MANual

The hysteresis is defined with [TRIGger:NOISe<m>:ABSolute](#) or [TRIGger:NOISe<m>:RELative](#).

*RST: AUTO

Usage: Asynchronous command

18.10.16 Channel filter

TRIGger:FILTermode	1037
TRIGger:LFRreject	1038
TRIGger:RFReject	1038

TRIGger:FILTermode <Mode>

Selects the filter mode for the trigger channel.

Parameters:

<Mode> OFF | LFRreject | RFReject
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Trigger filter mode"](#) on page 194

TRIGger:LFReject <Bandwidth>

Sets the limit frequency limit for the highpass filter of the trigger signal. Frequencies lower than this value are rejected, higher frequencies pass the filter.

Parameters:

<Bandwidth> Range: 50 kHz
 *RST: 50 kHz
 Default unit: Hz

Usage: Asynchronous command

Manual operation: See "[LF reject BW](#)" on page 194

TRIGger:RFReject <Bandwidth>

Sets the limit frequency limit for the lowpass filter of the trigger signal. Frequencies higher than this value are rejected, lower frequencies pass the filter.

Parameters:

<Bandwidth> Range: 1E+3 to 500E+6
 Increment: 1000
 *RST: 1E+6
 Default unit: Hz

Usage: Asynchronous command

Manual operation: See "[RF reject BW](#)" on page 195

18.10.17 Actions on trigger

TRIGger:ACTions:BEEP.....	1038
TRIGger:ACTions:OUT:STATe.....	1039
TRIGger:ACTions:OUT:SOURce.....	1039
TRIGger:ACTions:OUT:DELay.....	1039
TRIGger:ACTions:OUT:PLENgtH.....	1039
TRIGger:ACTions:OUT:POLarity.....	1040
TRIGger:ACTions:SCReenshot.....	1040
TRIGger:ACTions:STOP.....	1040
TRIGger:ACTions:WFMSave.....	1040

TRIGger:ACTions:BEEP <Beep>

Generates a beep sound if the command is set to TRIGger.

Parameters:

<Beep> NOAction | TRIGger
 *RST: NOAction

Usage: Asynchronous command

Manual operation: See "[Beep](#)" on page 195

TRIGger:ACTions:OUT:STATe <State>

Activates the outgoing pulse on the [Trigger Out] connector on the rear panel.

If ON, a pulse is sent out each time when a trigger occurs.

Parameters:

<State> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Trigger out pulse"](#) on page 196

TRIGger:ACTions:OUT:SOURce <SignalSource>

Defines when the trigger out signal is initiated: at the trigger point, when waiting for the trigger, or when the post-trigger time is finished.

Parameters:

<SignalSource> TRIG | TRIGGER | POST | POSTTRIGGER | WAIT | WAITTRIGGER
TRIG = TRIGGER, POST = POSTTRIGGER, WAIT = WAIT-TRIGGER
*RST: TRIG

Usage: Asynchronous command

Manual operation: See ["Signal source"](#) on page 196

TRIGger:ACTions:OUT:DELay <Delay>

Defines the delay of the first pulse edge to the trigger point. The minimum delay is 600 ns.

Parameters:

<Delay> Range: 8E-07 to 1
Increment: 4E-09
*RST: 8E-07
Default unit: s

Usage: Asynchronous command

Manual operation: See ["Delay"](#) on page 197

TRIGger:ACTions:OUT:PLENgtH <PulseLength>

Sets the length of the trigger out pulse.

Parameters:

<PulseLength> Range: 1.6E-08 to 0.05
 Increment: 1.6E-08
 *RST: 9.6E-08
 Default unit: s

Usage: Asynchronous command

Manual operation: See ["Pulse length"](#) on page 197

TRIGger:ACTions:OUT:POLarity <Polarity>

Sets the polarity of the trigger out pulse, which is the direction of the first pulse edge.

Parameters:

<Polarity> POSitive | NEGative
 *RST: POSitive

Usage: Asynchronous command

Manual operation: See ["Polarity"](#) on page 197

TRIGger:ACTions:SCReenshot <SaveScreenshot>

Saves a screenshot at each trigger if the command is set to TRIGger.

To configure the screenshot settings, use the commands described in [Section 18.13.9, "Screenshots"](#), on page 1114.

Parameters:

<SaveScreenshot> NOAction | TRIGger
 *RST: NOAction

Usage: Asynchronous command

Manual operation: See ["Screenshot"](#) on page 196

TRIGger:ACTions:STOP <StopAcq>

Stops the running acquisition if the command is set to TRIGger.

Parameters:

<StopAcq> NOAction | TRIGger
 *RST: NOAction

Usage: Asynchronous command

Manual operation: See ["Stop acq"](#) on page 195

TRIGger:ACTions:WFMSave <SaveWfm>

Saves the waveform data to file at each trigger if the command is set to TRIGger.

To define the path and file names, use the `EXPort:WAVeform:AUTonaming:*` commands:

- `EXPort:WAVeform:AUTonaming:NAME` on page 1105
- `EXPort:WAVeform:AUTonaming:PATH` on page 1106
- `EXPort:WAVeform:AUTonaming:TYPE` on page 1106

Parameters:

<SaveWfm> NOAction | TRIGger
*RST: NOAction

Usage: Asynchronous command

Manual operation: See "Save wfm" on page 196

18.10.18 Zone trigger

Zone trigger commands are available since FW version 2.2.x.x.

<code>ZONE<m>:ADD</code>	1041
<code>TRIGger:ZONE:EXPRession[:DEFine]</code>	1042
<code>ZONE<m>:ACOMbination</code>	1042
<code>ZONE<m>:AREA<n>:ADD</code>	1042
<code>ZONE<m>:AREA<n>:COUNT?</code>	1042
<code>ZONE<m>:AREA<n>:INTersect</code>	1043
<code>ZONE<m>:AREA<n>:LABel</code>	1043
<code>ZONE<m>:AREA<n>:VALid?</code>	1043
<code>ZONE<m>:AREA<n>:POINT<o>:ADD</code>	1044
<code>ZONE<m>:AREA<n>:POINT<o>:COUNT?</code>	1044
<code>ZONE<m>:AREA<n>:POINT<o>:REMOve</code>	1044
<code>ZONE<m>:AREA<n>:POINT<o>:X</code>	1045
<code>ZONE<m>:AREA<n>:POINT<o>:Y</code>	1045
<code>ZONE<m>:AREA<n>:POINT<o>:VALid?</code>	1045
<code>ZONE<m>:AREA<n>:REMOve</code>	1046
<code>ZONE<m>:AREA<n>:STATe</code>	1046
<code>ZONE<m>:COUNT?</code>	1046
<code>ZONE<m>:DIAGram</code>	1046
<code>TRIGger:ZONE:HISTory</code>	1047
<code>ZONE<m>:REMOve</code>	1047
<code>ZONE<m>:SOURce</code>	1047
<code>ZONE<m>[:VISible]</code>	1047

ZONE<m>:ADD

Adds a new trigger zone.

Suffix:

<m> 1 to 4, index of the zone

Usage:

Setting only
Asynchronous command

Manual operation: See ["Add zone, !\[\]\(eafc244b53721dd1ec133f0772f70fc7_img.jpg\)](#)" on page 205

TRIGger:ZONE:EXPRession[:DEFine] <LogicExpression>

Defines the zone trigger. The available operators for the combination between the zones are AND | NOT | OR | XOR.

Parameters:

<LogicExpression> String with the logical expression

Example:

Prerequisite: Zone1 and Zone2 are defined.

```
TRIGger:ZONE:EXPRession 'Zone1 and Zone2'
```

```
TRIGger:ZONE:EXPRession?
```

```
<-- Zone1 and Zone2
```

Usage: Asynchronous command

Manual operation: See ["Trigger condition"](#) on page 206

ZONE<m>:ACOMbination <AreaCombination>

Sets the logic combination that applies to all areas in the indicated zone.

Suffix:

<m> 1 to 4, index of the zone

Parameters:

<AreaCombination> AND | OR

*RST: AND

Usage: Asynchronous command

Manual operation: See ["Area"](#) on page 205

ZONE<m>:AREA<n>:ADD

Adds a new area to the trigger zone.

Suffix:

<m> 1 to 4, index of the zone

<n> 1 to 8, index of the zone area

Usage: Setting only
Asynchronous command

Manual operation: See ["Area"](#) on page 205

ZONE<m>:AREA<n>:COUNT?

Returns the number of the defined areas in the zone.

ZONE<m>:AREA:COUNT? MAX returns the maximum number of areas that can be created.

Suffix:

<m> 1 to 4, index of the zone
 <n> Irrelevant, omit the suffix.

Return values:

<Count> Number of defined zone areas

Usage:

Query only
 Asynchronous command

Manual operation: See ["Area"](#) on page 205

ZONE<m>:AREA<n>:INTERsect <Intersection>

Defines if the signal must intersect the zone to allow the instrument to trigger, or if it must not intersect the zone.

Suffix:

<m> 1 to 4, index of the zone
 <n> 1 to 8, index of the zone area

Parameters:

<Intersection> MUST | NOT
 *RST: MUST

Usage:

Asynchronous command

Manual operation: See ["Area"](#) on page 205

ZONE<m>:AREA<n>:LABel <Label>

Defines a label for the selected area.

Suffix:

<m> 1 to 4, index of the zone
 <n> 1 to 8, index of the zone area

Parameters:

<Label>

Usage:

Asynchronous command

Manual operation: See ["Area"](#) on page 205

ZONE<m>:AREA<n>:VALid?

Checks the validity of the indicated zone area. The area is invalid if one of its points is invalid. See [Figure 7-13](#).

Suffix:

<m> 1 to 4, index of the zone
 <n> 1 to 8, index of the zone area

Return values:

<Valid> OFF | ON
 *RST: ON

Usage:

Query only
 Asynchronous command

ZONE<m>:AREA<n>:POINT<o>:ADD

Adds a new point to the area at the indicated point index.

To define the coordinates of the point, use `ZONE<m>:AREA<n>:POINT<o>:X` and `ZONE<m>:AREA<n>:POINT<o>:Y`.

Suffix:

<m> 1 to 4, index of the zone
 <n> 1 to 8, index of the zone area
 <o> 1 to 16, index of the zone area point

Usage:

Setting only
 Asynchronous command

ZONE<m>:AREA<n>:POINT<o>:COUNT?

Queries the number of the defined points in the area.

`ZONE<m>:AREA<n>:POINT<o>:COUNT? MAX` returns the maximum number of points that can be created.

Suffix:

<m> 1 to 4, index of the zone
 <n> 1 to 8, index of the zone area
 <o> Irrelevant, omit the suffix.

Return values:

<Count> Range: 0 to 16

Usage:

Query only
 Asynchronous command

ZONE<m>:AREA<n>:POINT<o>:REMove

Removes the selected point from the area.

Suffix:

<m> 1 to 4, index of the zone
 <n> 1 to 8, index of the zone area
 <o> 1 to 16, index of the zone area point

Usage: Setting only
Asynchronous command

ZONE<m>:AREA<n>:POINT<o>:X <X>

Sets the horizontal X coordinates for the selected point of the area.

Suffix:

<m> 1 to 4, index of the zone
<n> 1 to 8, index of the zone area
<o> 1 to 16, index of the zone area point

Parameters:

<X> Range: -1E+26 to 1E+26
Increment: 1E-06
*RST: 0
Default unit: s

Usage: Asynchronous command

ZONE<m>:AREA<n>:POINT<o>:Y <Y>

Sets the vertical Y coordinates for the selected point of the area.

Suffix:

<m> 1 to 4, index of the zone
<n> 1 to 8, index of the zone area
<o> 1 to 16, index of the zone area point

Parameters:

<Y> Range: -1E+26 to 1E+26
Increment: 1E-06
*RST: 0
Default unit: V

Usage: Asynchronous command

ZONE<m>:AREA<n>:POINT<o>:VALid?

Checks the validity of the selected point. See [Figure 7-13](#).

Suffix:

<m> 1 to 4, index of the zone
<n> 1 to 8, index of the zone area
<o> 1 to 16, index of the zone area point

Return values:

<Valid> OFF | ON
*RST: ON

Usage: Query only
Asynchronous command

ZONE<m>:AREA<n>:REMove

Removes the selected area from the trigger zone.

Suffix:
 <m> 1 to 4, index of the zone
 <n> 1 to 8, index of the zone area

Usage: Setting only
Asynchronous command

Manual operation: See ["Delete icon"](#) on page 206

ZONE<m>:AREA<n>:STATe <State>

Enables the selected area.

Suffix:
 <m> 1 to 4, index of the zone
 <n> 1 to 8, index of the zone area

Parameters:
 <State> OFF | ON
 *RST: ON

Usage: Asynchronous command

ZONE<m>:COUNT? <Count>

Returns the number of zones.

ZONE:COUNT? MAX returns the maximum number of zones that can be created.

Suffix:
 <m> Irrelevant, omit the suffix.

Return values:
 <Count> Number of defined zones

Usage: Query only
Asynchronous command

ZONE<m>:DIAGram <SignDiagKey>

Selects the diagram on which the zone trigger is applied, for example layoutset1 diagram1 (L1_D1).

For more information about the SmartGrid definition, see [Section 18.8.3, "SmartGrid"](#), on page 927.

Suffix:

<m> 1 to 4, index of the zone

Parameters:

<SignDiagKey> String that indicates the layout set and the diagram, e.g. "L1_D1".

Usage:

Asynchronous command

TRIGger:ZONE:HISTory <ApplyToHistory>

Applies the zone trigger condition to the acquisitions that are stored in the history memory. Thus, you can filter the history of waveforms on zone conditions.

Parameters:

<ApplyToHistory> OFF | ON
*RST: OFF

Usage:

Asynchronous command

Manual operation: See ["Apply zone trigger to history"](#) on page 208

ZONE<m>:REMOve

Removes the selected trigger zone.

Suffix:

<m> 1 to 4, index of the zone

Usage:

Setting only
Asynchronous command

Manual operation: See ["Delete icon"](#) on page 206

ZONE<m>:SOURce <Source>

Sets the source of the zone trigger.

Suffix:

<m> 1 to 4, index of the zone

Parameters:

<Source> NONE | C1 | C2 | ... | C8 | M1 | M2 | ... | M8 | XY1 | XY2 | XY3 | XY4 | SPECNORM1 | SPECNORM2 | SPECNORM3 | SPECNORM4

Usage:

Asynchronous command

Manual operation: See ["Source"](#) on page 205

ZONE<m>[:VISible] <DisplayState>

Enables the display of the zone on the screen.

Suffix:
 <m> 1 to 4, index of the zone

Parameters:
 <DisplayState> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See "Display" on page 205

18.11 Signal configuration

18.11.1 Reference levels

- [Reference level settings](#)..... 1048
- [Reference level results](#)..... 1052

18.11.1.1 Reference level settings

REFLevel<rl>:ENABLE	1048
REFLevel<rl>:LMODE	1049
REFLevel<rl>:ABSolute:HYSTeresis	1049
REFLevel<rl>:ABSolute:LLEVel	1049
REFLevel<rl>:ABSolute:MLEVel	1049
REFLevel<rl>:ABSolute:ULEVel	1050
REFLevel<rl>:RELative:HYSTeresis	1050
REFLevel<rl>:RELative:LOWer	1050
REFLevel<rl>:RELative:MIDDLE	1051
REFLevel<rl>:RELative:MODE	1051
REFLevel<rl>:RELative:UPPer	1052

REFLevel<rl>:ENABLE <First>

Enables the specified reference level.

Suffix:
 <rl> 1 to 8, index of the reference level set

Parameters:
 <First> OFF | ON

Usage: Asynchronous command

Manual operation: See "RLx" on page 210

REFLevel<rl>:LMODE <LevelMode>

Defines if the reference level is set in absolute or relative values.

Suffix:

<rl> 1 to 8, index of the reference level set

Parameters:

<LevelMode> ABS | REL
*RST: REL

Usage: Asynchronous command

Manual operation: See "[Level mode](#)" on page 210

REFLevel<rl>:ABSolute:HYSTeresis <HystAbs>

Defines a hysteresis for the middle reference level. A rise or fall from the middle reference value that does not exceed the hysteresis is rejected as noise.

Suffix:

<rl> 1 to 8, index of the reference level set

Parameters:

<HystAbs> Range: 0 to 1E+26
Increment: 0.001
*RST: 0.005
Default unit: V

Usage: Asynchronous command

Manual operation: See "[Hysteresis](#)" on page 211

REFLevel<rl>:ABSolute:LLEVel <LowerLevel>

Sets the lower reference level in absolute values. This is required, e.g., to determine a fall.

Suffix:

<rl> 1 to 8, index of the reference level set

Parameters:

<LowerLevel> Range: -1E+26 to 1E+26
Increment: 0.001
*RST: 0
Default unit: V

Usage: Asynchronous command

Manual operation: See "[Upper level, Middle level, Lower level](#)" on page 210

REFLevel<rl>:ABSolute:MLEVel <MiddleLevel>

Sets the middle reference level in absolute values.

Suffix:

<rl> 1 to 8, index of the reference level set

Parameters:

<MiddleLevel> Range: -1E+26 to 1E+26
 Increment: 0.001
 *RST: 0
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Upper level, Middle level, Lower level](#)" on page 210

REFLevel<rl>:ABSolute:ULEVel <UpperLevel>

Sets the upper reference level in absolute values. This is required to determine a rise.

Suffix:

<rl> 1 to 8, index of the reference level set

Parameters:

<UpperLevel> Range: -1E+26 to 1E+26
 Increment: 0.001
 *RST: 0
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Upper level, Middle level, Lower level](#)" on page 210

REFLevel<rl>:RELative:HYSTeresis <HystRel>

Defines a hysteresis for the middle reference level. A rise or fall from the middle reference value that does not exceed the hysteresis is rejected as noise.

Suffix:

<rl> 1 to 8, index of the reference level set

Parameters:

<HystRel> Range: 0 to 50
 Increment: 1
 *RST: 10
 Default unit: %

Usage: Asynchronous command

Manual operation: See "[Hysteresis](#)" on page 211

REFLevel<rl>:RELative:LOWer <LowRefLevRel>

Sets the lower relative reference level if [REFLevel<rl>:RELative:MODE](#) is set to USER.

Suffix:

<rl> 1 to 8, index of the reference level set

Parameters:

<LowRefLevRel> Range: -100 to 200
 Increment: 1
 *RST: 10
 Default unit: %

Usage: Asynchronous command

Manual operation: See "[Upper level, Middle level, Lower level](#)" on page 211

REFLevel<rl>:RELative:MIDDLE <MidRefLevRel>

Sets the middle relative reference level if [REFLevel<rl>:RELative:MODE](#) is set to USER.

Suffix:

<rl> 1 to 8, index of the reference level set

Parameters:

<MidRefLevRel> Range: -100 to 200
 Increment: 1
 *RST: 50
 Default unit: %

Usage: Asynchronous command

Manual operation: See "[Upper level, Middle level, Lower level](#)" on page 211

REFLevel<rl>:RELative:MODE <RelativeLevels>

The lower, middle and upper reference levels, defined as percentages of the high signal level.

Suffix:

<rl> 1 to 8, index of the reference level set

Parameters:

<RelativeLevels> FIVE | TEN | TWENTy | USER

FIVE

5/50/95

TEN

10/50/90

TWENTy

20/50/80

USER

Set the reference levels to individual values with

[REFLevel<rl>:RELative:LOWer](#), [REFLevel<rl>:RELative:MIDDLE](#), and [REFLevel<rl>:RELative:UPPer](#).

*RST: TEN

Usage: Asynchronous command

Manual operation: See "Relative levels" on page 211

REFLevel<rl>:RELative:UPPer <UppRefLevRel>

Sets the upper relative reference level if **REFLevel<rl>:RELative:MODE** is set to **USER**.

Suffix:

<rl> 1 to 8, index of the reference level set

Parameters:

<UppRefLevRel> Range: -100 to 200
Increment: 1
*RST: 90
Default unit: %

Usage: Asynchronous command

Manual operation: See "Upper level, Middle level, Lower level" on page 211

18.11.1.2 Reference level results

MEASurement<mg>:REFLevel<rl>:RESult:LOWer?	1052
MEASurement<mg>:REFLevel<rl>:RESult:MIDDLE?	1052
MEASurement<mg>:REFLevel<rl>:RESult:UPPer?	1052
MEASurement<mg>:REFLevel<rl>:RESult:SIGHigh?	1052
MEASurement<mg>:REFLevel<rl>:RESult:SIGLow?	1052

MEASurement<mg>:REFLevel<rl>:RESult:LOWer?

MEASurement<mg>:REFLevel<rl>:RESult:MIDDLE?

MEASurement<mg>:REFLevel<rl>:RESult:UPPer?

Return the lower, middle, and upper reference level, respectively.

Suffix:

<mg> 1 to 24, index of the measurement

<rl> Irrelevant, omit the suffix.

Return values:

<Value> Range: -1E+26 to 1E+26
Increment: 0
*RST: 0

Usage: Query only
Asynchronous command

MEASurement<mg>:REFLevel<rl>:RESult:SIGHigh?

MEASurement<mg>:REFLevel<rl>:RESult:SIGLow?

Return the high and low signal level, respectively.

Suffix:

<mg> 1 to 24, index of the measurement

<rl> Irrelevant, omit the suffix.

Return values:

<SignalValue> Range: -1E+26 to 1E+26
Increment: 0
*RST: 0

Usage:

Query only
Asynchronous command

18.11.2 Gate

GATE<g>:ENABle.....	1053
GATE<g>:GCOupling.....	1053
GATE<g>:CURSor.....	1054
GATE<g>:ZDIagram.....	1054
GATE<g>:MODE.....	1054
GATE<g>:ABSolute:START.....	1055
GATE<g>:ABSolute:STOP.....	1055
GATE<g>:RELative:START.....	1055
GATE<g>:RELative:STOP.....	1055
GATE<g>:SHOW.....	1055

GATE<g>:ENABle <First>

Enables the gate.

Suffix:

<g> 1 to 8, index of the gate

Parameters:

<First> OFF | ON

Usage:

Asynchronous command

Manual operation: See "Add" on page 212

GATE<g>:GCOupling <CouplingMode>

The gate coupling mode selects how the gate area is defined.

Suffix:

<g> 1 to 8, index of the gate

Parameters:

<CouplingMode> MANual | CURSor | ZOOM | SPECtrum

MANual

Manually define the gate with a user-defined start and stop values.

CURSor

Cursor coupling is available if a cursor is defined. The gate area is defined by the cursor lines of an active cursor measurement.

ZOOM

Zoom coupling is available if a zoom is defined. The gate area is defined identically to the zoom area - if you change the zoom, the gate changes as well.

SPECTrum

Spectrum coupling is available if a spectrum is enabled.

*RST: MANual

Usage: Asynchronous command

Manual operation: See ["Coupling mode"](#) on page 212

GATE<g>:CURSor <Cursor>

Available for [GATE<g>:GCOupling](#) = CURSor.

Selects the cursor set to be used for measurement gating. The gate area is defined by the cursor lines.

Suffix:

<g> 1 to 8, index of the gate

Parameters:

<Cursor> CURSOR1 | CURSor1 | CURSOR2 | CURSor2 | CURSOR3 |
CURSor3 | CURSOR4 | CURSor4

Usage: Asynchronous command

Manual operation: See ["Coupling mode"](#) on page 212

GATE<g>:ZDIagram <SignalSource>,[<SignalSource2>]

Available for [GATE<g>:GCOupling](#) = ZOOM.

The gate area is defined identically to the zoom area for the selected zoom diagram.

Suffix:

<g> 1 to 8, index of the gate

Parameters:

<SignalSource>

<SignalSource2>

Usage: Asynchronous command

Manual operation: See ["Coupling mode"](#) on page 212

GATE<g>:MODE <Mode>

Selects if the gate settings are configured using absolute or relative values.

Suffix:

<g> 1 to 8, index of the gate

Parameters:

<Mode> ABS | REL
 *RST: ABS

Usage: Asynchronous command

Manual operation: See "[Mode, Start, Stop](#)" on page 212

GATE<g>:ABSolute:START <Start>

GATE<g>:ABSolute:STOP <Stop>

Define the absolute start and end values for the gate, respectively.

Available, if [GATE<g>:GCoupling](#) = MANUal and [GATE<g>:MODE](#) =ABS.

Suffix:

<g> 1 to 8, index of the gate

Parameters:

<Stop> Range: -1E+26 to 1E+26
 Increment: 0.01
 *RST: 0.01
 Default unit: Depends on the underlying waveform

Usage: Asynchronous command

Manual operation: See "[Mode, Start, Stop](#)" on page 212

GATE<g>:RELative:START <RelativeStart>

GATE<g>:RELative:STOP <RelativeStop>

Define the relative start and end values for the gate, respectively.

Available, if [GATE<g>:GCoupling](#) = MANUal and [GATE<g>:MODE](#) =REL.

Suffix:

<g> 1 to 8, index of the gate

Parameters:

<RelativeStop> Range: 0 to 100
 Increment: 0.1
 *RST: 100
 Default unit: %

Usage: Asynchronous command

Manual operation: See "[Mode, Start, Stop](#)" on page 212

GATE<g>:SHOW <DisplayState>

If enabled, the gate area is indicated in the source diagram.

Suffix:

<g> 1 to 8, index of the gate

Parameters:<DisplayState> OFF | ON
*RST: ON**Usage:**

Asynchronous command

18.11.3 Timing reference

TREference<m>:CDR:SOFTware:ALGorithm.....	1056
TREference<m>:CDR:SOFTware:BWIDth.....	1057
TREference<m>:CDR:SOFTware:CFRequency:CRSYnc.....	1057
TREference<m>:CDR:SOFTware:PLL:DAMPing.....	1057
TREference<m>:CDR:SOFTware:PLL:ORDer.....	1058
TREference<m>:CDR:SOFTware:SREStimate.....	1058
TREference<m>:CDR:SOFTware:PLL:SYNC.....	1058
TREference<m>:CDR:SOFTware:RELBwidth.....	1058
TREference<m>:CDR:SOFTware:SELResults.....	1059
TREference<m>:CLK:FACTor.....	1059
TREference<m>:CLK:FREquency.....	1059
TREference<m>:CLK:OFFSet.....	1060
TREference<m>:CLK:REFLevel.....	1060
TREference<m>:EDGE.....	1060
TREference<m>:ENABle.....	1061
TREference<m>:GATE.....	1061
TREference<m>:REFLevel.....	1062
TREference<m>:RFLSet.....	1062
TREference<m>:SOURce.....	1062
TREference<m>:STATe?.....	1062
TREference<m>:SYMRate.....	1063
TREference<m>:TYPE.....	1063
TRFS:COUNt?.....	1063

TREference<m>:CDR:SOFTware:ALGorithm <Algorithm>

Sets the software algorithm that is used for software clock data recovery.

Suffix:

<m> 1...4, index of the timing reference

Parameters:<Algorithm> CFRequency | PLL | FF | PLLRlock
CFRequency: constant frequency
PLL: phase-locked loop control system
FF: feed forward
PLLRlock: PLL which is locked at the acquisition start.
*RST: PLLRlock**Usage:**

Asynchronous command

Manual operation: See ["Algorithm"](#) on page 217

TREference<m>:CDR:SOFTware:BWIDth <Bandwidth>

Sets the PLL bandwidth. It defines the part of the spectrum that the PLL can follow during synchronization.

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<Bandwidth> Range: 20000 to Device specific: Double-Val(uso::db::wfa::IDeviceConstDataWFA::DOUBLE_ITEM::MaxDeviceBandwidth)
Increment: 10
*RST: 599880
Default unit: Hz

Usage: Asynchronous command

Manual operation: See ["Bandwidth"](#) on page 217

TREference<m>:CDR:SOFTware:CFRequency:CRSYnc <ClockResync>

Enables continuous synchronization of the clock with the data signal.

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<ClockResync> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Clock resync"](#) on page 217

TREference<m>:CDR:SOFTware:PLL:DAMPing <Damping>

Sets the damping factor, which is only relevant for second order PLL.

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<Damping> Range: 0.5 to 2
Increment: 0.01
*RST: 0.7

Usage: Asynchronous command

Manual operation: See ["Damping"](#) on page 218

TREference<m>:CDR:SOFTware:PLL:ORDer <PLLOrder>

Sets the order of the PLL: first or second order. PLL of higher order can compensate for more complex jitter behavior.

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<PLLOrder> FIRSt | SEConD
*RST: SEConD

Usage: Asynchronous command

Manual operation: See ["Order"](#) on page 218

TREference<m>:CDR:SOFTware:SREStimate

Starts a software algorithm to detect the symbol rate for the selected source automatically.

Suffix:

<m> 1...4, index of the timing reference

Usage:

Event
Asynchronous command

Manual operation: See ["Estimate symbol rate"](#) on page 217

TREference<m>:CDR:SOFTware:PLL:SYNC <InitialPhase>

Defines the phase reference for the first clock edge.

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<InitialPhase> SAMPlE | DATaedge
SAMPlE: the first clock edge matches the first sample of the waveform at the left border of the display.
DATaedge: the first clock edge matches the first edge of the data signal.
*RST: DATaedge

Usage: Asynchronous command

Manual operation: See ["Initial phase sync"](#) on page 218

TREference<m>:CDR:SOFTware:RELBwidth <RelBw>

Sets the relative bandwidth, that is the ratio of the nominal bit rate to the PLL bandwidth.

Suffix:
 <m> 1...4, index of the timing reference

Parameters:
 <RelBw> Range: 10 to 6000
 Increment: 1
 *RST: 1667

Usage: Asynchronous command

Manual operation: See ["Rel. bandwidth"](#) on page 218

TREference<m>:CDR:SOFTware:SELResults <Results>

Selects when the CDR algorithm returns clock edges.

Suffix:
 <m> 1...4, index of the timing reference

Parameters:
 <Results> ALL | LOCKed | AISYnc
 ALL: all clock edges are used.
 AISYnc = LOCKed: the clock edges of the synchronization time are discarded; results are gathered after initial synchronization of the CDR.
 *RST: ALL

Usage: Asynchronous command

Manual operation: See ["Selected results"](#) on page 218

TREference<m>:CLK:FACTor <Multiplier>

Sets a value for the clock multiplier if [TREference<m>:TYPE CLOCk](#) is set. The multiplier is the ratio of an internal clock rate to the externally supplied clock. It defines the number of samples per clock interval.

Suffix:
 <m> 1...4, index of the timing reference

Parameters:
 <Multiplier> Range: 1 to 100
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Clock multiplier"](#) on page 215

TREference<m>:CLK:FREQuency <Frequency>

Sets the frequency of the clock signal if [TREference<m>:TYPE CLOCk](#) is set.

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<Frequency> Range: 1000 to Device specific: Double-Val(uso::db::wfa::IDeviceConstDataWFA::DOUBLE_ITEM::MaxDeviceBandwidth)
 Increment: 10
 *RST: 500000000
 Default unit: Hz

Usage:

Asynchronous command

Manual operation: See ["Clock frequency"](#) on page 214

TREference<m>:CLK:OFFSet <Offset>

Sets the offset between the clock edge and the data edge if [TREference<m>:TYPE CLOCK](#) is set.

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<Offset> Range: -1000 to 1000
 Increment: 0.01
 *RST: 0
 Default unit: UI

Usage:

Asynchronous command

Manual operation: See ["Clock offset"](#) on page 215

TREference<m>:CLK:REFLevel <ReferenceLevel>

Selects the reference level that is used for the timing reference if the indicated timing reference uses an explicit click signal.

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<ReferenceLevel> UPPer | MIDDle | LOWer
 *RST: MIDDle

Usage:

Asynchronous command

Manual operation: See ["Reference level"](#) on page 214

TREference<m>:EDGE <Edge>

Sets the clock edges that are used for measurements if [TREference<m>:TYPE CLOCK](#) is set for the indicated measurement.

Sets the data edges for clock data recovery if **TREference<m>:TYPE** **SCDR** is set for the indicated measurement.

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<Edge> POSitive | NEGative | EITHer

POSitive

The positive clock slope can be used, for example, for single data rate (SDR) signals with bit start at the positive clock edge.

NEGative

The negative clock slope can be used, for example, for SDR signals with bit start at the negative clock edge.

EITHer

Can be used for double data rate (DDR) signals and clock edges. For data edges, it is the most common setting.

*RST: EITHer

Usage: Asynchronous command

Manual operation: See "[Clock edges](#)" on page 215

TREference<m>:ENABLE <TimeRef>

Adds the indicated timing reference (ON) or removes it (OFF).

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<TimeRef> OFF | ON

Usage: Asynchronous command

TREference<m>:GATE <Gate>

Sets the gate for the timing reference. Enable and configure a gate before you assign it (**GATE<g>:ENABLE** =ON).

The query returns 0, if no gate is assigned.

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<Gate> Number of the gate to be used

Usage: Asynchronous command

TREference<m>:REFLevel <ReferenceLevel>

Selects the reference level that is used for the timing reference if the indicated timing reference uses an explicit click signal.

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<ReferenceLevel> UPPer | MIDDle | LOWer
*RST: MIDDle

Usage: Asynchronous command

TREference<m>:RFLSet <RefLevelSet>

Selects the set of reference levels that is used for the timing reference measurements.

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<RefLevelSet> 1 to 8, index of the reference level set
Number of the reference level set. Define the reference level set before you use it.

Usage: Asynchronous command

Manual operation: See ["Reference levels"](#) on page 213

TREference<m>:SOURce <Source>

Selects the clock source if [TREference<m>:TYPE CLOCk](#) is set.

Sets the data source for clock data recovery if [TREference<m>:TYPE SCDR](#) is set for the indicated measurement.

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<Source> C1 | C2 | ... | C8 | D0 | D1 | D2 | ... | D14 | D15 | M1 | M2 | ... | M8
| O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 11)

Usage: Asynchronous command

Manual operation: See ["Source"](#) on page 214

TREference<m>:STATe?

Returns if the specified timing reference is used by an application, e.g. by jitter measurements.

Suffix:

<m> 1...4, index of the timing reference

Return values:

<State> OFF | ON
 *RST: OFF

Usage:

Query only
 Asynchronous command

TREference<m>:SYMRate <SymbolRate>

Sets the symbol rate of the data signal for the indicated timing reference.

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<SymbolRate> Range: 100000 to 5000000000
 Increment: 10
 *RST: 1000000000
 Default unit: Bd

Usage:

Asynchronous command

Manual operation: See ["Symbol rate"](#) on page 215

TREference<m>:TYPE <Type>

Defines the origin of the clock signal - either an existing clock signal or waveform, or a clock generated by clock data recovery (CDR).

Suffix:

<m> 1...4, index of the timing reference

Parameters:

<Type> CLOCK | SCDR
 CLOCK: explicit clock signal
 SCDR: software CDR
 *RST: CLOCK

Usage:

Asynchronous command

Manual operation: See ["Type"](#) on page 213

TRFS:COUNT?

Returns the number of defined timing references.

Return values:

<Count> Range: 1 to 4

Usage:

Query only
 Asynchronous command

18.12 Waveform analysis

Some of the commands in the following section are asynchronous. An overlapping or asynchronous command does not automatically finish executing before the next command starts executing. If overlapping commands must be executed in a defined order, e.g. to avoid wrong measurement results, they must be serviced sequentially.

To prevent an overlapping execution of commands, one of the commands `*OPC`, `*OPC?` or `*WAI` can be used after the command or a command set.

For more information, see:

- www.rohde-schwarz.com/rc-via-scp, section "Command sequence and synchronization"
- [Zoom](#)..... 1064
- [Mathematics](#)..... 1073
- [History](#)..... 1078
- [Reference waveforms](#)..... 1081
- [Waveform histograms](#)..... 1091

18.12.1 Zoom

LAYout<ly>:ZOOM<zo>[:ENABle]	1065
LAYout<ly>:ZOOM<zo>:COUNT?	1065
LAYout<ly>:ZOOM<zo>:DIAG?	1065
LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:POSition	1065
LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:SPAN	1066
LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:START	1066
LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:STOP	1066
LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:WIDTh	1067
LAYout<ly>:ZOOM<zo>:HORizontal:MODE	1067
LAYout<ly>:ZOOM<zo>:HORizontal:RELative:POSition	1067
LAYout<ly>:ZOOM<zo>:HORizontal:RELative:SPAN	1068
LAYout<ly>:ZOOM<zo>:HORizontal:RELative:START	1068
LAYout<ly>:ZOOM<zo>:HORizontal:RELative:STOP	1069
LAYout<ly>:ZOOM<zo>:HORizontal:RELative:WIDTh	1069
LAYout<ly>:ZOOM<zo>:SOURce	1069
LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:POSition	1070
LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:RANGe	1070
LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:SPAN	1070
LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:START	1070
LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:STOP	1071
LAYout<ly>:ZOOM<zo>:VERTical:MODE	1071
LAYout<ly>:ZOOM<zo>:VERTical:RELative:POSition	1071
LAYout<ly>:ZOOM<zo>:VERTical:RELative:START	1072
LAYout<ly>:ZOOM<zo>:VERTical:RELative:STOP	1072
LAYout<ly>:ZOOM<zo>:VERTical:RELative:WIDTh	1072
LAYout<ly>:ZOOM<zo>:VERTical:RELative:SPAN	1072
LAYout<ly>:ZOOM<zo>:SSCReen	1073

LAYout<ly>:ZOOM<zo>[:ENABLE] <State>

Enables the zoom.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

<State> OFF | ON

Example: See [Section 18.5.1, "SmartGrid layout with zoom"](#), on page 911.

Usage: Asynchronous command

Manual operation: See ["State"](#) on page 220

LAYout<ly>:ZOOM<zo>:COUNT?

Returns the max number of available zooms.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Return values:

<Count>

Usage: Query only
Asynchronous command

LAYout<ly>:ZOOM<zo>:DIAG?

Returns the index of the diagram that shows the zoomed waveform.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Return values:

<ZoomDiagramKey> String with the index of the zoom diagram, e.g. "9".

Usage: Query only
Asynchronous command

LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:POSition <Center>

Defines the x-value of the centerpoint of the zoom area in absolute values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

<Center> Range: -1E+26 to 1E+26
 Increment: 0.01
 *RST: 0
 Default unit: Depends on the underlying waveform

Usage: Asynchronous command

Manual operation: See ["Position range"](#) on page 221

**LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:SPAN **

Defines the width of the zoom area in absolute values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout
 <zo> 1 to 8, index of the zoom

Parameters:

 Range: 0 to 1E+26
 Increment: 0.01
 *RST: 0.02
 Default unit: Depends on the underlying waveform

Usage: Asynchronous command

Manual operation: See ["Position range"](#) on page 221

LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:STARt <Start>

Defines the lower limit of the zoom area on the x-axis in absolute values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout
 <zo> 1 to 8, index of the zoom

Parameters:

<Start> Range: -1E+26 to 1E+26
 Increment: 0.01
 *RST: -0.01
 Default unit: Depends on the underlying waveform

Usage: Asynchronous command

Manual operation: See ["Start Stop"](#) on page 221

LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:STOP <Stop>

Defines the upper limit of the zoom area on the x-axis in absolute values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

<Stop> Range: -1E+26 to 1E+26
Increment: 0.01
*RST: 0.01
Default unit: Depends on the underlying waveform

Usage: Asynchronous command

Manual operation: See ["Start Stop"](#) on page 221

**LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:WIDTh **

Defines the width of the zoom area in absolute values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

 Range: 0 to 1E+26
Increment: 0.01
*RST: 0.02
Default unit: Depends on the underlying waveform

Usage: Asynchronous command

LAYout<ly>:ZOOM<zo>:HORizontal:MODE <Mode>

Defines if absolute or relative values are used to specify the x-axis values. Since the zoom area refers to the active signal, relative values ensure that the zoom area remains the same.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

<Mode> ABS | REL
*RST: ABS

Example: See [Section 18.5.1, "SmartGrid layout with zoom"](#), on page 911.

Usage: Asynchronous command

Manual operation: See ["Mode"](#) on page 222

LAYout<ly>:ZOOM<zo>:HORizontal:RELative:POSition <RelativeCenter>

Defines the x-value of the centerpoint of the zoom area in relative values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

<RelativeCenter> Relative position of the centerpoint (x-value)

Range: 0 to 100

Increment: 0.1

*RST: 50

Default unit: %

Usage: Asynchronous command

Manual operation: See ["Position range"](#) on page 221

LAYout<ly>:ZOOM<zo>:HORizontal:RELative:SPAN <RelativeSpan>

Defines the width of the zoom area in relative values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

<RelativeSpan> Range: 1E-15 to 100

Increment: 0.1

*RST: 1

Default unit: %

Usage: Asynchronous command

Manual operation: See ["Position range"](#) on page 221

LAYout<ly>:ZOOM<zo>:HORizontal:RELative:START <RelativeStart>

Defines the lower limit of the zoom area on the x-axis in relative values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

<RelativeStart> Range: 0 to 100

Increment: 0.1

*RST: 0

Default unit: %

Example: See [Section 18.5.1, "SmartGrid layout with zoom"](#), on page 911.

Usage: Asynchronous command

Manual operation: See ["Start Stop"](#) on page 221

LAYout<ly>:ZOOM<zo>:HORizontal:RELative:STOP <RelativeStop>

Defines the upper limit of the zoom area on the x-axis in relative values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

<RelativeStop> Range: 0 to 100
 Increment: 0.1
 *RST: 100
 Default unit: %

Example: See [Section 18.5.1, "SmartGrid layout with zoom"](#), on page 911.

Usage: Asynchronous command

Manual operation: See ["Start Stop"](#) on page 221

LAYout<ly>:ZOOM<zo>:HORizontal:RELative:WIDTH <RelativeSpan>

Defines the width of the zoom area in relative values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

<RelativeSpan> Range: 1E-15 to 100
 Increment: 0.1
 *RST: 1
 Default unit: %

Usage: Asynchronous command

LAYout<ly>:ZOOM<zo>:SOURce <Diagrams>

Indicates which of the waveform diagrams is selected for zooming. The number is displayed on the screen in the middle of each diagram.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

<Diagrams> Index of the diagram that is zoomed.

Example: See [Section 18.5.1, "SmartGrid layout with zoom"](#), on page 911.

Usage: Asynchronous command

Manual operation: See ["Diagram"](#) on page 220

LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:POSition <Center>

Defines the y-value of the centerpoint of the zoom area in absolute values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

<Center> Range: -1E+26 to 1E+26
 Increment: 0.01
 *RST: 0.01

Usage: Asynchronous command

Manual operation: See ["Position range"](#) on page 221

LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:RANGe **LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:SPAN **

Defines the height of the zoom area in absolute values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

 Range: 0 to 1E+26
 Increment: 0.01
 *RST: 0.01

Usage: Asynchronous command

Manual operation: See ["Position range"](#) on page 221

LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:STARt <Start>

Defines the lower limit of the zoom area on the y-axis in absolute values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

<Start> Range: -1E+26 to 1E+26
 Increment: 0.01
 *RST: 0.01

Usage: Asynchronous command

Manual operation: See ["Start Stop"](#) on page 221

LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:STOP <Stop>

Defines the upper limit of the zoom area on the y-axis in absolute values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

<Stop> Range: -1E+26 to 1E+26
 Increment: 0.01
 *RST: 0.01

Usage: Asynchronous command

Manual operation: See ["Start Stop"](#) on page 221

LAYout<ly>:ZOOM<zo>:VERTical:MODE <Mode>

Defines if absolute or relative values are used to specify the y-axis values. Since the zoom area refers to the active signal, relative values ensure that the zoom area remains the same.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

<Mode> ABS | REL
 *RST: REL

Usage: Asynchronous command

Manual operation: See ["Mode"](#) on page 222

LAYout<ly>:ZOOM<zo>:VERTical:RELative:POSition <RelativeCenter>

Defines the y-value of the centerpoint of the zoom area in relative values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout

<zo> 1 to 8, index of the zoom

Parameters:

<RelativeCenter> Range: 0 to 100
 Increment: 0.1
 *RST: 50
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Position range"](#) on page 221

LAYout<ly>:ZOOM<zo>:VERTical:RELative:STARt <RelativeStart>

Defines the lower limit of the zoom area on the y-axis in relative values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout
 <zo> 1 to 8, index of the zoom

Parameters:

<RelativeStart> Range: 0 to 100
 Increment: 0.1
 *RST: 0
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Start Stop"](#) on page 221

LAYout<ly>:ZOOM<zo>:VERTical:RELative:STOP <RelativeStop>

Defines the upper limit of the zoom area on the x-axis, in relative values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout
 <zo> 1 to 8, index of the zoom

Parameters:

<RelativeStop> Range: 0 to 100
 Increment: 0.1
 *RST: 100
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Start Stop"](#) on page 221

LAYout<ly>:ZOOM<zo>:VERTical:RELative:WIDTH <RelativeSpan>**LAYout<ly>:ZOOM<zo>:VERTical:RELative:SPAN <RelativeSpan>**

Defines the height of the zoom area in relative values.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout
 <zo> 1 to 8, index of the zoom

Parameters:

<RelativeSpan> Range: 1E-15 to 100
 Increment: 0.1
 *RST: 100
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Position range"](#) on page 221

LAYout<ly>:ZOOM<zo>:SSCReen

Sets the zoom area to the whole screen.

Suffix:

<ly> 1 to 8, index of the SmartGrid layout
<zo> 1 to 8, index of the zoom

Usage:

Setting only
Asynchronous command

Manual operation: See "Set to screen" on page 221

18.12.2 Mathematics

For fast export of several waveforms at once, use `EXPort:WAVEform:DATA[:VALues]?` on page 1109.

<code>CALCulate:MATH<m>:STATe</code>	1073
<code>CALCulate:MATH<m>[:EXPRession][:DEFine]</code>	1073
<code>CALCulate:MATH<m>:LABel</code>	1075
<code>CALCulate:MATH<m>:VERTical:SCALe[:VALue]</code>	1075
<code>CALCulate:MATH<m>:UNIT</code>	1075
<code>CALCulate:MATH<m>:VERTical:OFFSet</code>	1075
<code>CALCulate:MATH<m>:ENVSelection</code>	1076
<code>CALCulate:MATH<m>:VERTical:SCALe:MODE</code>	1076
<code>CALCulate:MATH<m>:DATA:HEADer?</code>	1076
<code>CALCulate:MATH<m>:DATA:STYPe?</code>	1077
<code>CALCulate:MATH<m>:DATA[:VALues]?</code>	1077

CALCulate:MATH<m>:STATe <First>

Activates the selected Math channel and displays the defined math waveforms.

Suffix:

<m> 1 to 8, index of the math waveform

Parameters:

<First> OFF | ON

Usage:

Asynchronous command

Manual operation: See "Display" on page 225

CALCulate:MATH<m>[:EXPRession][:DEFine] <Expression>

Defines the math expression to be calculated for the specified math channel.

Operation	<Expression>	Comment
Addition	"C1+C2"	
Subtraction	"C1-C2"	

Operation	<Expression>	Comment
Multiplication	"C1*C2"	
Division	"C1/C2"	0/0 = 0 +1 / 0 = Clip+ -1 / 0 = Clip-
Inverting	"-C1"	
Absolute value	"Abs(C1)"	
Derivation	"Derivation(C1,NoiseReject)"	NoiseReject can get any value between 1 and 5000 points Default = 50
Integral	"Integral(C1)"	
Logarithm (based on 10)	"Log(C1)"	Uses the absolute value of the source in calculation. Log(0) = Clip -
Natural logarithm (based on e)	"Ln(C1)"	Uses the absolute value of the source in calculation. Log(0) = Clip -
Binary logarithm (based on 2)	"Ld(C1)"	Uses the absolute value of the source in calculation. Log(0) = Clip -
Square	"Pow(C1)"	
Square root	"Sqrt(C1)"	Uses the absolute value of the source in calculation.
Rescale	"Rescale(C1,a,b)"	a = scale, default = 1 b = offset, default = 0
FIR	"FIR(Type,C1,Cut-Off,Characteristics)" Examples: "FIR(highpass,C1,10000000,Gaussian)" "FIR(lowpass,C1,10000000,rectangle)"	Type = lowpass, highpass Cut-Off = limit frequency Characteristics = Gaussian, rectangle Cut-Off can get any value between 4 GHz and 1 kHz

Suffix:

<m>

1 to 8, index of the math waveform

Parameters:

<Expression>

String with regular expression for calculation

Example:

CALC:MATH 'C1*C2'

Defines the multiplication of waveforms channel 1 and channel 2.

Usage:

Asynchronous command

Manual operation:See "[Operator](#)" on page 226

CALCulate:MATH<m>:LABel <Label>

Defines a label for the selected math waveform.

Suffix:

<m> 1 to 8, index of the math waveform

Parameters:

<Label> String with the label

Example:

CALCulate:MATH3:LABel 'M3AddC1C2'

Usage:

Asynchronous command

Manual operation: See "[Label](#)" on page 225

CALCulate:MATH<m>:VERTical:SCALE[:VALue] <VerticalScale>

Sets the scale of the y-axis in the math function diagram. The value is defined as "<unit> per division", e.g. *50 mV/div*. In this case, the horizontal grid lines are displayed in intervals of 50 mV.

Suffix:

<m> 1 to 8, index of the math waveform

Parameters:

<VerticalScale> Range: 1E-12 to 100E+12
Increment: 1E-05
*RST: 0.5
Default unit: V

Usage:

Asynchronous command

Manual operation: See "[\[Scale\]](#)" on page 57

CALCulate:MATH<m>:UNIT <UserUnit>

Sets a user-defined unit for the math operation.

Suffix:

<m> 1 to 8, index of the math waveform

Parameters:

<UserUnit> String with the base unit

Example:

CALCulate:MATH:UNIT 'A'

Usage:

Asynchronous command

Manual operation: See "[Unit](#)" on page 235

CALCulate:MATH<m>:VERTical:OFFSet <VerticalOffset>

Sets a voltage offset to adjust the vertical position of the math function on the screen. Negative values move the waveform up, positive values move it down.

Suffix:

<m> 1 to 8, index of the math waveform

Parameters:

<VerticalOffset> Range: -100E12 to 100E12
 Increment: 0.01
 *RST: 0
 Default unit: div

Usage: Asynchronous command

Manual operation: See ["Vertical offset"](#) on page 235

CALCulate:MATH<m>:ENVSelection <EnvelopeCurve>

Selects the upper or lower part of the input waveform for mathematic calculation, or a combination of both.

Suffix:

<m> 1 to 8, index of the math waveform

Parameters:

<EnvelopeCurve> MIN | MAX | BOTH
 *RST: BOTH

Usage: Asynchronous command

Manual operation: See ["Envelope wfm selection"](#) on page 227

CALCulate:MATH<m>:VERTical:SCALE:MODE <VertScIMd>

Sets how the vertical scale is adapted to the current measurement results. By default, scaling is done automatically to provide an optimal display. However, if necessary, you can define scaling values manually to suit your requirements.

Suffix:

<m> 1 to 8, index of the math waveform

Parameters:

<VertScIMd> MANual | AUTO
 *RST: AUTO

Usage: Asynchronous command

Manual operation: See ["Scale mode"](#) on page 234

CALCulate:MATH<m>:DATA:HEADer?

Returns the header of math waveform data, the attributes of the waveform.

Suffix:

<m> 1 to 8, index of the math waveform

Return values:

<XStart>	1. header value: time of the first sample in s
<XStop>	2. header value: time of the last sample in s
<RecordLength>	3. header value: record length of the waveform in samples
<ValuesPerSample>	4. header value: number of values per sample. For most waveforms, the result is 1. For peak detect and envelope waveforms, it is 2. If the number is 2, the number of returned values is twice the number of samples (record length).

Example:

```
CALC:MATH1:DATA:HEAD?
-1E-07,9.9800000000000001E-08,1000,1
```

Start time of the data is $-1\text{E-}07 = 100\text{ ns}$, and end time of the data is $9.9800000000000001\text{E-}08 = 99.8\text{ ns}$. The data stream has 1000 values with one value per sample.

Usage:

Query only
Asynchronous command

CALCulate:MATH<m>:DATA:SType?

Returns the signal type of the math waveform.

Suffix:

<m> 1 to 8, index of the math waveform

Return values:

<SignalType> MATH

Usage:

Query only
Asynchronous command

CALCulate:MATH<m>:DATA[:VALues]? [<Offset>[,<Length>]]

Returns the data of the math waveform points for transmission from the instrument to the controlling computer. The data can be used in MATLAB, for example.

Without parameters, the complete waveform is retrieved. Using the offset and length parameters, data can be retrieved in smaller portions, which makes the command faster. If you send only one parameter, it is interpreted as offset, and the data is retrieved from offset to the end of the waveform.

To set the export format, use `FORMat [:DATA]`.

Suffix:

<m> 1 to 8, index of the math waveform

Query parameters:

<Offset> Number of offset waveform points to be skipped.

<Length> Number of waveform points to be retrieved.

Return values:

<Data> List of values according to the format and content settings.

Example: `:CALC:MATH1:DATA:VAL? 100,10`
Returns 10 points from the start index 100.

Usage: Query only
Asynchronous command

18.12.3 History

<code>ACQuire:HISTory:CURRent</code>	1078
<code>ACQuire:HISTory:ISODate?</code>	1078
<code>ACQuire:HISTory:PLAY</code>	1079
<code>ACQuire:HISTory:REPLay</code>	1079
<code>ACQuire:HISTory:START</code>	1079
<code>ACQuire:HISTory:STOP</code>	1079
<code>ACQuire:HISTory:TPACq</code>	1080
<code>ACQuire:HISTory:TSABsolute?</code>	1080
<code>ACQuire:HISTory:TSDate?</code>	1080
<code>ACQuire:HISTory:TSRelative?</code>	1080
<code>ACQuire:HISTory:TSRReference?</code>	1081
<code>ACQuire:HISTory[:STATe]</code>	1081

ACQuire:HISTory:CURRent <CurrentAcqIndex>

Accesses a particular acquisition in the memory to display it, or to save it. The newest acquisition always has the index "0". Older acquisitions have a negative index.

Parameters:

<CurrentAcqIndex> Range: -2147483648 to 0
 Increment: 1
 *RST: 0

Usage: Asynchronous command

Manual operation: See "[Current acq](#)" on page 238

ACQuire:HISTory:ISODate?

Returns the absolute date and time of the acquisition that is selected in history view in ISO 8601 format. The same format is used in the header of exported waveform data files.

See also: `ACQuire:HISTory:CURRent`).

Return values:

<DateTimeISO8601> String with absolute date and time in this order: year, month, day, hour, minutes, seconds, and milliseconds.

Example: `ACQ:HIST:ISOD?`
`<-- "2024-10-02T10:11:09.603208067"`

Usage: Query only
Asynchronous command

ACQUIRE:HISTORY:PLAY

Starts and stops the replay of the history waveforms.

Usage: Event
Asynchronous command

Manual operation: See ["Player"](#) on page 238

ACQUIRE:HISTORY:REPLAY <AutoRepeat>

If enabled, the replay of the history waveform sequence repeats automatically.

Otherwise, the replay stops at the stop index set with [ACQUIRE:HISTORY:STOP](#) on page 1079.

Parameters:
<AutoRepeat> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Auto repeat"](#) on page 240

ACQUIRE:HISTORY:START <StartAcqIndex>

Sets the index of the first (oldest) acquisition to be displayed or exported. The index is always negative.

Parameters:
<StartAcqIndex> Range: -2147483648 to 0
Increment: 1
*RST: 0

Usage: Asynchronous command

Manual operation: See ["Start acq"](#) on page 238

ACQUIRE:HISTORY:STOP <StopAcqIndex>

Sets the index of the last (newest) acquisition to be displayed or exported. The newest acquisition of the complete acquisition series always has the index "0".

Parameters:
<StopAcqIndex> Range: -2147483648 to 0
Increment: 1
*RST: 0

Usage: Asynchronous command

Manual operation: See ["Stop acq"](#) on page 238

ACQuire:HISTory:TPACq <TimePerAcq>

Sets the display time for one acquisition. The shorter the time, the faster the replay is.

Parameters:

<TimePerAcq>	Range:	4E-05 to 10
	Increment:	1
	*RST:	0.05
	Default unit:	s

Usage: Asynchronous command

Manual operation: See ["Display time"](#) on page 238

ACQuire:HISTory:TSABsolute?

Returns the absolute daytime of the selected acquisition ([ACQuire:HISTory:CURRent](#)).

For automatic parsing of the time, use [ACQuire:HISTory:ISODate?](#).

Return values:

<TimeAbsString> String containing the time and unit

Example:

```
ACQ:HIST:TSAB?
<-- "10:11 9,603.208.067 s"
```

Usage: Query only
Asynchronous command

Manual operation: See ["Time stamp"](#) on page 239

ACQuire:HISTory:TSDate?

Returns the date of the selected acquisition ([ACQuire:HISTory:CURRent](#)).

For automatic parsing of the time, use [ACQuire:HISTory:ISODate?](#).

Return values:

<DateAbsString> String parameter with acquisition date

Example:

```
ACQ:HIST:TSD?
<-- "2024:10:02" //02 Oct 2024
```

Usage: Query only
Asynchronous command

Manual operation: See ["Time stamp"](#) on page 239

ACQuire:HISTory:TSRelative?

Returns the relative time of the current acquisition - the time difference to the newest acquisition (index = 0).

See also: [ACQuire:HISTory:CURRent](#).

Return values:

<TimeRelativ> Range: -1E+26 to 1E+26
 Increment: 1
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

Manual operation: See ["Time stamp"](#) on page 239

ACQuire:HISTory:TSRReference?

Returns the relative time of the currently selected acquisition and the internal reference time (horizontal alignment) in history view in relation to the acquisition with index 0.

Return values:

<TimeRelIntRef> Range: -1E+26 to 1E+26
 Increment: 1
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

Manual operation: See ["Time stamp"](#) on page 239

ACQuire:HISTory[:STATe] <State>

Enables the history mode and allows you to save history waveforms to file.

Parameters:

<State> OFF | ON
 *RST: OFF

Usage:

Asynchronous command

Manual operation: See ["Show history"](#) on page 237

18.12.4 Reference waveforms

- [Setup](#).....1081
- [Scaling](#).....1085
- [Reference waveform data export](#).....1089

18.12.4.1 Setup

[REFCurve<rc>:ABORt](#).....1082
[REFCurve<rc>:CLEar](#).....1082
[REFCurve<rc>:NAME](#).....1082
[REFCurve<rc>:OFFSet](#).....1083

REFCurve<rc>:OPEN.....	1083
REFCurve<rc>:REStore.....	1083
REFCurve<rc>:SAVE.....	1083
REFCurve<rc>:SOURce.....	1084
REFCurve<rc>:STATe.....	1084
REFCurve<rc>:UPDate.....	1085

REFCurve<rc>:ABORt

Aborts a running reference waveform export, which was started with [REFCurve<rc>:SAVE](#), or a running reference waveform update, which was started with [REFCurve<rc>:UPDate](#).

Suffix:

<rc> 1 to 8, index of the reference waveform

Usage:

Event
Asynchronous command

Manual operation: See ["Save as"](#) on page 245

REFCurve<rc>:CLEar

Deletes the selected reference waveform. It disappears from the display, and its memory is deleted.

Suffix:

<rc> 1 to 8, index of the reference waveform

Usage:

Setting only
Asynchronous command

Manual operation: See ["Clear"](#) on page 245

REFCurve<rc>:NAME <Name>

Defines the path, filename and extension of the reference waveform file to be loaded, saved or deleted.

For supported file types, see ["Supported file formats"](#) on page 241.

Suffix:

<rc> 1 to 8, index of the reference waveform

Parameters:

<Name> String with path, filename and extension

Usage:

Asynchronous command

Manual operation: See ["Save as"](#) on page 245

REFCurve<rc>:OFFSet <VerticalOffset>

The vertical offset moves the reference waveform vertically. Enter a value with the unit of the waveform.

Suffix:

<rc> 1 to 8, index of the reference waveform

Parameters:

<VerticalOffset> Range: -1E+26 to 1E+26
Increment: 1E-06
*RST: 0
Default unit: V

Usage: Asynchronous command

Manual operation: See "[Vertical offset](#)" on page 248

REFCurve<rc>:OPEN

Loads the reference waveform file selected by [REFCurve<rc>:NAME](#).

Suffix:

<rc> 1 to 8, index of the reference waveform

Usage: Event
Asynchronous command

Manual operation: See "[Open](#)" on page 245

REFCurve<rc>:REStore

Applies the original settings of the reference waveform to the horizontal and vertical settings of the selected waveform.

Suffix:

<rc> 1 to 8, index of the reference waveform

Usage: Setting only
Asynchronous command

Manual operation: See "[Restore settings](#)" on page 247

REFCurve<rc>:SAVE

Saves the reference waveform to the file selected by [REFCurve<rc>:NAME](#).

Suffix:

<rc> 1 to 8, index of the reference waveform

Usage: Event
Asynchronous command

Manual operation: See "[Save as](#)" on page 245

REFCurve<rc>:SOURce <Source>

Selects the source waveform from the active waveforms, e.g. input channels, math waveforms, or spectrum.

Suffix:

<rc> 1 to 8, index of the reference waveform

Parameters:

<Source> C1 | C2 | ... | C8 | M1 | M2 | ... | M8 | R1 | R2 | ... | R8 | SPEC-MAXH1 | SPECMINH1 | SPECNORM1 | SPECAVER1 | SPEC-MAXH2 | SPECMINH2 | SPECNORM2 | SPECAVER2 | SPEC-MAXH3 | SPECMINH3 | SPECNORM3 | SPECAVER3 | SPEC-MAXH4 | SPECMINH4 | SPECNORM4 | SPECAVER4 | TRK1 | TRK2 | TRK3 | ... | TRK24 | PA1QPOWER | PA2QPOWER | ... | PA6QPOWER | PA1HPOWER1 | PA2HPOWER1 | ... | PA6HPOWER1 | PA1SPOWER | PA2SPOWER | ... | PA6SPOWER | PA1SOA | PA2SOA | ... | PA6SOA | PA1IPOWER | PA2IPOWER | ... | PA6IPOWER | PA1OPOWER1 | PA2OPOWER1 | ... | PA6OPOWER1 | PA1OPOWER2 | PA2OPOWER2 | ... | PA6OPOWER2 | PA1OPOWER3 | PA2OPOWER3 | ... | PA6OPOWER3 | PTHREE1HPOWER1 | PTHREE2HPOWER1 | ... | PTHREE6HPOWER1 | PTHREE1HPOWER2 | PTHREE2HPOWER2 | ... | PTHREE6HPOWER2 | PTHREE1HPOWER3 | PTHREE2HPOWER3 | ... | PTHREE6HPOWER3 | PTHREE1HTPOWER | PTHREE2HTPOWER | ... | PTHREE6HTPOWER | PTHREE1QPOWER1 | PTHREE2QPOWER1 | ... | PTHREE6QPOWER1 | PTHREE1QPOWER2 | PTHREE2QPOWER2 | ... | PTHREE6QPOWER2 | PTHREE1QPOWER3 | PTHREE2QPOWER3 | ... | PTHREE6QPOWER3 | PTHREE1QTPOWER | PTHREE2QTPOWER | ... | PTHREE6QTPOWER | PA1TOPOWER | PA2TOPOWER | ... | PA6TOPOWER | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 11)

Usage: Asynchronous command

Manual operation: See "[Source](#)" on page 244

REFCurve<rc>:STATe <State>

Enables the display of the reference waveform in the diagram. Before you can display it, create the reference waveform.

Suffix:

<rc> 1 to 8, index of the reference waveform

Parameters:

<State> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Show"](#) on page 244

REFCurve<rc>:UPDATE

Copies the selected source waveform with all its settings to the memory of the reference waveform. If there is a previously defined reference waveform in this memory, it is updated by the current source waveform. If the acquisition is running, the reference waveform is a snapshot.

Suffix:

<rc> 1 to 8, index of the reference waveform

Usage:

Event
Asynchronous command

Manual operation: See ["Create/Update"](#) on page 245

18.12.4.2 Scaling

REFCurve<rc>:AXIS[:XMODE]	1085
REFCurve<rc>:SCALE	1085
REFCurve<rc>:POSITION	1086
REFCurve<rc>:HMODE	1086
REFCurve<rc>:RESCale:HORizontal:FACTor	1087
REFCurve<rc>:RESCale:HORizontal:OFFSet	1087
REFCurve<rc>:RESCale:HORizontal:STATe	1087
REFCurve<rc>:RESCale:VERTical:FACTor	1088
REFCurve<rc>:RESCale:VERTical:OFFSet	1088
REFCurve<rc>:RESCale:VERTical:STATe	1088
REFCurve<rc>:TOORiginal	1089
REFCurve<rc>:VMODE	1089

REFCurve<rc>:AXIS[:XMODE] <XAxisMode>

Defines the scaling method for the frequency (x-axis) of the reference curve.

Suffix:

<rc> 1 to 8, index of the reference waveform

Parameters:

<XAxisMode> LIN | LOG
 LIN: Linear scaling
 LOG: Logarithmic scaling
 *RST: LIN

Usage:

Asynchronous command

REFCurve<rc>:SCALE <VerticalScale>

Sets the vertical scale, which defines the displayed amplitude of the selected waveform.

Suffix:

<rc> 1 to 8, index of the reference waveform

Parameters:

<VerticalScale> Range: 1E-15 to 1E+26
 Increment: 1E-05
 *RST: 0.5
 Default unit: Unit of the source waveform

Usage: Asynchronous command

Manual operation: See "[Scale]" on page 57

REFCurve<rc>:POSition <VertPosi>

Available, if **REFCurve<rc>:VMODE** is set to **INDependent**.

Moves the reference waveform up or down in the diagram.

Suffix:

<rc> 1 to 8, index of the reference waveform

Parameters:

<VertPosi> Range: -1E+26 to 1E+26
 Increment: 0.02
 *RST: 0
 Default unit: div

Usage: Asynchronous command

Manual operation: See "Vertical position" on page 248

REFCurve<rc>:HMODE <HorizontalMode>

Selects the coupling of horizontal settings.

Suffix:

<rc> 1 to 8, index of the reference waveform

Parameters:

<HorizontalMode> ORIGINAL | COUPled

ORIGINAL

Horizontal scaling and reference point of the source waveform are used.

COUPled

The current horizontal settings of the diagram are used.

*RST: ORIGINAL

Usage: Asynchronous command

Manual operation: See "Mode" on page 249

REFCurve<rc>:RESCale:HORizontal:FACTOR <ScaleFactor>

Sets the horizontal scale factor. A factor greater than 1 stretches the waveform horizontally, a factor lower than 1 compresses the curve.

Suffix:

<rc> 1 to 8, index of the reference waveform

Parameters:

<ScaleFactor> Range: 1E-14 to 1000000000000000
Increment: 0.1
*RST: 1

Usage: Asynchronous command

Manual operation: See ["Scale factor"](#) on page 249

REFCurve<rc>:RESCale:HORizontal:OFFSet <Offset>

Moves the waveform horizontally. Enter a value with a time unit suitable for the time scale of the diagram.

Positive values shift the waveform to the right, negative values shift it to the left.

Suffix:

<rc> 1 to 8, index of the reference waveform

Parameters:

<Offset> Range: -5000000 to 5000000
Increment: 0.01
*RST: 0
Default unit: s

Usage: Asynchronous command

Manual operation: See ["Horizontal offset"](#) on page 250

REFCurve<rc>:RESCale:HORizontal:STATe <State>

If enabled, the horizontal offset and factor are applied to the reference waveform.

Stretching and offset change the display of the waveform independent of the horizontal settings of the source waveform and of the horizontal diagram settings.

Suffix:

<rc> 1 to 8, index of the reference waveform

Parameters:

<State> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Enable"](#) on page 249

REFCurve<rc>:RESCale:VERTical:FACTOR <ScaleFactor>

Sets the vertical scale factor. A factor greater than 1 stretches the waveform vertically, a factor lower than 1 compresses the curve.

Suffix:

<rc> 1 to 8, index of the reference waveform

Parameters:

<ScaleFactor> Range: -1000000000 to 1000000000
Increment: 0.1
*RST: 1

Usage: Asynchronous command

Manual operation: See ["Scale factor"](#) on page 249

REFCurve<rc>:RESCale:VERTical:OFFSet <Offset>

The vertical offset moves the reference waveform vertically. Enter a value with the unit of the waveform.

Like vertical offset of a channel waveform, the offset of a reference waveform is subtracted from the measured value. Negative values shift the waveform up, positive values shift it down.

Suffix:

<rc> 1 to 8, index of the reference waveform

Parameters:

<Offset> Range: -1000000000 to 1000000000
Increment: 1E-06
*RST: 0
Default unit: V

Usage: Asynchronous command

Manual operation: See ["Vertical offset"](#) on page 249

REFCurve<rc>:RESCale:VERTical:STATe <State>

If enabled, the vertical offset and factor are applied to the reference waveform.

Stretching and offset change the display of the waveform independent of the vertical scale and position.

Suffix:

<rc> 1 to 8, index of the reference waveform

Parameters:

<State> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Enable"](#) on page 249

REFCurve<rc>:TOORiginal

Available, if [REFCurve<rc>:VMODE](#) is set to `INDependent`.

Restores the original vertical settings of the reference waveform.

Suffix:

<rc> 1 to 8, index of the reference waveform

Usage:

Setting only
Asynchronous command

Manual operation: See ["Set to original"](#) on page 247

REFCurve<rc>:VMODE <VerticalMode>

Selects the coupling of vertical settings.

Suffix:

<rc> 1 to 8, index of the reference waveform

Parameters:

<VerticalMode> COUPled | INDependent

COUPled

Vertical position and scale of the source are used.

INDependent

Scaling and position can be set specific to the reference waveform.

*RST: INDependent

Usage:

Asynchronous command

Manual operation: See ["Vertical mode"](#) on page 247

18.12.4.3 Reference waveform data export

Commands to transmit the data of reference waveforms are listed below. Commands for saving waveform data to a file are described in [Section 18.13.4, "Waveform export to file"](#), on page 1105.

REFCurve<rc>:DATA:STYPe?	1089
REFCurve<rc>:DATA:HEADer?	1090
REFCurve<rc>:DATA[:VALues]?	1091

REFCurve<rc>:DATA:STYPe?

Returns the type of the source signal from which the reference waveform was created.

Suffix:

<rc> 1 to 8, index of the reference waveform

Return values:

<SignalType> NONE | CHANNEL | MATH | TRACK | REFERENCE |
SPECTRUM | FRA_REF

Usage: Query only
Asynchronous command

REFCurve<rc>:DATA:HEADer?

Returns header information on the reference waveform, the attributes of the waveform.

The information depends on the waveform domain, it is different for time domain and frequency domain reference waveforms. See:

- [CHANnel<ch>:DATA:HEADer?](#) on page 1004
- [CALCulate:SPECTrum<sp>:WAVEform:NORMal:DATA:HEADer?](#) on page 1174

Suffix:
<rc> 1 to 8, index of the reference waveform

Return values:

<XStart>	1. header value: time of the first sample in s for a time domain signal, or start frequency of the first spectrum bin in Hz for a frequency domain signal
<XStop>	2. header value: time of the last sample in s for a time domain signal, or start frequency of the last spectrum bin in Hz for a frequency domain signal
<RecordLength>	3. header value: record length of the waveform in samples or bins
<ValuesPerSample>	4. header value: number of values per sample or bin. The number depends on the source waveform from which the reference waveform was created.

Example: Time domain signal:
REFC:DATA:HEAD?
-1E-07,9.980000000000001E-08,1000,1

Start time of the data is -1E-07= -100 ns and stop time of the data is 9.980000000000001E-08= 99.8 ns. The data stream has 1000 values with one value per sample.

Example: Frequency domain signal:
REFC:DATA:HEAD?
549316.1734194756,1999450683.360919,2621,1

Start frequency of the first spectrum bin is 549316.1734194756 = ~ 549.3 kHz and start frequency of the last spectrum bin is 1999450683.360919 = ~ 1.999 GHz. The data stream has 2621 values with one value per bin.

Usage: Query only
Asynchronous command

REFCurve<rc>:DATA[:VALues]? [<Offset>[,<Length>]]

Returns the data of the channel waveform points for transmission from the instrument to the controlling computer. The data can be used in MATLAB, for example.

Without parameters, the complete waveform is retrieved. Using the offset and length parameters, data can be retrieved in smaller portions, which makes the command faster. If you send only one parameter, it is interpreted as offset, and the data is retrieved from offset to the end of the waveform.

To set the export format, use [FORMat \[:DATA\]](#) on page 921.

Suffix:

<rc> 1 to 8, index of the reference waveform

Query parameters:

<Offset> Number of offset waveform points to be skipped.
Range: 0 to m. Limit: $n + m \leq \text{record length}$

<Length> Number of waveform points to be retrieved.
Range: 1 to n. Limit: $n + m \leq \text{record length}$

Return values:

<Data> List of values according to the format and content settings.

Usage:

Query only
Asynchronous command

18.12.5 Waveform histograms

- [Histogram settings](#)..... 1091
- [Window settings](#)..... 1093
- [Histogram data transfer](#)..... 1096

18.12.5.1 Histogram settings**HISTogram<m>:ADD**

Creates a new histogram with the specified index.

Suffix:

<m> 1...8, index of the histogram

Usage:

Setting only
Asynchronous command

HISTogram<m>:COUNT? <Count>

Returns the number of created histograms.

You can query the minimum and maximum values with <command>? MIN and <command>? MAX.

Suffix:

<m> Irrelevant, omit the suffix.

Return values:

<Count> Counted number of histograms

Usage:

Query only
Asynchronous command

HISTogram<m>:ENABLE <State>

Enables or disables the histogram evaluation and display. The histogram settings are kept until the histogram is deleted.

Suffix:

<m> 1...8, index of the histogram

Parameters:

<State> OFF | ON
*RST: OFF

Usage:

Asynchronous command

Manual operation: See "State" on page 252

HISTogram<m>:MODE <Mode>

Defines the type of histogram.

Suffix:

<m> 1...8, index of the histogram

Parameters:

<Mode> VERTical | HORizontal

VERTical

A vertical histogram has horizontal bars that show the occurrence of amplitude, or vertical values.

HORizontal

A horizontal histogram has vertical bars that show the occurrence of a sample at a given time on the x-axis.

*RST: VERTical

Usage:

Asynchronous command

Manual operation: See "Mode" on page 252

HISTogram<m>:REMove

Deletes the specified histogram.

Suffix:

<m> 1...8, index of the histogram

Usage: Setting only
Asynchronous command

HISTogram<m>:RESet

Restarts the calculation of the selected histogram.

To reset all histograms and measurements, use [DISPlay:CLR](#).

Suffix:
<m> 1...8, index of the histogram

Usage: Setting only
Asynchronous command

Manual operation: See ["Reset"](#) on page 252

HISTogram<m>:SOURce <Source>

Defines the source of the histogram.

Suffix:
<m> 1...8, index of the histogram

Parameters:
<Source> C1 | C2 | ... | C8 | M1 | M2 | ... | M8 | R1 | R2 | ... | R8 | O<n>C1 |
O<n>C2 | ... | O<n>C8 (<n> = 2 to 11)

Usage: Asynchronous command

Manual operation: See ["Source"](#) on page 252

18.12.5.2 Window settings

HISTogram<m>:WINDow:ENABle	1094
HISTogram<m>:WINDow:HORizontal:MODE	1094
HISTogram<m>:WINDow:VERTical:MODE	1094
HISTogram<m>:WINDow:HORizontal:ABSolute:POSition	1094
HISTogram<m>:WINDow:HORizontal:ABSolute:SPAN	1094
HISTogram<m>:WINDow:HORizontal:ABSolute:STARt	1094
HISTogram<m>:WINDow:HORizontal:ABSolute:STOP	1094
HISTogram<m>:WINDow:HORizontal:RELative:POSition	1095
HISTogram<m>:WINDow:HORizontal:RELative:SPAN	1095
HISTogram<m>:WINDow:HORizontal:RELative:STARt	1095
HISTogram<m>:WINDow:HORizontal:RELative:STOP	1095
HISTogram<m>:WINDow:VERTical:ABSolute:POSition	1095
HISTogram<m>:WINDow:VERTical:ABSolute:SPAN	1095
HISTogram<m>:WINDow:VERTical:ABSolute:STARt	1095
HISTogram<m>:WINDow:VERTical:ABSolute:STOP	1095
HISTogram<m>:WINDow:VERTical:RELative:POSition	1095

HISTogram<m>:WINDow:VERTical:RELative:SPAN.....	1095
HISTogram<m>:WINDow:VERTical:RELative:START.....	1095
HISTogram<m>:WINDow:VERTical:RELative:STOP.....	1095

HISTogram<m>:WINDow:ENABle <State>

When you use a histogram window, the analyzed part of the source waveform is limited vertically and horizontally.

Suffix:

<m> 1...8, index of the histogram

Parameters:

<State> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Use window"](#) on page 253

HISTogram<m>:WINDow:HORizontal:MODE <Mode>

HISTogram<m>:WINDow:VERTical:MODE <Mode>

The commands define whether the window limits are entered as absolute or relative values, in horizontal and vertical direction.

Suffix:

<m> 1...8, index of the histogram

Parameters:

<Mode> ABS | REL
*RST: ABS

Usage: Asynchronous command

Manual operation: See ["Mode"](#) on page 253

HISTogram<m>:WINDow:HORizontal:ABSolute:POSition <Value>

HISTogram<m>:WINDow:HORizontal:ABSolute:SPAN <Value>**HISTogram<m>:WINDow:HORizontal:ABSolute:START <Value>****HISTogram<m>:WINDow:HORizontal:ABSolute:STOP <Value>**

Set the horizontal window limits as absolute values. Enter the unit of the horizontal axis together with the value.

Suffix:

<m> 1...8, index of the histogram

Parameters:

<Value> Range: -1E+26 to 1E+26
Increment: 0.01
*RST: 0 for position, 0.02 for span, -0.01 for start and 0.01 for stop

Usage: Asynchronous command

Manual operation: See ["Start, Stop, Range, Position"](#) on page 253

HISTogram<m>:WINDow:HORizontal:RELative:POSition <Value>

HISTogram<m>:WINDow:HORizontal:RELative:SPAN <Value>

HISTogram<m>:WINDow:HORizontal:RELative:START <Value>

HISTogram<m>:WINDow:HORizontal:RELative:STOP <Value>

Set the horizontal window limits as relative values in % of the diagram width.

Suffix:

<m> 1...8, index of the histogram

Parameters:

<Value> Range: 0 for position, start and stop, 1E-15 for span to 100

Increment: 0.1

*RST: position: 50, span: 1, start: 0, stop: 100

Default unit: %

Usage: Asynchronous command

Manual operation: See ["Relative start, Relative stop, Relative range, Relative position"](#) on page 254

HISTogram<m>:WINDow:VERTical:ABSolute:POSition <Value>

HISTogram<m>:WINDow:VERTical:ABSolute:SPAN <Value>

HISTogram<m>:WINDow:VERTical:ABSolute:START <Value>

HISTogram<m>:WINDow:VERTical:ABSolute:STOP <Value>

Set the vertical window limits as absolute values. Enter the unit of the vertical axis together with the value.

Suffix:

<m> 1...8, index of the histogram

Parameters:

<Value> Range: -1E+26 to 1E+26

Increment: 0.01

*RST: 0 for position, 0.02 for span, -0.01 for start and 0.01 for stop

Usage: Asynchronous command

Manual operation: See ["Start, Stop, Range, Position"](#) on page 254

HISTogram<m>:WINDow:VERTical:RELative:POSition <Value>

HISTogram<m>:WINDow:VERTical:RELative:SPAN <Value>

HISTogram<m>:WINDow:VERTical:RELative:START <Value>

HISTogram<m>:WINDow:VERTical:RELative:STOP <Value>

Set the vertical window limits as relative values in % of the diagram height.

Suffix:

<m> 1...8, index of the histogram

Parameters:

<Value> Range: 0 for position, start and stop, 1E-15 for span to 100
 Increment: 0.1
 *RST: position: 50, span: 1, start: 0, stop: 100
 Default unit: %

Usage: Asynchronous command

Manual operation: See "Start, Stop, Range, Position" on page 254

18.12.5.3 Histogram data transfer

EXPort:HISTogram<m>:DATA:HEADer?..... 1096
 EXPort:HISTogram<m>:DATA[:VALues]?..... 1096

EXPort:HISTogram<m>:DATA:HEADer?

Returns the header of the histogram data, the attributes of the waveform histogram.

Suffix:

<m> 1...8, index of the histogram

Return values:

<Start> 1. header value: start value, for vertical histogram in the waveform unit, for horizontal histogram in s.
 <End> 2. header value: end value, for vertical histogram in the waveform unit, for horizontal histogram in s.
 <HistoGrLength> 3. header value: number of histogram bins

Example:

EXP:HIST3:DATA:HEAD?
 -0.250244,0.250122,1024

Start value of the histogram is about -250 mV, and end value is about 250 mV. The data stream has 1024 values, one value for each bin.

Usage:

Query only
 Asynchronous command

EXPort:HISTogram<m>:DATA[:VALues]?

Returns the data of the specified histogram for transmission from the instrument to the controlling computer. The data can be used in MATLAB, for example.

To set the export format, use `FORMat[:DATA]`. For histogram data, only ASCII and REAL,32 and REAL,64 are supported. The normalization setting is considered:

`EXPort:HISTogram<m>:NORMalize.`

Suffix:	
<m>	1...8, index of the histogram
Return values:	
<Data>	Comma-separated list of values according to the format setting.
Usage:	Query only Asynchronous command

18.13 Data management

Some of the commands in the following section are asynchronous. An overlapping or asynchronous command does not automatically finish executing before the next command starts executing. If overlapping commands must be executed in a defined order, e.g. to avoid wrong measurement results, they must be serviced sequentially.

To prevent an overlapping execution of commands, one of the commands `*OPC`, `*OPC?` or `*WAI` can be used after the command or a command set.

For more information, see:

- www.rohde-schwarz.com/rc-via-scp, section "Command sequence and synchronization"

18.13.1 Instrument settings

The Mass MEMory subsystem provides commands to access the storage media and to save and reload instrument settings.

File and directory names

The <file_name> and <directory_name> parameters are strings. Some commands use a fixed directory; for others the <file_name> can contain the complete path including the drive name and all subdirectories. If no complete path is specified, the file location is relative to the current directory, queried with `MMEMory:CDIRectory?`. The filename itself may contain the period as a separator for extensions.

File and directory names can be chosen according to Windows™ conventions. All letters and numbers are allowed, as well as the special characters "_", "^", "\$", "~", "!", "#", "%", "&", "-", "{", "}", "(", ")", "@", and ". Reserved filenames are CON, AUX, COM1, ..., COM4, LPT1, ..., LPT3, NUL and PRN.

The use of wildcards ? and * is not allowed.

MMEMory:DRIVes?	1098
MMEMory:DCATalog?	1098
MMEMory:DCATalog:LENGth?	1099
MMEMory:CDIRectory	1099
MMEMory:MDIRectory	1099
MMEMory:RDIRectory	1099
MMEMory:CATalog?	1100

MMEMory:CATalog:LENGth?	1100
MMEMory:COpy	1101
MMEMory:MOve	1101
MMEMory:DELe	1101
MMEMory:DATA	1102
MMEMory:ATTRibute	1102
MMEMory:SAV	1102
MMEMory:RCL	1103
MMEMory:STORe:STATe	1103
MMEMory:LOAD:STATe	1103
MMEMory:GENerator:RCL	1103
MMEMory:GENerator:SAV	1104

MMEMory:DRIVes?

Returns the path list of available drives.

Return values:

<Drive>

List of strings, for example:

Instrument only: "/home/storage/userData"

Instrument with connected USB flash drive:

"/home/storage/userData", "/run/media/usb/<MyDriveName>/MYD

. MYDATA is the partition name, which is also shown in the file explorer.

Instrument with connected USB flash drive:

"/home/storage/userData", "/run/media/usb/<MyDriveName>/8AF

. 8AF8-3EBA is an example ID. ID is used if the partition does not have a name, or the name cannot be read.

Usage:

Query only

MMEMory:DCATalog? [<PathName>]

Returns the subdirectories of the current or of a specified directory.

Query parameters:

<PathName>

String parameter to specify the directory. If the directory is omitted, the command queries the contents of the current directory, to be set and queried with [MMEMory:CDIRectory](#).

Return values:

<FileEntry>

Names of the subdirectories separated by colons. The first two strings are related to the parent directory.

Example:

MMEM:DCAT?

Usage:

Query only

MMEMory:DCATalog:LENGth? [<PathName>]

Returns the number of subdirectories of the current or of a specified directory. The number includes the parent directory strings "." and ".." and corresponds to the number of strings returned by the [MMEMory:DCATalog?](#) command.

Query parameters:

<PathName> String parameter to specify the directory. If the directory is omitted, the command queries the contents of the current directory, to be set and queried with [MMEMory:CDIRectory](#).

Return values:

<FileEntryCount> Number of parent directories and subdirectories.

Example: MMEM:DCAT:LENG?
5

Usage: Query only

MMEMory:CDIRectory [<DirectoryName>]

Changes the default directory for file access.

Parameters:

<DirectoryName> String parameter to specify the directory.
*RST: ""

Example: MMEM:CDIR ' /home/storage/userData/Waveforms '

Usage: SCPI confirmed

MMEMory:MDIRectory <DirectoryName>

Creates a new directory with the specified name.

Setting parameters:

<DirectoryName> String parameter to specify the new directory. If the path consists of several subdirectories, the complete tree is created if necessary.

Example: MMEM:MDIR ' /home/storage/userData/Waveforms '

Usage: Setting only

MMEMory:RDIRectory <DirectoryName>

Deletes the specified directory.

Setting parameters:

<DirectoryName> String parameter to specify the directory to be deleted. This directory must be empty, otherwise it is not deleted.

Example: MMEM:RDIR ' /home/storage/userData/Test '

Usage: Setting only

MMEMory:CATalog? [<PathName>][, <Format>]

Returns a list of files contained in the specified directory. The result corresponds to the number of files returned by the MMEMory:CATalog:LENGth command.

Query parameters:

<PathName>	String parameter to specify the directory. If the directory is omitted, the command queries directory specified with MMEMory:CDIRectory .
<Format>	ALL WTime ALL: Extended result including file, date, time and attributes WTime: Extended result including file, date, time

Return values:

<UsedMemory>	Total amount of storage currently used in the directory, in bytes.
<FreeMemory>	Total amount of storage available in the directory, in bytes.
<FileEntry>	All files and subdirectories of the directory are listed with their filename, format and size in bytes. The first two strings are related to the parent directory.

Example:

```
MMEM:CAT? '/home/storage/userData'
529479,1831777894400,".",DIR,0","..",DIR,0",
"Backup,DIR,0","CSS,DIR,0","DATEN,DIR,0",
"Commands.jar,BIN,529479","FAVORITES,DIR,0",
"LOG,DIR,0","DATA,DIR,0","test,DIR,0",
"TotalCMD,DIR,0"
```

Usage:

Query only
SCPI confirmed

MMEMory:CATalog:LENGth? [<PathName>]

Returns the number of files and subdirectories of the current or specified directory. The number includes the parent directory strings "." and ".." and it corresponds to the number of <FileEntry> strings returned by the [MMEMory:CATalog?](#) command.

Query parameters:

<PathName>	String parameter, directory to be queried. If the directory is omitted, the current directory is queried, specified with MMEMory:CDIRectory .

Return values:

<Count>	Number of files and subdirectories including parent directory entries.

Example:

```
MMEM:CDIR '/home/storage/userData'
MMEM:CAT:LENG?
11
```

Usage:

Query only

MMEMory:COPY <FileSource>[, <FileDestination>]

Copies an existing file to a new file.

Setting parameters:

<FileSource> String parameter. Contains name and path of the file to be copied. Wildcards (* and ?) are allowed.

<FileDestination> String parameter. Contains name and path of the new file. If the file already exists, it is overwritten without notice. If no file destination is specified, the source file is written to the current directory specified with [MMEMory:CDIRectory](#).

Usage: Setting only
SCPI confirmed

MMEMory:MOVE <FileSource>, <FileDestination>

Moves the specified file to a new location on the same drive and renames it.

Setting parameters:

<FileSource> String parameter, contains name and path of the file to be copied. Wildcards (* and ?) are allowed. Therefore, specify a directory for <FileDestination>. Renaming is not possible.

<FileDestination> String parameter. Contains name and path of the new file. If no path is specified, the <FileSource> directory is used - the file is renamed.

Usage: Setting only
SCPI confirmed

MMEMory:DELeTe <FileName>

Removes the specified file/files. To delete directories, use [MMEMory:RDIRectory](#).

Setting parameters:

<FileName> String parameter to specify the name and directory of the file to be removed. Wildcards (* and ?) are allowed. If no path is defined, the current directory is used, specified with [MMEMory:CDIRectory](#).

Example: `MMEM:DEL '* .CFG'`
Deletes all CFG files from the current directory.

Usage: Setting only
SCPI confirmed

MMEMory:DATA <FileName>, <Data>

MMEMory:DATA? <FileName>

Stores data in the specified file to the storage location specified using [MMEMory:CDIRectory](#).

Parameters:

<Data> <block>

488.2 block data format. The delimiter EOI must be selected to achieve correct data transfer.

The block begins with character '#'. The next digit is the length of the length information, followed by this given number of digits providing the number of bytes in the following binary data.

Parameters for setting and query:

<FileName> String parameter, the name of the file the data is stored to.

Example:

MMEM:DATA 'abc.txt', #216This is the file
#2: the length information has two digits.
16: the binary data has 16 bytes.

Example:

MMEM:DATA? 'abc.txt'
Returns the data from file abc.txt.

MMEMory:ATTRibute <FileName>, <Attributes>

MMEMory:ATTRibute? <FileName>

Sets file attributes for the specified file/files. The command can be used for files only.

Setting parameters:

<Attributes> String with attributes and setting information.
'+' before the attribute: sets the attribute
'-' before the attribute: deletes the attribute
'R': read only
'H': hidden file

Parameters for setting and query:

<FileName> String parameter, contains name and path of the file. Wildcards (* and ?) are allowed.

Return values:

<FileEntry> String containing: "<file_name>,<file_attributes>"

MMEMory:SAV <FileDestination>

Stores the current instrument settings to the specified file.

Waveform generator settings are not included.

This command has the same effect as the combination of *SAV and MMEMory:STORe:STATe.

Parameters:

<FileDestination> String parameter specifying path and filename of the target file. Wildcards are not allowed.

Usage: Event

MMEMory:RCL <FileSource>

Restores the instrument settings from the specified file.

The stored instrument settings do not include waveform generator settings.

This command has the same effect as the combination of **MMEMory:LOAD:STATe** and ***RCL**.

Parameters:

'<FileSource>' String parameter specifying the path and filename of the source file. Wildcards are not allowed.

Usage: Event

MMEMory:STORE:STATe <MemoryNumber>, <FileName>

Stores the instrument settings from the specified internal memory to the specified file. To store the current instrument settings to the internal memory, use ***SAV** first.

Setting parameters:

<MemoryNumber> Number of the internal memory

Range: 1 to 99

<FileName> String parameter specifying the complete path and filename of the source file.

Usage: Setting only

MMEMory:LOAD:STATe <MemoryNumber>, <FileName>

Loads the instrument settings from the specified file to the specified internal memory. After the file has been loaded, the settings must be activated using a ***RCL** command.

Setting parameters:

<MemoryNumber> Number of the internal memory

Range: 1 to 99

<FileName> String parameter specifying the complete path and filename of the source file.

Usage: Setting only

MMEMory:GENerator:RCL <FilePath>

Restores the waveform generator settings from the specified file.

Parameters:

<FilePath> String parameter specifying the path and filename of the settings file.

Usage: Asynchronous command

MMEMory:GENerator:SAV <FilePath>

Stores the current waveform generator settings to the specified file.

Parameters:

<FilePath> String parameter specifying path and filename of the settings file.

Usage: Asynchronous command

18.13.2 Saveset

SAVeset:CONFig:PREView <IncludePreview>

If set to OFF, the saveset is stored without the preview image to reduce the file size.

Use the command each time before you save a saveset.

Parameters:

<IncludePreview> OFF | ON
*RST: ON

Usage: Asynchronous command

SAVeset:CONFig:UPReferences <UserSettings>

If ON, the user-specific display settings for the toolbar, waveform colors and diagram presentation are included in the saveset file. The setting affects the saving and the recall actions.

Parameters:

<UserSettings> OFF | ON
*RST: OFF

Usage: Asynchronous command

18.13.3 Generator saveset

GENerator:RCL <filePath>

Restores the waveform generator from the specified file.

Parameters:

<filePath> String parameter specifying the path and filename of the source file.

Usage: Asynchronous command

GENerator:SAV <filePath>

Stores the current waveform generator settings to the specified file.

Parameters:

<filePath> String parameter specifying path and filename of the target file.

Usage: Asynchronous command

18.13.4 Waveform export to file

EXPort:WAVeform:ABORt.....	1105
EXPort:WAVeform:AUTonaming:NAME.....	1105
EXPort:WAVeform:AUTonaming:PATH.....	1106
EXPort:WAVeform:AUTonaming:TYPE.....	1106
EXPort:WAVeform:CURSorset.....	1106
EXPort:WAVeform:GATE.....	1106
EXPort:WAVeform:NAME.....	1107
EXPort:WAVeform:SAVE.....	1107
EXPort:WAVeform:SCOPe.....	1107
EXPort:WAVeform:SOURce.....	1108
EXPort:WAVeform:STARt.....	1109
EXPort:WAVeform:STOP.....	1109

EXPort:WAVeform:ABORt

Aborts a running waveform export, which was started with [EXPort:WAVeform:SAVE](#).

Usage: Event
Asynchronous command

EXPort:WAVeform:AUTonaming:NAME <FileName>

Sets a name for the waveform file, without extension. The name is extended with a time stamp when the file is saved.

The setting is used for automatic saving actions, for example, saving on trigger or mask violation. It has **no** effect on [EXPort:WAVeform:SAVE](#).

Parameters:

<FileName> String with the filename.

Usage: Asynchronous command

Manual operation: See "[File name base](#)" on page 449

EXPort:WAVeform:AUTonaming:PATH <FolderPath>

Sets the directory where the waveform file is saved. For local storage, the path is always `/home/storage/userData`.

The setting is used for automatic saving actions, for example, saving on trigger or mask violation. It has **no effect** on `EXPort:WAVeform:SAVE`.

Parameters:

<FolderPath> String with the path.

Usage: Asynchronous command

Manual operation: See "<Folder>" on page 449

EXPort:WAVeform:AUTonaming:TYPE <FileExtension>

Sets the file type of the waveform file.

The setting is used for automatic saving actions, for example, saving on trigger or mask violation. It has **no effect** on `EXPort:WAVeform:SAVE`.

Parameters:

<FileExtension> CSV | REF | ZIP | H5
 *RST: REF

Usage: Asynchronous command

Manual operation: See "File extension" on page 449

EXPort:WAVeform:CURSorset <Cursorset>

Sets the cursor set to be used for limited data export if `EXPort:WAVeform:SCOPE` is set to `CURSor`.

Parameters:

<Cursorset> CURSOR1 | CURSor1 | CURSOR2 | CURSor2 | CURSOR3 |
 CURSor3 | CURSOR4 | CURSor4

Usage: Asynchronous command

Manual operation: See "Export mode" on page 448

EXPort:WAVeform:GATE <Gate>

Selects the gate to be used for limited data export if `EXPort:WAVeform:SCOPE` is set to `GATE`.

Parameters:

<Gate> Number of the gate to be applied to exported data.

Usage: Asynchronous command

Manual operation: See "Export mode" on page 448

EXPort:WAVeform:NAME <name>

Sets the path, the filename and the file format of the export file. The setting is used for save-as operations that do not use the autonaming settings.

Parameters:

<name> String with path and filename with extension `.ref`, `.csv`, `.zip`, or `.h5`. Extension `.ref` is provided for single waveform export only, while `.zip` is for export of multiple waveforms in REF format. CSV can be used for export of single waveforms, and multiple analog channels. For local storage, the path is always `/home/storage/userData`.

Example:

```
EXP:WAV:NAME
'/home/storage/userData/Export_C1.csv'
EXP:WAV:SCOP DISP
EXP:WAV:SAVE
Saves the visible waveform data of channel 1 in xml format
to /home/storage/userData/Export_C1.csv.
```

Usage: Asynchronous command

Manual operation: See ["Save As"](#) on page 449

EXPort:WAVeform:SAVE

Saves the waveform to the file specified with `EXPort:WAVeform:NAME`.

Usage: Event
Asynchronous command

Manual operation: See ["Save As"](#) on page 449

EXPort:WAVeform:SCOPE <Scope>

Defines the part of the waveform record that has to be stored.

Parameters:

<Scope> DISPlay | ALL | CURSor | GATE | MANual

DISPlay
Waveform data that is displayed in the diagram.

ALL
Complete waveform, which is usually longer than the displayed waveform.

CURSor
Data between the cursor lines if a cursor measurement is defined for the source waveform.

GATE
Data included in the measurement gate if a gated measurement is defined for the source waveform.

MANual

Saves the data between user-defined start and stop values to be set with `EXPort:WAVeform:START` and `EXPort:WAVeform:STOP`.

*RST: DISPlay

Example: See [Section 18.5.4, "Data transfer in roll mode"](#), on page 916.

Usage: Asynchronous command

Manual operation: See ["Export mode"](#) on page 448

EXPort:WAVeform:SOURce <Sources>

Selects the waveform or waveforms to be exported to file.

Parameters:

<Sources>

Comma-separated list of waveforms

Possible waveform sources are:

Analog signals: C1,C2,...,C8

Digital signals: D0,D1,D2,...,D15

Math waveforms: M1,M2,M3,M4,M5

Reference waveforms: R1,R2,R3,R4

Spectrum traces: SPECMAH1,SPECMINH1,SPEC-NORM1,SPECAVER1,SPECMAH2,SPECMINH2,SPEC-NORM2,SPECAVER2,SPECMAH3,SPECMINH3,SPEC-NORM3,SPECAVER3,SPECMAH4,SPECMINH4,SPEC-NORM4,SPECAVER4

Tracks: TRK1,TRK2,TRK3, ...,TRK24

Analog channels of connected scopes (ScopeSync):

O<n>C1,O<n>C2, ... ,O<n>C8 (<n> = 2 to 11)

Power waveforms: PA1QPOWER | PA2QPOWER | ... | PA6QPOWER | PA1HPOWER1 | PA2HPOWER1 | ... | PA6HPOWER1 | PA1SPOWER | PA2SPOWER | ... | PA6SPOWER | PA1IPOWER | PA2IPOWER | ... | PA6IPOWER | PA1OPOWER1 | PA2OPOWER1 | ... | PA6OPOWER1 | PA1OPOWER2 | PA2OPOWER2 | ... | PA6OPOWER2 | PA1OPOWER3 | PA2OPOWER3 | ... | PA6OPOWER3 | PA1TOPOWER | PA2TOPOWER | ... | PA6TOPOWER | PA1SOA | PA2SOA | ... | PA6SOA

Example:

```
EXP:WAV:NAME '/home/storage/userData/Export_C2.csv'
EXPort:WAVeform:SOURce C2
EXP:WAV:SCOP DISP
EXP:WAV:SAVE
```

Exports the data of channel 2 to a CSV file.

Example:

```
EXP:WAV:NAME '/home/storage/userData/Export_multi.zip'
EXP:WAV:FORM:SOURce C1,C2,SPECNORM1,SPECAVER1
EXP:WAV:SCOP DISP
EXP:WAV:SAVE
```

Exports the data of channel 1, channel 2, normal and average spectrum traces to a zip file.

Usage: Asynchronous command

Manual operation: See ["Source"](#) on page 447

EXP:WAV:FORM:START <Start>

Sets the start time value of the waveform section for export, if [EXP:WAV:FORM:SCOPE](#) on page 1107 is set to `Manual`.

Parameters:

<Start>

Range:	-1E+26 to 1E+26
Increment:	0.01
*RST:	0.01
Default unit:	s

Usage: Asynchronous command

Manual operation: See ["Export mode"](#) on page 448

EXP:WAV:FORM:STOP <Stop>

Sets the end time value of the waveform section for export, if [EXP:WAV:FORM:SCOPE](#) on page 1107 is set to `Manual`.

Parameters:

<Stop>

Range:	-1E+26 to 1E+26
Increment:	0.01
*RST:	0.01
Default unit:	s

Usage: Asynchronous command

Manual operation: See ["Export mode"](#) on page 448

18.13.5 Fast data export

EXP:WAV:FORM:DATA[:VALUES]?

Starts a fast export of the selected waveforms for use in automated analysis systems. There is no corresponding `...:DATA:HEADER` command. Offset and length parameters are not available.

Select the waveforms for export with [EXP:WAV:FORM:SOURce](#), and the data scope with [EXP:WAV:FORM:SCOPE](#).

The data stream contains the pure data of the exported sources. The order of the sources can be read with `EXPort:WAVeform:SOURce?`. The order is predefined and independent of the setting order to ensure the same order for the same selection of waveforms.

Fast export is possible at low record length, depending on the instrument and active functionality. If fast export is not possible, you can export the single signals.

Parameters:

<Values> Binary format: stream of bytes, without delimiter
 ASCII: comma-separated value list

Example:

The following waveforms are active and acquired: C1, C2 and SPECNORM1.

Determine the number of values per waveform:

```
CHANnel1:WAVeform:DATA:HEADer? --> 1000 values
CHANnel2:WAVeform:DATA:HEADer?      --> 1000 values
CALCulate:SPECTrum1:WAVeform:NORMal:DATA:HEADer? --> 2867 values
```

Fast export of all waveforms at once as float values:

```
FORMat:DATA REAL, 32
EXPort:WAVeform:SOURce C2,C1,SPECNORM1
EXPort:WAVeform:SOURce?      --> C1,C2,SPECNORM1
EXPort:WAVeform:DATA:VALues?
--> data stream of 1000 values C1, then 1000 values C2, then 2867 values
```

If the fast export fails, use the export of single waveforms:

```
CHANnel1:WAVeform:DATA:VALues?
CHANnel2:WAVeform:DATA:VALues?
CALCulate:SPECTrum1:WAVeform:NORMal:DATA:VALues?
```

Usage:

Query only
 Asynchronous command

18.13.6 Waveform histograms

<code>EXPort:HISTogram<m>:NORMalize</code>	1110
<code>EXPort:HISTogram<m>:NAME</code>	1111
<code>EXPort:HISTogram<m>:SAVE</code>	1111

EXPort:HISTogram<m>:NORMalize <Normalization>

If normalization is off, the number of samples in a given bin is exported as integer values. With normalization, the ratio of samples in a given bin to the sum of all samples is exported as float value. The sum of all normalized values is 1.

The command affects all histogram exports.

Suffix:

<m> Irrelevant, omit the suffix.

Parameters:

<Normalization> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Normalization"](#) on page 464

EXPort:HISTogram<m>:NAME <SaveAsPath>

Sets the path, the filename and the file format of the export file for histogram. The command affects all histogram exports.

Suffix:

<m> Irrelevant, omit the suffix.

Parameters:

<SaveAsPath> String with path and file name with extension `.csv`.

Usage: Asynchronous command

Manual operation: See ["Save settings"](#) on page 464

EXPort:HISTogram<m>:SAVE

Saves the specified histogram to file. The target file is set using [EXPort:HISTogram<m>:NAME](#) on page 1111.

Suffix:

<m> 1...8, index of the histogram

Usage: Event
 Asynchronous command

Manual operation: See ["Save settings"](#) on page 464

18.13.7 Sessions

SESSion:LOAD[:EXECute]	1111
SESSion:SAVE:ABORT	1112
SESSion:SAVE:CHANnel	1112
SESSion:SAVE:REFerence	1112
SESSion:SAVE[:EXECute]	1112
SESSion:USERpref	1113

SESSion:LOAD[:EXECute] <Filepath>

Loads a session file.

To reload also user-specific display settings (if included in the session file), set [SESSion:USERpref](#) ON.

Setting parameters:

<Filepath> String parameter specifying path and filename of the session file.

Usage: Setting only
Asynchronous command

Manual operation: See ["Open"](#) on page 469

SESSion:SAVE:ABORt

Stops the saving process of a session file.

Usage: Setting only
Asynchronous command

Manual operation: See ["Save settings"](#) on page 468

SESSion:SAVE:CHANnel <ChWfms>

Includes the channel waveform data in the session file.

Parameters:

<ChWfms> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Channel waveforms"](#) on page 467

SESSion:SAVE:REFerence <RefWfms>

Includes the reference waveform data in the session file.

Parameters:

<RefWfms> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Reference waveforms"](#) on page 467

SESSion:SAVE[:EXECute] <Filepath>

Saves the current session with selected content to the specified file.

Setting parameters:

<Filepath> String parameter specifying path and filename of the target file.

Usage: Setting only
Asynchronous command

Manual operation: See ["Save settings"](#) on page 468

SESSion:USERpref <UserSettings>

If ON, the user-specific display settings for the toolbar, waveform colors and diagram presentation are included in the session file. The setting affects the saving and the recall actions.

Parameters:

<UserSettings> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Toolbar, color and diagram settings"](#) on page 467

18.13.8 Results

EXPort:RESult:NAME	1113
EXPort:RESult:SAVE	1113
EXPort:RESult:SElect:CURSor	1113
EXPort:RESult:SElect:MEASurement	1114

EXPort:RESult:NAME <FilePath>

Sets the path, the filename and the file format of the export file.

Parameters:

<FilePath> String with path and file name with extension `.csv`.

Usage: Asynchronous command

EXPort:RESult:SAVE

Saves the results to file. The target file is set using [EXPort:RESult:NAME](#). To select the results to be exported, use [EXPort:RESult:SElect:CURSor](#) and [EXPort:RESult:SElect:MEASurement](#).

Usage: Event
 Asynchronous command

EXPort:RESult:SElect:CURSor <CursorResult>

Includes the current cursor results in the export file.

Parameters:

<CursorResult> OFF | ON
 *RST: OFF

Usage: Asynchronous command

EXPort:RESult:SElect:MEASurement <MeasResult>

Includes the current automatic measurement results in the export file.

Parameters:

<MeasResult> OFF | ON
 *RST: OFF

Usage: Asynchronous command

18.13.9 Screenshots

The `HCOPY` subsystem and some other commands control the output of display information for documentation purposes. The instrument allows two independent output configurations which can be set separately with the suffix.

Note that the remote mode is intended for maximum performance. Therefore, the display does not follow the remote commands constantly. To get a correct screenshot, turn the display on using `SYSTem:DISPlay:UPDate`.

<code>HCOPY:DESTination<m></code>	1114
<code>MMEMory:NAME</code>	1115
<code>HCOPY:DEvice<m>:LANGuage</code>	1115
<code>HCOPY:DEvice<m>:INVerse</code>	1115
<code>HCOPY:IMMediate<m>:NEXT</code>	1115
<code>HCOPY:IMMediate<m></code>	1116
<code>HCOPY:ISBA</code>	1116
<code>HCOPY:SSD</code>	1116
<code>HCOPY:WBKG</code>	1117
<code>HCOPY:DATA?</code>	1117

HCOPY:DESTination<m> <medium>

Selects the output medium: file or clipboard.

Suffix:

<m> 1..2
 Selects the output configuration.

Parameters:

<medium> MMEM | CLIPBOARD
 MMEM: saves image to a file.
 CLIPBOARD: directs the image to the clipboard.
 *RST: MMEM

Usage: Asynchronous command

Manual operation: See "<Folder>" on page 473

MMEMory:NAME <FileName>

Defines the filename for a screenshot that is stored to a file.

Parameters:

<FileName> String parameter specifying path and filename of the screenshot.

Example: See [Section 18.5.3, "Saving screenshots to file"](#), on page 916.

Usage: SCPI confirmed
Asynchronous command

Manual operation: See ["File name base"](#) on page 473

HCOPy:DEVIce<m>:LANGuage <FileFormat>

Defines the file format for output of the screenshot to file.

To set the output to file, use [HCOPy:DESTination<m>](#) with parameter `MMEM`.

Suffix:

<m> 1..2
Selects the output configuration.

Parameters:

<FileFormat> PNG | JPG
*RST: PNG

Usage: Asynchronous command

Manual operation: See ["File extension"](#) on page 473

HCOPy:DEVIce<m>:INVerse <InverseColor>

Inverts the colors of the output, i.e. a dark waveform is shown on a white background.

See also [HCOPy:WBKG](#) and [White background](#).

Suffix:

<m> 1..2
Selects the output configuration.

Parameters:

<InverseColor> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Inverse color"](#) on page 472

HCOPy:IMMEDIATE<m>:NEXT

Starts the output of the next display image, depending on the [HCOPy:DESTination<m>](#) destination setting.

If the screenshot is saved to a file, the file name used in the last saving process is automatically counted up to the next unused name. To define the file name, use `MMEMoRY:NAME`.

Suffix:

`<m>` 1..2
Selects the output configuration.

Example: See [Section 18.5.3, "Saving screenshots to file"](#), on page 916.

Usage: Asynchronous command

Manual operation: See ["Save"](#) on page 473

HCOPy:IMMEDIATE<m>

Starts the immediate output of the display image, depending on the `HCOPy:DESTINATION<m>` destination setting.

To define the file name, use `MMEMoRY:NAME`. Existing files are overwritten by the `HCOP:IMM` command.

To get a correct screenshot of the diagrams, results, and dialog boxes, turn on the display using `SYSTem:DISPlay:UPDate`.

Suffix:

`<m>` 1..2
Selects the output configuration.

Example: See [Section 18.5.3, "Saving screenshots to file"](#), on page 916.

Usage: Event
Asynchronous command

Manual operation: See ["Save"](#) on page 473

HCOPy:ISBA <IncludeSignBarScpi>

If enabled, the screenshot shows the signal bar below the diagram area.

Parameters:

`<IncludeSignBarScpi>` OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Include signal bar"](#) on page 472

HCOPy:SSD <ShowSetupDialog>

If enabled, the currently open dialog box is included in the screenshot.

Parameters:

`<ShowSetupDialog>` OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Show setup dialog"](#) on page 472

HCOPY:WBKG <WhiteBackground>

Inverts the background color, so you can picture waveforms with normal waveform colors on white background.

If both `HCOPY:WBKG` and `HCOPY:DEVICE<m>:INVERSE` are ON, the instrument inverts the background twice, and it appears black.

Parameters:

<WhiteBackground> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["White background"](#) on page 472

HCOPY:DATA?

Creates a PNG screenshot and returns the data of the image file in a binary data stream. When receiving the data, write them into a PNG file which you can open later.

Usage: Query only
Asynchronous command

18.14 Automatic measurements

This section contains all remote commands to set up automatic measurements and to analyze the measurement results.

Measurement suffix <mg>

The suffix <mg> indicates the number of the measurement for which the command takes effect.

18.14.1 General settings

MEASurement<mg>:ACTive	1118
MEASurement<mg>:COUNT?	1118
MEASurement<mg>[:ENABle]	1118
MEASurement<mg>:SOURce	1118
MEASurement<mg>:FSRC	1119
MEASurement<mg>:SSRC	1119
MEASurement<mg>:MAIN	1120
MEASurement<mg>:GATE	1121

MEASurement<mg>:DISPlay:RESults.....	1121
MEASurement<mg>:DISPlay:REFLevel<rl>:LEVels.....	1121
MEASurement<mg>:ENVSelect.....	1121

MEASurement<mg>:ACTive <First>

Activates or deactivates the indicated measurement.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<First> OFF | ON

Usage: Asynchronous command

Manual operation: See ["Add"](#) on page 272

MEASurement<mg>:COUNT?

Returns the maximum number of measurements, which is the maximum value for the <mg> suffix.

Suffix:

<mg> Irrelevant, omit the suffix.

Return values:

<Count> Maximum number of measurements

Usage: Query only
Asynchronous command

MEASurement<mg>[:ENABLE] <First>

Selects the indicated measurement.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<First> OFF | ON

Usage: Asynchronous command

Manual operation: See ["Add"](#) on page 272

MEASurement<mg>:SOURce <SignalSource>,[<SignalSource2>]

Sets the source of the measurement.

The source must fit the selected measurement type. For example, histogram measurements require a waveform histogram as source, and protocol measurements require a serial bus.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<SignalSource> NONE | C1 | C2 | ... | C8 | D0 | D1 | D2 | ... | D14 | D15 | M1 | M2 | ... | M8 | TRK1 | TRK2 | TRK3 | ... | TRK24 | HWAVeform1 | HWAVeform2 | ... | HWAVeform8 | PA1QPOWER | PA2QPOWER | ... | PA6QPOWER | PA1HPOWER1 | PA2HPOWER1 | ... | PA6HPOWER1 | PA1SPOWER | PA2SPOWER | ... | PA6SPOWER | PA1SOA | PA2SOA | ... | PA6SOA | PA1IPOWER | PA2IPOWER | ... | PA6IPOWER | PA1OPOWER1 | PA2OPOWER1 | ... | PA6OPOWER1 | PA1OPOWER2 | PA2OPOWER2 | ... | PA6OPOWER2 | PA1OPOWER3 | PA2OPOWER3 | ... | PA6OPOWER3 | PTHREE1HPOWER1 | PTHREE2HPOWER1 | ... | PTHREE6HPOWER1 | PTHREE1HPOWER2 | PTHREE2HPOWER2 | ... | PTHREE6HPOWER2 | PTHREE1HPOWER3 | PTHREE2HPOWER3 | ... | PTHREE6HPOWER3 | PTHREE1HTPOWER | PTHREE2HTPOWER | ... | PTHREE6HTPOWER | PTHREE1QPOWER1 | PTHREE2QPOWER1 | ... | PTHREE6QPOWER1 | PTHREE1QPOWER2 | PTHREE2QPOWER2 | ... | PTHREE6QPOWER2 | PTHREE1QPOWER3 | PTHREE2QPOWER3 | ... | PTHREE6QPOWER3 | PTHREE1QTPOWER | PTHREE2QTPOWER | ... | PTHREE6QTPOWER | PA1TOPOWER | PA2TOPOWER | ... | PA6TOPOWER | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 11)

<SignalSource2> Same as <SignalSource>

Usage: Asynchronous command**Manual operation:** See "Source" on page 271**MEASurement<mg>:FSRC <Source>**

Defines the first measurement source.

The command is an alternative to [MEASurement<mg>:SOURce](#).**Suffix:**

<mg> 1 to 24, index of the measurement

Parameters:<Source> See [MEASurement<mg>:SOURce](#) on page 1118.**Usage:** Asynchronous command**MEASurement<mg>:SSRC <Source2>**

Defines the second measurement source.

The command is an alternative to [MEASurement<mg>:SOURce](#).

Suffix:
 <mg> 1 to 24, index of the measurement

Parameters:
 <Source2> See [MEASurement<mg>:SOURce](#) on page 1118.

Usage: Asynchronous command

Manual operation: See ["Source 2, Clock source"](#) on page 283

MEASurement<mg>:MAIN <MeasType>

Defines the measurement type that is assigned to the indicated measurement. To query the result, use [MEASurement<mg>:RESult\[:ACTual\]?](#) on page 1137.

Suffix:
 <mg> 1 to 24, index of the measurement

Parameters:

<MeasType>

Amplitude/time measurements

HIGH | LOW | AMPLitude | MAXimum | MINimum | PDELta | MEAN | RMS | STDDev | CREST | POVershoot | NOVershoot | AREA | RTIME | FTIME | PPULse | NPULse | PERiod | FREQuency | PDCYcle | NDCYcle | CYCarea | CYCMean | CYCRms | CYCStddev | CYCCrest | CAMPLitude | CMAXimum | CMINimum | CPDelta | PULCnt | DELay | PHASe | BWIDth | EDGe-count | SETup | HOLD | SHT | SHR | DTOTrigger | SLERising | SLEFalling

Jitter measurements

CCJitter | NCJitter | CCWidth | CCDutycycle | TIE | UINterval | DRATe | SKWDelay | SKWPhase
 Require option R&S MXO5C-K12.

Measurements on waveform histograms

WCOunt | HSAMples | HPEak | PEAK | UPEakvalue | LPEakvalue | HMAXimum | HMINimum | MEDian | MAXMin | HMEan | HSTDdev | M1STddev | M2STddev | M3STddev | MKPositive | MKNegative

Measurements for serial protocols

F2F | T2F | F2T | FLDValue | MBitRate | SBitRate | BIDLe | GAP | FCNT | FEC | FER | CFER | RSERr
 Require option R&S MXO5C-K500.

Eye measurements

ERPercent | ERDB | EHEight | EWIDth | ETOP | EBASe | QFACtor | RMSNoise | SNRatio | DCDistortion | ERTIME | EFTIME | EBRate | EAMPLitude | PPJitter | STDJitter | RMSJitter | CPPercent
 Require option R&S MXO5C-K136.

Usage: Asynchronous command

Manual operation: See ["Select measurements"](#) on page 272

MEASurement<mg>:GATE <Gate>

Sets the gate of the indicated measurement. Enable a gate before you assign a measurement to it ([GATE<g>:ENABLe](#) =ON).

The query returns 0, if no gate is assigned.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<Gate> Number of the gate to be used

Usage:

Asynchronous command

Manual operation: See "[Gate](#)" on page 274

MEASurement<mg>:DISPlay:RESults <ResultLines>

Enables the measurement annotations for the selected measurement. These annotations are, for example, periods, maximum and minimum values, relevant reference levels, and more.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<ResultLines> OFF | ON

*RST: OFF

Usage:

Asynchronous command

Manual operation: See "[Display result lines](#)" on page 281

MEASurement<mg>:DISPlay:REFLevel<rl>:LEVelS <DisplayLevels>

Displays the reference levels of the indicated measurement.

Suffix:

<mg> 1 to 24, index of the measurement

<rl>

Irrelevant, omit the suffix.

Reference level set is assigned to the measurement.

Parameters:

<DisplayLevels> OFF | ON

*RST: OFF

Usage:

Asynchronous command

MEASurement<mg>:ENVSelect <EnvelopeCurve>

Relevant only for measurements on envelope waveforms. It selects the envelope to be used for measurement.

Prerequisites:

- `ACquire:TYPE` is set to `ENVELOpe`.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<EnvelopeCurve> MIN | MAX | BOTH

MIN

Measures on the lower envelope.

MAX

Measures on the upper envelope.

BOTH

The envelope is ignored, and the waveform is measured as usual.

*RST: BOTH

Usage:

Asynchronous command

Manual operation: See "[Envelope](#)" on page 281

18.14.2 Settings for amplitude/time measurements

MEASurement<mg>:AMPTime:CSLOpe	1122
MEASurement<mg>:AMPTime:ESLOpe	1123
MEASurement<mg>:AMPTime:PTCount	1123
MEASurement<mg>:AMPTime:PSLOpe	1123
MEASurement<mg>:AMPTime:DELaY<n>:DIRectiOn	1124
MEASurement<mg>:AMPTime:DTOTriGger<n>:SLOPe	1124
MEASurement<mg>:AMPTime:DELaY<n>:SLOPe	1124
MEASurement<mg>:AMPTime:PHASe:UNIT	1125
MEASurement<mg>:REFLevel<rl>:REFerence	1125

MEASurement<mg>:AMPTime:CSLOpe <SetHoldClkSlp>

Sets the edge of the clock from which the setup and hold times are measured.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<SetHoldClkSlp> POSitive | NEGative | EITHer

*RST: POSitive

Usage:

Asynchronous command

Manual operation: See "[Clock slope](#)" on page 283

MEASurement<mg>:AMPTime:ESLope <EdgesSlope>

Sets the edge direction to be counted: rising edges, falling edges, or both. The setting is only relevant for edge count measurement [MEASurement<mg>:MAIN](#) is set to [EDGecount](#).

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<EdgesSlope> POSitive | NEGative | EITHer
*RST: POSitive

Usage: Asynchronous command

Manual operation: See ["Edges slope"](#) on page 282

MEASurement<mg>:AMPTime:PTCount <PulseCount>

Sets the number of positive pulses for the pulse train measurement. It measures the duration of N positive pulses from the rising edge of the first pulse to the falling edge of the N-th pulse.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<PulseCount> Range: 1 to 2147483647
Increment: 1
*RST: 1

Usage: Asynchronous command

Manual operation: See ["Pulse count"](#) on page 281

MEASurement<mg>:AMPTime:PSLope <PulsesSlope>

Sets the first slope of the pulses to be counted. The setting is only relevant for pulse count and pulse train measurements ([MEASurement<mg>:MAIN](#) is set to [PULCnt](#) or [PULSetrain](#)).

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<PulsesSlope> POSitive | NEGative | EITHer
*RST: POSitive

Usage: Asynchronous command

Manual operation: See ["Pulse slope"](#) on page 281

MEASurement<mg>:AMPTime:DElay<n>:DIRection <EdgeCountDir>

Selects the direction for counting slopes for each source: from the beginning of the waveform, or from the end.

Suffix:

<mg> 1 to 24, index of the measurement

<n> 1..2
Selects the source number.

Parameters:

<EdgeCountDir> FRFI | FRLA
FRFI - FRom FIrst, counting starts with the first edge of the waveform.
FRLA - FRom LAsT, counting starts with the last edge of the waveform.
*RST: FRFI

Usage: Asynchronous command

Manual operation: See ["Direction"](#) on page 284

MEASurement<mg>:AMPTime:DTOTrigger<n>:SLOPe <DlyTrigSlp>

Sets the edge direction to be used for delay measurement.

Suffix:

<mg> 1 to 24, index of the measurement

<n> 1..2
Selects the source number.

Parameters:

<DlyTrigSlp> POSitive | NEGative | EITHer
*RST: POSitive

Usage: Asynchronous command

Manual operation: See ["Delay to trigger measurement settings"](#) on page 284

MEASurement<mg>:AMPTime:DElay<n>:SLOPe <Slope>

Sets the edge of each source, between which the delay is measured.

Suffix:

<mg> 1 to 24, index of the measurement

<n> 1..2
Selects the source number.

Parameters:

<Slope> POSitive | NEGative | EITHer
*RST: POSitive

Usage: Asynchronous command

Manual operation: See ["Slope"](#) on page 283

MEASurement<mg>:AMPTime:PHASe:UNIT <PhaseMode>

Selects the unit of the phase: degrees or radians.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<PhaseMode> DEGRees | RADians

*RST: DEGRees

Usage: Asynchronous command

Manual operation: See ["Phase unit"](#) on page 284

MEASurement<mg>:REFLevel<rl>:REFerence <RefLevSet>

Selects the set of reference levels that is used for the measurement and for the indicated measurement source. Each source of the measurement can have its own reference level set.

Suffix:

<mg> 1 to 24, index of the measurement

<rl> 1..2

Measurement source, to which the reference level set is applied. For most measurements, one source is needed. For delay measurements, for example, two measurement sources are required, and each source can have its own reference levels.

Parameters:

<RefLevSet> Number of the reference level set. Define the reference level set before you use it.

Example:

```
MEASurement1:MAIN DELay
MEASurement1:SOURce C1,C2
MEASurement1:REFLevel1:REFerence 1
MEASurement1:REFLevel2:REFerence 2
```

Measurement 1 is a delay measurement on channel 1 and channel 2. C1 is the first source and uses reference level set 1 (RL1). C2 is the second source and uses reference level set 2 (RL2).

Usage: Asynchronous command

Manual operation: See ["Reference levels"](#) on page 273

18.14.3 Settings for jitter measurements

Jitter measurements require option R&S MXO5C-K12.

MEASurement<mg>:JITTer:NCYCles	1126
MEASurement<mg>:JITTer:POLarity	1126
MEASurement<mg>:JITTer:REFLevel<rl>	1126
MEASurement<mg>:JITTer:RELPolarity	1127
MEASurement<mg>:JITTer:SLOPe	1128
MEASurement<mg>:JITTer:TREF	1128
MEASurement<mg>:JITTer:UNIT	1129

MEASurement<mg>:JITTer:NCYCles <NumberCycles>

Sets the number of periods (cycles) that are accumulated to measure the N-cycle jitter.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<NumberCycles> Range: 1 to 4294967295
Increment: 1
*RST: 2

Usage: Asynchronous command

Manual operation: See ["Number of cycles"](#) on page 290

MEASurement<mg>:JITTer:POLarity <Polarity>

For cycle-cycle width and the cycle-cycle duty cycle measurements, the command sets the polarity of pulses for which the pulse width is measured: POSitive or NEGative.

[MEASurement<mg>:MAIN](#) is set to measurements CCWidth | CCDutycycle.

For skew delay and skew phase measurements, the command sets the edge of the first waveform from which the measurements starts: POSitive, NEGative or EITHer.

[MEASurement<mg>:MAIN](#) is set to measurements SKWDelay | SKWPhase.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<Polarity> POSitive | NEGative | EITHer
*RST: POSitive

Usage: Asynchronous command

Manual operation: See ["Pulse polarity"](#) on page 290

MEASurement<mg>:JITTer:REFLevel<rl> <ReferenceLevel>

Selects the reference level that is used for the measurement and for the indicated measurement source. Each source of the measurement can have its own reference level .

Suffix:

<mg> 1 to 24, index of the measurement

<rl> 1..2

Measurement source, to which the reference level set is applied. For most measurements, one source is needed. For delay measurements, for example, two measurement sources are required, and each source can have its own reference levels.

Parameters:

<ReferenceLevel> UPPer | MIDDle | LOWer

*RST: MIDDle

Example:

```
MEASurement1:MAIN SKWDelay
MEASurement1:SOURce C1,C2
MEASurement1:JITTer:REFLevel1 MIDDle
MEASurement1:JITTer:REFLevel2 UPPer
```

Measurement 1 is a skew delay measurement on channel 1 and channel 2. C1 is the first source and uses the middle reference level. C2 is the second source and uses the upper reference level.

Usage: Asynchronous command

Manual operation: See ["Reference level"](#) on page 290

MEASurement<mg>:JITTer:RELPolarity <RelPolarity>

Sets the edge of the second waveform relative to the first waveform.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<RelPolarity> MATChing | INVerse

MATCHing

Measures from positive to positive edge or from negative to negative edge.

INVerse

Measures from positive to negative edge or from negative to positive edge.

*RST: MATChing

Usage: Asynchronous command

Manual operation: See ["Relative polarity"](#) on page 290

MEASurement<mg>:JITTer:SLOPe <Slope>

For cycle-cycle jitter, N-cycle jitter, and cycle-cycle duty cycle measurements, the setting selects the slope at which the periods and thus the jitter is measured: FIRSt, POSitive, NEGative or EITHER. [MEASurement<mg>:MAIN](#) is set to measurements CCJitter | NCJitter | CCDutycycle.

For time-interval error measurements, the command sets the edges of the data signal that are used for measurements: POSitive, NEGative or EITHER. [MEASurement<mg>:MAIN](#) is set to TIE.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<Slope> FIRSt | POSitive | NEGative | EITHER

*RST: FIRSt

<Slope> FIRSt | POSitive | NEGative | EITHER

FIRSt

Measures the period from the first edge that is found, no matter of its direction.

POSitive

Measures the period at positive going edges.

NEGative

Measures the period at negative going edges.

EITHER

Measures the period at both positive and negative going edges. This option is useful, for example, to check the clock stability of a double data rate clock.

*RST: FIRSt

Usage: Asynchronous command

Manual operation: See ["Cycle begin, Slope"](#) on page 289

MEASurement<mg>:JITTer:TREF <TimingReference>

Selects the timing reference, which is one of the available clock configurations. The timing reference must be defined before it can be used.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<TimingReference> Range: 1 to 4

Usage: Asynchronous command

Manual operation: See ["Timing reference"](#) on page 292

MEASurement<mg>:JITTer:UNIT <Unit>

Sets the unit for data rate measurements.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<Unit> BIT_S | HZ
*RST: BIT_S

Usage: Asynchronous command

Manual operation: See "Unit" on page 292

18.14.4 Default settings for eye measurements

Measurement defaults are available for eye measurements, which require option R&S MXO5C-K136.

MDEFaults:SETTings<m>:ENABLE <Item>

Adds or removes the specified default measurement configuration.

Suffix:

<m> 1 to 8, index of the default measurement configuration

Parameters:

<Item> OFF | ON

Usage: Asynchronous command

MDEFaults:SETTings<m>:EYE:ALGorithm <MeasLevAlgorithm>

Selects the algorithm, which defines how to compute the top and base levels and the corresponding sigma values.

Suffix:

<m> 1 to 8, index of the default measurement configuration

Parameters:

<MeasLevAlgorithm> MEAN | PEAK | INNPeak | OUTPeak

MEAN

Mean value of the histogram. The Sigma value is the standard deviation of the histogram.

PEAK

Maximum peak of the histogram. Only values corresponding to this peak are used to compute sigma.

INNPeak

Inner peak of the histogram. Only values corresponding to this peak are used to compute sigma.

OUTPeak

Outer peak of the histogram. Only values corresponding to this peak are used to compute sigma.

*RST: MEAN

Usage: Asynchronous command

Manual operation: See ["Algorithm"](#) on page 295

MDEFaults:SETTings<m>:EYE:RELative:STARt <MeasWindowStart>

Defines the global start time for the eye measurements.

Suffix:

<m> 1 to 8, index of the default measurement configuration

Parameters:

<MeasWindowStart> Start time of the window in % of the difference of the eye crossings. Tcrossing1 relates to 0 %, and Tcrossing2 relates to 100 %.

Range: 1 to 99

Increment: 1

*RST: 40

Default unit: %

Usage: Asynchronous command

Manual operation: See ["Start, Stop"](#) on page 295

MDEFaults:SETTings<m>:EYE:RELative:STOP <RelTimeStpLevMeasWind>

Defines the global stop time for the eye measurements.

Suffix:

<m> 1 to 8, index of the default measurement configuration

Parameters:

<RelTimeStpLevMeasWind> Stop time of the window in % of the difference of the eye crossings. Tcrossing1 relates to 0 %, and Tcrossing2 relates to 100 %.

Range: 1 to 99

Increment: 1

*RST: 60

Default unit: %

Usage: Asynchronous command

Manual operation: See ["Start, Stop"](#) on page 295

MDEFaults:SETTings<m>:EYE:THReshold <MeasLevThres>

Sets the threshold that is used to separate peaks. Two peaks are separated if they are split by a valley of height *Threshold * Maximal_histogram_value*.

Suffix:
 <m> 1 to 8, index of the default measurement configuration

Parameters:
 <MeasLevThres> Range: 1 to 99
 Increment: 1
 *RST: 50
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 296

18.14.5 Settings for eye measurements

Eye measurements require option R&S MXO5C-K136.

MEASurement<mg>:EYE:ABSolute:STARt <AbsoluteStart>

Sets the absolute start value for the selected algorithm for eye height and eye width measurements.

Suffix:
 <mg> 1 to 24, index of the measurement

Parameters:
 <AbsoluteStart> Range: -1E+26 to 1E+26
 Increment: 0.1
 *RST: -2.5E-09
 Default unit: s

Usage: Asynchronous command

Manual operation: See ["Start, Stop \(for eye height, eye width\)"](#) on page 299

MEASurement<mg>:EYE:ABSolute:STOP <AbsoluteStop>

Sets the absolute stop value for the selected algorithm for eye height and eye width measurements.

Suffix:
 <mg> 1 to 24, index of the measurement

Parameters:
 <AbsoluteStop> Range: -1E+26 to 1E+26
 Increment: 0.1
 *RST: 2.5E-09
 Default unit: s

Usage: Asynchronous command

Manual operation: See ["Start, Stop \(for eye height, eye width\)"](#) on page 299

MEASurement<mg>:EYE:ALGorithm <Algorithm>

Selects the algorithm for the measurement of the eye height and eye width.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<Algorithm> ACTHeight | MAXHeight | ACTWidth | AWMWindow |
MAXWidth | TSiGma

TSiGma

Three sigma: The eye height is measured with the settings defined with MDEFaults:Settings:EYE commands. The eye width is measured at the crossing level.

ACTHeight

The actual height is the vertical distance between the top and the bottom of the eye opening at the sampling point. The default window is 40% - 60% of the eye period. Specific start and stop values are used for calculation.

ACTWidth

The eye width is measured at the crossing level. Refers to "Crossing level" in the GUI.

MAXHeight

The maximum height is the theoretical maximum vertical distance between the highest possible 1 level and the lowest possible 0 level. The default measurement window is 40% - 60% of the eye period. Specific start and stop values are used for maximum calculation.

MAXWidth

The maximum width of an eye diagram is the maximum horizontal distance between the points where the ideal eye opening crosses the decision threshold level. Specific start and stop values are used for maximum calculation.

AWMWindow

The eye width is measured as the horizontal distance between the points where the eye opening crosses the threshold level. Specific start and stop values are used for calculation.

*RST: TSiGma

Usage:

Asynchronous command

Manual operation: See ["Algorithm \(for eye height, eye width\)"](#) on page 298

MEASurement<mg>:EYE:DEFSettings <CommonDefaults>

Selects the default measurement configuration.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<CommonDefaults> Number of the default measurement configuration to be used.

Usage:

Asynchronous command

Manual operation:

See ["Default settings"](#) on page 294

MEASurement<mg>:EYE:LEVel <RelativeLevel>

Defines the relative level for the jitter measurements on eye diagrams if [MEASurement<mg>:EYE:USELevel](#) on page 1134 is ON. The setting also defines the level for duty cycle distortion measurement.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<RelativeLevel> Range: 1 to 99
Increment: 1
*RST: 50
Default unit: %

Usage:

Asynchronous command

Manual operation:

See ["Level \(jitter, duty cycle\)"](#) on page 299

MEASurement<mg>:EYE:MODE <Mode>

Selects between absolute and relative values for the eye measurement-specific start and stop values.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<Mode> ABS | REL
*RST: REL

Usage:

Asynchronous command

Manual operation:

See ["Mode \(for eye height, eye width\)"](#) on page 298

MEASurement<mg>:EYE:RELative:STARt <RelativeStart>

Sets the relative start value for the selected algorithm of eye height and eye width measurements.

For rise time and fall time eye measurements, the command sets the offset before the first eye crossing (local start level). Only values inside the specified horizontal range are considered for the measurements.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<RelativeStart> The value refers to one unit interval for rise and fall time measurements.
 For eye width, the value refers to the eye top and base levels.
 For eye height, the value refers to the eye crossings.
 Range: 1 to 99
 Increment: 1
 *RST: 40
 Default unit: %

Usage:

Asynchronous command

Manual operation: See ["Start, Stop \(eye height and width, rise/fall time\)"](#) on page 299

MEASurement<mg>:EYE:RELative:STOP <RelativeStop>

Sets the relative stop value for the selected algorithm of eye height and eye width measurements.

For rise time and fall time eye measurements, the command sets the offset after the first eye crossing (local stop level). Only values inside the specified horizontal range are considered for the measurements.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<RelativeStop> The value refers to one unit interval for rise and fall time measurements.
 For eye width, the value refers to the eye top and base levels.
 For eye height, the value refers to the eye crossings.
 Range: 1 to 99
 Increment: 1
 *RST: 60
 Default unit: %

Usage:

Asynchronous command

Manual operation: See ["Start, Stop \(eye height and width, rise/fall time\)"](#) on page 299

MEASurement<mg>:EYE:USELevel <UseLevel>

If ON, you can define a user-defined level for the jitter measurements on eye diagrams with [MEASurement<mg>:EYE:LEVel](#).

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<UseLevel> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Use level \(jitter\)"](#) on page 299

18.14.6 Settings for protocol measurements

Protocol measurements require option R&S MXO5C-K500, and at least one serial protocol option.

MEASurement<mg>:PROTocol:FNAME	1135
MEASurement<mg>:PROTocol:FDName	1135
MEASurement<mg>:PROTocol:FDValue	1135
MEASurement<mg>:PROTocol:F2Name	1136
MEASurement<mg>:PROTocol:FD2Name	1136
MEASurement<mg>:PROTocol:FD2Value	1136

MEASurement<mg>:PROTocol:FNAME <FrameName>

Sets or queries the name of the frame or the frame type, at which the oscilloscope executes or starts the measurement.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<FrameName>

Usage: Asynchronous command

Manual operation: See ["Frame Type"](#) on page 302

MEASurement<mg>:PROTocol:FDName <FieldName>

Sets or queries the name of the field or the field type, at which the oscilloscope executes or starts the measurement.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<FieldName>

Usage: Asynchronous command

Manual operation: See ["Field Type"](#) on page 303

MEASurement<mg>:PROTocol:FDValue <FieldValue>

Sets or queries the one or more values of the field, at which the oscilloscope executes or starts the measurement.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<FieldValue> List of comma-separated values

Usage:

Asynchronous command

Manual operation:

See ["Field Value"](#) on page 303

MEASurement<mg>:PROTocol:F2Name <Frame2Name>

Sets or queries the name of the frame or the frame type, at which the oscilloscope ends the measurement in a "From" - "To" condition.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<Frame2Name>

Usage:

Asynchronous command

Manual operation:

See ["Frame Type"](#) on page 303

MEASurement<mg>:PROTocol:FD2Name <Field2Name>

Sets or queries the name of the field or the field type, at which the oscilloscope ends the measurement in a "From" - "To" condition.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<Field2Name>

Usage:

Asynchronous command

Manual operation:

See ["Field Type"](#) on page 303

MEASurement<mg>:PROTocol:FD2Value <Field2Value>

Sets or queries the one or more values of the field, at which the oscilloscope ends the measurement in a "From" - "To" condition.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<Field2Value> List of comma-separated values

Usage:

Asynchronous command

Manual operation:

See ["Field Value"](#) on page 303

18.14.7 Results

MEASurement<mg>:RESult[:ACTual]?	1137
MEASurement<mg>:RESult:AVG?	1137
MEASurement<mg>:RESult:EVTCount?	1137
MEASurement<mg>:RESult:NPEak?	1137
MEASurement<mg>:RESult:PPEak?	1137
MEASurement<mg>:RESult:RMS?	1137
MEASurement<mg>:RESult:WFMCCount?	1137
MEASurement<mg>:RESult:RSTDdev?	1137
MEASurement<mg>:RESult:STDDev?	1137
MEASurement<mg>:RESult:START?	1138
MEASurement<mg>:RESult:STOP?	1138
MEASurement<mg>:RESult:EVENTs:COUNT?	1138
MEASurement<mg>:RESult:EVENTs:START?	1138
MEASurement<mg>:RESult:EVENTs:STOP?	1139
MEASurement<mg>:RESult:EVENTs:VALue?	1139

MEASurement<mg>:RESult[:ACTual]?
MEASurement<mg>:RESult:AVG?
MEASurement<mg>:RESult:EVTCount?
MEASurement<mg>:RESult:NPEak?
MEASurement<mg>:RESult:PPEak?
MEASurement<mg>:RESult:RMS?
MEASurement<mg>:RESult:WFMCCount?
MEASurement<mg>:RESult:RSTDdev?
MEASurement<mg>:RESult:STDDev?

Return the statistic results of the specified measurement. The measurement type is defined with **MEASurement<mg>:MAIN**.

- [:ACTual]: current measurement result
- AVG: arithmetic mean of the measurement results
- EVTCount: number of measurement results in the measurement
- NPEak: negative peak value of the measurement results
- PPEak: positive peak value of the measurement results
- RMS: RMS value of the measurement results
- STDDev: standard deviation of the measurement results
- RSTDdev: relative standard deviation ($STDDev / AVG$)
- WFMCCount: number of measured waveforms

Suffix:

<mg> 1 to 24, index of the measurement

Return values:

<Result> Numeric result value

Usage:

Query only
Asynchronous command

MEASurement<mg>:RESult:START?**MEASurement<mg>:RESult:STOP?**

Return the start and stop times of the specified measurement. The parameter defines the measurement. If no parameter is specified, the result of the main measurement is returned. The main measurement is defined using [MEASurement<mg>:MAIN](#).

Suffix:

<mg> 1 to 24, index of the measurement

Return values:

<Stop> Range: -1E+26 to 1E+26
Increment: 0
*RST: 0

Usage:

Query only
Asynchronous command

MEASurement<mg>:RESult:EVENTs:COUNT?

Returns the number of measured events in one acquisition.

The command is relevant for measurements of all events, see [MEASurement<mg>:MULTiple](#).

Suffix:

<mg> 1 to 24, index of the measurement

Return values:

<Count> Number of events

Usage:

Query only
Asynchronous command

MEASurement<mg>:RESult:EVENTs:START? <EventIndex>

Returns the start time of the indicated measured event.

The command is relevant for measurements of all events, see [MEASurement<mg>:MULTiple](#).

Suffix:

<mg> 1 to 24, index of the measurement

Setting parameters:

<EventIndex> Index number of the measured event.

Return values:

<EventStart> Range: -1E+26 to 1E+26
Increment: 0
*RST: 0

Usage:

Query only
Asynchronous command

MEASurement<mg>:RESult:EVENTs:STOP? <EventIndex>

Returns the end time of the indicated measured event.

The command is relevant for measurements of all events, see [MEASurement<mg>:MULTiple](#).

Suffix:

<mg> 1 to 24, index of the measurement

Setting parameters:

<EventIndex> Index number of the measured event.

Return values:

<EventStop> Range: -1E+26 to 1E+26
Increment: 0
*RST: 0

Usage:

Query only
Asynchronous command

MEASurement<mg>:RESult:EVENTs:VALue? <MeasResEvtIdx>

Returns the measured value of the indicated measured event.

The command is relevant for measurements of all events, see [MEASurement<mg>:MULTiple](#).

Suffix:

<mg> 1 to 24, index of the measurement

Setting parameters:

<EventIndex> Index number of the measured event.

Return values:

<EventValue> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

18.14.8 Statistics

MEASurement<mg>:STATistics:ARESet	1140
MEASurement<mg>:STATistics:RESet	1140
MEASurement<mg>:CLEar	1140
MEASurement<mg>:STATistics[:ENABle]	1140
MEASurement<mg>:MULTiple	1140
MEASurement<mg>:MNOMeas	1141

MEASurement<mg>:STATistics:ARESet

Resets the statistics for all measurements.

Suffix:

<mg> Irrelevant, omit the suffix.

Usage:

Setting only
Asynchronous command

Manual operation: See ["Clear results"](#) on page 307

MEASurement<mg>:STATistics:RESet**MEASurement<mg>:CLEar**

Deletes the results of the specified measurement.

Suffix:

<mg> 1 to 24, index of the measurement

Usage:

Setting only
Asynchronous command

Manual operation: See ["Clear results"](#) on page 307

MEASurement<mg>:STATistics[:ENABLE] <GlobalEnable>

Enables statistics calculation for all measurements.

Suffix:

<mg> Irrelevant, omit the suffix.

Parameters:

<GlobalEnable> OFF | ON
*RST: OFF

Usage:

Asynchronous command

Manual operation: See ["Statistics"](#) on page 307

MEASurement<mg>:MULTiple <GlobalMeassAll>

If ON, the measurement is performed repeatedly if the measured parameter occurs several times inside the acquisition or defined gate. All results are included in evaluation, e.g. in statistics. To set the number of results to be considered, use [MEASurement<mg>:MNOMeas](#).

Suffix:

<mg> Irrelevant, omit the suffix.

Parameters:

<GlobalMeassAll> OFF | ON
*RST: OFF

Usage:

Asynchronous command

Manual operation: See ["Measure all events"](#) on page 307

MEASurement<mg>:MNOMeas <MaxMeasPerAcq>

Sets the maximum number of measurements per acquisition if [MEASurement<mg>:MULTiple](#) is on. The setting affects all measurements.

Suffix:

<mg> Irrelevant, omit the suffix.

Parameters:

<MaxMeasPerAcq> Range: 2 to 1E6
Increment: 1
*RST: 1E6

Usage: Asynchronous command

Manual operation: See ["Max. No. of events"](#) on page 307

18.14.9 Tracks

MEASurement<mg>:TRACk[:STATe]	1141
MEASurement<mg>:TRACk:AUTO	1141
MEASurement<mg>:TRACk:CONTiuous	1142
MEASurement<mg>:TRACk:OFFSet	1142
MEASurement<mg>:TRACk:SCALe	1142
MEASurement<mg>:TRACk:DATA:HEADer?	1143
MEASurement<mg>:TRACk:DATA[:VALues]?	1143

MEASurement<mg>:TRACk[:STATe] <State>

Enables or disables the track for the selected measurement.

Suffix:

<mg> 1 to 24, index of the measurement

Parameters:

<State> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["State"](#) on page 309

MEASurement<mg>:TRACk:AUTO

Sets the vertical scale and the offset of the track, so that the complete height of the diagram is used.

Suffix:

<mg> 1 to 24, index of the measurement

Usage: Event
Asynchronous command

Manual operation: See ["Fit to screen"](#) on page 309

MEASurement<mg>:TRACK:CONTiunous <AutoScale>

Performs an automatic scaling whenever the track does not fit in the diagram during the measurement period.

Suffix:
<mg> 1 to 24, index of the measurement

Parameters:
<AutoScale> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Auto scale"](#) on page 309

MEASurement<mg>:TRACK:OFFSet <VerticalOffset>

Sets or queries the offset of the track waveform.

If [MEASurement<mg>:TRACK:CONTiunous](#) is ON, use the command to query the current value.

If [MEASurement<mg>:TRACK:CONTiunous](#) is OFF, the command sets the offset.

Suffix:
<mg> 1 to 24, index of the measurement

Parameters:
<VerticalOffset> Range: -1E+26 to 1E+26
Increment: 1E-06
*RST: 0
Default unit: div

Usage: Asynchronous command

Manual operation: See ["Meas offset"](#) on page 309

MEASurement<mg>:TRACK:SCALE <VerticalScale>

Sets or queries the vertical scale of the track diagram.

If [MEASurement<mg>:TRACK:CONTiunous](#) is ON, use the command to query the current value.

If [MEASurement<mg>:TRACK:CONTiunous](#) is OFF, the command sets the scale.

Suffix:
<mg> 1 to 24, index of the measurement

Parameters:

<VerticalScale> Range: 1E-26 to 1E+26
 Increment: 1E-05
 *RST: 0.5
 Default unit: V/div

Usage: Asynchronous command

Manual operation: See ["Meas scale"](#) on page 309

MEASurement<mg>:TRACk:DATA:HEADer?

Returns the header of track data, the attributes of the waveform.

Suffix:

<mg> 1 to 24, index of the measurement

Return values:

<XStart> 1. header value: time of the first track value in s
 <XStop> 2. header value: time of the last track value in s
 <RecordLength> 3. header value: number of measured events = number of points in the track waveform
 <ValuesPerSample> 4. header value: number of values per sample. For tracks, the result is always 1.

Example:

```
MEAS1:TRAC:DATA:HEAD?
-1E-07,9.9800000000000001E-08,1000,1
```

Start time of the data is -1E-07 = -100 ns, and end time of the data is 9.9800000000000001E-08= 99.8 ns. The data stream has 1000 values with one value per sample, in other words, the track waveform has 1000 points.

Usage:

Query only
 Asynchronous command

MEASurement<mg>:TRACk:DATA[:VALues]? [<Offset>[,<Length>]]

Returns the data of the indicated track waveform for transmission from the instrument to the controlling computer. The data can be used in MATLAB, for example.

Without parameters, the complete waveform is retrieved. Using the offset and length parameters, data can be retrieved in smaller portions, which makes the command faster. If you send only one parameter, it is interpreted as offset, and the data is retrieved from offset to the end of the waveform.

Suffix:

<mg> 1 to 24, index of the measurement

Query parameters:

<Offset> Number of offset track points, which are ignored in the data transfer.

[<Length>]	Number of track points to be retrieved.
Return values:	
<Data>	List of values according to the format and content settings.
Usage:	Query only Asynchronous command

18.15 Cursor measurements

Some of the commands in the following section are asynchronous. An overlapping or asynchronous command does not automatically finish executing before the next command starts executing. If overlapping commands must be executed in a defined order, e.g. to avoid wrong measurement results, they must be serviced sequentially.

To prevent an overlapping execution of commands, one of the commands *OPC, *OPC? or *WAI can be used after the command or a command set.

For more information, see:

- www.rohde-schwarz.com/rc-via-scp, section "Command sequence and synchronization"
- [Cursor setup](#)..... 1144
- [Cursor results](#)..... 1153
- [Peak search using cursors](#)..... 1155
- [Cursor appearance](#)..... 1157

18.15.1 Cursor setup

CURSor<cu>:AOFF	1145
CURSor<cu>:COUNT?	1145
CURSor<cu>:STATe	1145
CURSor<cu>:FUNCTION	1145
CURSor<cu>:SMODE	1146
CURSor<cu>:SOURce	1146
CURSor<cu>:USSource	1147
CURSor<cu>:SSource	1148
CURSor<cu>:X1Position	1148
CURSor<cu>:X2Position	1148
CURSor<cu>:Y1Position	1149
CURSor<cu>:Y2Position	1150
CURSor<cu>:SSCReen	1150
CURSor<cu>:TRACking[:STATe]	1150
CURSor<cu>:LABel	1150
CURSor<cu>:HORizontal<n>:LABel	1151
CURSor<cu>:VERTical<n>:LABel	1151
CURSor<cu>:DISPlay:VALues	1151
CURSor<cu>:SIAD	1152
CURSor<cu>:XCOupling	1152

CURSor<cu>:YCOupling.....	1152
CURSor<cu>:X1ENvelope.....	1153
CURSor<cu>:X2ENvelope.....	1153

CURSor<cu>:AOFF

Switches all cursors off.

Suffix:

<cu> Irrelevant, omit the suffix.

Usage:

Setting only
Asynchronous command

CURSor<cu>:COUNT?

Returns the maximum number of cursor sets, which is the maximum value for the cursor suffix.

Suffix:

<cu> Irrelevant, omit the suffix.

Return values:

<Count> Maximum number of cursor sets

Usage:

Query only
Asynchronous command

CURSor<cu>:STATe <State>

Enables the selected cursor measurement.

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<State> OFF | ON
*RST: OFF

Usage:

Asynchronous command

Manual operation: See ["Show cursor"](#) on page 260

CURSor<cu>:FUNCTioN <Type>

Defines the cursor type to be used for the measurement.

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<Type> VERTical | HORizontal | PAIRed

HORizontal

A pair of horizontal cursor lines. Not available for measurements on multiple sources.

VERTical

A pair of vertical cursor lines. Not available for measurements on multiple sources.

PAIRed

Both vertical and horizontal cursor line pairs.

*RST: PAIRed

Usage: Asynchronous command

Manual operation: See ["Type"](#) on page 261

CURSor<cu>:SMODE <SourceMode>

Selects the number of sources that you want to measure.

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<SourceMode> SINGle | SECond | MSourc

SINGle

The cursor lines are set on one waveform. Select the source with [CURSor<cu>:SOURce](#).

SECond

The cursor lines are set on two waveforms. To set the second source, use [CURSor<cu>:SSource](#).

MSource

Multiple waveforms are selected to be measured with one cursor set. Activates [CURSor<cu>:TRACking\[:STATe\]](#) and sets [CURSor<cu>:FUNctio](#)n to PAIRed. Select the sources with [CURSor<cu>:SOURce](#).

*RST: SINGle

Usage: Asynchronous command

Manual operation: See ["Source mode"](#) on page 261

CURSor<cu>:SOURce <Signal>

Selects the cursor source or multiple sources, which are the waveforms to be measured. The query returns the waveforms sorted by category and number.

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<Signal> C1,C2,...,C8,D0,D1,D2,...,D15,M1,M2,M3,M4,M5,R1,R2,R3,R4, SPECMAXH1,SPECMINH1,SPECNORM1,SPECAVER1,SPEC-MAXH2,SPECMINH2,SPECNORM2,SPECAVER2,SPEC-MAXH3,SPECMINH3,SPECNORM3,SPECAVER3,SPEC-MAXH4,SPECMINH4,SPECNORM4,SPECAVER4, TRK1,TRK2,TRK3, ...,TRK24,PBUS1,PBUS2,PBUS3,PBUS4,X Y1,XY2,XY3,XY4 | PA1QPOWER,PA2QPOWER,...,PA6QPO-WER,PA1HPOWER1,PA2HPOWER1,...,PA6HPO-WER1,PA1SPOWER,PA2SPOWER,...,PA6SPO-WER,PA1SOA,PA2SOA,...,PA6SOA,PA1IPOWER,PA2IPO-WER,...,PA6IPOWER,PA1OPOWER1,PA2OPO-WER1,...,PA6OPOWER1,PA1OPOWER2,PA2OPOWER2,...,PA6OPOWER2,PA1OPOWER3,PA2OPOWER3,...,PA6OPO-WER3,PTHREE1HPOWER1,PTHREE2HPO-WER1,...,PTHREE6HPOWER1, PTHREE1HPO-WER2,PTHREE2HPOWER2,...,PTHREE6HPOWER2, PTHREE1HPOWER3,PTHREE2HPOWER3,...,THREE6HPO-WER3, PTHREE1HTPOWER,PTHREE2HTPOWER,...,PTHREE6HTPO-WER,PTHREE1QPOWER1,PTHREE2QPO-WER1,...,PTHREE6QPOWER1, PTHREE1QPO-WER2,PTHREE2QPOWER2,...,PTHREE6QPOWER2, PTHREE1QPOWER3,PTHREE2QPOWER3,...,PTHREE6QPO-WER3, PTHREE1QTPOWER,PTHREE2QTPOWER,...,PTHREE6QTP-OWER | PA1TOPOWER,PA2TOPOWER,...,PA6TOPOWER | O<n>C1,O<n>C2, ... ,O<n>C8 (<n> = 2 to 11) | EYE1 | EYE2 | ... | EYE8

Comma-separated list of waveforms.

Example:

```
CURSor:SOURce C1
```

Sets channel 1 as cursor source and changes [CURSor<cu>:SMODE](#) to SINGLE if MSOURCE was set before.

Example:

```
CURSor:SOURce C1,M1,C3
CURSor:SOURce? --> C1,C3,M1
```

Sets channel 1, 3 and math 1 as cursor sources and changes [CURSor<cu>:SMODE](#) to MSOURCE if SINGLE was set before.
Activates [CURSor<cu>:TRACKing\[:STATE\]](#) for the specified cursor set.

Usage:

Asynchronous command

Manual operation: See ["Source"](#) on page 261

CURSor<cu>:USSource <UseSource2>

Enables the second cursor source. To select the second source, use [CURSor<cu>:SSource](#).

The command has the same effect as `CURSor<cu>:SMODE SECond`.

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<UseSource2> OFF | ON

Usage:

Asynchronous command

CURSor<cu>:SSource <Source2>

Selects the second cursor source.

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<Source2> One of the possible cursor sources, see `CURSor<cu>:SOURce`.

Usage:

Asynchronous command

Manual operation: See "Source 2" on page 261

CURSor<cu>:X1Position <X1Position>

Defines the position of the left vertical cursor line.

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<X1Position> Range: 0 to 500
Increment: 0.1
*RST: depends on time scale, at 25% of the time axis
Default unit: s

Usage:

Asynchronous command

Manual operation: See "X1 position, X2 position" on page 262

CURSor<cu>:X2Position <X2Position>

Defines the position of the right vertical cursor line.

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<X2Position> Range: 0 to 500
Increment: 0.1
*RST: depends on time scale, at 75% of the time axis
Default unit: s

Usage:

Asynchronous command

Manual operation: See "X1 position, X2 position" on page 262

CURSor<cu>:Y1Position [<Signal>]

The command usage depends on the setting of `CURSor<cu>:SMODE`.

In single source and second source mode, the command sets or queries the position of the lower horizontal cursor line. The <Signal> parameter is irrelevant. If `CURSor<cu>:TRACking[:STATe]` is enabled, the Y-positions are set automatically, and the query returns the measurement result.

In multiple source mode, tracking is always on. The command is used as query only, and you specify the signal for which you want to get the value.

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<Value> Y-position of the first horizontal cursor line.

Query parameters:

<Signal> Only relevant for `CURSor<cu>:SMODE MSource`. One of the sources that are specified with `CURSor<cu>:SOURCE`.

Example:

```
CURSor2:SMODE SINGLE
CURSor2:FUNCTION PAIRed
CURSor2:TRACking ON
CURSor2:Y1Position?
--> 0.123859
```

In single source mode with active tracking, the command returns the Y-value.

Example:

```
CURSor:SMODE SINGLE
CURSor:FUNCTION PAIRed
CURSor:TRACking OFF
CURSor:Y1Position 0.15
```

In single source mode with disabled tracking, the command sets the Y-value.

Example:

```
CURSor2:SMODE MSource
CURSor2:Y1Position? C1
--> 0.123859
```

In multiple source mode, tracking is always active. The command returns the Y-value for the specified source.

Usage:

Asynchronous command

Manual operation: See "Y1 position, Y2 position" on page 262

CURSor<cu>:Y2Position [<Signal>]

Defines or queries the position of the upper horizontal cursor line. The command works in the same way as [CURSor<cu>:Y1Position](#).

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<Value> Y-position of the second horizontal cursor line.

Query parameters:

<Signal> Only relevant for [CURSor<cu>:SMODE MSOURCE](#). One of the sources that are specified with [CURSor<cu>:SOURCE](#).

Usage: Asynchronous command

Manual operation: See "[Y1 position, Y2 position](#)" on page 262

CURSor<cu>:SSCReen

Resets the cursors to their initial positions. Reset is helpful if the cursors have disappeared from the display or need to be moved for a larger distance.

Suffix:

<cu> 1 to 4, index of the cursor set

Usage:

Setting only
Asynchronous command

Manual operation: See "[Place on display](#)" on page 263

CURSor<cu>:TRACking[:STATe] <TrackCurve>

If enabled, the horizontal cursor lines follow the waveform. The function is available if both horizontal and vertical cursors are displayed ([CURSor<cu>:FUNCTION PAIRed](#)).

The function is not available for measurements on eyes (R&S MXO5C-K136).

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<TrackCurve> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See "[Track waveform](#)" on page 262

CURSor<cu>:LABel <ShowLabel>

Shows the cursor labels in the diagram.

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<ShowLabel> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Show label"](#) on page 264

CURSor<cu>:HORizontal<n>:LABel <Label>

Defines the label to be displayed with the horizontal cursor lines. By default, the cursors are labeled as Cu1.1, Cu1.2, Cu2.1, ...

Suffix:

<cu> 1 to 4, index of the cursor set

<n> 1..2
Number of the cursor line

Parameters:

<Label> String with the cursor label

Example:

```
CURSor1:HORizontal1:LABel 'Cu1H1'
CURSor1:HORizontal2:LABel "Cu1H2"
```

Usage: Asynchronous command

Manual operation: See ["Horizontal cursor 1, Horizontal cursor 2"](#) on page 264

CURSor<cu>:VERTical<n>:LABel <Label>

Defines the label to be displayed with the vertical cursor lines. By default, the cursors are labeled as Cu1.1, Cu1.2, Cu2.1, ...

Suffix:

<cu> 1 to 4, index of the cursor set

<n> 1..2
Number of the cursor line

Parameters:

<Label> String with the cursor label

Example:

```
CURSor2:VERTical1:LABel 'Cu2V1'
CURSor2:VERTical2:LABel "Cu2V2"
```

Usage: Asynchronous command

Manual operation: See ["Vertical cursor 1, Vertical cursor 2"](#) on page 264

CURSor<cu>:DISPlay:VALues <AddValuesLabel>

Shows the measured values in the cursor labels.

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<AddValuesLabel> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Show values"](#) on page 264

CURSor<cu>:SIAD <ShwInAllDiags>

Shows the enabled cursor measurements in all active diagrams of the time domain.

In the spectrum domain, the setting is disabled. The cursors are shown only on the source spectrum of the measurement.

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<ShwInAllDiags> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Show in all diagrams"](#) on page 263

CURSor<cu>:XCOupling <Coupling>

Defines the positioning mode of the vertical cursor.

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<Coupling> OFF | ON
ON
 Moving one cursor line moves the other cursor line too. The cursor lines always remain a fixed distance.
OFF
 Each cursor line is positioned independently.
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["X, Y"](#) on page 263

CURSor<cu>:YCOupling <Coupling>

Defines the positioning mode of the horizontal cursor. If the horizontal cursor lines track the waveform, the y coupling is irrelevant ([CURSor<cu>:TRACking\[:STATe\]](#) is ON).

Suffix:**<cu>** 1 to 4, index of the cursor set**Parameters:****<Coupling>** OFF | ON**ON**

Moving one cursor line moves the other cursor line too. The cursor lines always remain a fixed distance.

OFF

Each cursor line is positioned independently.

***RST:** OFF**Usage:**

Asynchronous command

Manual operation: See "X, Y" on page 263**CURSor<cu>:X1ENvelope <EnvelopeSelect>****CURSor<cu>:X2ENvelope <EnvelopeSelect>**

Define which horizontal cursor is positioned to the maximum and which to the minimum envelope values.

Prerequisites:

- **ACQuire:TYPE** is set to **ENVELOpe** or **PDETECT**.
- **CURSor<cu>:TRACking[:STATe]** is set to **ON**.
- **CURSor<cu>:FUNCTion** is set to **PAIRed**.

Suffix:**<cu>** 1 to 4, index of the cursor set**Parameters:****<EnvelopeSelect>** MIN | MAX**MIN**

The horizontal cursor is set to the crossing point of the vertical cursor with the minimum waveform envelope.

MAX

The horizontal cursor is set to the crossing point of the vertical cursor with the maximum waveform envelope.

***RST:** MAX**Usage:**

Asynchronous command

Manual operation: See "Envelope 1, Envelope 2" on page 262**18.15.2 Cursor results**

CURSor<cu>:XDELta[:VALue]?	1154
CURSor<cu>:XDELta:INVerse?	1154
CURSor<cu>:YDELta[:VALue]?	1154
CURSor<cu>:YDELta:SLOPe?	1155

CURSor<cu>:XDELta[:VALue]?

Queries the delta value (distance) of two vertical cursor lines.

Suffix:

<cu> 1 to 4, index of the cursor set

Return values:

<Delta> Range: -1E+26 to 1E+26
Increment: 0.1
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

CURSor<cu>:XDELta:INVerse?

Queries the inverse value of the delta value (distance) of the two vertical cursor lines.

Suffix:

<cu> 1 to 4, index of the cursor set

Return values:

<DeltaInverse> Range: -1E+26 to 1E+26
Increment: 0.1
*RST: 0
Default unit: Hz

Usage:

Query only
Asynchronous command

CURSor<cu>:YDELta[:VALue]? [<Signal>]

Returns the delta value (distance) of the two horizontal cursor lines.

In multiple source mode, specify the signal for which you want to get the value.

Suffix:

<cu> 1 to 4, index of the cursor set

Query parameters:

<Signal> Only relevant for [CURSor<cu>:SMODE MSource](#). One of the sources that are specified with [CURSor<cu>:SOURCE](#).

Return values:

<Value> Inverse value of the delta value of the two horizontal cursor lines.

Usage:

Query only
Asynchronous command

CURSor<cu>:YDELta:SLOPe? [<Signal>]

Returns the inverse value of the voltage difference, the reciprocal of the vertical distance of two horizontal cursor lines: $1/\Delta V$.

In multiple source mode, specify the signal for which you want to get the value.

Suffix:

<cu> 1 to 4, index of the cursor set

Query parameters:

<Signal> Only relevant for CURSor<cu>:SMODE MSource. One of the sources that are specified with CURSor<cu>:SOURCE.

Return values:

<Value> Inverse value of the delta value of the two cursor lines.

Usage:

Query only
Asynchronous command

18.15.3 Peak search using cursors

CURSor<cu>:FFT:SETCenter.....	1155
CURSor<cu>:FFT:TOCenter.....	1155
CURSor<cu>:MAXimum[:PEAK].....	1156
CURSor<cu>:MAXimum:LEFT.....	1156
CURSor<cu>:MAXimum:RIGHT.....	1156
CURSor<cu>:MAXimum:NEXT.....	1156
CURSor<cu>:PEXCursion.....	1156

CURSor<cu>:FFT:SETCenter

Sets the center frequency to the frequency value that is measured at cursor line Cu1.

Suffix:

<cu> 1 to 4, index of the cursor set

Usage:

Setting only
Asynchronous command

Manual operation: See "Set center frequency to" on page 265

CURSor<cu>:FFT:TOCenter

Sets the vertical cursor line Cu1 to the center frequency.

Suffix:

<cu> 1 to 4, index of the cursor set

Usage:

Setting only
Asynchronous command

Manual operation: See "Center frequency" on page 265

CURSor<cu>:MAXimum[:PEAK]

Sets both cursors to the absolute peak value.

Suffix:

<cu> 1 to 4, index of the cursor set

Usage:

Event
Asynchronous command

Manual operation: See ["Absolute peak"](#) on page 265

CURSor<cu>:MAXimum:LEFT

Cursor 2 is set to the next peak to the left of the current position.

Suffix:

<cu> 1 to 4, index of the cursor set

Usage:

Event
Asynchronous command

Manual operation: See ["Next peak left"](#) on page 265

CURSor<cu>:MAXimum:RIGHT

Cursor 2 is set to the next peak to the right of the current position.

Suffix:

<cu> 1 to 4, index of the cursor set

Usage:

Event
Asynchronous command

Manual operation: See ["Next peak right"](#) on page 265

CURSor<cu>:MAXimum:NEXT

Cursor 2 is set to the next smaller absolute peak from the current position.

Suffix:

<cu> 1 to 4, index of the cursor set

Usage:

Event
Asynchronous command

Manual operation: See ["Next peak"](#) on page 265

CURSor<cu>:PEXCursion <Value>

Sets the minimum level by which the waveform must rise or fall so that it will be identified as a maximum or a minimum by the search functions.

Suffix:

<cu> 1 to 4, index of the cursor set

Parameters:

<Value>

Usage:

Asynchronous command

Manual operation:See "[Peak excursion](#)" on page 266

18.15.4 Cursor appearance

CURSor<cu>:STYLe <Style>

Defines how the cursor is displayed in the diagram.

Suffix:

<cu>

1 to 4, index of the cursor set

Parameters:

<Style>

LINes | LRHombus | VLRHombus | RHOMbus

LINes

The cursors are displayed as lines.

LRHombus

The cursors are displayed as lines. The intersections of the cursors with the waveforms are displayed by rhombus-shaped points.

VLRHombus

The cursors are displayed only as vertical lines. The intersections of the cursors with the waveforms are displayed by rhombus-shaped points.

RHOMbus

The intersections of the cursors with the waveforms are displayed by rhombus-shaped points.

*RST: LINes

Usage:

Asynchronous command

Manual operation:See "[Cursor style](#)" on page 260

18.16 Spectrum analysis

18.16.1 Spectrum setup

CALCulate:SPECTrum<sp>:FREQuency:BANDwidth[:RESolution]:ADJusted?	1158
CALCulate:SPECTrum<sp>:FREQuency:BANDwidth[:RESolution]:AUTO	1158
CALCulate:SPECTrum<sp>:FREQuency:BANDwidth[:RESolution]:RATio	1159
CALCulate:SPECTrum<sp>:FREQuency:BANDwidth[:RESolution][:VALue]	1159
CALCulate:SPECTrum<sp>:FREQuency:CENTer	1159
CALCulate:SPECTrum<sp>:FREQuency:SCALe	1160

CALCulate:SPECTrum<sp>:FREQuency:SPAN.....	1160
CALCulate:SPECTrum<sp>:FREQuency:START.....	1160
CALCulate:SPECTrum<sp>:FREQuency:STOP.....	1161
CALCulate:SPECTrum<sp>:FREQuency:WINDow:TYPE.....	1161
CALCulate:SPECTrum<sp>:MAGNitude:LEVel.....	1162
CALCulate:SPECTrum<sp>:MAGNitude:RANGe.....	1162
CALCulate:SPECTrum<sp>:MAGNitude:SCALE.....	1162
CALCulate:SPECTrum<sp>:PRESet.....	1163
CALCulate:SPECTrum<sp>:SOURce.....	1163
CALCulate:SPECTrum<sp>:STATe.....	1163
CALCulate:SPECTrum<sp>:THReshold.....	1164
CALCulate:SPECTrum<sp>:PEXCursion.....	1164
CALCulate:SPECTrum<sp>:WAVEform:AVERage:COUNt.....	1164
CALCulate:SPECTrum<sp>:WAVEform:AVERage:ENABLe.....	1165
CALCulate:SPECTrum<sp>:WAVEform:MAXimum:ENABLe.....	1165
CALCulate:SPECTrum<sp>:WAVEform:MINimum:ENABLe.....	1165
CALCulate:SPECTrum<sp>:WAVEform:NORMAl[:ENABLe].....	1165

CALCulate:SPECTrum<sp>:FREQuency:BANDwidth[:RESolution]:ADJusted?

Queries the effective resolution bandwidth.

Suffix:

<sp> 1 to 4, index of the spectrum

Return values:

<AdjResBW> Range: 0 to 200E+9
 Increment: 0.01
 *RST: 0
 Default unit: Hz

Usage:

Query only
 Asynchronous command

CALCulate:SPECTrum<sp>:FREQuency:BANDwidth[:RESolution]:AUTO <AutoRBW>

Couples the frequency span to the "RBW" setting.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<AutoRBW> OFF | ON
 *RST: ON

Usage:

Asynchronous command

Manual operation: See ["Auto RBW"](#) on page 319

CALCulate:SPECTrum<sp>:FREQuency:BANDwidth[:RESolution]:RATio
 <SpanRBWRatio>

Defines the coupling ratio for Span/RBW.

Available, if **CALCulate:SPECTrum<sp>:FREQuency:BANDwidth[:RESolution]:AUTO** is set to ON.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<SpanRBWRatio> Range: 10 to 10000
 Increment: 1
 *RST: 1000

Usage: Asynchronous command

Manual operation: See "[Span/RBW](#)" on page 319

CALCulate:SPECTrum<sp>:FREQuency:BANDwidth[:RESolution][:VALue]
 <RBW>

Queries or defines the used resolution bandwidth.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<RBW> Range: 0.0002 to 2000000
 Increment: 0.01
 *RST: 2000000
 Default unit: Hz

Usage: Asynchronous command

Manual operation: See "[RBW](#)" on page 320

CALCulate:SPECTrum<sp>:FREQuency:CENTer <Center>

Defines the position of the displayed frequency range, which is (Center - Span/2) to (Center + Span/2). The width of the range is defined using the frequency span setting.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<Center> Range: -1E+26 to 1E+26
 Increment: 0.01
 *RST: 0
 Default unit: HZ

Usage: Asynchronous command

Manual operation: See "[\[Position\]](#)" on page 54

CALCulate:SPECTrum<sp>:FREQuency:SCALe <XAxisMode>

Defines the scaling method for the frequency axis (x-axis) of the spectrogram.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<XAxisMode> LIN | LOG
 LIN: linear scaling
 LOG: logarithmic scaling
 *RST: LIN

Usage: Asynchronous command

Manual operation: See ["Frequency axis"](#) on page 322

**CALCulate:SPECTrum<sp>:FREQuency:SPAN **

The span is specified in Hertz and defines the width of the displayed frequency range, which is (Center - Span/2) to (Center + Span/2). The position of the span is defined using the "Center" setting.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

 Range: 0 to 1E+26
 Increment: 0.01
 *RST: 0.02
 Default unit: HZ

Usage: Asynchronous command

Manual operation: See ["\[Scale\]"](#) on page 55

CALCulate:SPECTrum<sp>:FREQuency:STARt <Start>

Defines the start frequency of the displayed frequency span.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<Start> Range: -1E+26 to 1E+26
 Increment: 0.01
 *RST: -0.01
 Default unit: HZ

Usage: Asynchronous command

Manual operation: See ["Start"](#) on page 319

CALCulate:SPECTrum<sp>:FREQuency:STOP <Stop>

Sets the stop frequency of the displayed frequency span.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<Stop> Range: -1E+26 to 1E+26
Increment: 0.01
*RST: 0.01
Default unit: HZ

Usage: Asynchronous command

Manual operation: See ["Stop"](#) on page 319

CALCulate:SPECTrum<sp>:FREQuency:WINDow:TYPE <WindowFunction>

Selects the window type. Windowing helps minimize the discontinuities at the end of the measured signal interval and thus reduces the effect of spectral leakage, increasing the frequency resolution.

Various different window functions are provided in the MXO 5C to suit different input signals. Each of the window functions has specific characteristics, including some advantages and some trade-offs. Consider these characteristics carefully to find the optimum solution for the measurement task.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<WindowFunction> RECTangular | HAMMing | HANN | BLACKharris | GAUSSian | FLATTOP2 | KAISerbessel

RECTangular

The rectangular window has the best frequency resolution, but a poor amplitude accuracy and is recommended for separating two tones with almost equal amplitudes and a small frequency distance.

HAMMing

The Hamming window is bell shaped and has a good frequency resolution and fair amplitude accuracy. It is recommended for frequency response measurements and sine waves, periodic signals and narrowband noise.

HANN

The Hann window is bell shaped and has a slightly worse frequency resolution but smaller sidelobe level than the Hamming window. The applications are the same.

BLACKharris

The Blackman window is bell shaped and has a poor frequency resolution, but very good amplitude accuracy. It is recommended mainly for signals with single frequencies to detect harmonics.

GAUSSian

Good frequency resolution and best magnitude resolution, recommended for weak signals and short duration

FLATTOP2

The flat top window has a poor frequency resolution, but the best amplitude accuracy and the sharpest sidelobe. It is recommended for accurate single tone amplitude measurements.

KAISerbessel

The kaiser-bessel window has a fair frequency resolution and good amplitude accuracy, and a very high sidelobe level. It is recommended for separating two tones with differing amplitudes and a small frequency distance.

*RST: BLACkharris

Usage: Asynchronous command
Manual operation: See ["Window type"](#) on page 320

CALCulate:SPECTrum<sp>:MAGNitude:LEVel <VerticalMax>

Sets the maximum displayed value on the vertical scale.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<VerticalMax> Range: -1E+26 to 10000000000000000
 Increment: 1
 *RST: 10

Usage: Asynchronous command
Manual operation: See ["Vertical maximum"](#) on page 322

CALCulate:SPECTrum<sp>:MAGNitude:RANGe <VerticalRange>

Sets the range of the spectrum values to be displayed.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<VerticalRange> Range: 0 to 10000000000000000
 Increment: 0.01
 *RST: 100

Usage: Asynchronous command
Manual operation: See ["Vertical range"](#) on page 322

CALCulate:SPECTrum<sp>:MAGNitude:SCALE <Unit>

Sets the unit for the y-axis.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<Unit> LINear | DB | DBM | DBV | DBUV | DBS | DBHZ

*RST: DBM

Usage:

Asynchronous command

Manual operation: See ["Magnitude unit"](#) on page 322

CALCulate:SPECTrum<sp>:PRESet

Presets the spectrum measurement.

Suffix:

<sp> 1 to 4, index of the spectrum

Usage:

Setting only

Asynchronous command

Manual operation: See ["Spectrum preset"](#) on page 321

CALCulate:SPECTrum<sp>:SOURce <Source>

Selects the source for the spectrum.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<Source> C1 | C2 | ... | C8 | M1 | M2 | ... | M8 | R1 | R2 | ... | R8 | TRK1 | TRK2 | TRK3 | ... | TRK24 | PA1QPOWER | PA2QPOWER | ... | PA6QPOWER | PA1SPOWER | PA2SPOWER | ... | PA6SPOWER | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 11)

Usage:

Asynchronous command

Manual operation: See ["Source"](#) on page 318

CALCulate:SPECTrum<sp>:STATe <State>

Enables the spectrum.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<State> OFF | ON

*RST: OFF

Usage:

Asynchronous command

Manual operation: See ["Display"](#) on page 318

CALCulate:SPECTrum<sp>:THReshold <Threshold>

Sets an absolute threshold as an additional condition for the peak search. Only peaks that exceed the threshold are detected.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<Threshold> Range: -500 to 500
Increment: 1
*RST: -70
Default unit: dBm

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 266

CALCulate:SPECTrum<sp>:PEXCursion <PeakExcursion>

Defines a minimum level value by which the waveform must drop left and right of the local maximum to be listed as a peak. Enter a peak excursion value to omit close by peaks and list just the highest peak.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<PeakExcursion> Range: 0 to 100
Increment: 1
*RST: 5
Default unit: dB

Usage: Asynchronous command

Manual operation: See ["Peak excursion"](#) on page 266

CALCulate:SPECTrum<sp>:WAVEform:AVERage:COUNt <AverageCount>

Sets the number of segments used for the averaging of the spectrum.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<AverageCount> Range: 2 to 65534
Increment: 1
*RST: 1000

Usage: Asynchronous command

Manual operation: See ["Traces"](#) on page 320

CALCulate:SPECTrum<sp>:WAVEform:AVERAge:ENABle <Enable>

Enables the average trace.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<Enable> OFF | ON

Usage: Asynchronous command

Manual operation: See ["Traces"](#) on page 320

CALCulate:SPECTrum<sp>:WAVEform:MAXimum:ENABle <Enable>

Enables the maximum trace.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<Enable> OFF | ON

Usage: Asynchronous command

Manual operation: See ["Traces"](#) on page 320

CALCulate:SPECTrum<sp>:WAVEform:MINimum:ENABle <Enable>

Enables the minimum trace.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<Enable> OFF | ON

Usage: Asynchronous command

Manual operation: See ["Traces"](#) on page 320

CALCulate:SPECTrum<sp>:WAVEform:NORMAl[:ENABle] <Enable>

Enables the normal spectrum trace.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<Enable> OFF | ON

Usage: Asynchronous command

Manual operation: See ["Traces"](#) on page 320

18.16.2 Spectrum gate

CALCulate:SPECTrum<sp>:GATE:POSition.....	1166
CALCulate:SPECTrum<sp>:GATE:STARt.....	1166
CALCulate:SPECTrum<sp>:GATE:STOP.....	1166
CALCulate:SPECTrum<sp>:GATE:WIDTh.....	1167

CALCulate:SPECTrum<sp>:GATE:POSition <Center>

Sets the position of the displayed frequency range.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<Center> Range: -1E+26 to 1E+26
Increment: 0.01
*RST: 0
Default unit: HZ

Usage: Asynchronous command

Manual operation: See "[Position](#)" on page 323

CALCulate:SPECTrum<sp>:GATE:STARt <Start>

Sets the starting value for the gate.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<Start> Range: -1E+26 to 1E+26
Increment: 0.01
*RST: -0.01
Default unit: HZ

Usage: Asynchronous command

Manual operation: See "[Start](#)" on page 323

CALCulate:SPECTrum<sp>:GATE:STOP <Stop>

Sets the end value for the gate.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<Stop> Range: -1E+26 to 1E+26
Increment: 0.01
*RST: 0.01
Default unit: HZ

Usage: Asynchronous command

Manual operation: See ["Stop"](#) on page 323

**CALCulate:SPECTrum<sp>:GATE:WIDTh **

Defines the width of the displayed gate.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

 Range: 0 to 1E+26
Increment: 0.01
*RST: 0.02
Default unit: HZ

Usage: Asynchronous command

Manual operation: See ["Width"](#) on page 323

18.16.3 Peak list

CALCulate:SPECTrum<sp>:PLISt:COUNT?	1167
CALCulate:SPECTrum<sp>:PLISt[:STATe]	1168
CALCulate:SPECTrum<sp>:PLISt:MAXCount	1168
CALCulate:SPECTrum<sp>:PLISt:MODE	1168
CALCulate:SPECTrum<sp>:PLISt:SOURce	1168
CALCulate:SPECTrum<sp>:PLISt:SPOW	1169
CALCulate:SPECTrum<sp>:PLISt:RESult[:VALue]?	1169
CALCulate:SPECTrum<sp>:PLISt:SORT:COLUMN	1169
CALCulate:SPECTrum<sp>:PLISt:SORT:ORDER	1170
CALCulate:SPECTrum<sp>:PLISt:LABel:FREQuency[:STATe]	1170
CALCulate:SPECTrum<sp>:PLISt:LABel:MAXCount	1170
CALCulate:SPECTrum<sp>:PLISt:LABel:INVert	1170
CALCulate:SPECTrum<sp>:PLISt:LABel:MAXCount	1171
CALCulate:SPECTrum<sp>:PLISt:LABel[:STATe]	1171

CALCulate:SPECTrum<sp>:PLISt:COUNT?

Returns the current number of peak list results.

Suffix:

<sp> 1 to 4, index of the spectrum

Return values:

<Count>

Usage: Query only
Asynchronous command

CALCulate:SPECTrum<sp>:PLIST[:STATe] <ShowTable>

Enables the display of the peak table.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<ShowTable> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Peak table"](#) on page 325

CALCulate:SPECTrum<sp>:PLIST:MAXCount <MaxNoRess>

Sets the maximum number of measurement results that are listed in the result table.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<MaxNoRess> Range: 1 to 1000

Increment: 1

*RST: 10

Usage: Asynchronous command

Manual operation: See ["Max results"](#) on page 326

CALCulate:SPECTrum<sp>:PLIST:MODE <ResultMode>

Selects how the measurement results are displayed.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<ResultMode> ABS | REL

*RST: ABS

Usage: Asynchronous command

Manual operation: See ["Result mode"](#) on page 326

CALCulate:SPECTrum<sp>:PLIST:SOURce <Source>

Selects the source of the peak table. You can select one of the traces that is enabled with [Traces](#).

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<Source> SPECMAXH1 | SPECMINH1 | SPECNORM1 | SPECAVER1 |
 SPECMAXH2 | SPECMINH2 | SPECNORM2 | SPECAVER2 |
 SPECMAXH3 | SPECMINH3 | SPECNORM3 | SPECAVER3 |
 SPECMAXH4 | SPECMINH4 | SPECNORM4 | SPECAVER4

Usage: Asynchronous command

Manual operation: See ["Source"](#) on page 327

CALCulate:SPECTrum<sp>:PLISt:SPOW <ShowPeaks>

Displays a box with a description for each detected peak in the spectrum, including the magnitude.

If `CALCulate:SPECTrum<sp>:PLISt:LABel:FREQuency[:STATe]` is ON, the frequency values are also displayed.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<ShowPeaks> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Peak on waveform"](#) on page 325

CALCulate:SPECTrum<sp>:PLISt:RESult[:VALue]?

Returns the current peak list measurement results.

Suffix:

<sp> 1 to 4, index of the spectrum

Return values:

<Value> Comma-separated list of results

Usage: Query only
 Asynchronous command

CALCulate:SPECTrum<sp>:PLISt:SORT:COLumn <ResultColumn>

Sorts the results in the spectrum peak list table either according to the frequency or according to the value.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<ResultColumn> FREQ | VAL
 *RST: FREQ

Usage: Asynchronous command

CALCulate:SPECTrum<sp>:PLISt:SORT:ORDER <ResultOrder>

Defines if the spectrum peak list results are sorted in an ascending (increasing) or descending (decreasing) order.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<ResultOrder> ASC | DESC
 ASC: ascending
 DESC: descending
 *RST: ASC

Usage: Asynchronous command

CALCulate:SPECTrum<sp>:PLISt:LABel:FREQuency[:STATe] <ShowFrequency>

Includes the frequency of the detected peak in the diagram labels.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<ShowFrequency> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Show frequency"](#) on page 327

CALCulate:SPECTrum<sp>:PLISt:LABel:MAXCount <MaxNumberPeaks>

Sets the maximum number of measurement results that are listed in the result table.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<MaxNumberPeaks> Range: 1 to 100
 Increment: 1
 *RST: 10

Usage: Asynchronous command

CALCulate:SPECTrum<sp>:PLISt:LABel:INVert <Inverse>

Inverts the colors of the peak list labels, the peak boxes are shown with a white background.

Suffix:
 <sp> 1 to 4, index of the spectrum

Parameters:
 <Inverse> OFF | ON
 *RST: OFF

Usage: Asynchronous command

CALCulate:SPECTrum<sp>:PLISt:LABel:MAXCount <MaxNumberPeaks>

Sets the maximum number of measurement results that are listed in the result table.

Suffix:
 <sp> 1 to 4, index of the spectrum

Parameters:
 <MaxNumberPeaks> Range: 1 to 100
 Increment: 1
 *RST: 10

Usage: Asynchronous command

CALCulate:SPECTrum<sp>:PLISt:LABel[:STATe] <ShowLabels>

Displays the labels in the peak list diagram.

Suffix:
 <sp> 1 to 4, index of the spectrum

Parameters:
 <ShowLabels> OFF | ON
 *RST: ON

Usage: Asynchronous command

18.16.4 Spectrum with frames and overlap

CALCulate:SPECTrum<sp>:OVERlap:ENABLE.....	1171
CALCulate:SPECTrum<sp>:OVERlap:FACTOR:VALue.....	1172
CALCulate:SPECTrum<sp>:OVERlap:FACTOR:ADJusted?.....	1172
CALCulate:SPECTrum<sp>:OVERlap:FCOunt:LIMit:ENABLE.....	1172
CALCulate:SPECTrum<sp>:OVERlap:FCOunt:VALue.....	1173
CALCulate:SPECTrum<sp>:OVERlap:FCOunt:ADJusted?.....	1173
CALCulate:SPECTrum<sp>:OVERlap:FWIDTH?.....	1173

CALCulate:SPECTrum<sp>:OVERlap:ENABLE <State>

Activates the use of frames and overlap to create the FFT spectrum.

Suffix:
 <sp> 1 to 4, index of the spectrum

Parameters:

<State> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Enable"](#) on page 327

CALCulate:SPECTrum<sp>:OVERlap:FACTor:VALue <OverlapFactor>

Defines the minimum factor by which two neighboring frames overlap.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<OverlapFactor> Range: 0 to 90
 Increment: 1
 *RST: 20
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Overlap factor"](#) on page 328

CALCulate:SPECTrum<sp>:OVERlap:FACTor:ADJusted?

Returns the adjusted overlap factor that is used for calculation. It is based on the given minimum overlap factor and the current settings.

Suffix:

<sp> 1 to 4, index of the spectrum

Return values:

<AdjOverlapFact> Range: 0 to 100
 Increment: 1
 *RST: 20
 Default unit: %

Usage: Query only
 Asynchronous command

Manual operation: See ["Overlap factor"](#) on page 328

CALCulate:SPECTrum<sp>:OVERlap:FCOunt:LIMit:ENABLE <LimitNumberFFT>

Limits the number of FFTs that are done per acquisition. To set the number of FFTs, use [CALCulate:SPECTrum<sp>:OVERlap:FCOunt:VALue](#).

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<LimitNumberFFT> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See "Limit # of FFTs" on page 327

CALCulate:SPECTrum<sp>:OVERlap:FCOunt:VALue <FFTPerAcq>

Sets the number of frames to be used for FFT with `CALCulate:SPECTrum<sp>:OVERlap:FCOunt:LIMit:ENABle` set ON.

Suffix:

<sp> 1 to 4, index of the spectrum

Parameters:

<FFTPerAcq> Range: 1 to 4294967295
 Increment: 1
 *RST: 1000

Usage: Asynchronous command

Manual operation: See "FFTs per acq." on page 328

CALCulate:SPECTrum<sp>:OVERlap:FCOunt:ADJusted?

Returns the adjusted number of frames that is used for FFT calculation.

Suffix:

<sp> 1 to 4, index of the spectrum

Return values:

<AdjFFTPerAcq> Range: 1 to 4294967295
 Increment: 1
 *RST: 1000

Usage: Query only
 Asynchronous command

Manual operation: See "FFTs per acq." on page 328

CALCulate:SPECTrum<sp>:OVERlap:FWIDth?

Returns the frame width.

Suffix:

<sp> 1 to 4, index of the spectrum

Return values:

<FrameWidth> Range: 1E-16 to 10000
 Increment: 1
 *RST: 1
 Default unit: s

Usage: Query only
Asynchronous command

Manual operation: See "Frame width" on page 328

18.16.5 Data export of spectrum waveforms

For each of the spectrum traces, a dedicated command is available. For a description of the traces, see "Traces" on page 320.

For fast export of several waveforms at once, use `EXPort:WAVeform:DATA[:VALues]?` on page 1109.

CALCulate:SPECTrum<sp>:WAVeform:AVERAge:DATA:HEADer?
CALCulate:SPECTrum<sp>:WAVeform:MAXimum:DATA:HEADer?
CALCulate:SPECTrum<sp>:WAVeform:MINimum:DATA:HEADer?
CALCulate:SPECTrum<sp>:WAVeform:NORMal:DATA:HEADer?

Returns the header of spectrum data, the attributes of the waveform.

Suffix:

<sp> 1 to 4, index of the spectrum

Return values:

<XStart> 1. header value: start frequency of the first spectrum bin in Hz
 <XStop> 2. header value: start frequency of the last spectrum bin in Hz
 <RecordLength> 3. header value: record length of the waveform in bins
 <ValuesPerSample> 4. header value: the number of values per bin is always = 1.

Example:

`CALC:SPEC1:WAV:NORM:DATA:HEAD?`
 549316.1734194756,1999450683.360919,2621,1
 Start frequency of the first spectrum bin is 549316.1734194756
 = ~ 549.3 kHz. Start frequency of the last spectrum bin is
 1999450683.360919 = ~ 1.999 GHz. The data stream has 2621
 values with one value per bin.

Usage: Query only
Asynchronous command

CALCulate:SPECTrum<sp>:WAVeform:AVERAge:DATA[:VALues]?
 [<Offset>[,<Length>]]
CALCulate:SPECTrum<sp>:WAVeform:MAXimum:DATA[:VALues]?
 [<Offset>[,<Length>]]
CALCulate:SPECTrum<sp>:WAVeform:MINimum:DATA[:VALues]?
 [<Offset>[,<Length>]]
CALCulate:SPECTrum<sp>:WAVeform:NORMal:DATA[:VALues]?
 [<Offset>[,<Length>]]

Returns the data of the spectrum points for transmission from the instrument to the controlling computer. The data can be used in MATLAB, for example.

Without parameters, the complete waveform is retrieved. Using the offset and length parameters, data can be retrieved in smaller portions, which makes the command faster. If you send only one parameter, it is interpreted as offset, and the data is retrieved from offset to the end of the waveform.

To set the export format, use [FORMat \[: DATA \]](#) on page 921.

Suffix:

<sp> 1 to 4, index of the spectrum

Query parameters:

<Offset> Number of offset waveform points to be skipped.
Range: 0 to m. Limit: $n + m \leq \text{record length}$

<Length> Number of waveform points to be retrieved.
Range: 1 to n. Limit: $n + m \leq \text{record length}$

Return values:

<Data> List of values according to the format and content settings.

Usage:

Query only
Asynchronous command

**CALCulate:SPECTrum<sp>:WAVEform:NORMAL:DATA:FRAME<fr>[:VALues]?
[<Offset>[,<Length>]]**

Returns the data of the spectrum points of the specified frame for transmission from the instrument to the controlling computer. The data can be used in MATLAB, for example.

Without parameters, the complete waveform is retrieved. Using the offset and length parameters, data can be retrieved in smaller portions, which makes the command faster. If you send only one parameter, it is interpreted as offset, and the data is retrieved from offset to the end of the waveform.

To set the export format, use [FORMat \[: DATA \]](#) on page 921.

Suffix:

<sp> 1 to 4, index of the spectrum

<fr> 1..*
Index of the frame

Query parameters:

<Offset> Number of offset waveform points to be skipped.
Range: 0 to m. Limit: $n + m \leq \text{record length}$

<Length> Number of waveform points to be retrieved.
Range: 1 to n. Limit: $n + m \leq \text{record length}$

Return values:

<Data> List of values according to the format and content settings.

Usage:

Query only
Asynchronous command

18.17 Applications

18.17.1 Mask testing

Some of the commands in the following section are asynchronous. An overlapping or asynchronous command does not automatically finish executing before the next command starts executing. If overlapping commands must be executed in a defined order, e.g. to avoid wrong measurement results, they must be serviced sequentially.

To prevent an overlapping execution of commands, one of the commands `*OPC`, `*OPC?` or `*WAI` can be used after the command or a command set.

For more information, see:

- www.rohde-schwarz.com/rc-via-scpj, section "Command sequence and synchronization"
- [Mask test definition](#)..... 1176
- [Segment definition](#)..... 1179
- [Actions](#)..... 1183
- [Results](#)..... 1185

18.17.1.1 Mask test definition

MTEST<m>:ADD	1176
MTEST<m>:COUNT?	1177
MTEST<m>:DIAGram	1177
MTEST<m>:IMEXport:NAME	1177
MTEST<m>:IMEXport:OPEN	1177
MTEST<m>:IMEXport:SAVE	1178
MTEST<m>:REMove	1178
MTEST<m>:SOURce	1178
MTEST<m>:STATe	1178
MTEST<m>:VISible	1179

MTEST<m>:ADD

Creates a mask test with the indicated index.

Suffix:

<m> 1 to 8, index of the mask

Example: See [Section 18.5.2, "Creating a mask"](#), on page 915.

Usage: Setting only
Asynchronous command

Manual operation: See ["Add mask"](#) on page 331

MTESt<m>:COUNT?

Returns the number of masks.

MTESt:COUNT? MAX returns the maximum number of masks that can be created.

Suffix:

<m> Irrelevant, omit the suffix.

Return values:

<Count> Number of defined masks

Usage:

Query only
Asynchronous command

MTESt<m>:DIAGram <DiagramKey>

Sets the layout and the diagram where the mask is located and the test runs.

Suffix:

<m> 1 to 8, index of the mask

Parameters:

<DiagramKey> String with the layout-diagram key.

Example:

```
:MTESt:DIAGram?  
-->"L1_D1"
```

Usage:

Asynchronous command

MTESt<m>:IMEXport:NAME <Name>

Sets the path, the filename and the file format of the mask file.

Suffix:

<m> 1 to 8, index of the mask

Parameters:

<Name> String with path and file name with extension .xml.

Example:

```
MTESt:IMEX:NAME  
'/home/storage/userData/Masks/MyMask2.xml'  
File and path definition for mask test 2.
```

Usage:

Asynchronous command

Manual operation: See ["Save mask"](#) on page 332

MTESt<m>:IMEXport:OPEN

Opens and loads the mask selected by `MTESt<m>:IMEXport:NAME`.

Suffix:

<m> 1 to 8, index of the mask

Usage: Event
Asynchronous command

Manual operation: See ["Load mask"](#) on page 332

MTESt<m>:IMEXport:SAVE

Saves the mask test to the file selected by [MTESt<m>:IMEXport:NAME](#).

Suffix:
<m> 1 to 8, index of the mask

Usage: Event
Asynchronous command

Manual operation: See ["Save mask"](#) on page 332

MTESt<m>:REMove

Deletes the selected mask.

Suffix:
<m> 1 to 8, index of the mask

Usage: Setting only
Asynchronous command

MTESt<m>:SOURce <Source>

Selects the waveform to be tested against the mask.

Suffix:
<m> 1 to 8, index of the mask

Parameters:
<Source> C1 | C2 | ... | C8 | M1 | M2 | ... | M8 | XY1 | XY2 | XY3 | XY4 |
SPECNORM1 | SPECNORM2 | SPECNORM3 | SPECNORM4 |
O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 11 | EYE1 | EYE2
| ... | EYE8

Usage: Asynchronous command

Manual operation: See ["Source"](#) on page 332

MTESt<m>:STATe <State>

Activates or deactivates the mask test.

Suffix:
<m> 1 to 8, index of the mask

Parameters:
<State> OFF | ON
*RST: ON

Usage: Asynchronous command
Manual operation: See ["Enable test"](#) on page 332

MTESSt<m>:VISible <DisplayState>

Displays all mask segments of the selected mask in the diagrams, or hides them.

Suffix:
 <m> 1 to 8, index of the mask

Parameters:
 <DisplayState> OFF | ON
 *RST: ON

Usage: Asynchronous command
Manual operation: See ["Display"](#) on page 332

18.17.1.2 Segment definition

MTESSt<m>:SEGMENT<n>:ADD.....	1179
MTESSt<m>:SEGMENT<n>:COUNT?.....	1179
MTESSt<m>:SEGMENT<n>:POINT<o>:ADD.....	1180
MTESSt<m>:SEGMENT<n>:POINT<o>:COUNT?.....	1180
MTESSt<m>:SEGMENT<n>:POINT<o>:REMOve.....	1181
MTESSt<m>:SEGMENT<n>:POINT<o>:VALId?.....	1181
MTESSt<m>:SEGMENT<n>:POINT<o>:X.....	1181
MTESSt<m>:SEGMENT<n>:POINT<o>:Y.....	1182
MTESSt<m>:SEGMENT<n>:REMOve.....	1182
MTESSt<m>:SEGMENT<n>:VALId?.....	1182

MTESSt<m>:SEGMENT<n>:ADD

Adds a new segment to the selected mask. The segment has no points, use [MTESSt<m>:SEGMENT<n>:POINT<o>:ADD](#) to add the points.

Suffix:
 <m> 1 to 8, index of the mask
 <n> 1 to 8, index of the segment
 Omit the suffix to use the next free suffix.

Example: See [Section 18.5.2, "Creating a mask"](#), on page 915.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Add segment"](#) on page 333

MTESSt<m>:SEGMENT<n>:COUNT?

Returns the number of segments that belong to the indicated mask.

MTESt<m>:SEGMent:COUNT? MAX returns the maximum number of segments that can be created.

Suffix:

<m> 1 to 8, index of the mask

<n> Irrelevant, omit the suffix.

Return values:

<Count> Number of defined masks

Usage:

Query only
Asynchronous command

MTESt<m>:SEGMent<n>:POINT<o>:ADD

Adds a corner point to the selected mask segment at the next free suffix. The new point has the coordinates 0;0.

Suffix:

<m> 1 to 8, index of the mask

<n> 1 to 8, index of the segment

<o> 1 to *, index of the segment point

Example: See [Section 18.5.2, "Creating a mask"](#), on page 915.

Usage:

Setting only
Asynchronous command

Manual operation: See ["Add +"](#) on page 334

MTESt<m>:SEGMent<n>:POINT<o>:COUNT?

Returns the number of points that was added to the indicated mask segment.

You can query the maximum value with <command>? MAX.

Suffix:

<m> 1 to 8, index of the mask

<n> 1 to 8, index of the segment

<o> Irrelevant, omit the suffix.

Parameters:

<Count> Number of defined points

Example: See [Section 18.5.2, "Creating a mask"](#), on page 915.

Usage:

Query only
Asynchronous command

Manual operation: See ["Add +"](#) on page 334

MTESt<m>:SEGMent<n>:POINT<o>:REMOve

Deletes the indicated corner point of the mask segment.

Suffix:

<m>	1 to 8, index of the mask
<n>	1 to 8, index of the segment
<o>	1 to *, index of the segment point

Usage:

Setting only
Asynchronous command

Manual operation: See ["Delete, Delete all"](#) on page 335

MTESt<m>:SEGMent<n>:POINT<o>:VALid?

Checks the validity of the selected point. See ["Mask Definition"](#) on page 329.

Suffix:

<m>	1 to 8, index of the mask
<n>	1 to 8, index of the segment
<o>	1 to *, index of the segment point

Return values:

<Valid>	OFF ON
	ON = valid
	OFF = invalid
*RST:	ON

Usage:

Query only
Asynchronous command

MTESt<m>:SEGMent<n>:POINT<o>:X <X>

Sets the horizontal position of the selected corner point.

Suffix:

<m>	1 to 8, index of the mask
<n>	1 to 8, index of the segment
<o>	1 to *, index of the segment point

Parameters:

<X>	Range: -1E+26 to 1E+26
	Increment: 1E-06
	*RST: 0
	Default unit: s

Example: See [Section 18.5.2, "Creating a mask"](#), on page 915.

Usage:

Asynchronous command

Manual operation: See ["Point, X, Y"](#) on page 334

MTES<m>:SEGMent<n>:POINt<o>:Y <Y>

Sets the vertical position of the selected corner point.

Suffix:

<m>	1 to 8, index of the mask
<n>	1 to 8, index of the segment
<o>	1 to *, index of the segment point

Parameters:

<Y>	Range: -1E+26 to 1E+26
	Increment: 1E-06
	*RST: 0
	Default unit: V

Example: See [Section 18.5.2, "Creating a mask"](#), on page 915.

Usage: Asynchronous command

Manual operation: See ["Point, X, Y"](#) on page 334

MTES<m>:SEGMent<n>:REMOve

Deletes the specified mask segment.

Suffix:

<m>	1 to 8, index of the mask
<n>	1 to 8, index of the segment

Usage:

Setting only
Asynchronous command

Manual operation: See ["Delete, Delete all"](#) on page 335

MTES<m>:SEGMent<n>:VALid?

Checks the validity of the indicated segment. The segment is invalid if one of its points is invalid. See ["Mask Definition"](#) on page 329.

Suffix:

<m>	1 to 8, index of the mask
<n>	1 to 8, index of the segment

Return values:

<Valid>	OFF ON
	ON = valid
	OFF = invalid
	*RST: ON

Usage: Query only
Asynchronous command

18.17.1.3 Actions

MTES<m>:ONViolation:BEEP.....	1183
MTES<m>:ONViolation:SCReenshot.....	1183
MTES<m>:ONViolation:STOP.....	1183
MTES<m>:ONViolation:TRIGgerout.....	1184
MTES<m>:ONViolation:WFMSave.....	1184

MTES<m>:ONViolation:BEEP <Beep>

Generates a beep sound if the command is set to SUCCess or VIOlation.

Suffix:

<m> 1 to 8, index of the mask

Parameters:

<Beep> NOAction | SUCCess | VIOlation
*RST: NOAction

Usage: Asynchronous command

Manual operation: See "Beep" on page 335

MTES<m>:ONViolation:SCReenshot <SaveScreenshot>

Saves the waveform data to file if the command is set to SUCCess or VIOlation.

To configure the screenshot settings, use the commands described in [Section 18.13.9, "Screenshots"](#), on page 1114.

Suffix:

<m> 1 to 8, index of the mask

Parameters:

<SaveScreenshot> NOAction | SUCCess | VIOlation
*RST: NOAction

Usage: Asynchronous command

Manual operation: See "Screenshot" on page 336

MTES<m>:ONViolation:STOP <StopAcq>

Stops the running acquisition if the command is set to SUCCess or VIOlation.

Suffix:

<m> 1 to 8, index of the mask

Parameters:

<StopAcq> NOAction | SUCCESS | VIOLation
 *RST: NOAction

Usage: Asynchronous command

Manual operation: See ["Stop acq"](#) on page 336

MTESt<m>:ONViolation:TRIGgerout <TrigOutPls>

Sends an outgoing pulse to the [Trigger Out] connector if the command is set to SUCCESS or VIOLation.

To configure the pulse, use the following commands:

- [TRIGger:ACTions:OUT:SOURce](#) on page 1039
- [TRIGger:ACTions:OUT:POLarity](#) on page 1040
- [TRIGger:ACTions:OUT:DELay](#) on page 1039
- [TRIGger:ACTions:OUT:PLENgtH](#) on page 1039

Suffix:

<m> 1 to 8, index of the mask

Parameters:

<TrigOutPls> NOAction | SUCCESS | VIOLation
 *RST: NOAction

Usage: Asynchronous command

Manual operation: See ["Trigger out pulse"](#) on page 336

MTESt<m>:ONViolation:WFMSave <SaveWfm>

Saves the waveform data to file if the command is set to SUCCESS or VIOLation.

To define the path and file names, use the EXPORT:WAVEform:AUTonaming:* commands:

- [EXPORT:WAVEform:AUTonaming:NAME](#) on page 1105
- [EXPORT:WAVEform:AUTonaming:PATH](#) on page 1106
- [EXPORT:WAVEform:AUTonaming:TYPE](#) on page 1106

Suffix:

<m> 1 to 8, index of the mask

Parameters:

<SaveWfm> NOAction | SUCCESS | VIOLation
 *RST: NOAction

Usage: Asynchronous command

Manual operation: See ["Save wfm"](#) on page 336

18.17.1.4 Results

MTES<m>:RESult:COUNT:FWAVeforms?	1185
MTES<m>:RESult:COUNT:PWAVeforms?	1185
MTES<m>:RESult:COUNT:WAVeforms?	1185
MTES<m>:RESult:FRATe?	1186
MTES<m>:RESult[:RESult]?	1186

MTES<m>:RESult:COUNT:FWAVeforms?

Returns the number of failed acquisitions.

Suffix:

<m> 1 to 8, index of the mask

Return values:

<AcqsFailed> Range: 0 to 1000000000000000
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

Manual operation: See "[Failed acq.](#)" on page 330

MTES<m>:RESult:COUNT:PWAVeforms?

Returns the number of acquisitions that passed the test successfully.

Suffix:

<m> 1 to 8, index of the mask

Return values:

<AcqsPassed> Range: 0 to 1000000000000000
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

Manual operation: See "[Passed acq.](#)" on page 330

MTES<m>:RESult:COUNT:WAVeforms?

Returns the number of tested acquisitions.

Suffix:

<m> 1 to 8, index of the mask

Return values:

<AcqsCompleted> Range: 0 to 1000000000000000
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

Manual operation: See ["Total acq."](#) on page 330

MTESt<m>:RESult:FRATe?

Returns the fail rate, the ratio of failed acquisitions to the number of tested acquisitions.

Suffix:
<m> 1 to 8, index of the mask

Return values:
<FailRate> Range: -1E+26 to 1E+26
Increment: 0
*RST: 0
Default unit: %

Usage: Query only
Asynchronous command

Manual operation: See ["Fail rate"](#) on page 331

MTESt<m>:RESult[:RESult]?

Returns the overall test result.

Suffix:
<m> 1 to 8, index of the mask

Return values:
<TestResult> PASS | FAIL
*RST: PASS

Usage: Query only
Asynchronous command

Manual operation: See ["Result"](#) on page 331

18.17.2 Frequency response analysis (option R&S MXO5C-K36)

- [Frequency response analysis settings](#)..... 1187
- [Frequency response analysis amplitude profile](#)..... 1194
- [Frequency response analysis calibration settings](#)..... 1195
- [Frequency response analysis diagram settings](#)..... 1196
- [Frequency response analysis results](#)..... 1200
- [Reference waveforms in frequency response analysis](#)..... 1204
- [Frequency response analysis export](#)..... 1208

18.17.2.1 Frequency response analysis settings

FRANalysis:STATe.....	1187
FRANalysis:ENABle.....	1187
FRANalysis:AUToscale.....	1188
FRANalysis:AMPLitude:MODE.....	1188
FRANalysis:FREQuency:MODE.....	1188
FRANalysis:FREQuency:STARt.....	1188
FRANalysis:FREQuency:STOP.....	1189
FRANalysis:GENerator:AMPLitude.....	1189
FRANalysis:GENerator:LOAD.....	1189
FRANalysis:GENerator[:CHANnel].....	1189
FRANalysis:HDEFinition[:ENABle].....	1190
FRANalysis:INPut[:SOURce].....	1190
FRANalysis:MEASurement:DELay:STATe.....	1190
FRANalysis:MEASurement:DELay:MODE.....	1190
FRANalysis:MEASurement:DELay[:TIME].....	1191
FRANalysis:MEASurement:DELay:PERiod[:NUMBer].....	1191
FRANalysis:MEASurement:POINt[:DISPlay].....	1191
FRANalysis:MEASurement:RBW.....	1192
FRANalysis:OUTPut[:SOURce].....	1192
FRANalysis:POINts:LOGarithmic.....	1192
FRANalysis:POINts:MODE.....	1192
FRANalysis:POINts:TOTal.....	1193
FRANalysis:REPeat.....	1193
FRANalysis:RESet.....	1193
FRANalysis:PHASe:MAXimum.....	1193

FRANalysis:STATe <Value>

Starts the frequency response analysis.

Parameters:

<Value> RUN | STOP | OFF

Usage: Asynchronous command

Manual operation: See "Run" on page 346

FRANalysis:ENABle <State>

Enables the frequency response analysis application.

If the frequency response analysis is disabled, the instrument does not accept any `FRANalysis` command.

You can start the analysis with `FRANalysis:STATe`.

Parameters:

<State> OFF | ON

Usage: Asynchronous command

FRANalysis:AUToscale <AutoScale>

Enables the auto scaling function for each measurement.

Parameters:

<AutoScale> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Auto scale"](#) on page 351

FRANalysis:AMPLitude:MODE <AmplitudeMode>

Selects, if the amplitude is a constant value ([FRANalysis:GENerator:AMPLitude](#)) or is defined as an amplitude profile.

Parameters:

<AmplitudeMode> CONStant | PROFile
 *RST: CONStant

Usage: Asynchronous command

Manual operation: See ["Amplitude mode"](#) on page 347

FRANalysis:FREQuency:MODE <FrequencyMode>

Selects between single frequency and sweep analysis.

Parameters:

<FrequencyMode> SWEep | SINGLE
 *RST: SWEep

Usage: Asynchronous command

Manual operation: See ["Frequency mode"](#) on page 346

FRANalysis:FREQuency:START <StartFrequency>

Sets the start frequency of the sweep.

Parameters:

<StartFrequency> Range: 0.01 to 100E+6
 Increment: 1
 *RST: 100
 Default unit: Hz

Usage: Asynchronous command

Manual operation: See ["Start, Stop"](#) on page 346

FRANalysis:FREQuency:STOP <StopFrequency>

Sets the stop frequency of the sweep.

Parameters:

<StopFrequency> Range: 0.01 to 100E+6
 Increment: 1
 *RST: 10000
 Default unit: Hz

Usage: Asynchronous command

Manual operation: See "[Start, Stop](#)" on page 346

FRANalysis:GENerator:AMPLitude <GenAmplitude>

Sets a fixed amplitude for the frequency response analysis.

Parameters:

<GenAmplitude> Range: 0.01 to 12
 Increment: 0.1
 *RST: 1
 Default unit: Vpp

Usage: Asynchronous command

Manual operation: See "[Amplitude](#)" on page 347

FRANalysis:GENerator:LOAD <GenLoad>

Selects the generator voltage display for 50Ω or high impedance load.

Parameters:

<GenLoad> FIFTy | HIZ
 HIZ: high input impedance
 *RST: FIFTy

Usage: Asynchronous command

Manual operation: See "[User load](#)" on page 347

FRANalysis:GENerator[:CHANnel] <GenCh>

Selects the built-in generator to start a frequency sweep for a defined frequency range.

Parameters:

<GenCh> GEN1 | GEN2
 *RST: GEN1

Usage: Asynchronous command

Manual operation: See "[Generator](#)" on page 347

FRANalysis:HDEfinition[:ENABle] <HDMode>

Disables the HD mode, which is active by default. In particular, disable the HD mode if you analyze switching peaks.

Parameters:

<HDMode> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["HD mode"](#) on page 351

FRANalysis:INPut[:SOURce] <InputChannel>

Sets the channel for the input signal of the DUT.

Parameters:

<InputChannel> C1 | C2 | ... | C8
*RST: C1

Usage: Asynchronous command

Manual operation: See ["Input"](#) on page 345

FRANalysis:MEASurement:DELay:STATe <MeasDelay>

Enables the measurement delay.

Parameters:

<MeasDelay> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Meas. delay mode, Delay time, Delay period"](#) on page 350

FRANalysis:MEASurement:DELay:MODE <MeasDelayMode>

Selects the delay mode.

Parameters:

<MeasDelayMode> TIME | PERiod
*RST: TIME

Usage: Asynchronous command

Manual operation: See ["Meas. delay mode, Delay time, Delay period"](#) on page 350

FRANalysis:MEASurement:DElay[:TIME] <MeasDelayTime>

Sets a time delay, that the system waits before measuring the next point of the plot. This is helpful in systems that need more time to adapt to the new frequency, for example if filters with significant time group delays are present.

The settings takes effect if if `FRANalysis:MEASurement:DElay:STATe = ON` and `FRANalysis:MEASurement:DElay:MODE = PERiod`.

Parameters:

<MeasDelayTime> Range: 0 to 10
 Increment: 0.001
 *RST: 0
 Default unit: s

Example:

```
FRANalysis:MEASurement:DElay:STATe ON
FRANalysis:MEASurement:DElay:MODE TIME
FRANalysis:MEASurement:DElay 0.005
```

Usage: Asynchronous command

Manual operation: See "[Meas. delay mode, Delay time, Delay period](#)" on page 350

FRANalysis:MEASurement:DElay:PERiod[:NUMBer] <MeasDelayPeriod>

Sets a period delay, which the system waits before measuring the next point of the plot.

The settings takes effect if if `FRANalysis:MEASurement:DElay:STATe = ON` and `FRANalysis:MEASurement:DElay:MODE = PERiod`.

Parameters:

<MeasDelayPeriod> Range: 0.01 to 1000
 Increment: 0.01
 *RST: 1

Example:

```
FRANalysis:MEASurement:DElay:STATe ON
FRANalysis:MEASurement:DElay:MODE PERiod
FRANalysis:MEASurement:DElay:PERiod 0.05
```

Usage: Asynchronous command

Manual operation: See "[Meas. delay mode, Delay time, Delay period](#)" on page 350

FRANalysis:MEASurement:POINt[:DISPlay] <Points>

Enables the display of the measurement points for the frequency response analysis.

Parameters:

<Points> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See "[Display points](#)" on page 351

FRANalysis:MEASurement:RBW <RBW>

Sets the resolution bandwidth, which determines the number of measurements that are used for creating the plot.

Parameters:

<RBW> HIGH | MID | LOW
*RST: MID

Usage: Asynchronous command

Manual operation: See ["RBW"](#) on page 350

FRANalysis:OUTPut[:SOURce] <OutputChannel>

Sets the channel for the output signal of the DUT.

Parameters:

<OutputChannel> C1 | C2 | ... | C8
*RST: C2

Usage: Asynchronous command

Manual operation: See ["Output"](#) on page 346

FRANalysis:POINts:LOGarithmic <PtsPerDecade>

Selects the number of points that are measured per decade, if [FRANalysis:POINts:MODE](#) is set to `DECade`.

Parameters:

<PtsPerDecade> Range: 10 to 500
Increment: 1
*RST: 10

Usage: Asynchronous command

Manual operation: See ["Points"](#) on page 346

FRANalysis:POINts:MODE <PointsMode>

Selects, if the number of points for the FRA are measured as total or per decade.

You can set the number of points with [FRANalysis:POINts:TOTal](#)/ [FRANalysis:POINts:LOGarithmic](#).

Parameters:

<PointsMode> TOTal | DECade
*RST: DECade

Usage: Asynchronous command

Manual operation: See ["Points"](#) on page 346

FRANalysis:POINts:TOTal <TotalPoints>

Set the total number of points for the FRA analysis, if [FRANalysis:POINts:MODE](#) on page 1192 is set to `TOTal`.

Parameters:

<TotalPoints> Range: 10 to 5000
 Increment: 1
 *RST: 100

Usage: Asynchronous command

Manual operation: See "[Points](#)" on page 346

FRANalysis:REPeat <Repeat>

Repeats the measurement, using the same parameters.

Parameters:

<Repeat> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See "[Repeat](#)" on page 346

FRANalysis:RESet

Resets the frequency response analysis.

Usage: Setting only
 Asynchronous command

FRANalysis:PHASe:MAXimum <MaxPhase>

Sets the upper boundary of the vertical phase window.

The lower boundary is given by "Maximum phase" - 360°.

By default, the "Maximum phase" is set to 180° for a phase window ranging from -180° to 180° accordingly.

Parameters:

<MaxPhase> Range: 0 to 360
 Increment: 1
 *RST: 180
 Default unit: °

Usage: Asynchronous command

Manual operation: See "[Maximum phase](#)" on page 350

18.17.2.2 Frequency response analysis amplitude profile

FRANalysis:AMPLitude:PROFile:COUNT.....	1194
FRANalysis:AMPLitude:PROFile:APOint.....	1194
FRANalysis:AMPLitude:PROFile:POINt<m>:REMove.....	1194
FRANalysis:AMPLitude:PROFile:SORT.....	1194
FRANalysis:AMPLitude:PROFile:MODE.....	1195
FRANalysis:AMPLitude:PROFile:POINt<m>:FREQuency.....	1195
FRANalysis:AMPLitude:PROFile:POINt<m>:AMPLitude.....	1195

FRANalysis:AMPLitude:PROFile:COUNT <Value>

Sets the number of defined points for the amplitude profile.

Parameters:

<Value>

Usage: Asynchronous command

Manual operation: See ["Add"](#) on page 348

FRANalysis:AMPLitude:PROFile:APOint

Adds a new step to the amplitude profile.

Usage: Setting only
Asynchronous command

Manual operation: See ["Add"](#) on page 348

FRANalysis:AMPLitude:PROFile:POINt<m>:REMove

Removes the specified step from the amplitude profile.

Suffix:

<m> 1..*, step index

Usage: Setting only
Asynchronous command

Manual operation: See ["Delete"](#) on page 349

FRANalysis:AMPLitude:PROFile:SORT

Sorts the steps in the amplitude table by frequency, starting with the lowest frequency.

Usage: Setting only
Asynchronous command

Manual operation: See ["Sort"](#) on page 349

FRANalysis:AMPLitude:PROFile:MODE <VoltageChange>

Selects if the voltage change is done as a single step or as a ramp.

Parameters:

<VoltageChange> SINGle | RAMP
 *RST: SINGle

Usage: Asynchronous command

Manual operation: See "[Voltage change](#)" on page 348

FRANalysis:AMPLitude:PROFile:POINt<m>:FREQUency <Frequency>

Sets the start frequency for the selected point.

Suffix:

<m> Index of the amplitude profile point

Parameters:

<Frequency> Range: 0.01 to 100E6
 Increment: 1
 *RST: 100
 Default unit: Hz

Usage: Asynchronous command

Manual operation: See "[Step start freq, Amplitude](#)" on page 348

FRANalysis:AMPLitude:PROFile:POINt<m>:AMPLitude <Amplitude>

Sets the amplitude for the selected point.

Suffix:

<m> Index of the amplitude profile point

Parameters:

<Amplitude> Range: 0 to 5.995
 Increment: 0.1
 *RST: 1
 Default unit: Vpp

Usage: Asynchronous command

Manual operation: See "[Step start freq, Amplitude](#)" on page 348

18.17.2.3 Frequency response analysis calibration settings

FRANalysis:CALibration:CALibration	1196
FRANalysis:CALibration:RESult?	1196
FRANalysis:CALibration:STATe	1196

FRANalysis:CALibration:CALibration

Runs a calibration sequence.

Usage: Event

Manual operation: See ["Start calibration"](#) on page 355

FRANalysis:CALibration:RESult?

Returns the result of the calibration.

Return values:

<States> PASS | FAIL | RUN | NOAL
 PASS: the calibration is successful.
 FAIL: the calibration failed.
 RUN: a calibration cycle is running.
 NOAL: no active calibration.
 *RST: NOAL

Usage: Query only

Manual operation: See ["Start calibration"](#) on page 355

FRANalysis:CALibration:STATe <UseCalData>

If ON, the user calibration data is used for the frequency response analysis.

Parameters:

<UseCalData> OFF | ON
 *RST: OFF

Manual operation: See ["Use calibration data"](#) on page 355

18.17.2.4 Frequency response analysis diagram settings

FRANalysis:PHASe:ENABle	1197
FRANalysis:PHASe:OFFSet	1197
FRANalysis:PHASe:SCALe	1197
FRANalysis:GAIN:ENABle	1197
FRANalysis:GAIN:OFFSet	1197
FRANalysis:GAIN:SCALe	1198
FRANalysis:AMPLitude:SCALe	1198
FRANalysis:AMPLitude:ENABle	1198
FRANalysis:AMPLitude:OFFSet	1198
FRANalysis:PHASe:DATA?	1199
FRANalysis:FREQuency:DATA?	1199
FRANalysis:GAIN:DATA?	1199

FRANalysis:PHASe:ENABle <State>

Enables the phase waveform for the frequency response analysis.

Parameters:

<State> OFF | ON
 *RST: OFF

Usage: Asynchronous command

FRANalysis:PHASe:OFFSet <VerticalOffset>

Sets a vertical offset of the phase waveform.

Parameters:

<VerticalOffset> Range: -10000 to 10000
 Increment: 0.001
 *RST: 0
 Default unit: °

Usage: Asynchronous command

Manual operation: See "[Vertical offset](#)" on page 352

FRANalysis:PHASe:SCALE <VerticalScale>

Sets the vertical scale for the phase waveform.

Parameters:

<VerticalScale> Range: 1 to 180
 Increment: 1
 *RST: 36
 Default unit: °/div

Usage: Asynchronous command

Manual operation: See "[Vertical scale](#)" on page 352

FRANalysis:GAIN:ENABle <State>

Enables the gain waveform for the frequency response analysis.

Parameters:

<State> OFF | ON
 *RST: OFF

Usage: Asynchronous command

FRANalysis:GAIN:OFFSet <VerticalOffset>

Sets a vertical offset of the gain waveform.

Parameters:

<VerticalOffset> Range: -2000 to 2000
 Increment: 0.001
 *RST: 10
 Default unit: dB

Usage: Asynchronous command

Manual operation: See ["Vertical offset"](#) on page 352

FRANalysis:GAIN:SCALE <VerticalScale>

Sets the vertical scale for the gain waveform.

Parameters:

<VerticalScale> Range: 0.1 to 20
 Increment: 1
 *RST: 10
 Default unit: dB/div

Usage: Asynchronous command

Manual operation: See ["Vertical scale"](#) on page 352

FRANalysis:AMPLitude:SCALE <VerticalScale>

Sets the vertical scale for the amplitude waveform.

Parameters:

<VerticalScale> Range: 0.01 to 10
 Increment: 0.01
 *RST: 0.5
 Default unit: Vpp/div

Usage: Asynchronous command

FRANalysis:AMPLitude:ENABLE <State>

Enables the amplitude signal for the frequency response analysis. You can then define the amplitude profile of the signal.

Parameters:

<State> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Amplitude profile"](#) on page 347

FRANalysis:AMPLitude:OFFSet <VerticalOffset>

Sets a vertical offset of the amplitude waveform.

Parameters:

<VerticalOffset> Range: -100 to 100
 Increment: 0.01
 *RST: 5
 Default unit: Vpp

Usage: Asynchronous command

FRANalysis:PHASe:DATA?

Returns the data of the phase as a list of comma-separated values in degree.

Return values:

<Data> Comma-separated list of values

Example:

FRAN:PHAS:DATA?

Result:

```
-0.07463742650985239,-0.09417628145200041,
-0.1457021392091207,-0.1914790795969807,
-0.2494368612845221,-0.3415108478964939,
-0.4350150706042513,-0.5673151547214843,
-0.7363486980048108,-0.9055923620805615,
-1.0829557075417
```

Usage: Query only
 Asynchronous command

FRANalysis:FREQuency:DATA?

Returns the data of the frequency points for which gain and phase have been calculated as a list of comma-separated values in Hz.

Return values:

<Data> Comma-separated list of values

Example:

FRAN:FREQ:DATA?

Result:

```
-0.07463742650985239,-0.09417628145200041,
-0.1457021392091207,-0.1914790795969807,
-0.2494368612845221,-0.3415108478964939,
-0.4350150706042513,-0.5673151547214843,
-0.7363486980048108,-0.9055923620805615,
-1.0829557075417
```

Usage: Query only
 Asynchronous command

FRANalysis:GAIN:DATA?

Returns the data of the gain as a list of comma-separated values in dB.

Return values:**<Data>** Comma-separated list of values**Example:**

FRAN:GAIN:DATA?

Result:

0.4381956630254851,0.4593246383252179,
 0.461895233375762,0.4570717993766185,
 0.4623802509651942,0.4533450898899926,
 0.4408194360143725,0.4221600784741697,
 0.4483342212879299,0.4473558449908476,
 0.4915016244058707

Usage:

Query only

Asynchronous command

18.17.2.5 Frequency response analysis results

FRANalysis:RESult:STATe.....	1200
FRANalysis:MARGin:STATe.....	1200
FRANalysis:MARGin:GAIN:FREQuency?.....	1201
FRANalysis:MARGin:GAIN:VALue?.....	1201
FRANalysis:MARGin:PHASe:FREQuency?.....	1201
FRANalysis:MARGin:PHASe:VALue?.....	1201
FRANalysis:MARKer<m>:STATe.....	1201
FRANalysis:MARKer<m>:FREQuency.....	1202
FRANalysis:MARKer<m>:GAIN?.....	1202
FRANalysis:MARKer<m>:PHASe?.....	1202
FRANalysis:MARKer<m>:DIFFerence:FREQuency?.....	1202
FRANalysis:MARKer<m>:DIFFerence:GAIN?.....	1203
FRANalysis:MARKer<m>:DIFFerence:PHASe?.....	1203
FRANalysis:MARKer<m>:INDex?.....	1203
FRANalysis:MARKer<m>:SSCRen.....	1203

FRANalysis:RESult:STATe <Table>

Enables the display of the result table for the FRA.

Parameters:

<Table> OFF | ON
 *RST: ON

Usage:

Asynchronous command

Manual operation: See ["Result table"](#) on page 352**FRANalysis:MARGin:STATe <Margins>**

Enables the display of the margin table for the FRA.

Parameters:

<Margins> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See "[Margin](#)" on page 352

FRANalysis:MARGin:GAIN:FREQuency?

Returns the frequency of the gain margin.

Return values:

<Frequency>

Usage: Query only
Asynchronous command

FRANalysis:MARGin:GAIN:VALue?

Returns the value of the gain margin.

Return values:

<Phase>

Usage: Query only
Asynchronous command

FRANalysis:MARGin:PHASe:FREQuency?

Returns the frequency of the phase margin.

Return values:

<Frequency>

Usage: Query only
Asynchronous command

FRANalysis:MARGin:PHASe:VALue?

Returns the value of the phase margin.

Return values:

<Phase>

Usage: Query only
Asynchronous command

FRANalysis:MARKer<m>:STATe <Markers>

Enables the display of the marker table for the FRA.

Suffix:

<m> Irrelevant, omit the suffix.

Parameters:

<Markers> OFF | ON
*RST: ON

Usage:

Asynchronous command

Manual operation: See "[Markers](#)" on page 352

FRANalysis:MARKer<m>:FREQuency <Frequency>

Sets the frequency for the specified marker, which defines the horizontal marker position.

Suffix:

<m> 1..2
Selects the marker number.

Parameters:

<Frequency> Numeric value in Hz

Usage:

Asynchronous command

FRANalysis:MARKer<m>:GAIN?

Returns the gain for the specified marker.

Suffix:

<m> 1..2
Selects the marker number.

Usage:

Query only
Asynchronous command

FRANalysis:MARKer<m>:PHASe?

Returns the phase value for the specified marker.

Suffix:

<m> 1..2
Selects the marker number.

Usage:

Query only
Asynchronous command

FRANalysis:MARKer<m>:DIFFerence:FREQuency?

Returns the delta value of the frequency between the two markers.

Suffix:

<m> Irrelevant, omit the suffix.

Return values:

<DeltaFrequency>

Usage:

Query only
Asynchronous command

FRANalysis:MARKer<m>:DIFFerence:GAIN?

Returns the delta value of the gain between the two markers.

Suffix:

<m> Irrelevant, omit the suffix.

Return values:

<DeltaGain>

Usage:

Query only
Asynchronous command

FRANalysis:MARKer<m>:DIFFerence:PHASe?

Returns the delta value of the phase between the two markers.

Suffix:

<m> Irrelevant, omit the suffix.

Return values:

<DeltaPhase>

Usage:

Query only
Asynchronous command

FRANalysis:MARKer<m>:INDEX?

Returns the point index in the plot where the specified marker is positioned.

Suffix:

<m> 1..2
Selects the marker number.

Return values:

<Index> The lowest index is 0, which corresponds to line 1 in the result table.
PointIndex = # in result table - 1

Usage:

Query only
Asynchronous command

FRANalysis:MARKer<m>:SSCReen

Resets the markers to their initial positions. Reset is helpful if the markers have disappeared from the display or need to be moved for a larger distance.

Suffix:

<m> Irrelevant, omit the suffix.

Usage:

Setting only
Asynchronous command

18.17.2.6 Reference waveforms in frequency response analysis

FRANalysis:REFCurve<rc>:CLEAr.....	1204
FRANalysis:REFCurve<rc>:DATA?.....	1204
FRANalysis:REFCurve<rc>:NAME.....	1204
FRANalysis:REFCurve<rc>:OFFSet.....	1205
FRANalysis:REFCurve<rc>:OPEN.....	1205
FRANalysis:REFCurve<rc>:SAVE.....	1205
FRANalysis:REFCurve<rc>:SCALE.....	1206
FRANalysis:REFCurve<rc>:SOURce.....	1206
FRANalysis:REFCurve<rc>:ENABLE.....	1206
FRANalysis:REFCurve<rc>:TOORiginal.....	1206
FRANalysis:REFCurve<rc>:UPDate.....	1207
FRANalysis:REFCurve<rc>:VMODE.....	1207
FRANalysis:MARKer<m>:REFerence<rc>?.....	1207
FRANalysis:MARKer<m>:DIFFerence:REFerence<rc>?.....	1208

FRANalysis:REFCurve<rc>:CLEAr

Deletes the selected reference waveform. It disappears from the display, and its memory is deleted.

Suffix:

<rc> 1...4, index of the reference waveform

Usage:

Setting only
Asynchronous command

Manual operation: See "Clear" on page 359

FRANalysis:REFCurve<rc>:DATA?

Returns the data of the specified reference waveform.

Suffix:

<rc> 1...4, index of the reference waveform

Return values:

<Data> Comma-separated values

Usage:

Query only
Asynchronous command

FRANalysis:REFCurve<rc>:NAME <Name>

Defines the name of the reference waveform file to be loaded, saved or deleted.

Suffix:

<rc> 1...4, index of the reference waveform

Parameters:

<Name> String with the file path, filename and extension.

Usage:

Asynchronous command

Manual operation: See ["Save as"](#) on page 359

FRANalysis:REFCurve<rc>:OFFSet <VerticalOffset>

The vertical offset moves the reference waveform vertically. Enter a value with the unit of the waveform.

Suffix:

<rc> 1...4, index of the reference waveform

Parameters:

<VerticalOffset> Range: -100 to 100
Increment: 1
*RST: 5

Usage:

Asynchronous command

Manual operation: See ["Vertical offset"](#) on page 361

FRANalysis:REFCurve<rc>:OPEN

Loads the reference waveform file selected by [FRANalysis:REFCurve<rc>:NAME](#).

Suffix:

<rc> 1...4, index of the reference waveform

Usage:

Event
Asynchronous command

Manual operation: See ["Open"](#) on page 359

FRANalysis:REFCurve<rc>:SAVE

Saves the FRA reference waveform to the file defined by [FRANalysis:REFCurve<rc>:NAME](#).

Suffix:

<rc> 1...4, index of the reference waveform

Usage:

Event
Asynchronous command

Manual operation: See ["Save as"](#) on page 359

FRANalysis:REFCurve<rc>:SCALE <VerticalScale>

Sets the vertical scale, which defines the displayed amplitude of the selected waveform.

Suffix:

<rc> 1...4, index of the reference waveform

Parameters:

<VerticalScale> Range: -100 to 100
Increment: 1
*RST: 0.5

Usage: Asynchronous command

Manual operation: See "[Vertical scale](#)" on page 360

FRANalysis:REFCurve<rc>:SOURCE <Source>

Selects the source waveform of the reference.

Suffix:

<rc> 1...4, index of the reference waveform

Parameters:

<Source> FGAin | FPHase | FREF1 | FREF2 | FREF3 | FREF4

Usage: Asynchronous command

Manual operation: See "[Source](#)" on page 358

FRANalysis:REFCurve<rc>:ENABLE <State>

Enables the display of the reference waveform in the diagram. Before you can display it, create the reference waveform.

Suffix:

<rc> 1...4, index of the reference waveform

Parameters:

<State> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See "[Display](#)" on page 358

FRANalysis:REFCurve<rc>:TOORiginal

Restores the original vertical settings of the reference waveform.

Suffix:

<rc> 1...4, index of the reference waveform

Usage: Setting only
Asynchronous command

Manual operation: See ["Set to original"](#) on page 360

FRANalysis:REFCurve<rc>:UPDate

Copies the selected source waveform with all its settings to the memory of the reference waveform. If there is a previously defined reference waveform in this memory, it is updated by the current source waveform.

Suffix:
<rc> 1...4, index of the reference waveform

Usage: Event
Asynchronous command

Manual operation: See ["Create/Update"](#) on page 359

FRANalysis:REFCurve<rc>:VMODE <VerticalMode>

Selects the type of vertical settings for the reference waveform.

Suffix:
<rc> 1...4, index of the reference waveform

Parameters:
<VerticalMode> COUPled | INDependent

COUPled
Vertical position and scale of the source are used.

INDependent
Scaling and position can be set specific to the reference waveform.

*RST: INDependent

Usage: Asynchronous command

Manual operation: See ["Vertical mode"](#) on page 360

FRANalysis:MARKer<m>:REFerence<rc>?

Returns the vertical value of the reference waveform at the specified marker.

Suffix:
<m> 1..2
Selects the marker number.

<rc> 1...4, index of the reference waveform

Usage: Query only
Asynchronous command

FRANalysis:MARKer<m>:DIFFerence:REFerence<rc>?

Returns the difference between the two markers on the reference waveform. If no marker values are exist, or they are invalid, an execution error is returned.

Suffix:

<m> Irrelevant, omit the suffix.
 <rc> 1...4, index of the reference waveform

Return values:

<DeltaReference> Value of the difference

Usage:

Query only
 Asynchronous command

18.17.2.7 Frequency response analysis export

EXPort:RESult:SElect:FRA:MARGin..... 1208
 EXPort:RESult:SElect:FRA:MARKer..... 1208
 EXPort:RESult:SElect:FRA:RESult..... 1208

EXPort:RESult:SElect:FRA:MARGin <MarginResult>

If enabled, includes the margin results in the results export file of the FRA.

Parameters:

<MarginResult> OFF | ON
 *RST: OFF

Usage:

Asynchronous command

Manual operation: See "FRA results" on page 356

EXPort:RESult:SElect:FRA:MARKer <MarkerResult>

If enabled, includes the marker results in the results export file of the FRA.

Parameters:

<MarkerResult> OFF | ON
 *RST: OFF

Usage:

Asynchronous command

Manual operation: See "FRA results" on page 356

EXPort:RESult:SElect:FRA:RESult <Result>

If enabled, includes the frequency response analysis results, including the frequency, gain, phase and amplitude, in the results export file of the FRA.

Parameters:

<Result> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See "FRA results" on page 356

18.17.3 Power analysis (option R&S MXO5C-K31)

Some of the commands in the following section are asynchronous. An overlapping or asynchronous command does not automatically finish executing before the next command starts executing. If overlapping commands must be executed in a defined order, e.g. to avoid wrong measurement results, they must be serviced sequentially.

To prevent an overlapping execution of commands, one of the commands *OPC, *OPC? or *WAI can be used after the command or a command set.

For more information, see:

- www.rohde-schwarz.com/rc-via-scpj, section "Command sequence and synchronization"

Overview of statistic results

The remote commands for the power analysis measurements can retrieve statistic results. The abbreviations in the commands have the following meaning:

Command	Description
POWer<m>:xxx:RESult:nnn[:ACTual]?	Current measurement result
POWer<m>:xxx:RESult:nnn:AVERage?	Average of the measurement results
POWer<m>:xxx:RESult:nnn:EVTCount?	Number of calculated measurement results (periods)
POWer<m>:xxx:RESult:nnn:RMS?	RMS value of the measurement results
POWer<m>:xxx:RESult:nnn:PPEak?	Positive peak value of the measurement results
POWer<m>:xxx:RESult:nnn:NPEak?	Negative peak value of the measurement results
POWer<m>:xxx:RESult:xxx:STDDev?	Standard deviation of the measurement results
POWer<m>:xxx:RESult:nnn:WFMCCount?	Number of calculated waveforms

- [General settings](#)..... 1210
- [Power quality](#)..... 1212
- [Power harmonics](#)..... 1225
- [Switching loss](#)..... 1234
- [Turn on/off time](#)..... 1244
- [Power efficiency](#)..... 1248
- [Safe operating area \(SOA\)](#)..... 1255

• Power waveform.....	1265
• Reference level.....	1267
• Power analysis data.....	1273

18.17.3.1 General settings

POWer<m>[:ENABle].....	1210
POWer<m>:TYPE.....	1210
POWer<m>:ASKew[:EXECute].....	1211
EXPort:RESult:SElect:POWer<m>.....	1211
POWer<m>:EFFiciency:STATistics[:ENABle].....	1211
POWer<m>:SWITching:STATistics:ENABle.....	1211
POWer<m>:QUALity:STATistics[:ENABle].....	1211
POWer<m>:EFFiciency:STATistics:RESet.....	1211
POWer<m>:SWITching:STATistics:RESet.....	1211
POWer<m>:QUALity:STATistics:RESet.....	1211
POWer<m>:EFFiciency:STATistics:WFMCount?.....	1212
POWer<m>:SWITching:STATistics:WFMCount?.....	1212
POWer<m>:QUALity:STATistics:WFMCount?.....	1212

POWer<m>[:ENABle] <State>

Enables the power measurement instance.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<State> OFF | ON

Usage: Asynchronous command

Manual operation: See "+ Add" on page 363

POWer<m>:TYPE <Type>

Sets the type for the respective power analysis measurement.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Type> QUALity | HARMonics | SWITching | ONOFF | EFFiciency | SOA
 SWITching = switching loss
 ONOFF = turn on/off time
 SOA = safe operating area

Example:

POW1:TYPE QUAL
 Sets the first power analysis measurement to quality.

Usage: Asynchronous command

Manual operation: See "+ Add" on page 363

POWer<m>:ASKew[:EXECute]

Performs auto deskew adjustment.

Suffix:

<m> Irrelevant, omit the suffix.

Usage:

Event
Asynchronous command

Manual operation: See ["Auto deskew"](#) on page 364

EXPort:RESult:SELEct:POWer<m> <ExportResults>

If enabled, includes the results of selected power analysis measurement in the results export file.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ExportResults> OFF | ON
*RST: OFF

Usage:

Asynchronous command

POWer<m>:EFFiciency:STATistics[:ENABLE] <State>**POWer<m>:SWITching:STATistics:ENABLE <State>****POWer<m>:QUALity:STATistics[:ENABLE] <State>**

The commands activate statistical calculation for the selected power measurement. Make sure that the suffix matches the selected power measurement.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<State> OFF | ON
*RST: ON

Usage:

Asynchronous command

Manual operation: See ["Statistics"](#) on page 368

POWer<m>:EFFiciency:STATistics:RESet**POWer<m>:SWITching:STATistics:RESet****POWer<m>:QUALity:STATistics:RESet**

The commands restart statistical calculation for the selected power measurement. Make sure that the suffix matches the selected power measurement.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Usage: Setting only
Asynchronous command

Manual operation: See ["Clear results"](#) on page 368

POWER<m>:EFFiciency:STATistics:WFMCount?

POWER<m>:SWITching:STATistics:WFMCount?

POWER<m>:QUALity:STATistics:WFMCount?

Return the number of waveforms included in the selected power analysis. Make sure that the suffix matches the selected power measurement.

Suffix:
<m> 1 to 6, index of the power analysis measurement

Return values:
<WaveformCount> Number of analyzed waveforms.

Usage: Query only
Asynchronous command

Manual operation: See ["Statistics"](#) on page 368

18.17.3.2 Power quality

- [Power quality setup](#)..... 1212
- [Power quality measurement display](#)..... 1214
- [Power quality results](#)..... 1217

Power quality setup

POWER<m>:QUALity:SOURce:CURRent..... 1212
 POWER<m>:QUALity:SOURce[:VOLTage]..... 1213
 POWER<m>:QUALity:SOURce:CYCLE..... 1213
 POWER<m>:QUALity:FREQuency[:VALue]..... 1213
 POWER<m>:QUALity:FREQuency:USER..... 1213
 POWER<m>:QUALity:GATE..... 1214

POWER<m>:QUALity:SOURce:CURRent <CurrentSource>

Selects the current source waveform. Analog channels and math waveforms can be used.

Suffix:
<m> 1 to 6, index of the power analysis measurement

Parameters:
<CurrentSource> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Usage: Asynchronous command

Manual operation: See ["Current"](#) on page 367

POWER<m>:QUALity:SOURce[:VOLTage] <VoltageSource>

Selects the voltage source waveform. Analog channels and math waveforms can be used.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<VoltageSource> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Usage: Asynchronous command

Manual operation: See "[Voltage](#)" on page 367

POWER<m>:QUALity:SOURce:CYCLe <CycleSource>

Selects if voltage or current is used for the cycle measurement.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<CycleSource> VOLTage | CURRent

*RST: VOLTage

Usage: Asynchronous command

Manual operation: See "[Cycle source](#)" on page 368

POWER<m>:QUALity:FREQuency[:VALue] <FundamFreq>

Sets the input frequency of the source signal in Hz.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<FundamFreq> F50 | F60 | F400 | USER | AUTO

*RST: F50

Usage: Asynchronous command

Manual operation: See "[Fund. frequency](#)" on page 367

POWER<m>:QUALity:FREQuency:USER <FundamentalFreq>

Sets the user-defined frequency, if [POWER<m>:QUALity:FREQuency\[:VALue\]](#) is set to USER.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<FundamentalFreq> Range: 10 to 1000000
 Increment: 1
 *RST: 50
 Default unit: Hz

Usage: Asynchronous command

Manual operation: See "Fund. frequency" on page 367

POWER<m>:QUALity:GATE <Gate>

Selects the gate that is used for limiting the range of the power quality measurement.

Enable the gate before you assign a measurement to it (GATE<g>:ENABLE =ON).

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Gate> Number of the gate to be used

Usage: Asynchronous command

Power quality measurement display**POWER<m>:QUALity:DISPlay:CURRent:CREStfactor <ShwCurrCrest>**

Enables the current crest factor measurement for the power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ShwCurrCrest> OFF | ON
 *RST: ON

Usage: Asynchronous command

POWER<m>:QUALity:DISPlay:CURRent:PEAK <ShwCurrPeak>

Enables the current peak measurement for the power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ShwCurrPeak> OFF | ON
 *RST: ON

Usage: Asynchronous command

POWER<m>:QUALity:DISPlay:CURRent:RMS <ShowCurrentRMS>

Enables the current RMS measurement for the power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ShowCurrentRMS> OFF | ON

*RST: ON

Usage: Asynchronous command

POWER<m>:QUALity:DISPlay:POWer:ACTive <ShwActPow>

Enables the active power measurement for the power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ShwActPow> OFF | ON

*RST: ON

Usage: Asynchronous command

POWER<m>:QUALity:DISPlay:POWer:APParent <ShwApparentPow>

Enables the apparent power measurement for the power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ShwApparentPow> OFF | ON

*RST: ON

Usage: Asynchronous command

POWER<m>:QUALity:DISPlay:POWer:PFACTor <ShwPowFact>

Enables the power factor measurement for the power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ShwPowFact> OFF | ON

*RST: ON

Usage: Asynchronous command

POWER<m>:QUALity:DISPlay:POWer:PHASe <ShowPhase>

Enables the power phase measurement for the power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ShowPhase> OFF | ON

*RST: ON

Usage: Asynchronous command

POWER<m>:QUALity:DISPlay:POWer:REACtive <ShwReactivePow>

Enables the reactive power measurement for the power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ShwReactivePow> OFF | ON

*RST: ON

Usage: Asynchronous command

POWER<m>:QUALity:DISPlay:VOLTage:CREStfactor <ShwVoltageCrest>

Enables the voltage crest factor measurement for the power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ShwVoltageCrest> OFF | ON

*RST: ON

Usage: Asynchronous command

POWER<m>:QUALity:DISPlay:VOLTage:FREQuency <ShwVoltageFreq>

Enables the voltage frequency measurement for the power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ShwVoltageFreq> OFF | ON

*RST: ON

Usage: Asynchronous command

POWER<m>:QUALity:DISPlay:VOLTage:PEAK <ShwVoltagePeak>

Enables the voltage peak value measurement for the power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ShwVoltagePeak> OFF | ON
*RST: ON

Usage: Asynchronous command

POWER<m>:QUALity:DISPlay:VOLTage:RMS <ShowVoltageRMS>

Enables the voltage RMS measurement for the power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ShowVoltageRMS> OFF | ON
*RST: ON

Usage: Asynchronous command

Power quality results

See ["Overview of statistic results"](#) on page 1209.

POWER<m>:QUALity:RESult:CURRent:CREStfactor[:ACTual]?.....	1219
POWER<m>:QUALity:RESult:CURRent:CREStfactor:AVERage?.....	1219
POWER<m>:QUALity:RESult:CURRent:CREStfactor:EVTCount?.....	1219
POWER<m>:QUALity:RESult:CURRent:CREStfactor:NPEak?.....	1219
POWER<m>:QUALity:RESult:CURRent:CREStfactor:PPEak?.....	1219
POWER<m>:QUALity:RESult:CURRent:CREStfactor:RMS?.....	1219
POWER<m>:QUALity:RESult:CURRent:CREStfactor:WFMCount?.....	1219
POWER<m>:QUALity:RESult:CURRent:CREStfactor:STDDev?.....	1219
POWER<m>:QUALity:RESult:CURRent:PEAK[:ACTual]?.....	1220
POWER<m>:QUALity:RESult:CURRent:PEAK:AVERage?.....	1220
POWER<m>:QUALity:RESult:CURRent:PEAK:EVTCount?.....	1220
POWER<m>:QUALity:RESult:CURRent:PEAK:NPEak?.....	1220
POWER<m>:QUALity:RESult:CURRent:PEAK:PPEak?.....	1220
POWER<m>:QUALity:RESult:CURRent:PEAK:RMS?.....	1220
POWER<m>:QUALity:RESult:CURRent:PEAK:WFMCount?.....	1220
POWER<m>:QUALity:RESult:CURRent:PEAK:STDDev?.....	1220
POWER<m>:QUALity:RESult:CURRent:RMS[:ACTual]?.....	1220
POWER<m>:QUALity:RESult:CURRent:RMS:AVERage?.....	1220
POWER<m>:QUALity:RESult:CURRent:RMS:EVTCount?.....	1220
POWER<m>:QUALity:RESult:CURRent:RMS:NPEak?.....	1220
POWER<m>:QUALity:RESult:CURRent:RMS:PPEak?.....	1220
POWER<m>:QUALity:RESult:CURRent:RMS:RMS?.....	1220

POWer<m>:QUALity:RESult:CURRent:RMS:WFMCount?	1220
POWer<m>:QUALity:RESult:CURRent:RMS:STDDDev?	1220
POWer<m>:QUALity:RESult:POWer:ACTive[:ACTual]?	1220
POWer<m>:QUALity:RESult:POWer:ACTive:AVERage?	1220
POWer<m>:QUALity:RESult:POWer:ACTive:EVTCount?	1220
POWer<m>:QUALity:RESult:POWer:ACTive:NPEak?	1220
POWer<m>:QUALity:RESult:POWer:ACTive:PPEak?	1221
POWer<m>:QUALity:RESult:POWer:ACTive:RMS?	1221
POWer<m>:QUALity:RESult:POWer:ACTive:WFMCount?	1221
POWer<m>:QUALity:RESult:POWer:ACTive:STDDDev?	1221
POWer<m>:QUALity:RESult:POWer:APParent[:ACTual]?	1221
POWer<m>:QUALity:RESult:POWer:APParent:AVERage?	1221
POWer<m>:QUALity:RESult:POWer:APParent:EVTCount?	1221
POWer<m>:QUALity:RESult:POWer:APParent:NPEak?	1221
POWer<m>:QUALity:RESult:POWer:APParent:PPEak?	1221
POWer<m>:QUALity:RESult:POWer:APParent:RMS?	1221
POWer<m>:QUALity:RESult:POWer:APParent:WFMCount?	1221
POWer<m>:QUALity:RESult:POWer:APParent:STDDDev?	1221
POWer<m>:QUALity:RESult:POWer:PFACtor[:ACTual]?	1221
POWer<m>:QUALity:RESult:POWer:PFACtor:AVERage?	1221
POWer<m>:QUALity:RESult:POWer:PFACtor:EVTCount?	1221
POWer<m>:QUALity:RESult:POWer:PFACtor:NPEak?	1221
POWer<m>:QUALity:RESult:POWer:PFACtor:PPEak?	1221
POWer<m>:QUALity:RESult:POWer:PFACtor:RMS?	1221
POWer<m>:QUALity:RESult:POWer:PFACtor:WFMCount?	1221
POWer<m>:QUALity:RESult:POWer:PFACtor:STDDDev?	1221
POWer<m>:QUALity:RESult:POWer:PHASe[:ACTual]?	1222
POWer<m>:QUALity:RESult:POWer:PHASe:AVERage?	1222
POWer<m>:QUALity:RESult:POWer:PHASe:EVTCount?	1222
POWer<m>:QUALity:RESult:POWer:PHASe:NPEak?	1222
POWer<m>:QUALity:RESult:POWer:PHASe:PPEak?	1222
POWer<m>:QUALity:RESult:POWer:PHASe:RMS?	1222
POWer<m>:QUALity:RESult:POWer:PHASe:WFMCount?	1222
POWer<m>:QUALity:RESult:POWer:PHASe:STDDDev?	1222
POWer<m>:QUALity:RESult:POWer:REACTive[:ACTual]?	1222
POWer<m>:QUALity:RESult:POWer:REACTive:AVERage?	1222
POWer<m>:QUALity:RESult:POWer:REACTive:EVTCount?	1222
POWer<m>:QUALity:RESult:POWer:REACTive:NPEak?	1222
POWer<m>:QUALity:RESult:POWer:REACTive:PPEak?	1222
POWer<m>:QUALity:RESult:POWer:REACTive:RMS?	1222
POWer<m>:QUALity:RESult:POWer:REACTive:WFMCount?	1222
POWer<m>:QUALity:RESult:POWer:REACTive:STDDDev?	1222
POWer<m>:QUALity:RESult:VOLTage:CREStfactor[:ACTual]?	1223
POWer<m>:QUALity:RESult:VOLTage:CREStfactor:AVERage?	1223
POWer<m>:QUALity:RESult:VOLTage:CREStfactor:EVTCount?	1223
POWer<m>:QUALity:RESult:VOLTage:CREStfactor:NPEak?	1223
POWer<m>:QUALity:RESult:VOLTage:CREStfactor:PPEak?	1223
POWer<m>:QUALity:RESult:VOLTage:CREStfactor:RMS?	1223
POWer<m>:QUALity:RESult:VOLTage:CREStfactor:WFMCount?	1223
POWer<m>:QUALity:RESult:VOLTage:CREStfactor:STDDDev?	1223

POWer<m>:QUALity:RESult:VOLTage:FREQuency[:ACTual]?	1223
POWer<m>:QUALity:RESult:VOLTage:FREQuency:AVERAge?	1223
POWer<m>:QUALity:RESult:VOLTage:FREQuency:EVTCount?	1223
POWer<m>:QUALity:RESult:VOLTage:FREQuency:NPEak?	1223
POWer<m>:QUALity:RESult:VOLTage:FREQuency:PPEak?	1223
POWer<m>:QUALity:RESult:VOLTage:FREQuency:RMS?	1223
POWer<m>:QUALity:RESult:VOLTage:FREQuency:WFMCount?	1223
POWer<m>:QUALity:RESult:VOLTage:FREQuency:STDDDev?	1223
POWer<m>:QUALity:RESult:VOLTage:PEAK[:ACTual]?	1224
POWer<m>:QUALity:RESult:VOLTage:PEAK:AVERAge?	1224
POWer<m>:QUALity:RESult:VOLTage:PEAK:EVTCount?	1224
POWer<m>:QUALity:RESult:VOLTage:PEAK:NPEak?	1224
POWer<m>:QUALity:RESult:VOLTage:PEAK:PPEak?	1224
POWer<m>:QUALity:RESult:VOLTage:PEAK:RMS?	1224
POWer<m>:QUALity:RESult:VOLTage:PEAK:WFMCount?	1224
POWer<m>:QUALity:RESult:VOLTage:PEAK:STDDDev?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS[:ACTual]?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS:AVERAge?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS:EVTCount?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS:NPEak?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS:PPEak?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS:RMS?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS:WFMCount?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS:STDDDev?	1224

POWer<m>:QUALity:RESult:CURRent:CREStfactor[:ACTual]?

POWer<m>:QUALity:RESult:CURRent:CREStfactor:AVERAge?

POWer<m>:QUALity:RESult:CURRent:CREStfactor:EVTCount?

POWer<m>:QUALity:RESult:CURRent:CREStfactor:NPEak?

POWer<m>:QUALity:RESult:CURRent:CREStfactor:PPEak?

POWer<m>:QUALity:RESult:CURRent:CREStfactor:RMS?

POWer<m>:QUALity:RESult:CURRent:CREStfactor:WFMCount?

POWer<m>:QUALity:RESult:CURRent:CREStfactor:STDDDev?

Returns the current crest factor, the *Peak value* / *RMS value* for the power quality analysis.

For details on the statistics, see ["Overview of statistic results"](#) on page 1209.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<StdDev> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

POWer<m>:QUALity:RESult:CURRent:PEAK[:ACTual]?
POWer<m>:QUALity:RESult:CURRent:PEAK:AVERage?
POWer<m>:QUALity:RESult:CURRent:PEAK:EVTCount?
POWer<m>:QUALity:RESult:CURRent:PEAK:NPEak?
POWer<m>:QUALity:RESult:CURRent:PEAK:PPEak?
POWer<m>:QUALity:RESult:CURRent:PEAK:RMS?
POWer<m>:QUALity:RESult:CURRent:PEAK:WFMCount?
POWer<m>:QUALity:RESult:CURRent:PEAK:STDDev?

Returns the current peak value, the highest measured magnitude value for the power quality analysis.

For details on the statistics, see ["Overview of statistic results"](#) on page 1209.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<StdDev> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

POWer<m>:QUALity:RESult:CURRent:RMS[:ACTual]?
POWer<m>:QUALity:RESult:CURRent:RMS:AVERage?
POWer<m>:QUALity:RESult:CURRent:RMS:EVTCount?
POWer<m>:QUALity:RESult:CURRent:RMS:NPEak?
POWer<m>:QUALity:RESult:CURRent:RMS:PPEak?
POWer<m>:QUALity:RESult:CURRent:RMS:RMS?
POWer<m>:QUALity:RESult:CURRent:RMS:WFMCount?
POWer<m>:QUALity:RESult:CURRent:RMS:STDDev?

Returns the root mean square of the current for the power quality analysis.

For details on the statistics, see ["Overview of statistic results"](#) on page 1209.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<StdDev> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

POWer<m>:QUALity:RESult:POWer:ACTive[:ACTual]?
POWer<m>:QUALity:RESult:POWer:ACTive:AVERage?
POWer<m>:QUALity:RESult:POWer:ACTive:EVTCount?
POWer<m>:QUALity:RESult:POWer:ACTive:NPEak?

POWer<m>:QUALity:RESult:POWer:ACTive:PPEak?
POWer<m>:QUALity:RESult:POWer:ACTive:RMS?
POWer<m>:QUALity:RESult:POWer:ACTive:WFMCount?
POWer<m>:QUALity:RESult:POWer:ACTive:STDDev?

Returns the active power for the power quality analysis.

For details on the statistics, see ["Overview of statistic results"](#) on page 1209.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<StdDev> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

POWer<m>:QUALity:RESult:POWer:APParent[:ACTual]?
POWer<m>:QUALity:RESult:POWer:APParent:AVERage?
POWer<m>:QUALity:RESult:POWer:APParent:EVTCount?
POWer<m>:QUALity:RESult:POWer:APParent:NPEak?
POWer<m>:QUALity:RESult:POWer:APParent:PPEak?
POWer<m>:QUALity:RESult:POWer:APParent:RMS?
POWer<m>:QUALity:RESult:POWer:APParent:WFMCount?
POWer<m>:QUALity:RESult:POWer:APParent:STDDev?

Returns the apparent power for the power quality analysis.

For details on the statistics, see ["Overview of statistic results"](#) on page 1209.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<StdDev> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

POWer<m>:QUALity:RESult:POWer:PFACTOR[:ACTual]?
POWer<m>:QUALity:RESult:POWer:PFACTOR:AVERage?
POWer<m>:QUALity:RESult:POWer:PFACTOR:EVTCount?
POWer<m>:QUALity:RESult:POWer:PFACTOR:NPEak?
POWer<m>:QUALity:RESult:POWer:PFACTOR:PPEak?
POWer<m>:QUALity:RESult:POWer:PFACTOR:RMS?
POWer<m>:QUALity:RESult:POWer:PFACTOR:WFMCount?
POWer<m>:QUALity:RESult:POWer:PFACTOR:STDDev?

Returns the power factor for the power quality analysis.

For details on the statistics, see ["Overview of statistic results"](#) on page 1209.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<StdDev> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

POWER<m>:QUALity:RESult:POWer:PHASe[:ACTual]?
POWER<m>:QUALity:RESult:POWer:PHASe:AVERage?
POWER<m>:QUALity:RESult:POWer:PHASe:EVTCount?
POWER<m>:QUALity:RESult:POWer:PHASe:NPEak?
POWER<m>:QUALity:RESult:POWer:PHASe:PPEak?
POWER<m>:QUALity:RESult:POWer:PHASe:RMS?
POWER<m>:QUALity:RESult:POWer:PHASe:WFMCount?
POWER<m>:QUALity:RESult:POWer:PHASe:STDDev?

Returns the phase for the power quality analysis.

For details on the statistics, see ["Overview of statistic results"](#) on page 1209.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<StdDev> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

POWER<m>:QUALity:RESult:POWer:REACTive[:ACTual]?
POWER<m>:QUALity:RESult:POWer:REACTive:AVERage?
POWER<m>:QUALity:RESult:POWer:REACTive:EVTCount?
POWER<m>:QUALity:RESult:POWer:REACTive:NPEak?
POWER<m>:QUALity:RESult:POWer:REACTive:PPEak?
POWER<m>:QUALity:RESult:POWer:REACTive:RMS?
POWER<m>:QUALity:RESult:POWer:REACTive:WFMCount?
POWER<m>:QUALity:RESult:POWer:REACTive:STDDev?

Returns the reactive power for the power quality analysis.

For details on the statistics, see ["Overview of statistic results"](#) on page 1209.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<StdDev> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

POWER<m>:QUALity:RESult:VOLTage:CREStfactor[:ACTual]?
 POWER<m>:QUALity:RESult:VOLTage:CREStfactor:AVERage?
 POWER<m>:QUALity:RESult:VOLTage:CREStfactor:EVTCount?
 POWER<m>:QUALity:RESult:VOLTage:CREStfactor:NPEak?
 POWER<m>:QUALity:RESult:VOLTage:CREStfactor:PPEak?
 POWER<m>:QUALity:RESult:VOLTage:CREStfactor:RMS?
 POWER<m>:QUALity:RESult:VOLTage:CREStfactor:WFMCCount?
 POWER<m>:QUALity:RESult:VOLTage:CREStfactor:STDDev?

Returns the voltage crest factor, the *Peak value* / *RMS value* for the power quality analysis.

For details on the statistics, see ["Overview of statistic results"](#) on page 1209.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<StdDev> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

POWER<m>:QUALity:RESult:VOLTage:FREQuency[:ACTual]?
 POWER<m>:QUALity:RESult:VOLTage:FREQuency:AVERage?
 POWER<m>:QUALity:RESult:VOLTage:FREQuency:EVTCount?
 POWER<m>:QUALity:RESult:VOLTage:FREQuency:NPEak?
 POWER<m>:QUALity:RESult:VOLTage:FREQuency:PPEak?
 POWER<m>:QUALity:RESult:VOLTage:FREQuency:RMS?
 POWER<m>:QUALity:RESult:VOLTage:FREQuency:WFMCCount?
 POWER<m>:QUALity:RESult:VOLTage:FREQuency:STDDev?

Returns the voltage frequency value for the power quality analysis.

For details on the statistics, see ["Overview of statistic results"](#) on page 1209.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<StdDev> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage: Query only
Asynchronous command

POWER<m>:QUALity:RESult:VOLTage:PEAK[:ACTual]?
POWER<m>:QUALity:RESult:VOLTage:PEAK:AVERage?
POWER<m>:QUALity:RESult:VOLTage:PEAK:EVTCount?
POWER<m>:QUALity:RESult:VOLTage:PEAK:NPEak?
POWER<m>:QUALity:RESult:VOLTage:PEAK:PPEak?
POWER<m>:QUALity:RESult:VOLTage:PEAK:RMS?
POWER<m>:QUALity:RESult:VOLTage:PEAK:WFMCount?
POWER<m>:QUALity:RESult:VOLTage:PEAK:STDDev?

Returns the voltage peak value, the highest measured magnitude value for the power quality analysis.

For details on the statistics, see ["Overview of statistic results"](#) on page 1209.

Suffix:
<m> 1 to 6, index of the power analysis measurement

Return values:
<StdDev> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage: Query only
Asynchronous command

POWER<m>:QUALity:RESult:VOLTage:RMS[:ACTual]?
POWER<m>:QUALity:RESult:VOLTage:RMS:AVERage?
POWER<m>:QUALity:RESult:VOLTage:RMS:EVTCount?
POWER<m>:QUALity:RESult:VOLTage:RMS:NPEak?
POWER<m>:QUALity:RESult:VOLTage:RMS:PPEak?
POWER<m>:QUALity:RESult:VOLTage:RMS:RMS?
POWER<m>:QUALity:RESult:VOLTage:RMS:WFMCount?
POWER<m>:QUALity:RESult:VOLTage:RMS:STDDev?

Returns the root mean square of the voltage for the power quality analysis.

For details on the statistics, see ["Overview of statistic results"](#) on page 1209.

Suffix:
<m> 1 to 6, index of the power analysis measurement

Return values:
<StdDev> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage: Query only
Asynchronous command

18.17.3.3 Power harmonics

- [Power harmonics setup](#)..... 1225
- [Power harmonics results](#)..... 1230

Power harmonics setup

POWER<m>:HARMonics:SOURce:CURRent	1225
POWER<m>:HARMonics:SOURce[:VOLTage]	1225
POWER<m>:HARMonics:STANdard	1226
POWER<m>:HARMonics:REVisiOn	1226
POWER<m>:HARMonics:FREQuency:EN	1226
POWER<m>:HARMonics:FREQuency:MIL	1227
POWER<m>:HARMonics:FREQuency:RTCA	1227
POWER<m>:HARMonics:DISPlay:HARMonics[:DISPlay]	1227
POWER<m>:HARMonics:DISPlay:BARGraph:VERTical:SCALE:TYPE	1228
POWER<m>:HARMonics:DISPlay:HARMonics:START[:VALue]	1228
POWER<m>:HARMonics:DISPlay:HARMonics:STOP[:VALue]	1228
POWER<m>:HARMonics:RPOWER[:MODE]	1228
POWER<m>:HARMonics:RPOWER:USER	1229
POWER<m>:HARMonics:PFACTOR:USER	1229
POWER<m>:HARMonics:PFACTOR[:MODE]	1230

POWER<m>:HARMonics:SOURce:CURRent <CurrentSource>

Sets the channel for the current source input of the power harmonics analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<CurrentSource> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Usage:

Asynchronous command

Manual operation: See ["Current"](#) on page 374

POWER<m>:HARMonics:SOURce[:VOLTage] <VoltageSource>

Sets the channel for the voltage source input of the power harmonics analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<VoltageSource> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Usage:

Asynchronous command

Manual operation: See ["Voltage"](#) on page 374

POWer<m>:HARMonics:STANdard <Standard>

Sets a standard for the current harmonic measurement.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Standard> ENA | ENB | ENC | END | MIL | RTCA

ENA: EN 61000-3-2 Class A

ENB: EN 61000-3-2 Class B

ENC: EN 61000-3-2 Class C

END: EN 61000-3-2 Class D

MIL: MIL-STD-1399

RTCA: RTCA DO-160

*RST: ENA

Usage: Asynchronous command

Manual operation: See ["Standard"](#) on page 374

POWer<m>:HARMonics:REVisiOn <Revision>

Selects the revision of the EN61000 standard, if [POWer<m>:HARMonics:STANdard](#) is set to ENA / ENB / ENC / END.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Revision> REV2011 | REV2019

*RST: REV2019

Usage: Asynchronous command

Manual operation: See ["Standard"](#) on page 374

POWer<m>:HARMonics:FREQuency:EN <FundFreqEN61000>

Sets the fundamental frequency of the input signal for the EN61000 standard, if [POWer<m>:HARMonics:STANdard](#) is set to ENA / ENB / ENC / END.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<FundFreqEN61000> F50 | F60 | AUTO

F50: 50 Hz

F60: 60 Hz

AUTO: automatically set

*RST: AUTO

Usage: Asynchronous command

Manual operation: See "Fund. frequency" on page 375

POWer<m>:HARMonics:FREQuency:MIL <FundFreqMIL>

Sets the fundamental frequency of the input signal for the MIL standard, if **POWer<m>:HARMonics:STANdard** is set to MIL.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<FundFreqMIL> F60 | F400
 F60: 60 Hz
 F400: 400 Hz
 *RST: F60

Usage: Asynchronous command

Manual operation: See "Fund. frequency" on page 375

POWer<m>:HARMonics:FREQuency:RTCA <FundamFreqRTCA>

Sets the fundamental frequency of the input signal for the RTCA standard, if **POWer<m>:HARMonics:STANdard** is set to RTCA.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<FundFreqRTCA> F400 | NVF | WVF
 F400: 400 Hz
 NVF
 WVF
 *RST: F400

Usage: Asynchronous command

Manual operation: See "Fund. frequency" on page 375

POWer<m>:HARMonics:DISPlay:HARMonics[:DISPlay] <DispedHarmonics>

Selects which harmonics are displayed in the bar graph: all, odd even or depending on the standard definition.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<DispedHarmonics> ALL | EVEN | ODD | STANdard
 *RST: STANdard

Usage: Asynchronous command

Manual operation: See ["Displ. harmonics"](#) on page 376

POWer<m>:HARMonics:DISPlay:BARGraph:VERTical:SCALE:TYPE <Scaling>

Selects a logarithmic or linear scale for the display for the harmonics bar graph.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Scaling> LIN | LOG
*RST: LIN

Usage: Asynchronous command

Manual operation: See ["Scale type"](#) on page 376

POWer<m>:HARMonics:DISPlay:HARMonics:START[:VALue] <BarGraphStart>

Sets the first harmonic to be shown in the bar graph.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<BarGraphStart> Range: 1 to 37
Increment: 1
*RST: 1

Usage: Asynchronous command

Manual operation: See ["Start harmonic, Max harmonic"](#) on page 376

POWer<m>:HARMonics:DISPlay:HARMonics:STOP[:VALue] <BarGraphStop>

Sets the last harmonic to be shown in the bar graph.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<BarGraphStop> Range: 3 to 40
Increment: 1
*RST: 40

Usage: Asynchronous command

Manual operation: See ["Start harmonic, Max harmonic"](#) on page 376

POWer<m>:HARMonics:RPOWer[:MODE] <ActPowMd>

Available if [POWer<m>:HARMonics:STANdard](#) is set to END.

Selects if the power factor is defined automatically, or a user-defined value is used (`POWer<m>:HARMonics:RPOWer:USER`).

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ActPowMd> AUTO | USER
*RST: AUTO

Usage: Asynchronous command

Manual operation: See "Real power, Power" on page 375

POWer<m>:HARMonics:RPOWer:USER <UsrActPow>

Selects the revision of the EN61000 standard, if `POWer<m>:HARMonics:STANdard` is set to `END` and `POWer<m>:HARMonics:RPOWer:USER` is set to `USER`.

Sets a user-defined power value.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<UsrActPow> Range: 0 to 10000
Increment: 1
*RST: 100
Default unit: W

Usage: Asynchronous command

Manual operation: See "Real power, Power" on page 375

POWer<m>:HARMonics:PFACTOR:USER <UsrPowFact>

Available if `POWer<m>:HARMonics:STANdard` is set to `ENC` and `POWer<m>:HARMonics:PFACTOR[:MODE]` is set to `USER`.

Sets a user-defined power factor.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<UsrPowFact> Range: 0 to 100
Increment: 1
*RST: 100
Default unit: %

Usage: Asynchronous command

Manual operation: See "Power factor" on page 375

POWer<m>:HARMonics:PFACtor[:MODE] <PowFactMd>

Available if `POWer<m>:HARMonics:STANdard` is set to `ENC`.

Selects if the power factor is defined automatically, or a user-defined value is used (`POWer<m>:HARMonics:PFACtor:USER`).

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<PowFactMd> AUTO | USER
*RST: AUTO

Usage: Asynchronous command

Manual operation: See "Power factor" on page 375

Power harmonics results

<code>POWer<m>:HARMonics:AVAIlable?</code>	1230
<code>POWer<m>:HARMonics:MEASurement:FREQuency[:ACTual]?</code>	1230
<code>POWer<m>:HARMonics:MEASurement:POWer:ACTive[:ACTual]?</code>	1231
<code>POWer<m>:HARMonics:MEASurement:THDFundament[:ACTual]?</code>	1231
<code>POWer<m>:HARMonics:MEASurement:THDRms[:ACTual]?</code>	1231
<code>POWer<m>:HARMonics:RESult<n>:VIOLation?</code>	1231
<code>POWer<m>:HARMonics:RESult<n>[:FREQuency]?</code>	1232
<code>POWer<m>:HARMonics:RESult<n>:MAGNitude:PERCent:MAXimum?</code>	1232
<code>POWer<m>:HARMonics:RESult<n>:MAGNitude:PERCent:MINimum?</code>	1232
<code>POWer<m>:HARMonics:RESult<n>:MAGNitude:PERCent[:ACTual]?</code>	1232
<code>POWer<m>:HARMonics:RESult<n>:MAGNitude:RMS:MAXimum?</code>	1233
<code>POWer<m>:HARMonics:RESult<n>:MAGNitude:RMS:MINimum?</code>	1233
<code>POWer<m>:HARMonics:RESult<n>:MAGNitude:RMS[:ACTual]?</code>	1233

POWer<m>:HARMonics:AVAIlable?

Returns the number of measured harmonics.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<Count>

Usage:

Query only
Asynchronous command

POWer<m>:HARMonics:MEASurement:FREQuency[:ACTual]?

Returns the frequency of measured harmonics.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<Actual> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

POWer<m>:HARMonics:MEASurement:POWer:ACTive[:ACTual]?

Returns the active power. Only available, if `POWer<m>:HARMonics:STANdard` on page 1226 is set to `ENC` / `END`.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Usage:

Query only
 Asynchronous command

POWer<m>:HARMonics:MEASurement:THDFundament[:ACTual]?

Returns the total harmonic distortion relative to fundamental (THDF).

Suffix:

<m> 1 to 6, index of the power analysis measurement

Usage:

Query only
 Asynchronous command

POWer<m>:HARMonics:MEASurement:THDRms[:ACTual]?

Returns the total harmonic distortion relative to the RMS amplitude (THD RMS).

Suffix:

<m> 1 to 6, index of the power analysis measurement

Usage:

Query only
 Asynchronous command

POWer<m>:HARMonics:RESult<n>:VIOLation?

Queries if the value of n-th harmonic is within the defined limit for the current measurement.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...n, index of the harmonics

Return values:

<Harmonic>

Usage: Query only
Asynchronous command

POWer<m>:HARMonics:RESult<n>[:FREQuency]?

Returns the frequency of the n-th harmonic.

Suffix:
<m> 1 to 6, index of the power analysis measurement
<n> 1...n, index of the harmonics

Return values:
<Harmonic>

Usage: Query only
Asynchronous command

POWer<m>:HARMonics:RESult<n>:MAGNitude:PERCent:MAXimum?

Returns the maximum magnitude of the n-th harmonic in percent.

Suffix:
<m> 1 to 6, index of the power analysis measurement
<n> 1...n, index of the harmonics

Return values:
<Harmonic>

Usage: Query only
Asynchronous command

POWer<m>:HARMonics:RESult<n>:MAGNitude:PERCent:MINimum?

Returns the minimum magnitude of the n-th harmonic in percent.

Suffix:
<m> 1 to 6, index of the power analysis measurement
<n> 1...n, index of the harmonics

Return values:
<Harmonic>

Usage: Query only
Asynchronous command

POWer<m>:HARMonics:RESult<n>:MAGNitude:PERCent[:ACTual]?

Returns the magnitude of the n-th harmonic in percent.

Suffix:
<m> 1 to 6, index of the power analysis measurement

<n> 1...n, index of the harmonics

Return values:

<Harmonic>

Usage:

Query only
Asynchronous command

POWer<m>:HARMonics:RESult<n>:MAGNitude:RMS:MAXimum?

Returns the maximum magnitude of the n-th harmonic in RMS.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...n, index of the harmonics

Return values:

<Harmonic>

Usage:

Query only
Asynchronous command

POWer<m>:HARMonics:RESult<n>:MAGNitude:RMS:MINimum?

Returns the minimum magnitude of the n-th harmonic in RMS.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...n, index of the harmonics

Return values:

<Harmonic>

Usage:

Query only
Asynchronous command

POWer<m>:HARMonics:RESult<n>:MAGNitude:RMS[:ACTual]?

Returns the magnitude of the n-th harmonic in RMS.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...n, index of the harmonics

Return values:

<Harmonic>

Usage:

Query only
Asynchronous command

18.17.3.4 Switching loss

- [Switching loss setup](#)..... 1234
- [Switching loss display](#)..... 1237
- [Switching loss results](#)..... 1238

Switching loss setup

POWER<m>:SWITChing:SOURce:CURRent	1234
POWER<m>:SWITChing:SOURce[:VOLTage]	1234
POWER<m>:SWITChing:DISPlay:TYPE	1235
POWER<m>:SWITChing:REGion:TOTal[:START]	1235
POWER<m>:SWITChing:REGion:TON[:START]	1235
POWER<m>:SWITChing:REGion:TON:STOP	1235
POWER<m>:SWITChing:REGion:CONDUction[:START]	1235
POWER<m>:SWITChing:REGion:CONDUction:STOP	1236
POWER<m>:SWITChing:REGion:TOFF[:START]	1236
POWER<m>:SWITChing:REGion:TOFF:STOP	1236
POWER<m>:SWITChing:REGion:NCONduction[:START]	1236
POWER<m>:SWITChing:REGion:NCONduction:STOP	1236
POWER<m>:SWITChing:REGion:TOTal:STOP	1236

POWER<m>:SWITChing:SOURce:CURRent <SourceCurrent>

Selects the current source waveform. Analog channels and math waveforms can be used.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<SourceCurrent> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Usage:

Asynchronous command

Manual operation: See ["Current"](#) on page 381

POWER<m>:SWITChing:SOURce[:VOLTage] <SourceVoltage>

Selects the voltage source waveform. Analog channels and math waveforms can be used.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<SourceVoltage> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Usage:

Asynchronous command

Manual operation: See ["Voltage"](#) on page 381

POWer<m>:SWITching:DISPlay:TYPE <Unit>

Selects the measurement type: power or energy.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Unit> POWer | ENERgy
*RST: POWer

Usage: Asynchronous command

Manual operation: See "[Unit](#)" on page 381

POWer<m>:SWITching:REGion:TOTal[:START] <T1Position>**POWer<m>:SWITching:REGion:TON[:START] <T1Position>**

Sets the start time for the turn on area in relation to the trigger point. This value is also the start time of the total switching cycle.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<T1Position> Range: -500 to 500
Increment: 1E-09
*RST: -1E-06
Default unit: s

Usage: Asynchronous command

Manual operation: See "[T<n> position](#)" on page 381

POWer<m>:SWITching:REGion:TON:STOP <T2Position>**POWer<m>:SWITching:REGion:CONduction[:START] <T2Position>**

Sets the start time for the conduction area in relation to the trigger point. This value is also end time of the turn on area.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<T2Position> Range: -500 to 500
Increment: 1E-09
*RST: 1E-06
Default unit: s

Usage: Asynchronous command

Manual operation: See "[T<n> position](#)" on page 381

POWer<m>:SWITching:REGion:CONduction:STOP <T3Position>
POWer<m>:SWITching:REGion:TOFF[:START] <T3Position>

Sets the start time for the turn off area in relation to the trigger point. This value is also the end time of the conduction area.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<T3Position> Range: -500 to 500
 Increment: 1E-09
 *RST: 5E-06
 Default unit: s

Usage: Asynchronous command

Manual operation: See "[T<n> position](#)" on page 381

POWer<m>:SWITching:REGion:TOFF:STOP <T4Position>
POWer<m>:SWITching:REGion:NCONduction[:START] <T4Position>

Sets the start time for the non-conduction area in relation to the trigger point. This value is also the end time of the turn off area.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<T4Position> Range: -500 to 500
 Increment: 1E-09
 *RST: 6E-06
 Default unit: s

Usage: Asynchronous command

Manual operation: See "[T<n> position](#)" on page 381

POWer<m>:SWITching:REGion:NCONduction:STOP <T5Position>
POWer<m>:SWITching:REGion:TOTal:STOP <T5Position>

Sets the end time for the non-conduction area in relation to the trigger point. This value is also the end of the total switching cycle.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<T5Position> Range: -500 to 500
 Increment: 1E-09
 *RST: 1E-05
 Default unit: s

Usage: Asynchronous command

Manual operation: See "[T<n> position](#)" on page 381

Switching loss display

POWer<m>:SWITching:DISPlay:CONduction[:ENABle].....	1237
POWer<m>:SWITching:DISPlay:NCONduction[:ENABle].....	1237
POWer<m>:SWITching:DISPlay:TOFF[:ENABle].....	1237
POWer<m>:SWITching:DISPlay:TON[:ENABle].....	1237
POWer<m>:SWITching:DISPlay:CONduction:COLor.....	1237
POWer<m>:SWITching:DISPlay:NCONduction:COLor.....	1237
POWer<m>:SWITching:DISPlay:TOFF:COLor.....	1237
POWer<m>:SWITching:DISPlay:TON:COLor.....	1237
POWer<m>:SWITching:DISPlay:TOTal[:ENABle].....	1238
POWer<m>:SWITching:DISPlay:LABel[:ENABle].....	1238

POWer<m>:SWITching:DISPlay:CONduction[:ENABle] <Show>
POWer<m>:SWITching:DISPlay:NCONduction[:ENABle] <Show>
POWer<m>:SWITching:DISPlay:TOFF[:ENABle] <Show>
POWer<m>:SWITching:DISPlay:TON[:ENABle] <Show>

The commands enable the measurements of the conduction area, non-conduction area, turn off area and turn on area, respectively. Results of enabled measurements are shown in the result table.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Show> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See "Turn on" on page 382

POWer<m>:SWITching:DISPlay:CONduction:COLor <Color>
POWer<m>:SWITching:DISPlay:NCONduction:COLor <Color>
POWer<m>:SWITching:DISPlay:TOFF:COLor <Color>
POWer<m>:SWITching:DISPlay:TON:COLor <Color>

The commands set the display color of the conduction area, non-conduction area, turn off area and turn on area, respectively.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Color> Decimal value of the ARGB color. Use the color dialog on the instrument to get the hex value of the color, and convert the hex value to a decimal value.
 0 is fully transparent black.
 4278190080 (dec) = FF000000 (hex) is opaque black.
 4294967295 (dec) = FFFFFFFF (hex) is opaque white.
 Range: 0 to 4294967295
 Increment: 1

Usage: Asynchronous command

Manual operation: See ["Turn on"](#) on page 382

Reset values:

Conduction	2030010343
Non-conduction	2023358259
Turn off	2030002176
Turn on	2026077439

POWER<m>:SWITching:DISPlay:TOTal[:ENABLE] <ShowTotal>

Enables the measurements of the total switching cycle.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ShowTotal> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Total"](#) on page 383

POWER<m>:SWITching:DISPlay:LABel[:ENABLE] <ShowLabel>

Displays the names of the switching cycle areas.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ShowLabel> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Area label"](#) on page 383

Switching loss results

See ["Overview of statistic results"](#) on page 1209.

POWER<m>:SWITching:RESult:CONduction:ENERgy[:ACTual]?.....	1240
POWER<m>:SWITching:RESult:CONduction:POWer[:ACTual]?.....	1240
POWER<m>:SWITching:RESult:NCONduction:ENERgy[:ACTual]?.....	1240
POWER<m>:SWITching:RESult:NCONduction:POWer[:ACTual]?.....	1240
POWER<m>:SWITching:RESult:TOFF:ENERgy[:ACTual]?.....	1240
POWER<m>:SWITching:RESult:TOFF:POWer[:ACTual]?.....	1240
POWER<m>:SWITching:RESult:TOn:ENERgy[:ACTual]?.....	1240

POWer<m>:SWITching:RESult:TON:POWer[:ACTual]?	1240
POWer<m>:SWITching:RESult:TOTal:ENERgy[:ACTual]?	1240
POWer<m>:SWITching:RESult:TOTal:POWer[:ACTual]?	1240
POWer<m>:SWITching:RESult:CONduction:ENERgy:AVERage?	1240
POWer<m>:SWITching:RESult:CONduction:POWer:AVERage?	1240
POWer<m>:SWITching:RESult:NCONduction:ENERgy:AVERage?	1240
POWer<m>:SWITching:RESult:NCONduction:POWer:AVERage?	1241
POWer<m>:SWITching:RESult:TOFF:ENERgy:AVERage?	1241
POWer<m>:SWITching:RESult:TOFF:POWer:AVERage?	1241
POWer<m>:SWITching:RESult:TON:ENERgy:AVERage?	1241
POWer<m>:SWITching:RESult:TON:POWer:AVERage?	1241
POWer<m>:SWITching:RESult:TOTal:ENERgy:AVERage?	1241
POWer<m>:SWITching:RESult:TOTal:POWer:AVERage?	1241
POWer<m>:SWITching:RESult:CONduction:ENERgy:EVTCount?	1241
POWer<m>:SWITching:RESult:CONduction:POWer:EVTCount?	1241
POWer<m>:SWITching:RESult:NCONduction:ENERgy:EVTCount?	1241
POWer<m>:SWITching:RESult:NCONduction:POWer:EVTCount?	1241
POWer<m>:SWITching:RESult:TOFF:ENERgy:EVTCount?	1241
POWer<m>:SWITching:RESult:TOFF:POWer:EVTCount?	1241
POWer<m>:SWITching:RESult:TON:ENERgy:EVTCount?	1241
POWer<m>:SWITching:RESult:TON:POWer:EVTCount?	1241
POWer<m>:SWITching:RESult:TOTal:ENERgy:EVTCount?	1241
POWer<m>:SWITching:RESult:TOTal:POWer:EVTCount?	1241
POWer<m>:SWITching:RESult:CONduction:ENERgy:NPEak?	1241
POWer<m>:SWITching:RESult:CONduction:POWer:NPEak?	1241
POWer<m>:SWITching:RESult:NCONduction:ENERgy:NPEak?	1241
POWer<m>:SWITching:RESult:NCONduction:POWer:NPEak?	1241
POWer<m>:SWITching:RESult:TOFF:ENERgy:NPEak?	1241
POWer<m>:SWITching:RESult:TOFF:POWer:NPEak?	1241
POWer<m>:SWITching:RESult:TON:ENERgy:NPEak?	1242
POWer<m>:SWITching:RESult:TON:POWer:NPEak?	1242
POWer<m>:SWITching:RESult:TOTal:ENERgy:NPEak?	1242
POWer<m>:SWITching:RESult:TOTal:POWer:NPEak?	1242
POWer<m>:SWITching:RESult:CONduction:ENERgy:PPEak?	1242
POWer<m>:SWITching:RESult:CONduction:POWer:PPEak?	1242
POWer<m>:SWITching:RESult:NCONduction:ENERgy:PPEak?	1242
POWer<m>:SWITching:RESult:NCONduction:POWer:PPEak?	1242
POWer<m>:SWITching:RESult:TOFF:ENERgy:PPEak?	1242
POWer<m>:SWITching:RESult:TOFF:POWer:PPEak?	1242
POWer<m>:SWITching:RESult:TON:ENERgy:PPEak?	1242
POWer<m>:SWITching:RESult:TON:POWer:PPEak?	1242
POWer<m>:SWITching:RESult:TOTal:ENERgy:PPEak?	1242
POWer<m>:SWITching:RESult:TOTal:POWer:PPEak?	1242
POWer<m>:SWITching:RESult:CONduction:ENERgy:RMS?	1242
POWer<m>:SWITching:RESult:CONduction:POWer:RMS?	1242
POWer<m>:SWITching:RESult:NCONduction:ENERgy:RMS?	1242
POWer<m>:SWITching:RESult:NCONduction:POWer:RMS?	1242
POWer<m>:SWITching:RESult:TOFF:ENERgy:RMS?	1242
POWer<m>:SWITching:RESult:TOFF:POWer:RMS?	1242
POWer<m>:SWITching:RESult:TON:ENERgy:RMS?	1242

POWer<m>:SWITching:RESult:TON:POWer:RMS?	1242
POWer<m>:SWITching:RESult:TOTal:ENERgy:RMS?	1243
POWer<m>:SWITching:RESult:TOTal:POWer:RMS?	1243
POWer<m>:SWITching:RESult:CONDUction:ENERgy:STDDev?	1243
POWer<m>:SWITching:RESult:CONDUction:POWer:STDDev?	1243
POWer<m>:SWITching:RESult:NCONduction:ENERgy:STDDev?	1243
POWer<m>:SWITching:RESult:NCONduction:POWer:STDDev?	1243
POWer<m>:SWITching:RESult:TOFF:ENERgy:STDDev?	1243
POWer<m>:SWITching:RESult:TOFF:POWer:STDDev?	1243
POWer<m>:SWITching:RESult:TON:ENERgy:STDDev?	1243
POWer<m>:SWITching:RESult:TON:POWer:STDDev?	1243
POWer<m>:SWITching:RESult:TOTal:ENERgy:STDDev?	1243
POWer<m>:SWITching:RESult:TOTal:POWer:STDDev?	1243
POWer<m>:SWITching:RESult:CONDUction:ENERgy:WFMCount?	1243
POWer<m>:SWITching:RESult:CONDUction:POWer:WFMCount?	1243
POWer<m>:SWITching:RESult:NCONduction:ENERgy:WFMCount?	1243
POWer<m>:SWITching:RESult:NCONduction:POWer:WFMCount?	1243
POWer<m>:SWITching:RESult:TOFF:ENERgy:WFMCount?	1243
POWer<m>:SWITching:RESult:TOFF:POWer:WFMCount?	1243
POWer<m>:SWITching:RESult:TON:ENERgy:WFMCount?	1243
POWer<m>:SWITching:RESult:TON:POWer:WFMCount?	1243
POWer<m>:SWITching:RESult:TOTal:ENERgy:WFMCount?	1244
POWer<m>:SWITching:RESult:TOTal:POWer:WFMCount?	1244

POWer<m>:SWITching:RESult:CONDUction:ENERgy[:ACTual]?
POWer<m>:SWITching:RESult:CONDUction:POWer[:ACTual]?
POWer<m>:SWITching:RESult:NCONduction:ENERgy[:ACTual]?
POWer<m>:SWITching:RESult:NCONduction:POWer[:ACTual]?
POWer<m>:SWITching:RESult:TOFF:ENERgy[:ACTual]?
POWer<m>:SWITching:RESult:TOFF:POWer[:ACTual]?
POWer<m>:SWITching:RESult:TON:ENERgy[:ACTual]?
POWer<m>:SWITching:RESult:TON:POWer[:ACTual]?
POWer<m>:SWITching:RESult:TOTal:ENERgy[:ACTual]?
POWer<m>:SWITching:RESult:TOTal:POWer[:ACTual]?

Return the current result value of the selected measurement type.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<Actual> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

POWer<m>:SWITching:RESult:CONDUction:ENERgy:AVERage?
POWer<m>:SWITching:RESult:CONDUction:POWer:AVERage?
POWer<m>:SWITching:RESult:NCONduction:ENERgy:AVERage?

POWer<m>:SWITching:RESult:NCONduction:POWer:AVERage?
POWer<m>:SWITching:RESult:TOFF:ENERgy:AVERage?
POWer<m>:SWITching:RESult:TOFF:POWer:AVERage?
POWer<m>:SWITching:RESult:TON:ENERgy:AVERage?
POWer<m>:SWITching:RESult:TON:POWer:AVERage?
POWer<m>:SWITching:RESult:TOTal:ENERgy:AVERage?
POWer<m>:SWITching:RESult:TOTal:POWer:AVERage?

Return the average value of the selected measurement type if statistics are enabled.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<Average> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

POWer<m>:SWITching:RESult:CONduction:ENERgy:EVTCount?
POWer<m>:SWITching:RESult:CONduction:POWer:EVTCount?
POWer<m>:SWITching:RESult:NCONduction:ENERgy:EVTCount?
POWer<m>:SWITching:RESult:NCONduction:POWer:EVTCount?
POWer<m>:SWITching:RESult:TOFF:ENERgy:EVTCount?
POWer<m>:SWITching:RESult:TOFF:POWer:EVTCount?
POWer<m>:SWITching:RESult:TON:ENERgy:EVTCount?
POWer<m>:SWITching:RESult:TON:POWer:EVTCount?
POWer<m>:SWITching:RESult:TOTal:ENERgy:EVTCount?
POWer<m>:SWITching:RESult:TOTal:POWer:EVTCount?

Return the number of calculated measurement results of the selected measurement type if statistics are enabled.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<Count> Range: 0 to 4000000000
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

POWer<m>:SWITching:RESult:CONduction:ENERgy:NPEak?
POWer<m>:SWITching:RESult:CONduction:POWer:NPEak?
POWer<m>:SWITching:RESult:NCONduction:ENERgy:NPEak?
POWer<m>:SWITching:RESult:NCONduction:POWer:NPEak?
POWer<m>:SWITching:RESult:TOFF:ENERgy:NPEak?
POWer<m>:SWITching:RESult:TOFF:POWer:NPEak?

POWer<m>:SWITching:RESult:TON:ENERgy:NPEak?
POWer<m>:SWITching:RESult:TON:POWer:NPEak?
POWer<m>:SWITching:RESult:TOTal:ENERgy:NPEak?
POWer<m>:SWITching:RESult:TOTal:POWer:NPEak?

Return the negative peak value (minimum) of the selected measurement type if statistics are enabled.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<MinPeak> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

POWer<m>:SWITching:RESult:CONDUction:ENERgy:PPEak?
POWer<m>:SWITching:RESult:CONDUction:POWer:PPEak?
POWer<m>:SWITching:RESult:NCONduction:ENERgy:PPEak?
POWer<m>:SWITching:RESult:NCONduction:POWer:PPEak?
POWer<m>:SWITching:RESult:TOFF:ENERgy:PPEak?
POWer<m>:SWITching:RESult:TOFF:POWer:PPEak?
POWer<m>:SWITching:RESult:TON:ENERgy:PPEak?
POWer<m>:SWITching:RESult:TON:POWer:PPEak?
POWer<m>:SWITching:RESult:TOTal:ENERgy:PPEak?
POWer<m>:SWITching:RESult:TOTal:POWer:PPEak?

Return the positive peak value (maximum) of the selected measurement type if statistics are enabled.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<MaxPeak> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

POWer<m>:SWITching:RESult:CONDUction:ENERgy:RMS?
POWer<m>:SWITching:RESult:CONDUction:POWer:RMS?
POWer<m>:SWITching:RESult:NCONduction:ENERgy:RMS?
POWer<m>:SWITching:RESult:NCONduction:POWer:RMS?
POWer<m>:SWITching:RESult:TOFF:ENERgy:RMS?
POWer<m>:SWITching:RESult:TOFF:POWer:RMS?
POWer<m>:SWITching:RESult:TON:ENERgy:RMS?
POWer<m>:SWITching:RESult:TON:POWer:RMS?

POWer<m>:SWITching:RESult:TOTal:ENERgy:RMS?

POWer<m>:SWITching:RESult:TOTal:POWer:RMS?

Return the RMS value of the selected measurement type if statistics are enabled.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<RMS> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

POWer<m>:SWITching:RESult:CONduction:ENERgy:STDDev?

POWer<m>:SWITching:RESult:CONduction:POWer:STDDev?

POWer<m>:SWITching:RESult:NCONduction:ENERgy:STDDev?

POWer<m>:SWITching:RESult:NCONduction:POWer:STDDev?

POWer<m>:SWITching:RESult:TOFF:ENERgy:STDDev?

POWer<m>:SWITching:RESult:TOFF:POWer:STDDev?

POWer<m>:SWITching:RESult:TON:ENERgy:STDDev?

POWer<m>:SWITching:RESult:TON:POWer:STDDev?

POWer<m>:SWITching:RESult:TOTal:ENERgy:STDDev?

POWer<m>:SWITching:RESult:TOTal:POWer:STDDev?

Return the standard deviation of the selected measurement type if statistics are enabled.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<StdDev> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

POWer<m>:SWITching:RESult:CONduction:ENERgy:WFMCount?

POWer<m>:SWITching:RESult:CONduction:POWer:WFMCount?

POWer<m>:SWITching:RESult:NCONduction:ENERgy:WFMCount?

POWer<m>:SWITching:RESult:NCONduction:POWer:WFMCount?

POWer<m>:SWITching:RESult:TOFF:ENERgy:WFMCount?

POWer<m>:SWITching:RESult:TOFF:POWer:WFMCount?

POWer<m>:SWITching:RESult:TON:ENERgy:WFMCount?

POWer<m>:SWITching:RESult:TON:POWer:WFMCount?

POWer<m>:SWITching:RESult:TOTal:ENERgy:WFMCount?
POWer<m>:SWITching:RESult:TOTal:POWer:WFMCount?

Return the number of calculated waveforms of the selected measurement type if statistics are enabled.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<WaveformsCount> Range: 0 to 4000000000
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

18.17.3.5 Turn on/off time

- [Turn on/off setup](#)..... 1244
- [Turn on/off display](#)..... 1247
- [Turn on/off results](#)..... 1247

Turn on/off setup

POWer<m>:ONOff:INPut:AC:ABSolute[:VALue]	1244
POWer<m>:ONOff:INPut:DC:ABSolute[:VALue]	1245
POWer<m>:ONOff:INPut:TYPE	1245
POWer<m>:ONOff:INPut[:SOURce]	1245
POWer<m>:ONOff:ONUMber	1245
POWer<m>:ONOff:OUTPut<n>:DC:ABSolute[:VALue]	1246
POWer<m>:ONOff:OUTPut<n>:DISPlay:RESult[:ENABLE]	1246
POWer<m>:ONOff:OUTPut<n>[:SOURce]	1246
POWer<m>:ONOff[:TYPE]	1247

POWer<m>:ONOff:INPut:AC:ABSolute[:VALue] <InputACThreshold>

Sets the threshold for the AC input signal.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<InputACThreshold> Range: 0 to 1E+26
 Increment: 0.001
 *RST: 1
 Default unit: V

Usage:

Asynchronous command

Manual operation: See "[AC threshold](#)" on page 388

POWer<m>:ONOff:INPut:DC:ABSolute[:VALue] <InputDCThreshold>

Sets the threshold for the DC input signal.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<InputDCThreshold> Range: -1E+26 to 1E+26
Increment: 0.001
*RST: 1
Default unit: V

Usage: Asynchronous command

Manual operation: See ["DC threshold"](#) on page 387

POWer<m>:ONOff:INPut:TYPE <InputType>

Selects whether the input signal is AC or CD.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<InputType> DC | AC
*RST: DC

Usage: Asynchronous command

Manual operation: See ["Input type"](#) on page 387

POWer<m>:ONOff:INPut[:SOURce] <InputSource>

Selects the source waveform of the input signal.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<InputSource> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Usage: Asynchronous command

Manual operation: See ["Input source"](#) on page 387

POWer<m>:ONOff:ONUMber <OutputCount>

Sets the number of outputs to be used in the measurement.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<OutputCount>

Usage: Asynchronous command

POWer<m>:ONOff:OUTPut<n>:DC:ABSolute[:VALue] <OutDCThreshold>

Sets the threshold for the selected output signal.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1..3, index of the output signal (4-channel instrument).
1..7, index of the output signal (8-channel instrument).

Parameters:

<OutDCThreshold> Range: -1E+26 to 1E+26
Increment: 0.001
*RST: 1
Default unit: V

Usage: Asynchronous command

Manual operation: See ["DC threshold"](#) on page 388

POWer<m>:ONOff:OUTPut<n>:DISPlay:RESult[:ENABLE] <Enable>

Activates the indicated output line.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1..3, index of the output signal (4-channel instrument).
1..7, index of the output signal (8-channel instrument).

Parameters:

<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Enable output"](#) on page 388

POWer<m>:ONOff:OUTPut<n>[:SOURce] <OutputSource>

Selects the channel of the output signal. All analog channels except for the input channel can be used. Each channel can be used only once.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1..3, index of the output signal (4-channel instrument).
1..7, index of the output signal (8-channel instrument).

Parameters:

<OutputSource> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Example: POW2:ONOF:OUTP3 C4
Sets the 3rd output to channel 4.

Usage: Asynchronous command

Manual operation: See "Output source" on page 388

POWer<m>:ONOFf[:TYPE] <Mode>

Selects the turn on or turn off measurement.

Suffix:
<m> 1 to 6, index of the power analysis measurement

Parameters:
<Mode> TON | TOFF
*RST: TON

Usage: Asynchronous command

Manual operation: See "Mode" on page 387

Turn on/off display

POWer<m>:ONOFf:OUTPut<n>:DISPlay:RLINe[:ENABLE] <Display>

Enables the result lines for the selected output.

Suffix:
<m> 1 to 6, index of the power analysis measurement
<n> 1..3, index of the output signal (4-channel instrument).
1..7, index of the output signal (8-channel instrument).

Parameters:
<Display> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See "Result line <n>" on page 389

Turn on/off results

POWer<m>:ONOFf:RESult<n>:TIME[:ACTual]?

Returns the measured turn-on time or turn-off time of the specified input-output pair.

Suffix:
<m> 1 to 6, index of the power analysis measurement
<n> 1..*
Index of the output signal.

Return values:

<Time> Range: -1E+26 to 1E+26
 Increment: 0.1
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

18.17.3.6 Power efficiency

- [Efficiency setup](#)..... 1248
- [Efficiency gate](#)..... 1250
- [Efficiency display](#)..... 1250
- [Efficiency results](#)..... 1251

Efficiency setup

POWER<m>:EFFiciency:INPut<n>:CURRent[:SOURce]	1248
POWER<m>:EFFiciency:INPut<n>:VOLTage[:SOURce]	1248
POWER<m>:EFFiciency:INPut<n>[:TYPE]	1249
POWER<m>:EFFiciency:ONUMber?	1249
POWER<m>:EFFiciency:OUTPut<n>:CURRent[:SOURce]	1249
POWER<m>:EFFiciency:OUTPut<n>:VOLTage[:SOURce]	1250
POWER<m>:EFFiciency:OUTPut<n>[:TYPE]	1250

POWER<m>:EFFiciency:INPut<n>:CURRent[:SOURce] <SourceCurrent>

Selects the current source waveform of the input line.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <n> Irrelevant, omit the suffix.

Parameters:

<SourceCurrent> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Usage:

Asynchronous command

Manual operation: See "[Current \(Input\)](#)" on page 392

POWER<m>:EFFiciency:INPut<n>:VOLTage[:SOURce] <SourceVoltage>

Selects the voltage source waveform of the input line.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <n> Irrelevant, omit the suffix.

Parameters:

<SourceVoltage> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Usage: Asynchronous command
Manual operation: See "[Voltage \(Input\)](#)" on page 392

POWER<m>:EFFiciency:INPut<n>[:TYPE] <Type>

Selects the type of the current flow: AC or DC.

Suffix:
 <m> 1 to 6, index of the power analysis measurement
 <n> Irrelevant, omit the suffix.

Parameters:
 <Type> DC | AC
 *RST: DC

Usage: Asynchronous command
Manual operation: See "[Input type](#)" on page 392

POWER<m>:EFFiciency:ONUMber? [MAX]

Returns the number of available outputs.

You can query the maximum value with <command>? MAX.

The maximum number of output lines is *Number of channels / 2 - 1*.

Suffix:
 <m> 1 to 6, index of the power analysis measurement

Return values:
 <OutputCount> Number of outputs

Usage: Query only
 Asynchronous command

POWER<m>:EFFiciency:OUTPut<n>:CURRent[:SOURce] <SourceCurrent>

Selects the current source waveform of the selected output line.

Suffix:
 <m> 1 to 6, index of the power analysis measurement
 <n> 1..3, output index
 Suffix >1 requires an instrument with more than 4 channels.

Parameters:
 <SourceCurrent> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Usage: Asynchronous command
Manual operation: See "[Current \(Output\)](#)" on page 393

POWer<m>:EFFiciency:OUTPut<n>:VOLTage[:SOURce] <SourceVoltage>

Selects the voltage source waveform of the selected output line.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1..3, output index
Suffix >1 requires an instrument with more than 4 channels.

Parameters:

<SourceVoltage> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Usage: Asynchronous command

Manual operation: See "[Voltage \(Output\)](#)" on page 393

POWer<m>:EFFiciency:OUTPut<n>[:TYPE] <Type>

Selects the type of the current flow: AC or DC.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1..3, output index
Suffix >1 requires an instrument with more than 4 channels.

Parameters:

<Type> DC | AC
*RST: DC

Usage: Asynchronous command

Manual operation: See "[Output type](#)" on page 393

Efficiency gate**POWer<m>:EFFiciency:GATE <Gate>**

Sets the gate for the specified efficiency analysis. Configure the gate before you can assign it. Make sure that the suffix matches the power efficiency measurement.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Gate> 0 to 8, index of the assigned gate. The value 0 indicates that no gate is assigned.

Usage: Asynchronous command

Efficiency display

[POWer<m>:EFFiciency:DISPlay:RESult:OUTPut<n>:EFFiciency\[:ENABLE\]](#).....1251

[POWer<m>:EFFiciency:DISPlay:RESult:OUTPut<n>:POWer\[:ENABLE\]](#).....1251

POWer<m>:EFFiciency:DISPlay:RESult:TOTal<n>:EFFiciency[:ENABle].....	1251
POWer<m>:EFFiciency:DISPlay:RESult:TOTal<n>:OPOWer[:ENABle].....	1251

POWer<m>:EFFiciency:DISPlay:RESult:OUTPut<n>:EFFiciency[:ENABle]

<Show>

POWer<m>:EFFiciency:DISPlay:RESult:OUTPut<n>:POWER[:ENABle] <Show>

The commands enable the power and efficiency measurements of the selected output line.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1..3, output index
 Suffix >1 requires an instrument with more than 4 channels.

Parameters:

<Show> OFF | ON

*RST: ON

Usage: Asynchronous command

POWer<m>:EFFiciency:DISPlay:RESult:TOTal<n>:EFFiciency[:ENABle] <Show>
POWer<m>:EFFiciency:DISPlay:RESult:TOTal<n>:OPOWer[:ENABle] <Show>

The commands enable the total power and efficiency measurements of the selected output line. These measurements require an instrument with more than 4 channels.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Parameters:

<Show> OFF | ON

*RST: ON

Usage: Asynchronous command**Efficiency results**

See "Overview of statistic results" on page 1209.

POWer<m>:EFFiciency:RESult:INPut:POWer[:ACTual]?.....	1252
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency[:ACTual]?.....	1252
POWer<m>:EFFiciency:RESult:TOTal:OPOWer[:ACTual]?.....	1252
POWer<m>:EFFiciency:RESult:INPut:POWer:AVERAge?.....	1252
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:AVERAge?.....	1252
POWer<m>:EFFiciency:RESult:TOTal:OPOWer:AVERAge?.....	1252
POWer<m>:EFFiciency:RESult:INPut:POWer:EVTCount?.....	1253
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:EVTCount?.....	1253
POWer<m>:EFFiciency:RESult:TOTal:OPOWer:EVTCount?.....	1253
POWer<m>:EFFiciency:RESult:INPut:POWer:NPEak?.....	1253
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:NPEak?.....	1253

POWer<m>:EFFiciency:RESult:TOTal:OPower:NPEak?	1253
POWer<m>:EFFiciency:RESult:INPut:POWer:PPEak?	1253
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:PPEak?	1253
POWer<m>:EFFiciency:RESult:TOTal:OPower:PPEak?	1253
POWer<m>:EFFiciency:RESult:INPut:POWer:RMS?	1254
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:RMS?	1254
POWer<m>:EFFiciency:RESult:TOTal:OPower:RMS?	1254
POWer<m>:EFFiciency:RESult:INPut:POWer:STDDev?	1254
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:STDDev?	1254
POWer<m>:EFFiciency:RESult:TOTal:OPower:STDDev?	1254
POWer<m>:EFFiciency:RESult:INPut:POWer:WFMCount?	1254
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:WFMCount?	1254
POWer<m>:EFFiciency:RESult:TOTal:OPower:WFMCount?	1254

POWer<m>:EFFiciency:RESult:INPut:POWer[:ACTual]?
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency[:ACTual]?
POWer<m>:EFFiciency:RESult:TOTal:OPower[:ACTual]?

Return the current result value for input power, total efficiency and total output power.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<Actual> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

POWer<m>:EFFiciency:RESult:INPut:POWer:AVERage?
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:AVERage?
POWer<m>:EFFiciency:RESult:TOTal:OPower:AVERage?

Return the average value for input power, total efficiency and total output power if statistics are enabled.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<Average> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

POWer<m>:EFFiciency:RESult:INPut:POWer:EVTCount?
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:EVTCount?
POWer<m>:EFFiciency:RESult:TOTal:OPOWer:EVTCount?

Return the number of calculated measurement results for input power, total efficiency and total output power if statistics are enabled.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<Count> Range: 0 to 4000000000
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

POWer<m>:EFFiciency:RESult:INPut:POWer:NPEak?
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:NPEak?
POWer<m>:EFFiciency:RESult:TOTal:OPOWer:NPEak?

Return the negative peak value (minimum) for input power, total efficiency and total output power if statistics are enabled.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<MinPeak> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

POWer<m>:EFFiciency:RESult:INPut:POWer:PPEak?
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:PPEak?
POWer<m>:EFFiciency:RESult:TOTal:OPOWer:PPEak?

Return the npositive peak value (maximum) for input power, total efficiency and total output power if statistics are enabled.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<MaxPeak> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

POWer<m>:EFFiciency:RESult:INPut:POWer:RMS?
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:RMS?
POWer<m>:EFFiciency:RESult:TOTal:OPOWer:RMS?

Return the RMS value for input power, total efficiency and total output power if statistics are enabled.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<RMS> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

POWer<m>:EFFiciency:RESult:INPut:POWer:STDDev?
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:STDDev?
POWer<m>:EFFiciency:RESult:TOTal:OPOWer:STDDev?

Return the standard deviation for input power, total efficiency and total output power if statistics are enabled.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<StdDev> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

POWer<m>:EFFiciency:RESult:INPut:POWer:WFMCount?
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:WFMCount?
POWer<m>:EFFiciency:RESult:TOTal:OPOWer:WFMCount?

Return the number of calculated waveforms for input power, total efficiency and total output power if statistics are enabled.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<WaveformsCount> Range: 0 to 4000000000
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

18.17.3.7 Safe operating area (SOA)

• SOA setup	1255
• SOA mask	1256
• SOA actions	1261
• SOA results	1263

SOA setup

POWer<m>:SOA:MTESt<n>:IMEXport:NAME <Name>

Sets the path, the filename and the file format of the mask file.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Parameters:

<Name> String with path and file name with extension .xml.

Usage: Asynchronous command

Manual operation: See "[Save mask](#)" on page 398

POWer<m>:SOA:MTESt<n>:IMEXport:OPEN

Opens and loads the mask selected by [POWer<m>:SOA:MTESt<n>:IMEXport:NAME](#).

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Usage: Event
Asynchronous command

Manual operation: See "[Open](#)" on page 399

POWer<m>:SOA:MTESt<n>:IMEXport:SAVE

Saves the mask test to the file selected by [POWer<m>:SOA:MTESt<n>:IMEXport:NAME](#).

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Usage: Event
Asynchronous command

Manual operation: See "[Save mask](#)" on page 398

POWer<m>:SOA:SOURce:CURRent <SourceCurrent>

Selects the current source waveform. Analog channels and math waveforms can be used.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<SourceCurrent> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Usage:

Asynchronous command

Manual operation: See "[Current](#)" on page 398

POWer<m>:SOA:SOURce:VOLTage <SourceVoltage>

Selects the voltage source waveform. Analog channels and math waveforms can be used.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<SourceVoltage> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Usage:

Asynchronous command

Manual operation: See "[Voltage](#)" on page 398

SOA mask

POWer<m>:SOA:LIMit:APPLy	1256
POWer<m>:SOA:LIMit:IMAX	1257
POWer<m>:SOA:LIMit:PMAX	1257
POWer<m>:SOA:LIMit:VMAX	1257
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:ADD	1258
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:COUNT?	1258
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:ADD	1258
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:COUNT?	1259
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:REMOVe	1259
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:VALId?	1259
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:X	1260
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:Y	1260
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:REMOVe	1261

POWer<m>:SOA:LIMit:APPLy

Generates a mask using the given maximum values. The result is mask segment in the first quadrant of the XY-diagram.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Usage: Setting only
Asynchronous command

Manual operation: See ["Generate mask"](#) on page 401

POWer<m>:SOA:LIMit:IMAX <CurrentMax>

Sets the maximum current for the mask.

Suffix:
<m> 1 to 6, index of the power analysis measurement

Parameters:
<CurrentMax> Range: 0 to 1E+26
Increment: 0.001
*RST: 1
Default unit: A

Usage: Asynchronous command

Manual operation: See ["I max"](#) on page 400

POWer<m>:SOA:LIMit:PMAX <PowerMax>

Sets the maximum power for the mask.

Suffix:
<m> 1 to 6, index of the power analysis measurement

Parameters:
<PowerMax> Range: 0 to 1E+26
Increment: 0.001
*RST: 50
Default unit: W

Usage: Asynchronous command

Manual operation: See ["P max"](#) on page 401

POWer<m>:SOA:LIMit:VMAX <VoltageMax>

Sets the maximum voltage for the mask.

Suffix:
<m> 1 to 6, index of the power analysis measurement

Parameters:
<VoltageMax> Range: 0 to 1E+26
Increment: 0.001
*RST: 100
Default unit: V

Usage: Asynchronous command

Manual operation: See ["U max"](#) on page 400

POWer<m>:SOA:MTESt<n>:SEGMENT<o>:ADD

Adds a new segment to the SOA mask. Consider the order of the segments (1, 2, 3, 4) and use the next free segment index. If the specified segment index already exists, the given number is ignored and the new segment gets the next free index.

The new segment has no points. Use **POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:ADD** to add the points.

Suffix:

<m>	1 to 6, index of the power analysis measurement
<n>	Irrelevant, omit the suffix.
<o>	1...4, index of the segment.

Usage:

Setting only
Asynchronous command

Manual operation: See ["Add segment"](#) on page 400

POWer<m>:SOA:MTESt<n>:SEGMENT<o>:COUNT?

Returns the number of segments that belong to the SOA mask.

Suffix:

<m>	1 to 6, index of the power analysis measurement
<n>	Irrelevant, omit the suffix.
<o>	Irrelevant, omit the suffix.

Return values:

<Count>	Number of the mask segments
Range:	0 to 1
Increment:	1
*RST:	0

Usage:

Query only
Asynchronous command

Manual operation: See ["Add segment"](#) on page 400

POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:ADD

Adds a corner point to the selected mask segment at the next free suffix. The new point has the coordinates 0;0.

Suffix:

<m>	1 to 6, index of the power analysis measurement
<n>	Irrelevant, omit the suffix.
<o>	1...4, index of the segment.
<p>	Index is ignored.

Usage: Setting only
Asynchronous command

Manual operation: See ["Add segment"](#) on page 400

POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:COUNT? [MAX]

Returns the number of points that was added to the indicated mask segment.

You can query the maximum value with `<command>? MAX`.

Suffix:

<m>	1..*
<n>	*
<o>	*
<p>	*

Return values:

<Count>	Number of defined points

Usage: Query only
Asynchronous command

Manual operation: See ["Add segment"](#) on page 400

POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:REMOve

Deletes the specified corner point of the mask segment. When a point is deleted, the remaining points are reordered similar to segment deletion ([POWer<m>:SOA:MTESt<n>:SEGMENT<o>:REMOve](#)).

Suffix:

<m>	1 to 6, index of the power analysis measurement
<n>	Irrelevant, omit the suffix.
<o>	1...4, index of the segment.
<p>	1...9, point index

Usage: Setting only
Asynchronous command

Manual operation: See ["Add segment"](#) on page 400

POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:VALId?

Checks the validity of the selected point.

Suffix:

<m>	1 to 6, index of the power analysis measurement
<n>	Irrelevant, omit the suffix.

<o> 1...4, index of the segment.

<p> 1...9, point index

Return values:

<Valid> OFF | ON
ON = valid
OFF = invalid
*RST: ON

Usage: Query only
Asynchronous command

Manual operation: See ["Add segment"](#) on page 400

POWER<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:X <X>

Sets the horizontal position of the selected point.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

<o> 1...4, index of the segment.

<p> 1...4, index of the segment.

Parameters:

<X> Range: -1E+26 to 1E+26
Increment: 1E-06
*RST: 0
Default unit: s

Usage: Asynchronous command

Manual operation: See ["Point, X, Y"](#) on page 334

POWER<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:Y <Y>

Sets the vertical position of the selected point.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

<o> 1...4, index of the segment.

<p> 1...4, index of the segment.

Parameters:

<Y> Range: -1E+26 to 1E+26
Increment: 1E-06
*RST: 0
Default unit: V

Usage: Asynchronous command

Manual operation: See ["Point, X, Y"](#) on page 334

POWer<m>:SOA:MTESt<n>:SEGMENT<o>:REMove

Deletes the specified mask segment. When a segment is deleted, the remaining segments are reordered. For example, there are 3 segments (1, 2, 3). When you delete segment 2, then segment 3 gets the index 2.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

<o> 1...4, index of the segment.

Usage: Setting only
Asynchronous command

Manual operation: See ["Add segment"](#) on page 400

SOA actions

POWer<m>:SOA:MTESt<n>:ONViolation:BEEP	1261
POWer<m>:SOA:MTESt<n>:ONViolation:SCReenshot	1261
POWer<m>:SOA:MTESt<n>:ONViolation:STOP	1262
POWer<m>:SOA:MTESt<n>:ONViolation:TRIGgerout	1262
POWer<m>:SOA:MTESt<n>:ONViolation:WFMSave	1263

POWer<m>:SOA:MTESt<n>:ONViolation:BEEP <Beep>

Generates a beep sound if the command is set to `SUCCESS` or `VIOLation`.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Parameters:

<Beep> NOAction | SUCCESS | VIOLation

*RST: NOAction

Usage: Asynchronous command

Manual operation: See ["Beep"](#) on page 335

POWer<m>:SOA:MTESt<n>:ONViolation:SCReenshot <SaveScreenshot>

Saves the waveform data to file if the command is set to `SUCCESS` or `VIOLation`.

To configure the screenshot settings, use the commands described in [Section 18.13.9, "Screenshots"](#), on page 1114.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Parameters:

<SaveScreenshot> NOAction | SUCCess | VIOLation

*RST: NOAction

Usage: Asynchronous command

Manual operation: See ["Screenshot"](#) on page 336

POWer<m>:SOA:MTESt<n>:ONViolation:STOP <StopAcq>

Stops the running acquisition if the command is set to SUCCess or VIOLation.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Parameters:

<StopAcq> NOAction | SUCCess | VIOLation

*RST: NOAction

Usage: Asynchronous command

Manual operation: See ["Stop acq"](#) on page 336

POWer<m>:SOA:MTESt<n>:ONViolation:TRIGgerout <TrigOutPls>

Sends an outgoing pulse to the [Trigger Out] connector if the command is set to SUCCess or VIOLation.

To configure the pulse, user the following commands:

- [TRIGger:ACTions:OUT:SOURce](#) on page 1039
- [TRIGger:ACTions:OUT:POLarity](#) on page 1040
- [TRIGger:ACTions:OUT:DELay](#) on page 1039
- [TRIGger:ACTions:OUT:PLENgtH](#) on page 1039

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Parameters:

<TrigOutPls> NOAction | SUCCess | VIOLation

*RST: NOAction

Usage: Asynchronous command

Manual operation: See ["Trigger out pulse"](#) on page 336

POWer<m>:SOA:MTESt<n>:ONViolation:WFMSave <SaveWfm>

Saves the waveform data to file if the command is set to `SUCCESS` or `VIOLation`.

To define the path and file names, use the `EXPort:WAVEform:AUTonaming:*` commands:

- `EXPort:WAVEform:AUTonaming:NAME` on page 1105
- `EXPort:WAVEform:AUTonaming:PATH` on page 1106
- `EXPort:WAVEform:AUTonaming:TYPE` on page 1106

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Parameters:

<SaveWfm> NOAction | SUCCESS | VIOLation
*RST: NOAction

Usage: Asynchronous command

Manual operation: See "Save wfm" on page 336

SOA results

<code>POWer<m>:SOA:RESult<n>:COUNT:FWAVEforms?</code>	1263
<code>POWer<m>:SOA:RESult<n>:COUNT:PWAVEforms?</code>	1263
<code>POWer<m>:SOA:RESult<n>:COUNT:WAVEforms?</code>	1264
<code>POWer<m>:SOA:RESult<n>:FRATe?</code>	1264
<code>POWer<m>:SOA:RESult<n>[:RESult]?</code>	1264

POWer<m>:SOA:RESult<n>:COUNT:FWAVEforms?

Returns the number of acquisitions that have failed the mask test, they hit the mask limits.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Return values:

<AcqsFailed> Range: 0 to 10000000000000
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

POWer<m>:SOA:RESult<n>:COUNT:PWAVEforms?

Returns the number of acquisitions that have passed the mask test without violation.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Return values:

<AcqsPassed> Range: 0 to 10000000000000
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

POWer<m>:SOA:RESult<n>:COUNT:WAVEforms?

Returns the number of tested acquisitions (waveforms).

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Return values:

<AcqsCompleted> Range: 0 to 10000000000000
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

POWer<m>:SOA:RESult<n>:FRATe?

Returns the ratio of failed acquisitions to the number of tested acquisitions.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Return values:

<FailRate> *RST: 0
Default unit: %

Usage:

Query only
Asynchronous command

POWer<m>:SOA:RESult<n>[:RESult]?

Returns the summary test status.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Return values:

<TestResult> PASS | FAIL
 *RST: PASS

Usage:

Query only
 Asynchronous command

18.17.3.8 Power waveform

POWER<m>:EFFiciency:DISPlay:WAVEform:INPut<n>:POWER[:ENABLE]	1265
POWER<m>:EFFiciency:DISPlay:WAVEform:OUTPut<n>:POWER[:ENABLE]	1265
POWER<m>:EFFiciency:DISPlay:WAVEform:TOTal<n>:OPower[:ENABLE]	1265
POWER<m>:HARMonics:DISPlay:POWER:WAVEform:ENABLE	1265
POWER<m>:QUALity:DISPlay:POWER:WAVEform:ENABLE	1265
POWER<m>:SWITChing:DISPlay:POWER:WAVEform[:ENABLE]	1265
POWER<m>:EFFiciency:INPut<n>:POWER:VERTical:OFFSet	1266
POWER<m>:EFFiciency:OUTPut<n>:POWER:VERTical:OFFSet	1266
POWER<m>:EFFiciency:TOTal<n>:OPower:VERTical:OFFSet	1266
POWER<m>:HARMonics:POWER:VERTical:OFFSet	1266
POWER<m>:QUALity:POWER:VERTical:OFFSet	1266
POWER<m>:SWITChing:POWER:VERTical:OFFSet	1266
POWER<m>:EFFiciency:INPut<n>:POWER:VERTical:SCALE:MODE	1266
POWER<m>:EFFiciency:OUTPut<n>:POWER:VERTical:SCALE:MODE	1266
POWER<m>:EFFiciency:TOTal<n>:OPower:VERTical:SCALE:MODE	1266
POWER<m>:HARMonics:POWER:VERTical:SCALE:MODE	1266
POWER<m>:QUALity:POWER:VERTical:SCALE:MODE	1266
POWER<m>:SWITChing:POWER:VERTical:SCALE:MODE	1266
POWER<m>:EFFiciency:INPut<n>:POWER:VERTical:SCALE[:VALue]	1267
POWER<m>:EFFiciency:OUTPut<n>:POWER:VERTical:SCALE[:VALue]	1267
POWER<m>:EFFiciency:TOTal<n>:OPower:VERTical:SCALE[:VALue]	1267
POWER<m>:HARMonics:POWER:VERTical:SCALE[:VALue]	1267
POWER<m>:QUALity:POWER:VERTical:SCALE[:VALue]	1267
POWER<m>:SWITChing:POWER:VERTical:SCALE[:VALue]	1267

POWER<m>:EFFiciency:DISPlay:WAVEform:INPut<n>:POWER[:ENABLE] <State>
POWER<m>:EFFiciency:DISPlay:WAVEform:OUTPut<n>:POWER[:ENABLE] <State>
POWER<m>:EFFiciency:DISPlay:WAVEform:TOTal<n>:OPower[:ENABLE] <State>
POWER<m>:HARMonics:DISPlay:POWER:WAVEform:ENABLE <State>
POWER<m>:QUALity:DISPlay:POWER:WAVEform:ENABLE <State>
POWER<m>:SWITChing:DISPlay:POWER:WAVEform[:ENABLE] <State>

Displays or hides the specified power waveform.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <n> INPut and TOTal index: omit the suffix. OUTPut index: 1 to 3
 (suffix >1 requires an instrument with more than 4 channels).

Parameters:

<State> OFF | ON

Usage: Asynchronous command

Manual operation: See ["Display"](#) on page 406

POWer<m>:EFFiciency:INPut<n>:POWer:VERTical:OFFSet <VerticalOffset>
POWer<m>:EFFiciency:OUTPut<n>:POWer:VERTical:OFFSet <VerticalOffset>
POWer<m>:EFFiciency:TOTal<n>:OPOWer:VERTical:OFFSet <VerticalOffset>
POWer<m>:HARMonics:POWer:VERTical:OFFSet <VerticalOffset>
POWer<m>:QUALity:POWer:VERTical:OFFSet <VerticalOffset>
POWer<m>:SWITching:POWer:VERTical:OFFSet <VerticalOffset>

Sets the vertical offset of the power waveform if the relevant
 POWer<m>:*:POWer:VERTical:SCALE:MODE command is set to MANual.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> INPut and TOTal index: omit the suffix. OUTPut index: 1 to 3
 (suffix >1 requires an instrument with more than 4 channels).

Parameters:

<VerticalOffset> Range: -1000000000000000 to 1000000000000000
 Increment: 0.01
 *RST: 0
 Default unit: div

Usage: Asynchronous command

Manual operation: See ["Offset"](#) on page 407

POWer<m>:EFFiciency:INPut<n>:POWer:VERTical:SCALE:MODE <VertScIMd>
POWer<m>:EFFiciency:OUTPut<n>:POWer:VERTical:SCALE:MODE <VertScIMd>
POWer<m>:EFFiciency:TOTal<n>:OPOWer:VERTical:SCALE:MODE <VertScIMd>
POWer<m>:HARMonics:POWer:VERTical:SCALE:MODE <VertScIMd>
POWer<m>:QUALity:POWer:VERTical:SCALE:MODE <VertScIMd>
POWer<m>:SWITching:POWer:VERTical:SCALE:MODE <VertScIMd>

Selects the scaling mode for display of the power waveform.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> INPut and TOTal index: omit the suffix. OUTPut index: 1 to 3
 (suffix >1 requires an instrument with more than 4 channels).

Parameters:

<VertScIMd> MANual | AUTO

AUTO
 The instrument selects the most appropriate scale.

MANual
 You can change the vertical scale and offset.

*RST: AUTO

Usage: Asynchronous command

Manual operation: See "Scale mode" on page 407

POWer<m>:EFFiciency:INPut<n>:POWer:VERTical:SCALe[:VALue]
 <VerticalScale>

POWer<m>:EFFiciency:OUTPut<n>:POWer:VERTical:SCALe[:VALue]
 <VerticalScale>

POWer<m>:EFFiciency:TOTal<n>:OPOWer:VERTical:SCALe[:VALue]
 <VerticalScale>

POWer<m>:HARMonics:POWer:VERTical:SCALe[:VALue] <VerticalScale>

POWer<m>:QUALity:POWer:VERTical:SCALe[:VALue] <VerticalScale>

POWer<m>:SWITching:POWer:VERTical:SCALe[:VALue] <VerticalScale>

Sets the vertical scale of the power waveform if the relevant
 POWer<m>:*:POWer:VERTical:SCALe:MODE command is set to MANual.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> INPut and TOTal index: omit the suffix. OUTPut index: 1 to 3
 (suffix >1 requires an instrument with more than 4 channels).

Parameters:

<VerticalScale> Range: 1E-12 to 1000000000000000
 Increment: 1E-05
 *RST: 0.5
 Default unit: V

Usage: Asynchronous command

Manual operation: See "Scale" on page 407

18.17.3.9 Reference level

POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:HYSTeresis.....	1268
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:HYSTeresis.....	1268
POWer<m>:HARMonics:REFLevel<rl>:ABSolute:HYSTeresis.....	1268
POWer<m>:QUALity:REFLevel<rl>:ABSolute:HYSTeresis.....	1268
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:LLEVel.....	1269
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:LLEVel.....	1269
POWer<m>:HARMonics:REFLevel<rl>:ABSolute:LLEVel.....	1269
POWer<m>:QUALity:REFLevel<rl>:ABSolute:LLEVel.....	1269
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:MLEVel.....	1269
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:MLEVel.....	1269
POWer<m>:HARMonics:REFLevel<rl>:ABSolute:MLEVel.....	1269
POWer<m>:QUALity:REFLevel<rl>:ABSolute:MLEVel.....	1269
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:ULEVel.....	1270
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:ULEVel.....	1270
POWer<m>:HARMonics:REFLevel<rl>:ABSolute:ULEVel.....	1270
POWer<m>:QUALity:REFLevel<rl>:ABSolute:ULEVel.....	1270
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:LMODE.....	1270

POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:LMODE.....	1270
POWer<m>:HARMonics:REFLevel<rl>:LMODE.....	1270
POWer<m>:QUALity:REFLevel<rl>:LMODE.....	1270
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:HYSTeresis.....	1270
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:HYSTeresis.....	1270
POWer<m>:HARMonics:REFLevel<rl>:RELative:HYSTeresis.....	1271
POWer<m>:QUALity:REFLevel<rl>:RELative:HYSTeresis.....	1271
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:LOWer.....	1271
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:LOWer.....	1271
POWer<m>:HARMonics:REFLevel<rl>:RELative:LOWer.....	1271
POWer<m>:QUALity:REFLevel<rl>:RELative:LOWer.....	1271
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:MIDDLE.....	1271
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:MIDDLE.....	1271
POWer<m>:HARMonics:REFLevel<rl>:RELative:MIDDLE.....	1272
POWer<m>:QUALity:REFLevel<rl>:RELative:MIDDLE.....	1272
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:MODE.....	1272
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:MODE.....	1272
POWer<m>:HARMonics:REFLevel<rl>:RELative:MODE.....	1272
POWer<m>:QUALity:REFLevel<rl>:RELative:MODE.....	1272
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:UPPer.....	1273
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:UPPer.....	1273
POWer<m>:HARMonics:REFLevel<rl>:RELative:UPPer.....	1273
POWer<m>:QUALity:REFLevel<rl>:RELative:UPPer.....	1273

POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:HYSTeresis <HystAbs>

POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:HYSTeresis

<HystAbs>

POWer<m>:HARMonics:REFLevel<rl>:ABSolute:HYSTeresis <HystAbs>

POWer<m>:QUALity:REFLevel<rl>:ABSolute:HYSTeresis <HystAbs>

Defines a hysteresis for the middle reference level. A rise or fall from the middle reference value that does not exceed the hysteresis is rejected as noise.

Suffix:

<m>	1 to 6, index of the power analysis measurement
<rl>	Irrelevant, omit the suffix.
<n>	INPut index: omit the suffix. OUTPut index: 1 to 3 (suffix >1 requires an instrument with more than 4 channels).

Parameters:

<HystAbs>	Range: 0 to 1E+26
	Increment: 0.001
	*RST: 0.005
	Default unit: V

Usage: Asynchronous command

Manual operation: See "Hysteresis" on page 405

POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:LLEVel <LowerLevel>
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:LLEVel
 <LowerLevel>

POWer<m>:HARMonics:REFLevel<rl>:ABSolute:LLEVel <LowerLevel>

POWer<m>:QUALity:REFLevel<rl>:ABSolute:LLEVel <LowerLevel>

Sets the lower reference level in absolute values. This is required, e.g., to determine a fall.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <rl> Irrelevant, omit the suffix.
 <n> INPut index: omit the suffix. OUTPut index: 1 to 3 (suffix >1 requires an instrument with more than 4 channels).

Parameters:

<LowerLevel> Range: -1E+26 to 1E+26
 Increment: 0.001
 *RST: 0
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Upper level](#), [Middle level](#), [Lower level](#)" on page 403

POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:MLEVel <MiddleLevel>
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:MLEVel
 <MiddleLevel>

POWer<m>:HARMonics:REFLevel<rl>:ABSolute:MLEVel <MiddleLevel>

POWer<m>:QUALity:REFLevel<rl>:ABSolute:MLEVel <MiddleLevel>

Sets the middle reference level in absolute values.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <rl> Irrelevant, omit the suffix.
 <n> INPut index: omit the suffix. OUTPut index: 1 to 3 (suffix >1 requires an instrument with more than 4 channels).

Parameters:

<MiddleLevel> Range: -1E+26 to 1E+26
 Increment: 0.001
 *RST: 0
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Upper level](#), [Middle level](#), [Lower level](#)" on page 403

POWER<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:ULEVel <UpperLevel>
POWER<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:ULEVel
 <UpperLevel>

POWER<m>:HARMonics:REFLevel<rl>:ABSolute:ULEVel <UpperLevel>

POWER<m>:QUALity:REFLevel<rl>:ABSolute:ULEVel <UpperLevel>

Sets the upper reference level in absolute values. This is required to determine a rise.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <rl> Irrelevant, omit the suffix.
 <n> INPut index: omit the suffix. OUTPut index: 1 to 3 (suffix >1 requires an instrument with more than 4 channels).

Parameters:

<UpperLevel> Range: -1E+26 to 1E+26
 Increment: 0.001
 *RST: 0
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Upper level](#), [Middle level](#), [Lower level](#)" on page 403

POWER<m>:EFFiciency:INPut<n>:REFLevel<rl>:LMODE <LevelMode>
POWER<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:LMODE <LevelMode>
POWER<m>:HARMonics:REFLevel<rl>:LMODE <LevelMode>
POWER<m>:QUALity:REFLevel<rl>:LMODE <LevelMode>

Defines if the reference level is set in absolute or relative values.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <rl> Irrelevant, omit the suffix.
 <n> INPut index: omit the suffix. OUTPut index: 1 to 3 (suffix >1 requires an instrument with more than 4 channels).

Parameters:

<LevelMode> ABS | REL
 *RST: REL

Usage: Asynchronous command

Manual operation: See "[Level mode](#)" on page 403

POWER<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:HYSTeresis <HystRel>
POWER<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:HYSTeresis
 <HystRel>

POWer<m>:HARMonics:REFLevel<rl>:RELative:HYSTeresis <HystRel>
POWer<m>:QUALity:REFLevel<rl>:RELative:HYSTeresis <HystRel>

Defines a hysteresis for the middle reference level. A rise or fall from the middle reference value that does not exceed the hysteresis is rejected as noise.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <rl> Irrelevant, omit the suffix.
 <n> INPut index: omit the suffix. OUTPut index: 1 to 3 (suffix >1 requires an instrument with more than 4 channels).

Parameters:

<HystRel> Range: 0 to 50
 Increment: 1
 *RST: 10
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Hysteresis"](#) on page 405

POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:LOWer
 <LowRefLevRel>

POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:LOWer
 <LowRefLevRel>

POWer<m>:HARMonics:REFLevel<rl>:RELative:LOWer <LowRefLevRel>

POWer<m>:QUALity:REFLevel<rl>:RELative:LOWer <LowRefLevRel>

Sets the lower relative reference level if [POWer<m>:QUALity:REFLevel<rl>:RELative:MODE](#) is set to USER.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <rl> Irrelevant, omit the suffix.
 <n> INPut index: omit the suffix. OUTPut index: 1 to 3 (suffix >1 requires an instrument with more than 4 channels).

Parameters:

<LowRefLevRel> Range: -100 to 200
 Increment: 1
 *RST: 10
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Upper level, Middle level, Lower level"](#) on page 404

POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:MIDDLE <MidRefLevRel>

POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:MIDDLE
 <MidRefLevRel>

POWer<m>:HARMonics:REFLevel<rl>:RELative:MIDDLE <MidRefLevRel>
POWer<m>:QUALity:REFLevel<rl>:RELative:MIDDLE <MidRefLevRel>

Sets the middle relative reference level if **POWer<m>:QUALity:REFLevel<rl>:RELative:MODE** is set to **USER**.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <rl> Irrelevant, omit the suffix.
 <n> INPut index: omit the suffix. OUTPut index: 1 to 3 (suffix >1 requires an instrument with more than 4 channels).

Parameters:

<MidRefLevRel> Range: -100 to 200
 Increment: 1
 *RST: 50
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Upper level, Middle level, Lower level"](#) on page 404

POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:MODE <RelativeLevels>
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:MODE
 <RelativeLevels>

POWer<m>:HARMonics:REFLevel<rl>:RELative:MODE <RelativeLevels>
POWer<m>:QUALity:REFLevel<rl>:RELative:MODE <RelativeLevels>

The lower, middle and upper reference levels, defined as percentages of the high signal level.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <rl> Irrelevant, omit the suffix.
 <n> INPut index: omit the suffix. OUTPut index: 1 to 3 (suffix >1 requires an instrument with more than 4 channels).

Parameters:

<RelativeLevels> FIVE | TEN | TWENTy | USER

FIVE

5/50/95

TEN

10/50/90

TWENTy

20/50/80

USER

Set the reference levels to individual values with **POWer<m>:QUALity:REFLevel<rl>:RELative:LOWer**, **POWer<m>:QUALity:REFLevel<rl>:RELative:MIDDLE**, and **POWer<m>:QUALity:REFLevel<rl>:RELative:UPPer**.

*RST: TEN

Usage: Asynchronous command

Manual operation: See ["Relative levels"](#) on page 404

POWER<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:UPPer <UppRefLevRel>

**POWER<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:UPPer
<UppRefLevRel>**

POWER<m>:HARMonics:REFLevel<rl>:RELative:UPPer <UppRefLevRel>

POWER<m>:QUALity:REFLevel<rl>:RELative:UPPer <UppRefLevRel>

Sets the upper relative reference level if **POWER<m>:QUALity:REFLevel<rl>:RELative:MODE** on page 1272 is set to **USER**.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<rl> Irrelevant, omit the suffix.

<n> INPut index: omit the suffix. OUTPut index: 1 to 3 (suffix >1 requires an instrument with more than 4 channels).

Parameters:

<UppRefLevRel> Range: -100 to 200
Increment: 1
*RST: 90
Default unit: %

Usage: Asynchronous command

Manual operation: See ["Upper level, Middle level, Lower level"](#) on page 404

18.17.3.10 Power analysis data

This section describes the commands for exporting power analysis measurement data.

POWER<m>:EFFiciency:INPut<n>:POWER:DATA:HEADer?	1273
POWER<m>:EFFiciency:OUTPut<n>:POWER:DATA:HEADer?	1273
POWER<m>:EFFiciency:TOTal<n>:OPOWER:DATA:HEADer?	1273
POWER<m>:HARMonics:POWER:DATA:HEADer?	1274
POWER<m>:QUALity:POWER:DATA:HEADer?	1274
POWER<m>:SWITching:POWER:DATA:HEADer?	1274
POWER<m>:EFFiciency:INPut<n>:POWER:DATA[:VALues]?	1274
POWER<m>:EFFiciency:OUTPut<n>:POWER:DATA[:VALues]?	1274
POWER<m>:EFFiciency:TOTal<n>:OPOWER:DATA[:VALues]?	1274
POWER<m>:HARMonics:POWER:DATA[:VALues]?	1274
POWER<m>:QUALity:POWER:DATA[:VALues]?	1274
POWER<m>:SWITching:POWER:DATA[:VALues]?	1274

POWER<m>:EFFiciency:INPut<n>:POWER:DATA:HEADer?

POWER<m>:EFFiciency:OUTPut<n>:POWER:DATA:HEADer?

POWER<m>:EFFiciency:TOTal<n>:OPOWER:DATA:HEADer?

POWer<m>:HARMonics:POWer:DATA:HEADer?

POWer<m>:QUALity:POWer:DATA:HEADer?

POWer<m>:SWITching:POWer:DATA:HEADer?

Returns the header of the power analysis waveform data. The header contains the attributes of the waveform.

For power harmonics measurements, data is only available if **POWer<m>:HARMonics:STANdard** is set to **ENC** or **END**.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<XStart> 1. header value: start time in s

<XStop> 2. header value: end time in s

<RecordLength> 3. header value: record length of the waveform in samples

<ValuesPerSample> 4. header value: number of values per sample. For power quality measurements, the value is 1.

Usage:

Query only

Asynchronous command

POWer<m>:EFFiciency:INPut<n>:POWer:DATA[:VALues]? [<Offset>[,<Length>]]
POWer<m>:EFFiciency:OUTPut<n>:POWer:DATA[:VALues]? [<Offset>[,<Length>]]
POWer<m>:EFFiciency:TOTal<n>:OPOWer:DATA[:VALues]? [<Offset>[,<Length>]]
POWer<m>:HARMonics:POWer:DATA[:VALues]? [<Offset>[,<Length>]]
POWer<m>:QUALity:POWer:DATA[:VALues]? [<Offset>[,<Length>]]
POWer<m>:SWITching:POWer:DATA[:VALues]? [<Offset>[,<Length>]]

Returns the data of the power analysis waveform points for transmission from the instrument to the controlling computer.

Without parameters, the complete waveform is retrieved. Using the offset and length parameters, data can be retrieved in smaller portions, which makes the command faster. If you send only one parameter, it is interpreted as offset, and the data is retrieved from offset to the end of the waveform.

To set the export format, use **FORMat [:DATA]**.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Query parameters:

<Offset> Number of offset waveform points to be skipped.

<Length> Number of waveform points to be retrieved.

Return values:

<Data> List of values according to the format and content settings.

Usage:

Query only

Asynchronous command

18.17.4 3-phase power analysis (option R&S MXO5C-K333)

Some of the commands in the following section are asynchronous. An overlapping or asynchronous command does not automatically finish executing before the next command starts executing. If overlapping commands must be executed in a defined order, e.g. to avoid wrong measurement results, they must be serviced sequentially.

To prevent an overlapping execution of commands, one of the commands `*OPC`, `*OPC?` or `*WAI` can be used after the command or a command set.

For more information, see:

- www.rohde-schwarz.com/rc-via-scp, section "Command sequence and synchronization"
- [3-phase general settings](#)..... 1275
- [3-phase power quality](#)..... 1276
- [3-phase power harmonics](#)..... 1290
- [3-phase power sources](#)..... 1298
- [3-phase power waveform](#)..... 1300
- [3-phase reference level](#)..... 1303
- [3-phase power analysis data](#)..... 1308

18.17.4.1 3-phase general settings

P3PHase<m>[:ENABLE]	1275
P3PHase<m>:TYPE	1275
EXPort:RESult:SElect:P3PHase<m>	1276

P3PHase<m>[:ENABLE] <State>

Enables the 3-phase power measurement instance.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<State> OFF | ON

Usage: Asynchronous command

Manual operation: See "+ Add" on page 409

P3PHase<m>:TYPE <Type>

Sets the type for the respective 3-phase power analysis measurement.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Type> P3Quality | P3Harmonics
 P3Quality = 3-phase power quality
 P3Harmonics = 3-phase power harmonics

Example: P3PH1:TYPE QUAL
Sets the first power analysis measurement to quality.

Usage: Asynchronous command

Manual operation: See "+ Add" on page 409

EXPort:RESult:SElect:P3PHase<m> <ExportResults>

If enabled, includes the results of selected 3-phase power analysis measurement in the results export file.

Suffix:
<m> 1 to 6, index of the power analysis measurement

Parameters:
<ExportResults> OFF | ON
*RST: OFF

Usage: Asynchronous command

18.17.4.2 3-phase power quality

- [3-phase power quality setup](#)..... 1276
- [3-phase phasor diagram](#)..... 1277
- [3-phase power quality measurement display](#)..... 1278
- [3-phase power quality results](#)..... 1282

3-phase power quality setup

- P3PHase<m>:QUALity:FREQuency[:VALue]..... 1276
- P3PHase<m>:QUALity:FREQuency:USER..... 1276
- P3PHase<m>:QUALity:FREQuency:USER..... 1277

P3PHase<m>:QUALity:FREQuency[:VALue] <FundamFreq>

Sets the input frequency of the source signal in Hz.

Suffix:
<m> 1 to 6, index of the power analysis measurement

Parameters:
<FundamFreq> F50 | F60 | F400 | USER | AUTO
*RST: AUTO

Usage: Asynchronous command

Manual operation: See "Fund. frequency" on page 411

P3PHase<m>:QUALity:FREQuency:USER <UsrFundamFreq>

Sets the horizontal timebase to control the time scale of the waveform display.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<UsrFundamFreq> Range: 10 to 1000000
 Increment: 1
 *RST: 10
 Default unit: Hz

Usage: Asynchronous command

Manual operation: See ["User Frequency"](#) on page 412

P3PHase<m>:QUALity:FREQuency:USER <UsrFundamFreq>

Sets the horizontal timebase to control the time scale of the waveform display.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<UsrFundamFreq> Range: 10 to 1000000
 Increment: 1
 *RST: 10
 Default unit: Hz

Usage: Asynchronous command

Manual operation: See ["User Frequency"](#) on page 412

3-phase phasor diagram

P3PHase<m>:QUALity:PHASor[:ENABLE]	1277
P3PHase<m>:QUALity:PHASor:VOLTag:OFFSet	1278
P3PHase<m>:QUALity:PHASor:CURREnt:OFFSet	1278
P3PHase<m>:QUALity:PHASor:VOLTag:MAXimum	1278
P3PHase<m>:QUALity:PHASor:CURREnt:MAXimum	1278
P3PHase<m>:QUALity:PHASor:FSCreen	1278

P3PHase<m>:QUALity:PHASor[:ENABLE] <State>

Enables the phasor measurement for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<State> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["State"](#) on page 413

P3PHase<m>:QUALity:PHASor:VOLTage:OFFSet <VoltageOffset>

P3PHase<m>:QUALity:PHASor:CURREnt:OFFSet <CurrentOffset>

Sets the inner point of the phasor diagram.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<CurrentOffset> Range: -1000000000000000 to 100000
Increment: 0.11
*RST: 0
Default unit: A

Usage: Asynchronous command

Manual operation: See ["Offset"](#) on page 413

P3PHase<m>:QUALity:PHASor:VOLTage:MAXimum <VoltageMaximum>

P3PHase<m>:QUALity:PHASor:CURREnt:MAXimum <CurrentMaximum>

Sets the outer circumference of the phasor diagram.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<CurrentMaximum> Range: -1000000000000000 to 100000
Increment: 0.11
*RST: 0
Default unit: A

Usage: Asynchronous command

Manual operation: See ["Maximum"](#) on page 413

P3PHase<m>:QUALity:PHASor:FSCReen

Selects the most appropriate scale for the voltage and current phasors.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Usage:

Setting only
Asynchronous command

Manual operation: See ["Fit to Screen"](#) on page 413

3-phase power quality measurement display

P3PHase<m>:QUALity:DISPlay:CURREnt:CRESTfactor<n>[:ENABLE]..... 1279

P3PHase<m>:QUALity:DISPlay:CURREnt:PEAK<n>[:ENABLE]..... 1279

P3PHase<m>:QUALity:DISPlay:CURREnt:RMS<n>[:ENABLE]..... 1279

P3PHase<m>:QUALity:DISPlay:POWer<n>:ACTive[:ENABLE].....	1280
P3PHase<m>:QUALity:DISPlay:POWer<n>:APParent[:ENABLE].....	1280
P3PHase<m>:QUALity:DISPlay:POWer<n>:PFACtor[:ENABLE].....	1280
P3PHase<m>:QUALity:DISPlay:POWer<n>:PHASe[:ENABLE].....	1281
P3PHase<m>:QUALity:DISPlay:POWer<n>:REACTive[:ENABLE].....	1281
P3PHase<m>:QUALity:DISPlay:VOLTagE:CREStfactor<n>[:ENABLE].....	1281
P3PHase<m>:QUALity:DISPlay:VOLTagE:FREQuency<n>[:ENABLE].....	1281
P3PHase<m>:QUALity:DISPlay:VOLTagE:PEAK<n>[:ENABLE].....	1282
P3PHase<m>:QUALity:DISPlay:VOLTagE:RMS<n>[:ENABLE].....	1282

P3PHase<m>:QUALity:DISPlay:CURRent:CREStfactor<n>[:ENABLE] <DisplayState>

Enables the current crest factor measurement for individual phases for the 3-phase power quality analysis.

Suffix:

<m>	1 to 6, index of the power analysis measurement
<n>	1...3, index of the individual phase

Parameters:

<DisplayState>	OFF ON
*RST:	ON

Usage: Asynchronous command

P3PHase<m>:QUALity:DISPlay:CURRent:PEAK<n>[:ENABLE] <DisplayState>

Enables the current peak value measurement for individual phases for the 3-phase power quality analysis.

Suffix:

<m>	1 to 6, index of the power analysis measurement
<n>	1...3, index of the individual phase

Parameters:

<DisplayState>	OFF ON
*RST:	ON

Usage: Asynchronous command

P3PHase<m>:QUALity:DISPlay:CURRent:RMS<n>[:ENABLE] <DisplayState>

Enables the current RMS measurement for individual phases for the 3-phase power quality analysis.

Suffix:

<m>	1 to 6, index of the power analysis measurement
<n>	1...3, index of the individual phase

Parameters:

<DisplayState> OFF | ON
*RST: ON

Usage: Asynchronous command

P3PHase<m>:QUALity:DISPlay:POWer<n>:ACTive[:ENABLE] <DisplayState>

Enables the active measurement for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement
<n> 1...3, index of the individual phase

Parameters:

<DisplayState> OFF | ON
*RST: ON

Usage: Asynchronous command

P3PHase<m>:QUALity:DISPlay:POWer<n>:APParent[:ENABLE] <DisplayState>

Enables the apparent power measurement for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement
<n> 1...3, index of the individual phase

Parameters:

<DisplayState> OFF | ON
*RST: ON

Usage: Asynchronous command

P3PHase<m>:QUALity:DISPlay:POWer<n>:PFActor[:ENABLE] <DisplayState>

Enables the power factor measurement for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement
<n> 1...3, index of the individual phase

Parameters:

<DisplayState> OFF | ON
*RST: ON

Usage: Asynchronous command

P3PHase<m>:QUALity:DISPlay:POWer<n>:PHASe[:ENABLE] <DisplayState>

Enables the power phase measurement for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Parameters:

<DisplayState> OFF | ON
*RST: ON

Usage: Asynchronous command

P3PHase<m>:QUALity:DISPlay:POWer<n>:REACtive[:ENABLE] <DisplayState>

Enables the reactive power measurement for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Parameters:

<DisplayState> OFF | ON
*RST: ON

Usage: Asynchronous command

P3PHase<m>:QUALity:DISPlay:VOLTage:CREStfactor<n>[:ENABLE] <DisplayState>

Enables the voltage crest factor measurement for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Parameters:

<DisplayState> OFF | ON
*RST: ON

Usage: Asynchronous command

P3PHase<m>:QUALity:DISPlay:VOLTage:FREQuency<n>[:ENABLE] <DisplayState>

Enables the voltage frequency measurement for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Parameters:

<DisplayState> OFF | ON

*RST: ON

Usage:

Asynchronous command

P3PHase<m>:QUALity:DISPlay:VOLTage:PEAK<n>[:ENABLE] <DisplayState>

Enables the voltage peak value measurement for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Parameters:

<DisplayState> OFF | ON

*RST: ON

Usage:

Asynchronous command

P3PHase<m>:QUALity:DISPlay:VOLTage:RMS<n>[:ENABLE] <DisplayState>

Enables the voltage RMS measurement for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Parameters:

<DisplayState> OFF | ON

*RST: ON

Usage:

Asynchronous command

3-phase power quality results

P3PHase<m>:QUALity:RESult:CSorce:FREQuency<n>[:ACTual]?	1283
P3PHase<m>:QUALity:RESult:CURREnt:CREStfactor<n>[:ACTual]?	1283
P3PHase<m>:QUALity:RESult:TOTal:CURREnt:CREStfactor<n>[:ACTual]?	1284
P3PHase<m>:QUALity:RESult:CURREnt:PEAK<n>[:ACTual]?	1284
P3PHase<m>:QUALity:RESult:TOTal:CURREnt:PEAK<n>[:ACTual]?	1284
P3PHase<m>:QUALity:RESult:CURREnt:RMS<n>[:ACTual]?	1285
P3PHase<m>:QUALity:RESult:TOTal:CURREnt:RMS<n>[:ACTual]?	1285
P3PHase<m>:QUALity:RESult:POWer:ACTive<n>[:ACTual]?	1285
P3PHase<m>:QUALity:RESult:TOTal:POWer:ACTive<n>[:ACTual]?	1285

P3PHase<m>:QUALity:RESult:POWer:APParent<n>[:ACTual]?	1286
P3PHase<m>:QUALity:RESult:TOTal:POWer:APParent<n>[:ACTual]?	1286
P3PHase<m>:QUALity:RESult:POWer:PFACTOR<n>[:ACTual]?	1286
P3PHase<m>:QUALity:RESult:TOTal:POWer:PFACTOR<n>[:ACTual]?	1287
P3PHase<m>:QUALity:RESult:POWer:PHASe<n>[:ACTual]?	1287
P3PHase<m>:QUALity:RESult:TOTal:POWer:PHASe<n>[:ACTual]?	1287
P3PHase<m>:QUALity:RESult:POWer:REACTive<n>[:ACTual]?	1288
P3PHase<m>:QUALity:RESult:TOTal:POWer:REACTive<n>[:ACTual]?	1288
P3PHase<m>:QUALity:RESult:VOLTage:CRESTfactor<n>[:ACTual]?	1288
P3PHase<m>:QUALity:RESult:TOTal:VOLTage:CRESTfactor<n>[:ACTual]?	1289
P3PHase<m>:QUALity:RESult:VOLTage:PEAK<n>[:ACTual]?	1289
P3PHase<m>:QUALity:RESult:TOTal:VOLTage:PEAK<n>[:ACTual]?	1289
P3PHase<m>:QUALity:RESult:VOLTage:RMS<n>[:ACTual]?	1290
P3PHase<m>:QUALity:RESult:TOTal:VOLTage:RMS<n>[:ACTual]?	1290

P3PHase<m>:QUALity:RESult:CSOURCE:FREQUENCY<n>[:ACTual]?

Returns the cycle source frequency of each channel for the 3-phase power quality analysis.

Suffix:

<m>	1 to 6, index of the power analysis measurement
<n>	1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<Actual>	Range: -1E+26 to 1E+26
	Increment: 1E-10
	*RST: 0

Usage:

Query only
Asynchronous command

P3PHase<m>:QUALity:RESult:CURREnt:CRESTfactor<n>[:ACTual]?

Returns the current crest factors for individual phases for the 3-phase power quality analysis.

Suffix:

<m>	1 to 6, index of the power analysis measurement
<n>	1...3, index of the individual phase

Return values:

<Actual>	Range: -1E+26 to 1E+26
	Increment: 1E-10
	*RST: 0

Usage:

Query only
Asynchronous command

P3PHase<m>:QUALity:RESult:TOTal:CURRent:CREStfactor<n>[:ACTual]?

Returns the current total crest factor for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Return values:

<Actual> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

P3PHase<m>:QUALity:RESult:CURRent:PEAK<n>[:ACTual]?

Returns the current peak values for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Return values:

<Actual> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

P3PHase<m>:QUALity:RESult:TOTal:CURRent:PEAK<n>[:ACTual]?

Returns the total current peak values for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Return values:

<Actual> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

P3PHase<m>:QUALity:RESult:CURRent:RMS<n>[:ACTual]?

Returns the current RMS values for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Return values:

<Actual> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

P3PHase<m>:QUALity:RESult:TOTal:CURRent:RMS<n>[:ACTual]?

Returns the current total RMS for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Return values:

<Actual> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

P3PHase<m>:QUALity:RESult:POWEr:ACTive<n>[:ACTual]?

Returns the active power for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Return values:

<Actual> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

P3PHase<m>:QUALity:RESult:TOTal:POWEr:ACTive<n>[:ACTual]?

Returns the total active power for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Return values:

<Actual> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

P3PHase<m>:QUALity:RESult:POWer:APParent<n>[:ACTual]?

Returns the apparent power for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Return values:

<Actual> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

P3PHase<m>:QUALity:RESult:TOTal:POWer:APParent<n>[:ACTual]?

Returns the total apparent power for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Return values:

<Actual> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage:

Query only
Asynchronous command

P3PHase<m>:QUALity:RESult:POWer:PFACTOR<n>[:ACTual]?

Returns the power factor for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Return values:

<Actual> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage: Query only
Asynchronous command

P3PHase<m>:QUALity:RESult:TOTal:POWer:PFACtor<n>[:ACTual]?

Returns the total power factor for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Return values:

<Actual> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage: Query only
Asynchronous command

P3PHase<m>:QUALity:RESult:POWer:PHASe<n>[:ACTual]?

Returns the phase values for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Return values:

<Actual> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0

Usage: Query only
Asynchronous command

P3PHase<m>:QUALity:RESult:TOTal:POWer:PHASe<n>[:ACTual]?

Returns the total phase value for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> Irrelevant, omit the suffix.

Return values:

<Actual> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

P3PHase<m>:QUALity:RESult:POWer:REACTive<n>[:ACTual]?

Returns the reactive power for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <n> 1...3, index of the individual phase

Return values:

<Actual> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

P3PHase<m>:QUALity:RESult:TOTal:POWer:REACTive<n>[:ACTual]?

Returns the total reactive power for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <n> Irrelevant, omit the suffix.

Return values:

<Actual> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

P3PHase<m>:QUALity:RESult:VOLTage:CREStfactor<n>[:ACTual]?

Returns the voltage crest factors for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <n> 1...3, index of the individual phase

Return values:

<Actual> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

P3PHase<m>:QUALity:RESult:TOTal:VOLTage:CREStfactor<n>[:ACTual]?

Returns the total voltage crest factor for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <n> Irrelevant, omit the suffix.

Return values:

<Actual> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

P3PHase<m>:QUALity:RESult:VOLTage:PEAK<n>[:ACTual]?

Returns the voltage peak values for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <n> 1...3, index of the individual phase

Return values:

<Actual> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

P3PHase<m>:QUALity:RESult:TOTal:VOLTage:PEAK<n>[:ACTual]?

Returns the total voltage peak value for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <n> Irrelevant, omit the suffix.

Return values:

<Actual> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

P3Phase<m>:QUALity:RESult:VOLTage:RMS<n>[:ACTual]?

Returns the voltage RMS values for individual phases for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <n> 1...3, index of the individual phase

Return values:

<Actual> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

P3Phase<m>:QUALity:RESult:TOTal:VOLTage:RMS<n>[:ACTual]?

Returns the total voltage RMS value for the 3-phase power quality analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <n> Irrelevant, omit the suffix.

Return values:

<Actual> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage:

Query only
 Asynchronous command

18.17.4.3 3-phase power harmonics

- [3-phase power harmonics setup](#)..... 1291
- [3-phase bar graph](#)..... 1293
- [3-phase power harmonics results](#)..... 1295

3-phase power harmonics setup

P3PHase<m>:HARMonics:STANdard.....	1291
P3PHase<m>:HARMonics:REVisIon.....	1291
P3PHase<m>:HARMonics:FREQuency:EN.....	1291
P3PHase<m>:HARMonics:PFACtor:MODE.....	1292
P3PHase<m>:HARMonics:PFACtor:USER.....	1292
P3PHase<m>:HARMonics:RPOWer:MODE.....	1292
P3PHase<m>:HARMonics:RPOWer:USER.....	1293

P3PHase<m>:HARMonics:STANdard <Limits>

Sets a standard for the current harmonic measurement.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Limits> ENA | ENB | ENC | END
 ENA: EN 61000-3-2 Class A
 ENB: EN 61000-3-2 Class B
 ENC: EN 61000-3-2 Class C
 END: EN 61000-3-2 Class D
 *RST: ENA

Usage: Asynchronous command

Manual operation: See "Standard, Revision" on page 418

P3PHase<m>:HARMonics:REVisIon <Revision>

Selects the revision of the EN61000 standard, if P3PHase<m>:HARMonics:STANdard is set to ENA / ENB / ENC / END.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Revision> REV2011 | REV2019
 *RST: REV2019

Usage: Asynchronous command

Manual operation: See "Standard, Revision" on page 418

P3PHase<m>:HARMonics:FREQuency:EN <FundamFreqEN61000>

Sets the fundamental frequency of the input signal for the EN61000 standard, if P3PHase<m>:HARMonics:STANdard is set to ENA / ENB / ENC / END.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<FundamFreqEN61000-50 | F60 | AUTO
 *RST: AUTO

Usage: Asynchronous command

Manual operation: See "Fund. frequency" on page 418

P3PHase<m>:HARMonics:PFACTOR:MODE <PowFactMd>

Available if `P3PHase<m>:HARMonics:STANDARD` is set to ENC.

Selects if the power factor is defined automatically, or a user-defined value is used (`P3PHase<m>:HARMonics:PFACTOR:USER`).

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<PowFactMd> AUTO | USER
 *RST: AUTO

Usage: Asynchronous command

Manual operation: See "Power factor" on page 418

P3PHase<m>:HARMonics:PFACTOR:USER <UsrPowFact>

Available if `P3PHase<m>:HARMonics:STANDARD` is set to ENC and `P3PHase<m>:HARMonics:PFACTOR:MODE` is set to USER.

Sets a user-defined power factor.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<UsrPowFact> Range: 0 to 100
 Increment: 1
 *RST: 100
 Default unit: %

Usage: Asynchronous command

Manual operation: See "Power factor" on page 418

P3PHase<m>:HARMonics:RPOWER:MODE <ActPowMd>

Available if `P3PHase<m>:HARMonics:STANDARD` is set to END.

Selects if the power factor is defined automatically, or a user-defined value is used (`P3PHase<m>:HARMonics:RPOWER:USER`).

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<ActPowMd> AUTO | USER
 *RST: AUTO

Usage: Asynchronous command

Manual operation: See "Real power, Power" on page 419

P3PHase<m>:HARMonics:RPOWER:USER <UsrActPow>

Available if **P3PHase<m>:HARMonics:STANdard** is set to **END** and **P3PHase<m>:HARMonics:RPOWER:USER** is set to **USER**.

Sets a user-defined real power value.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<UsrActPow> Range: 0 to 10000
 Increment: 1
 *RST: 100
 Default unit: W

Usage: Asynchronous command

Manual operation: See "Real power, Power" on page 419

3-phase bar graph

P3PHase<m>:HARMonics:DISPlay:BARGraph[:ENABLE]	1293
P3PHase<m>:HARMonics:DISPlay:HARMonics[:DISPlay]	1294
P3PHase<m>:HARMonics:DISPlay:BARGraph:VERTical:SCALE:TYPE	1294
P3PHase<m>:HARMonics:DISPlay:HARMonics:START[:VALue]	1294
P3PHase<m>:HARMonics:DISPlay:HARMonics:STOP[:VALue]	1294

P3PHase<m>:HARMonics:DISPlay:BARGraph[:ENABLE] <State>

Displays or hides the bar graph.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<State> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See "State" on page 420

P3Phase<m>:HARMonics:DISPlay:HARMonics[:DISPlay] <DispedHarmonics>

Selects which harmonics are displayed in the bar graph: all, odd even or depending on the standard definition.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<DispedHarmonics> ALL | EVEN | ODD | STANdard

*RST: STANdard

Usage: Asynchronous command

Manual operation: See ["Displ. harmonics"](#) on page 420

P3Phase<m>:HARMonics:DISPlay:BARGraph:VERTical:SCALe:TYPE <Scaling>

Selects a logarithmic or linear scale for the display for the harmonics bar graph.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Scaling> LIN | LOG

*RST: LIN

Usage: Asynchronous command

Manual operation: See ["Scale type"](#) on page 420

P3Phase<m>:HARMonics:DISPlay:HARMonics:START[:VALue] <BarGraphStart>

Sets the first harmonic to be shown in the bar graph.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<BarGraphStart> Range: 1 to 37

Increment: 1

*RST: 1

Usage: Asynchronous command

Manual operation: See ["Start harmonic"](#) on page 420

P3Phase<m>:HARMonics:DISPlay:HARMonics:STOP[:VALue] <BarGraphStop>

Sets the last harmonic to be shown in the bar graph.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<BarGraphStop> Range: 3 to 40
 Increment: 1
 *RST: 40

Usage: Asynchronous command

Manual operation: See "Max harmonic" on page 420

3-phase power harmonics results

P3PHase<m>:HARMonics:AVailable<n>.....	1295
P3PHase<m>:HARMonics:MEASurement:CSOource:FREQuency<n>[:ACTual]?.....	1295
P3PHase<m>:HARMonics:MEASurement:POWEr<n>:ACTive[:ACTual]?.....	1296
P3PHase<m>:HARMonics:MEASurement:THDFundament<n>[:ACTual]?.....	1296
P3PHase<m>:HARMonics:MEASurement:THDRms<n>[:ACTual]?.....	1296
P3PHase<m>:HARMonics:RESult<n>:VIOLation<o>?.....	1296
P3PHase<m>:HARMonics:RESult<n>[:FREQuency]?.....	1297
P3PHase<m>:HARMonics:RESult<n>:MAGNitude<o>:PERCent[:ACTual]?.....	1297
P3PHase<m>:HARMonics:RESult<n>:MAGNitude<o>:RMS[:ACTual]?.....	1297

P3PHase<m>:HARMonics:AVailable<n>

Returns the number of measured harmonics for the individual phases.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <n> 1...3, index of the individual phase

Return values:

<Count>

Usage: Asynchronous command

P3PHase<m>:HARMonics:MEASurement:CSOource:FREQuency<n>[:ACTual]?

Returns the cycle source frequency of each channel for the 3-phase power harmonics analysis.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <n> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<Actual> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0

Usage: Query only
 Asynchronous command

P3PHase<m>:HARMonics:MEASurement:POWer<n>:ACTive[:ACTual]?

Returns the active power for the individual phases.. Only available, if [P3PHase<m>:HARMonics:STANdard](#) is set to ENC / END.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Usage:

Query only
Asynchronous command

P3PHase<m>:HARMonics:MEASurement:THDFundament<n>[:ACTual]?

Returns the total harmonic distortion relative to fundamental (THDF) for the individual phases.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Usage:

Query only
Asynchronous command

P3PHase<m>:HARMonics:MEASurement:THDRms<n>[:ACTual]?

Returns the total harmonic distortion relative to the RMS amplitude (THD RMS) for the individual phases.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Usage:

Query only
Asynchronous command

P3PHase<m>:HARMonics:RESult<n>:VIOLation<o>?

Queries if the value of o-th harmonic is within the defined limit for the current measurement for the individual phases.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

<o> 1...n, index of the harmonics

Return values:

<Harmonic>

Usage: Query only
Asynchronous command

P3PHase<m>:HARMonics:RESult<n>[:FREQuency]?

Returns the frequency of the n-th harmonic.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...n, index of the harmonics

Return values:

<Harmonic>

Usage: Query only
Asynchronous command

P3PHase<m>:HARMonics:RESult<n>:MAGNitude<o>:PERCent[:ACTual]?

Returns the magnitude of the o-th harmonic in percent for the individual phases.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

<o> 1...n, index of the harmonics

Return values:

<Harmonic>

Usage: Query only
Asynchronous command

P3PHase<m>:HARMonics:RESult<n>:MAGNitude<o>:RMS[:ACTual]?

Returns the magnitude of the o-th harmonic as RMS for the individual phases.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

<o> 1...n, index of the harmonics

Return values:

<Harmonic>

Usage: Query only
Asynchronous command

18.17.4.4 3-phase power sources

P3PHase<m>:QUALity:SOURce:WIRing.....	1298
P3PHase<m>:HARMonics:SOURce:WIRing.....	1298
P3PHase<m>:QUALity:SOURce:INOut.....	1298
P3PHase<m>:HARMonics:SOURce:INOut.....	1298
P3PHase<m>:QUALity:SOURce:LINes:W2V2a.....	1299
P3PHase<m>:HARMonics:SOURce:LINes:W2V2a.....	1299
P3PHase<m>:QUALity:SOURce:CURREnt:W2V2a.....	1299
P3PHase<m>:QUALity:SOURce:CURREnt:W3V3a.....	1299
P3PHase<m>:QUALity:SOURce:CURREnt:W3VN3a.....	1299
P3PHase<m>:HARMonics:SOURce:CURREnt:W2V2a.....	1299
P3PHase<m>:HARMonics:SOURce:CURREnt:W3V3a.....	1299
P3PHase<m>:HARMonics:SOURce:CURREnt:W3VN3a.....	1299
P3PHase<m>:QUALity:SOURce:VOLTage:W2V2a.....	1299
P3PHase<m>:QUALity:SOURce:VOLTage:W3V3a.....	1299
P3PHase<m>:QUALity:SOURce:VOLTage:W3VN3a.....	1299
P3PHase<m>:HARMonics:SOURce:VOLTage:W2V2a.....	1299
P3PHase<m>:HARMonics:SOURce:VOLTage:W3V3a.....	1300
P3PHase<m>:HARMonics:SOURce:VOLTage:W3VN3a.....	1300
P3PHase<m>:QUALity:SOURce:CYCLe.....	1300
P3PHase<m>:HARMonics:SOURce:CYCLe.....	1300
P3PHase<m>:QUALity:GATE.....	1300

P3PHase<m>:QUALity:SOURce:WIRing <Wiring>

P3PHase<m>:HARMonics:SOURce:WIRing <Wiring>

Configures how your probes are connected to the three-phase device. It allows you to visualize the connections for proper setup. If you can only measure on four channels, select the "W2V2A" wiring.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Wiring> W2V2A | W3V3A | W3VN3A
*RST: W3VN3A

Usage: Asynchronous command

Manual operation: See "[Wiring](#)" on page 423

P3PHase<m>:QUALity:SOURce:INOut <InputOutput>

P3PHase<m>:HARMonics:SOURce:INOut <InputOutput>

Configures whether the oscilloscope is configured to receive signals (input) for analysis, or to generate signals output) as a source for testing.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<InputOutput> INPut | OUTPut
 *RST: INPut

Usage: Asynchronous command

Manual operation: See ["Input/output"](#) on page 424

P3PHase<m>:QUALity:SOURce:LINEs:W2V2a <Lines>

P3PHase<m>:HARMonics:SOURce:LINEs:W2V2a <LineType>

Select the configuration for your probe setup.

Selects the gate that is used for limiting the range of the 3-phase power quality measurement.

This setting is only necessary, if you have configured [P3PHase<m>:HARMonics:SOURce:WIRing](#) =W2V2A.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<LineType> V12LV32L | V13LV23L | V21LV31L

Usage: Asynchronous command

Manual operation: See ["Select lines"](#) on page 424

P3PHase<m>:QUALity:SOURce:CURREnt:W2V2a <Sources>

P3PHase<m>:QUALity:SOURce:CURREnt:W3V3a <Sources>

P3PHase<m>:QUALity:SOURce:CURREnt:W3VN3a <Sources>

P3PHase<m>:HARMonics:SOURce:CURREnt:W2V2a <Sources>

P3PHase<m>:HARMonics:SOURce:CURREnt:W3V3a <Sources>

P3PHase<m>:HARMonics:SOURce:CURREnt:W3VN3a <Sources>

Selects the current source waveform. Analog channels and math waveforms can be used.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Sources> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Usage: Asynchronous command

Manual operation: See ["Current"](#) on page 425

P3PHase<m>:QUALity:SOURce:VOLTage:W2V2a <Sources>

P3PHase<m>:QUALity:SOURce:VOLTage:W3V3a <Sources>

P3PHase<m>:QUALity:SOURce:VOLTage:W3VN3a <Sources>

P3PHase<m>:HARMonics:SOURce:VOLTage:W2V2a <Sources>

P3PHase<m>:HARMonics:SOURce:VOLTage:W3V3a <Sources>

P3PHase<m>:HARMonics:SOURce:VOLTage:W3VN3a <Sources>

Selects the voltage source waveform. Analog channels and math waveforms can be used.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Sources> C1 | C2 | ... | C8 | M1 | M2 | ... | M8

Usage: Asynchronous command

Manual operation: See "[Voltage](#)" on page 425

P3PHase<m>:QUALity:SOURce:CYCLE <CycleSource>

P3PHase<m>:HARMonics:SOURce:CYCLE <CycleSource>

Selects the channel (voltage source) to serve as the timing reference for data calculations across all sources when the periods are not aligned on the x-axis.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<CycleSource> C1 | C2 | ... | C8

Usage: Asynchronous command

Manual operation: See "[Source](#)" on page 426

P3PHase<m>:QUALity:GATE <Gate>

Selects the gate that is used for limiting the range of the 3-phase power quality measurement.

Enable the gate before you assign a measurement to it ([GATE<g>:ENABLE](#) =ON).

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<Gate> Number of the gate to be used

Usage: Asynchronous command

18.17.4.5 3-phase power waveform

[P3PHase<m>:QUALity:DISPlay:POWer<n>:WAVEform\[:ENABLE\]](#)..... 1301

[P3PHase<m>:HARMonics:DISPlay:POWer<n>:WAVEform\[:ENABLE\]](#)..... 1301

[P3PHase<m>:QUALity:DISPlay:TOTal:POWer:WAVEform\[:ENABLE\]](#)..... 1301

[P3PHase<m>:HARMonics:DISPlay:TOTal:POWer:WAVEform\[:ENABLE\]](#)..... 1301

[P3PHase<m>:QUALity:POWer<n>:VERTical:OFFSet](#)..... 1301

[P3PHase<m>:HARMonics:POWer<n>:VERTical:OFFSet](#)..... 1301

P3PHase<m>:QUALity:TOTal:POWer:VERTical:OFFSet.....	1302
P3PHase<m>:HARMonics:TOTal:POWer:VERTical:OFFSet.....	1302
P3PHase<m>:QUALity:POWer<n>:VERTical:SCALE:MODE.....	1302
P3PHase<m>:HARMonics:POWer<n>:VERTical:SCALE:MODE.....	1302
P3PHase<m>:QUALity:TOTal:POWer:VERTical:SCALE:MODE.....	1302
P3PHase<m>:HARMonics:TOTal:POWer:VERTical:SCALE:MODE.....	1302
P3PHase<m>:QUALity:POWer<n>:VERTical:SCALE[:VALue].....	1303
P3PHase<m>:HARMonics:POWer<n>:VERTical:SCALE[:VALue].....	1303
P3PHase<m>:QUALity:TOTal:POWer:VERTical:SCALE[:VALue].....	1303
P3PHase<m>:HARMonics:TOTal:POWer:VERTical:SCALE[:VALue].....	1303

P3PHase<m>:QUALity:DISPlay:POWer<n>:WAVEform[:ENABLE] <State>
P3PHase<m>:HARMonics:DISPlay:POWer<n>:WAVEform[:ENABLE] <State>

Displays or hides the specified power waveform.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Parameters:

<State> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Display individual phases"](#) on page 427

P3PHase<m>:QUALity:DISPlay:TOTal:POWer:WAVEform[:ENABLE] <State>
P3PHase<m>:HARMonics:DISPlay:TOTal:POWer:WAVEform[:ENABLE] <State>

Displays or hides the total power waveform.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<State> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Display"](#) on page 427

P3PHase<m>:QUALity:POWer<n>:VERTical:OFFSet <VerticalOffset>
P3PHase<m>:HARMonics:POWer<n>:VERTical:OFFSet <VerticalOffset>

Sets the vertical offset of the specified power waveform if the relevant
P3PHase<m>:*:POWer:VERTical:SCALE:MODE command is set to MANual.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Parameters:

<VerticalOffset> Range: -1000000000000000 to 1000000000000000
 Increment: 0.01
 *RST: 0
 Default unit: div

Usage: Asynchronous command

P3PHase<m>:QUALity:TOTal:POWer:VERTical:OFFSet <VerticalOffset>

P3PHase<m>:HARMonics:TOTal:POWer:VERTical:OFFSet <VerticalOffset>

Sets the vertical offset of the total power waveform if the relevant

P3PHase<m>:*:POWer:VERTical:SCALe:MODE command is set to MANual.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<VerticalOffset> Range: -1000000000000000 to 1000000000000000
 Increment: 0.01
 *RST: 0
 Default unit: div

Usage: Asynchronous command

Manual operation: See ["Offset"](#) on page 427

P3PHase<m>:QUALity:POWer<n>:VERTical:SCALe:MODE <VertScIMd>

P3PHase<m>:HARMonics:POWer<n>:VERTical:SCALe:MODE <VertScIMd>

Selects the scaling mode for display of the specific power waveform.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Parameters:

<VertScIMd> MANual | AUTO
 *RST: AUTO

Usage: Asynchronous command

Manual operation: See ["Mode"](#) on page 427

P3PHase<m>:QUALity:TOTal:POWer:VERTical:SCALe:MODE <VertScIMd>

P3PHase<m>:HARMonics:TOTal:POWer:VERTical:SCALe:MODE <VertScIMd>

Selects the scaling mode for display of the total power waveform.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<VertSclMd> MANual | AUTO
 *RST: AUTO

Usage: Asynchronous command

Manual operation: See ["Mode"](#) on page 428

P3PHase<m>:QUALity:POWer<n>:VERTical:SCALe[:VALue] <VerticalScale>

P3PHase<m>:HARMonics:POWer<n>:VERTical:SCALe[:VALue] <VerticalScale>

Sets the vertical scale of the specific power waveform if the relevant

P3PHase<m>: *:POWer:VERTical:SCALe:MODE command is set to MANual.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Parameters:

<VerticalScale> Range: 1E-12 to 1000000000000000
 Increment: 1E-05
 *RST: 0.5
 Default unit: VA

Usage: Asynchronous command

Manual operation: See ["Scale"](#) on page 427

P3PHase<m>:QUALity:TOTal:POWer:VERTical:SCALe[:VALue] <VerticalScale>

P3PHase<m>:HARMonics:TOTal:POWer:VERTical:SCALe[:VALue]

<VerticalScale>

Sets the vertical scale of the total power waveform if the relevant

P3PHase<m>: *:POWer:VERTical:SCALe:MODE command is set to MANual.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Parameters:

<VerticalScale> Range: 1E-12 to 1000000000000000
 Increment: 1E-05
 *RST: 0.5
 Default unit: V

Usage: Asynchronous command

Manual operation: See ["Scale"](#) on page 428

18.17.4.6 3-phase reference level

[P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:HYSTeresis](#)..... 1304

[P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:HYSTeresis](#)..... 1304

[P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:LLEVel](#)..... 1304

P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:LLEVel.....	1304
P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:MLEVel.....	1305
P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:MLEVel.....	1305
P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:ULEVel.....	1305
P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:ULEVel.....	1305
P3PHase<m>:QUALity:REFLevel<rl>:LMODE.....	1305
P3PHase<m>:HARMonics:REFLevel<rl>:LMODE.....	1305
P3PHase<m>:QUALity:REFLevel<rl>:RELative:HYSTeresis.....	1306
P3PHase<m>:HARMonics:REFLevel<rl>:RELative:HYSTeresis.....	1306
P3PHase<m>:QUALity:REFLevel<rl>:RELative:LOWer.....	1306
P3PHase<m>:HARMonics:REFLevel<rl>:RELative:LOWer.....	1306
P3PHase<m>:QUALity:REFLevel<rl>:RELative:MIDDLE.....	1307
P3PHase<m>:HARMonics:REFLevel<rl>:RELative:MIDDLE.....	1307
P3PHase<m>:QUALity:REFLevel<rl>:RELative:MODE.....	1307
P3PHase<m>:HARMonics:REFLevel<rl>:RELative:MODE.....	1307
P3PHase<m>:QUALity:REFLevel<rl>:RELative:UPPer.....	1308
P3PHase<m>:HARMonics:REFLevel<rl>:RELative:UPPer.....	1308

P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:HYSTeresis <HystAbs>

P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:HYSTeresis <HystAbs>

Defines a hysteresis for the middle reference level. A rise or fall from the middle reference value that does not exceed the hysteresis is rejected as noise.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <rl> Irrelevant, omit the suffix.

Parameters:

<HystAbs> Range: 0 to 1E+26
 Increment: 0.001
 *RST: 0.005
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Hysteresis](#)" on page 405

P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:LLEVel <LowerLevel>

P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:LLEVel <LowerLevel>

Sets the lower reference level in absolute values. This is required, e.g., to determine a fall.

Suffix:

<m> 1 to 6, index of the power analysis measurement
 <rl> Irrelevant, omit the suffix.

Parameters:

<LowerLevel> Range: -1E+26 to 1E+26
 Increment: 0.001
 *RST: 0
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Upper level](#), [Middle level](#), [Lower level](#)" on page 403

P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:MLEVel <MiddleLevel>

P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:MLEVel <MiddleLevel>

Sets the middle reference level in absolute values.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<rl> Irrelevant, omit the suffix.

Parameters:

<MiddleLevel> Range: -1E+26 to 1E+26
 Increment: 0.001
 *RST: 0
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Upper level](#), [Middle level](#), [Lower level](#)" on page 403

P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:ULEVel <UpperLevel>

P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:ULEVel <UpperLevel>

Sets the upper reference level in absolute values. This is required to determine a rise.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<rl> Irrelevant, omit the suffix.

Parameters:

<UpperLevel> Range: -1E+26 to 1E+26
 Increment: 0.001
 *RST: 0
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Upper level](#), [Middle level](#), [Lower level](#)" on page 403

P3PHase<m>:QUALity:REFLevel<rl>:LMODe <LevelMode>

P3PHase<m>:HARMonics:REFLevel<rl>:LMODe <LevelMode>

Defines if the reference level is set in absolute or relative values.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<rl> Irrelevant, omit the suffix.

Parameters:

<LevelMode> ABS | REL

*RST: REL

Usage: Asynchronous command

Manual operation: See "[Level mode](#)" on page 403

P3PHase<m>:QUALity:REFLevel<rl>:RELative:HYSTeresis <HystRel>

P3PHase<m>:HARMonics:REFLevel<rl>:RELative:HYSTeresis <HystRel>

Defines a hysteresis for the middle reference level. A rise or fall from the middle reference value that does not exceed the hysteresis is rejected as noise.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<rl> Irrelevant, omit the suffix.

Parameters:

<HystRel> Range: 0 to 50

Increment: 1

*RST: 10

Default unit: %

Usage: Asynchronous command

Manual operation: See "[Hysteresis](#)" on page 405

P3PHase<m>:QUALity:REFLevel<rl>:RELative:LOWer <LowRefLevRel>

P3PHase<m>:HARMonics:REFLevel<rl>:RELative:LOWer <LowRefLevRel>

Sets the lower relative reference level if [P3PHase<m>:HARMonics:REFLevel<rl>:RELative:MODE](#) is set to USER.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<rl> Irrelevant, omit the suffix.

Parameters:

<LowRefLevRel> Range: -100 to 200

Increment: 1

*RST: 10

Default unit: %

Usage: Asynchronous command

Manual operation: See "[Upper level, Middle level, Lower level](#)" on page 404

P3PHase<m>:QUALity:REFLevel<rl>:RELative:MIDDLE <MidRefLevRel>
P3PHase<m>:HARMonics:REFLevel<rl>:RELative:MIDDLE <MidRefLevRel>

Sets the middle relative reference level if **P3PHase<m>:HARMonics:REFLevel<rl>:RELative:MODE** is set to **USER**.

Suffix:

<m> 1 to 6, index of the power analysis measurement
<rl> Irrelevant, omit the suffix.

Parameters:

<MidRefLevRel> Range: -100 to 200
Increment: 1
*RST: 50
Default unit: %

Usage: Asynchronous command

Manual operation: See "[Upper level, Middle level, Lower level](#)" on page 404

P3PHase<m>:QUALity:REFLevel<rl>:RELative:MODE <RelativeLevels>
P3PHase<m>:HARMonics:REFLevel<rl>:RELative:MODE <RelativeLevels>

The lower, middle and upper reference levels, defined as percentages of the high signal level.

Suffix:

<m> 1 to 6, index of the power analysis measurement
<rl> Irrelevant, omit the suffix.

Parameters:

<RelativeLevels> FIVE | TEN | TWENTy | USER

FIVE

5/50/95

TEN

10/50/90

TWENTy

20/50/80

USER

Set the reference levels to individual values with **P3PHase<m>:HARMonics:REFLevel<rl>:RELative:LOWer**, **P3PHase<m>:HARMonics:REFLevel<rl>:RELative:MIDDLE**, and **P3PHase<m>:HARMonics:REFLevel<rl>:RELative:UPPer**.

*RST: TEN

Usage: Asynchronous command

Manual operation: See "[Relative levels](#)" on page 404

P3PHase<m>:QUALity:REFLevel<rl>:RELative:UPPer <UppRefLevRel>

P3PHase<m>:HARMonics:REFLevel<rl>:RELative:UPPer <UppRefLevRel>

Sets the upper relative reference level if **P3PHase<m>:HARMonics:REFLevel<rl>:RELative:MODE** is set to **USER**.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<rl> Irrelevant, omit the suffix.

Parameters:

<UppRefLevRel> Range: -100 to 200
Increment: 1
*RST: 90
Default unit: %

Usage: Asynchronous command

Manual operation: See "Upper level, Middle level, Lower level" on page 404

18.17.4.7 3-phase power analysis data

This section describes the commands for exporting 3-phase power analysis measurement data.

P3PHase<m>:QUALity:POWer<n>:DATA:HEADer?	1308
P3PHase<m>:HARMonics:POWer<n>:DATA:HEADer?	1308
P3PHase<m>:QUALity:TOTal:POWer:DATA:HEADer?	1309
P3PHase<m>:HARMonics:TOTal:POWer:DATA:HEADer?	1309
P3PHase<m>:QUALity:POWer<n>:DATA[:VALues]?	1309
P3PHase<m>:HARMonics:POWer<n>:DATA[:VALues]?	1309
P3PHase<m>:QUALity:TOTal:POWer:DATA[:VALues]?	1310
P3PHase<m>:HARMonics:TOTal:POWer:DATA[:VALues]?	1310

P3PHase<m>:QUALity:POWer<n>:DATA:HEADer?

P3PHase<m>:HARMonics:POWer<n>:DATA:HEADer?

Returns the header of the 3-phase power analysis waveform data for the individual phases. The header contains the attributes of the waveform.

For power harmonics measurements, data is only available if **P3PHase<m>:HARMonics:STANdard** is set to **ENC** or **END**.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Return values:

<XStart> 1. header value: start time in s

<XStop> 2. header value: end time in s

<RecordLength> 3. header value: record length of the waveform in samples

<ValsPerSmp> 4. header value: number of values per sample. For 3-phase power quality measurements, the value is 1.

Usage: Query only
Asynchronous command

P3PHase<m>:QUALity:TOTal:POWer:DATA:HEADer?

P3PHase<m>:HARMonics:TOTal:POWer:DATA:HEADer?

Returns the header of the 3-phase power analysis waveform data for the total phase. The header contains the attributes of the waveform.

For power harmonics measurements, data is only available if **P3PHase<m>:HARMonics:STANdard** is set to ENC or END.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Return values:

<XStart> 1. header value: start time in s
<XStop> 2. header value: end time in s
<RecordLength> 3. header value: record length of the waveform in samples
<ValsPerSmp> 4. header value: number of values per sample. For 3-phase power quality measurements, the value is 1.

Usage: Query only
Asynchronous command

P3PHase<m>:QUALity:POWer<n>:DATA[:VALues]? [<Offset>],[<Length>]

P3PHase<m>:HARMonics:POWer<n>:DATA[:VALues]? [<Offset>],[<Length>]

Returns the individual phase data of the 3-phase power analysis waveform points for transmission from the instrument to the controlling computer.

Without parameters, the complete waveform is retrieved. Using the offset and length parameters, data can be retrieved in smaller portions, which makes the command faster. If you send only one parameter, it is interpreted as offset, and the data is retrieved from offset to the end of the waveform.

To set the export format, use **FORMat [:DATA]**.

Suffix:

<m> 1 to 6, index of the power analysis measurement

<n> 1...3, index of the individual phase

Query parameters:

<Offset> Number of offset waveform points to be skipped.
<Length> Number of waveform points to be retrieved.

Usage: Query only
Asynchronous command

P3PHase<m>:QUALity:TOTal:POWer:DATA[:VALues]? [<Offset>],[<Length>]

P3PHase<m>:HARMonics:TOTal:POWer:DATA[:VALues]? [<Offset>],[<Length>]

Returns the total phase data of the 3-phase power analysis waveform points for transmission from the instrument to the controlling computer.

Without parameters, the complete waveform is retrieved. Using the offset and length parameters, data can be retrieved in smaller portions, which makes the command faster. If you send only one parameter, it is interpreted as offset, and the data is retrieved from offset to the end of the waveform.

To set the export format, use **FORMat [:DATA]**.

Suffix:

<m> 1 to 6, index of the power analysis measurement

Query parameters:

<Offset> Number of offset waveform points to be skipped.

<Length> Number of waveform points to be retrieved.

Usage:

Query only

Asynchronous command

18.17.5 Digital voltmeter

This section describes the commands for setting up and querying the results of the digital voltmeter.

METer:BANDwidth	1310
METer:DVMeter<m>:ENABle?	1311
METer:DVMeter<m>:ACRMs:ENABle	1311
METer:DVMeter<m>:ACRMs:RESult?	1311
METer:DVMeter<m>:DC:ENABle	1312
METer:DVMeter<m>:DC:RESult?	1312
METer:DVMeter<m>:DCRMs:ENABle	1312
METer:DVMeter<m>:DCRMs:RESult?	1313
METer:MTIMe	1313

METer:BANDwidth <Bandwidth>

Sets the filter bandwidth.

Parameters:

<Bandwidth> B20M | B10M | B5M | B2M | B1M | B500 | B200

B20M: 20 MHz

B10M: 10 MHz

B5M: 5 MHz

B2M: 2 MHz

B1M: 1 MHz

B500: 500 kHz

B200: 200 kHz

*RST: B20M

Usage: Asynchronous command

Manual operation: See ["Filter bandwidth"](#) on page 430

METer:DVMeter<m>:ENABle?

Queries the state of the voltmeter for the respective channel.

Suffix:

<m> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<State> OFF | ON

*RST: OFF

Usage: Query only
Asynchronous command

METer:DVMeter<m>:ACRMs:ENABle <ACRMSResults_St>

Enables the AC RMS voltmeter measurement for the respective channel.

Suffix:

<m> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<ACRMSResults_St> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Measurements"](#) on page 430

METer:DVMeter<m>:ACRMs:RESult?

Returns the result of the AC RMS voltmeter measurement.

Suffix:

<m> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<Results_ACRMS> Range: -1E+26 to 1E+26
Increment: 0.1
*RST: 0
Default unit: V

Usage: Query only
Asynchronous command

Manual operation: See ["Measurements"](#) on page 430

METer:DVMeter<m>:DC:ENABLE <DCResults_St>

Enables the DC voltmeter measurement for the respective channel.

Suffix:

<m> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<DCResults_St> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Measurements"](#) on page 430

METer:DVMeter<m>:DC:RESult?

Returns the result of the DC voltmeter measurement.

Suffix:

<m> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<Results_DC> Range: -1E+26 to 1E+26
Increment: 0.1
*RST: 0
Default unit: V

Usage: Query only
Asynchronous command

Manual operation: See ["Measurements"](#) on page 430

METer:DVMeter<m>:DCRMs:ENABLE <DCRMSResults_St>

Enables the DC RMS voltmeter measurement for the respective channel.

Suffix:

<m> 1 to 8, depending on instrument model. Index of the analog channel.

Parameters:

<DCRMSResults_St> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Measurements"](#) on page 430

METer:DVMeter<m>:DCRMs:RESult?

Returns the result of the DC RMS voltmeter measurement.

Suffix:

<m> 1 to 8, depending on instrument model. Index of the analog channel.

Return values:

<Results_DCRMS> Range: -1E+26 to 1E+26
Increment: 0.1
*RST: 0
Default unit: V

Usage:

Query only
Asynchronous command

Manual operation: See ["Measurements"](#) on page 430

METer:MTIME <MeasTime>

Sets the measurement time. The time begins in the moment that a measurement is enabled.

Parameters:

<MeasTime> Range: 0.05 to 1
Increment: 0.05
*RST: 0.5
Default unit: s

Usage:

Asynchronous command

Manual operation: See ["Measurement time"](#) on page 430

18.17.6 XY-plot

XY<m>:SWAP	1313
XY<m>[:STATe]	1314
XY<m>:YSource	1314
XY<m>:XSource	1314

XY<m>:SWAP

Replaces the source of the x-axis with the source of the y-axis and vice versa.

Suffix:

<m> 1 to 4, index of the XY-plot

Usage:

Setting only
Asynchronous command

Manual operation: See ["Swap XY"](#) on page 432

XY<m>[:STATe] <State>

Activates an XY-waveform.

Suffix:

<m> 1 to 4, index of the XY-plot

Parameters:

<State> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See "Display" on page 431

XY<m>:YSource <YSource>

Defines the signal source that supplies the y-values of the XY-diagram.

Suffix:

<m> 1 to 4, index of the XY-plot

Parameters:

<YSource> NONE | C1 | C2 | ... | C8 | M1 | M2 | ... | M8 | R1 | R2 | ... | R8 |
TRK1 | TRK2 | TRK3 | ... | TRK24 | O<n>C1 | O<n>C2 | ... |
O<n>C8 (<n> = 2 to 11)

Usage: Asynchronous command

Manual operation: See "X-source, Y-source" on page 432

XY<m>:XSource <XSource>

Defines the signal source that supplies the x-values of the XY-diagram.

Suffix:

<m> 1 to 4, index of the XY-plot

Parameters:

<XSource> NONE | C1 | C2 | ... | C8 | M1 | M2 | ... | M8 | R1 | R2 | ... | R8 |
TRK1 | TRK2 | TRK3 | ... | TRK24 | O<n>C1 | O<n>C2 | ... |
O<n>C8 (<n> = 2 to 11)

Usage: Asynchronous command

Manual operation: See "X-source, Y-source" on page 432

18.17.7 Eye analysis (option R&S MXO5C-K136)

EYE<e>:DISPlay:PERsistence:INFinite.....	1315
EYE<e>:DISPlay:PERsistence:RESet.....	1315
EYE<e>:DISPlay:PERsistence:STATe.....	1315
EYE<e>:DISPlay:PERsistence:TIME.....	1316
EYE<e>:HORizontal:ABSolute:POSition.....	1316

EYE<e>:HORizontal:ABSolute:RANGe.....	1316
EYE<e>:HORizontal:UINterval:POSition.....	1317
EYE<e>:HORizontal:UINterval:RANGe.....	1317
EYE<e>:HORizontal:UNIT.....	1317
EYE<e>:MSLices.....	1318
EYE<e>:QUALify:GATE.....	1318
EYE<e>:RFLSet.....	1318
EYE<e>:SAMTime.....	1319
EYE<e>:SOURce.....	1319
EYE<e>:STATe.....	1319
EYE<e>:TREFerence.....	1319
EYE<e>:VERTical:COUPle.....	1320
EYE<e>:VERTical:OFFSet.....	1320
EYE<e>:VERTical:POSition.....	1320
EYE<e>:VERTical:SCALe.....	1321

EYE<e>:DISPlay:PERSistence:INFinite <InfPersist>

If infinite persistence is ON, each new waveform point remains on the screen until this option is disabled, or the display is reset.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<InfPersist> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Infinite persistence"](#) on page 436

EYE<e>:DISPlay:PERSistence:RESet

Resets the display, removing all waveform points.

Suffix:

<e> 1 to 8, index of the eye

Usage:

Setting only
Asynchronous command

Manual operation: See ["Reset"](#) on page 436

EYE<e>:DISPlay:PERSistence:STATe <State>

If ON, each new data point in the diagram area remains on the screen for the duration that is defined using [EYE<e>:DISPlay:PERSistence:TIME](#), or as long as [EYE<e>:DISPlay:PERSistence:INFinite](#) is ON.

If OFF, the waveform points are displayed only for the current acquisition.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<State> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Enable"](#) on page 436

EYE<e>:DISPlay:PERSistence:TIME <Time>

Sets the time how long the eye points remain on the display.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<Time> Range: 0.05 to 50
Increment: 0.05
*RST: 0.05
Default unit: s

Usage: Asynchronous command

Manual operation: See ["Time"](#) on page 436

EYE<e>:HORizontal:ABSolute:POSition <HorizPosition>

Defines the position of the zero point in the diagram in seconds. The zero point is the alignment point on which the slice timestamps are superimposed.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<HorizPosition> Range: -100 to 100
Increment: 1E-09
*RST: 0
Default unit: s

Usage: Asynchronous command

Manual operation: See ["Position"](#) on page 435

EYE<e>:HORizontal:ABSolute:RANGe <HorizRange>

Sets the time range that is covered by the eye diagram in absolute time values.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<HorizRange> Range: 1E-10 to 100
 Increment: 1E-09
 *RST: 2E-09
 Default unit: s

Usage: Asynchronous command

Manual operation: See "[Range](#)" on page 435

EYE<e>:HORizontal:UINterval:POSition <HorizPosition>

Defines the position of the zero point in the diagram in unit intervals. The zero point is the alignment point on which the slice timestamps are superimposed.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<HorizPosition> Range: -1000 to 1000
 Increment: 0.001
 *RST: 0
 Default unit: UI

Usage: Asynchronous command

Manual operation: See "[Position](#)" on page 435

EYE<e>:HORizontal:UINterval:RANGe <HorizRange>

Sets the time range that is covered by the eye diagram in unit intervals.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<HorizRange> Range: 0.001 to 1000
 Increment: 0.001
 *RST: 2
 Default unit: UI

Usage: Asynchronous command

Manual operation: See "[Range](#)" on page 435

EYE<e>:HORizontal:UNIT <HorizontalUnit>

Sets the method to define the horizontal scale of the eye diagram: as absolute time, or in unit intervals.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<HorizontalUnit> ATIMe | UI | UINterval
 UI = UINterval
 *RST: UI

Usage: Asynchronous command

Manual operation: See ["Time units"](#) on page 434

EYE<e>:MSLices <MaxSliceCount>

Sets the number of waveform slices for a single acquisition.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<MaxSliceCount> Range: 1 to 2500000
 Increment: 1
 *RST: 2000

Usage: Asynchronous command

Manual operation: See ["Slices per acquisition"](#) on page 434

EYE<e>:QUALify:GATE <Gate>

Selects the gate, which restricts the contributing slices in horizontal direction. Only the timestamps within the defined horizontal interval qualify for eye generation.

Enable and configure a gate before you assign it ([GATE<g>:ENABLE](#) =ON). The query returns 0, if no gate is assigned.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<Gate> Number of the gate to be used

Usage: Asynchronous command

Manual operation: See ["Gate"](#) on page 436

EYE<e>:RFLSet <RefLevelSet><RefLevelSet>

Selects the reference level set that defines the timestamps for slicing the data waveform. Define the reference level set before you use it.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<RefLevelSet> Number of the reference level set

Usage: Asynchronous command

Manual operation: See ["Reference levels"](#) on page 433

EYE<e>:SAMTime <SamplingTime>

Sets a sampling time for the clock signal, an offset for the clock edge in relation to the bit start.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<SamplingTime> Range: 0 to 1
Increment: 0.0001
*RST: 0.5
Default unit: UI

Usage: Asynchronous command

Manual operation: See ["Sampling time"](#) on page 434

EYE<e>:SOURce <Source>

Selects the waveform from which the eye diagram is generated.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<Source> C1 | C2 | ... | C8 | M1 | M2 | ... | M8 | R1 | R2 | ... | R8

Usage: Asynchronous command

Manual operation: See ["Source"](#) on page 433

EYE<e>:STATe <State>

Activates or deactivates the eye diagram.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<State> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Enable"](#) on page 433

EYE<e>:TREFerence <TimingReference>

Selects the timing reference, which defines the reference signal and the method that are used to obtain the timing information required to slice the data source waveform.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<TimingReference> Range: 1 to 4

Usage: Asynchronous command

Manual operation: See ["Timing reference"](#) on page 434

EYE<e>:VERTical:COUPle <VertCoupling>

If ON, the vertical position and scale of the source are used.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<VertCoupling> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Couple to source"](#) on page 435

EYE<e>:VERTical:OFFSet <VerticalOffset>

Defines the vertical offset in divisions if [EYE<e>:VERTical:COUPle](#) is OFF. If coupling is ON, the query returns the coupled value.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<VerticalOffset> Range: -1000000000000000 to 1000000000000000

Increment: 0.01

*RST: 0

Default unit: div

Usage: Asynchronous command

Manual operation: See ["Vertical offset"](#) on page 435

EYE<e>:VERTical:POSition <VertPosition>

Defines the vertical position in divisions if [EYE<e>:VERTical:COUPle](#) is OFF. If coupling is ON, the query returns the coupled value.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<VertPosition> Range: -1E+26 to 1E+26
 Increment: 0.02
 *RST: 0
 Default unit: div

Usage: Asynchronous command

Manual operation: See "[Vertical position](#)" on page 435

EYE<e>:VERTical:SCALE <VerticalScale>

Defines the vertical scale in Volts per division if [EYE<e>:VERTical:COUPle](#) is OFF. If coupling is ON, the query returns the coupled value.

Suffix:

<e> 1 to 8, index of the eye

Parameters:

<VerticalScale> Range: 1E-12 to 1000000000000000
 Increment: 1E-05
 *RST: 0.5
 Default unit: V

Usage: Asynchronous command

Manual operation: See "[Vertical scale](#)" on page 435

18.18 Protocols

• Configuration settings for all serial protocols	1322
• SPI (option R&S MXO5C-K510)	1327
• QUAD-SPI (option R&S MXO5C-K510)	1352
• I²C (option R&S MXO5C-K510)	1384
• I3C (option R&S MXO5C-K550)	1410
• UART / RS-232 (option R&S MXO5C- K510)	1434
• NRZ Clocked (option R&S MXO5C-K510)	1456
• NRZ Unclocked (option R&S MXO5C-K510)	1484
• Manchester (option R&S MXO5C-K510)	1510
• CAN (option R&S MXO5C-K520)	1538
• LIN (option R&S MXO5C-K520)	1577
• SENT (option R&S MXO5C-K520)	1601
• ARINC 429 (option R&S MXO5C-K530)	1627
• MIL-1553 (option R&S MXO5C-K530)	1645
• SpaceWire (option R&S MXO5C-K530)	1663
• SPMI (option R&S MXO5C-K550)	1681
• RFFE (option R&S MXO5C-K550)	1703
• 10BASE-T1S (option R&S MXO5C-K560)	1726
• 100BASE-T1 (option R&S MXO5C-K560)	1748

- 1000BASE-T1 (option R&S MXO5C-K560)..... 1770
- USB 1.1 (option R&S MXO5C-K570)..... 1792
- USB 2.0 (option R&S MXO5C-K570)..... 1814

18.18.1 Configuration settings for all serial protocols

18.18.1.1 General settings

SBUS<sb>[:STATe].....	1322
SBUS<sb>:TYPE.....	1322
SBUS<sb>:FORMat.....	1323
SBUS<sb>:RESult.....	1324
SBUS<sb>:RMSBus.....	1324
SBUS<sb>:THReshold.....	1325
SBUS<sb>:ZCOupling.....	1325

SBUS<sb>[:STATe] <ProtocolState>

Enables the decoding of the specified bus.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ProtocolState> OFF | ON

Usage:

Asynchronous command

Manual operation: See ["State"](#) on page 478

SBUS<sb>:TYPE <Protocol Type>

Selects the bus type for analysis. The type of buses available depends on the installed options.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Protocol Type> I2C | I3C | SPI | QSPI | UART | CAN | LIN | SENT | TNOS | MILS1553 | MILStd | ARIN429 | ARINc429 | SWIR | SWIRe | RFFE | SPMI | MANC | NRZC | NRZU | USB1 | USB2 | USBHspeed | USBLow | USBFull | HBTO | TBTO

SPI: SPI protocol, see [Section 18.18.2, "SPI \(option R&S MXO5C-K510\)"](#), on page 1327.

QSPI: Quad SPI protocol, see [Section 18.18.3, "QUAD-SPI \(option R&S MXO5C-K510\)"](#), on page 1352.

I2C: I²C protocol, see [Section 18.18.4, "I²C \(option R&S MXO5C-K510\)"](#), on page 1384.

I3C: I3C protocol, see [Section 18.18.5, "I3C \(option R&S MXO5C-K550\)"](#), on page 1410.

UART: UART protocol, see [Section 18.18.6, "UART / RS-232 \(option R&S MXO5C-K510\)"](#), on page 1434.

NRZC: NRZ clocked protocol, see [Section 18.18.7, "NRZ Clocked \(option R&S MXO5C-K510\)"](#), on page 1456.

NRZU: NRZ unclocked protocol, see [Section 18.18.8, "NRZ Unclocked \(option R&S MXO5C-K510\)"](#), on page 1484.

MANC: Manchester protocol, see [Section 18.18.9, "Manchester \(option R&S MXO5C-K510\)"](#), on page 1510.

CAN: CAN protocol, see [Section 18.18.10, "CAN \(option R&S MXO5C-K520\)"](#), on page 1538.

LIN: LIN protocol, see [Section 18.18.11, "LIN \(option R&S MXO5C-K520\)"](#), on page 1577.

SENT: SENT protocol, see [Section 18.18.12, "SENT \(option R&S MXO5C-K520\)"](#), on page 1601.

ARIN429 | ARINC429: ARINC 429 protocol, see [Section 18.18.13, "ARINC 429 \(option R&S MXO5C-K530\)"](#), on page 1627.

MILS1553 | MILStd: MIL-1553 protocol, see [Section 18.18.14, "MIL-1553 \(option R&S MXO5C-K530\)"](#), on page 1645.

SWIR | SWIRE: SpaceWire protocol, see [Section 18.18.15, "SpaceWire \(option R&S MXO5C-K530\)"](#), on page 1663.

SPMI: SPMI protocol, see [Section 18.18.16, "SPMI \(option R&S MXO5C-K550\)"](#), on page 1681.

RFFE: RFFE protocol, see [Section 18.18.17, "RFFE \(option R&S MXO5C-K550\)"](#), on page 1703.

TNOS: Ethernet 10BASE-T1S protocol, see [Section 18.18.18, "10BASE-T1S \(option R&S MXO5C-K560\)"](#), on page 1726.

HBTO: Ethernet 100BASE-T1 protocol, see [Section 18.18.19, "100BASE-T1 \(option R&S MXO5C-K560\)"](#), on page 1748.

TBTO: Ethernet 1000BASE-T1 protocol, see [Section 18.18.20, "1000BASE-T1 \(option R&S MXO5C-K560\)"](#), on page 1770.

USB1 | USBLow | USBFull: USB 1.1 protocol, see [Section 18.18.21, "USB 1.1 \(option R&S MXO5C-K570\)"](#), on page 1792.

USB2 | USBHspeed: USB 2.0 protocol, see [Section 18.18.22, "USB 2.0 \(option R&S MXO5C-K570\)"](#), on page 1814.

Usage: Asynchronous command

Manual operation: See ["Protocol type"](#) on page 478

SBUS<sb>:FORMat <DataFormat>

Sets the number format for decoded data values of the indicated serial bus. It defines the format in the decode table, and in the combs of the decoded signal on the screen.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DataFormat> HEX | OCT | BIN | ASCII | ASCii | SIGN | USIG

HEX

Hexadecimal

OCT

Octal

BIN

Binary

ASCII = ASCii

American standard code for information interchange

SIGN

Signed, e.g. 8 bits signed ranges from -128 to +127 decimal

USIG

Unsigned, e.g. 8 bits unsigned ranges from 0 to 255 decimal

*RST: HEX

Usage:

Asynchronous command

Manual operation: See ["Data format"](#) on page 481

SBUS<sb>:RESult <ShwResTbl>

Enables a table with decoded data of the serial signal. The function requires the option for the analyzed protocol.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ShwResTbl> OFF | ON

*RST: OFF

Usage:

Asynchronous command

Manual operation: See ["Show decode table"](#) on page 481

SBUS<sb>:RMSBus

Deletes the specified serial bus.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Add serial bus"](#), ["Delete serial bus"](#) on page 478

SBUS<sb>:THReshold <ShwThresLines>

If enabled, the threshold lines are displayed in the diagram.

The label of the threshold line is set according to the signal that it is referring to, see also [Show threshold lines](#).

Suffix:

<sb> 1..4

Parameters:

<ShwThresLines> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See "[Show threshold lines](#)" on page 479

SBUS<sb>:ZCOupling <ZoomCoupling>

If enabled, the protocol decode zoom and result table are synchronized.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ZoomCoupling> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See "[Zoom coupling](#)" on page 482

18.18.1.2 Export results settings

SBUS<sb>:EXPResult:DETail	1325
SBUS<sb>:EXPResult:SAVE	1326
SBUS<sb>:EXPResult:TIME	1326
SBUS<sb>:EXPResult:EXTension	1326
SBUS<sb>:EXPResult:PATH	1327

SBUS<sb>:EXPResult:DETail <IncludeDetails>

If enabled, includes the detailed results for all frames in the export result file.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<IncludeDetails> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See "[Include details](#)" on page 490

SBUS<sb>:EXPResult:SAVE <FileName>

Saves the selected results to the indicated file.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName>

Example:

```
SBUS1:EXPResult:SAVE
'/home/storage/userData/export_10base-t1s.csv'
```

Usage:

Setting only
Asynchronous command

Manual operation: See ["Save as"](#) on page 491

SBUS<sb>:EXPResult:TIME <IncludeTiming>

If enabled, includes the frame timing in the export result file.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<IncludeTiming> OFF | ON
*RST: ON

Usage:

Asynchronous command

Manual operation: See ["Include timing"](#) on page 490

SBUS<sb>:EXPResult:EXTension <FileType>

Selects the file format.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<FileType> HTML | CSV | XML | PY
HTML
Hypertext markup language
CSV
Comma-separated values
XML
Extensible markup language
PY
Python
*RST: HTML

Usage:

Asynchronous command

Manual operation: See ["File type"](#) on page 490

SBUS<sb>:EXPResult:PATH <Path>

Sets the path where the protocol export files are stored. On the instrument, the default path is `/home/storage/userData/Protocol`. You can create subfolders in this folder.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Path> String parameter

Usage:

Asynchronous command

Manual operation: See ["Save as"](#) on page 491

18.18.2 SPI (option R&S MXO5C-K510)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with `SBUS<sb>[:STATe]`.
- The bus is set to the correct type with `SBUS<sb>:TYPE`.

• Configuration	1327
• Filter	1334
• Hardware trigger	1340
• Software trigger	1341
• Decode results	1347

18.18.2.1 Configuration

SBUS<sb>:SPI:BORDer	1328
SBUS<sb>:SPI:FRCondition	1328
SBUS<sb>:SPI:CSElect:HYSteresis	1328
SBUS<sb>:SPI:CSElect:POLarity	1329
SBUS<sb>:SPI:CSElect:SOURce	1329
SBUS<sb>:SPI:CSElect:THReshold	1329
SBUS<sb>:SPI:MISO:HYSteresis	1330
SBUS<sb>:SPI:MISO:POLarity	1330
SBUS<sb>:SPI:MISO:SOURce	1330
SBUS<sb>:SPI:MISO:THReshold	1330
SBUS<sb>:SPI:MOSI:HYSteresis	1331
SBUS<sb>:SPI:MOSI:POLarity	1331
SBUS<sb>:SPI:MOSI:SOURce	1331
SBUS<sb>:SPI:MOSI:THReshold	1332
SBUS<sb>:SPI:SCLK:HYSteresis	1332
SBUS<sb>:SPI:SCLK:SOURce	1332
SBUS<sb>:SPI:SCLK:THReshold	1332

SBUS<sb>:SPI:TIMEout.....	1333
SBUS<sb>:SPI:WSize.....	1333
SBUS<sb>:SPI:MISO:POStion.....	1333
SBUS<sb>:SPI:MISO:SCALE.....	1333
SBUS<sb>:SPI:MOSI:POStion.....	1334
SBUS<sb>:SPI:MOSI:SCALE.....	1334

SBUS<sb>:SPI:BORDER <BitOrder>

Selects the bit order, which determines if the data of the messages starts with MSB (most significant bit) or LSB (least significant bit).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<BitOrder> LSBF | MSBF
*RST: MSBF

Usage: Asynchronous command

Manual operation: See "Bit order" on page 495

SBUS<sb>:SPI:FRCondition <FrameCondition>

Defines the start of a frame. A frame contains a number of successive words, at least one word.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<FrameCondition> CS | CLKTimeout

CS

Start and end of the frame is defined by the active state of the sub select signal, see [SBUS<sb>:SPI:CSElect:POLarity](#).

CLKTimeout

Defines a timeout on the clock line SCLK as limiter between two frames. The timeout condition is used for SPI connections without a CS line.

*RST: CS

Usage: Asynchronous command

SBUS<sb>:SPI:CSElect:HYSteresis <Hysteresis>

Sets a value for the hysteresis for the CS channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage:

Asynchronous command

Manual operation:See ["Threshold"](#) on page 496**SBUS<sb>:SPI:CSElect:POLarity <CSPolarity>**

Selects if the transmitted signal for the respective line is active high (high = 1) or active low (low = 1).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<CSPolarity>

ACTLow | ACTHigh

*RST: ACTLow

Usage:

Asynchronous command

Manual operation:See ["Polarity: MOSI, MISO, CS"](#) on page 495**SBUS<sb>:SPI:CSElect:SOURce <CSSource>**

Sets the input channel of the CS line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<CSSource>

C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
 | D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
 | M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
 R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage:

Asynchronous command

Manual operation:See ["SCLK,MOSI,MISO,CS"](#) on page 494**SBUS<sb>:SPI:CSElect:THReshold <Threshold>**

Sets a user-defined threshold value for the line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold>

Usage:

Asynchronous command

Manual operation:See ["Threshold"](#) on page 496

SBUS<sb>:SPI:MISO:HYSTeresis <Hysteresis>

Sets a value for the hysteresis for the MISO channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 496

SBUS<sb>:SPI:MISO:POLarity <MISOPolarity>

Selects if the transmitted signal for the respective line is active high (high = 1) or active low (low = 1).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MISOPolarity> ACTLow | ACTHigh
*RST: ACTHigh

Usage: Asynchronous command

Manual operation: See ["Polarity: MOSI, MISO, CS"](#) on page 495

SBUS<sb>:SPI:MISO:SOURce <MISOSource>

Sets the input channel of the MISO line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MISOSource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["SCLK,MOSI,MISO,CS"](#) on page 494

SBUS<sb>:SPI:MISO:THReshold <Threshold>

Sets a user-defined threshold value for the line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold>

Usage:

Asynchronous command

Manual operation:See ["Threshold"](#) on page 496**SBUS<sb>:SPI:MOSI:HYSTeresis <Hysteresis>**

Sets a value for the hysteresis for the MOSI channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage:

Asynchronous command

Manual operation:See ["Threshold"](#) on page 496**SBUS<sb>:SPI:MOSI:POLarity <MOSIPolarity>**

Selects if the transmitted signal for the respective line is active high (high = 1) or active low (low = 1).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MOSIPolarity>

ACTLow | ACTHigh

*RST: ACTHigh

Usage:

Asynchronous command

Manual operation:See ["Polarity: MOSI, MISO, CS"](#) on page 495**SBUS<sb>:SPI:MOSI:SOURce <MOSISource>**

Sets the input channel of the MOSI line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MOSISource>

C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)**Usage:**

Asynchronous command

Manual operation:See ["SCLK,MOSI,MISO,CS"](#) on page 494

SBUS<sb>:SPI:MOSI:THReshold <Threshold>

Sets a user-defined threshold value for the line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 496

SBUS<sb>:SPI:SCLK:HYSTeresis <Hysteresis>

Sets a value for the hysteresis for the SCLK channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 496

SBUS<sb>:SPI:SCLK:SOURce <SCLKSource>

Sets the input channel of the SCLK line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SCLKSource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["SCLK,MOSI,MISO,CS"](#) on page 494

SBUS<sb>:SPI:SCLK:THReshold <Threshold>

Sets a user-defined threshold value for the line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 496

SBUS<sb>:SPI:TIMEout <ClockTimeout>

Sets the minimum clock idle time if a timeout on the clock line SCLK is used as limiter between two frames.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ClockTimeout> Range: 5E-08 to 10
Increment: 1E-06
*RST: 0.001
Default unit: s

Usage: Asynchronous command

Manual operation: See ["Timeout"](#) on page 495

SBUS<sb>:SPI:WSize <WordLength>

Sets the word length (or symbol size), which is the number of bits in a message. The maximum word length is 32 bit.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<WordLength> Range: 4 to 32
Increment: 1
*RST: 8

Usage: Asynchronous command

Manual operation: See ["Word length"](#) on page 495

SBUS<sb>:SPI:MISO:POSition <SPI MISO position>

Sets the vertical position of the MISO signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SPI MISO position>

Usage: Asynchronous command

SBUS<sb>:SPI:MISO:SCALE <SPI MISO scale>

Set the vertical scale of the MISO signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SPI MISO scale>

Usage:

Asynchronous command

SBUS<sb>:SPI:MOSI:POSition <SPI MISO position>

Sets the vertical position of the MOSI signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SPI MISO position>

Usage:

Asynchronous command

SBUS<sb>:SPI:MOSI:SCALe <SPI MOSI scale>

Set the vertical scale of the MOSI signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SPI MOSI scale>

Usage:

Asynchronous command

18.18.2.2 Filter

There are two commands for each parameter, that you can use for defining the SPI settings.

For example, to set the *Frame type =MISO > Field =MISO >01100* value you can use one of the following commands:

- `SBUS:SPI:FILTer:FRAMe1:FLD1:DMIN 01100`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `SBUS:SPI:FILTer:DMIN "MISO", "MISO", 01100`
Defines the parameter by using the frame and field name.

<code>SBUS<sb>:SPI:FILTer:CHKall</code>	1335
<code>SBUS<sb>:SPI:FILTer:CLR</code>	1335
<code>SBUS<sb>:SPI:FILTer:INVert</code>	1335
<code>SBUS<sb>:SPI:FILTer:RST</code>	1336
<code>SBUS<sb>:SPI:FILTer:BIT</code>	1336
<code>SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:BIT</code>	1336
<code>SBUS<sb>:SPI:FILTer:DMAX</code>	1336
<code>SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:DMAX</code>	1336

SBUS<sb>:SPI:FILTer:DMIN.....	1337
SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1337
SBUS<sb>:SPI:FILTer:DOPerator.....	1337
SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1337
SBUS<sb>:SPI:FILTer:ERENable.....	1337
SBUS<sb>:SPI:FILTer:ERRor<n>:ENABle.....	1337
SBUS<sb>:SPI:FILTer:FIENable.....	1338
SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1338
SBUS<sb>:SPI:FILTer:FRENable.....	1338
SBUS<sb>:SPI:FILTer:FRAMe<fr>:ENABle.....	1338
SBUS<sb>:SPI:FILTer:IMAX.....	1338
SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1338
SBUS<sb>:SPI:FILTer:IMIN.....	1339
SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1339
SBUS<sb>:SPI:FILTer:IOPerator.....	1339
SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1339

SBUS<sb>:SPI:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 497

SBUS<sb>:SPI:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 497

SBUS<sb>:SPI:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 497

SBUS<sb>:SPI:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 497

SBUS<sb>:SPI:FILTer:BIT <Frame>,<Field>,<Bit>**SBUS<sb>:SPI:FILTer:BIT? <Bit>****SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:BIT <BitState>**

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO
*RST: ZERO

Usage:

Asynchronous command

Manual operation: See ["Edit"](#) on page 498

SBUS<sb>:SPI:FILTer:DMAX <Frame>,<Field>,<Data>**SBUS<sb>:SPI:FILTer:DMAX? <Data>****SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>**

Sets the end value of a data pattern range if the operator is set to `INRange` or `OORANGE`.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage:

Asynchronous command

Manual operation: See ["Edit"](#) on page 498

SBUS<sb>:SPI:FILTER:DMIN <Frame>,<Field>,<Data>

SBUS<sb>:SPI:FILTER:DMIN? <Data>

SBUS<sb>:SPI:FILTER:FRAME<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 498

SBUS<sb>:SPI:FILTER:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:SPI:FILTER:DOPerator? <Operator>

SBUS<sb>:SPI:FILTER:FRAME<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange

*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 498

SBUS<sb>:SPI:FILTER:ERENable <ErrorName>,<Enabler>

SBUS<sb>:SPI:FILTER:ERENable? <Enabler>

SBUS<sb>:SPI:FILTER:ERRor<n>:ENABLE <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command
Manual operation: See ["Error type"](#) on page 499

SBUS<sb>:SPI:FILTER:FIENable <Frame>,<Field>,<Enabler>
SBUS<sb>:SPI:FILTER:FIENable? <Enabler>
SBUS<sb>:SPI:FILTER:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:
 <CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command
Manual operation: See ["Edit"](#) on page 498

SBUS<sb>:SPI:FILTER:FRENable <Frame>,<Enabler>
SBUS<sb>:SPI:FILTER:FRENable? <Enabler>
SBUS<sb>:SPI:FILTER:FRAME<fr>:ENABLE <Enable>

Enables or disables the checking condition for the selected frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Parameters:
 <Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command
Manual operation: See ["Frame type"](#) on page 498

SBUS<sb>:SPI:FILTER:IMAX <Frame>,<Field>,<Data>
SBUS<sb>:SPI:FILTER:IMAX? <Data>
SBUS<sb>:SPI:FILTER:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range if the operator is set to INRange.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 498

SBUS<sb>:SPI:FILTer:IMIN <Frame>,<Field>,<Data>

SBUS<sb>:SPI:FILTer:IMIN? <Data>

SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 498

SBUS<sb>:SPI:FILTer:IOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:SPI:FILTer:IOPerator? <Operator>

SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 498

18.18.2.3 Hardware trigger

Trigger commands for serial buses affect the current trigger source. Therefore, set the trigger source to the required serial bus with `TRIGger:EVENT<ev>:SOURCE` before sending the bus-specific trigger commands.

<code>TRIGger:SBHW:SPI:TYPE</code>	1340
<code>TRIGger:SBHW:SPI:PALignment</code>	1340
<code>TRIGger:SBHW:SPI:FCONdition</code>	1341
<code>TRIGger:SBHW:SPI:DPOsition</code>	1341
<code>TRIGger:SBHW:SPI:DMINpattern</code>	1341

TRIGger:SBHW:SPI:TYPE <Type>

Selects the trigger type for SPI analysis.

Parameters:

<Type> FRSTart | FREnd | MOSI | MISO

FRSTart

Triggers on the beginning of the frame.

FREnd

Triggers on the end of the frame.

MOSI

Triggers on a specified data pattern in that is expected on the MOSI line.

MISO

Triggers on a specified data pattern in that is expected on the MISO line.

*RST: FRSTart

Usage: Asynchronous command

Manual operation: See "[Type](#)" on page 500

TRIGger:SBHW:SPI:PALignment <DataAlignment>

Defines how the specified data pattern is searched.

Parameters:

<DataAlignment> WORD | BIT

WORD

The pattern is matched only at word boundaries.

BIT

Bit-by-bit: the pattern can start at any position in the message.

*RST: WORD

Usage: Asynchronous command

Manual operation: See "[Search mode](#)" on page 501

TRIGger:SBHW:SPI:FCONdition <DataOperator>

Selects the operator for the MISO and MOSI pattern.

Parameters:

<DataOperator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan
 *RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Data"](#) on page 501

TRIGger:SBHW:SPI:DPOStion <DataPosition>

Sets the number of bits or words to be ignored before the first bit or word of interest.
 The effect is defined by [TRIGger:SBHW:SPI:PALignment](#).

Parameters:

<DataPosition> Range: 1 to 4096
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Position"](#) on page 501

TRIGger:SBHW:SPI:DMINpattern <DataPattern>

Specifies a data bit pattern, or sets the start value of a pattern range.

Parameters:

<DataPattern>

Usage: Asynchronous command

Manual operation: See ["Data"](#) on page 501

18.18.2.4 Software trigger

There are two commands for each parameter, that you can use for defining the SPI settings.

For example, to set the *Frame type =MISO > Field =MISO >01100* value you can use one of the following commands:

- `TRIGger:SBSW:SPI:FRAME1:FLD1:DMIN 01100`
 Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `TRIGger:SBSW:SPI:DMIN "MISO", "MISO", 01100`
 Defines the parameter by using the frame and field name.

[TRIGger:SBSW:SPI:CHKall](#)..... 1342
[TRIGger:SBSW:SPI:CLR](#)..... 1342
[TRIGger:SBSW:SPI:INVert](#)..... 1342

TRIGger:SBSW:SPI:RST.....	1343
TRIGger:SBSW:SPI:FREnable.....	1343
TRIGger:SBSW:SPI:FRAME<fr>:ENABLE.....	1343
TRIGger:SBSW:SPI:BIT.....	1343
TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:BIT.....	1343
TRIGger:SBSW:SPI:DMAX.....	1343
TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:DMAX.....	1343
TRIGger:SBSW:SPI:DMIN.....	1344
TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:DMIN.....	1344
TRIGger:SBSW:SPI:DOPerator.....	1344
TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:DOPerator.....	1344
TRIGger:SBSW:SPI:FIENable.....	1345
TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:ENABLE.....	1345
TRIGger:SBSW:SPI:IMAX.....	1345
TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:IMAX.....	1345
TRIGger:SBSW:SPI:IMIN.....	1345
TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:IMIN.....	1345
TRIGger:SBSW:SPI:IOperator.....	1346
TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:IOperator.....	1346
TRIGger:SBSW:SPI:ERENable.....	1346
TRIGger:SBSW:SPI:ERRor<m>:ENABLE.....	1346
SBUS<sb>:SPI:SWTindex?.....	1346
SBUS<sb>:SPI:SWTTime?.....	1347

TRIGger:SBSW:SPI:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 502

TRIGger:SBSW:SPI:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 502

TRIGger:SBSW:SPI:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 502

TRIGger:SBSW:SPI:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 502

TRIGger:SBSW:SPI:FREnable <Frame>,<Enabler>**TRIGger:SBSW:SPI:FREnable? <Enabler>****TRIGger:SBSW:SPI:FRAME<fr>:ENABLE <Enable>**

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:
 <fr> Index of the frame

Parameters:
 <Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 503

TRIGger:SBSW:SPI:BIT <Frame>,<Field>,<Bit>**TRIGger:SBSW:SPI:BIT? <Bit>****TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:BIT <BitState>**

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:
 <fr> Index of the frame
 <fl> Index of the field

Parameters:
 <BitState> ONE | ZERO
 *RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 503

TRIGger:SBSW:SPI:DMAX <Frame>,<Field>,<Data>**TRIGger:SBSW:SPI:DMAX? <Data>****TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:DMAX <Data_Max>**

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGE.

You can set the operator with `TRIGger:SBSW:SPI:FRAMe<fr>:FLD<fl>:DOPerator`.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See "Edit" on page 503

TRIGger:SBSW:SPI:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:SPI:DMIN? <Data>

TRIGger:SBSW:SPI:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See "Edit" on page 503

TRIGger:SBSW:SPI:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:SPI:DOPerator? <Operator>

TRIGger:SBSW:SPI:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange
*RST: EQUal

Usage: Asynchronous command

Manual operation: See "Edit" on page 503

TRIGger:SBSW:SPI:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:SPI:FIENable? <Enabler>

TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:ENable <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 503

TRIGger:SBSW:SPI:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:SPI:IMAX? <Data>

TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with [TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:IOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535

Increment: 1

*RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 503

TRIGger:SBSW:SPI:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:SPI:IMIN? <Data>

TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 503

TRIGger:SBSW:SPI:IOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:SPI:IOPerator? <Operator>

TRIGger:SBSW:SPI:FRAMe<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 503

TRIGger:SBSW:SPI:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:SPI:ERENable? <Enabler>

TRIGger:SBSW:SPI:ERRor<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> Index of the error

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 504

SBUS<sb>:SPI:SWTindex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns `Invalid`.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

SBUS<sb>:SPI:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

18.18.2.5 Decode results

SBUS<sb>:SPI:FCOunt?	1347
SBUS<sb>:SPI:FRAMe<fr>:BITRate?	1348
SBUS<sb>:SPI:FRAMe<fr>:DATA?	1348
SBUS<sb>:SPI:FRAMe<fr>:STARt?	1348
SBUS<sb>:SPI:FRAMe<fr>:STATus?	1349
SBUS<sb>:SPI:FRAMe<fr>:STOP?	1349
SBUS<sb>:SPI:FRAMe<fr>:WCOunt?	1349
SBUS<sb>:SPI:FRAMe<fr>:WORD<w>:FMISo?	1350
SBUS<sb>:SPI:FRAMe<fr>:WORD<w>:FMOSi?	1350
SBUS<sb>:SPI:FRAMe<fr>:WORD<w>:MISO?	1350
SBUS<sb>:SPI:FRAMe<fr>:WORD<w>:MOSI?	1351
SBUS<sb>:SPI:FRAMe<fr>:WORD<w>:STARt?	1351
SBUS<sb>:SPI:FRAMe<fr>:WORD<w>:STOP?	1351

SBUS<sb>:SPI:FCOunt?

Returns the number of decoded frames.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count>

Usage: Query only
Asynchronous command

SBUS<sb>:SPI:FRAME<fr>:BITRate?

Returns the bit rate of the specified frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <PrimaryBitRate> Increment: 1
 *RST: 0
 Default unit: bps

Usage: Query only
Asynchronous command

SBUS<sb>:SPI:FRAME<fr>:DATA?

Returns the data words of the specified frame in comma-separated values.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <FrameData> Comma-separated sequence of integer values (N, L1, R1,..., LN, RN). N is the number of word pairs in the frame, and {L1,R1} ...{LN,RN} are the value pairs. The values Lx and Rx are associated with the MOSI and the MISO channel, respectively. If a channel is disabled, an empty value is returned.

Usage: Query only
Asynchronous command

SBUS<sb>:SPI:FRAME<fr>:START?

Returns the start time of the specified frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <FrameStart> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:SPI:FRAME<fr>:STATus?

Returns the overall state of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameState> OK | VOID | INComplete | LENGth

OK: the frame is valid.

VOID: the frame is empty.

INComplete: INComplete word. The word is cut off at the left or right side of the acquisition.

LENGth: The frame that was found has an unexpected length: there are either too few or too many bits in this frame.

*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:SPI:FRAME<fr>:STOP?

Returns the end time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26

Increment: 1E-10

*RST: 0

Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:SPI:FRAME<fr>:WCOunt?

Returns the number of words in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameWordCount> Range: 0 to 65535
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

SBUS<sb>:SPI:FRAME<fr>:WORD<w>:FMISo?

Returns the formatted value of the specified word on the MISO line.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <w> Index of the word

Return values:

<FormattedMISOVal>

Usage:

Query only
 Asynchronous command

SBUS<sb>:SPI:FRAME<fr>:WORD<w>:FMOSi?

Returns the formatted value of the specified word on the MOSI line.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <w> Index of the word

Return values:

<FormattedMOSIVal>

Usage:

Query only
 Asynchronous command

SBUS<sb>:SPI:FRAME<fr>:WORD<w>:MISO?

Returns the data value of the specified word on the MISO line.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <w> Index of the word

Return values:

<MISOValue> Range: 0 to 4294967295
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

SBUS<sb>:SPI:FRAME<fr>:WORD<w>:MOSI?

Returns the data value of the specified word on the MOSI line.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <w> Index of the word

Return values:

<MOSIValue> Range: 0 to 4294967295
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

SBUS<sb>:SPI:FRAME<fr>:WORD<w>:START?

Returns the start time of the specified data word.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <w> Index of the word

Return values:

<FrameWordStart> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

SBUS<sb>:SPI:FRAME<fr>:WORD<w>:STOP?

Returns the end time of the specified data word.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

<w> Index of the word

Return values:

<FrameWordStop> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage: Query only
 Asynchronous command

18.18.3 QUAD-SPI (option R&S MXO5C-K510)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with `SBUS<sb>[:STATe]`.
- The bus is set to the correct type with `SBUS<sb>:TYPE`.

• Configuration	1352
• Opcode	1362
• Filter	1367
• Software trigger	1372
• Decode results	1378

18.18.3.1 Configuration

SBUS<sb>:QSPi:CSEL:HYSteresis	1353
SBUS<sb>:QSPi:CSEL:POLarity	1353
SBUS<sb>:QSPi:CSEL:SOURce	1353
SBUS<sb>:QSPi:CSEL:THReshold	1354
SBUS<sb>:QSPi:INSTruction	1354
SBUS<sb>:QSPi:IOONe:HYSteresis	1354
SBUS<sb>:QSPi:IOONe:POLarity	1354
SBUS<sb>:QSPi:IOONe:POSition	1355
SBUS<sb>:QSPi:IOONe:SCALE	1355
SBUS<sb>:QSPi:IOONe:SOURce	1355
SBUS<sb>:QSPi:IOONe:THReshold	1355
SBUS<sb>:QSPi:IOThree:HYSteresis	1356
SBUS<sb>:QSPi:IOThree:POLarity	1356
SBUS<sb>:QSPi:IOThree:POSition	1356
SBUS<sb>:QSPi:IOThree:SCALE	1357
SBUS<sb>:QSPi:IOThree:SOURce	1357
SBUS<sb>:QSPi:IOThree:THReshold	1357
SBUS<sb>:QSPi:IOTwo:HYSteresis	1357
SBUS<sb>:QSPi:IOTwo:POLarity	1358
SBUS<sb>:QSPi:IOTwo:POSition	1358
SBUS<sb>:QSPi:IOTwo:SCALE	1358
SBUS<sb>:QSPi:IOTwo:SOURce	1358
SBUS<sb>:QSPi:IOTwo:THReshold	1359
SBUS<sb>:QSPi:IOZero:HYSteresis	1359

SBUS<sb>:QSPI:IOZero:POLarity.....	1359
SBUS<sb>:QSPI:IOZero:POSition.....	1360
SBUS<sb>:QSPI:IOZero:SCALe.....	1360
SBUS<sb>:QSPI:IOZero:SOURce.....	1360
SBUS<sb>:QSPI:IOZero:THReshold.....	1360
SBUS<sb>:QSPI:SCLK:HYSTeresis.....	1361
SBUS<sb>:QSPI:SCLK:POLarity.....	1361
SBUS<sb>:QSPI:SCLK:SOURce.....	1361
SBUS<sb>:QSPI:SCLK:THReshold.....	1361

SBUS<sb>:QSPI:CSEL:HYSTeresis <Hysteresis>

Sets a value for the hysteresis for the CS channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage:

Asynchronous command

Manual operation: See "[CS/SCLK/IO hysteresis](#)" on page 513

SBUS<sb>:QSPI:CSEL:POLarity <CSPolarity>

Selects if the transmitted signal for the respective line is active high (high = 1) or active low (low = 1).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<CSPolarity> ACTLow | ACTHigh
*RST: ACTLow

Usage:

Asynchronous command

Manual operation: See "[Polarity: CS, IOx](#)" on page 512

SBUS<sb>:QSPI:CSEL:SOURce <CSSource>

Sets the input channel of the CS line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<CSSource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage:

Asynchronous command

Manual operation: See ["CS, SCLK, IO n"](#) on page 511

SBUS<sb>:QSPI:CSEL:THReshold <Threshold>

Sets a user-defined threshold value for the line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold>

Usage:

Asynchronous command

Manual operation: See ["CS/SCLK/IO threshold"](#) on page 513

SBUS<sb>:QSPI:INSTruction <Instruction>

Selects the instruction mode that defines how many lanes are used to transmit data.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Instruction> SINGLE | DUAL | QUAD

*RST: SINGLE

Usage:

Asynchronous command

Manual operation: See ["Instruction"](#) on page 512

SBUS<sb>:QSPI:IOONe:HYSTeresis <Hysteresis>

Sets a value for the hysteresis for the IO1 line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage:

Asynchronous command

Manual operation: See ["CS/SCLK/IO hysteresis"](#) on page 513

SBUS<sb>:QSPI:IOONe:POLarity <IO1Polarity>

Selects if the transmitted signal for the respective line is active high (high = 1) or active low (low = 1).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<IO1Polarity> ACTLow | ACTHigh
 *RST: ACTHigh

Usage: Asynchronous command

Manual operation: See "Polarity: CS, IOx" on page 512

SBUS<sb>:QSPI:IOONe:POSition <QUADSPI IO1 position>

Sets the vertical position of the IO1 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<QUADSPI IO1
 position>

Usage: Asynchronous command

SBUS<sb>:QSPI:IOONe:SCALE <QUADSPI IO1 scale>

Set the vertical scale of the IO1 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<QUADSPI IO1
 scale>

Usage: Asynchronous command

SBUS<sb>:QSPI:IOONe:SOURce <IO1Source>

Sets the input channel of the IO 1 line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<IO1Source> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
 | D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
 | M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
 R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See "CS, SCLK, IO n" on page 511

SBUS<sb>:QSPI:IOONe:THReshold <Threshold>

Sets a user-defined threshold value for the line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold>

Usage:

Asynchronous command

Manual operation: See "[CS/SCLK/IO threshold](#)" on page 513

SBUS<sb>:QSPI:IOTHree:HYSTeresis <Hysteresis>

Sets a value for the hysteresis for the IO0 line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage:

Asynchronous command

Manual operation: See "[CS/SCLK/IO hysteresis](#)" on page 513

SBUS<sb>:QSPI:IOTHree:POLarity <IO3Polarity>

Selects if the transmitted signal for the respective line is active high (high = 1) or active low (low = 1).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<IO3Polarity> ACTLow | ACTHigh

*RST: ACTHigh

Usage:

Asynchronous command

Manual operation: See "[Polarity: CS, IOx](#)" on page 512

SBUS<sb>:QSPI:IOTHree:POSition <QUADSPI IO3 position>

Sets the vertical position of the IO3 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<QUADSPI IO3
position>

Usage:

Asynchronous command

SBUS<sb>:QSPI:IOTHree:SCALe <QUADSPI IO3 scale>

Set the vertical scale of the IO3 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<QUADSPI IO3
scale>

Usage: Asynchronous command

SBUS<sb>:QSPI:IOTHree:SOURce <IO3Source>

Sets the input channel of the IO 3 line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<IO3Source> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See "[CS, SCLK, IO n](#)" on page 511

SBUS<sb>:QSPI:IOTHree:THReshold <Threshold>

Sets a user-defined threshold value for the line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold>

Usage: Asynchronous command

Manual operation: See "[CS/SCLK/IO threshold](#)" on page 513

SBUS<sb>:QSPI:IOTWo:HYSTeresis <Hysteresis>

Sets a value for the hysteresis for the IO2 line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage: Asynchronous command

Manual operation: See ["CS/SCLK/IO hysteresis"](#) on page 513

SBUS<sb>:QSPI:IOTWo:POLarity <IO2Polarity>

Selects if the transmitted signal for the respective line is active high (high = 1) or active low (low = 1).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<IO2Polarity> ACTLow | ACTHigh
*RST: ACTHigh

Usage: Asynchronous command

Manual operation: See ["Polarity: CS, IOx"](#) on page 512

SBUS<sb>:QSPI:IOTWo:POSition <QUADSPI IO2 position>

Sets the vertical position of the IO2 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<QUADSPI IO2 position>

Usage: Asynchronous command

SBUS<sb>:QSPI:IOTWo:SCALE <QUADSPI IO2 scale>

Set the vertical scale of the IO2 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<QUADSPI IO2 scale>

Usage: Asynchronous command

SBUS<sb>:QSPI:IOTWo:SOURce <IO2Source>

Sets the input channel of the IO 2 line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<IO2Source> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["CS, SCLK, IO n"](#) on page 511

SBUS<sb>:QSPI:IOTwo:THReshold <Threshold>

Sets a value for the hysteresis for the IO2 line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold>

Usage: Asynchronous command

Manual operation: See ["CS/SCLK/IO threshold"](#) on page 513

SBUS<sb>:QSPI:IOZero:HYSTeresis <Hysteresis>

Sets a value for the hysteresis for the IO0 line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage: Asynchronous command

Manual operation: See ["CS/SCLK/IO hysteresis"](#) on page 513

SBUS<sb>:QSPI:IOZero:POLarity <IO0Polarity>

Selects if the transmitted signal for the respective line is active high (high = 1) or active low (low = 1).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<IO0Polarity> ACTLow | ACTHigh
*RST: ACTHigh

Usage: Asynchronous command

Manual operation: See ["Polarity: CS, IOx"](#) on page 512

SBUS<sb>:QSPI:IOZero:POSition <QUADSPI IO0 position>

Sets the vertical position of the IO0 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<QUADSPI IO0 position>

Usage:

Asynchronous command

SBUS<sb>:QSPI:IOZero:SCALE <QUADSPI IO0 scale>

Set the vertical scale of the IO0 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<QUADSPI IO0 scale>

Usage:

Asynchronous command

SBUS<sb>:QSPI:IOZero:SOURce <IO0Source>

Sets the input channel of the IO 0 line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<IO0Source> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2 | M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage:

Asynchronous command

Manual operation: See "[CS, SCLK, IO n](#)" on page 511

SBUS<sb>:QSPI:IOZero:THReshold <Threshold>

Sets a user-defined threshold value for the line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold>

Usage:

Asynchronous command

Manual operation: See "[CS/SCLK/IO threshold](#)" on page 513

SBUS<sb>:QSPI:SCLK:HYSTeresis <Hysteresis>

Sets a value for the hysteresis for the SCLK channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage: Asynchronous command

Manual operation: See ["CS/SCLK/IO hysteresis"](#) on page 513

SBUS<sb>:QSPI:SCLK:POLarity <SCLKPolarity>

Sets the polarity for the clock line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SCLKPolarity> FALLing | RISing
*RST: RISing

Usage: Asynchronous command

Manual operation: See ["SCLK SDR Polarity"](#) on page 511

SBUS<sb>:QSPI:SCLK:SOURce <SCLKSource>

Sets the input channel of the SCLK clock line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SCLKSource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["CS, SCLK, IO n"](#) on page 511

SBUS<sb>:QSPI:SCLK:THReshold <Threshold>

Sets a user-defined threshold value for the line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold>

Usage: Asynchronous command

Manual operation: See ["CS/SCLK/IO threshold"](#) on page 513

18.18.3.2 Opcode

SBUS<sb>:QSPI:OPCode:APPend.....	1362
SBUS<sb>:QSPI:OPCode:DALL.....	1362
SBUS<sb>:QSPI:OPCode:DELeTe.....	1363
SBUS<sb>:QSPI:OPCode:RESet.....	1363
SBUS<sb>:QSPI:LDOPCode.....	1363
SBUS<sb>:QSPI:OPCode:SIZE?.....	1363
SBUS<sb>:QSPI:OPCode:ITEM<n>:ADBYtes.....	1364
SBUS<sb>:QSPI:OPCode:ITEM<n>:ADLanes.....	1364
SBUS<sb>:QSPI:OPCode:ITEM<n>:ALT.....	1364
SBUS<sb>:QSPI:OPCode:ITEM<n>:CODE.....	1365
SBUS<sb>:QSPI:OPCode:ITEM<n>:DATA.....	1365
SBUS<sb>:QSPI:OPCode:ITEM<n>:DDR.....	1365
SBUS<sb>:QSPI:OPCode:ITEM<n>:DMCYcles.....	1366
SBUS<sb>:QSPI:OPCode:ITEM<n>:DTLanes.....	1366
SBUS<sb>:QSPI:OPCode:ITEM<n>:NAME.....	1366
SBUS<sb>:QSPI:SVOP.....	1367

SBUS<sb>:QSPI:OPCode:APPend

Adds a new item to the opcode list.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage: Setting only
Asynchronous command

Manual operation: See ["Add"](#) on page 516

SBUS<sb>:QSPI:OPCode:DALL

Deletes all currently defined opcodes from the list.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage: Setting only
Asynchronous command

Manual operation: See ["Delete all"](#) on page 516

SBUS<sb>:QSPI:OPCode:DELeTe <Index>

Deletes the opcode with the selected index.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<Index>

Usage:

Setting only
Asynchronous command

Manual operation: See ["Delete"](#) on page 516

SBUS<sb>:QSPI:OPCode:RESet

Resets the opcode fields to the predefined values.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Preset"](#) on page 517

SBUS<sb>:QSPI:LDOPcode <FileName>

Loads an opcode file from the selected file.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName>

Usage:

Setting only
Asynchronous command

Manual operation: See ["Open, Save as"](#) on page 517

SBUS<sb>:QSPI:OPCode:SIZE?

Sets the size of the opcode, hence the number of opcodes currently defined on the table in the "Format" tab of QUAD-SPI.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count>

Usage:

Query only
Asynchronous command

SBUS<sb>:QSPI:OPCode:ITEM<n>:ADBytes <AddressBytes>

Sets the address byte. It specifies the location in the flash memory where the operation (e.g., read, write) is performed.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the opcode

Parameters:

<AddressBytes> Range: 0 to 4
Increment: 1
*RST: 0

Usage: Asynchronous command

Manual operation: See ["Address Bytes"](#) on page 518

SBUS<sb>:QSPI:OPCode:ITEM<n>:ADLanes <AddressLanes>

Selects how many lines or lanes are used to send the address bytes to the flash memory.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the opcode

Parameters:

<AddressLanes> SINGLE | DUAL | QUAD
*RST: SINGLE

Usage: Asynchronous command

Manual operation: See ["Address Lanes"](#) on page 518

SBUS<sb>:QSPI:OPCode:ITEM<n>:ALT <Alt>

Enable, if an alternative field is available.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the opcode

Parameters:

<Alt> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Alternative Field"](#) on page 518

SBUS<sb>:QSPI:OPCode:ITEM<n>:CODE <Opcode>

Sets the opcode value.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the opcode

Parameters:

<Opcode> Range: 0 to 255
Increment: 1
*RST: 0

Usage: Asynchronous command

Manual operation: See "[Opcode](#)" on page 517

SBUS<sb>:QSPI:OPCode:ITEM<n>:DATA <Data>

Enable, if data is being transferred in the opcode operation.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the opcode

Parameters:

<Data> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See "[Data](#)" on page 518

SBUS<sb>:QSPI:OPCode:ITEM<n>:DDR <DDR>

If enabled, the data is transferred on both the rising and falling edges of the clock signal. This setting effectively doubles the data transfer rate compared to a single data rate (SDR), which transfers data only on one clock edge.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the opcode

Parameters:

<DDR> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See "[DDR](#)" on page 518

SBUS<sb>:QSPI:OPCode:ITEM<n>:DMCYcles <DummyCycles>

Sets the number of dummy cycles. Dummy cycles are clock cycles inserted after the address or other command sequences but before data transfer begins. These cycles allow the flash memory device additional time to perform internal operations or latch onto the correct data to ensure accurate read or write operations.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the opcode

Parameters:

<DummyCycles> Range: 0 to 255
Increment: 1
*RST: 0

Usage: Asynchronous command

Manual operation: See ["Dummy Cycles"](#) on page 518

SBUS<sb>:QSPI:OPCode:ITEM<n>:DTLanes <DataLanes>

Selects how many lanes are used for the data transfer.

The data lanes refer to the physical connections through which data is transmitted between the main (typically a microcontroller) and the sub (typically a flash memory device). QADSPI can utilize multiple data lines to increase the speed and efficiency of data transfer.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the opcode

Parameters:

<DataLanes> SINGLE | DUAL | QUAD
*RST: SINGLE

Usage: Asynchronous command

Manual operation: See ["Data Lanes"](#) on page 519

SBUS<sb>:QSPI:OPCode:ITEM<n>:NAME <Name>

Sets the name for the Opcode.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the opcode

Parameters:

<Name>

Usage: Asynchronous command

Manual operation: See ["Name"](#) on page 518

SBUS<sb>:QSPI:SVOP <FileName>

Saves the opcode file.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName>

Usage:

Setting only

Asynchronous command

Manual operation: See ["Open, Save as"](#) on page 517

18.18.3.3 Filter

There are two commands for each parameter, that you can use for defining the QUAD SPI settings.

For example, to set the *Frame type =Data > Field =Addr >01100* value you can use one of the following commands:

- SBUS:QSPI:FILTer:FRAMe1:FLD1:DMIN 01100
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- SBUS:QSPI:FILTer:DMIN "Data", "Addr", 01100
Defines the parameter by using the frame and field name.

SBUS<sb>:QSPI:FILTer:CHKall.....	1368
SBUS<sb>:QSPI:FILTer:CLR.....	1368
SBUS<sb>:QSPI:FILTer:INVert.....	1368
SBUS<sb>:QSPI:FILTer:RST.....	1368
SBUS<sb>:QSPI:FILTer:BIT.....	1369
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1369
SBUS<sb>:QSPI:FILTer:DMAX.....	1369
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1369
SBUS<sb>:QSPI:FILTer:DMIN.....	1369
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1369
SBUS<sb>:QSPI:FILTer:DOPerator.....	1370
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1370
SBUS<sb>:QSPI:FILTer:IMAX.....	1370
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1370
SBUS<sb>:QSPI:FILTer:IMIN.....	1370
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1370
SBUS<sb>:QSPI:FILTer:IOPerator.....	1371
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1371
SBUS<sb>:QSPI:FILTer:ERENable.....	1371
SBUS<sb>:QSPI:FILTer:ERRor<n>:ENABLE.....	1371
SBUS<sb>:QSPI:FILTer:FIENable.....	1372

SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1372
SBUS<sb>:QSPI:FILTer:FRENAble.....	1372
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:ENABle.....	1372

SBUS<sb>:QSPI:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 519

SBUS<sb>:QSPI:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 519

SBUS<sb>:QSPI:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 519

SBUS<sb>:QSPI:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 519

SBUS<sb>:QSPI:FILTer:BIT <Frame>,<Field>,<Bit>

SBUS<sb>:QSPI:FILTer:BIT? <Bit>

SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO

*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 520

SBUS<sb>:QSPI:FILTer:DMAX <Frame>,<Field>,<Data>

SBUS<sb>:QSPI:FILTer:DMAX? <Data>

SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range if the operator is set to INRange or OORANGE.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 520

SBUS<sb>:QSPI:FILTer:DMIN <Frame>,<Field>,<Data>

SBUS<sb>:QSPI:FILTer:DMIN? <Data>

SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 520

SBUS<sb>:QSPI:FILTer:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:QSPI:FILTer:DOPerator? <Operator>

SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange

*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 520

SBUS<sb>:QSPI:FILTer:IMAX <Frame>,<Field>,<Data>

SBUS<sb>:QSPI:FILTer:IMAX? <Data>

SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range if the operator is set to INRange.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535

Increment: 1

*RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 520

SBUS<sb>:QSPI:FILTer:IMIN <Frame>,<Field>,<Data>

SBUS<sb>:QSPI:FILTer:IMIN? <Data>

SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
Increment: 1
*RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 520

SBUS<sb>:QSPI:FILTer:IOperator <Frame>,<Field>,<Operator>

SBUS<sb>:QSPI:FILTer:IOperator? <Operator>

SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGE
*RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 520

SBUS<sb>:QSPI:FILTer:ERENable <ErrorName>,<Enabler>

SBUS<sb>:QSPI:FILTer:ERENable? <Enabler>

SBUS<sb>:QSPI:FILTer:ERRor<n>:ENABle <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> index of the error

Parameters:

<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 521

SBUS<sb>:QSPI:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:QSPI:FILTer:FIENable? <Enabler>

SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:ENABLE <CondEnabler>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 520

SBUS<sb>:QSPI:FILTer:FRENable <Frame>,<Enabler>

SBUS<sb>:QSPI:FILTer:FRENable? <Enabler>

SBUS<sb>:QSPI:FILTer:FRAMe<fr>:ENABLE <Enable>

Enables or disables the checking condition for the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

18.18.3.4 Software trigger

There are two commands for each parameter, that you can use for defining the QUAD SPI settings.

For example, to set the *Frame type =Data > Field =Addr >01100* value you can use one of the following commands:

- `TRIGger:SBSW:QSPI:FRAMe1:FLD1:DMIN 01100`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `TRIGger:SBSW:QSPI:DMIN "Data", "Addr", 01100`
Defines the parameter by using the frame and field name.

[TRIGger:SBSW:QSPI:CHKall](#)..... 1373

[TRIGger:SBSW:QSPI:CLR](#)..... 1373

[TRIGger:SBSW:QSPI:INVert](#)..... 1373

TRIGger:SBSW:QSPI:RST.....	1374
TRIGger:SBSW:QSPI:FREnable.....	1374
TRIGger:SBSW:QSPI:FRAMe<fr>:ENABLE.....	1374
TRIGger:SBSW:QSPI:BIT.....	1374
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:BIT.....	1374
TRIGger:SBSW:QSPI:DMAX.....	1374
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:DMAX.....	1374
TRIGger:SBSW:QSPI:DMIN.....	1375
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:DMIN.....	1375
TRIGger:SBSW:QSPI:DOPerator.....	1375
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:DOPerator.....	1375
TRIGger:SBSW:QSPI:FIENable.....	1376
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:ENABLE.....	1376
TRIGger:SBSW:QSPI:IMAX.....	1376
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:IMAX.....	1376
TRIGger:SBSW:QSPI:IMIN.....	1376
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:IMIN.....	1376
TRIGger:SBSW:QSPI:IOperator.....	1377
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:IOperator.....	1377
TRIGger:SBSW:QSPI:ERENable.....	1377
TRIGger:SBSW:QSPI:ERRor<m>:ENABLE.....	1377
SBUS<sb>:QSPI:SWTIndex?.....	1377
SBUS<sb>:QSPI:SWTTime?.....	1378

TRIGger:SBSW:QSPI:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 522

TRIGger:SBSW:QSPI:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 522

TRIGger:SBSW:QSPI:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 522

TRIGger:SBSW:QSPI:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 522

TRIGger:SBSW:QSPI:FREnable <Frame>,<Enabler>**TRIGger:SBSW:QSPI:FREnable? <Enabler>****TRIGger:SBSW:QSPI:FRAME<fr>:ENABLE <Enable>**

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:
 <fr> Index of the frame

Parameters:
 <Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 523

TRIGger:SBSW:QSPI:BIT <Frame>,<Field>,<Bit>**TRIGger:SBSW:QSPI:BIT? <Bit>****TRIGger:SBSW:QSPI:FRAME<fr>:FLD<fl>:BIT <BitState>**

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:
 <fr> Index of the frame
 <fl> Index of the field

Parameters:
 <BitState> ONE | ZERO
 *RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 523

TRIGger:SBSW:QSPI:DMAX <Frame>,<Field>,<Data>**TRIGger:SBSW:QSPI:DMAX? <Data>****TRIGger:SBSW:QSPI:FRAME<fr>:FLD<fl>:DMAX <Data_Max>**

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGE.

You can set the operator with `TRIGger:SBSW:QSPI:FRAME<fr>:FLD<fl>:DOPerator`.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See "Edit" on page 523

TRIGger:SBSW:QSPI:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:QSPI:DMIN? <Data>

TRIGger:SBSW:QSPI:FRAME<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See "Edit" on page 523

TRIGger:SBSW:QSPI:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:QSPI:DOPerator? <Operator>

TRIGger:SBSW:QSPI:FRAME<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange
*RST: EQUal

Usage: Asynchronous command

Manual operation: See "Edit" on page 523

TRIGger:SBSW:QSPI:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:QSPI:FIENable? <Enabler>

TRIGger:SBSW:QSPI:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 523

TRIGger:SBSW:QSPI:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:QSPI:IMAX? <Data>

TRIGger:SBSW:QSPI:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with [TRIGger:SBSW:QSPI:FRAME<fr>:FLD<fl>:IOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535

Increment: 1

*RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 523

TRIGger:SBSW:QSPI:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:QSPI:IMIN? <Data>

TRIGger:SBSW:QSPI:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 523

TRIGger:SBSW:QSPI:IOperator <Frame>,<Field>,<Operator>

TRIGger:SBSW:QSPI:IOperator? <Operator>

TRIGger:SBSW:QSPI:FRAME<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Operator> EQUAL | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 523

TRIGger:SBSW:QSPI:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:QSPI:ERENable? <Enabler>

TRIGger:SBSW:QSPI:ERROR<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> Index of the error

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 525

SBUS<sb>:QSPI:SWTindex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns `Invalid`.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

SBUS<sb>:QSPI:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

18.18.3.5 Decode results

SBUS<sb>:QSPI:FCOunt?	1378
SBUS<sb>:QSPI:FRAMe<fr>:ADDR?	1379
SBUS<sb>:QSPI:FRAMe<fr>:ALT?	1379
SBUS<sb>:QSPI:FRAMe<fr>:BITRate?	1379
SBUS<sb>:QSPI:FRAMe<fr>:DATA?	1380
SBUS<sb>:QSPI:FRAMe<fr>:FLDCount?	1380
SBUS<sb>:QSPI:FRAMe<fr>:FDATa?	1380
SBUS<sb>:QSPI:FRAMe<fr>:FLD<fl>:VALue?	1380
SBUS<sb>:QSPI:FRAMe<fr>:FLD<fl>:FVALue?	1381
SBUS<sb>:QSPI:FRAMe<fr>:FLD<fl>:LABel?	1381
SBUS<sb>:QSPI:FRAMe<fr>:FLD<fl>:STATe?	1381
SBUS<sb>:QSPI:FRAMe<fr>:ILBL?	1382
SBUS<sb>:QSPI:FRAMe<fr>:IVALue?	1382
SBUS<sb>:QSPI:FRAMe<fr>:STARt?	1383
SBUS<sb>:QSPI:FRAMe<fr>:STATus?	1383
SBUS<sb>:QSPI:FRAMe<fr>:STOP?	1383

SBUS<sb>:QSPI:FCOunt?

Returns the number of decoded frames.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count>

Usage:

Query only
Asynchronous command

SBUS<sb>:QSPI:FRAME<fr>:ADDR?

Returns the address of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameAddress> Range: 0 to 4294967295
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:QSPI:FRAME<fr>:ALT?

Retruns the value of the alternate byte for the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameAlt> Range: 0 to 65535
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:QSPI:FRAME<fr>:BITRate?

Returns the bit rate of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<PrimaryBitRate> Increment: 1
*RST: 0
Default unit: bps

Usage: Query only
Asynchronous command

SBUS<sb>:QSPI:FRAME<fr>:DATA?

Returns the data of the specified frame in comma-separated values.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:
<Count>
<Values>

Usage: Query only
Asynchronous command

SBUS<sb>:QSPI:FRAME<fr>:FLDCount?

Returns the field count for the specified frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:
<Count>

Usage: Query only
Asynchronous command

SBUS<sb>:QSPI:FRAME<fr>:FDATA?

Returns the formatted data value of the specified frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:
<FrameData>

Usage: Query only
Asynchronous command

SBUS<sb>:QSPI:FRAME<fr>:FLD<fl>:VALue?

Returns the value of the specified field of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Value> Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:QSPI:FRAME<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<FormattedValue>

Usage:

Query only
Asynchronous command

SBUS<sb>:QSPI:FRAME<fr>:FLD<fl>:LABEL?

Returns the label of the selected field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Label>

Usage:

Query only
Asynchronous command

SBUS<sb>:QSPI:FRAME<fr>:FLD<fl>:STATe?

Returns the state of the selected field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<State> OK | LENGth | OPCode | INComplete

OK

The field is valid.

LENGth

The field does not have the expected length.

OPCode

The opcode value is not found in your frame description list. See [Section 14.3.2.4, "Format"](#), on page 514.

INComplete

The field is not completely contained in the acquisition. The acquired part of the field is usually valid, but cannot always be trusted.

*RST: OK

Usage:

Query only
Asynchronous command

SBUS<sb>:QSPI:FRAMe<fr>:ILBL?

Returns the label of the instruction.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameLabel>

Usage:

Query only
Asynchronous command

SBUS<sb>:QSPI:FRAMe<fr>:IVALue?

Returns the instruction mode value for the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrmInstruction> Range: 0 to 65535
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:QSPI:FRAMe<fr>:STARt?

Returns the start time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStart> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:QSPI:FRAMe<fr>:STATus?

Returns the overall state of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameState> OK | LENGth | OPCode | INComplete
OK: the frame is valid.
OPCode: operation code.
INComplete: INComplete word. The word does not have the expected word length.
LENGth: The frame is not contained in the acquisition.
*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:QSPI:FRAMe<fr>:STOP?

Returns the end time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

18.18.4 I²C (option R&S MXO5C-K510)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with `SBUS<sb>[:STATe]`.
- The bus is set to the correct type with `SBUS<sb>:TYPE`.
- [Configuration](#)..... 1384
- [Filter](#)..... 1387
- [Hardware trigger](#)..... 1392
- [Software trigger](#)..... 1396
- [Decode results](#)..... 1402

18.18.4.1 Configuration

SBUS<sb>:I2C:SCL:HYSTeresis	1384
SBUS<sb>:I2C:SCL:SOURce	1384
SBUS<sb>:I2C:SCL:THReshold	1385
SBUS<sb>:I2C:SDA:HYSTeresis	1385
SBUS<sb>:I2C:SDA:SOURce	1385
SBUS<sb>:I2C:SDA:THReshold	1386
SBUS<sb>:I2C:POSition	1386
SBUS<sb>:I2C:SCALe	1386
SBUS<sb>:I2C:SYMBols	1386
SBUS<sb>:I2C:NEWLlist	1387

SBUS<sb>:I2C:SCL:HYSTeresis <Hysteresis>

Sets a hysteresis value for the clock line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage:

Asynchronous command

Manual operation: See "[SDA/SCL threshold, SDA/SCL hysteresis](#)" on page 533

SBUS<sb>:I2C:SCL:SOURce SCLSource

Selects the waveform source of the clock line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

SCLSource C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["SCL source"](#) on page 533

SBUS<sb>:I2C:SCL:THReshold <Threshold>

Sets a user-defined threshold value for the clock line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold>

Usage: Asynchronous command

Manual operation: See ["SDA/SCL threshold, SDA/SCL hysteresis"](#) on page 533

SBUS<sb>:I2C:SDA:HYSTeresis <Hysteresis>

Sets a hysteresis value for the data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage: Asynchronous command

Manual operation: See ["SDA/SCL threshold, SDA/SCL hysteresis"](#) on page 533

SBUS<sb>:I2C:SDA:SOURce SDASource

Sets the source channel to which the data line is connected.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

SDASource C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["SDA source"](#) on page 533

SBUS<sb>:I2C:SDA:THReshold <Threshold>

Sets a user-defined threshold value for the data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold>

Usage: Asynchronous command

Manual operation: See ["SDA/SCL threshold, SDA/SCL hysteresis"](#) on page 533

SBUS<sb>:I2C:POSition <Position>

Sets the vertical position of the I²C signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Position>

Usage: Asynchronous command

SBUS<sb>:I2C:SCALe <Scale>

Set the vertical scale of the I²C signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Scale>

Usage: Asynchronous command

SBUS<sb>:I2C:SYMBols <ShowSymbols>

Activates the symbol list to be used for decoding.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ShowSymbols> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Show symbols"](#) on page 535

SBUS<sb>:I2C:NEWList <FileName>

Loads a symbol list file.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName> String parameter with path and file name.

Example:

```
SBUS1:I2C:NEWList
'/home/storage/userData/Protocol/I2C.csv'
SBUS1:I2C:SYMBOLS ON
```

Usage:

Setting only
Asynchronous command

Manual operation: See ["Show symbols"](#) on page 535

18.18.4.2 Filter

There are two commands for each parameter, that you can use for defining the I2C settings.

For example, to set the *Frame type =WRITE > Field =Address >Data* value you can use one of the following commands:

- SBUS:I2C:FILTer:FRAMe1:FLD1:DMIN 01100
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- SBUS:I2C:FILTer:DMIN "WRITe", "Address", 01100
Defines the parameter by using the frame and field name.

SBUS<sb>:I2C:FILTer:CHKall.....	1388
SBUS<sb>:I2C:FILTer:CLR.....	1388
SBUS<sb>:I2C:FILTer:INVert.....	1388
SBUS<sb>:I2C:FILTer:RST.....	1388
SBUS<sb>:I2C:FILTer:FRENAble.....	1389
SBUS<sb>:I2C:FILTer:FRAMe<fr>:ENABle.....	1389
SBUS<sb>:I2C:FILTer:DMAx.....	1389
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:DMAx.....	1389
SBUS<sb>:I2C:FILTer:DMIN.....	1389
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1389
SBUS<sb>:I2C:FILTer:DOPerator.....	1390
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1390
SBUS<sb>:I2C:FILTer:ERENABle.....	1390
SBUS<sb>:I2C:FILTer:ERRor<n>:ENABle.....	1390
SBUS<sb>:I2C:FILTer:IMAX.....	1390
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1390
SBUS<sb>:I2C:FILTer:IMIN.....	1391
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1391
SBUS<sb>:I2C:FILTer:IOPerator.....	1391
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1391

SBUS<sb>:I2C:FILTer:BIT.....	1392
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1392
SBUS<sb>:I2C:FILTer:FIENable.....	1392
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1392

SBUS<sb>:I2C:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 536

SBUS<sb>:I2C:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 536

SBUS<sb>:I2C:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 536

SBUS<sb>:I2C:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 536

SBUS<sb>:I2C:FILTer:FREnAble <Frame>,<Enabler>

SBUS<sb>:I2C:FILTer:FREnAble? <Enabler>

SBUS<sb>:I2C:FILTer:FRAMe<fr>:ENABLe <Enable>

Enables or disables the specific frame to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 537

SBUS<sb>:I2C:FILTer:DMAx <Frame>,<Field>,<Data>

SBUS<sb>:I2C:FILTer:DMAx? <Data>

SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:DMAx <Data_Max>

Sets the end value of a data pattern range if the operator is set to INRange or OORANGE.

You can set the operator with [SBUS<sb>:I2C:FILTer:DOPerator](#).

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 537

SBUS<sb>:I2C:FILTer:DMin <Frame>,<Field>,<Data>

SBUS<sb>:I2C:FILTer:DMin? <Data>

SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:DMin <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 537

SBUS<sb>:I2C:FILTer:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:I2C:FILTer:DOPerator? <Operator>

SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange

*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 537

SBUS<sb>:I2C:FILTer:ERENable <ErrorName>,<Enabler>

SBUS<sb>:I2C:FILTer:ERENable? <Enabler>

SBUS<sb>:I2C:FILTer:ERRor<n>:ENABle <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 538

SBUS<sb>:I2C:FILTer:IMAX <Frame>,<Field>,<Data>

SBUS<sb>:I2C:FILTer:IMAX? <Data>

SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range if the operator is set to INRange.

You can set the operator with [SBUS<sb>:I2C:FILTer:IOperator](#).

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
Increment: 1
*RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 537

SBUS<sb>:I2C:FILTer:IMIN <Frame>,<Field>,<Data>

SBUS<sb>:I2C:FILTer:IMIN? <Data>

SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
Increment: 1
*RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 537

SBUS<sb>:I2C:FILTer:IOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:I2C:FILTer:IOPerator? <Operator>

SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGE
*RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 537

SBUS<sb>:I2C:FILTer:BIT <Frame>,<Field>,<Bit>

SBUS<sb>:I2C:FILTer:BIT? <Bit>

SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO

*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 537

SBUS<sb>:I2C:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:I2C:FILTer:FIENable? <Enabler>

SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 537

18.18.4.3 Hardware trigger

Trigger commands for serial buses affect the current trigger source. Therefore, set the trigger source to the required serial bus with [TRIGger:EVENT<ev>:SOURce](#) before sending the bus-specific trigger commands.

TRIGger:SBHW:I2C:TYPE	1393
TRIGger:SBHW:I2C:ACcEss	1393
TRIGger:SBHW:I2C:ACONdition	1394
TRIGger:SBHW:I2C:ADDResS	1394
TRIGger:SBHW:I2C:ADDTo	1394
TRIGger:SBHW:I2C:ADNack	1394
TRIGger:SBHW:I2C:AMODE	1395

TRIGger:SBHW:I2C:DCondition.....	1395
TRIGger:SBHW:I2C:DMIN.....	1395
TRIGger:SBHW:I2C:DPOStion.....	1395
TRIGger:SBHW:I2C:DRNack.....	1396
TRIGger:SBHW:I2C:DWNack.....	1396

TRIGger:SBHW:I2C:TYPE <Type>

Selects the trigger type for I²C analysis.

Parameters:

<Type>	START REPStart STOP NACK ADDRess DATA ADAT
START	Start condition
REPStart	Repeated start - the start condition occurs without previous stop condition.
STOP	Stop condition, end of frame
NACK	Missing acknowledge bit. To localize specific missing acknowledge bits, use: TRIGger:SBHW:I2C:ADNack TRIGger:SBHW:I2C:DWNack TRIGger:SBHW:I2C:DRNack
ADDRess	Triggers on one specific address
DATA	Triggers on a specific data
ADAT	Triggers on a combination of address and data condition.
*RST:	START

Usage: Asynchronous command

Manual operation: See "Type" on page 539

TRIGger:SBHW:I2C:ACCess <RWBitAddress>

Toggles the trigger condition between read and write access of the primary. Select "Either" if the transfer direction is not relevant for the trigger condition.

Parameters:

<RWBitAddress>	READ WRITe EITHer
*RST:	EITHer

Usage: Asynchronous command

Manual operation: See "R/W bit" on page 541

TRIGger:SBHW:I2C:ACONdition <AddrOptor>

Sets the operator to set a specific address or an address range. The address values are set with [TRIGger:SBHW:I2C:ADDRess](#) and [TRIGger:SBHW:I2C:ADDTo](#).

Parameters:

<AddrOptor> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUal

Usage: Asynchronous command

TRIGger:SBHW:I2C:ADDRess <Address>

Triggers on the specified address, or sets the start value of an address range depending on the condition set with [TRIGger:SBHW:I2C:ACONdition](#).

Parameters:

<Address>

Usage: Asynchronous command

Manual operation: See ["Address"](#) on page 541

TRIGger:SBHW:I2C:ADDTo <AddressTo>

Sets the end value of an address range if the condition is set to an address range with [TRIGger:SBHW:I2C:ACONdition](#).

Parameters:

<AddressTo>

Usage: Asynchronous command

Manual operation: See ["Address"](#) on page 541

TRIGger:SBHW:I2C:ADNack <AddressNack>

Triggers if the address acknowledge bit is missing - no target recognizes the address.

Parameters:

<AddressNack> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["No Ack conditions"](#) on page 541

TRIGger:SBHW:I2C:AMODe <AddressType>

Sets the address length to be triggered on: 7 bit or 10 bit.

Parameters:

<AddressType> BIT7 | BIT7RW | BIT7_RW | BIT10

Note that BIT7RW is the same address type as BIT7_RW.

BIT7 | BIT10

Enter only the seven or ten address bits in the address pattern.

BIT7RW | BIT7_RW

Enter seven address bits and also the read/write bit.

*RST: BIT7

Usage: Asynchronous command

Manual operation: See ["Address type"](#) on page 541

TRIGger:SBHW:I2C:DCONDition <DataOperator>

Sets the operator to set a specific data value or a data range.

Parameters:

<DataOperator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan

*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Data"](#) on page 542

TRIGger:SBHW:I2C:DMIN <Data>

Specifies the data bit pattern, or sets the start value of a data pattern range. Enter the bytes in MSB first bit order. The maximum pattern length is 64 bit. Waveform data is compared with the pattern byte-by-byte.

Parameters:

<Data>

Usage: Asynchronous command

Manual operation: See ["Data"](#) on page 542

TRIGger:SBHW:I2C:DPOStion <DataPosition>

Sets the number of data bytes to be skipped after the address.

Parameters:

<DataPosition> Range: 1 to 4096

Increment: 1

*RST: 1

Usage: Asynchronous command

Manual operation: See ["Position"](#) on page 542

TRIGger:SBHW:I2C:DRNack <DataReadNack>

Triggers on the end of the read process when the controller reads data from the target. This NACK is sent according to the protocol definition, it is not an error.

Parameters:

<DataReadNack> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["No Ack conditions"](#) on page 541

TRIGger:SBHW:I2C:DWNack <DataWriteNack>

Triggers if a data acknowledge bit is missing - the addressed target does not accept the data.

Parameters:

<DataWriteNack> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["No Ack conditions"](#) on page 541

18.18.4.4 Software trigger

There are two commands for each parameter, that you can use for defining the I2C settings.

For example, to set the *Frame type =WRITE > Field =Address >Data* value you can use one of the following commands:

- TRIGger:SBSW:I2C:FRAMe1:FLD1:DMIN 01100
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- STRIGger:SBSW:I2C:DMIN "WRITE", "Address", 01100
Defines the parameter by using the frame and field name.

TRIGger:SBSW:I2C:CHKall.....	1397
TRIGger:SBSW:I2C:CLR.....	1397
TRIGger:SBSW:I2C:INVert.....	1397
TRIGger:SBSW:I2C:RST.....	1397
TRIGger:SBSW:I2C:FRENable.....	1398
TRIGger:SBSW:I2C:FRAMe<fr>:ENABLE.....	1398
TRIGger:SBSW:I2C:BIT.....	1398
TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:BIT.....	1398
TRIGger:SBSW:I2C:DMAX.....	1398
TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:DMAX.....	1398

TRIGger:SBSW:I2C:DMIN.....	1399
TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:DMIN.....	1399
TRIGger:SBSW:I2C:DOPerator.....	1399
TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:DOPerator.....	1399
TRIGger:SBSW:I2C:FIENable.....	1399
TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:ENABLE.....	1399
TRIGger:SBSW:I2C:IMAX.....	1400
TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:IMAX.....	1400
TRIGger:SBSW:I2C:IMIN.....	1400
TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:IMIN.....	1400
TRIGger:SBSW:I2C:IOPerator.....	1401
TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:IOPerator.....	1401
TRIGger:SBSW:I2C:ERENable.....	1401
TRIGger:SBSW:I2C:ERRor<m>:ENABLE.....	1401
SBUS<sb>:I2C:SWTindex?.....	1401
SBUS<sb>:I2C:SWTTime?.....	1402

TRIGger:SBSW:I2C:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 543

TRIGger:SBSW:I2C:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 543

TRIGger:SBSW:I2C:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 543

TRIGger:SBSW:I2C:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 543

TRIGger:SBSW:I2C:FREnable <Frame>,<Enabler>

TRIGger:SBSW:I2C:FREnable? <Enabler>

TRIGger:SBSW:I2C:FRAMe<fr>:ENABLe <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 544

TRIGger:SBSW:I2C:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:I2C:BIT? <Bit>

TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO

*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 544

TRIGger:SBSW:I2C:DMAx <Frame>,<Field>,<Data>

TRIGger:SBSW:I2C:DMAx? <Data>

TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:DMAx <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGe.

You can set the operator with [TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:DOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 544

TRIGger:SBSW:I2C:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:I2C:DMIN? <Data>

TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 544

TRIGger:SBSW:I2C:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:I2C:DOPerator? <Operator>

TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange
*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 544

TRIGger:SBSW:I2C:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:I2C:FIENable? <Enabler>

TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 544

TRIGger:SBSW:I2C:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:I2C:IMAX? <Data>

TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with [TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:IOperator](#).

Suffix:

<fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 544

TRIGger:SBSW:I2C:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:I2C:IMIN? <Data>

TRIGger:SBSW:I2C:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 544

TRIGger:SBSW:I2C:IOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:I2C:IOPerator? <Operator>

TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGe

*RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 544

TRIGger:SBSW:I2C:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:I2C:ERENable? <Enabler>

TRIGger:SBSW:I2C:ERRor<m>:ENABle <Enable>

Defines the error type for the software trigger.

Suffix:

<m> index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 545

SBUS<sb>:I2C:SWTindex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295

Increment: 1

*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:I2C:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

18.18.4.5 Decode results

SBUS<sb>:I2C:FCOunt?	1402
SBUS<sb>:I2C:FRAMe<fr>:AACcess?	1403
SBUS<sb>:I2C:FRAMe<fr>:ACCess?	1403
SBUS<sb>:I2C:FRAMe<fr>:ACOMplete?	1403
SBUS<sb>:I2C:FRAMe<fr>:ADBStart?	1404
SBUS<sb>:I2C:FRAMe<fr>:ADDRess?	1404
SBUS<sb>:I2C:FRAMe<fr>:ADEVice?	1404
SBUS<sb>:I2C:FRAMe<fr>:AMODE?	1405
SBUS<sb>:I2C:FRAMe<fr>:ASTart?	1405
SBUS<sb>:I2C:FRAMe<fr>:BITRate?	1405
SBUS<sb>:I2C:FRAMe<fr>:FLDCount?	1406
SBUS<sb>:I2C:FRAMe<fr>:FLD<fl>:FVALue?	1406
SBUS<sb>:I2C:FRAMe<fr>:FLD<fl>:LABel?	1406
SBUS<sb>:I2C:FRAMe<fr>:FLD<fl>:START?	1406
SBUS<sb>:I2C:FRAMe<fr>:FLD<fl>:STATe?	1407
SBUS<sb>:I2C:FRAMe<fr>:FLD<fl>:VALue?	1407
SBUS<sb>:I2C:FRAMe<fr>:DATA?	1408
SBUS<sb>:I2C:FRAMe<fr>:RWBStart?	1408
SBUS<sb>:I2C:FRAMe<fr>:START?	1408
SBUS<sb>:I2C:FRAMe<fr>:STATus?	1409
SBUS<sb>:I2C:FRAMe<fr>:STOP?	1409
SBUS<sb>:I2C:FRAMe<fr>:SYMBol?	1410

SBUS<sb>:I2C:FCOunt?

Returns the number of decoded frames.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count> Total number of decoded frames.

Usage: Query only
Asynchronous command

SBUS<sb>:I2C:FRAMe<fr>:AACcess?

Returns the address acknowledge bit value for the indicated frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <AddressAckBit> ACK | NACK | EITHer
 *RST: EITHer

Usage: Query only
Asynchronous command

SBUS<sb>:I2C:FRAMe<fr>:ACCess?

Returns the value of the R/W bit of the indicated frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <RWBit> UNDefined | READ | WRITe | EITHer
 *RST: UNDefined

Usage: Query only
Asynchronous command

SBUS<sb>:I2C:FRAMe<fr>:ACOMplete?

Returns if the address is completely contained in the acquisition.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <AddrComplete> OFF | ON
 *RST: OFF

Usage: Query only
Asynchronous command

SBUS<sb>:I2C:FRAMe<fr>:ADBStart?

Returns the start time of the address acknowledge bit.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<AddrAckBtStrt> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:I2C:FRAMe<fr>:ADDRess?

Returns the device address value of the indicated frame. That is, the address value that is shown in the decoded cells and in the decode results table.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<AddressValue> Range: 0 to 2047
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:I2C:FRAMe<fr>:ADEVice?

Returns the pure device address of the indicated frame *without* the R/W bit.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<DeviceAddress> Range: 0 to 1023
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:I2C:FRAMe<fr>:AMODe?

Returns the address length.

See also [TRIGger:SBHW:I2C:AMODe](#) on page 1395.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<AddressType> BIT7 | BIT7RW | BIT7_RW | BIT10

*RST: BIT7

Usage:

Query only
Asynchronous command

SBUS<sb>:I2C:FRAMe<fr>:AStart?

Returns the start time of the address for the indicated frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<AddressStart> Range: -1E+26 to 1E+26

Increment: 1E-10

*RST: 0

Default unit: s

Usage:

Query only
Asynchronous command

SBUS<sb>:I2C:FRAMe<fr>:BITRate?

Returns the primary bit rate.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<PrimaryBitRate> Increment: 1

*RST: 0

Default unit: bps

Usage:

Query only
Asynchronous command

SBUS<sb>:I2C:FRAME<fr>:FLDCount?

Returns the number of fields in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<Count>

Usage:

Query only
Asynchronous command

SBUS<sb>:I2C:FRAME<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<fl> Index of the field

Return values:

<FormattedValue>

Usage:

Query only
Asynchronous command

SBUS<sb>:I2C:FRAME<fr>:FLD<fl>:LABEL?

Returns the name (label) of the specified field in the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<fl> Index of the field

Return values:

<Label>

Usage:

Query only
Asynchronous command

SBUS<sb>:I2C:FRAME<fr>:FLD<fl>:START?

Returns the start time of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr>	Index of the frame
<fl>	Index of the field
Return values:	
<Start>	Range: -1E+26 to 1E+26 Increment: 1E-10 *RST: 0 Default unit: s
Usage:	
	Query only Asynchronous command

SBUS<sb>:I2C:FRAME<fr>:FLD<fl>:STATE?

Returns the overall state of the specified field in the selected frame.

Suffix:	
<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field
Return values:	
<State>	OK ADDifferent NOSTop UNKNown INComplete
	OK The field has no error, it is valid.
	ADDDifferent 10-bit read address different. For a read access on a 10-bit address, the first address byte is sent twice, first as write, the second as read. The first 7 bits of the byte must be identical. If they are not identical, the ADDiffernt error is indicated.
	NOSTop The stop bit is missing.
	UNKNown Unknown field type detected.
	INComplete The field is not completely contained in the acquisition. The acquired part of the field is usually valid, but cannot always be trusted.
	*RST: OK
Usage:	
	Query only Asynchronous command

SBUS<sb>:I2C:FRAME<fr>:FLD<fl>:VALue?

Returns the data value of the specified field.

Suffix:	
<sb>	1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Value> Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:I2C:FRAME<fr>:DATA?

Returns the data words of the specified frame as comma-separated values.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Count>

<Values>

Example: BUS:I2C:FRAME4:DATA?
<-- 3,74,164,18

Usage: Query only
Asynchronous command

SBUS<sb>:I2C:FRAME<fr>:RWBStart?

Returns the start time of the R/W bit

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<RWBitStart> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:I2C:FRAME<fr>:START?

Returns the start time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStart> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:I2C:FRAMe<fr>:STATus?

Returns the overall state of the frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameState> OK | ADDifferent | NOSTop | UNKNown | INComplete

OK

The frame is valid.

ADDDifferent

10-bit read address different. For a read access on a 10-bit address, the first address byte is sent twice, first as write, the second as read. The first 7 bits of the byte must be identical. If they are not identical, the ADDiffernt error is indicated.

NOSTop

The stop bit is missing.

UNKNown

Unknown frame type detected.

INComplete

The frame is not completely contained in the acquisition. The acquired part of the frame is usually valid, but cannot always be trusted.

*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:I2C:FRAMe<fr>:STOP?

Returns the end time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

SBUS<sb>:I2C:FRAMe<fr>:SYMBol?

Returns the symbolic label of the specified frame if the label list is enabled.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<Translation> String with the symbolic name of the frame

Usage:

Query only
 Asynchronous command

18.18.5 I3C (option R&S MXO5C-K550)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with [SBUS<sb>\[:STATe\]](#).
- The bus is set to the correct type with [SBUS<sb>:TYPE](#).

• Configuration	1410
• Filter	1414
• Software trigger	1419
• Decode results	1425

18.18.5.1 Configuration

SBUS<sb>:I3C:SCL:HYSTeresis	1411
SBUS<sb>:I3C:SCL:SOURce	1411
SBUS<sb>:I3C:SCL:THReshold	1411
SBUS<sb>:I3C:SDA:HYSTeresis	1411
SBUS<sb>:I3C:SDA:SOURce	1412
SBUS<sb>:I3C:SDA:THReshold	1412
SBUS<sb>:I3C:MINGap:SElect	1412
SBUS<sb>:I3C:MINGap:WIDTh	1412
SBUS<sb>:I3C:POSition	1413
SBUS<sb>:I3C:SCALe	1413
SBUS<sb>:I3C:SYMBols	1413
SBUS<sb>:I3C:NEWLisT	1414

SBUS<sb>:I3C:SCL:HYSTeresis <SCLHysteresis>

Sets a hysteresis value for the clock line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SCLHysteresis>

Usage:

Asynchronous command

Manual operation: See ["SDA/SCL threshold, SDA/SCL hysteresis"](#) on page 555

SBUS<sb>:I3C:SCL:SOURce SCLSource

Selects the waveform source of the clock line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

SCLSource C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage:

Asynchronous command

Manual operation: See ["SCL source"](#) on page 554

SBUS<sb>:I3C:SCL:THReshold <SCLThreshold>

Sets a user-defined threshold value for the clock line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SCLThreshold>

Usage:

Asynchronous command

Manual operation: See ["SDA/SCL threshold, SDA/SCL hysteresis"](#) on page 555

SBUS<sb>:I3C:SDA:HYSTeresis <SDAHysteresis>

Sets a hysteresis value for the data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SDAHysteresis>

Usage:

Asynchronous command

Manual operation: See ["SDA/SCL threshold, SDA/SCL hysteresis"](#) on page 555

SBUS<sb>:I3C:SDA:SOURce SDASource

Sets the source channel to which the data line is connected.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

SDASource C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["SDA source"](#) on page 554

SBUS<sb>:I3C:SDA:THReshold <SDAThreshold>

Sets a user-defined threshold value for the data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SDAThreshold>

Usage: Asynchronous command

Manual operation: See ["SDA/SCL threshold, SDA/SCL hysteresis"](#) on page 555

SBUS<sb>:I3C:MINGap:SElect <MingapSelect>

Specifies whether a minimum gap before the 1st decoded frame is required.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MingapSelect> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Require min gap"](#) on page 555

SBUS<sb>:I3C:MINGap:WIDTh <MingapWidth>

Specifies the minimum duration of the gap.

Available, if [SBUS<sb>:I3C:MINGap:SElect](#) is set to ON.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MingapWidth> Range: 1E-11 to 1
 Increment: 1E-11
 *RST: 1E-06
 Default unit: s

Usage: Asynchronous command

Manual operation: See "[Min gap width](#)" on page 555

SBUS<sb>:I3C:POSition <Position>

Sets the vertical position of the I3C signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Position>

Usage: Asynchronous command

SBUS<sb>:I3C:SCALe <Scale>

Sets the vertical scale of the I3C signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Scale>

Usage: Asynchronous command

SBUS<sb>:I3C:SYMBols <ShowSymbols>

Activates the symbol list to be used for decoding.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ShowSymbols> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See "[Show symbols](#)" on page 556

SBUS<sb>:I3C:NEWList <FileName>

Loads a symbol list file.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName> String parameter with path and file name.

Example:

```
SBUS1:I3C:NEWList
'/home/storage/userData/Protocol/I3C.csv'
SBUS1:I3C:SYMBOLS ON
```

Usage:

Setting only
Asynchronous command

Manual operation: See ["Show symbols"](#) on page 556

18.18.5.2 Filter

There are two commands for each parameter, that you can use for defining the I3C settings.

For example, to set the *Frame type =WRITE > Field =Address >Data* value you can use one of the following commands:

- SBUS:I3C:FILTer:FRAMe1:FLD1:DMIN 01100
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- SBUS:I3C:FILTer:DMIN "WRITe", "Address", 01100
Defines the parameter by using the frame and field name.

SBUS<sb>:I3C:FILTer:CHKall.....	1415
SBUS<sb>:I3C:FILTer:CLR.....	1415
SBUS<sb>:I3C:FILTer:INVert.....	1415
SBUS<sb>:I3C:FILTer:RST.....	1415
SBUS<sb>:I3C:FILTer:FRENable.....	1416
SBUS<sb>:I3C:FILTer:FRAMe<fr>:ENABle.....	1416
SBUS<sb>:I3C:FILTer:DMAx.....	1416
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:DMAx.....	1416
SBUS<sb>:I3C:FILTer:DMIN.....	1416
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1416
SBUS<sb>:I3C:FILTer:DOPerator.....	1417
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1417
SBUS<sb>:I3C:FILTer:ERENable.....	1417
SBUS<sb>:I3C:FILTer:ERRor<n>:ENABle.....	1417
SBUS<sb>:I3C:FILTer:IMAX.....	1417
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1417
SBUS<sb>:I3C:FILTer:IMIN.....	1418
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1418
SBUS<sb>:I3C:FILTer:IOperator.....	1418
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:IOperator.....	1418

SBUS<sb>:I3C:FILTer:BIT.....	1419
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1419
SBUS<sb>:I3C:FILTer:FIENable.....	1419
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1419

SBUS<sb>:I3C:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 558

SBUS<sb>:I3C:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 558

SBUS<sb>:I3C:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 558

SBUS<sb>:I3C:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 558

SBUS<sb>:I3C:FILTer:FREnAble <Frame>,<Enabler>

SBUS<sb>:I3C:FILTer:FREnAble? <Enabler>

SBUS<sb>:I3C:FILTer:FRAMe<fr>:ENABLe <Enable>

Enables or disables the specific frame to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 558

SBUS<sb>:I3C:FILTer:DMAx <Frame>,<Field>,<Data>

SBUS<sb>:I3C:FILTer:DMAx? <Data>

SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:DMAx <Data_Max>

Sets the end value of a data pattern range if the operator is set to INRange or OORANGE.

You can set the operator with [SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:DOperator](#).

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 558

SBUS<sb>:I3C:FILTer:DMin <Frame>,<Field>,<Data>

SBUS<sb>:I3C:FILTer:DMin? <Data>

SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:DMin <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage:

Asynchronous command

Manual operation:See ["Edit"](#) on page 558**SBUS<sb>:I3C:FILTer:DOPerator** <Frame>,<Field>,<Operator>**SBUS<sb>:I3C:FILTer:DOPerator?** <Operator>**SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:DOPerator** <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange

*RST: EQUal

Usage:

Asynchronous command

Manual operation:See ["Edit"](#) on page 558**SBUS<sb>:I3C:FILTer:ERENable** <ErrorName>,<Enabler>**SBUS<sb>:I3C:FILTer:ERENable?** <Enabler>**SBUS<sb>:I3C:FILTer:ERRor<n>:ENABLe** <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage:

Asynchronous command

Manual operation:See ["Error type"](#) on page 560**SBUS<sb>:I3C:FILTer:IMAX** <Frame>,<Field>,<Data>**SBUS<sb>:I3C:FILTer:IMAX?** <Data>**SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:IMAX** <Index_Max>

Sets the end value of an index range if the operator is set to INRange.

You can set the operator with [SBUS<sb>:I3C:FILTer:IOperator](#).

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:**

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 558**SBUS<sb>:I3C:FILTer:IMIN** <Frame>,<Field>,<Data>**SBUS<sb>:I3C:FILTer:IMIN?** <Data>**SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:IMIN** <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:**

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 558**SBUS<sb>:I3C:FILTer:IOPerator** <Frame>,<Field>,<Operator>**SBUS<sb>:I3C:FILTer:IOPerator?** <Operator>**SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:IOPerator** <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:**

<Index_Operator> EQUAL | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 558

SBUS<sb>:I3C:FILTer:BIT <Frame>,<Field>,<Bit>

SBUS<sb>:I3C:FILTer:BIT? <Bit>

SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO

*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 558

SBUS<sb>:I3C:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:I3C:FILTer:FIENable? <Enabler>

SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 558

18.18.5.3 Software trigger

There are two commands for each parameter, that you can use for defining the I3C settings.

For example, to set the *Frame type =WRITE > Field =Address >Data* value you can use one of the following commands:

- `TRIGger:SBSW:I3C:FRAMe1:FLD1:DMIN 01100`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `STRIGger:SBSW:I3C:DMIN "WRITe", "Address", 01100`
Defines the parameter by using the frame and field name.

TRIGger:SBSW:I3C:CHKall.....	1420
TRIGger:SBSW:I3C:CLR.....	1420
TRIGger:SBSW:I3C:INVert.....	1420
TRIGger:SBSW:I3C:RST.....	1421
TRIGger:SBSW:I3C:FRENable.....	1421
TRIGger:SBSW:I3C:FRAME<fr>:ENABLE.....	1421
TRIGger:SBSW:I3C:BIT.....	1421
TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:BIT.....	1421
TRIGger:SBSW:I3C:DMAX.....	1422
TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:DMAX.....	1422
TRIGger:SBSW:I3C:DMIN.....	1422
TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:DMIN.....	1422
TRIGger:SBSW:I3C:DOPerator.....	1422
TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:DOPerator.....	1422
TRIGger:SBSW:I3C:FIENable.....	1423
TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:ENABLE.....	1423
TRIGger:SBSW:I3C:IMAX.....	1423
TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:IMAX.....	1423
TRIGger:SBSW:I3C:IMIN.....	1424
TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:IMIN.....	1424
TRIGger:SBSW:I3C:IOperator.....	1424
TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:IOperator.....	1424
TRIGger:SBSW:I3C:ERENable.....	1424
TRIGger:SBSW:I3C:ERRor<m>:ENABLE.....	1424
SBUS<sb>:I3C:SWTIndex?.....	1425
SBUS<sb>:I3C:SWTTime?.....	1425

TRIGger:SBSW:I3C:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
 Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 561

TRIGger:SBSW:I3C:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
 Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 561

TRIGger:SBSW:I3C:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 561

TRIGger:SBSW:I3C:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 561

TRIGger:SBSW:I3C:FREnable <Frame>,<Enabler>

TRIGger:SBSW:I3C:FREnable? <Enabler>

TRIGger:SBSW:I3C:FRAME<fr>:ENABLE <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:
<fr> Index of the frame

Parameters:
<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 561

TRIGger:SBSW:I3C:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:I3C:BIT? <Bit>

TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:
<fr> Index of the frame

<fl> Index of the field

Parameters:
<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 561

TRIGger:SBSW:I3C:DMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:I3C:DMAX? <Data>

TRIGger:SBSW:I3C:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGe.

You can set the operator with **TRIGger:SBSW:I3C:FRAMe<fr>:FLD<fl>:DOPerator**.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max> List of comma-separated values

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 561

TRIGger:SBSW:I3C:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:I3C:DMIN? <Data>

TRIGger:SBSW:I3C:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min> List of comma-separated values

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 561

TRIGger:SBSW:I3C:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:I3C:DOPerator? <Operator>

TRIGger:SBSW:I3C:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUAL | NEQUAL | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUAL

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 561

TRIGger:SBSW:I3C:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:I3C:FIENable? <Enabler>

TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 561

TRIGger:SBSW:I3C:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:I3C:IMAX? <Data>

TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with [TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:IOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 561

TRIGger:SBSW:I3C:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:I3C:IMIN? <Data>

TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 561

TRIGger:SBSW:I3C:IOperator <Frame>,<Field>,<Operator>

TRIGger:SBSW:I3C:IOperator? <Operator>

TRIGger:SBSW:I3C:FRAME<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 561

TRIGger:SBSW:I3C:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:I3C:ERENable? <Enabler>

TRIGger:SBSW:I3C:ERROR<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> Index of the error

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 563

SBUS<sb>:I3C:SWTIndex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:I3C:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

18.18.5.4 Decode results

SBUS<sb>:I3C:FCOut?	1426
SBUS<sb>:I3C:FRAMe<fr>:ADDRess?	1426
SBUS<sb>:I3C:FRAMe<fr>:ASTart?	1426
SBUS<sb>:I3C:FRAMe<fr>:FLDCount?	1427
SBUS<sb>:I3C:FRAMe<fr>:BITRate?	1427
SBUS<sb>:I3C:FRAMe<fr>:DATA?	1427
SBUS<sb>:I3C:FRAMe<fr>:RWBStart?	1428
SBUS<sb>:I3C:FRAMe<fr>:START?	1428
SBUS<sb>:I3C:FRAMe<fr>:STATus?	1428
SBUS<sb>:I3C:FRAMe<fr>:STOP?	1429
SBUS<sb>:I3C:FRAMe<fr>:SYMBol?	1429
SBUS<sb>:I3C:FRAMe<fr>:ACK?	1430
SBUS<sb>:I3C:FRAMe<fr>:ACKStart?	1430
SBUS<sb>:I3C:FRAMe<fr>:FLD<fl>:FVALue?	1430
SBUS<sb>:I3C:FRAMe<fr>:FLD<fl>:LABel?	1431
SBUS<sb>:I3C:FRAMe<fr>:FLD<fl>:STATe?	1431

SBUS<sb>:I3C:FRAMe<fr>:FLD<fl>:VALue?	1432
SBUS<sb>:I3C:FRAMe<fr>:COMMand?	1432
SBUS<sb>:I3C:FRAMe<fr>:CRC?	1432
SBUS<sb>:I3C:FRAMe<fr>:FADDress?	1432
SBUS<sb>:I3C:FRAMe<fr>:FCOMmand?	1433
SBUS<sb>:I3C:FRAMe<fr>:FCRC?	1433
SBUS<sb>:I3C:FRAMe<fr>:RWBit?	1433
SBUS<sb>:I3C:FRAMe<fr>:TYPE?	1434

SBUS<sb>:I3C:FCOut?

Returns the number of decoded frames.

Suffix:

<sb> 1 to 4, index of the serial bus
Selects the serial bus.

Return values:

<Count> Total number of decoded frames.

Usage:

Query only
Asynchronous command

SBUS<sb>:I3C:FRAMe<fr>:ADDRes?

Returns the device address value of the indicated frame. That is, the address value that is shown in the decoded cells and in the decode results table.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<AddressValue> Range: 0 to 65535
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:I3C:FRAMe<fr>:AStart?

Returns the start time of the address for the indicated frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<AddressStart> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

SBUS<sb>:I3C:FRAMe<fr>:FLDCount?

Returns the number of fields in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<Count>

Usage:

Query only
 Asynchronous command

SBUS<sb>:I3C:FRAMe<fr>:BITRate?

Returns the primary bit rate.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<BitRate> Increment: 1
 *RST: 0
 Default unit: bps

Usage:

Query only
 Asynchronous command

SBUS<sb>:I3C:FRAMe<fr>:DATA?

Returns the data words of the specified frame in comma-separated values.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<Count>
 <Values>

Example: BUS:I3C:FRAME4:DATA?
<-- 3,74,164,18

Usage: Query only
Asynchronous command

SBUS<sb>:I3C:FRAME<fr>:RWBStart?

Returns the start time of the R/W bit

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:
<RWBitStart> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:I3C:FRAME<fr>:START?

Returns the start time of the specified frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:
<FrameStart> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:I3C:FRAME<fr>:STATUs?

Returns the overall state of the frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:
<FrameState> OK | ACK | PAR | CRC | LENGTH | UNKNown | INComplete

OK

The frame is valid.

ACK

Wrong acknowledgment (ACK) delimiter occurred.

PAR

Wrong parity detected.

CRC

Cyclic redundancy check failed.

LENGth

Wrong length of frame.

UNKNown

Unknown frame type detected.

INComplete

The frame is not completely contained in the acquisition. The acquired part of the frame is usually valid, but cannot always be trusted.

*RST: OK

Usage:

Query only

Asynchronous command

SBUS<sb>:I3C:FRAMe<fr>:STOP?

Returns the end time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only

Asynchronous command

SBUS<sb>:I3C:FRAMe<fr>:SYMBol?

Returns the symbolic label of the specified frame if the label list is enabled.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Translation> String with the symbolic name of the frame

Usage: Query only
Asynchronous command

SBUS<sb>:I3C:FRAMe<fr>:ACK?

Returns the value of the acknowledge bit for the selected frame. Because this ACK bit is transmitted right after the address field, it acknowledges receiving the address.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <AckBitValue> ACK | NACK | EITHer
 *RST: EITHer

Usage: Query only
Asynchronous command

SBUS<sb>:I3C:FRAMe<fr>:ACKStart?

Returns the start time of the acknowledge bit for the selected frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <AckBitStart> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:I3C:FRAMe<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified field for the selected frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Return values:
 <FormattedValue>

Usage: Query only
Asynchronous command

SBUS<sb>:I3C:FRAME<fr>:FLD<fl>:LABel?

Returns the name (label) of the specified field in the selected frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Return values:

<Label>

Usage:

Query only
Asynchronous command

SBUS<sb>:I3C:FRAME<fr>:FLD<fl>:STATe?

Returns the overall state of the specified field for the selected frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Return values:

<State> OK | ACK | PAR | CRC | LENGth | UNKNown | INComplete

OK

The field has no error, it is valid.

ACK

Wrong acknowledgment (ACK) delimiter occurred.

PAR

Wrong parity detected.

CRC

Cyclic redundancy check failed.

LENGth

Wrong length of the field.

UNKNown

Unknown field type detected.

INComplete

The field is not completely contained in the acquisition. The acquired part of the field is usually valid, but cannot always be trusted.

*RST: OK

Usage:

Query only
Asynchronous command

SBUS<sb>:I3C:FRAMe<fr>:FLD<fl>:VALue?

Returns the data value of the specified field.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Return values:

<Value>	Increment: 1
	*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:I3C:FRAMe<fr>:COMManD?

Returns the selected frame's command response, which is an integer.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame

Return values:

<Response>	Range: 0 to 65535
	Increment: 1
	*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:I3C:FRAMe<fr>:CRC?

Returns the cyclic redundancy check (CRC) checksum of the selected frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame

Return values:

<CRCValue>	Range: 0 to 65535
	Increment: 1
	*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:I3C:FRAMe<fr>:FADDDress?

Returns the formatted address for the selected frame.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Return values:****<FormattedAddrVal>****Usage:**

Query only

Asynchronous command

SBUS<sb>:I3C:FRAME<fr>:FCOMmand?

Returns the formatted command from the selected frame.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Return values:****<FormattedCmd>****Usage:**

Query only

Asynchronous command

SBUS<sb>:I3C:FRAME<fr>:FCRC?

Returns the formatted CRC value for the selected frame.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Return values:****<FormattedCRCVal>****Usage:**

Query only

Asynchronous command

SBUS<sb>:I3C:FRAME<fr>:RWBit?

Returns the value of the R/W bit of the selected frame. The value "0" denotes "Write", the value "1" denotes "Read".

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Return values:****<RWBitValue>** UNDEFINED | READ | WRITE | EITHER***RST:** UNDEFINED

Usage: Query only
Asynchronous command

SBUS<sb>:I3C:FRAMe<fr>:TYPE?

Returns the frame type of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<FrameType> UNKNown | PROB | READ | WRIT | BRDC | DRCT | HDDR | HTSX
*RST: UNKNown

Usage: Query only
Asynchronous command

18.18.6 UART / RS-232 (option R&S MXO5C- K510)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with [SBUS<sb>\[:STATe\]](#).
- The bus is set to the correct type with [SBUS<sb>:TYPE](#).

• Configuration	1434
• Filter	1440
• Hardware trigger	1445
• Software trigger	1447
• Decode results	1453

18.18.6.1 Configuration

SBUS<sb>:UART:BITRate	1435
SBUS<sb>:UART:BORDER	1435
SBUS<sb>:UART:PACKets	1435
SBUS<sb>:UART:PARity	1436
SBUS<sb>:UART:POLarity	1436
SBUS<sb>:UART:RX:HYSTeresis	1436
SBUS<sb>:UART:RX:SOURce	1437
SBUS<sb>:UART:RX:THReshold	1437
SBUS<sb>:UART:SBIT	1437
SBUS<sb>:UART:SSIZe	1437
SBUS<sb>:UART:TOUT	1438
SBUS<sb>:UART:TX:HYSTeresis	1438
SBUS<sb>:UART:TX:SOURce	1438
SBUS<sb>:UART:TX:THReshold	1439
SBUS<sb>:UART:RX:POSition	1439

SBUS<sb>:UART:RX:SCALE.....	1439
SBUS<sb>:UART:TX:POSition.....	1439
SBUS<sb>:UART:TX:SCALE.....	1440

SBUS<sb>:UART:BITRate <Bitrate>

Sets the number of transmitted bits per second.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Bitrate> Range: 300 to 20000000
Increment: 1
*RST: 9600
Default unit: bps

Usage: Asynchronous command

Manual operation: See "[Bit rate](#)" on page 571

SBUS<sb>:UART:BORDER <BitOrder>

Selects the bit order, which determines if the data of the messages starts with MSB (most significant bit) or LSB (least significant bit).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<BitOrder> LSBF | MSBF
*RST: LSBF

Usage: Asynchronous command

Manual operation: See "[Bit order](#)" on page 571

SBUS<sb>:UART:PACKets <FrmSeparation>

Defines the method of packet separation. A packet is a number of subsequent words in a data stream.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<FrmSeparation> NONE | TOUT

NONE

Packets are not considered.

TOUT

Defines a timeout between the packets. To set the timeout, use [SBUS<sb>:UART:TOUT](#).

*RST: TOUT

Usage: Asynchronous command
Manual operation: See "[Packets](#)" on page 572

SBUS<sb>:UART:PARity <Parity>

Defines the optional parity bit that is used for error detection.

Suffix:
 <sb> 1 to 4, index of the serial bus

Parameters:
 <Parity> NONE | ODD | EVEN | MARK | SPC | DC

MARK
 The parity bit is always a logic 1.

SPC
 SPaCe: The parity bit is always a logic 0.

DC
 Do not care: the parity is ignored.

*RST: NONE

Usage: Asynchronous command
Manual operation: See "[Parity](#)" on page 571

SBUS<sb>:UART:POLarity <Polarity>

Defines the logic levels of the bus. The idle state corresponds to a logic 1. The start bit corresponds to a logic 0. "Idle high" (high=1) is used, for example, for control signals, while "Idle low" (low=1) is defined for data lines (RS-232).

Suffix:
 <sb> 1 to 4, index of the serial bus

Parameters:
 <Polarity> IDLLow | IDLHigh

*RST: IDLHigh

Usage: Asynchronous command
Manual operation: See "[Polarity](#)" on page 571

SBUS<sb>:UART:RX:HYSTeresis <Rx hysteresis>

Sets the hysteresis for the Tx line.

Suffix:
 <sb> 1 to 4, index of the serial bus

Parameters:
 <Rx hysteresis>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 572

SBUS<sb>:UART:RX:SOURce <RxSource>

Selects the input channel for the receiver signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<RxSource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["Source: Tx, Rx"](#) on page 571

SBUS<sb>:UART:RX:THReshold <Rx threshold>

Sets a user-defined threshold value for the Rx line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Rx threshold>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 572

SBUS<sb>:UART:SBIT <StopBits>

Sets the number of stop bits: 1 or 1.5 or 2 stop bits are possible.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<StopBits> B1 | B15 | B2
*RST: B1

Usage: Asynchronous command

Manual operation: See ["Stop bits"](#) on page 571

SBUS<sb>:UART:SSIZe <DataBits>

Sets the number of data bits of a word in a range from 5 bits to 8 bits. If no parity bit is used, then 9 data bits are possible.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DataBits> Range: 5 to 9
Increment: 1
*RST: 8

Usage:

Asynchronous command

Manual operation: See ["Data bits"](#) on page 571

SBUS<sb>:UART:TOUT <Timeout>

Sets the timeout between packets in a UART data stream. A new packet starts with the first start bit after the timeout.

The command is relevant if [SBUS<sb>:UART:PACKets](#) is set to TOUT.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Timeout> Range: 1E-06 to 1
Increment: 1
*RST: 0.000625
Default unit: s

Usage:

Asynchronous command

Manual operation: See ["Packets"](#) on page 572

SBUS<sb>:UART:TX:HYSTeresis <Tx hysteresis>

Sets the hysteresis for the TX line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Tx hysteresis>

Usage:

Asynchronous command

Manual operation: See ["Threshold"](#) on page 572

SBUS<sb>:UART:TX:SOURce <TxSource>

Selects the input channel for the transmitter signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<TxSource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
 | D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
 | M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
 R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["Source: Tx, Rx"](#) on page 571

SBUS<sb>:UART:TX:THReshold <Tx threshold>

Sets a user-defined threshold value for the Tx line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Tx threshold> User-defined clock threshold

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 572

SBUS<sb>:UART:RX:POSition <Rx position>

Sets the vertical position of the RX UART signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Rx position>

Usage: Asynchronous command

SBUS<sb>:UART:RX:SCALe <Rx scale>

Set the vertical scale of the RX UART signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Rx scale>

Usage: Asynchronous command

SBUS<sb>:UART:TX:POSition <Tx position>

Sets the vertical position of the TX UART signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Tx position>

Usage:

Asynchronous command

SBUS<sb>:UART:TX:SCALE <Tx scale>

Set the vertical scale of the TX UART signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Tx scale>

Usage:

Asynchronous command

18.18.6.2 Filter

There are two commands for each parameter, that you can use for defining the UART settings.

For example, to set the *Frame type =Tx > Field =Data >01100* value you can use one of the following commands:

- SBUS:UART:FILTer:FRAMe1:FLD1:DMIN 01100
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- SBUS:UART:FILTer:DMIN "Tx", "Data", 01100
Defines the parameter by using the frame and field name.

SBUS<sb>:UART:FILTer:CHKall.....	1441
SBUS<sb>:UART:FILTer:CLR.....	1441
SBUS<sb>:UART:FILTer:INVert.....	1441
SBUS<sb>:UART:FILTer:RST.....	1441
SBUS<sb>:UART:FILTer:IMIN.....	1442
SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1442
SBUS<sb>:UART:FILTer:IMAX.....	1442
SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1442
SBUS<sb>:UART:FILTer:IOperator.....	1442
SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:IOperator.....	1442
SBUS<sb>:UART:FILTer:ERENable.....	1443
SBUS<sb>:UART:FILTer:ERRor<n>:ENABLE.....	1443
SBUS<sb>:UART:FILTer:DOPerator.....	1443
SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1443
SBUS<sb>:UART:FILTer:DMIN.....	1443
SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1443
SBUS<sb>:UART:FILTer:DMAX.....	1444
SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1444
SBUS<sb>:UART:FILTer:BIT.....	1444
SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1444
SBUS<sb>:UART:FILTer:FRENable.....	1445

SBUS<sb>:UART:FILTer:FRAMe<fr>:ENABle.....	1445
SBUS<sb>:UART:FILTer:FIENable.....	1445
SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1445

SBUS<sb>:UART:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 574

SBUS<sb>:UART:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 574

SBUS<sb>:UART:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 574

SBUS<sb>:UART:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 574

SBUS<sb>:UART:FILTer:IMIN <Frame>,<Field>,<Data>

SBUS<sb>:UART:FILTer:IMIN? <Data>

SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
Increment: 1
*RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 574

SBUS<sb>:UART:FILTer:IMAX <Frame>,<Field>,<Data>

SBUS<sb>:UART:FILTer:IMAX? <Data>

SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range if the operator is set to INRange.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
Increment: 1
*RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 574

SBUS<sb>:UART:FILTer:IOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:UART:FILTer:IOPerator? <Operator>

SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator>	EQUAL INRange RANGE
*RST:	INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 574

SBUS<sb>:UART:FILTER:ERENable <ErrorName>,<Enabler>

SBUS<sb>:UART:FILTER:ERENable? <Enabler>

SBUS<sp>:UART:FILTER:ERROR<n>:ENABLE <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

$\langle n \rangle$ Index of the error

Parameters:

<Enable>	OFF ON
*RST:	ON

Usage: Asynchronous command

Manual operation: See "Error type" on page 575

SBUS<sb>:UART:FILTer:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:UART:FILTer:DOPerator? <Operator>

SBUS<sb>:UART:FiLTer:FRAME<fr>:FLD<fl>:DOPerator <Data Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<code><fr></code>	Index of the frame

<fl>	Index of the field

Parameters:

```
<Data_Operator>   EQUal | NEQual | LTHan | LETHan | GTHan | GETHan |
                   INRange | OORange
                   *RST:   EQUal
```

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 574

SBUS<sb>:UART:FILTER:DMIN <Frame>,<Field>,<Data>

SBUS<sb>:UART:FILTER:DMIN? <Data>

SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:DMIN <Data Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb>	1..4 Selects the serial bus.
<fr>	* Specifies the frame number.
<fl>	* Specifies the field number within the frame.

Parameters:

<Data_Min>

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 574**SBUS<sb>:UART:FILTer:DMAX <Frame>,<Field>,<Data>****SBUS<sb>:UART:FILTer:DMAX? <Data>****SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>**

Sets the end value of a data pattern range if the operator is set to `INRange` or `OORANGE`.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 574**SBUS<sb>:UART:FILTer:BIT <Frame>,<Field>,<Bit>****SBUS<sb>:UART:FILTer:BIT? <Bit>****SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:BIT <BitState>**

Sets the bit state of a field that only consists of one bit.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Parameters:

<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 574

SBUS<sb>:UART:FILTer:FRENAble <Frame>,<Enabler>

SBUS<sb>:UART:FILTer:FRENAble? <Enabler>

SBUS<sb>:UART:FILTer:FRAME<fr>:ENABLe <Enable>

Enables or disables the checking condition for the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 574

SBUS<sb>:UART:FILTer:FIENABLe <Frame>,<Field>,<Enabler>

SBUS<sb>:UART:FILTer:FIENABLe? <Enabler>

SBUS<sb>:UART:FILTer:FRAME<fr>:FLD<fl>:ENABLe <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 574

18.18.6.3 Hardware trigger

Trigger commands for serial buses affect the current trigger source. Therefore, set the trigger source to the required serial bus with [TRIGger:EVENT<ev>:SOURce](#) before sending the bus-specific trigger commands.

TRIGger:SBHW:UART:DATA	1446
TRIGger:SBHW:UART:DPOStion	1446
TRIGger:SBHW:UART:FCONdition	1446
TRIGger:SBHW:UART:OPERator	1446
TRIGger:SBHW:UART:SOURce	1446
TRIGger:SBHW:UART:TYPE	1447

TRIGger:SBHW:UART:DATA <DataPattern>

Specifies the data pattern to be found on the specified trigger source. Enter the words in MSB first bit order.

Parameters:

<DataPattern>

Usage: Asynchronous command

Manual operation: See "[Value](#)" on page 576

TRIGger:SBHW:UART:DPOStion <DataPosition>

Sets the number of words before the first word of interest. These offset words are ignored.

Parameters:

<DataPosition> Range: 1 to 4096
Increment: 1
*RST: 1

Usage: Asynchronous command

Manual operation: See "[Position](#)" on page 576

TRIGger:SBHW:UART:FCONdition <DataOperator>

Selects the operator for the "Data" pattern.

Parameters:

<DataOperator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan
*RST: EQUal

Usage: Asynchronous command

Manual operation: See "[Data](#)" on page 576

TRIGger:SBHW:UART:OPERator <DataOperator>

Sets the operator for the data pattern in the selected field of the selected frame.

Parameters:

<DataOperator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan
*RST: EQUal

Usage: Asynchronous command

TRIGger:SBHW:UART:SOURce <Source>

Selects the transmitter or receiver line as trigger source.

Parameters:

<Source> TX | RX
 *RST: TX

Usage: Asynchronous command

TRIGger:SBHW:UART:TYPE <Type>

Selects the trigger type condition.

Parameters:

<Type> STBT | PCKS | DATA | PRER | BRKC | STPerror
 STBT: Start bit
 PCKS: Packet start
 DATA: Serial pattern
 PRER: Parity error
 BRKC: Break condition
 STPerror: Stop error
 *RST: STBT

Usage: Asynchronous command

18.18.6.4 Software trigger

There are two commands for each parameter, that you can use for defining the UART settings.

For example, to set the *Frame type =Tx > Field =Data >01100* value you can use one of the following commands:

- **TRIGger:SBSW:UART:FRAME1:FLD1:DMIN 01100**
 Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- **TRIGger:SBSW:UART:DMIN "Tx", "Data", 01100**
 Defines the parameter by using the frame and field name.

TRIGger:SBSW:UART:CHKall.....	1448
TRIGger:SBSW:UART:CLR.....	1448
TRIGger:SBSW:UART:INVert.....	1448
TRIGger:SBSW:UART:RST.....	1448
TRIGger:SBSW:UART:FRENable.....	1449
TRIGger:SBSW:UART:FRAME<fr>:ENABLE.....	1449
TRIGger:SBSW:UART:BIT.....	1449
TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:BIT.....	1449
TRIGger:SBSW:UART:DMAX.....	1449
TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:DMAX.....	1449
TRIGger:SBSW:UART:DMIN.....	1450
TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:DMIN.....	1450
TRIGger:SBSW:UART:DOPerator.....	1450
TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:DOPerator.....	1450
TRIGger:SBSW:UART:FIENable.....	1450

TRIGger:SBSW:UART:FRAMe<fr>:FLD<fl>:ENABle.....	1450
TRIGger:SBSW:UART:IMAX.....	1451
TRIGger:SBSW:UART:FRAMe<fr>:FLD<fl>:IMAX.....	1451
TRIGger:SBSW:UART:IMIN.....	1451
TRIGger:SBSW:UART:FRAMe<fr>:FLD<fl>:IMIN.....	1451
TRIGger:SBSW:UART:IOPerator.....	1452
TRIGger:SBSW:UART:FRAMe<fr>:FLD<fl>:IOPerator.....	1452
TRIGger:SBSW:UART:ERENable.....	1452
TRIGger:SBSW:UART:ERRor<m>:ENABle.....	1452
SBUS<sb>:UART:SWTIndex?.....	1452
SBUS<sb>:UART:SWTTime?.....	1453

TRIGger:SBSW:UART:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all](#), [Clear](#), [Invert](#), [Preset](#)" on page 577

TRIGger:SBSW:UART:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all](#), [Clear](#), [Invert](#), [Preset](#)" on page 577

TRIGger:SBSW:UART:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all](#), [Clear](#), [Invert](#), [Preset](#)" on page 577

TRIGger:SBSW:UART:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all](#), [Clear](#), [Invert](#), [Preset](#)" on page 577

TRIGger:SBSW:UART:FRENable <Frame>,<Enabler>

TRIGger:SBSW:UART:FRENable? <Enabler>

TRIGger:SBSW:UART:FRAME<fr>:ENABLE <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 578

TRIGger:SBSW:UART:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:UART:BIT? <Bit>

TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO

*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 578

TRIGger:SBSW:UART:DMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:UART:DMAX? <Data>

TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGE.

You can set the operator with [TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:DOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 578

TRIGger:SBSW:UART:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:UART:DMIN? <Data>

TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 578

TRIGger:SBSW:UART:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:UART:DOPerator? <Operator>

TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange
*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 578

TRIGger:SBSW:UART:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:UART:FIENable? <Enabler>

TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 578

TRIGger:SBSW:UART:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:UART:IMAX? <Data>

TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with [TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:IOperator](#).

Suffix:

<fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 578

TRIGger:SBSW:UART:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:UART:IMIN? <Data>

TRIGger:SBSW:UART:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 578

TRIGger:SBSW:UART:IOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:UART:IOPerator? <Operator>

TRIGger:SBSW:UART:FRAMe<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGe

*RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 578

TRIGger:SBSW:UART:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:UART:ERENable? <Enabler>

TRIGger:SBSW:UART:ERRor<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> Index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 579

SBUS<sb>:UART:SWTindex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295

Increment: 1

*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:UART:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

18.18.6.5 Decode results

SBUS<sb>:UART:WCOunt?	1453
SBUS<sb>:UART:WORD<w>:BITRate?	1453
SBUS<sb>:UART:WORD<w>:RXValue?	1454
SBUS<sb>:UART:WORD<w>:SOURce?	1454
SBUS<sb>:UART:WORD<w>:START?	1454
SBUS<sb>:UART:WORD<w>:STOP?	1455
SBUS<sb>:UART:WORD<w>:STATe?	1455
SBUS<sb>:UART:WORD<w>:TXValue?	1456

SBUS<sb>:UART:WCOunt?

Returns the number of words in the acquisition.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count> Total number of words.

Usage:

Query only
Asynchronous command

SBUS<sb>:UART:WORD<w>:BITRate?

Returns the primary bit rate.

Suffix:

<sb> 1 to 4, index of the serial bus

<w> Index of the word

Return values:

<PrimaryBitRate> Increment: 1
 *RST: 0
 Default unit: bps

Usage:

Query only
 Asynchronous command

SBUS<sb>:UART:WORD<w>:RXValue?

Returns the value of the specified word on the Rx line.

Suffix:

<sb> 1 to 4, index of the serial bus
 <w> Index of the word

Return values:

<RxValue> Range: 0 to 511
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

SBUS<sb>:UART:WORD<w>:SOURce?

Returns the line on which the specified word was transferred.

Suffix:

<sb> 1 to 4, index of the serial bus
 <w> Index of the word

Return values:

<WordSource> TX | RX
 *RST: TX

Usage:

Query only
 Asynchronous command

SBUS<sb>:UART:WORD<w>:START?

Returns the start time of the specified word.

Suffix:

<sb> 1 to 4, index of the serial bus
 <w> Index of the word

Return values:

<WordStart> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

SBUS<sb>:UART:WORD<w>:STOP?

Returns the stop time of the specified word.

Suffix:

<sb> 1 to 4, index of the serial bus
 <w> Index of the word

Return values:

<WordStop> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

SBUS<sb>:UART:WORD<w>:STATe?

Returns the status of the specified word.

Suffix:

<sb> 1 to 4, index of the serial bus
 <w> Index of the word

Return values:

<WordState> OK | BREak | STERror | SPERror | PRERror | INComplete
 OK: the frame is valid.
 BREak: stop bit error with 0x00 word
 STERror: start error, incorrect start bit
 SPERror: stop error, incorrect stop bit
 PRERror: parity error, incorrect parity bit.
 INComplete: The frame is not completely contained in the acquisition. The acquired part of the frame is valid.
 *RST: OK

Usage:

Query only
 Asynchronous command

SBUS<sb>:UART:WORD<w>:TXValue?

Returns the value of the specified word on the TX line.

Suffix:

<sb> 1 to 4, index of the serial bus
 <w> Index of the word

Return values:

<TxValue> Range: 0 to 511
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

18.18.7 NRZ Clocked (option R&S MXO5C-K510)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with [SBUS<sb>\[:STATE\]](#).
- The bus is set to the correct type with [SBUS<sb>:TYPE](#).

• Configuration	1456
• Filter	1461
• Frame format	1467
• Software trigger	1473
• Decode results	1479

18.18.7.1 Configuration

SBUS<sb>:NRZC:CLK:SOURce	1457
SBUS<sb>:NRZC:CLK:POLarity	1457
SBUS<sb>:NRZC:DATA:SOURce	1457
SBUS<sb>:NRZC:DATA:POLarity	1458
SBUS<sb>:NRZC:ENABLE:SOURce	1458
SBUS<sb>:NRZC:ENABLE:POLarity	1458
SBUS<sb>:NRZC:MINGap:SElect	1459
SBUS<sb>:NRZC:MINGap:WIDTh	1459
SBUS<sb>:NRZC:CLK:THReshold	1459
SBUS<sb>:NRZC:CLK:HYSteresis	1460
SBUS<sb>:NRZC:DATA:THReshold	1460
SBUS<sb>:NRZC:DATA:HYSteresis	1460
SBUS<sb>:NRZC:ENABLE:THReshold	1460
SBUS<sb>:NRZC:ENABLE:HYSteresis	1461
SBUS<sb>:NRZC:POSition	1461
SBUS<sb>:NRZC:SCALE	1461

SBUS<sb>:NRZC:CLK:SOURce Source

Selects the source for the clock signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

Source C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["Clock source"](#) on page 585

SBUS<sb>:NRZC:CLK:POLarity <CLKPolarity>

Sets the polarity for the data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<CLKPolarity> RISE | FALL | BOTH

RISE

Data is sampled at the rising edges of the clock signal.

FALL

Data is sampled at the falling edges of the clock signal.

BOTH

Data is sampled at the rising and falling edges of the clock signal.

*RST: RISE

Usage: Asynchronous command

Manual operation: See ["Clock polarity"](#) on page 585

SBUS<sb>:NRZC:DATA:SOURce Source

Selects the channel for the data signal source.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

Source C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["Data source"](#) on page 585

SBUS<sb>:NRZC:DATA:POLarity <DATAPolarity>

Sets the polarity for the data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DATAPolarity> ACTLow | ACTHigh

ACTLow

The transmitted signal for the data line is active high (high = 1).

ACTHigh

The transmitted signal for the data line is active low (low = 1).

*RST: ACTHigh

Usage: Asynchronous command

Manual operation: See ["Data polarity"](#) on page 585

SBUS<sb>:NRZC:ENABLE:SOURce Source

Selects the channel for the enable signal source.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

Source C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2 | M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["Enable source"](#) on page 586

SBUS<sb>:NRZC:ENABLE:POLarity <ENABPolarity>

Sets the polarity for the enable line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ENABPolarity> ACTLow | ACTHigh

ACTLow

The transmitted signal for the enable line is active high (high = 1).

ACTHigh

The transmitted signal for the enable line is active low (low = 1).

*RST: ACTHigh

Usage: Asynchronous command

Manual operation: See ["Enable source"](#) on page 586

SBUS<sb>:NRZC:MINGap:SElect <MingapSelect>

Enables checking the minimum idle time between two frames during decoding.

To set the idle time, use the command [SBUS<sb>:NRZC:MINGap:WIDTh](#).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MingapSelect> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Check gap time"](#) on page 586

SBUS<sb>:NRZC:MINGap:WIDTh <MingapWidth>

Sets the minimum duration of the idle time. Any inactivity greater than this time is interpreted as a gap and leads to a resynchronization to the signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MingapWidth> Range: 1E-09 to 1

Increment: 1E-09

*RST: 1E-05

Default unit: s

Usage: Asynchronous command

Manual operation: See ["Check gap time"](#) on page 586

SBUS<sb>:NRZC:CLK:THReshold <CLKThreshold>

Sets the threshold value for the digitization of the clock signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<CLKThreshold>

Usage: Asynchronous command

Manual operation: See ["Clock threshold, Clock hysteresis"](#) on page 587

SBUS<sb>:NRZC:CLK:HYSTeresis <CLKHysteresis>

Sets a value for the hysteresis of the clock signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<CLKHysteresis>

Usage: Asynchronous command

Manual operation: See ["Clock threshold, Clock hysteresis"](#) on page 587

SBUS<sb>:NRZC:DATA:THReshold <SDAThreshold>

Sets the threshold for the data channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SDAThreshold>

Usage: Asynchronous command

Manual operation: See ["Data threshold, Data hysteresis"](#) on page 587

SBUS<sb>:NRZC:DATA:HYSTeresis <SDAHysteresis>

Sets the hysteresis for the data channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SDAHysteresis>

Usage: Asynchronous command

Manual operation: See ["Data threshold, Data hysteresis"](#) on page 587

SBUS<sb>:NRZC:ENABle:THReshold <ENABThreshold>

Sets the threshold for the enable channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ENABThreshold>

Usage: Asynchronous command

Manual operation: See ["Enable threshold, Enable hysteresis"](#) on page 587

SBUS<sb>:NRZC:ENABle:HYSTeresis <ENABHysteresis>

Sets the hysteresis for the enable channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ENABHysteresis>

Usage: Asynchronous command

Manual operation: See ["Enable threshold, Enable hysteresis"](#) on page 587

SBUS<sb>:NRZC:POSition <Position>

Sets the vertical position of the NRZ clocked signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Position>

Usage: Asynchronous command

SBUS<sb>:NRZC:SCALE <Scale>

Sets the vertical scale of the NRZ clocked signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Scale>

Usage: Asynchronous command

18.18.7.2 Filter

There are two commands for each parameter, that you can use for defining the NRZ clocked settings.

For example, to set the *Frame type =NRZC-Frame > Field =Data >Data* value you can use one of the following commands:

- SBUS:NRZC:FILTer:FRAMe1:FLD1:DMIN 01100
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- SBUS:NRZC:FILTer:DMIN "NRZC-Frame", "Data", 01100
Defines the parameter by using the frame and field name.

SBUS<sb>:NRZC:FILTer:CHKall.....	1462
SBUS<sb>:NRZC:FILTer:CLR.....	1462
SBUS<sb>:NRZC:FILTer:INVert.....	1462

SBUS<sb>:NRZC:FILTer:RST.....	1463
SBUS<sb>:NRZC:FILTer:BIT.....	1463
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1463
SBUS<sb>:NRZC:FILTer:ERENable.....	1463
SBUS<sb>:NRZC:FILTer:ERRor<n>:ENABLE.....	1463
SBUS<sb>:NRZC:FILTer:DMAX.....	1464
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1464
SBUS<sb>:NRZC:FILTer:DMIN.....	1464
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1464
SBUS<sb>:NRZC:FILTer:DOPerator.....	1464
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1464
SBUS<sb>:NRZC:FILTer:FIENable.....	1465
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:ENABLE.....	1465
SBUS<sb>:NRZC:FILTer:FRENable.....	1465
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:ENABLE.....	1465
SBUS<sb>:NRZC:FILTer:IMAX.....	1466
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1466
SBUS<sb>:NRZC:FILTer:IMIN.....	1466
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1466
SBUS<sb>:NRZC:FILTer:IOPerator.....	1466
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1466

SBUS<sb>:NRZC:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 589

SBUS<sb>:NRZC:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 589

SBUS<sb>:NRZC:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 589

SBUS<sb>:NRZC:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 589

SBUS<sb>:NRZC:FILTer:BIT <Frame>,<Field>,<Bit>**SBUS<sb>:NRZC:FILTer:BIT? <Bit>****SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:BIT <BitState>**

Sets the bit state of a field that only consists of one bit.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO
*RST: ZERO

Usage:

Asynchronous command

Manual operation: See ["Edit"](#) on page 590

SBUS<sb>:NRZC:FILTer:ERENable <ErrorName>,<Enabler>**SBUS<sb>:NRZC:FILTer:ERENable? <Enabler>****SBUS<sb>:NRZC:FILTer:ERRor<n>:ENABLE <Enable>**

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> index of the error

Parameters:

<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command
Manual operation: See ["Error type"](#) on page 592

SBUS<sb>:NRZC:FILTer:DMAX <Frame>,<Field>,<Data>
SBUS<sb>:NRZC:FILTer:DMAX? <Data>
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range if the operator is set to INRange or OORANGe.

You can set the operator with **SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:DOPerator**.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:
 <Data_Max>

Usage: Asynchronous command
Manual operation: See ["Edit"](#) on page 590

SBUS<sb>:NRZC:FILTer:DMIN <Frame>,<Field>,<Data>
SBUS<sb>:NRZC:FILTer:DMIN? <Data>
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:
 <Data_Min>

Usage: Asynchronous command
Manual operation: See ["Edit"](#) on page 590

SBUS<sb>:NRZC:FILTer:DOPerator <Frame>,<Field>,<Operator>
SBUS<sb>:NRZC:FILTer:DOPerator? <Operator>
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:
 <sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange
*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 590

SBUS<sb>:NRZC:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:NRZC:FILTer:FIENable? <Enabler>

SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 590

SBUS<sb>:NRZC:FILTer:FRENable <Frame>,<Enabler>

SBUS<sb>:NRZC:FILTer:FRENable? <Enabler>

SBUS<sb>:NRZC:FILTer:FRAMe<fr>:ENABLE <Enable>

Enables the filtering on NRZ clocked frames. Only the frames that match the selected filter conditions are displayed.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Enable"](#) on page 589

SBUS<sb>:NRZC:FILTer:IMAX <Frame>,<Field>,<Data>

SBUS<sb>:NRZC:FILTer:IMAX? <Data>

SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range if the operator is set to `INRange`.

You can set the operator with `SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:IOperator`.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
Increment: 1
*RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 590

SBUS<sb>:NRZC:FILTer:IMIN <Frame>,<Field>,<Data>

SBUS<sb>:NRZC:FILTer:IMIN? <Data>

SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
Increment: 1
*RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 590

SBUS<sb>:NRZC:FILTer:IOperator <Frame>,<Field>,<Operator>

SBUS<sb>:NRZC:FILTer:IOperator? <Operator>

SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGE
*RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 590

18.18.7.3 Frame format

This section describes the commands to specify and query frame formats for the "NRZ Clocked" protocol.

For manual operation, refer to [Section 14.7.4, "NRZ frame format configuration"](#), on page 592.

SBUS<sb>:NRZC:FORMat:ADDFrame.....	1467
SBUS<sb>:NRZC:FORMat:LOAD.....	1467
SBUS<sb>:NRZC:FORMat:SAVE.....	1468
SBUS<sb>:NRZC:FORMat:CLR.....	1468
SBUS<sb>:NRZC:FORMat:FCOunt?.....	1468
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:ADDField.....	1469
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLDCount?.....	1469
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:NAME.....	1469
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:COLor.....	1469
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:NAME.....	1470
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:COLor.....	1470
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:BITCount.....	1470
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:CONDition.....	1471
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:FORMat.....	1471
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:BITOrder.....	1472
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:CLMN.....	1472

SBUS<sb>:NRZC:FORMat:ADDFrame

Appends a new frame description to the frame list.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Add Frame"](#) on page 594

SBUS<sb>:NRZC:FORMat:LOAD <FileName>

Loads a the specified XML file with a list of frame descriptions.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName>

Usage: Setting only
Asynchronous command

Manual operation: See ["Open"](#) on page 595

SBUS<sb>:NRZC:FORMat:SAVE <FileName>

Saves the current list of frame descriptions to an XML file with the specified name.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName>

Usage: Setting only
Asynchronous command

Manual operation: See ["Save as"](#) on page 595

SBUS<sb>:NRZC:FORMat:CLR

Erases from the volatile memory all field and frame format descriptions that you have created for a specific custom protocol.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage: Setting only
Asynchronous command

Manual operation: See ["Edit List"](#) on page 594

SBUS<sb>:NRZC:FORMat:FCOut?

Returns the number of frame format descriptions available for a specific custom protocol.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count>

Usage: Query only
Asynchronous command

Manual operation: See ["Edit List"](#) on page 594

SBUS<sb>:NRZC:FORMat:FRAMe<fr>:ADDField

Appends a new field description to the selected frame description.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Usage:

Setting only

Asynchronous command

Manual operation: See ["Add Field"](#) on page 595

SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLDCount?

Returns the number of field descriptions available for the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Count>

Usage:

Query only

Asynchronous command

Manual operation: See ["Edit List"](#) on page 596

SBUS<sb>:NRZC:FORMat:FRAMe<fr>:NAME <Name>

Specifies the name for the frame description of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Name>

Usage:

Asynchronous command

Manual operation: See ["Frame name"](#) on page 596

SBUS<sb>:NRZC:FORMat:FRAMe<fr>:COLor <Color>

Specifies the color for the frame description of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Color> Use 32-bit RGB encoding in decimal format.
 Range: 0 to 4294967295
 Increment: 1
 *RST: 4278255615

Usage: Asynchronous command

Manual operation: See ["Frame Color"](#) on page 597

SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:NAME <Name>

Specifies the name for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Name>

Usage: Asynchronous command

Manual operation: See ["Field name"](#) on page 597

SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:COLor <Color>

Specifies the color for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Color> Use 32-bit RGB encoding in decimal format.
 Range: 0 to 4294967295
 Increment: 1
 *RST: 4294967040

Usage: Asynchronous command

Manual operation: See ["Field Color"](#) on page 597

SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:BITCount <BitCount>

Specifies the bit count, hence length, of the selected field in the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitCount> Range: 1 to 64
Increment: 1
*RST: 1

Usage: Asynchronous command

Manual operation: See ["Bit count"](#) on page 597

SBUS<sb>:NRZC:FORMat:FRAME<fr>:FLD<fl>:CONDition <Condition>

Specifies a user-defined condition operator for the selected field of the selected frame. The various condition operators can identify, for example, a mandatory CRC checksum value or a frame ID.

Set the numeric format of the condition by the command [SBUS<sb>:NRZC:FORMat:FRAME<fr>:FLD<fl>:FORMat](#).

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Condition> The implemented conditions are the "equal" and "array" operators.

Usage: Asynchronous command

Manual operation: See ["Condition"](#) on page 598

SBUS<sb>:NRZC:FORMat:FRAME<fr>:FLD<fl>:FORMat <NumericFormat>

Specifies the numerical format for the condition value of the selected field in the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<NumericFormat> HEX | OCT | BIN | ASCII | ASCii | SIGN | USIG | DEC | LIST | FLIN

DEC

Decimal format

HEX

Hexadecimal format

OCT

Octal format

BIN

Binary format

*RST: HEX

Usage: Asynchronous command**Manual operation:** See ["Numeric format"](#) on page 600**SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:BITorder <BitOrder>**

Specifies, in which order the algorithm evaluates the bits of the condition value of the selected field in the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitOrder> LSBF | MSBF

LSBF

Least significant bit first

MSBF

Most significant bit first

*RST: MSBF

Usage: Asynchronous command**Manual operation:** See ["Bit order"](#) on page 601**SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:CLMN <Column>**

Specifies, in which result column of the decode table to display the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Column> NONE | COL1 | COL2 | COL3

NONE

The result is not displayed.

COL1

The result is displayed in column 1.

COL2

The result is displayed in column 2.

COL3

The result is displayed in column 3.

*RST: NONE

Usage: Asynchronous command

Manual operation: See ["Result column"](#) on page 601

18.18.7.4 Software trigger

There are two commands for each parameter that you can use for defining the "NRZ Clocked" settings.

For example, to set the *Frame type =NRZC-Frame > Field =Data >Data* value you can use one of the following commands:

- TRIGger:SBSW:NRZC:FRAMe1:FLD1:DMIN 01100
Defines the parameter by using the index <fr> for the frame number and <fl> for the field number.
- TRIGger:SBSW:NRZC:DMIN "NRZC-Frame", "Data", 01100
Defines the parameter by using the frame and field name.

TRIGger:SBSW:NRZC:CHKall.....	1474
TRIGger:SBSW:NRZC:CLR.....	1474
TRIGger:SBSW:NRZC:INVert.....	1474
TRIGger:SBSW:NRZC:RST.....	1474
TRIGger:SBSW:NRZC:FRENable.....	1474
TRIGger:SBSW:NRZC:FRAMe<fr>:ENABle.....	1474
TRIGger:SBSW:NRZC:BIT.....	1475
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:BIT.....	1475
TRIGger:SBSW:NRZC:DMAX.....	1475
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:DMAX.....	1475
TRIGger:SBSW:NRZC:DMIN.....	1475
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:DMIN.....	1475
TRIGger:SBSW:NRZC:DOPerator.....	1476
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:DOPerator.....	1476
TRIGger:SBSW:NRZC:FIENable.....	1476
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:ENABle.....	1476
TRIGger:SBSW:NRZC:IMAX.....	1476
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:IMAX.....	1476
TRIGger:SBSW:NRZC:IMIN.....	1477
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:IMIN.....	1477
TRIGger:SBSW:NRZC:IOPerator.....	1477
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:IOPerator.....	1477
TRIGger:SBSW:NRZC:ERENable.....	1478
TRIGger:SBSW:NRZC:ERRor<m>:ENABle.....	1478
SBUS<sb>:NRZC:SWTindex?.....	1478
SBUS<sb>:NRZC:SWTTime?.....	1478

TRIGger:SBSW:NRZC:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 602

TRIGger:SBSW:NRZC:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 602

TRIGger:SBSW:NRZC:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 602

TRIGger:SBSW:NRZC:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 602

TRIGger:SBSW:NRZC:FRENable <Frame>,<Enabler>**TRIGger:SBSW:NRZC:FRENable? <Enabler>****TRIGger:SBSW:NRZC:FRAME<fr>:ENABLE <Enable>**

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:
<fr> Index of the frame

Parameters:
<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 603

TRIGger:SBSW:NRZC:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:NRZC:BIT? <Bit>

TRIGger:SBSW:NRZC:FRAME<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO

*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 603

TRIGger:SBSW:NRZC:DMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:NRZC:DMAX? <Data>

TRIGger:SBSW:NRZC:FRAME<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGE.

You can set the operator with [TRIGger:SBSW:NRZC:FRAME<fr>:FLD<fl>:DOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 603

TRIGger:SBSW:NRZC:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:NRZC:DMIN? <Data>

TRIGger:SBSW:NRZC:FRAME<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 603

TRIGger:SBSW:NRZC:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:NRZC:DOPerator? <Operator>

TRIGger:SBSW:NRZC:FRAME<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan | INRange | OORange

*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 603

TRIGger:SBSW:NRZC:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:NRZC:FIENable? <Enabler>

TRIGger:SBSW:NRZC:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 603

TRIGger:SBSW:NRZC:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:NRZC:IMAX? <Data>

TRIGger:SBSW:NRZC:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with [TRIGger:SBSW:NRZC:FRAME<fr>:FLD<fl>:IOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 603**TRIGger:SBSW:NRZC:IMIN** <Frame>,<Field>,<Data>**TRIGger:SBSW:NRZC:IMIN?** <Data>**TRIGger:SBSW:NRZC:FRAME<fr>:FLD<fl>:IMIN** <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 603**TRIGger:SBSW:NRZC:IOPerator** <Frame>,<Field>,<Operator>**TRIGger:SBSW:NRZC:IOPerator?** <Operator>**TRIGger:SBSW:NRZC:FRAME<fr>:FLD<fl>:IOPerator** <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 603

TRIGger:SBSW:NRZC:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:NRZC:ERENable? <Enabler>

TRIGger:SBSW:NRZC:ERRor<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 605

SBUS<sb>:NRZC:SWTindex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295

Increment: 1

*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:NRZC:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26

Increment: 1E-10

*RST: 0

Default unit: s

Usage: Query only
Asynchronous command

18.18.7.5 Decode results

This section describes the commands to query the results of the decoding of the "NRZ Clocked" protocol.

For manual operation, refer to [Section 14.7.7, "Performing NRZ decoding"](#), on page 605 and [Section 14.7.8, "NRZ decode results"](#), on page 607.

SBUS<sb>:NRZC:FCOunt?	1479
SBUS<sb>:NRZC:FRAMe<fr>:FLDCount?	1479
SBUS<sb>:NRZC:FRAMe<fr>:WBRate?	1480
SBUS<sb>:NRZC:FRAMe<fr>:FLD<fl>:STATe?	1480
SBUS<sb>:NRZC:FRAMe<fr>:FLD<fl>:LABel?	1480
SBUS<sb>:NRZC:FRAMe<fr>:FLD<fl>:VALue?	1481
SBUS<sb>:NRZC:FRAMe<fr>:FLD<fl>:FVALue?	1481
SBUS<sb>:NRZC:FRAMe<fr>:STATus?	1481
SBUS<sb>:NRZC:FRAMe<fr>:START?	1482
SBUS<sb>:NRZC:FRAMe<fr>:STOP?	1482
SBUS<sb>:NRZC:FRAMe<fr>:TYPE?	1483
SBUS<sb>:NRZC:FRAMe<fr>:CONE?	1483
SBUS<sb>:NRZC:FRAMe<fr>:CTWO?	1483
SBUS<sb>:NRZC:FRAMe<fr>:CTHRee?	1483

SBUS<sb>:NRZC:FCOunt?

Returns the number of decoded frames.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count>

Usage:

Query only
Asynchronous command

SBUS<sb>:NRZC:FRAMe<fr>:FLDCount?

Returns the number of fields available in the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<DataCount>

Usage:

Query only
Asynchronous command

SBUS<sb>:NRZC:FRAMe<fr>:WBRate?

Returns the bit rate of the frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameWBR> Increment: 1
 *RST: 0
 Default unit: bps

Usage: Query only

SBUS<sb>:NRZC:FRAMe<fr>:FLD<fl>:STATe?

Returns the overall state of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<State> OK | LENGth | CRC | PARity | INComplete

OK

The field has no error, it is valid.

LENGth

The length of the field is not as expected, indicating an error.

CRC

The CRC of the frame is not as expected, indicating an error.

PARity

Parity is not as expected, indicating an error

INComplete

The frame is incomplete.

*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:NRZC:FRAMe<fr>:FLD<fl>:LABel?

Returns the label of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Name>

Usage:

Query only
Asynchronous command

SBUS<sb>:NRZC:FRAMe<fr>:FLD<fl>:VALue?

Returns the value of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Value> *RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:NRZC:FRAMe<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<FormattedValue>

Usage:

Query only
Asynchronous command

SBUS<sb>:NRZC:FRAMe<fr>:STATus?

Returns the overall state of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameState> OK | LENGth | CRC | PARity | INComplete

OK

The frame is valid.

LENGth

Length of the frame is not as expected, indicating an error.

CRC

The checksum of the frame is not as expected, indicating an error.

PARity

Parity is not as expected, indicating an error.

INComplete

The frame is incomplete.

*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:NRZC:FRAMe<fr>:START?

Returns the start time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStart> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:NRZC:FRAMe<fr>:STOP?

Returns the end time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:NRZC:FRAMe<fr>:TYPE?

Returns the type of the specified decoded frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<FrameType> The frame type is undefined, because it is custom specific.

Usage:

Query only
Asynchronous command

SBUS<sb>:NRZC:FRAMe<fr>:CONE?

Returns the content of the 1st result column of the specified decoded frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<Result1>

Usage:

Query only
Asynchronous command

SBUS<sb>:NRZC:FRAMe<fr>:CTWO?

Returns the content of the 2nd result column of the specified decoded frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<Result2>

Usage:

Query only
Asynchronous command

SBUS<sb>:NRZC:FRAMe<fr>:CTHRee?

Returns the content of the 3rd result column of the specified decoded frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<Result3>

Usage: Query only
Asynchronous command

18.18.8 NRZ Unclocked (option R&S MXO5C-K510)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with `SBUS<sb>[:STATe]`.
- The bus is set to the correct type with `SBUS<sb>:TYPE`.
- [Configuration](#)..... 1484
- [Filter](#)..... 1488
- [Frame format](#)..... 1494
- [Software trigger](#)..... 1500
- [Decode results](#)..... 1505

18.18.8.1 Configuration

SBUS<sb>:NRZU:DATA:SOURce	1484
SBUS<sb>:NRZU:DATA:POLarity	1485
SBUS<sb>:NRZU:ENABle:SOURce	1485
SBUS<sb>:NRZU:ENABle:POLarity	1485
SBUS<sb>:NRZU:MINGap:SElect	1486
SBUS<sb>:NRZU:MINGap:WIDTh	1486
SBUS<sb>:NRZU:BITRate:SElect	1486
SBUS<sb>:NRZU:BITRate:WIDTh	1487
SBUS<sb>:NRZU:DATA:THReshold	1487
SBUS<sb>:NRZU:DATA:HYSteresis	1487
SBUS<sb>:NRZU:ENABle:THReshold	1487
SBUS<sb>:NRZU:ENABle:HYSteresis	1488
SBUS<sb>:NRZU:POSition	1488
SBUS<sb>:NRZU:SCALe	1488

SBUS<sb>:NRZU:DATA:SOURce Source

Selects the channel for the data signal source.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

Source C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See "[Data source](#)" on page 585

SBUS<sb>:NRZU:DATA:POLarity <DATAPolarity>

Sets the polarity for the data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DATAPolarity> ACTLow | ACTHigh

ACTLow

The transmitted signal for the data line is active high (high = 1).

ACTHigh

The transmitted signal for the data line is active low (low = 1).

*RST: ACTHigh

Usage: Asynchronous command

Manual operation: See ["Data polarity"](#) on page 585

SBUS<sb>:NRZU:ENABLE:SOURce Source

Selects the channel for the enable signal source.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

Source C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["Enable source"](#) on page 586

SBUS<sb>:NRZU:ENABLE:POLarity <ENABPolarity>

Sets the polarity for the enable line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ENABPolarity> ACTLow | ACTHigh

ACTLow

The transmitted signal for the enable line is active high (high = 1).

ACTHigh

The transmitted signal for the enable line is active low (low = 1).

*RST: ACTHigh

Usage: Asynchronous command

Manual operation: See ["Enable source"](#) on page 586

SBUS<sb>:NRZU:MINGap:SElect <MingapSelect>

Enables checking the minimum idle time between two frames during decoding.

To set the idle time, use the command [SBUS<sb>:NRZU:MINGap:WIDTh](#).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MingapSelect> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Check gap time"](#) on page 586

SBUS<sb>:NRZU:MINGap:WIDTh <MingapWidth>

Sets the minimum duration of the idle time. Any inactivity greater than this time is interpreted as a gap and leads to a resynchronization to the signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MingapWidth> Range: 1E-09 to 1
Increment: 1E-09
*RST: 1E-05
Default unit: s

Usage: Asynchronous command

Manual operation: See ["Check gap time"](#) on page 586

SBUS<sb>:NRZU:BITRate:SElect <BitrateSelect>

Enables setting the bit rate, which is required to trigger and decode unclocked NRZ signals.

You can set the bit rate with [SBUS<sb>:NRZU:BITRate:WIDTh](#).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<BitrateSelect> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Check bit rate"](#) on page 586

SBUS<sb>:NRZU:BITRate:WIDTH <BitrateWidth>

Specifies the bit rate, if enabled with [SBUS<sb>:NRZU:BITRate:SElect](#).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<BitrateWidth> Range: 300 to 2000000000
Increment: 100000
*RST: 10000000
Default unit: bps

Usage: Asynchronous command

Manual operation: See ["Check bit rate"](#) on page 586

SBUS<sb>:NRZU:DATA:THReshold <SDAThreshold>

Sets the threshold for the data channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SDAThreshold>

Usage: Asynchronous command

Manual operation: See ["Data threshold, Data hysteresis"](#) on page 587

SBUS<sb>:NRZU:DATA:HYSTeresis <SDAHysteresis>

Sets the hysteresis for the data channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SDAHysteresis>

Usage: Asynchronous command

Manual operation: See ["Data threshold, Data hysteresis"](#) on page 587

SBUS<sb>:NRZU:ENABLE:THReshold <ENABThreshold>

Sets the threshold for the enable channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ENABThreshold>

Usage: Asynchronous command

SBUS<sb>:NRZU:ENABle:HYSteresis <ENABHysteresis>

Sets the hysteresis for the enable channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ENABHysteresis>

Usage:

Asynchronous command

SBUS<sb>:NRZU:POSition <Position>

Sets the vertical position of the NRZ unlocked signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Position>

Usage:

Asynchronous command

SBUS<sb>:NRZU:SCALE <Scale>

Sets the vertical scale of the NRZ unlocked signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Scale>

Usage:

Asynchronous command

18.18.8.2 Filter

There are two commands for each parameter, that you can use for defining the NRZ unlocked settings.

For example, to set the *Frame type =NRZU-Frame > Field =Data >Data* value you can use one of the following commands:

- SBUS:NRZU:FILTer:FRAMe1:FLD1:DMIN 01100
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- SBUS:NRZU:FILTer:DMIN "NRZC-Frame", "Data", 01100
Defines the parameter by using the frame and field name.

SBUS<sb>:NRZU:FILTer:CHKall.....	1489
SBUS<sb>:NRZU:FILTer:CLR.....	1489
SBUS<sb>:NRZU:FILTer:INVert.....	1489
SBUS<sb>:NRZU:FILTer:RST.....	1490

SBUS<sb>:NRZU:FILTer:BIT.....	1490
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1490
SBUS<sb>:NRZU:FILTer:ERENable.....	1490
SBUS<sb>:NRZU:FILTer:ERRor<n>:ENABle.....	1490
SBUS<sb>:NRZU:FILTer:DMAx.....	1491
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:DMAx.....	1491
SBUS<sb>:NRZU:FILTer:DMIN.....	1491
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1491
SBUS<sb>:NRZU:FILTer:DOPerator.....	1491
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1491
SBUS<sb>:NRZU:FILTer:FIENable.....	1492
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1492
SBUS<sb>:NRZU:FILTer:FRENable.....	1492
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:ENABle.....	1492
SBUS<sb>:NRZU:FILTer:IMAX.....	1492
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1492
SBUS<sb>:NRZU:FILTer:IMIN.....	1493
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1493
SBUS<sb>:NRZU:FILTer:IOperator.....	1493
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:IOperator.....	1493

SBUS<sb>:NRZU:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 589

SBUS<sb>:NRZU:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 589

SBUS<sb>:NRZU:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 589

SBUS<sb>:NRZU:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:
<sb> 1 to 4, index of the serial bus

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 589

SBUS<sb>:NRZU:FILTer:BIT <Frame>,<Field>,<Bit>**SBUS<sb>:NRZU:FILTer:BIT? <Bit>****SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:BIT <BitState>**

Sets the bit state of a field that only consists of one bit.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<fl> Index of the field

Parameters:
<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 590

SBUS<sb>:NRZU:FILTer:ERENable <ErrorName>,<Enabler>**SBUS<sb>:NRZU:FILTer:ERENable? <Enabler>****SBUS<sb>:NRZU:FILTer:ERRor<n>:ENABLE <Enable>**

Defines the error type to be filtered on.

Suffix:
<sb> 1 to 4, index of the serial bus
<n> index of the error

Parameters:
<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 592

SBUS<sb>:NRZU:FILTer:DMAX <Frame>,<Field>,<Data>

SBUS<sb>:NRZU:FILTer:DMAX? <Data>

SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range if the operator is set to INRange or OORANGE.

You can set the operator with **SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:DOPerator**.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See "Edit" on page 590

SBUS<sb>:NRZU:FILTer:DMIN <Frame>,<Field>,<Data>

SBUS<sb>:NRZU:FILTer:DMIN? <Data>

SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See "Edit" on page 590

SBUS<sb>:NRZU:FILTer:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:NRZU:FILTer:DOPerator? <Operator>

SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 590

SBUS<sb>:NRZU:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:NRZU:FILTer:FIENable? <Enabler>

SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 590

SBUS<sb>:NRZU:FILTer:FRENable <Frame>,<Enabler>

SBUS<sb>:NRZU:FILTer:FRENable? <Enabler>

SBUS<sb>:NRZU:FILTer:FRAMe<fr>:ENABLE <Enable>

Enables the filtering on NRZ unlocked frames. Only the frames that match the selected filter conditions are displayed.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Enable"](#) on page 589

SBUS<sb>:NRZU:FILTer:IMAX <Frame>,<Field>,<Data>

SBUS<sb>:NRZU:FILTer:IMAX? <Data>

SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range if the operator is set to INRange.

You can set the operator with `SBUS<sb>:NRZU:FiLTeR:FRAMe<fr>:FLD<fl>:IOPerator`.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 590

SBUS<sb>:NRZU:FiLTeR:IMIN <Frame>,<Field>,<Data>

SBUS<sb>:NRZU:FiLTeR:IMIN? <Data>

SBUS<sb>:NRZU:FiLTeR:FRAMe<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 590

SBUS<sb>:NRZU:FiLTeR:IOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:NRZU:FiLTeR:IOPerator? <Operator>

SBUS<sb>:NRZU:FiLTeR:FRAMe<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGe
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 590

18.18.8.3 Frame format

This section describes the commands to specify and query frame formats for the "NRZ Unclocked" protocol.

For manual operation, refer to [Section 14.7.4, "NRZ frame format configuration"](#), on page 592.

SBUS<sb>:NRZU:FORMat:ADDFrame	1494
SBUS<sb>:NRZU:FORMat:LOAD	1494
SBUS<sb>:NRZU:FORMat:SAVE	1495
SBUS<sb>:NRZU:FORMat:CLR	1495
SBUS<sb>:NRZU:FORMat:FCOunt?	1495
SBUS<sb>:NRZU:FORMat:FRAME<fr>:ADDField	1495
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLDCount?	1496
SBUS<sb>:NRZU:FORMat:FRAME<fr>:NAME	1496
SBUS<sb>:NRZU:FORMat:FRAME<fr>:COLor	1496
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLD<fl>:NAME	1497
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLD<fl>:COLor	1497
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLD<fl>:BITCount	1497
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLD<fl>:CONDition	1498
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLD<fl>:FORMat	1498
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLD<fl>:BITOrder	1499
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLD<fl>:CLMN	1499

SBUS<sb>:NRZU:FORMat:ADDFrame

Appendes a new frame description to the frame list.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Add Frame"](#) on page 594

SBUS<sb>:NRZU:FORMat:LOAD <FileName>

Loads a the specified XML file with a list of frame descriptions.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName>

Usage:

Setting only
Asynchronous command

Manual operation: See ["Open"](#) on page 595

SBUS<sb>:NRZU:FORMat:SAVE <FileName>

Saves the current list of frame descriptions to an XML file with the specified name.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName>

Usage:

Setting only
Asynchronous command

Manual operation: See ["Save as"](#) on page 595

SBUS<sb>:NRZU:FORMat:CLR

Erases from the volatile memory all field and frame format descriptions that you have created for a specific custom protocol.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Edit List"](#) on page 594

SBUS<sb>:NRZU:FORMat:FCOUNT?

Returns the number of frame format descriptions available for a specific custom protocol.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count>

Usage:

Query only
Asynchronous command

Manual operation: See ["Edit List"](#) on page 594

SBUS<sb>:NRZU:FORMat:FRAME<fr>:ADDField

Appends a new field description to the selected frame description.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Usage: Setting only
Asynchronous command

Manual operation: See ["Add Field"](#) on page 595

SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLDCount?

Returns the number of field descriptions available for the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:
<Count>

Usage: Query only
Asynchronous command

Manual operation: See ["Edit List"](#) on page 596

SBUS<sb>:NRZU:FORMat:FRAMe<fr>:NAME <Name>

Specifies the name for the frame description of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:
<Name>

Usage: Asynchronous command

Manual operation: See ["Frame name"](#) on page 596

SBUS<sb>:NRZU:FORMat:FRAMe<fr>:COLor <Color>

Specifies the color for the frame description of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:
<Color> Use 32-bit RGB encoding in decimal format.

Range: 0 to 4294967295

Increment: 1

*RST: 4278255615

Usage: Asynchronous command

Manual operation: See ["Frame Color"](#) on page 597

SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLD<fl>:NAME <Name>

Specifies the name for the selected field of the selected frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Parameters:

<Name>

Usage: Asynchronous command

Manual operation: See ["Field name"](#) on page 597

SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLD<fl>:COLor <Color>

Specifies the color for the selected field of the selected frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Parameters:

<Color> Use 32-bit RGB encoding in decimal format.
 Range: 0 to 4294967295
 Increment: 1
 *RST: 4294967040

Usage: Asynchronous command

Manual operation: See ["Field Color"](#) on page 597

SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLD<fl>:BITCount <BitCount>

Specifies the bit count, hence length, of the selected field in the selected frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Parameters:

<BitCount> Range: 1 to 64
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Bit count"](#) on page 597

SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLD<fl>:CONDition <Condition>

Specifies a user-defined condition operator for the selected field of the selected frame. The various condition operators can identify, for example, a mandatory CRC checksum value or a frame ID.

Set the numeric format of the condition by the command `SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLD<fl>:FORMat`.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Parameters:

<Condition>	The implemented conditions are the "equal" and "array" operators.

Usage: Asynchronous command

Manual operation: See "[Condition](#)" on page 598

SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLD<fl>:FORMat <NumericFormat>

Specifies the numerical format for the condition value of the selected field in the selected frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Parameters:

<NumericFormat>	HEX OCT BIN ASCII ASCiï SIGN USIG DEC LIST FLIN
	DEC Decimal format
	HEX Hexadecimal format
	OCT Octal format
	BIN Binary format
	*RST: HEX

Usage: Asynchronous command

Manual operation: See "[Numeric format](#)" on page 600

SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLD<fl>:BITorder <BitOrder>

Specifies, in which order the algorithm evaluates the bits of the condition value of the selected field in the selected frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Parameters:

<BitOrder> LSBF | MSBF

LSBF

Least significant bit first

MSBF

Most significant bit first

*RST: MSBF

Usage: Asynchronous command

Manual operation: See ["Bit order"](#) on page 601

SBUS<sb>:NRZU:FORMat:FRAMe<fr>:FLD<fl>:CLMN <Column>

Specifies, in which result column of the decode table to display the selected field of the selected frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Parameters:

<Column> NONE | COL1 | COL2 | COL3

NONE

The result is not displayed.

COL1

The result is displayed in column 1.

COL2

The result is displayed in column 2.

COL3

The result is displayed in column 3.

*RST: NONE

Usage: Asynchronous command

Manual operation: See ["Result column"](#) on page 601

18.18.8.4 Software trigger

There are two commands for each parameter that you can use for defining the "NRZ Unclocked" settings.

For example, to set the *Frame type =NRZU-Frame > Field =Data >Data* value you can use one of the following commands:

- `TRIGger:SBSW:NRZU:FRAME1:FLD1:DMIN 01100`
Defines the parameter by using the index <fr> for the frame number and <fl> for the field number.
- `TRIGger:SBSW:NRZU:DMIN "NRZC-Frame", "Data", 01100`
Defines the parameter by using the frame and field name.

<code>TRIGger:SBSW:NRZU:CHKall</code>	1500
<code>TRIGger:SBSW:NRZU:CLR</code>	1501
<code>TRIGger:SBSW:NRZU:INVert</code>	1501
<code>TRIGger:SBSW:NRZU:RST</code>	1501
<code>TRIGger:SBSW:NRZU:FRENable</code>	1501
<code>TRIGger:SBSW:NRZU:FRAME<fr>:ENABLE</code>	1501
<code>TRIGger:SBSW:NRZU:BIT</code>	1501
<code>TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:BIT</code>	1501
<code>TRIGger:SBSW:NRZU:DMAX</code>	1502
<code>TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:DMAX</code>	1502
<code>TRIGger:SBSW:NRZU:DMIN</code>	1502
<code>TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:DMIN</code>	1502
<code>TRIGger:SBSW:NRZU:DOPerator</code>	1503
<code>TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:DOPerator</code>	1503
<code>TRIGger:SBSW:NRZU:FIENable</code>	1503
<code>TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:ENABLE</code>	1503
<code>TRIGger:SBSW:NRZU:IMAX</code>	1503
<code>TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:IMAX</code>	1503
<code>TRIGger:SBSW:NRZU:IMIN</code>	1504
<code>TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:IMIN</code>	1504
<code>TRIGger:SBSW:NRZU:IOperator</code>	1504
<code>TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:IOperator</code>	1504
<code>TRIGger:SBSW:NRZU:ERENable</code>	1504
<code>TRIGger:SBSW:NRZU:ERRor<m>:ENABLE</code>	1504
<code>SBUS<sb>:NRZU:SWTIndex?</code>	1505
<code>SBUS<sb>:NRZU:SWTTime?</code>	1505

TRIGger:SBSW:NRZU:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 602

TRIGger:SBSW:NRZU:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 602

TRIGger:SBSW:NRZU:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 602

TRIGger:SBSW:NRZU:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 602

TRIGger:SBSW:NRZU:FREnable <Frame>,<Enabler>**TRIGger:SBSW:NRZU:FREnable?** <Enabler>**TRIGger:SBSW:NRZU:FRAMe<fr>:ENABLe** <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:
<fr> Index of the frame

Parameters:
<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 603

TRIGger:SBSW:NRZU:BIT <Frame>,<Field>,<Bit>**TRIGger:SBSW:NRZU:BIT?** <Bit>**TRIGger:SBSW:NRZU:FRAMe<fr>:FLD<fl>:BIT** <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:
<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 603

TRIGger:SBSW:NRZU:DMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:NRZU:DMAX? <Data>

TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGE.

You can set the operator with [TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:DOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 603

TRIGger:SBSW:NRZU:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:NRZU:DMIN? <Data>

TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 603

TRIGger:SBSW:NRZU:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:NRZU:DOPerator? <Operator>

TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange

*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 603

TRIGger:SBSW:NRZU:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:NRZU:FIENable? <Enabler>

TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 603

TRIGger:SBSW:NRZU:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:NRZU:IMAX? <Data>

TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with [TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:IOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 603

TRIGger:SBSW:NRZU:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:NRZU:IMIN? <Data>

TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 603

TRIGger:SBSW:NRZU:IOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:NRZU:IOPerator? <Operator>

TRIGger:SBSW:NRZU:FRAME<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 603

TRIGger:SBSW:NRZU:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:NRZU:ERENable? <Enabler>

TRIGger:SBSW:NRZU:ERRor<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:
 <m> index of the error

Parameters:
 <Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 605

SBUS<sb>:NRZU:SWTIndex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:
 <sb> 1 to 4, index of the serial bus

Return values:
 <Index> Range: 0 to 4294967295
 Increment: 1
 *RST: 0

Usage: Query only
 Asynchronous command

SBUS<sb>:NRZU:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:
 <sb> 1 to 4, index of the serial bus

Return values:
 <Time> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage: Query only
 Asynchronous command

18.18.8.5 Decode results

This section describes the commands to query the results of the decoding of the "NRZ Unclocked" protocol.

For manual operation, refer to [Section 14.7.7, "Performing NRZ decoding"](#), on page 605 and [Section 14.7.8, "NRZ decode results"](#), on page 607.

SBUS<sb>:NRZU:FCOunt?	1506
SBUS<sb>:NRZU:FRAMe<fr>:FLDCount?	1506
SBUS<sb>:NRZU:FRAMe<fr>:WBRate?	1506
SBUS<sb>:NRZU:FRAMe<fr>:FLD<fl>:STATe?	1507
SBUS<sb>:NRZU:FRAMe<fr>:FLD<fl>:LABe?	1507
SBUS<sb>:NRZU:FRAMe<fr>:FLD<fl>:VALue?	1508
SBUS<sb>:NRZU:FRAMe<fr>:FLD<fl>:FVALue?	1508
SBUS<sb>:NRZU:FRAMe<fr>:STATus?	1508
SBUS<sb>:NRZU:FRAMe<fr>:STARt?	1509
SBUS<sb>:NRZU:FRAMe<fr>:STOP?	1509
SBUS<sb>:NRZU:FRAMe<fr>:TYPE?	1509
SBUS<sb>:NRZU:FRAMe<fr>:CONE?	1510
SBUS<sb>:NRZU:FRAMe<fr>:CTWO?	1510
SBUS<sb>:NRZU:FRAMe<fr>:CTHRee?	1510

SBUS<sb>:NRZU:FCOunt?

Returns the number of decoded frames.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count>

Usage:

Query only
Asynchronous command

SBUS<sb>:NRZU:FRAMe<fr>:FLDCount?

Returns the number of fields available in the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<DataCount>

Usage:

Query only
Asynchronous command

SBUS<sb>:NRZU:FRAMe<fr>:WBRate?

Returns the bit rate of the frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameWBR> Increment: 1
 *RST: 0
 Default unit: bps

Usage: Query only

SBUS<sb>:NRZU:FRAMe<fr>:FLD<fl>:STATe?

Returns the overall state of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Return values:

<State> OK | LENGth | CRC | PARity | INComplete

OK

The field has no error, it is valid.

LENGth

The length of the field is not as expected, indicating an error.

CRC

The CRC of the frame is not as expected, indicating an error.

PARity

Parity is not as expected, indicating an error

INComplete

The frame is incomplete.

*RST: OK

Usage: Query only
 Asynchronous command

SBUS<sb>:NRZU:FRAMe<fr>:FLD<fl>:LABe?

Returns the label of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Return values:

<Name>

Usage: Query only
 Asynchronous command

SBUS<sb>:NRZU:FRAMe<fr>:FLD<fl>:VALue?

Returns the value of the specified field in the specified frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Return values:

<Value> *RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:NRZU:FRAMe<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified field in the specified frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Return values:

<FormattedValue>

Usage:

Query only
Asynchronous command

SBUS<sb>:NRZU:FRAMe<fr>:STATus?

Returns the overall state of the specified frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame

Return values:

<FrameState> OK | LENGth | CRC | PARity | INComplete

OK

The frame is valid.

LENGth

Length of the frame is not as expected, indicating an error.

CRC

The checksum of the frame is not as expected, indicating an error.

PARity

Parity is not as expected, indicating an error.

INComplete

The frame is incomplete.

*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:NRZU:FRAME<fr>:START?

Returns the start time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStart> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:NRZU:FRAME<fr>:STOP?

Returns the end time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:NRZU:FRAME<fr>:TYPE?

Returns the type of the specified decoded frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameType> The frame type is undefined, because it is custom specific.

Usage: Query only
Asynchronous command

SBUS<sb>:NRZU:FRAMe<fr>:CONE?

Returns the content of the 1st result column of the specified decoded frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <Result1>

Usage: Query only
Asynchronous command

SBUS<sb>:NRZU:FRAMe<fr>:CTWO?

Returns the content of the 2nd result column of the specified decoded frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <Result2>

Usage: Query only
Asynchronous command

SBUS<sb>:NRZU:FRAMe<fr>:CTHRee?

Returns the content of the 3rd result column of the specified decoded frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <Result3>

Usage: Query only
Asynchronous command

18.18.9 Manchester (option R&S MXO5C-K510)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with `SBUS<sb>[:STATe]`.

- The bus is set to the correct type with `SBUS<sb>:TYPE`.
- [Configuration](#)..... 1511
- [Filter](#)..... 1516
- [Frame format](#)..... 1521
- [Software trigger](#)..... 1527
- [Decode results](#)..... 1533

18.18.9.1 Configuration

SBUS<sb>:MANCh:DATA:SOURce	1511
SBUS<sb>:MANCh:DATA:POLarity	1511
SBUS<sb>:MANCh:DATA:PHASe	1512
SBUS<sb>:MANCh:ENABLE:SOURce	1512
SBUS<sb>:MANCh:ENABLE:POLarity	1512
SBUS<sb>:MANCh:MINGap:SElect	1513
SBUS<sb>:MANCh:MINGap:WIDTh	1513
SBUS<sb>:MANCh:BITRate:SElect	1514
SBUS<sb>:MANCh:BITRate:WIDTh	1514
SBUS<sb>:MANCh:DATA:THUPper	1514
SBUS<sb>:MANCh:DATA:THLower	1514
SBUS<sb>:MANCh:DATA:HYSTeresis	1515
SBUS<sb>:MANCh:ENABLE:THReshold	1515
SBUS<sb>:MANCh:ENABLE:HYSTeresis	1515
SBUS<sb>:MANCh:POSition	1515
SBUS<sb>:MANCh:SCALe	1516

SBUS<sb>:MANCh:DATA:SOURce <DATASource>

Selects the channel for the data signal source.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DATASource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | M1 | M2 | M3 | M4 | M5 |
M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | R8 | O<n>C1 |
O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage:

Asynchronous command

Manual operation: See ["Data source"](#) on page 613

SBUS<sb>:MANCh:DATA:POLarity <DataPolarity>

Sets the polarity for the data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DataPolarity> MANC | MANT

MANC

Selects the "Manchester" data representation convention as per G. E. Thomas: High-to-low transition for logical 1.

MANT

Selects the "Manchester II" (Manchester Two) data representation convention as per IEEE 802.3: Low-to-high transition for logical 1.

*RST: MANC

Usage: Asynchronous command

Manual operation: See ["Data polarity"](#) on page 613

SBUS<sb>:MANCh:DATA:PHASe <DataPhase>

Sets the phase for the data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DataPhase> FEDGe | SEDGe

FEDGe

Selects capturing data bits on the clock's first (rising) edge.

SEdGe

Selects capturing data bits on the clock's second (falling) edge.

*RST: SEDGe

Usage: Asynchronous command

Manual operation: See ["Data phase"](#) on page 613

SBUS<sb>:MANCh:ENABLE:SOURce <DATASource>

Selects the channel for the enable signal source.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DATASource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | M1 | M2 | M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["Enable source"](#) on page 613

SBUS<sb>:MANCh:ENABLE:POLarity <EnablePolarity>

Sets the polarity for the enable line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<EnablePolarity> ACTLow | ACTHigh

ACTLow

The transmitted signal for the enable line is active high (high = 1).

ACTHigh

The transmitted signal for the enable line is active low (low = 1).

*RST: ACTHigh

Usage:

Asynchronous command

Manual operation: See ["Enable source"](#) on page 613

SBUS<sb>:MANCh:MINGap:SElect <MingapSelect>

Enables checking the minimum idle time between two frames during decoding.

To set the idle time, use the command [SBUS<sb>:MANCh:MINGap:WIDTh](#).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MingapSelect> OFF | ON

*RST: OFF

Usage:

Asynchronous command

Manual operation: See ["Check gap time"](#) on page 614

SBUS<sb>:MANCh:MINGap:WIDTh <MingapWidth>

Sets the minimum duration of the idle time. Any inactivity greater than this time is interpreted as a gap and leads to a resynchronization to the signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MingapWidth> Range: 1E-09 to 1

Increment: 1E-09

*RST: 1E-05

Default unit: s

Usage:

Asynchronous command

Manual operation: See ["Check gap time"](#) on page 614

SBUS<sb>:MANCh:BITRate:SElect <BitrateSelect>

Enables setting the bit rate.

To set the bit rate, use the command [SBUS<sb>:MANCh:BITRate:WIDTh](#).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<BitrateSelect> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Check bit rate"](#) on page 614

SBUS<sb>:MANCh:BITRate:WIDTh <BitrateWidth>

Sets the bit rate.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<BitrateWidth> Range: 300 to 2000000000
Increment: 100000
*RST: 10000000
Default unit: bps

Usage: Asynchronous command

Manual operation: See ["Check bit rate"](#) on page 614

SBUS<sb>:MANCh:DATA:THUPper <DatThresUpp>

Sets the upper threshold for the data channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DatThresUpp>

Usage: Asynchronous command

Manual operation: See ["Data upper threshold, Data lower threshold, Data hysteresis"](#) on page 615

SBUS<sb>:MANCh:DATA:THLower <DatThresLow>

Sets the lower threshold for the data channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DatThresLow>

Usage:

Asynchronous command

Manual operation:See ["Data upper threshold, Data lower threshold, Data hysteresis"](#) on page 615

SBUS<sb>:MANCh:DATA:HYSTeresis <DataHysteresis>

Sets the hysteresis for the data channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DataHysteresis>

Usage:

Asynchronous command

Manual operation:See ["Data upper threshold, Data lower threshold, Data hysteresis"](#) on page 615

SBUS<sb>:MANCh:ENABLE:THReshold <EnabThres>

Sets the threshold for the enable channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<EnabThres>

Usage:

Asynchronous command

Manual operation:See ["Enable threshold, Enable hysteresis"](#) on page 615

SBUS<sb>:MANCh:ENABLE:HYSTeresis <EnabHyst>

Sets the hysteresis for the enable channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<EnabHyst>

Usage:

Asynchronous command

Manual operation:See ["Enable threshold, Enable hysteresis"](#) on page 615

SBUS<sb>:MANCh:POSition <Position>

Sets the vertical position of the Manchester signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Position>

Usage:

Asynchronous command

SBUS<sb>:MANCh:SCALe <Scale>

Sets the vertical scale of the Manchester signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Scale>

Usage:

Asynchronous command

18.18.9.2 Filter

There are two commands for each parameter, that you can use for defining the Manchester settings.

For example, to set the *Frame type =Manchester-Frame > Field =Data >Data* value you can use one of the following commands:

- SBUS:MANCh:FILTer:FRAMe1:FLD1:DMIN 01100
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- SBUS:MANCh:FILTer:DMIN "Manchester-Frame", "Data", 01100
Defines the parameter by using the frame and field name.

SBUS<sb>:MANCh:FILTer:CHKall.....	1517
SBUS<sb>:MANCh:FILTer:CLR.....	1517
SBUS<sb>:MANCh:FILTer:INVert.....	1517
SBUS<sb>:MANCh:FILTer:RST.....	1517
SBUS<sb>:MANCh:FILTer:BIT.....	1518
SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1518
SBUS<sb>:MANCh:FILTer:ERENable.....	1518
SBUS<sb>:MANCh:FILTer:ERRor<n>:ENABLE.....	1518
SBUS<sb>:MANCh:FILTer:DMAX.....	1518
SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1518
SBUS<sb>:MANCh:FILTer:DMIN.....	1519
SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1519
SBUS<sb>:MANCh:FILTer:DOPerator.....	1519
SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1519
SBUS<sb>:MANCh:FILTer:FIENable.....	1519
SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:ENABLE.....	1519
SBUS<sb>:MANCh:FILTer:FRENable.....	1520
SBUS<sb>:MANCh:FILTer:FRAMe<fr>:ENABLE.....	1520
SBUS<sb>:MANCh:FILTer:IMAX.....	1520

SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1520
SBUS<sb>:MANCh:FILTer:IMIN.....	1521
SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1521
SBUS<sb>:MANCh:FILTer:IOPerator.....	1521
SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1521

SBUS<sb>:MANCh:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 616

SBUS<sb>:MANCh:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 616

SBUS<sb>:MANCh:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 616

SBUS<sb>:MANCh:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 616

SBUS<sb>:MANCh:FiLTer:BIT <Frame>,<Field>,<Bit>

SBUS<sb>:MANCh:FiLTer:BIT? <Bit>

SBUS<sb>:MANCh:FiLTer:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO

*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 617

SBUS<sb>:MANCh:FiLTer:ERENable <ErrorName>,<Enabler>

SBUS<sb>:MANCh:FiLTer:ERENable? <Enabler>

SBUS<sb>:MANCh:FiLTer:ERRor<n>:ENABle <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 619

SBUS<sb>:MANCh:FiLTer:DMAx <Frame>,<Field>,<Data>

SBUS<sb>:MANCh:FiLTer:DMAx? <Data>

SBUS<sb>:MANCh:FiLTer:FRAMe<fr>:FLD<fl>:DMAx <Data_Max>

Sets the end value of a data pattern range if the operator is set to `INRange` or `OORANGe`.

You can set the operator with `SBUS<sb>:MANCh:FiLTer:FRAMe<fr>:FLD<fl>:DOPerator`.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage:

Asynchronous command

Manual operation:See ["Edit"](#) on page 617**SBUS<sb>:MANCh:FILTer:DMIN** <Frame>,<Field>,<Data>**SBUS<sb>:MANCh:FILTer:DMIN?** <Data>**SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:DMIN** <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage:

Asynchronous command

Manual operation:See ["Edit"](#) on page 617**SBUS<sb>:MANCh:FILTer:DOPerator** <Frame>,<Field>,<Operator>**SBUS<sb>:MANCh:FILTer:DOPerator?** <Operator>**SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:DOPerator** <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUal

Usage:

Asynchronous command

Manual operation:See ["Edit"](#) on page 617**SBUS<sb>:MANCh:FILTer:FIENable** <Frame>,<Field>,<Enabler>**SBUS<sb>:MANCh:FILTer:FIENable?** <Enabler>**SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:ENABLE** <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<CondEnabler>** OFF | ON***RST:** OFF**Usage:** Asynchronous command**Manual operation:** See ["Edit"](#) on page 617**SBUS<sb>:MANCh:FILTer:FREnable** <Frame>,<Enabler>**SBUS<sb>:MANCh:FILTer:FREnable?** <Enabler>**SBUS<sb>:MANCh:FILTer:FRAMe<fr>:ENABLE** <Enable>

Enables the filtering on Manchester frames. Only the frames that match the selected filter conditions are displayed.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Parameters:****<Enable>** OFF | ON***RST:** ON**Usage:** Asynchronous command**Manual operation:** See ["Enable"](#) on page 617**SBUS<sb>:MANCh:FILTer:IMAX** <Frame>,<Field>,<Data>**SBUS<sb>:MANCh:FILTer:IMAX?** <Data>**SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:IMAX** <Index_Max>

Sets the end value of an index range if the operator is set to `INRange`.

You can set the operator with `SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:IOperator`.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<Index_Max>** Range: 1 to 65535

Increment: 1

***RST:** 65535**Usage:** Asynchronous command

Manual operation: See ["Edit"](#) on page 617

SBUS<sb>:MANCh:FILTer:IMIN <Frame>,<Field>,<Data>

SBUS<sb>:MANCh:FILTer:IMIN? <Data>

SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
Increment: 1
*RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 617

SBUS<sb>:MANCh:FILTer:IOperator <Frame>,<Field>,<Operator>

SBUS<sb>:MANCh:FILTer:IOperator? <Operator>

SBUS<sb>:MANCh:FILTer:FRAMe<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGE
*RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 617

18.18.9.3 Frame format

This section describes the commands to specify and query frame formats for the "Manchester" protocol.

For manual operation, refer to [Section 14.8.4, "Manchester frame format configuration"](#), on page 619.

SBUS<sb>:MANCh:FORMat:ADDFrame..... 1522
SBUS<sb>:MANCh:FORMat:LOAD..... 1522
SBUS<sb>:MANCh:FORMat:SAVE..... 1522

SBUS<sb>:MANCh:FORMat:CLR.....	1523
SBUS<sb>:MANCh:FORMat:FCOunt?.....	1523
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:ADDField.....	1523
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLDCount?.....	1523
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:NAME.....	1524
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:COLor.....	1524
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:NAME.....	1524
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:COLor.....	1525
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:BITCount.....	1525
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:CONDition.....	1525
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:FORMat.....	1526
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:BITOrder.....	1526
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:CLMN.....	1527

SBUS<sb>:MANCh:FORMat:ADDFrame

Appends a new frame description to the frame list.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Add Frame"](#) on page 621

SBUS<sb>:MANCh:FORMat:LOAD <FileName>

Loads a the specified XML file with a list of frame descriptions.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName>

Usage:

Setting only
Asynchronous command

Manual operation: See ["Open"](#) on page 622

SBUS<sb>:MANCh:FORMat:SAVE <FileName>

Saves the current list of frame descriptions to an XML file with the specified name.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName>

Usage:

Setting only
Asynchronous command

Manual operation: See ["Save as"](#) on page 622

SBUS<sb>:MANCh:FORMat:CLR

Erases from the volatile memory all field and frame format descriptions that you have created for a specific custom protocol.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Edit List"](#) on page 622

SBUS<sb>:MANCh:FORMat:FCOUNT?

Returns the number of frame format descriptions available for a specific custom protocol.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count>

Usage:

Query only
Asynchronous command

Manual operation: See ["Edit List"](#) on page 622

SBUS<sb>:MANCh:FORMat:FRAMe<fr>:ADDField

Appends a new field description to the selected frame description.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Usage:

Setting only
Asynchronous command

Manual operation: See ["Add Field"](#) on page 622

SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLDCOUNT?

Returns the number of field descriptions available for the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Count>

Usage:

Query only
Asynchronous command

Manual operation: See ["Edit List"](#) on page 623

SBUS<sb>:MANCh:FORMat:FRAMe<fr>:NAME <Name>

Specifies the name for the frame description of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Name>

Usage:

Asynchronous command

Manual operation: See ["Frame name"](#) on page 623

SBUS<sb>:MANCh:FORMat:FRAMe<fr>:COLor <Color>

Specifies the color for the frame description of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Color> Use 32-bit RGB encoding in decimal format.

Range: 0 to 4294967295

Increment: 1

*RST: 4278255615

Usage:

Asynchronous command

Manual operation: See ["Frame Color"](#) on page 624

SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:NAME <Name>

Specifies the name for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Name>

Usage: Asynchronous command
Manual operation: See ["Field name"](#) on page 624

SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:COLor <Color>

Specifies the color for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Color> Use 32-bit RGB encoding in decimal format.
 Range: 0 to 4294967295
 Increment: 1
 *RST: 4294967040

Usage: Asynchronous command
Manual operation: See ["Field Color"](#) on page 624

SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:BITCount <BitCount>

Specifies the bit count, hence length, of the selected field in the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<BitCount> Range: 1 to 64
 Increment: 1
 *RST: 1

Usage: Asynchronous command
Manual operation: See ["Bit count"](#) on page 624

SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:CONDition <Condition>

Specifies a user-defined condition operator for the selected field of the selected frame. The various condition operators can identify, for example, a mandatory CRC checksum value or a frame ID.

Set the numeric format of the condition by the command [SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:FORMat](#).

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Condition> The implemented conditions are the "equal" and "array" operators.

Usage: Asynchronous command

Manual operation: See ["Condition"](#) on page 625

SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:FORMat <NumericFormat>

Specifies the numerical format for the condition value of the selected field in the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<NumericFormat> HEX | OCT | BIN | ASCII | ASCii | SIGN | USIG | DEC | LIST | FLIN

DEC

Decimal format

HEX

Hexadecimal format

OCT

Octal format

BIN

Binary format

*RST: HEX

Usage: Asynchronous command

Manual operation: See ["Numeric format"](#) on page 627

SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:BITOrder <BitOrder>

Specifies, in which order the algorithm evaluates the bits of the condition value of the selected field in the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitOrder> LSBF | MSBF

LSBF

Least significant bit first

MSBF

Most significant bit first

*RST: MSBF

Usage: Asynchronous command**Manual operation:** See ["Bit order"](#) on page 627**SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:CLMN <Column>**

Specifies, in which result column of the decode table to display the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Column> NONE | COL1 | COL2 | COL3

NONE

The result is not displayed.

COL1

The result is displayed in column 1.

COL2

The result is displayed in column 2.

COL3

The result is displayed in column 3.

*RST: NONE

Usage: Asynchronous command**Manual operation:** See ["Result column"](#) on page 628**18.18.9.4 Software trigger**

There are two commands for each parameter that you can use for defining the "Manchester" settings.

For example, to set the *Frame type =Manchester-Frame > Field =Data >Data* value you can use one of the following commands:

- `TRIGger:SBSW:MANCh:FRAMe1:FLD1:DMIN 01100`
Defines the parameter by using the index <fr> for the frame number and <fl> for the field number.
- `TRIGger:SBSW:MANCh:DMIN "Manchester-Frame", "Data", 01100`
Defines the parameter by using the frame and field name.

TRIGger:SBSW:MANCh:CHKall.....	1528
TRIGger:SBSW:MANCh:CLR.....	1528
TRIGger:SBSW:MANCh:INVert.....	1528
TRIGger:SBSW:MANCh:RST.....	1529
TRIGger:SBSW:MANCh:FREnable.....	1529
TRIGger:SBSW:MANCh:FRAMe<fr>:ENABLE.....	1529
TRIGger:SBSW:MANCh:BIT.....	1529
TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:BIT.....	1529
TRIGger:SBSW:MANCh:DMAX.....	1530
TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:DMAX.....	1530
TRIGger:SBSW:MANCh:DMIN.....	1530
TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:DMIN.....	1530
TRIGger:SBSW:MANCh:DOPerator.....	1530
TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:DOPerator.....	1530
TRIGger:SBSW:MANCh:FIENable.....	1531
TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:ENABLE.....	1531
TRIGger:SBSW:MANCh:IMAX.....	1531
TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:IMAX.....	1531
TRIGger:SBSW:MANCh:IMIN.....	1532
TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:IMIN.....	1532
TRIGger:SBSW:MANCh:IOPerator.....	1532
TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:IOPerator.....	1532
TRIGger:SBSW:MANCh:ERENable.....	1532
TRIGger:SBSW:MANCh:ERRor<m>:ENABLE.....	1532
SBUS<sb>:MANCh:SWTIndex?.....	1533
SBUS<sb>:MANCh:SWTTime?.....	1533

TRIGger:SBSW:MANCh:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 629

TRIGger:SBSW:MANCh:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 629

TRIGger:SBSW:MANCh:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 629

TRIGger:SBSW:MANCh:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 629

TRIGger:SBSW:MANCh:FRENAble <Frame>,<Enabler>

TRIGger:SBSW:MANCh:FRENAble? <Enabler>

TRIGger:SBSW:MANCh:FRAMe<fr>:ENABle <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:
<fr> Index of the frame

Parameters:
<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 629

TRIGger:SBSW:MANCh:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:MANCh:BIT? <Bit>

TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:
<fr> Index of the frame
<fl> Index of the field

Parameters:
<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 630

TRIGger:SBSW:MANCh:DMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:MANCh:DMAX? <Data>

TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGe.

You can set the operator with **TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:DOPerator**.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See "Edit" on page 630

TRIGger:SBSW:MANCh:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:MANCh:DMIN? <Data>

TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See "Edit" on page 630

TRIGger:SBSW:MANCh:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:MANCh:DOPerator? <Operator>

TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 630

TRIGger:SBSW:MANCh:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:MANCh:FIENable? <Enabler>

TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 630

TRIGger:SBSW:MANCh:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:MANCh:IMAX? <Data>

TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with [TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:IOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 630

TRIGger:SBSW:MANCh:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:MANCh:IMIN? <Data>

TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 630

TRIGger:SBSW:MANCh:IOperator <Frame>,<Field>,<Operator>

TRIGger:SBSW:MANCh:IOperator? <Operator>

TRIGger:SBSW:MANCh:FRAMe<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 630

TRIGger:SBSW:MANCh:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:MANCh:ERENable? <Enabler>

TRIGger:SBSW:MANCh:ERRor<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> index of the error

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 631

SBUS<sb>:MANCh:SWTIndex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:MANCh:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

18.18.9.5 Decode results

This section describes the commands to query the results of the decoding of the "Manchester" protocol.

For manual operation, refer to [Section 14.8.7, "Performing Manchester decoding"](#), on page 632.

SBUS<sb>:MANCh:FCOunt?	1534
SBUS<sb>:MANCh:FRAME<fr>:FLDCount?	1534
SBUS<sb>:MANCh:FRAME<fr>:WBRate?	1534
SBUS<sb>:MANCh:FRAME<fr>:FLD<fl>:STATe?	1534
SBUS<sb>:MANCh:FRAME<fr>:FLD<fl>:LABel?	1535
SBUS<sb>:MANCh:FRAME<fr>:FLD<fl>:VALue?	1535
SBUS<sb>:MANCh:FRAME<fr>:FLD<fl>:FVALue?	1536
SBUS<sb>:MANCh:FRAME<fr>:STATus?	1536
SBUS<sb>:MANCh:FRAME<fr>:START?	1536
SBUS<sb>:MANCh:FRAME<fr>:STOP?	1537
SBUS<sb>:MANCh:FRAME<fr>:TYPE?	1537

SBUS<sb>:MANCh:FRAMe<fr>:CONE?	1537
SBUS<sb>:MANCh:FRAMe<fr>:CTWO?	1538
SBUS<sb>:MANCh:FRAMe<fr>:CTHRee?	1538

SBUS<sb>:MANCh:FCOut?

Returns the number of decoded frames.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count>

Usage:

Query only
Asynchronous command

SBUS<sb>:MANCh:FRAMe<fr>:FLDCount?

Returns the number of fields available in the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<DataCount>

Usage:

Query only
Asynchronous command

SBUS<sb>:MANCh:FRAMe<fr>:WBRate?

Returns the bit rate of the frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameWBR> Range: 0 to 100000000000
Increment: 1
*RST: 0
Default unit: bps

Usage:

Query only

SBUS<sb>:MANCh:FRAMe<fr>:FLD<fl>:STATe?

Returns the overall state of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<State> OK | LENGth | CRC | PARity | INComplete

OK

The field has no error, it is valid.

LENGth

The length of the field is not as expected, indicating an error.

CRC

The CRC of the frame is not as expected, indicating an error.

PARity

Parity is not as expected, indicating an error

INComplete

The frame is incomplete.

*RST: OK

Usage:

Query only

Asynchronous command

SBUS<sb>:MANCh:FRAMe<fr>:FLD<fl>:LABel?

Returns the label of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Name>

Usage:

Query only

Asynchronous command

SBUS<sb>:MANCh:FRAMe<fr>:FLD<fl>:VALue?

Returns the value of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Value> *RST: 0

Usage:

Query only

Asynchronous command

SBUS<sb>:MANCh:FRAMe<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified field in the specified frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Return values:

<FormattedValue>

Usage:

Query only
Asynchronous command

SBUS<sb>:MANCh:FRAMe<fr>:STATus?

Returns the overall state of the specified frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame

Return values:

<FrameState> OK | LENGth | CRC | PARity | INComplete

OK

The frame is valid.

LENGth

Length of the frame is not as expected, indicating an error.

CRC

The checksum of the frame is not as expected, indicating an error.

PARity

Parity is not as expected, indicating an error.

INComplete

The frame is incomplete.

*RST: OK

Usage:

Query only
Asynchronous command

SBUS<sb>:MANCh:FRAMe<fr>:START?

Returns the start time of the specified frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame

Return values:

<FrameStart> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

SBUS<sb>:MANCh:FRAMe<fr>:STOP?

Returns the end time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

SBUS<sb>:MANCh:FRAMe<fr>:TYPE?

Returns the type of the specified decoded frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<FrameType> The frame type is undefined, because it is custom specific.

Usage:

Query only
 Asynchronous command

SBUS<sb>:MANCh:FRAMe<fr>:CONE?

Returns the content of the 1st result column of the specified decoded frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<Result1>

Usage: Query only
Asynchronous command

SBUS<sb>:MANCh:FRAMe<fr>:CTWO?

Returns the content of the 2nd result column of the specified decoded frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <Result2>

Usage: Query only
Asynchronous command

SBUS<sb>:MANCh:FRAMe<fr>:CTHRee?

Returns the content of the 3rd result column of the specified decoded frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <Result3>

Usage: Query only
Asynchronous command

18.18.10 CAN (option R&S MXO5C-K520)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with [SBUS<sb>\[:STATe\]](#).
- The bus is set to the correct type with [SBUS<sb>:TYPE](#).

• Configuration	1538
• Filter	1544
• Hardware trigger	1549
• Software trigger	1559
• Decode results	1565

18.18.10.1 Configuration

SBUS<sb>:CAN:TYPE	1539
SBUS<sb>:CAN:BITRate	1539
SBUS<sb>:CAN:SAMPlepoint	1539
SBUS<sb>:CAN:SOURce	1540

SBUS<sb>:CAN:FDATa:DBITRate.....	1540
SBUS<sb>:CAN:FDATa:SAMPlEpoint.....	1540
SBUS<sb>:CAN:SIC:HYSTeresis.....	1541
SBUS<sb>:CAN:SIC:THReshold.....	1541
SBUS<sb>:CAN:FAST:THReshold.....	1541
SBUS<sb>:CAN:FAST:HYSTeresis.....	1542
SBUS<sb>:CAN:XDATa:DBITRate.....	1542
SBUS<sb>:CAN:XDATa:SAMPlEpoint.....	1542
SBUS<sb>:CAN:TRCVmode.....	1542
SBUS<sb>:CAN:SYMBols.....	1543
SBUS<sb>:CAN:NEWList.....	1543
SBUS<sb>:CAN:POSition.....	1543
SBUS<sb>:CAN:SCALE.....	1544

SBUS<sb>:CAN:TYPE <SignalType>

Selects the CAN-High or CAN-Low line. Both lines are required for differential signal transmission used by CAN.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SignalType> CANL | CANH
*RST: CANL

Usage: Asynchronous command

Manual operation: See "Type" on page 638

SBUS<sb>:CAN:BITRate <Bitrate>

Sets the number of transmitted bits per second.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Bitrate> Range: 10000 to 5000000
Increment: 100
*RST: 100000
Default unit: bps

Usage: Asynchronous command

Manual operation: See "Nominal bit rate" on page 638

SBUS<sb>:CAN:SAMPlEpoint <SamplePoint>

Sets the position of the sample point within the bit in percent of the nominal bit time.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SamplePoint> Range: 30 to 90
 Increment: 5
 *RST: 66
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Sample point"](#) on page 638

SBUS<sb>:CAN:SOURce Source

Sets the source channel to which the line is connected.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

Source With digital channels in SIC mode:
 C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
 | D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
 | M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
 R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)
 Without digital channels in FAST mode:
 C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | M1 | M2 | M3 | M4 | M5 |
 M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | R8 | O<n>C1 |
 O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["Data"](#) on page 637

SBUS<sb>:CAN:FData:DBITrate <FDBitrate>

Sets the bit rate of the data phase.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<FDBitrate> Range: 10000 to 15000000
 Increment: 100
 *RST: 1000000
 Default unit: bps

Usage: Asynchronous command

Manual operation: See ["FD bit rate"](#) on page 638

SBUS<sb>:CAN:FData:SAMplepoint <FDSamplePoint>

Sets the position of the sample point within the bit in percent of the nominal bit time.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<FDSamplePoint> Range: 30 to 90
Increment: 5
*RST: 66
Default unit: %

Usage: Asynchronous command

Manual operation: See ["FD sample point"](#) on page 638

SBUS<sb>:CAN:SIC:HYSTeresis <Hysteresis>

Sets a hysteresis value for the SIC transceiver mode.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 639

SBUS<sb>:CAN:SIC:THReshold <SIC Threshold>

Sets a threshold value for the SIC transceiver mode.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SIC Threshold>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 639

SBUS<sb>:CAN:FAST:THReshold <SIC Threshold>

Sets a threshold value for the fast transceiver mode.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SIC Threshold>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 639

SBUS<sb>:CAN:FAST:HYSteresis <Hysteresis>

Sets a hysteresis value for the fast transceiver mode.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 639

SBUS<sb>:CAN:XDATA:DBITrate <XLBitrate>

Sets the bit rate of the data phase for the CAN XL frame.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<XLBitrate> Range: 10000 to 30000000
Increment: 100
*RST: 10000000
Default unit: bps

Usage: Asynchronous command

Manual operation: See ["XL bit rate"](#) on page 638

SBUS<sb>:CAN:XDATA:SAMPlepoint <XLSamplePoint>

Sets the position of the sample point within the bit in percent of the nominal bit time for the CAN XL frame.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<XLSamplePoint> Range: 30 to 90
Increment: 5
*RST: 66
Default unit: %

Usage: Asynchronous command

Manual operation: See ["XL sample point"](#) on page 639

SBUS<sb>:CAN:TRCVmode <TransceiverMd>

Selects the transceiver mode for the CAN decoding.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<TransceiverMd> SIC | FAST
 *RST: SIC

Usage: Asynchronous command

Manual operation: See ["Transceiver mode"](#) on page 638

SBUS<sb>:CAN:SYMBOLs <ShowSymbols>

Activates the symbol list to be used for decoding.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ShowSymbols> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Show symbols"](#) on page 640

SBUS<sb>:CAN:NEWList <FileName>

Loads a symbol list file.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName> String parameter with path and file name.

Example:

```
SBUS1:CAN:NEWList
'/home/storage/userData/Protocol/CAN.csv'
SBUS1:CAN:SYMBOLs ON
```

Usage: Setting only
 Asynchronous command

Manual operation: See ["Show symbols"](#) on page 640

SBUS<sb>:CAN:POSition <CAN position>

Sets the vertical position of the CAN signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<CAN position>

Usage: Asynchronous command

SBUS<sb>:CAN:SCALE <CAN scale>

Set the vertical scale of the indicated CAN signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<CAN scale>

Usage:

Asynchronous command

18.18.10.2 Filter

There are two commands for each parameter, that you can use for defining the CAN settings.

For example, to set the *Frame type =CBFF > Field =Data >Data* value you can use one of the following commands:

- SBUS:CAN:FILTer:FRAMe1:FLD1:DMIN 01100
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- SBUS:CAN:FILTer:DMIN "CBFF", "Data", 01100
Defines the parameter by using the frame and field name.

SBUS<sb>:CAN:FILTer:CHKall.....	1545
SBUS<sb>:CAN:FILTer:CLR.....	1545
SBUS<sb>:CAN:FILTer:INVert.....	1545
SBUS<sb>:CAN:FILTer:RST.....	1545
SBUS<sb>:CAN:FILTer:BIT.....	1545
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1545
SBUS<sb>:CAN:FILTer:DMAX.....	1546
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1546
SBUS<sb>:CAN:FILTer:DMIN.....	1546
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1546
SBUS<sb>:CAN:FILTer:DOPerator.....	1547
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1547
SBUS<sb>:CAN:FILTer:ERENable.....	1547
SBUS<sb>:CAN:FILTer:ERRor<n>:ENABle.....	1547
SBUS<sb>:CAN:FILTer:FIENable.....	1547
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1547
SBUS<sb>:CAN:FILTer:FRENable.....	1548
SBUS<sb>:CAN:FILTer:FRAMe<fr>:ENABle.....	1548
SBUS<sb>:CAN:FILTer:IMAX.....	1548
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1548
SBUS<sb>:CAN:FILTer:IMIN.....	1548
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1548
SBUS<sb>:CAN:FILTer:IOPerator.....	1549
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1549

SBUS<sb>:CAN:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 642

SBUS<sb>:CAN:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 642

SBUS<sb>:CAN:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 642

SBUS<sb>:CAN:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 642

SBUS<sb>:CAN:FILTer:BIT <Frame>, <Field>, <Bit>

SBUS<sb>:CAN:FILTer:BIT? <Bit>

SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<BitState>** ONE | ZERO***RST:** ZERO**Usage:** Asynchronous command**Manual operation:** See ["Edit"](#) on page 643**SBUS<sb>:CAN:FILTER:DMAX** <Frame>,<Field>,<Data>**SBUS<sb>:CAN:FILTER:DMAX?** <Data>**SBUS<sb>:CAN:FILTER:FRAME<fr>:FLD<fl>:DMAX** <Data_Max>Sets the end value of a data pattern range if the operator is set to `INRange` or `ORANGE`.**Suffix:****<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<Data_Max>****Usage:** Asynchronous command**Manual operation:** See ["Edit"](#) on page 643**SBUS<sb>:CAN:FILTER:DMIN** <Frame>,<Field>,<Data>**SBUS<sb>:CAN:FILTER:DMIN?** <Data>**SBUS<sb>:CAN:FILTER:FRAME<fr>:FLD<fl>:DMIN** <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<Data_Min>****Usage:** Asynchronous command**Manual operation:** See ["Edit"](#) on page 643

SBUS<sb>:CAN:FILTer:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:CAN:FILTer:DOPerator? <Operator>

SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange

*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 643

SBUS<sb>:CAN:FILTer:ERENable <ErrorName>,<Enabler>

SBUS<sb>:CAN:FILTer:ERENable? <Enabler>

SBUS<sb>:CAN:FILTer:ERRor<n>:ENABle <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 645

SBUS<sb>:CAN:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:CAN:FILTer:FIENable? <Enabler>

SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:ENABle <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 643

SBUS<sb>:CAN:FILTER:FREnable <Frame>,<Enabler>

SBUS<sb>:CAN:FILTER:FREnable? <Enabler>

SBUS<sb>:CAN:FILTER:FRAME<fr>:ENABLE <Enable>

Enables the filtering on CAN frames. Only the frames that match the selected filter conditions are displayed.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 643

SBUS<sb>:CAN:FILTER:IMAX <Frame>,<Field>,<Data>

SBUS<sb>:CAN:FILTER:IMAX? <Data>

SBUS<sb>:CAN:FILTER:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range if the operator is set to INRange.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 643

SBUS<sb>:CAN:FILTER:IMIN <Frame>,<Field>,<Data>

SBUS<sb>:CAN:FILTER:IMIN? <Data>

SBUS<sb>:CAN:FILTER:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:**

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 643**SBUS<sb>:CAN:FILTer:IOperator** <Frame>,<Field>,<Operator>**SBUS<sb>:CAN:FILTer:IOperator?** <Operator>**SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:IOperator** <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:**

<Index_Operator> EQUal | INRange | RANGe
 *RST: INRange

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 643**18.18.10.3 Hardware trigger**

Trigger commands for serial buses affect the current trigger source. Therefore, set the trigger source to the required serial bus with [TRIGger:EVENT<ev>:SOURCE](#) before sending the bus-specific trigger commands.

TRIGger:SBHW:CAN:ACKError	1550
TRIGger:SBHW:CAN:BITSterror	1550
TRIGger:SBHW:CAN:BORDER	1551
TRIGger:SBHW:CAN:CRCError	1551
TRIGger:SBHW:CAN:DCondition	1551
TRIGger:SBHW:CAN:DLC	1552
TRIGger:SBHW:CAN:DLCCCondition	1552
TRIGger:SBHW:CAN:DMIN	1552
TRIGger:SBHW:CAN:FDATa:BRS	1552
TRIGger:SBHW:CAN:FDATa:DPOStition	1553
TRIGger:SBHW:CAN:FDATa:ESI	1553
TRIGger:SBHW:CAN:FDATa:SCERror	1553

TRIGger:SBHW:CAN:FORMerror.....	1553
TRIGger:SBHW:CAN:FTYPE.....	1554
TRIGger:SBHW:CAN:ICONdition.....	1554
TRIGger:SBHW:CAN:IMAX.....	1554
TRIGger:SBHW:CAN:IMIN.....	1555
TRIGger:SBHW:CAN:ITYPe.....	1555
TRIGger:SBHW:CAN:TYPE.....	1555
TRIGger:SBHW:CAN:XDATA:AF:CONDition.....	1556
TRIGger:SBHW:CAN:XDATA:AF:MAX.....	1557
TRIGger:SBHW:CAN:XDATA:AF:MIN.....	1557
TRIGger:SBHW:CAN:XDATA:SDT:CONDition.....	1557
TRIGger:SBHW:CAN:XDATA:SDT:MAX.....	1557
TRIGger:SBHW:CAN:XDATA:SDT:MIN.....	1558
TRIGger:SBHW:CAN:XDATA:SEC.....	1558
TRIGger:SBHW:CAN:XDATA:VCID:CONDition.....	1558
TRIGger:SBHW:CAN:XDATA:VCID:MAX.....	1559
TRIGger:SBHW:CAN:XDATA:VCID:MIN.....	1559

TRIGger:SBHW:CAN:ACKerror <AckError>

Triggers when the transmitter does not receive an acknowledgment - a dominant bit during the ACK Slot.

Available, if `TRIGger:SBHW:CAN:TYPE` is set to `ERRC`.

Parameters:

<AckError> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See "Error conditions" on page 652

TRIGger:SBHW:CAN:BITSterror <BitStuffError>

Triggers if a stuff error occurs - when the 6th consecutive equal bit level in the mentioned fields is detected.

Available, if `TRIGger:SBHW:CAN:TYPE` is set to `ERRC`.

Parameters:

<BitStuffError> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See "Error conditions" on page 652

TRIGger:SBHW:CAN:BORDER <Endianness>

Sets the byte order (endianness) of the data transfer. Only for CAN protocol.

Parameters:

<Endianness> BENDian | LENDian

BENDian

Big endian, data is analyzed and evaluated in the order of reception.

LENDian

Little endian, the instrument reads the complete data, reverses the byte order of the data, and compares it with the specified data word.

*RST: BENDian

Usage: Asynchronous command

TRIGger:SBHW:CAN:CRCError <ChecksumError>

Triggers on CRC errors. A CRC error occurs when the CRC calculated by the receiver differs from the received value in the CRC sequence.

Available, if [TRIGger:SBHW:CAN:TYPE](#) is set to `ERRC`.

Parameters:

<ChecksumError> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See "[Error conditions](#)" on page 652

TRIGger:SBHW:CAN:DCondition <DataOperator>

Sets the operator to set a specific data pattern or a data pattern range.

Parameters:

<DataOperator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan

EQUal | NEQual | LTHan | LETHan | GTHan | GETHan

Equal, not equal, less than, less or equal than, greater than, greater or equal than. These conditions require one data pattern to be set with [TRIGger:SBHW:CAN:DMIN](#).

*RST: EQUal

Usage: Asynchronous command

Manual operation: See "[Data pattern](#)" on page 651

TRIGger:SBHW:CAN:DLC <DLC>

Sets the data length code, the number of data bytes to be found. For complete definition, set also the operator with [TRIGger:SBHW:CAN:DLCCondition](#).

Parameters:

<DLC> Range: CAN: 1 to 8, CAN FD: 1 to 15 (64 bytes)
 Increment: 1
 *RST: 0

Usage: Asynchronous command

Manual operation: See "[DLC](#)" on page 650

TRIGger:SBHW:CAN:DLCCondition <DLCOperator>

Operator to set the data length code.

The number of data bytes to be found is set with [TRIGger:SBHW:CAN:DLC](#).

Parameters:

<DLCOperator> EQUal | GETHan
 For little endian transfer direction, EQUal must be set.
 *RST: GETHan

Usage: Asynchronous command

Manual operation: See "[DLC](#)" on page 650

TRIGger:SBHW:CAN:DMIN <DataPattern>

Sets a data pattern, or sets the start value of a data pattern range.

Parameters:

<DataPattern> List of comma-separated values

Usage: Asynchronous command

Manual operation: See "[Data pattern](#)" on page 651

TRIGger:SBHW:CAN:FDATa:BRS <BRS_Bit>

Sets the bit rate switch bit.

Parameters:

<BRS_Bit> ONE | ZERO | DC
 ONE: the bit rate switches from the bit rate of the arbitration phase to the faster data rate.
 *RST: ONE

Usage: Asynchronous command

Manual operation: See "[BRS, ESI](#)" on page 651

TRIGger:SBHW:CAN:FDATa:DPOsition <DataPosition>

Defines the number of the first data byte at which the data pattern may start.

Parameters:

<DataPosition> Range: 1 to 2048
 Increment: 1
 *RST: 1

Usage: Asynchronous command

TRIGger:SBHW:CAN:FDATa:ESI <ESI_Bit>

Sets the error state indicator bit.

Parameters:

<ESI_Bit> ONE | ZERO | DC
 DC: do not care, bit is nor relevant.
 *RST: DC

Usage: Asynchronous command

Manual operation: See ["BRS, ESI"](#) on page 651

TRIGger:SBHW:CAN:FDATa:SCERror <StuffCntErr>

Triggers on stuff count errors. A stuff bit error occurs if more than five consecutive bits of the same level occur on the bus.

Available, if [TRIGger:SBHW:CAN:TYPE](#) is set to `ERRor`.

Parameters:

<StuffCntErr> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error conditions"](#) on page 652

TRIGger:SBHW:CAN:FORMerror <FormError>

Triggers when a fixed-form bit field contains one or more illegal bits.

Available, if [TRIGger:SBHW:CAN:TYPE](#) is set to `ERRC`.

Parameters:

<FormError> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error conditions"](#) on page 652

TRIGger:SBHW:CAN:FTYPe <FrameType>

Sets the CAN frame type.

Parameters:

<FrameType> CBFF | CBFR | CEFF | CEFR | FBFF | FEFF | XLFF | ERRor | OVERload

CBFF: classical base frame format data
 CBFR: classical base frame format remote
 CEFF: classical extended frame format data
 CEFR: classical extended frame format remote
 FBFF: FD base frame format
 FEFF: FD extended frame format
 XLFF: XL frame format
 ERR: error
 OVLD: overload
 *RST: CBFF

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 648

TRIGger:SBHW:CAN:ICONdition <IdOperator>

Sets the operator to set a specific identifier or an identifier range.

Parameters:

<IdOperator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan | INRange | OORange

EQUal | NEQual | LTHan | LETHan | GTHan | GETHan
 Equal, not equal, less than, less or equal than, greater than, greater or equal than. These conditions require one identifier pattern to be set with [TRIGger:SBHW:CAN:IMIN](#).

INRange | OORange
 In range / out of range: Set the minimum and maximum value of the range with [TRIGger:SBHW:CAN:IMIN](#) and [TRIGger:SBHW:CAN:IMAX](#).

*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Identifier"](#) on page 650

TRIGger:SBHW:CAN:IMAX <IdPattern>

Sets the end value of an identifier range if [TRIGger:SBHW:CAN:ICONdition](#) is set to INRange or OORange.

Parameters:

<IdPattern> List of comma-separated values

Usage: Asynchronous command
Manual operation: See "[Identifier](#)" on page 650

TRIGger:SBHW:CAN:IMIN <IdPattern>

Specifies a message identifier pattern, or sets the start value of an identifier range.

Parameters:
 <IdPattern>

Usage: Asynchronous command
Manual operation: See "[Identifier](#)" on page 650

TRIGger:SBHW:CAN:ITYPE <IdentifierType>

Selects the format of data and remote frames.

Remote frames are not available in the CAN FD protocol.

Parameters:
 <IdentifierType>

B11 | B29

B11

11-bit identifier (standard format). The instrument triggers on the sample point of the IDE bit.

B29

29-bit identifier (extended format). The instrument triggers on the sample point of the RTR bit.

*RST: B11

Usage: Asynchronous command
Manual operation: See "[ID type](#)" on page 651

TRIGger:SBHW:CAN:TYPE <Type>

Selects the trigger type for CAN analysis.

Parameters:
 <Type>

STOF | EDOF | FTYP | ID | IDDT | ERRC

STOF

Start of Frame: triggers on the first edge of the dominant SOF bit (synchronization bit).

FTYP

Frame type: triggers on a specified frame type and on the identifier format.

ID

Identifier: Sets the trigger to one specific identifier or an identifier range.

To set the identifier, use `TRIGger:SBHW:CAN:ICONdition`, `TRIGger:SBHW:CAN:IMAX`, and `TRIGger:SBHW:CAN:IMIN`.

IDDT

Identifier and data: Combination of identifier and data conditions.

To set the identifier condition, use `TRIGger:SBHW:CAN:ICONdition`, `TRIGger:SBHW:CAN:IMIN`, and `TRIGger:SBHW:CAN:IMAX`.

To set the data condition, use `TRIGger:SBHW:CAN:DCONdition` and `TRIGger:SBHW:CAN:DMIN`.

ERRC

Error condition: Define the error types with:

`TRIGger:SBHW:CAN:ACKerror`

`TRIGger:SBHW:CAN:BITSterror`

`TRIGger:SBHW:CAN:CRCErrors`

`TRIGger:SBHW:CAN:FORMerror`

`TRIGger:SBHW:CAN:FDATA:SCERror`

*RST: STOF

Usage: Asynchronous command

Manual operation: See "Type" on page 646

TRIGger:SBHW:CAN:XDATA:AF:CONDition <AfOperator>

Sets the comparison condition for the acceptance field to a specific value or a range.

Parameters:

<AfOperator>

`EQUal` | `NEQUal` | `LTHan` | `LETHan` | `GTHan` | `GETHan` | `INRange` | `OORange`

`EQUal` | `NEQUal` | `LTHan` | `LETHan` | `GTHan` | `GETHan`

Equal, not equal, less than, less or equal than, greater than, greater or equal than. These conditions require one pattern to be set with `TRIGger:SBHW:CAN:XDATA:AF:MIN`.

`INRange` | `OORange`

In range / out of range: Set the minimum and maximum value of the range with `TRIGger:SBHW:CAN:XDATA:AF:MIN` and `TRIGger:SBHW:CAN:XDATA:AF:MAX`.

*RST: EQUal

Usage: Asynchronous command

Manual operation: See "AF" on page 652

TRIGger:SBHW:CAN:XDATA:AF:MAX <AfPatternTo>

Sets the end value of an acceptance field if **TRIGger:SBHW:CAN:XDATA:AF:CONDition** is set to **INRange** or **OORange**.

Parameters:

<AfPatternTo> List of comma-separated values

Usage: Asynchronous command

Manual operation: See "**AF**" on page 652

TRIGger:SBHW:CAN:XDATA:AF:MIN <AfPattern>

Specifies an acceptance field pattern, or sets the start value of a range.

Parameters:

<AfPattern> List of comma-separated values

Usage: Asynchronous command

Manual operation: See "**AF**" on page 652

TRIGger:SBHW:CAN:XDATA:SDT:CONDition <SdtOperator>

Sets the comparison condition for the service data unit type to a specific value or a range.

Parameters:

<SdtOperator> **EQUal** | **NEQual** | **LTHan** | **LETHan** | **GTHan** | **GETHan** | **INRange** | **OORange**

EQUal | **NEQual** | **LTHan** | **LETHan** | **GTHan** | **GETHan**

Equal, not equal, less than, less or equal than, greater than, greater or equal than. These conditions require one pattern to be set with **TRIGger:SBHW:CAN:XDATA:SDT:MIN**.

INRange | **OORange**

In range / out of range: Set the minimum and maximum value of the range with **TRIGger:SBHW:CAN:XDATA:SDT:MIN** and **TRIGger:SBHW:CAN:XDATA:SDT:MAX**.

*RST: **EQUal**

Usage: Asynchronous command

Manual operation: See "**SDT**" on page 651

TRIGger:SBHW:CAN:XDATA:SDT:MAX <SdtPatternTo>

Sets the end value of a service data unit type range if **TRIGger:SBHW:CAN:XDATA:SDT:CONDition** is set to **INRange** or **OORange**.

Parameters:

<SdtPatternTo> List of comma-separated values

Usage: Asynchronous command

Manual operation: See ["SDT"](#) on page 651

TRIGger:SBHW:CAN:XDATA:SDT:MIN <SdtPattern>

Specifies a service data unit type pattern, or sets the start value of a range.

Parameters:

<SdtPattern> List of comma-separated values

Usage: Asynchronous command

Manual operation: See ["SDT"](#) on page 651

TRIGger:SBHW:CAN:XDATA:SEC <SEC_Bit>

Sets a value for the simple extended content (SEC) field. It indicates, if the CAN XL data frame uses the CADsec protocol.

Parameters:

<SEC_Bit> ONE | ZERO | DC
*RST: DC

Usage: Asynchronous command

Manual operation: See ["SEC"](#) on page 652

TRIGger:SBHW:CAN:XDATA:VCID:CONDition <VcidOperator>

Sets the comparison condition for the VCID to a specific value or a range.

Parameters:

<VcidOperator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan |
INRange | OORange
EQUal | NEQual | LTHan | LETHan | GTHan | GETHan
Equal, not equal, less than, less or equal than, greater than,
greater or equal than. These conditions require one pattern to be
set with [TRIGger:SBHW:CAN:XDATA:VCID:MIN](#).

INRange | OORange

In range / out of range: Set the minimum and maximum value of
the range with [TRIGger:SBHW:CAN:XDATA:VCID:MIN](#) and
[TRIGger:SBHW:CAN:XDATA:VCID:MAX](#).

*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["VCID"](#) on page 652

TRIGger:SBHW:CAN:XDATA:VCID:MAX <VcidPatternTo>

Sets the end value of a VCID range if **TRIGger:SBHW:CAN:XDATA:VCID:CONDition** is set to **INRange** or **ORange**.

Parameters:

<VcidPatternTo> List of comma-separated values

Usage: Asynchronous command

Manual operation: See "**VCID**" on page 652

TRIGger:SBHW:CAN:XDATA:VCID:MIN <VcidPattern>

Specifies a VCID pattern, or sets the start value of a range.

Parameters:

<VcidPattern> List of comma-separated values

Usage: Asynchronous command

Manual operation: See "**VCID**" on page 652

18.18.10.4 Software trigger

There are two commands for each parameter, that you can use for defining the CAN settings.

For example, to set the *Frame type =CBFF > Field =Data >Data* value you can use one of the following commands:

- **TRIGger:SBSW:CAN:FRAME1:FLD1:DMIN 01100**
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- **TRIGger:SBSW:CAN:DMIN "CBFF", "Data", 01100**
Defines the parameter by using the frame and field name.

TRIGger:SBSW:CAN:CHKall	1560
TRIGger:SBSW:CAN:CLR	1560
TRIGger:SBSW:CAN:INVert	1560
TRIGger:SBSW:CAN:RST	1560
TRIGger:SBSW:CAN:FRENable	1561
TRIGger:SBSW:CAN:FRAME<fr>:ENABle	1561
TRIGger:SBSW:CAN:BIT	1561
TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:BIT	1561
TRIGger:SBSW:CAN:DMAx	1561
TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:DMAx	1561
TRIGger:SBSW:CAN:DMIN	1562
TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:DMIN	1562
TRIGger:SBSW:CAN:DOPerator	1562
TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:DOPerator	1562
TRIGger:SBSW:CAN:FIENable	1562
TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:ENABle	1562

TRIGger:SBSW:CAN:IMAX.....	1563
TRIGger:SBSW:CAN:FRAMe<fr>:FLD<fl>:IMAX.....	1563
TRIGger:SBSW:CAN:IMIN.....	1563
TRIGger:SBSW:CAN:FRAMe<fr>:FLD<fl>:IMIN.....	1563
TRIGger:SBSW:CAN:IOPerator.....	1564
TRIGger:SBSW:CAN:FRAMe<fr>:FLD<fl>:IOPerator.....	1564
TRIGger:SBSW:CAN:ERENable.....	1564
TRIGger:SBSW:CAN:ERRor<m>:ENABLE.....	1564
SBUS<sb>:CAN:SWTIndex?.....	1564
SBUS<sb>:CAN:SWTTime?.....	1565

TRIGger:SBSW:CAN:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 655

TRIGger:SBSW:CAN:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 655

TRIGger:SBSW:CAN:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 655

TRIGger:SBSW:CAN:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 655

TRIGger:SBSW:CAN:FRENAble <Frame>,<Enabler>

TRIGger:SBSW:CAN:FRENAble? <Enabler>

TRIGger:SBSW:CAN:FRAME<fr>:ENABle <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 655

TRIGger:SBSW:CAN:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:CAN:BIT? <Bit>

TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO

*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 655

TRIGger:SBSW:CAN:DMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:CAN:DMAX? <Data>

TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGE.

You can set the operator with [TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:DOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 655

TRIGger:SBSW:CAN:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:CAN:DMIN? <Data>

TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 655

TRIGger:SBSW:CAN:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:CAN:DOPerator? <Operator>

TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange
*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 655

TRIGger:SBSW:CAN:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:CAN:FIENable? <Enabler>

TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:ENABLe <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 655

TRIGger:SBSW:CAN:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:CAN:IMAX? <Data>

TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with [TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:IOperator](#).

Suffix:

<fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 655

TRIGger:SBSW:CAN:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:CAN:IMIN? <Data>

TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 655

TRIGger:SBSW:CAN:IOperator <Frame>,<Field>,<Operator>

TRIGger:SBSW:CAN:IOperator? <Operator>

TRIGger:SBSW:CAN:FRAME<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUAL | INRange | RANGE

*RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 655

TRIGger:SBSW:CAN:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:CAN:ERENable? <Enabler>

TRIGger:SBSW:CAN:ERROR<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 657

SBUS<sb>:CAN:SWTindex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295

Increment: 1

*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

18.18.10.5 Decode results

SBUS<sb>:CAN:FCOUNT?	1566
SBUS<sb>:CAN:FRAME<fr>:FLDCOUNT?	1566
SBUS<sb>:CAN:FRAME<fr>:ACKSTATE?	1566
SBUS<sb>:CAN:FRAME<fr>:ACKVALUE?	1566
SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:STATE?	1567
SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:LABEL?	1568
SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:VALUE?	1568
SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:FVALUE?	1568
SBUS<sb>:CAN:FRAME<fr>:CSSTATE?	1569
SBUS<sb>:CAN:FRAME<fr>:CSVALUE?	1569
SBUS<sb>:CAN:FRAME<fr>:DATA?	1569
SBUS<sb>:CAN:FRAME<fr>:DLCSTATE?	1570
SBUS<sb>:CAN:FRAME<fr>:DLCVALUE?	1570
SBUS<sb>:CAN:FRAME<fr>:IDSTATE?	1570
SBUS<sb>:CAN:FRAME<fr>:IDTYPE?	1571
SBUS<sb>:CAN:FRAME<fr>:IDVALUE?	1571
SBUS<sb>:CAN:FRAME<fr>:NDBYTES?	1571
SBUS<sb>:CAN:FRAME<fr>:START?	1572
SBUS<sb>:CAN:FRAME<fr>:STATUS?	1572
SBUS<sb>:CAN:FRAME<fr>:STOP?	1572
SBUS<sb>:CAN:FRAME<fr>:SYMBOL?	1573
SBUS<sb>:CAN:FRAME<fr>:TYPE?	1573
SBUS<sb>:CAN:FRAME<fr>:XDATAB<o>:AF?	1574
SBUS<sb>:CAN:FRAME<fr>:XDATAB<o>:PCRC?	1574
SBUS<sb>:CAN:FRAME<fr>:SBC?	1574
SBUS<sb>:CAN:FRAME<fr>:XDATAB<o>:SDT?	1575
SBUS<sb>:CAN:FRAME<fr>:XDATAB<o>:SEC?	1575
SBUS<sb>:CAN:FRAME<fr>:XDATAB<o>:VCID?	1575
SBUS<sb>:CAN:FRAME<fr>:FDATAB<o>:ESI?	1576
SBUS<sb>:CAN:FRAME<fr>:FDATAB<o>:BRS?	1576

SBUS<sb>:CAN:FRAME<fr>:DBITrate?	1576
SBUS<sb>:CAN:FRAME<fr>:NBITrate?	1577
SBUS<sb>:CAN:FRAME<fr>:XDATA<o>:FCRC?	1577

SBUS<sb>:CAN:FCount?

Returns the number of decoded frames for the CAN protocol analysis.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count> Total number of frames.

Usage:

Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:FLDCount?

Returns the number of fields in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Count>

Usage:

Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:ACKState?

Return the states of the acknowledgment field.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameAckState> OK | ERRor | UNDF
UNDF: Undefined
*RST: OK

Usage:

Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:ACKValue?

Returns the value of the acknowledge slot for the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameAckValue> Range: 0 to 1
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:STATe?

Returns the state of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> *
Selects the field number.

Return values:

<State> OK | EOFD | ACKD | NOACK | CRCd | CRC | SERRror |
FORM | BTST | UNKNown | INComplete

OK

The field has no error, it is valid.

EOFD

Wrong end of field

ACKD

Acknowledgment delimiter error

NOACK

Field acknowledgment is missing

CRCd

Checksum delimiter error

CRC

Checksum error, cyclic redundancy check failed

SERRror

Stuff count error (CAN-FD ISO only)

FORM

Fixed-bit form error

BTST

Bit stuffing error

UNKNown

State unknown

INComplete

Field not completely contained in the acquisition.

*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:LABel?

Returns the label of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Label>

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:VALue?

Returns the value of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> *
Index of the field

Return values:

<Value> Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<FormattedValue>

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:CSState?

Return the states of the checksum field (CRC).

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <ChecksumState> OK | ERRor | UNDF
 *RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:CSValue?

Returns the CRC sequence value of the selected frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <ChecksumValue> Range: 0 to 4294967295
 Increment: 1
 *RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:DATA?

Returns the data of the specified frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <Count> Comma-separated list of values. The first value is the number of bytes, followed by the values of the data bytes.

<Values>

Example: BUS1:CAN:FRAME2:DATA?
 --> 3,208,231,32

Returns the data of the 2nd frame: the number of data bytes is 3 (see 1st value).

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:DLCState?

Return the states of the state of data length code.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <FrameDLCState> OK | ERRor | UNDF
 *RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:DLCValue?

Returns the data length code of the selected frame - the number of data bytes in the frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <FrameDLCValue> Range: 0 to 2047
 Increment: 1
 *RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:IDState?

Return the states of the identifier state.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <IdtfSt> OK | ERRor | UNDF
 UNDF: Undefined
 *RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:IDType?

Returns the identifier type of the selected frame, the identifier format of data and remote frames.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<IdentifierType> B11 | B29
 B11: standard format, 11 bit
 B29: extended format, 29 bit
 *RST: B11

Usage:

Query only
 Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:IDValue?

Returns the identifier value of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<IdtfVal> Range: 0 to 536870911
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:NDBYtes?

Returns the number of data bytes.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<NDBytes> Range: 0 to 2048
 Increment: 1
 *RST: 1

Usage:

Query only
 Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:START?

Return the start time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStart> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage: Query only
 Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:STATUs?

Returns the overall state of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameState> OK | EOFD | ACKD | NOACK | CRCD | CRC | SERRror |
 FORM | BTST | UNKNown | INComplete

OK: the frame is valid.
 EOFD: Wrong end of frame.
 ACKD: Wrong ACK delimiter occurred.
 NOACK: Acknowledge is missing.
 CRCD: Wrong CRC delimiter occurred.
 CRC: Cyclic redundancy check failed.
 SERRror: Stuff count error (CAN FD ISO only).
 FORM: Fixed-bit form error.
 BTST: Bit stuffing error occurred.
 INSufficient: The frame is not completely contained in the
 acquisition. The acquired part of the frame is valid.
 *RST: OK

Usage: Query only
 Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:STOP?

Return the stop time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage: Query only
 Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:SYMBOL?

Returns the symbol of the specified frame if the label list is enabled.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Label> String with symbol of the identifier

Example: BUS:CAN:FRAME:SYMBOL?
 Response: Temperature

Usage: Query only

SBUS<sb>:CAN:FRAME<fr>:TYPE?

Returns the frame type of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameType> CBFF | CBFR | CEFF | CEFR | FBFF | FEFF | XLFF | ERRor |
 OVERload | UNDEFINED

CBFF: classical base frame format data
 CBFRremote: classical base frame format remote
 CEFF: classical extended frame format data
 CEFRremote: classical extended frame format remote
 FBFF: FD base frame format
 FEFF: FD extended frame format
 XLFF: XL frame format
 ERR: error
 OVLd: overload
 *RST: CBFF

Usage: Query only
 Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:XDATa<o>:AF?

Returns the value of the acceptance field for the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<o> Index of the field

Return values:

<AF> Range: 0 to 4294967295

 Increment: 1

 *RST: 0

Usage: Query only

 Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:XDATa<o>:PCRC?

Returns the value of the preamble cyclic redundant check (PCRC) for the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<o> Index of the field

Return values:

<PCRC> Range: 0 to 65535

 Increment: 1

 *RST: 0

Usage: Query only

 Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:SBC?

Returns the value of the stuff bit count (SBC) field for the selected CAN XL frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<SBC> Range: 0 to 15

 Increment: 1

 *RST: 0

Usage: Query only

 Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:XDATa<o>:SDT?

Returns the value of the service data unit field for the selected frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<o>	Index of the field

Return values:

<SDT>	Range: 0 to 255
	Increment: 1
	*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:XDATa<o>:SEC?

Returns the value of the simple extended content (SEC) field for the selected CAN XL frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<o>	Index of the field

Return values:

<SEC>	Range: 0 to 1
	Increment: 1
	*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:XDATa<o>:VCID?

Returns the value of the VCID field for the selected CAN XL frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<o>	Index of the field

Return values:

<VCID>	Range: 0 to 255
	Increment: 1
	*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:FDATa<o>:ESI?

Returns the value of the error state indicator (ESI) field for the selected frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<o> Index of the field

Return values:
<ESI> Range: 0 to 1
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:FDATa<o>:BRS?

Returns the value of the bit rate switch (BRS) field for the selected frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<o> Index of the field

Return values:
<BRS> Range: 0 to 1
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:DBITrate?

Returns the data bit rate of the frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:
<DataBitRate> Increment: 100
*RST: 0
Default unit: bps

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:NBITrate?

Returns the nominal bit rate of the frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<NominalBitRate> Increment: 1
*RST: 0
Default unit: bps

Usage: Query only
Asynchronous command

SBUS<sb>:CAN:FRAME<fr>:XDATa<o>:FCRC?

Returns the value of the frame CRC for the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<o> Index of the field

Return values:

<FCRC> Range: 0 to 4294967295
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

18.18.11 LIN (option R&S MXO5C-K520)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with `SBUS<sb>[:STATe]`.
- The bus is set to the correct type with `SBUS<sb>:TYPE`.

• Configuration	1578
• Filter	1581
• Hardware trigger	1586
• Software trigger	1589
• Decode results	1595

18.18.11.1 Configuration

SBUS<sb>:LIN:BITRate.....	1578
SBUS<sb>:LIN:DATA:HYSTeresis.....	1578
SBUS<sb>:LIN:DATA:SOURce.....	1578
SBUS<sb>:LIN:DATA:THReshold.....	1579
SBUS<sb>:LIN:POLarity.....	1579
SBUS<sb>:LIN:STANdard.....	1579
SBUS<sb>:LIN:POSition.....	1580
SBUS<sb>:LIN:SCALe.....	1580
SBUS<sb>:LIN:NEWLlist.....	1580
SBUS<sb>:LIN:SYMBols.....	1580

SBUS<sb>:LIN:BITRate <Bitrate>

Sets the number of transmitted bits per second. The maximum bit rate for LIN is 20 kbit/s.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Bitrate> Range: 1000 to 20000000
Increment: 1
*RST: 9600
Default unit: bps

Usage: Asynchronous command

Manual operation: See ["Bit rate"](#) on page 668

SBUS<sb>:LIN:DATA:HYSTeresis <Hysteresis>

Sets a value for the hysteresis for the data channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 669

SBUS<sb>:LIN:DATA:SOURce <DataSource>

Sets the waveform of the data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DataSource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
 | D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
 | M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
 R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["Data"](#) on page 668

SBUS<sb>:LIN:DATA:THReshold <Threshold>

Sets a user-defined threshold value for the data channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 669

SBUS<sb>:LIN:POLarity <Polarity>

Defines the idle state of the bus. The idle state is the recessive state and corresponds to a logic 1.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Polarity> IDLLow | IDLHigh
 *RST: IDLHigh

Usage: Asynchronous command

Manual operation: See ["Polarity"](#) on page 668

SBUS<sb>:LIN:STANdard <Standard>

Selects the version of the LIN standard.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Standard> V1X | V2X | J2602 | AUTO
 *RST: AUTO

Usage: Asynchronous command

Manual operation: See ["LIN standard"](#) on page 668

SBUS<sb>:LIN:POSition <LIN position>

Sets the vertical position of the LIN signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<LIN position>

Usage:

Asynchronous command

SBUS<sb>:LIN:SCALE <LIN scale>

Set the vertical scale of the indicated LIN signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<LIN scale>

Usage:

Asynchronous command

SBUS<sb>:LIN:NEWList <FileName>

Loads a symbol list file.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName> String parameter with path and file name.

Example:

```
SBUS1:LIN:NEWList  
'/home/storage/userData/Protocol/LIN.csv'  
SBUS1:LIN:SYMBOLs ON
```

Usage:

Setting only
Asynchronous command

SBUS<sb>:LIN:SYMBOLs <ShowSymbols>

Activates the symbol list to be used for decoding.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ShowSymbols> OFF | ON
*RST: OFF

Usage:

Asynchronous command

18.18.11.2 Filter

There are two commands for each parameter, that you can use for defining the LIN settings.

For example, to set the *Frame type =Data > Field =Id >00* value you can use one of the following commands:

- `SBUS:LIN:FILTer:FRAMe1:FLD1:DMIN 00`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `SBUS:LIN:FILTer:DMIN "Data", "Id", 00`
Defines the parameter by using the frame and field name.

<code>SBUS<sb>:LIN:FILTer:CHKall</code>	1581
<code>SBUS<sb>:LIN:FILTer:CLR</code>	1582
<code>SBUS<sb>:LIN:FILTer:INVert</code>	1582
<code>SBUS<sb>:LIN:FILTer:RST</code>	1582
<code>SBUS<sb>:LIN:FILTer:BIT</code>	1582
<code>SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:BIT</code>	1582
<code>SBUS<sb>:LIN:FILTer:DMAX</code>	1583
<code>SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:DMAX</code>	1583
<code>SBUS<sb>:LIN:FILTer:DMIN</code>	1583
<code>SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:DMIN</code>	1583
<code>SBUS<sb>:LIN:FILTer:DOPerator</code>	1583
<code>SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:DOPerator</code>	1583
<code>SBUS<sb>:LIN:FILTer:ERENable</code>	1584
<code>SBUS<sb>:LIN:FILTer:ERRor<n>:ENABle</code>	1584
<code>SBUS<sb>:LIN:FILTer:FIENable</code>	1584
<code>SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:ENABle</code>	1584
<code>SBUS<sb>:LIN:FILTer:FRENable</code>	1584
<code>SBUS<sb>:LIN:FILTer:FRAMe<fr>:ENABle</code>	1584
<code>SBUS<sb>:LIN:FILTer:IMAX</code>	1585
<code>SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:IMAX</code>	1585
<code>SBUS<sb>:LIN:FILTer:IMIN</code>	1585
<code>SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:IMIN</code>	1585
<code>SBUS<sb>:LIN:FILTer:IOPerator</code>	1586
<code>SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:IOPerator</code>	1586

SBUS<sb>:LIN:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See "[Check all](#), [Clear](#), [Invert](#), [Preset](#)" on page 670

SBUS<sb>:LIN:FILTER:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 670

SBUS<sb>:LIN:FILTER:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 670

SBUS<sb>:LIN:FILTER:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 670

SBUS<sb>:LIN:FILTER:BIT <Frame>,<Field>,<Bit>**SBUS<sb>:LIN:FILTER:BIT? <Bit>****SBUS<sb>:LIN:FILTER:FRAMe<fr>:FLD<fl>:BIT <BitState>**

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 671

SBUS<sb>:LIN:FILTER:DMAX <Frame>,<Field>,<Data>

SBUS<sb>:LIN:FILTER:DMAX? <Data>

SBUS<sb>:LIN:FILTER:FRAME<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range if the operator is set to `INRange` or `OORANGE`.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 671

SBUS<sb>:LIN:FILTER:DMIN <Frame>,<Field>,<Data>

SBUS<sb>:LIN:FILTER:DMIN? <Data>

SBUS<sb>:LIN:FILTER:FRAME<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 671

SBUS<sb>:LIN:FILTER:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:LIN:FILTER:DOPerator? <Operator>

SBUS<sb>:LIN:FILTER:FRAME<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUAL | NEQUAL | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUAL

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 671

SBUS<sb>:LIN:FILTER:ERENable <ErrorName>,<Enabler>

SBUS<sb>:LIN:FILTER:ERENable? <Enabler>

SBUS<sb>:LIN:FILTER:ERRor<n>:ENABLE <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 672

SBUS<sb>:LIN:FILTER:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:LIN:FILTER:FIENable? <Enabler>

SBUS<sb>:LIN:FILTER:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 671

SBUS<sb>:LIN:FILTER:FRENable <Frame>,<Enabler>

SBUS<sb>:LIN:FILTER:FRENable? <Enabler>

SBUS<sb>:LIN:FILTER:FRAME<fr>:ENABLE <Enable>

Enables the filtering on LIN frames. Only the frames that match the selected filter conditions are displayed.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Parameters:****<Enable>** OFF | ON***RST:** ON**Usage:** Asynchronous command**Manual operation:** See ["Frame type"](#) on page 671**SBUS<sb>:LIN:FILTER:IMAX** <Frame>,<Field>,<Data>**SBUS<sb>:LIN:FILTER:IMAX?** <Data>**SBUS<sb>:LIN:FILTER:FRAME<fr>:FLD<fl>:IMAX** <Index_Max>Sets the end value of an index range if the operator is set to `INRange`.**Suffix:****<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<Index_Max>** Range: 1 to 65535

Increment: 1

***RST:** 65535**Usage:** Asynchronous command**Manual operation:** See ["Edit"](#) on page 671**SBUS<sb>:LIN:FILTER:IMIN** <Frame>,<Field>,<Data>**SBUS<sb>:LIN:FILTER:IMIN?** <Data>**SBUS<sb>:LIN:FILTER:FRAME<fr>:FLD<fl>:IMIN** <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<Index_Min>** Range: 1 to 65535

Increment: 1

***RST:** 1**Usage:** Asynchronous command**Manual operation:** See ["Edit"](#) on page 671

SBUS<sb>:LIN:FILTER:IOPerator <Frame>, <Field>, <Operator>

SBUS<sb>:LIN:FILTER:IOPerator? <Operator>

SBUS<sb>:LIN:FILTER:FRAME<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGe

*RST: INRange

Usage: Asynchronous command

Manual operation: See "Edit" on page 671

18.18.11.3 Hardware trigger

Trigger commands for serial buses affect the current trigger source. Therefore, set the trigger source to the required serial bus with **TRIGger:EVENT<ev>:SOURCE** before sending the bus-specific trigger commands.

TRIGger:SBHW:LIN:TYPE	1586
TRIGger:SBHW:LIN:SYERror	1587
TRIGger:SBHW:LIN:IPERror	1587
TRIGger:SBHW:LIN:IMIN	1587
TRIGger:SBHW:LIN:IMAX	1588
TRIGger:SBHW:LIN:ICONdition	1588
TRIGger:SBHW:LIN:DPOStion	1588
TRIGger:SBHW:LIN:DMIN	1588
TRIGger:SBHW:LIN:DCONdition	1589
TRIGger:SBHW:LIN:CHKSError	1589

TRIGger:SBHW:LIN:TYPE <Type>

Selects the trigger type for LIN analysis.

Parameters:

<Type> STARTframe | ID | IDDT | WKFR | ERRC

STARTframe

Start of the frame. Triggers on the stop bit of the sync field.

ID

Sets the trigger to one specific identifier or an identifier range.

IDDT

Combination of identifier and data conditions.

WKFR

Wake-up frame.

ERRC

Error condition. Define the error types with:

[TRIGger:SBHW:LIN:CHKSError](#)

[TRIGger:SBHW:LIN:IPERror](#)

[TRIGger:SBHW:LIN:SYERror](#)

*RST: STARTframe

Usage: Asynchronous command

Manual operation: See ["Type"](#) on page 673

TRIGger:SBHW:LIN:SYERror <SyncError>

Triggers if a synchronization error occurs.

Available, if [TRIGger:SBHW:LIN:TYPE](#) is set to `ERRC`.

Parameters:

<SyncError> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error conditions"](#) on page 674

TRIGger:SBHW:LIN:IPERror <IdParityError>

Triggers if an error occurs in the identifier parity bits. The parity bits are the bits 6 and 7 of the identifier.

Available, if [TRIGger:SBHW:LIN:TYPE](#) is set to `ERRC`.

Parameters:

<IdParityError> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error conditions"](#) on page 674

TRIGger:SBHW:LIN:IMIN <IdPattern>

Specifies a secondary identifier pattern, or sets the start value of an identifier range.

Parameters:

<IdPattern>

Usage: Asynchronous command

Manual operation: See ["Identifier setup: Condition, Frame ID min, Frame ID max"](#) on page 674

TRIGger:SBHW:LIN:IMAX <IdPattern>

Sets the end value of an identifier range if [TRIGger:SBHW:LIN:ICONdition](#) is set to [INRange](#) or [OORange](#).

Parameters:

<IdPattern>

Usage: Asynchronous command

Manual operation: See ["Identifier setup: Condition, Frame ID min, Frame ID max"](#) on page 674

TRIGger:SBHW:LIN:ICONdition <IdOperator>

Sets the operator to set a specific identifier or an identifier range.

Parameters:

<IdOperator>

[EQUal](#) | [NEQual](#) | [LTHan](#) | [LETHan](#) | [GTHan](#) | [GETHan](#) | [INRange](#) | [OORange](#)

[EQUal](#) | [NEQual](#) | [LTHan](#) | [LETHan](#) | [GTHan](#) | [GETHan](#)

Equal, not equal, less than, less or equal than, greater than, greater or equal than. These conditions require one identifier pattern to be set with [TRIGger:SBHW:LIN:IMIN](#).

[INRange](#) | [OORange](#)

In range / out of range: Set the minimum and maximum value of the range with [TRIGger:SBHW:LIN:IMIN](#) and [TRIGger:SBHW:LIN:IMAX](#).

*RST: [EQUal](#)

Usage: Asynchronous command

Manual operation: See ["Identifier setup: Condition, Frame ID min, Frame ID max"](#) on page 674

TRIGger:SBHW:LIN:DPOStion <DataPosition>

Sets the number of data events that are ignored, before trigger condition check of the data starts.

Parameters:

<DataPosition>

Range: 1 to 4096

Increment: 1

*RST: 1

Usage: Asynchronous command

Manual operation: See ["Data setup: Condition, Pattern, Position"](#) on page 674

TRIGger:SBHW:LIN:DMIN <DataPattern>

Specifies a data pattern, or sets the start value of a data pattern range.

Parameters:

<DataPattern>

Usage:

Asynchronous command

Manual operation:See ["Data setup: Condition, Pattern, Position"](#) on page 674**TRIGger:SBHW:LIN:DCondition** <DataOperator>

Sets the operator to set a specific data pattern or a data pattern range.

Parameters:

<DataOperator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan

*RST: EQUal

Usage:

Asynchronous command

Manual operation:See ["Data setup: Condition, Pattern, Position"](#) on page 674**TRIGger:SBHW:LIN:CHKSError** <ChecksumError>

Triggers on checksum errors.

Available, if [TRIGger:SBHW:LIN:TYPE](#) is set to ERRC.**Parameters:**

<ChecksumError> OFF | ON

*RST: ON

Usage:

Asynchronous command

Manual operation:See ["Error conditions"](#) on page 674**18.18.11.4 Software trigger**

There are two commands for each parameter, that you can use for defining the LIN settings.

For example, to set the *Frame type =Data > Field =Id >00* value you can use one of the following commands:

- `TRIGger:SBSW:LIN:FRAME1:FLD1:DMIN 00`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `TRIGger:SBSW:LIN:DMIN "Data", "Id", 00`
Defines the parameter by using the frame and field name.

TRIGger:SBSW:LIN:CHKall	1590
TRIGger:SBSW:LIN:CLR	1590
TRIGger:SBSW:LIN:INVert	1590
TRIGger:SBSW:LIN:RST	1590
TRIGger:SBSW:LIN:FRENable	1591
TRIGger:SBSW:LIN:FRAME<fr>:ENABLE	1591
TRIGger:SBSW:LIN:BIT	1591

TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:BIT.....	1591
TRIGger:SBSW:LIN:DMAX.....	1591
TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:DMAX.....	1591
TRIGger:SBSW:LIN:DMIN.....	1592
TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:DMIN.....	1592
TRIGger:SBSW:LIN:DOPerator.....	1592
TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:DOPerator.....	1592
TRIGger:SBSW:LIN:FIENable.....	1592
TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:ENABle.....	1592
TRIGger:SBSW:LIN:IMAX.....	1593
TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:IMAX.....	1593
TRIGger:SBSW:LIN:IMIN.....	1593
TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:IMIN.....	1593
TRIGger:SBSW:LIN:IOperator.....	1594
TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:IOperator.....	1594
TRIGger:SBSW:LIN:ERENable.....	1594
TRIGger:SBSW:LIN:ERRor<m>:ENABle.....	1594
SBUS<sb>:LIN:SWTindex?.....	1594
SBUS<sb>:LIN:SWTTime?.....	1595

TRIGger:SBSW:LIN:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 676

TRIGger:SBSW:LIN:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 676

TRIGger:SBSW:LIN:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 676

TRIGger:SBSW:LIN:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 676

TRIGger:SBSW:LIN:FREnable <Frame>,<Enabler>

TRIGger:SBSW:LIN:FREnable? <Enabler>

TRIGger:SBSW:LIN:FRAMe<fr>:ENABle <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:
<fr> Index of the frame

Parameters:
<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 676

TRIGger:SBSW:LIN:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:LIN:BIT? <Bit>

TRIGger:SBSW:LIN:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:
<fr> Index of the frame
<fl> Index of the field

Parameters:
<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 677

TRIGger:SBSW:LIN:DMAx <Frame>,<Field>,<Data>

TRIGger:SBSW:LIN:DMAx? <Data>

TRIGger:SBSW:LIN:FRAMe<fr>:FLD<fl>:DMAx <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGe.

You can set the operator with [TRIGger:SBSW:LIN:FRAMe<fr>:FLD<fl>:DOPerator](#).

Suffix:
<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 677

TRIGger:SBSW:LIN:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:LIN:DMIN? <Data>

TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 677

TRIGger:SBSW:LIN:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:LIN:DOPerator? <Operator>

TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUAL | NEQUAL | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUAL

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 677

TRIGger:SBSW:LIN:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:LIN:FIENable? <Enabler>

TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 677**TRIGger:SBSW:LIN:IMAX** <Frame>,<Field>,<Data>**TRIGger:SBSW:LIN:IMAX?** <Data>**TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:IMAX** <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with [TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:IOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535

Increment: 1

*RST: 65535

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 677**TRIGger:SBSW:LIN:IMIN** <Frame>,<Field>,<Data>**TRIGger:SBSW:LIN:IMIN?** <Data>**TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:IMIN** <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535

Increment: 1

*RST: 1

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 677

TRIGger:SBSW:LIN:IOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:LIN:IOPerator? <Operator>

TRIGger:SBSW:LIN:FRAMe<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGe

*RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 677

TRIGger:SBSW:LIN:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:LIN:ERENable? <Enabler>

TRIGger:SBSW:LIN:ERRor<m>:ENABle <Enable>

Defines the error type for the software trigger.

Suffix:

<m> Index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 678

SBUS<sb>:LIN:SWTindex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295

Increment: 1

*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:LIN:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

18.18.11.5 Decode results

The following section describes the commands used for querying the results of the LIN decoding.

SBUS<sb>:LIN:FCOunt?	1595
SBUS<sb>:LIN:FRAMe<fr>:FLDCount?	1596
SBUS<sb>:LIN:FRAMe<fr>:BITRate?	1596
SBUS<sb>:LIN:FRAMe<fr>:FLD<fl>:STATe?	1596
SBUS<sb>:LIN:FRAMe<fr>:FLD<fl>:VALue?	1597
SBUS<sb>:LIN:FRAMe<fr>:FLD<fl>:FVALue?	1597
SBUS<sb>:LIN:FRAMe<fr>:FLD<fl>:LABeI?	1597
SBUS<sb>:LIN:FRAMe<fr>:CSValue?	1598
SBUS<sb>:LIN:FRAMe<fr>:DATA?	1598
SBUS<sb>:LIN:FRAMe<fr>:IDPValue?	1598
SBUS<sb>:LIN:FRAMe<fr>:IDValue?	1599
SBUS<sb>:LIN:FRAMe<fr>:STARt?	1599
SBUS<sb>:LIN:FRAMe<fr>:STATus?	1599
SBUS<sb>:LIN:FRAMe<fr>:STOP?	1600
SBUS<sb>:LIN:FRAMe<fr>:SYMBol?	1600
SBUS<sb>:LIN:FRAMe<fr>:PIDentifier?	1600

SBUS<sb>:LIN:FCOunt?

Returns the number of decoded frames.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count> Total number of decoded frames.

Usage:

Query only
Asynchronous command

SBUS<sb>:LIN:FRAMe<fr>:FLDCount?

Returns the number of fields in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Count> Total number of fields.

Usage:

Query only
Asynchronous command

SBUS<sb>:LIN:FRAMe<fr>:BITRate?

Returns the primary bit rate.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<PrimaryBitRate> Increment: 1
*RST: 0
Default unit: bps

Usage:

Query only
Asynchronous command

SBUS<sb>:LIN:FRAMe<fr>:FLD<fl>:STATe?

Returns the state of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<State> OK | WAKeup | CHCKsum | PRERror | STERror | SYERror |
LNERror | UNK | INComplete

OK

The field has no error, it is valid.

WAKeup

Wakeup bit missing

CHCKsum

Checksum error

PRERror

Parity error, incorrect parity bit

STERror

Start error, incorrect start bit

SYERror

Synchronization error, incorrect synchronization bit

LNERror

Length error

UNKNown

State unknown

INComplete

Field not completely contained in the acquisition.

*RST: OK

Usage:

Query only

Asynchronous command

SBUS<sb>:LIN:FRAMe<fr>:FLD<fl>:VALue?

Returns the value of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Value> Increment: 1

*RST: 0

Usage:

Query only

Asynchronous command

SBUS<sb>:LIN:FRAMe<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<FormattedValue>

Usage:

Query only

Asynchronous command

SBUS<sb>:LIN:FRAMe<fr>:FLD<fl>:LABel?

Returns the label of the fields in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Label>

Usage:

Query only
Asynchronous command

SBUS<sb>:LIN:FRAME<fr>:CSValue?

Returns the checksum value of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<ChecksumValue> Range: 0 to 255
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:LIN:FRAME<fr>:DATA?

Returns the data bytes of the specified frame in comma-separated values.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Count>

<Values>

Example:

BUS:LIN:FRAME4:DATA?
<-- 4,118,39,71,123

Usage:

Query only
Asynchronous command

SBUS<sb>:LIN:FRAME<fr>:IDPValue?

Returns the value of the identifier parity bits of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<IdtfParVal> Range: 0 to 3
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:LIN:FRAME<fr>:IDValue?

Returns the identifier value of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<IdtfVal> Range: 0 to 63
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:LIN:FRAME<fr>:START?

Returns the start time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStart> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:LIN:FRAME<fr>:STATus?

Returns the overall state of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameState> OK | WAKEup | CHCKsum | PRERror | STERror | SYERror |
 LNERror | UNK | INComplete
 WAKEup: wake-up frame.
 CHCKsum: checksum error
 PRERror: parity error in identifier
 STERror: stop error
 SYERror: synchronization error
 LNERror: unexpected length
 UNK: unknown error
 *RST: OK

Usage: Query only
 Asynchronous command

SBUS<sb>:LIN:FRAMe<fr>:STOP?

Returns the stop time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage: Query only
 Asynchronous command

SBUS<sb>:LIN:FRAMe<fr>:SYMBol?

Returns the symbolic label of the specified frame if the label list is enabled.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<Symbol>

Usage: Query only
 Asynchronous command

SBUS<sb>:LIN:FRAMe<fr>:PIDentifier?

Returns the protected identifier of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Protected identifier> Range: 0 to 255
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

18.18.12 SENT (option R&S MXO5C-K520)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with `SBUS<sb>[:STATe]`.
- The bus is set to the correct type with `SBUS<sb>:TYPE`.

• Configuration	1601
• Filter	1607
• Software trigger	1613
• Decode results	1619

18.18.12.1 Configuration

SBUS<sb>:SENT:CLKPeriod	1601
SBUS<sb>:SENT:CLKTolerance	1602
SBUS<sb>:SENT:CRCLength	1602
SBUS<sb>:SENT:CRCLength	1602
SBUS<sb>:SENT:DATA:HYSTeresis	1603
SBUS<sb>:SENT:DATA:SOURce	1603
SBUS<sb>:SENT:DATA:THReshold	1603
SBUS<sb>:SENT:DNIBbles	1604
SBUS<sb>:SENT:MODE	1604
SBUS<sb>:SENT:NEWList	1604
SBUS<sb>:SENT:POSition	1605
SBUS<sb>:SENT:PPFLength	1605
SBUS<sb>:SENT:PPULse	1605
SBUS<sb>:SENT:RDSt	1606
SBUS<sb>:SENT:SCALE	1606
SBUS<sb>:SENT:SFOFormat	1606
SBUS<sb>:SENT:SWTIndex?	1606
SBUS<sb>:SENT:SWTTime?	1607
SBUS<sb>:SENT:SYMBols	1607

SBUS<sb>:SENT:CLKPeriod <ClockPeriod>

Sets the transmitter-specific nominal clock period (clock tick).

The clock period and signal length determine the speed of transmission.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ClockPeriod> Range: 1E-06 to 0.0001
Increment: 1E-06
*RST: 6E-06
Default unit: s

Usage: Asynchronous command

Manual operation: See ["Clock period"](#) on page 688

SBUS<sb>:SENT:CLKTolerance <ClockTolerance>

Specifies a tolerated deviation of the clock.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ClockTolerance> Range: 1 to 25
Increment: 1
*RST: 20
Default unit: %

Usage: Asynchronous command

Manual operation: See ["Clock tolerance"](#) on page 688

SBUS<sb>:SENT:CRCCMethod <CRCCalculation>

Selects the method for CRC calculation.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<CRCCalculation> SAEJ | TLE
SAEJ: SAE_J2716
TLE: TLE_4998X
*RST: SAEJ

Usage: Asynchronous command

Manual operation: See ["CRC calculation"](#) on page 689

SBUS<sb>:SENT:CRCVersion <CRCVersion>

Selects the version the CRC check is based on.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<CRCVersion> LEGA | V2010
 LEGA: Legacy
 V2010: v2010/v2016
 *RST: V2010

Usage: Asynchronous command

Manual operation: See "[CRC version](#)" on page 689

SBUS<sb>:SENT:DATA:HYSteresis <SDATA Hyst>

Sets the hysteresis for the data channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SDATA Hyst>

Usage: Asynchronous command

Manual operation: See "[Threshold](#)" on page 689

SBUS<sb>:SENT:DATA:SOURce <DataSource>

Sets the source of the data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DataSource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | M1 | M2 | M3 | M4 | M5 |
 M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | R8 | O<n>C1 |
 O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See "[Data](#)" on page 688

SBUS<sb>:SENT:DATA:THReshold <SDATA Thres>

Sets the threshold for the data channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SDATA Thres>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 689

SBUS<sb>:SENT:DNIBbles <DataNibbles>

Sets the number of data units in a single transmission sequence.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DataNibbles> Range: 1 to 6
Increment: 1
*RST: 6

Usage: Asynchronous command

Manual operation: See ["Data nibbles"](#) on page 688

SBUS<sb>:SENT:MODE <Mode>

Selects the operating mode of the SENT protocol.

If *Legacy* is selected, the SPC mode is not supported.

If *SPC* mode is selected, the SENT protocol allows for the calibration of a sensor's output by sending a single calibrated value.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Mode> LEGacy | SPC
*RST: LEGacy

Usage: Asynchronous command

Manual operation: See ["Mode"](#) on page 688

SBUS<sb>:SENT:NEWList <FileName>

Loads a symbol list file.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName> String parameter with path and file name.

Example:

```
SBUS1:SENT:NEWList
'/home/storage/userData/Protocol/SENT.csv'
SBUS1:SENT:SYMBOLS ON
```

Usage: Setting only
Asynchronous command

SBUS<sb>:SENT:POSition <SENT position>

Sets the vertical position of the SENT signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SENT position>

Usage:

Asynchronous command

SBUS<sb>:SENT:PPFLength <FrameLength>

Specifies the fixed frame length in terms of ticks, which requires setting the pause pulse ([SBUS<sb>:SENT:PPULse](#)) to PPFL.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<FrameLength> Range: 104 to 922
Increment: 1
*RST: 256

Usage:

Asynchronous command

Manual operation: See ["Frame length"](#) on page 689

SBUS<sb>:SENT:PPULse <PausePulse>

Determines whether a pause pulse is transmitted after the checksum nibble.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<PausePulse> NPP | PP | PPFL

NPP

No pause pulse is transmitted.

PP

Enables transmitting a pause pulse.

PPFL

A pause pulse is transmitted to achieve a fixed frame length, which is specified by [SBUS<sb>:SENT:PPFLength](#).

*RST: NPP

Usage:

Asynchronous command

Manual operation: See ["Pause pulse"](#) on page 689

SBUS<sb>:SENT:RDSL <RessDispSel>

Selects the results to be displayed.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<RessDispSel> TRSQ | SMSG | ALL
TRSQ: transmission sequence
SMSG: serial messages
*RST: ALL

Usage: Asynchronous command

SBUS<sb>:SENT:SCALE <SENT scale>

Set the vertical scale of the indicated SENT signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SENT scale>

Usage: Asynchronous command

SBUS<sb>:SENT:SFORmat <SerialMessages>

Selects if serial messages are enabled or disabled.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SerialMessages> ENABled | DISabled
*RST: DISabled

Usage: Asynchronous command

Manual operation: See ["Serial message"](#) on page 688

SBUS<sb>:SENT:SWTindex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns `Invalid`.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

SBUS<sb>:SENT:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns `Invalid`.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

SBUS<sb>:SENT:SYMBOLs <ShowSymbols>

Activates the symbol list to be used for decoding.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ShowSymbols> OFF | ON
 *RST: OFF

Usage:

Asynchronous command

18.18.12.2 Filter

There are two commands for each parameter, that you can use for defining the SENT settings.

For example, to set the *Frame type =TransmissionSequence > Field =Data >01100* value you can use one of the following commands:

- `SBUS:SENT:FILTer:FRAMe1:FLD1:DMIN 01100`
 Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `SBUS:SENT:FILTer:DMIN "TransmissionSequence", "Data", 01100`
 Defines the parameter by using the frame and field name.

SBUS<sb>:SENT:FILTer:CHKall.....	1608
SBUS<sb>:SENT:FILTer:CLR.....	1608
SBUS<sb>:SENT:FILTer:INVert.....	1609
SBUS<sb>:SENT:FILTer:RST.....	1609
SBUS<sb>:SENT:FILTer:FRENAble.....	1609
SBUS<sb>:SENT:FILTer:FRAMe<fr>:ENABle.....	1609
SBUS<sb>:SENT:FILTer:BIT.....	1609
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1609
SBUS<sb>:SENT:FILTer:DMAX.....	1610
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1610
SBUS<sb>:SENT:FILTer:DMIN.....	1610
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1610
SBUS<sb>:SENT:FILTer:DOPerator.....	1611
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1611
SBUS<sb>:SENT:FILTer:FIENABle.....	1611
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1611
SBUS<sb>:SENT:FILTer:IMAX.....	1611
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1611
SBUS<sb>:SENT:FILTer:IMIN.....	1612
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1612
SBUS<sb>:SENT:FILTer:IOPerator.....	1612
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1612
SBUS<sb>:SENT:FILTer:ERENABle.....	1613
SBUS<sb>:SENT:FILTer:ERRor<n>:ENABle.....	1613

SBUS<sb>:SENT:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 692

SBUS<sb>:SENT:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 692

SBUS<sb>:SENT:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 692

SBUS<sb>:SENT:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 692

SBUS<sb>:SENT:FILTer:FRENAble <Frame>,<Enabler>**SBUS<sb>:SENT:FILTer:FRENAble? <Enabler>****SBUS<sb>:SENT:FILTer:FRAME<fr>:ENABle <Enable>**

Enables the filtering on SENT frames. Only the frames that match the selected filter conditions are displayed.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Enable> OFF | ON
*RST: ON

Usage:

Asynchronous command

Manual operation: See ["Enable"](#) on page 693

SBUS<sb>:SENT:FILTer:BIT <Frame>,<Field>,<Bit>**SBUS<sb>:SENT:FILTer:BIT? <Bit>****SBUS<sb>:SENT:FILTer:FRAME<fr>:FLD<fl>:BIT <BitState>**

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 693

SBUS<sb>:SENT:FILTer:DMAX <Frame>,<Field>,<Data>

SBUS<sb>:SENT:FILTer:DMAX? <Data>

SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range if the operator is set to INRange or OORANGE.

You can set the operator with [SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:DOPerator](#).

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 693

SBUS<sb>:SENT:FILTer:DMIN <Frame>,<Field>,<Data>

SBUS<sb>:SENT:FILTer:DMIN? <Data>

SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 693

SBUS<sb>:SENT:FILTer:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:SENT:FILTer:DOPerator? <Operator>

SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange

*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 693

SBUS<sb>:SENT:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:SENT:FILTer:FIENable? <Enabler>

SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> 1 to 4, index of the serial bus

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 693

SBUS<sb>:SENT:FILTer:IMAX <Frame>,<Field>,<Data>

SBUS<sb>:SENT:FILTer:IMAX? <Data>

SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range if the operator is set to INRange.

You can set the operator with [SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:IOperator](#).

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
Increment: 1
*RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 693

SBUS<sb>:SENT:FILTer:IMIN <Frame>,<Field>,<Data>

SBUS<sb>:SENT:FILTer:IMIN? <Data>

SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
Increment: 1
*RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 693

SBUS<sb>:SENT:FILTer:IOperator <Frame>,<Field>,<Operator>

SBUS<sb>:SENT:FILTer:IOperator? <Operator>

SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGE
*RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 693

SBUS<sb>:SENT:FILTer:ERENable <ErrorName>,<Enabler>

SBUS<sb>:SENT:FILTer:ERENable? <Enabler>

SBUS<sb>:SENT:FILTer:ERRor<n>:ENABLE <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 694

18.18.12.3 Software trigger

There are two commands for each parameter, that you can use for defining the SENT settings.

For example, to set the *Frame type =TransmissionSequence > Field =Data >01100* value you can use one of the following commands:

- `TRIGger:SBSW:SENT:FRAMe1:FLD1:DMIN 01100`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `TRIGger:SBSW:SENT:DMIN "TransmissionSequence", "Data", 01100`
Defines the parameter by using the frame and field name.

TRIGger:SBSW:SENT:CHKall.....	1614
TRIGger:SBSW:SENT:CLR.....	1614
TRIGger:SBSW:SENT:INVert.....	1614
TRIGger:SBSW:SENT:RST.....	1614
TRIGger:SBSW:SENT:FRAMe<fr>:ENABLE.....	1614
TRIGger:SBSW:SENT:FRENable.....	1614
TRIGger:SBSW:SENT:BIT.....	1615
TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:BIT.....	1615
TRIGger:SBSW:SENT:FIENable.....	1615
TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:ENABLE.....	1615
TRIGger:SBSW:SENT:DMAX.....	1615
TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:DMAX.....	1615
TRIGger:SBSW:SENT:DMIN.....	1616
TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:DMIN.....	1616
TRIGger:SBSW:SENT:DOPerator.....	1616
TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:DOPerator.....	1616
TRIGger:SBSW:SENT:IMAX.....	1617
TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:IMAX.....	1617
TRIGger:SBSW:SENT:IMIN.....	1617
TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:IMIN.....	1617

TRIGger:SBSW:SENT:IOPerator.....	1617
TRIGger:SBSW:SENT:FRAME<fr>:FLD<fl>:IOPerator.....	1617
TRIGger:SBSW:SENT:ERENable.....	1618
TRIGger:SBSW:SENT:ERRor<m>:ENABle.....	1618
SBUS<sb>:SENT:SWTindex?.....	1618
SBUS<sb>:SENT:SWTTime?.....	1618

TRIGger:SBSW:SENT:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 695

TRIGger:SBSW:SENT:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 695

TRIGger:SBSW:SENT:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 695

TRIGger:SBSW:SENT:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 695

TRIGger:SBSW:SENT:FRAME<fr>:ENABle <Enable>

TRIGger:SBSW:SENT:FRENable <Frame>,<Enabler>

TRIGger:SBSW:SENT:FRENable? <Enabler>

rcset

Setting parameters:
<Frame>

Parameters for setting and query:

<Enabler> OFF | ON

Usage: Asynchronous command**Manual operation:** See ["Frame type"](#) on page 696**TRIGger:SBSW:SENT:BIT** <Frame>,<Field>,<Bit>**TRIGger:SBSW:SENT:BIT?** <Bit>**TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:BIT** <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO

*RST: ZERO

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 696**TRIGger:SBSW:SENT:FIENable** <Frame>,<Field>,<Enabler>**TRIGger:SBSW:SENT:FIENable?** <Enabler>**TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:ENABLE** <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 696**TRIGger:SBSW:SENT:DMAX** <Frame>,<Field>,<Data>**TRIGger:SBSW:SENT:DMAX?** <Data>**TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:DMAX** <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGe.

You can set the operator with [TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:DOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 696**TRIGger:SBSW:SENT:DMIN** <Frame>,<Field>,<Data>**TRIGger:SBSW:SENT:DMIN?** <Data>**TRIGger:SBSW:SENT:FRAME<fr>:FLD<fl>:DMIN** <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 696**TRIGger:SBSW:SENT:DOPerator** <Frame>,<Field>,<Operator>**TRIGger:SBSW:SENT:DOPerator?** <Operator>**TRIGger:SBSW:SENT:FRAME<fr>:FLD<fl>:DOPerator** <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUal

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 696

TRIGger:SBSW:SENT:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:SENT:IMAX? <Data>

TRIGger:SBSW:SENT:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with **TRIGger:SBSW:SENT:FRAME<fr>:FLD<fl>:IOperator**.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See "Edit" on page 696

TRIGger:SBSW:SENT:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:SENT:IMIN? <Data>

TRIGger:SBSW:SENT:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See "Edit" on page 696

TRIGger:SBSW:SENT:IOperator <Frame>,<Field>,<Operator>

TRIGger:SBSW:SENT:IOperator? <Operator>

TRIGger:SBSW:SENT:FRAME<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUAL | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 696

TRIGger:SBSW:SENT:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:SENT:ERENable? <Enabler>

TRIGger:SBSW:SENT:ERRor<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> Index of the error

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 697

SBUS<sb>:SENT:SWTIndex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295
 Increment: 1
 *RST: 0

Usage: Query only
 Asynchronous command

SBUS<sb>:SENT:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

18.18.12.4 Decode results

SBUS<sb>:SENT:FCOunt?	1619
SBUS<sb>:SENT:FRAMe<fr>:BITRate?	1620
SBUS<sb>:SENT:FRAMe<fr>:CSValue?	1620
SBUS<sb>:SENT:FRAMe<fr>:DATA?	1620
SBUS<sb>:SENT:FRAMe<fr>:FDValues?	1620
SBUS<sb>:SENT:FRAMe<fr>:FSCom?	1621
SBUS<sb>:SENT:FRAMe<fr>:FSDTa?	1621
SBUS<sb>:SENT:FRAMe<fr>:IDTYpe?	1621
SBUS<sb>:SENT:FRAMe<fr>:IDValue?	1622
SBUS<sb>:SENT:FRAMe<fr>:MTPDuration?	1622
SBUS<sb>:SENT:FRAMe<fr>:FLDCount?	1622
SBUS<sb>:SENT:FRAMe<fr>:FLD<fl>:STATe?	1623
SBUS<sb>:SENT:FRAMe<fr>:FLD<fl>:VALue?	1623
SBUS<sb>:SENT:FRAMe<fr>:FLD<fl>:FVALue?	1623
SBUS<sb>:SENT:FRAMe<fr>:FLD<fl>:LABel?	1624
SBUS<sb>:SENT:FRAMe<fr>:PAPTicks?	1624
SBUS<sb>:SENT:FRAMe<fr>:SCOM?	1624
SBUS<sb>:SENT:FRAMe<fr>:SDATa?	1625
SBUS<sb>:SENT:FRAMe<fr>:SENSor?	1625
SBUS<sb>:SENT:FRAMe<fr>:START?	1625
SBUS<sb>:SENT:FRAMe<fr>:STATus?	1625
SBUS<sb>:SENT:FRAMe<fr>:STOP?	1626
SBUS<sb>:SENT:FRAMe<fr>:SYMBol?	1626
SBUS<sb>:SENT:FRAMe<fr>:SYNCduration?	1627
SBUS<sb>:SENT:FRAMe<fr>:TYPE?	1627

SBUS<sb>:SENT:FCOunt?

Returns the number of decoded frames.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count> Total number of decoded frames.

Usage:

Query only
 Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:BITRate?

Returns the bit rate of the frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<BitRate> Increment: 1
*RST: 0
Default unit: bps

Usage: Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:CSValue?

Returns the CRC sequence value of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<ChecksumValue> Range: 0 to 63
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:DATA?

Returns the data of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<data> Comma-separated sequence of integer values (N, D1, D2,..., DN). N is the number of nibbles in the frame, and D1...DN are the values of the nibbles.

Usage: Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:FDValues?

Returns the formatted data values.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Return values:****<FormattedDatVals>****Usage:**

Query only

Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:FSCom?

Retruns the formatted status communication.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Return values:****<FormattedStatusComm>****Usage:**

Query only

Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:FSDTa?

Returns the formatted symbolic data values.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Return values:****<FormattedSymbDat>****Usage:**

Query only

Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:IDTYpe?

Returns the identifier type of the selected frame.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Return values:****<IdentifierType>** B4 | B8

B4: standard format, 4 bit

B8: extended format, 8 bit

*RST: B4

Usage: Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:IDValue?

Returns the identifier value of the selected frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <IdtfVal> Range: 0 to 255
 Increment: 1
 *RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:MTPDuration?

Returns the duration of the main trigger pulse (MTP), which is an additional pulse added to the frame when running in "Short PWM Code" (SPC) mode. With pulse width modulation (PWM), you can connect multiple sensors to the bus. The duration of the MTP defines, which sensor starts the transmission.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <MTPDuration> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:FLDCount?

Returns the number of fields in the specified frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <Count>

Usage: Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:FLD<fl>:STATE?

Returns the state of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<State> OK | SYNC | PULSe | CRC | LENGth | FORM | PAUSE | INComplete

*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:FLD<fl>:VALue?

Returns the value of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Value> Range: 0 to 15

Increment: 1

*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<FormattedValue>

Usage: Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:FLD<fl>:LABEL?

Returns the label of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<fl> Index of the field

Return values:

<Label>

Usage: Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:PAPTicks?

Returns the number of the pulse pause clock ticks.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<PausePlsTicks> Range: 12 to 768
Increment: 1
*RST: 12

Usage: Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:SCOM?

Returns the value of the status/communication pulse.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<FrmStatusComm> Range: 0 to 15
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:SDATa?

Returns the symbolic data of the frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<SymbolicData>

Usage:

Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:SENSor?

Returns the sensor response time.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<SensRespTime> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:START?

Returns the start time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStart> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:STATus?

Returns the overall state of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameState> OK | SYNC | PULSe | CRC | LENGth | FORM | PAUSE | INComplete
 OK: the frame is valid.
 SYNC: Synchronization error occurred.
 PULSe: Pulse error occurred.
 CRC: Cyclic redundancy check failed.
 LENGth: Irregular frame length error occurred.
 FORM: Format error occurred.
 INComplete: The frame is not completely contained in the acquisition. The acquired part of the frame is valid.
 *RST: OK

Usage:

Query only
 Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:STOP?

Returns the stop time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:SYMBOL?

Returns the symbolic label of the specified frame if the label list is enabled.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<SymbolicName>

Example:

BUS:SENT:FRAME:SYMBOL?
 Response: Air Temperature

Usage: Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:SYNCDuration?

Returns the time of the synchronization pulse.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <FrameSyncTime> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:SENT:FRAME<fr>:TYPE?

Returns the type of SENT message.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <FrameType> TRSQ | SMSG | ESSM | ELSM | PAUSE | UNKNown
 TRSQ: transmission sequence
 SMSG: short serial message
 ESSM: enhanced 12 bit message
 ELSM: enhanced 16 bit message
 *RST: TRSQ

Usage: Query only
Asynchronous command

18.18.13 ARINC 429 (option R&S MXO5C-K530)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with **SBUS<sb>[:STATe]**.
- The bus is set to the correct type with **SBUS<sb>:TYPE**.

• Configuration	1628
• Filter	1632
• Software trigger	1636
• Decode results	1641

18.18.13.1 Configuration

SBUS<sb>:ARINc:BRMode.....	1628
SBUS<sb>:ARINc:BRValue.....	1628
SBUS<sb>:ARINc:POLarity.....	1629
SBUS<sb>:ARINc:SOURce.....	1629
SBUS<sb>:ARINc:THReshold:HIGH.....	1629
SBUS<sb>:ARINc:THReshold:HYSteresis.....	1629
SBUS<sb>:ARINc:THReshold:LOW.....	1630
SBUS<sb>:ARINc:NEwList.....	1630
SBUS<sb>:ARINc:SYMBols.....	1630
SBUS<sb>:ARINc:MAXGap:BITS.....	1630
SBUS<sb>:ARINc:MAXGap:SElect.....	1631
SBUS<sb>:ARINc:MINGap:BITS.....	1631
SBUS<sb>:ARINc:MINGap:SElect.....	1631
SBUS<sb>:ARINc:POSition.....	1632
SBUS<sb>:ARINc:SCALe.....	1632

SBUS<sb>:ARINc:BRMode <BitRateMode>

Sets the bit rate mode to high or low speed. You can set an exact bitrate value with [SBUS<sb>:ARINc:BRValue](#).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<BitRateMode> HIGH | LOW
*RST: HIGH

Usage: Asynchronous command

Manual operation: See ["Bit rate mode, Bit rate"](#) on page 705

SBUS<sb>:ARINc:BRValue <BitRateValue>

Sets the number of transmitted bits per second.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<BitRateValue> Range: 10000 to 110000
Increment: 100
*RST: 100000
Default unit: bps

Usage: Asynchronous command

Manual operation: See ["Bit rate mode, Bit rate"](#) on page 705

SBUS<sb>:ARINc:POLarity <Polarity>

Selects the wire on which the bus signal is measured : A Leg or B Leg. The setting affects the digitization of the signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Polarity> ALEG | BLEG
*RST: ALEG

Usage: Asynchronous command

Manual operation: See ["Polarity"](#) on page 704

SBUS<sb>:ARINc:SOURce Source

Sets the channel for the signal source.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

Source C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | M1 | M2 | M3 | M4 | M5 |
M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | R8 | O<n>C1 |
O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["Source"](#) on page 704

SBUS<sb>:ARINc:THReshold:HIGH <Upper threshold>

Sets the upper threshold level of the signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Upper threshold>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 706

SBUS<sb>:ARINc:THReshold:HYSTeresis <Hysteresis>

Sets a hysteresis value.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage: Asynchronous command
Manual operation: See ["Threshold"](#) on page 706

SBUS<sb>:ARINc:THReshold:LOW <Lower threshold>

Sets the lower threshold level of the signal.

Suffix:
 <sb> 1 to 4, index of the serial bus

Parameters:
 <Lower threshold>

Usage: Asynchronous command
Manual operation: See ["Threshold"](#) on page 706

SBUS<sb>:ARINc:NEWList <FileName>

Loads a symbol list file.

Suffix:
 <sb> 1 to 4, index of the serial bus

Setting parameters:
 <FileName> String parameter with path and file name.

Example:
 SBUS1:ARIN:NEWList
 '/home/storage/userData/Protocol/ARINC.csv'
 SBUS1:ARIN:SYMBOLS ON

Usage: Setting only
 Asynchronous command

Manual operation: See ["Show symbols"](#) on page 706

SBUS<sb>:ARINc:SYMBOLS <ShowSymbols>

Activates the symbol list to be used for decoding.

Suffix:
 <sb> 1 to 4, index of the serial bus

Parameters:
 <ShowSymbols> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Show symbols"](#) on page 706

SBUS<sb>:ARINc:MAXGap:BITS <MaxGapBits>

Sets the value for the maximum gap between two words.

See also: [SBUS<sb>:ARINc:MAXGap:SElect](#) on page 1631.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MaxGapBits> Range: 0 to 1000
Increment: 1
*RST: 100
Default unit: bit

Usage: Asynchronous command

Manual operation: See "[Min gap time,Max gap time](#)" on page 705

SBUS<sb>:ARINc:MAXGap:SElect <MaxGapSelect>

Enables the detection of the maximum gap time during decoding.

You can specify the maximum gap time with [SBUS<sb>:ARINc:MAXGap:BITS](#).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MaxGapSelect> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See "[Min gap time,Max gap time](#)" on page 705

SBUS<sb>:ARINc:MINGap:BITS <MinGapBits>

Sets a value for the minimum timing gap between two words.

See also: [SBUS<sb>:ARINc:MINGap:SElect](#).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MinGapBits> Range: 0 to 100
Increment: 1
*RST: 4
Default unit: bit

Usage: Asynchronous command

Manual operation: See "[Min gap time,Max gap time](#)" on page 705

SBUS<sb>:ARINc:MINGap:SElect <MinGapSelect>

Enables the detection of the minimum idle time between two words during decoding.

To specify the minimum gap, use `SBUS<sb>:ARINC:MINGap:BITS`.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MinGapSelect> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See "Min gap time,Max gap time" on page 705

SBUS<sb>:ARINC:POSition <Position>

Sets the vertical position of the ARINC signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Position>

Usage: Asynchronous command

SBUS<sb>:ARINC:SCALE <Scale>

Set the vertical scale of the indicated ARINC signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Scale>

Usage: Asynchronous command

18.18.13.2 Filter

There are two commands for each parameter, that you can use for defining the ARINC 429 settings.

For example, to set the *Frame type =ARINC429-Word > Field =Data >Data* value you can use one of the following commands:

- `SBUS:ARINC:FILTer:FRAME1:FLD1:DMIN 01100`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `SBUS:ARINC:FILTer:DMIN "ARINC429-Word", "Data", 01100`
Defines the parameter by using the frame and field name.

`SBUS<sb>:ARINC:FILTer:CHKall..... 1633`
`SBUS<sb>:ARINC:FILTer:CLR..... 1633`
`SBUS<sb>:ARINC:FILTer:INVert..... 1633`

SBUS<sb>:ARINc:FILTer:RST.....	1634
SBUS<sb>:ARINc:FILTer:BIT.....	1634
SBUS<sb>:ARINc:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1634
SBUS<sb>:ARINc:FILTer:ERENable.....	1634
SBUS<sb>:ARINc:FILTer:ERRor<n>:ENABle.....	1634
SBUS<sb>:ARINc:FILTer:DMAx.....	1635
SBUS<sb>:ARINc:FILTer:FRAMe<fr>:FLD<fl>:DMAx.....	1635
SBUS<sb>:ARINc:FILTer:DMin.....	1635
SBUS<sb>:ARINc:FILTer:FRAMe<fr>:FLD<fl>:DMin.....	1635
SBUS<sb>:ARINc:FILTer:DOPerator.....	1635
SBUS<sb>:ARINc:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1635
SBUS<sb>:ARINc:FILTer:FIENable.....	1636
SBUS<sb>:ARINc:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1636
SBUS<sb>:ARINc:FILTer:FRENable.....	1636
SBUS<sb>:ARINc:FILTer:FRAMe<fr>:ENABle.....	1636

SBUS<sb>:ARINc:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 708

SBUS<sb>:ARINc:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 708

SBUS<sb>:ARINc:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 708

SBUS<sb>:ARINc:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 708

SBUS<sb>:ARINc:FILTer:BIT <Frame>,<Field>,<Bit>**SBUS<sb>:ARINc:FILTer:BIT? <Bit>****SBUS<sb>:ARINc:FILTer:FRAMe<fr>:FLD<fl>:BIT <BitState>**

Sets the bit state of a field that only consists of one bit.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO
*RST: ZERO

Usage:

Asynchronous command

Manual operation: See ["Edit"](#) on page 709

SBUS<sb>:ARINc:FILTer:ERENable <ErrorName>,<Enabler>**SBUS<sb>:ARINc:FILTer:ERENable? <Enabler>****SBUS<sb>:ARINc:FILTer:ERRor<n>:ENABLe <Enable>**

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> index of the error

Parameters:

<Enable> OFF | ON
*RST: ON

Usage:

Asynchronous command

Manual operation: See ["Error type"](#) on page 710

SBUS<sb>:ARINc:FILTer:DMAX <Frame>,<Field>,<Data>

SBUS<sb>:ARINc:FILTer:DMAX? <Data>

SBUS<sb>:ARINc:FILTer:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range if the operator is set to INRange or OORANGE.

You can set the operator with [SBUS<sb>:ARINc:FILTer:FRAMe<fr>:FLD<fl>:DOPerator](#).

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 709

SBUS<sb>:ARINc:FILTer:DMIN <Frame>,<Field>,<Data>

SBUS<sb>:ARINc:FILTer:DMIN? <Data>

SBUS<sb>:ARINc:FILTer:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 709

SBUS<sb>:ARINc:FILTer:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:ARINc:FILTer:DOPerator? <Operator>

SBUS<sb>:ARINc:FILTer:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 709

SBUS<sb>:ARINC:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:ARINC:FILTer:FIENable? <Enabler>

SBUS<sb>:ARINC:FILTer:FRAMe<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 709

SBUS<sb>:ARINC:FILTer:FRENable <Frame>,<Enabler>

SBUS<sb>:ARINC:FILTer:FRENable? <Enabler>

SBUS<sb>:ARINC:FILTer:FRAMe<fr>:ENABLE <Enable>

Enables the filtering on ARINC 429 frames. Only the frames that match the selected filter conditions are displayed.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Enable"](#) on page 708

18.18.13.3 Software trigger

There are two commands for each parameter, that you can use for defining the ARINC 429 settings.

For example, to set the *Frame type* =ARINC429-Word > *Field* =Data >Data value you can use one of the following commands:

- TRIGger:SBSW:ARINc:FRAMe1:FLD1:DMIN 01100
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- TRIGger:SBSW:ARINc:DMIN "ARINC429-Word", "Data", 01100
Defines the parameter by using the frame and field name.

TRIGger:SBSW:ARINc:CHKall.....	1637
TRIGger:SBSW:ARINc:CLR.....	1637
TRIGger:SBSW:ARINc:INVert.....	1637
TRIGger:SBSW:ARINc:RST.....	1638
TRIGger:SBSW:ARINc:FRENAble.....	1638
TRIGger:SBSW:ARINc:FRAMe<fr>:ENABle.....	1638
TRIGger:SBSW:ARINc:BIT.....	1638
TRIGger:SBSW:ARINc:FRAMe<fr>:FLD<fl>:BIT.....	1638
TRIGger:SBSW:ARINc:DMAX.....	1639
TRIGger:SBSW:ARINc:FRAMe<fr>:FLD<fl>:DMAX.....	1639
TRIGger:SBSW:ARINc:DMIN.....	1639
TRIGger:SBSW:ARINc:FRAMe<fr>:FLD<fl>:DMIN.....	1639
TRIGger:SBSW:ARINc:DOPerator.....	1639
TRIGger:SBSW:ARINc:FRAMe<fr>:FLD<fl>:DOPerator.....	1639
TRIGger:SBSW:ARINc:FIENABle.....	1640
TRIGger:SBSW:ARINc:FRAMe<fr>:FLD<fl>:ENABle.....	1640
TRIGger:SBSW:ARINc:ERENABle.....	1640
TRIGger:SBSW:ARINc:ERRor<m>:ENABle.....	1640
SBUS<sb>:ARINc:SWTIndex?.....	1640
SBUS<sb>:ARINc:SWTTime?.....	1641

TRIGger:SBSW:ARINc:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
 Asynchronous command

Manual operation: See "Check all, Clear, Invert, Preset" on page 711

TRIGger:SBSW:ARINc:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
 Asynchronous command

Manual operation: See "Check all, Clear, Invert, Preset" on page 711

TRIGger:SBSW:ARINc:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 711

TRIGger:SBSW:ARINc:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 711

TRIGger:SBSW:ARINc:FRENAble <Frame>,<Enabler>

TRIGger:SBSW:ARINc:FRENAble? <Enabler>

TRIGger:SBSW:ARINc:FRAMe<fr>:ENABLe <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:
<fr> Index of the frame

Parameters:
<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 712

TRIGger:SBSW:ARINc:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:ARINc:BIT? <Bit>

TRIGger:SBSW:ARINc:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:
<fr> Index of the frame
<fl> Index of the field

Parameters:
<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 712

TRIGger:SBSW:ARINc:DMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:ARINc:DMAX? <Data>

TRIGger:SBSW:ARINc:FRAME<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGe.

You can set the operator with **TRIGger:SBSW:ARINc:FRAME<fr>:FLD<fl>:DOPerator**.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See "Edit" on page 712

TRIGger:SBSW:ARINc:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:ARINc:DMIN? <Data>

TRIGger:SBSW:ARINc:FRAME<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See "Edit" on page 712

TRIGger:SBSW:ARINc:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:ARINc:DOPerator? <Operator>

TRIGger:SBSW:ARINc:FRAME<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUAL | NEQUAL | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUAL

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 712

TRIGger:SBSW:ARINc:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:ARINc:FIENable? <Enabler>

TRIGger:SBSW:ARINc:FRAMe<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 712

TRIGger:SBSW:ARINc:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:ARINc:ERENable? <Enabler>

TRIGger:SBSW:ARINc:ERRor<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> index of the error

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 713

SBUS<sb>:ARINc:SWTindex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

SBUS<sb>:ARINc:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

18.18.13.4 Decode results

This section describes the commands to query the results of the decoding.

SBUS<sb>:ARINc:WCOunt?	1641
SBUS<sb>:ARINc:WORD<w>:BITRate?	1642
SBUS<sb>:ARINc:WORD<w>:DATA?	1642
SBUS<sb>:ARINc:WORD<w>:LABel?	1642
SBUS<sb>:ARINc:WORD<w>:PATtern?	1643
SBUS<sb>:ARINc:WORD<w>:SDI?	1643
SBUS<sb>:ARINc:WORD<w>:SSM?	1643
SBUS<sb>:ARINc:WORD<w>:START?	1644
SBUS<sb>:ARINc:WORD<w>:STATe?	1644
SBUS<sb>:ARINc:WORD<w>:STOP?	1644
SBUS<sb>:ARINc:WORD<w>:SYMBol?	1645

SBUS<sb>:ARINc:WCOunt?

Returns the number of decoded words.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count>

Usage: Query only
Asynchronous command

SBUS<sb>:ARINc:WORD<w>:BITRate?

Returns the bit rate of the word.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <w> *
 Index of the word

Return values:
 <PrimaryBitRate> Increment: 1
 *RST: 0
 Default unit: bps

Usage: Query only
Asynchronous command

SBUS<sb>:ARINc:WORD<w>:DATA?

Returns the data of the specified word.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <w> *
 Index of the word

Return values:
 <FrameData> Range: 0 to 524287
 Increment: 1
 *RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:ARINc:WORD<w>:LABel?

Returns the label of the specified word.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <w> *
 Index of the word

Return values:
 <FrameLabel> Range: 0 to 255
 Increment: 1
 *RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:ARINc:WORD<w>:PATtern?

Returns all 32 bits of the specified word.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <w> *
 Index of the word

Return values:
 <FrmDatPatt> List of comma separated values.

Example: SBUS1:ARINc:WORD1:PATtern?
 #H04, #H10, #H04

Usage: Query only
Asynchronous command

SBUS<sb>:ARINc:WORD<w>:SDI?

Returns the source/destination identifier (SDI) bits of the specified word.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <w> *
 Index of the word

Return values:
 <SDI> Range: 0 to 3
 Increment: 1
 *RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:ARINc:WORD<w>:SSM?

Returns the sign/status matrix (SSM) bits of the specified word.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <w> *
 Index of the word

Return values:
 <SSM> Range: 0 to 3
 Increment: 1
 *RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:ARINc:WORD<w>:START?

Returns the start time of the specified word.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <w> *
 Index of the word

Return values:
 <FrameStart> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:ARINc:WORD<w>:STATE?

Returns the overall state of the specified word.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <w> *
 Index of the word

Return values:
 <FrameState> OK | CODE | GAP | PAR | INC | UNKN
 CODE: coding error occurred.
 GAP: timing gap error occurred.
 PAR: parity error occurred.
 INComplete: the sequence is not completely contained in the acquisition
 UNKNown: unknown frame type
 *RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:ARINc:WORD<w>:STOP?

Returns the end time of the specified word.

Suffix:
 <sb> 1 to 4, index of the serial bus

<w>	*
	Index of the word
Return values:	
<FrameStop>	Range: -1E+26 to 1E+26
	Increment: 1E-10
	*RST: 0
	Default unit: s
Usage:	
	Query only
	Asynchronous command

SBUS<sb>:ARINc:WORD<w>:SYMBol?

Returns the label name of the word ID.

Suffix:	
<sb>	1 to 4, index of the serial bus
<w>	*
	Index of the word
Return values:	
<Translation>	
Usage:	
	Query only
	Asynchronous command

18.18.14 MIL-1553 (option R&S MXO5C-K530)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with [SBUS<sb>\[:STATe\]](#).
- The bus is set to the correct type with [SBUS<sb>:TYPE](#).

• Configuration	1645
• Filter	1648
• Software trigger	1653
• Decode results	1659

18.18.14.1 Configuration

SBUS<sb>:MILStd:POLarity	1646
SBUS<sb>:MILStd:SOURce	1646
SBUS<sb>:MILStd:THReshold:HIGH	1646
SBUS<sb>:MILStd:THReshold:HYSteresis	1646
SBUS<sb>:MILStd:THReshold:LOW	1647
SBUS<sb>:MILStd:NEWLlist	1647
SBUS<sb>:MILStd:POSition	1647
SBUS<sb>:MILStd:SCALe	1647
SBUS<sb>:MILStd:SYMBols	1648

SBUS<sb>:MILStd:POLarity <Polarity>

Sets the wire on which the bus signal is measured : normal or inverted. The setting affects the digitization of the signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Polarity> NORMal | INVerted
*RST: NORMal

Usage: Asynchronous command

Manual operation: See ["Polarity"](#) on page 733

SBUS<sb>:MILStd:SOURce Source

Sets the channel for the signal source.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

Source C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | M1 | M2 | M3 | M4 | M5 |
M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | R8 | O<n>C1 |
O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["Source"](#) on page 733

SBUS<sb>:MILStd:THReshold:HIGH <Threshold high>

Sets the lower threshold level of the signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold high>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 733

SBUS<sb>:MILStd:THReshold:HYSTeresis <Hysteresis>

Sets a hysteresis value.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage: Asynchronous command
Manual operation: See ["Threshold"](#) on page 733

SBUS<sb>:MILStd:THReshold:LOW <Threshold low>

Sets the lower threshold level of the signal.

Suffix:
 <sb> 1 to 4, index of the serial bus

Parameters:
 <Threshold low>

Usage: Asynchronous command
Manual operation: See ["Threshold"](#) on page 733

SBUS<sb>:MILStd:NEWList <FileName>

Loads a symbol list file.

Suffix:
 <sb> 1 to 4, index of the serial bus

Setting parameters:
 <FileName> String parameter with path and file name.

Example:
 SBUS1:MILStd:NEWList
 '/home/storage/userData/Protocol/MILStd.csv'
 SBUS1:MILStd:SYMBOLs ON

Usage: Setting only
 Asynchronous command

SBUS<sb>:MILStd:POSition <Position>

Sets the vertical position of the MIL-1553 signal.

Suffix:
 <sb> 1 to 4, index of the serial bus

Parameters:
 <Position>

Usage: Asynchronous command

SBUS<sb>:MILStd:SCALe <Scale>

Set the vertical scale of the indicated MIL-1553 signal.

Suffix:
 <sb> 1 to 4, index of the serial bus

Parameters:

<Scale>

Usage:

Asynchronous command

SBUS<sb>:MILStd:SYMBOLs <ShowSymbols>

Activates the symbol list to be used for decoding.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ShowSymbols> OFF | ON

*RST: OFF

Usage:

Asynchronous command

18.18.14.2 Filter

There are two commands for each parameter that you can use for defining the MIL-1553 settings.

For example, to set the *Frame type =Command > Field =Info >01100* value you can use one of the following commands:

- SBUS:MIL:FILTer:FRAMe1:FLD1:DMIN 01100
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- SBUS:MIL:FILTer:DMIN "Command", "Info", 01100
Defines the parameter by using the frame and field name.

SBUS<sb>:MILStd:FILTer:CHKall.....	1649
SBUS<sb>:MILStd:FILTer:CLR.....	1649
SBUS<sb>:MILStd:FILTer:INVert.....	1649
SBUS<sb>:MILStd:FILTer:RST.....	1649
SBUS<sb>:MILStd:FILTer:BIT.....	1650
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1650
SBUS<sb>:MILStd:FILTer:ERENable.....	1650
SBUS<sb>:MILStd:FILTer:ERRor<n>:ENABLE.....	1650
SBUS<sb>:MILStd:FILTer:DMAX.....	1650
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1650
SBUS<sb>:MILStd:FILTer:DMIN.....	1651
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1651
SBUS<sb>:MILStd:FILTer:DOPerator.....	1651
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1651
SBUS<sb>:MILStd:FILTer:IMAX.....	1651
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1651
SBUS<sb>:MILStd:FILTer:IMIN.....	1652
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1652
SBUS<sb>:MILStd:FILTer:IOPerator.....	1652
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1652

SBUS<sb>:MILStd:FILTer:FRENAble.....	1653
SBUS<sb>:MILStd:FILTer:FRAME<fr>:ENABle.....	1653
SBUS<sb>:MILStd:FILTer:FIENable.....	1653
SBUS<sb>:MILStd:FILTer:FRAME<fr>:FLD<fl>:ENABle.....	1653

SBUS<sb>:MILStd:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 735

SBUS<sb>:MILStd:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 735

SBUS<sb>:MILStd:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 735

SBUS<sb>:MILStd:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 735

SBUS<sb>:MILStd:FILTer:BIT <Frame>,<Field>,<Bit>

SBUS<sb>:MILStd:FILTer:BIT? <Bit>

SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO

*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 736

SBUS<sb>:MILStd:FILTer:ERENable <ErrorName>,<Enabler>

SBUS<sb>:MILStd:FILTer:ERENable? <Enabler>

SBUS<sb>:MILStd:FILTer:ERRor<n>:ENABLE <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 737

SBUS<sb>:MILStd:FILTer:DMAX <Frame>,<Field>,<Data>

SBUS<sb>:MILStd:FILTer:DMAX? <Data>

SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range if the operator is set to `INRange` or `OORANGe`.

You can set the operator with `SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:DOPerator`.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage:

Asynchronous command

Manual operation:See ["Edit"](#) on page 736**SBUS<sb>:MILStd:FILTer:DMIN** <Frame>,<Field>,<Data>**SBUS<sb>:MILStd:FILTer:DMIN?** <Data>**SBUS<sb>:MILStd:FILTer:FRAME<fr>:FLD<fl>:DMIN** <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage:

Asynchronous command

Manual operation:See ["Edit"](#) on page 736**SBUS<sb>:MILStd:FILTer:DOPerator** <Frame>,<Field>,<Operator>**SBUS<sb>:MILStd:FILTer:DOPerator?** <Operator>**SBUS<sb>:MILStd:FILTer:FRAME<fr>:FLD<fl>:DOPerator** <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUal

Usage:

Asynchronous command

Manual operation:See ["Edit"](#) on page 736**SBUS<sb>:MILStd:FILTer:IMAX** <Frame>,<Field>,<Data>**SBUS<sb>:MILStd:FILTer:IMAX?** <Data>**SBUS<sb>:MILStd:FILTer:FRAME<fr>:FLD<fl>:IMAX** <Index_Max>

Sets the end value of an index range if the operator is set to INRange.

You can set the operator with `SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:IOPerator`.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 736

SBUS<sb>:MILStd:FILTer:IMIN <Frame>,<Field>,<Data>

SBUS<sb>:MILStd:FILTer:IMIN? <Data>

SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 736

SBUS<sb>:MILStd:FILTer:IOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:MILStd:FILTer:IOPerator? <Operator>

SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGe
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 736

SBUS<sb>:MILStd:FILTer:FRENAble <Frame>,<Enabler>

SBUS<sb>:MILStd:FILTer:FRENAble? <Enabler>

SBUS<sb>:MILStd:FILTer:FRAMe<fr>:ENABLe <Enable>

Enables the filtering on MIL-1553 frames. Only the frames that match the selected filter conditions are displayed.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Enable"](#) on page 736

SBUS<sb>:MILStd:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:MILStd:FILTer:FIENable? <Enabler>

SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:ENABLe <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 736

18.18.14.3 Software trigger

There are two commands for each parameter that you can use for defining the MIL-1553 settings.

For example, to set the *Frame type =Command > Field =Info >01100* value you can use one of the following commands:

- TRIGger:SBSW:MIL:FRAMe1:FLD1:DMIN 01100

Defines the parameter by using the index <m> for the frame number and <n> for the field number.

- TRIGger:SBSW:MIL:DMIN "Command", "Info", 01100

Defines the parameter by using the frame and field name.

TRIGger:SBSW:MILStd:CHKall.....	1654
TRIGger:SBSW:MILStd:CLR.....	1654
TRIGger:SBSW:MILStd:INVert.....	1655
TRIGger:SBSW:MILStd:RST.....	1655
TRIGger:SBSW:MILStd:FRENable.....	1655
TRIGger:SBSW:MILStd:FRAMe<fr>:ENABle.....	1655
TRIGger:SBSW:MILStd:BIT.....	1655
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:BIT.....	1655
TRIGger:SBSW:MILStd:DMAX.....	1656
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:DMAX.....	1656
TRIGger:SBSW:MILStd:DMIN.....	1656
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:DMIN.....	1656
TRIGger:SBSW:MILStd:DOPerator.....	1656
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:DOPerator.....	1656
TRIGger:SBSW:MILStd:FIENable.....	1657
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:ENABle.....	1657
TRIGger:SBSW:MILStd:IMAX.....	1657
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:IMAX.....	1657
TRIGger:SBSW:MILStd:IMIN.....	1658
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:IMIN.....	1658
TRIGger:SBSW:MILStd:IOPerator.....	1658
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:IOPerator.....	1658
TRIGger:SBSW:MILStd:ERENable.....	1658
TRIGger:SBSW:MILStd:ERRor<m>:ENABle.....	1658
SBUS<sb>:MILStd:SWTIndex?.....	1659
SBUS<sb>:MILStd:SWTTime?.....	1659

TRIGger:SBSW:MILStd:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 738

TRIGger:SBSW:MILStd:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 738

TRIGger:SBSW:MILStd:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 738

TRIGger:SBSW:MILStd:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 738

TRIGger:SBSW:MILStd:FREnable <Frame>,<Enabler>**TRIGger:SBSW:MILStd:FREnable? <Enabler>****TRIGger:SBSW:MILStd:FRAME<fr>:ENABLE <Enable>**

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:
<fr> Index of the frame

Parameters:
<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 739

TRIGger:SBSW:MILStd:BIT <Frame>,<Field>,<Bit>**TRIGger:SBSW:MILStd:BIT? <Bit>****TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:BIT <BitState>**

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:
<fr> Index of the frame
<fl> Index of the field

Parameters:
<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 739

TRIGger:SBSW:MILStd:DMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:MILStd:DMAX? <Data>

TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGE.

You can set the operator with **TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:DOperator**.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 739

TRIGger:SBSW:MILStd:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:MILStd:DMIN? <Data>

TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 739

TRIGger:SBSW:MILStd:DOperator <Frame>,<Field>,<Operator>

TRIGger:SBSW:MILStd:DOperator? <Operator>

TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:DOperator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUAL | NEQUAL | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUAL

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 739

TRIGger:SBSW:MILStd:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:MILStd:FIENable? <Enabler>

TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 739

TRIGger:SBSW:MILStd:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:MILStd:IMAX? <Data>

TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with [TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:IOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 739

TRIGger:SBSW:MILStd:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:MILStd:IMIN? <Data>

TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> *

Parameters:

<Index_Min> Range: 1 to 65535

Increment: 1

*RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 739

TRIGger:SBSW:MILStd:IOperator <Frame>,<Field>,<Operator>

TRIGger:SBSW:MILStd:IOperator? <Operator>

TRIGger:SBSW:MILStd:FRAME<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUAL | INRange | RANGE

*RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 739

TRIGger:SBSW:MILStd:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:MILStd:ERENable? <Enabler>

TRIGger:SBSW:MILStd:ERROR<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> Index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 740

SBUS<sb>:MILStd:SWTindex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:MILStd:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

18.18.14.4 Decode results

SBUS<sb>:MILStd:WCOunt?	1659
SBUS<sb>:MILStd:WORD<w>:BITRate?	1660
SBUS<sb>:MILStd:WORD<w>:DATA?	1660
SBUS<sb>:MILStd:WORD<w>:INFO?	1660
SBUS<sb>:MILStd:WORD<w>:RTADdress?	1661
SBUS<sb>:MILStd:WORD<w>:STARt?	1661
SBUS<sb>:MILStd:WORD<w>:STATus?	1661
SBUS<sb>:MILStd:WORD<w>:STOP?	1662
SBUS<sb>:MILStd:WORD<w>:SYMBol?	1662
SBUS<sb>:MILStd:WORD<w>:TYPE?	1663

SBUS<sb>:MILStd:WCOunt?

Returns the number of decoded words.

Suffix:
 <sb> 1 to 4, index of the serial bus

Return values:
 <Count> Total number of words.

Usage:
 Query only
 Asynchronous command

SBUS<sb>:MILStd:WORD<w>:BITRate?

Returns the bit rate of the word.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <w> *
 Index of the word

Return values:
 <PrimaryBitRate> Increment: 1
 *RST: 0
 Default unit: bps

Usage:
 Query only
 Asynchronous command

SBUS<sb>:MILStd:WORD<w>:DATA?

Return the data pattern of the specified word.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <w> *
 Index of the word

Return values:
 <FrmDatPatt> List of comma separated values.

Usage:
 Query only
 Asynchronous command

SBUS<sb>:MILStd:WORD<w>:INFO?

Returns the info value for the specified word.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <w> *
 Index of the word

Return values:

<FrameInfo> Range: 0 to 2047
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

SBUS<sb>:MILStd:WORD<w>:RTAddress?

Returns the RT address for the selected word.

Suffix:

<sb> 1 to 4, index of the serial bus
 <w> *
 Index of the word

Return values:

<FrameRta> Range: 0 to 31
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

SBUS<sb>:MILStd:WORD<w>:START?

Return the start time of the selected word.

Suffix:

<sb> 1 to 4, index of the serial bus
 <w> *
 Index of the word

Return values:

<FrameStart> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

SBUS<sb>:MILStd:WORD<w>:STATus?

Returns the overall state of the selected word.

Suffix:

<sb> 1 to 4, index of the serial bus

<w> *
Index of the word

Return values:
<FrameState> OK | SYNC | MANC | PAR | GAP | RT | INComplete | UNKNown

OK: the word is valid.
 SYNC: synchronization error occurred.
 MANC: manchester coding error occurred.
 PAR: parity error occurred.
 GAP: timing gap error occurred.
 RT: remote terminal error occurred.
 INComplete: the sequence is not completely contained in the acquisition
 UNKNown: unknown frame type
 *RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:MILStd:WORD<w>:STOP?

Returns the stop time of the selected word.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <w> *
 Index of the word

Return values:
 <FrameStop> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:MILStd:WORD<w>:SYMBol?

Returns the symbolic label of the specified word if the label list is enabled.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <w> *
 Index of the word

Return values:
 <SymbolicName>

Usage: Query only
Asynchronous command

SBUS<sb>:MILStd:WORD<w>:TYPE?

Returns the type of the specified word.

Suffix:

<sb>	1 to 4, index of the serial bus
<w>	*
	Index of the word

Return values:

<FrameType>	UNKNown DATA CMD STAT CMST IM
	CMD: command word
	CMST: command/status word
	IM: inter message. Shows if there are gap errors or response timeout.
*RST:	DATA

Usage:

Query only
Asynchronous command

18.18.15 SpaceWire (option R&S MXO5C-K530)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with [SBUS<sb>\[:STATe\]](#).
- The bus is set to the correct type with [SBUS<sb>:TYPE](#).

• Configuration	1663
• Filter	1666
• Software trigger	1670
• Decode results	1675

18.18.15.1 Configuration

SBUS<sb>:SWIRe:DATA:SOURce	1663
SBUS<sb>:SWIRe:STRBe:SOURce	1664
SBUS<sb>:SWIRe:DATA:THReshold	1664
SBUS<sb>:SWIRe:DATA:HYSTeresis	1664
SBUS<sb>:SWIRe:STRBe:THReshold	1665
SBUS<sb>:SWIRe:STRBe:HYSTeresis	1665
SBUS<sb>:SWIRe:MINGap	1665
SBUS<sb>:SWIRe:MGAP	1665
SBUS<sb>:SWIRe:POSition	1665
SBUS<sb>:SWIRe:SCALe	1666

SBUS<sb>:SWIRe:DATA:SOURce Source

Selects the channel for the data signal source.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

Source C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage:

Asynchronous command

Manual operation: See ["Data Source"](#) on page 718

SBUS<sb>:SWIRe:STRBe:SOURce <StrobeSource>

Selects the source for the strobe signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<StrobeSource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage:

Asynchronous command

Manual operation: See ["Strobe Source"](#) on page 718

SBUS<sb>:SWIRe:DATA:THReshold <DataThreshold>

Sets the threshold for the data channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DataThreshold>

Usage:

Asynchronous command

Manual operation: See ["Thresholds"](#) on page 719

SBUS<sb>:SWIRe:DATA:HYSTeresis <DataHysteresis>

Sets the hysteresis for the data channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DataHysteresis>

Usage:

Asynchronous command

Manual operation: See ["Thresholds"](#) on page 719

SBUS<sb>:SWIRe:STRBe:THReshold <StrobeThres>

Sets the threshold value for the digitization of the strobe signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<StrobeThres>

Usage:

Asynchronous command

Manual operation: See ["Thresholds"](#) on page 719

SBUS<sb>:SWIRe:STRBe:HYSTeresis <StrobeHyst>

Sets a value for the hysteresis of the strobe signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<StrobeHyst>

Usage:

Asynchronous command

Manual operation: See ["Thresholds"](#) on page 719

SBUS<sb>:SWIRe:MINGap <MinGapTime>

SBUS<sb>:SWIRe:MGAP <MinGapTime>

Sets the minimum duration of a gap. Any inactivity greater than this time is interpreted as a gap and leads to a resynchronization to the signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MinGapTime> Range: 1E-09 to 1
Increment: 1E-09
*RST: 2E-07
Default unit: s

Usage:

Asynchronous command

Manual operation: See ["Min Gap"](#) on page 718

SBUS<sb>:SWIRe:POSition <Position>

Sets the vertical position of the SpaceWire signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Position>

Usage:

Asynchronous command

SBUS<sb>:SWIRe:SCALE <Scale>

Sets the vertical scale of the SpaceWire signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Scale>

Usage:

Asynchronous command

18.18.15.2 Filter

There are two commands for each parameter, that you can use for defining the SpaceWire settings.

For example, to set the *Frame type =SpaceWire-Frame > Field =Data >Data* value you can use one of the following commands:

- SBUS:SWIRe:FILTer:FRAMe1:FLD1:DMIN 01100
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- SBUS:SWIRe:FILTer:DMIN "SpaceWire-Frame", "Data", 01100
Defines the parameter by using the frame and field name.

SBUS<sb>:SWIRe:FILTer:CHKall.....	1667
SBUS<sb>:SWIRe:FILTer:CLR.....	1667
SBUS<sb>:SWIRe:FILTer:INVert.....	1667
SBUS<sb>:SWIRe:FILTer:RST.....	1667
SBUS<sb>:SWIRe:FILTer:BIT.....	1667
SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1667
SBUS<sb>:SWIRe:FILTer:ERENable.....	1668
SBUS<sb>:SWIRe:FILTer:ERRor<n>:ENABLE.....	1668
SBUS<sb>:SWIRe:FILTer:DMAX.....	1668
SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1668
SBUS<sb>:SWIRe:FILTer:DMIN.....	1669
SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1669
SBUS<sb>:SWIRe:FILTer:DOPerator.....	1669
SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1669
SBUS<sb>:SWIRe:FILTer:FIENable.....	1669
SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:ENABLE.....	1669
SBUS<sb>:SWIRe:FILTer:FRENable.....	1670
SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:ENABLE.....	1670

SBUS<sb>:SWIRe:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 721

SBUS<sb>:SWIRe:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 721

SBUS<sb>:SWIRe:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 721

SBUS<sb>:SWIRe:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 721

SBUS<sb>:SWIRe:FILTer:BIT <Frame>,<Field>,<Bit>

SBUS<sb>:SWIRe:FILTer:BIT? <Bit>

SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<BitState>** ONE | ZERO***RST:** ZERO**Usage:** Asynchronous command**Manual operation:** See ["Edit"](#) on page 722**SBUS<sb>:SWIRe:FILTer:ERENable** <ErrorName>,<Enabler>**SBUS<sb>:SWIRe:FILTer:ERENable?** <Enabler>**SBUS<sb>:SWIRe:FILTer:ERRor<n>:ENABLE** <Enable>

Defines the error type to be filtered on.

Suffix:**<sb>** 1 to 4, index of the serial bus**<n>** index of the error**Parameters:****<Enable>** OFF | ON***RST:** ON**Usage:** Asynchronous command**Manual operation:** See ["Error type"](#) on page 723**SBUS<sb>:SWIRe:FILTer:DMAX** <Frame>,<Field>,<Data>**SBUS<sb>:SWIRe:FILTer:DMAX?** <Data>**SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:DMAX** <Data_Max>Sets the end value of a data pattern range if the operator is set to **INRange** or **OORANGE**.You can set the operator with **SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:DOperator**.**Suffix:****<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<Data_Max>****Usage:** Asynchronous command**Manual operation:** See ["Edit"](#) on page 722

SBUS<sb>:SWIRe:FILTer:DMIN <Frame>,<Field>,<Data>

SBUS<sb>:SWIRe:FILTer:DMIN? <Data>

SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 722

SBUS<sb>:SWIRe:FILTer:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:SWIRe:FILTer:DOPerator? <Operator>

SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange

*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 722

SBUS<sb>:SWIRe:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:SWIRe:FILTer:FIENable? <Enabler>

SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 722

SBUS<sb>:SWIRe:FILTer:FRENAble <Frame>,<Enabler>

SBUS<sb>:SWIRe:FILTer:FRENAble? <Enabler>

SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:ENABLe <Enable>

Enables the filtering on SpaceWire frames. Only the frames that match the selected filter conditions are displayed.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Enable"](#) on page 721

18.18.15.3 Software trigger

There are two commands for each parameter, that you can use for defining the SpaceWire settings.

For example, to set the *Frame type =SpaceWire-Frame > Field =Data >Data* value you can use one of the following commands:

- `TRIGger:SBSW:SWIRe:FRAMe1:FLD1:DMIN 01100`
 Defines the parameter by using the index <fr> for the frame number and <fl> for the field number.
- `TRIGger:SBSW:SWIRe:DMIN "SpaceWire-Frame", "Data", 01100`
 Defines the parameter by using the frame and field name.

TRIGger:SBSW:SWIRe:CHKall	1671
TRIGger:SBSW:SWIRe:CLR	1671
TRIGger:SBSW:SWIRe:INVert	1671
TRIGger:SBSW:SWIRe:RST	1671
TRIGger:SBSW:SWIRe:FRENAble	1672
TRIGger:SBSW:SWIRe:FRAMe<fr>:ENABLe	1672
TRIGger:SBSW:SWIRe:BIT	1672
TRIGger:SBSW:SWIRe:FRAMe<fr>:FLD<fl>:BIT	1672
TRIGger:SBSW:SWIRe:DMAX	1672
TRIGger:SBSW:SWIRe:FRAMe<fr>:FLD<fl>:DMAX	1672
TRIGger:SBSW:SWIRe:DMIN	1673

TRIGger:SBSW:SWIRe:FRAMe<fr>:FLD<fl>:DMIN.....	1673
TRIGger:SBSW:SWIRe:DOPerator.....	1673
TRIGger:SBSW:SWIRe:FRAMe<fr>:FLD<fl>:DOPerator.....	1673
TRIGger:SBSW:SWIRe:FIENable.....	1673
TRIGger:SBSW:SWIRe:FRAMe<fr>:FLD<fl>:ENABLE.....	1673
TRIGger:SBSW:SWIRe:ERENable.....	1674
TRIGger:SBSW:SWIRe:ERRor<m>:ENABLE.....	1674
SBUS<sb>:SWIRe:SWTIndex?.....	1674
SBUS<sb>:SWIRe:SWTTime?.....	1674

TRIGger:SBSW:SWIRe:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 724

TRIGger:SBSW:SWIRe:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 724

TRIGger:SBSW:SWIRe:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 724

TRIGger:SBSW:SWIRe:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 724

TRIGger:SBSW:SWIRe:FREnable <Frame>,<Enabler>

TRIGger:SBSW:SWIRe:FREnable? <Enabler>

TRIGger:SBSW:SWIRe:FRAMe<fr>:ENABle <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 725

TRIGger:SBSW:SWIRe:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:SWIRe:BIT? <Bit>

TRIGger:SBSW:SWIRe:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO

*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 725

TRIGger:SBSW:SWIRe:DMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:SWIRe:DMAX? <Data>

TRIGger:SBSW:SWIRe:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGE.

You can set the operator with [TRIGger:SBSW:SWIRe:FRAMe<fr>:FLD<fl>:DOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 725

TRIGger:SBSW:SWIRe:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:SWIRe:DMIN? <Data>

TRIGger:SBSW:SWIRe:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 725

TRIGger:SBSW:SWIRe:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:SWIRe:DOPerator? <Operator>

TRIGger:SBSW:SWIRe:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange
*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 725

TRIGger:SBSW:SWIRe:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:SWIRe:FIENable? <Enabler>

TRIGger:SBSW:SWIRe:FRAMe<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 725

TRIGger:SBSW:SWIRe:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:SWIRe:ERENable? <Enabler>

TRIGger:SBSW:SWIRe:ERRor<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> index of the error

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 726

SBUS<sb>:SWIRe:SWTindex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295
 Increment: 1
 *RST: 0

Usage: Query only
 Asynchronous command

SBUS<sb>:SWIRe:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

18.18.15.4 Decode results

This section describes the commands to query the results of the decoding.

SBUS<sb>:SWIRe:FCOunt?	1675
SBUS<sb>:SWIRe:FRAMe<fr>:BITRate?	1675
SBUS<sb>:SWIRe:FRAMe<fr>:DATA?	1676
SBUS<sb>:SWIRe:FRAMe<fr>:CODParity?	1676
SBUS<sb>:SWIRe:FRAMe<fr>:DATParity?	1677
SBUS<sb>:SWIRe:FRAMe<fr>:ESCParity?	1677
SBUS<sb>:SWIRe:FRAMe<fr>:FLD<fl>:STATus?	1678
SBUS<sb>:SWIRe:FRAMe<fr>:FLD<fl>:TYPE?	1678
SBUS<sb>:SWIRe:FRAMe<fr>:FLD<fl>:VALue?	1679
SBUS<sb>:SWIRe:FRAMe<fr>:FLD<fl>:FVALue?	1679
SBUS<sb>:SWIRe:FRAMe<fr>:STATe?	1679
SBUS<sb>:SWIRe:FRAMe<fr>:START?	1680
SBUS<sb>:SWIRe:FRAMe<fr>:STOP?	1680
SBUS<sb>:SWIRe:FRAMe<fr>:TYPE?	1681

SBUS<sb>:SWIRe:FCOunt?

Returns the number of decoded frames.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count>

Usage:

Query only
 Asynchronous command

SBUS<sb>:SWIRe:FRAMe<fr>:BITRate?

Returns the bit rate of the frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<PrimaryBitRate> Increment: 1
 *RST: 0
 Default unit: bps

Usage:

Query only
 Asynchronous command

SBUS<sb>:SWIRe:FRAMe<fr>:DATA?

Returns the data of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<FrameData>

Usage:

Query only
 Asynchronous command

SBUS<sb>:SWIRe:FRAMe<fr>:CODParity?

If the frame has the `FCT`, `EOP`, `EEP` or `Code` field, the command returns the parity state of this field, which can take values of `OK` or `PARity`. For a description of these fields, see [Section 14.13.1, "SpaceWire basics"](#), on page 717.

If the frame has none of these fields, the command can return the states `LENGth`, `AMBiGuous` or `INComplete` of the frame, as described below.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<ParityCode> OK | PARity | LENGth | AMBiGuous | INComplete

OK

The parity check for the field covered by this parity bit passes.

PARity

The parity of the field is not correct.

LENGth

Regardless of the field, the length of the frame is not as expected, indicating an error.

AMBiGuous

Regardless of the field, the frame is ambiguous.

INComplete

Regardless of the field, the frame is incomplete.

*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:SWIRe:FRAMe<fr>:DATParity?

If the frame has the `Data` field, the command returns the parity state of this field, which can take values of `OK` or `PARity`. The `Data` field only appears in `Data` and `Time` frames, see [Figure 14-39](#) and [Figure 14-41](#).

If the frame has no `Data` field, the command can return the states `LENGth`, `AMBiGuous` or `INComplete` of the frame, as described below.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<ParityData> `OK` | `PARity` | `LENGth` | `AMBiGuous` | `INComplete`

OK

The parity check for the `Data` field passes.

PARity

The parity of the `Data` field is not correct.

LENGth

Regardless of the `Data` field, the length of the frame is not as expected, indicating an error

AMBiGuous

Regardless of the `Data` field, the frame is ambiguous.

INComplete

Regardless of the `Data` field, the frame is incomplete.

*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:SWIRe:FRAMe<fr>:ESCParity?

If the frame has the `ESC` field, the command returns the parity state of this field, which can take values of `OK` or `PARity`. See [Figure 14-40](#).

If the frame has no `ESC` field, the command can return the states `LENGth`, `AMBiGuous` or `INComplete` of the frame, as described below.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<ParityEscape> `OK` | `PARity` | `LENGth` | `AMBiGuous` | `INComplete`

OK

The parity check for the `ESC` field passes.

PARity

The parity of the `ESC` field is not correct.

LENGth

Regardless of the `ESC` field, the length of the frame is not as expected, indicating an error.

AMBiguous

Regardless of the `ESC` field, the frame is ambiguous.

INComplete

Regardless of the `ESC` field, the frame is incomplete.

*RST: OK

Usage:

Query only

Asynchronous command

SBUS<sb>:SWIRe:FRAME<fr>:FLD<fl>:STATus?

Returns the overall state of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<State> OK | PARity | LENGth | AMBiguous | INComplete

OK

The parity check for the selected field passes.

PARity

Parity is not as expected, indicating an error.

LENGth

The length of the field is not as expected, indicating an error.

AMBiguous

The frame is ambiguous.

INComplete

The frame is incomplete.

*RST: OK

Usage:

Query only

Asynchronous command

SBUS<sb>:SWIRe:FRAME<fr>:FLD<fl>:TYPE?

Returns the label of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Label>

Usage:

Query only

Asynchronous command

SBUS<sb>:SWIRe:FRAME<fr>:FLD<fl>:VALue?

Returns the value of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Value> *RST: 0

Usage:

Query only

Asynchronous command

SBUS<sb>:SWIRe:FRAME<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<FormattedValue>

Usage:

Query only

Asynchronous command

SBUS<sb>:SWIRe:FRAME<fr>:STATe?

Returns the overall state of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameState> OK | PARity | LENGth | AMBiguous | INComplete

OK

The frame is valid.

PARity

Parity is not as expected, indicating an error

LENGth

Length of the frame is not as expected, indicating an error

AMBiguous

The frame is ambiguous.

INComplete

The frame is incomplete.

*RST: OK

Usage:

Query only

Asynchronous command

SBUS<sb>:SWIRe:FRAMe<fr>:START?

Returns the start time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStart> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only

Asynchronous command

SBUS<sb>:SWIRe:FRAMe<fr>:STOP?

Returns the end time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:SWIRe:FRAME<fr>:TYPE?

Returns the type of the specified decoded frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameType> DATA | TCOD | FCT | NULL | EOP | EEP | BADX

DATA

Data frame

TCOD

Time-code frame

FCT

Flow control token

NULL

Null symbol

EOP

End of packet

EEP

Error end of packet

BADX

Illegal escape code

*RST: DATA

Usage: Query only
Asynchronous command

18.18.16 SPMI (option R&S MXO5C-K550)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with `SBUS<sb>[:STATe]`.
- The bus is set to the correct type with `SBUS<sb>:TYPE`.

• Configuration	1682
• Filter	1686
• Software trigger	1691
• Decode results	1697

18.18.16.1 Configuration

SBUS<sb>:SPMI:GSIDenable.....	1682
SBUS<sb>:SPMI:GIDValue.....	1682
SBUS<sb>:SPMI:GTCHenable.....	1683
SBUS<sb>:SPMI:GTWDith.....	1683
SBUS<sb>:SPMI:SCLK:HYSteresis.....	1683
SBUS<sb>:SPMI:SCLK:SOURce.....	1683
SBUS<sb>:SPMI:SCLK:THReshold.....	1684
SBUS<sb>:SPMI:SDATa:HYSteresis.....	1684
SBUS<sb>:SPMI:SDATa:SOURce.....	1684
SBUS<sb>:SPMI:SDATa:THReshold.....	1685
SBUS<sb>:SPMI:POSition.....	1685
SBUS<sb>:SPMI:SCALE.....	1685
SBUS<sb>:SPMI:SYMBols.....	1685
SBUS<sb>:SPMI:NEWList.....	1686

SBUS<sb>:SPMI:GSIDenable <UseGSID>

Enables the use of the group sub ID (GSID). You can set the GSID with [SBUS<sb>:SPMI:GIDValue](#).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<UseGSID> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Use GSID, GSID \(hex\)"](#) on page 745

SBUS<sb>:SPMI:GIDValue <GSID>

Sets a value for the group sub index. Available, if [SBUS<sb>:SPMI:GSIDenable](#) is set to ON.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<GSID> Range: 0 to 15
Increment: 1
*RST: 0

Usage: Asynchronous command

Manual operation: See ["Use GSID, GSID \(hex\)"](#) on page 745

SBUS<sb>:SPMI:GTCHenable <UseGlitchFilter>

Enables the glitch filter. A glitch filter can help to filter out short-duration voltage spikes/glitches that can occur on the communication line.

You can set the glitch filter width with [SBUS<sb>:SPMI:GTWDith](#).

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<UseGlitchFilter> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See "[Glitch filter, Glitch width](#)" on page 745

SBUS<sb>:SPMI:GTWDith <GlitchFilterWdt>

Sets the glitch width. Any signal transitions with a duration smaller than this value will be considered a glitch and filtered out.

This is available, if [SBUS<sb>:SPMI:GTCHenable](#) is set to ON.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<GlitchFilterWdt> Range: 1E-15 to 1000000000
Increment: 1E-10
*RST: 1E-09
Default unit: s

Usage: Asynchronous command

Manual operation: See "[Glitch filter, Glitch width](#)" on page 745

SBUS<sb>:SPMI:SCLK:HYSteresis <Hysteresis>

Sets a value for the hysteresis for the clock line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage: Asynchronous command

Manual operation: See "[Threshold](#)" on page 746

SBUS<sb>:SPMI:SCLK:SOURce <ClockSource>

Sets the source of the clock line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ClockSource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage:

Asynchronous command

Manual operation: See ["SCLK"](#) on page 745

SBUS<sb>:SPMI:SCLK:THReshold <Threshold>

Sets a user-defined threshold value for the clock line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold>

Usage:

Asynchronous command

Manual operation: See ["Threshold"](#) on page 746

SBUS<sb>:SPMI:SDATa:HYSTeresis <SDATA Hyst>

Sets a value for the hysteresis for the source data channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SDATA Hyst>

Usage:

Asynchronous command

Manual operation: See ["Threshold"](#) on page 746

SBUS<sb>:SPMI:SDATa:SOURce <DataSource>

Sets the source of the data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DataSource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage:

Asynchronous command

Manual operation: See ["SDATA"](#) on page 745

SBUS<sb>:SPMI:SDATa:THReshold <SDATA Thres>

Sets a user-defined threshold value for the source data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SDATA Thres>

Usage:

Asynchronous command

Manual operation: See ["Threshold"](#) on page 746

SBUS<sb>:SPMI:POSition <SPMI position>

Sets the vertical position of the SPMI signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SPMI position>

Usage:

Asynchronous command

SBUS<sb>:SPMI:SCALe <SPMI scale>

Sets the vertical position of the SPMI signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SPMI scale>

Usage:

Asynchronous command

SBUS<sb>:SPMI:SYMBols <ShowSymbols>

Activates the symbol list to be used for decoding.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ShowSymbols> OFF | ON

*RST: OFF

Usage:

Asynchronous command

SBUS<sb>:SPMI:NEWList <FileName>

Loads a symbol list file.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName> String parameter with path and filename.

Usage:

Setting only

Asynchronous command

18.18.16.2 Filter

There are two commands for each parameter, that you can use for defining the SPMI settings.

For example, to set the *Frame type =Register 0 Write > Field =Data >00* value you can use one of the following commands:

- SBUS:SPMI:FILTer:FRAMe1:FLD1:DMIN 00
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- SBUS:SPMI:FILTer:DMIN "Register 0 Write", "Data", 00
Defines the parameter by using the frame and field name.

SBUS<sb>:SPMI:FILTer:CHKall.....	1687
SBUS<sb>:SPMI:FILTer:CLR.....	1687
SBUS<sb>:SPMI:FILTer:INVert.....	1687
SBUS<sb>:SPMI:FILTer:RST.....	1687
SBUS<sb>:SPMI:FILTer:BIT.....	1687
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1687
SBUS<sb>:SPMI:FILTer:DMAX.....	1688
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1688
SBUS<sb>:SPMI:FILTer:DMIN.....	1688
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1688
SBUS<sb>:SPMI:FILTer:DOPerator.....	1689
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1689
SBUS<sb>:SPMI:FILTer:ERENable.....	1689
SBUS<sb>:SPMI:FILTer:ERRor<n>:ENABle.....	1689
SBUS<sb>:SPMI:FILTer:IOperator.....	1689
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:IOperator.....	1689
SBUS<sb>:SPMI:FILTer:IMIN.....	1690
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1690
SBUS<sb>:SPMI:FILTer:IMAX.....	1690
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1690
SBUS<sb>:SPMI:FILTer:FRENable.....	1691
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:ENABle.....	1691
SBUS<sb>:SPMI:FILTer:FIENable.....	1691
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1691

SBUS<sb>:SPMI:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 747

SBUS<sb>:SPMI:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 747

SBUS<sb>:SPMI:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 747

SBUS<sb>:SPMI:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 747

SBUS<sb>:SPMI:FILTer:BIT <Frame>,<Field>,<Bit>

SBUS<sb>:SPMI:FILTer:BIT? <Bit>

SBUS<sb>:SPMI:FILTer:FRAME<fr>:FLD<fl>:BIT <BitState>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<BitState>** ONE | ZERO***RST:** ZERO**Usage:** Asynchronous command**Manual operation:** See ["Edit"](#) on page 748**SBUS<sb>:SPMI:FILTer:DMAX** <Frame>,<Field>,<Data>**SBUS<sb>:SPMI:FILTer:DMAX?** <Data>**SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:DMAX** <Data_Max>Sets the end value of a data pattern range if the operator is set to `INRange` or `OORANGe`.You can set the operator with `SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:DOPerator`.**Suffix:****<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<Data_Max>****Usage:** Asynchronous command**Manual operation:** See ["Edit"](#) on page 748**SBUS<sb>:SPMI:FILTer:DMIN** <Frame>,<Field>,<Data>**SBUS<sb>:SPMI:FILTer:DMIN?** <Data>**SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:DMIN** <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<Data_Min>****Usage:** Asynchronous command**Manual operation:** See ["Edit"](#) on page 748

SBUS<sb>:SPMI:FILTer:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:SPMI:FILTer:DOPerator? <Operator>

SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange

*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 748

SBUS<sb>:SPMI:FILTer:ERENable <ErrorName>,<Enabler>

SBUS<sb>:SPMI:FILTer:ERENable? <Enabler>

SBUS<sb>:SPMI:FILTer:ERRor<n>:ENABle <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 749

SBUS<sb>:SPMI:FILTer:IOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:SPMI:FILTer:IOPerator? <Operator>

SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUAL | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 748

SBUS<sb>:SPMI:FILTer:IMIN <Frame>,<Field>,<Data>

SBUS<sb>:SPMI:FILTer:IMIN? <Data>

SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 748

SBUS<sb>:SPMI:FILTer:IMAX <Frame>,<Field>,<Data>

SBUS<sb>:SPMI:FILTer:IMAX? <Data>

SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range if the operator is set to INRange.

You can set the operator with [SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:IOperator](#).

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 748

SBUS<sb>:SPMI:FILTer:FRENAble <Frame>,<Enabler>

SBUS<sb>:SPMI:FILTer:FRENAble? <Enabler>

SBUS<sb>:SPMI:FILTer:FRAMe<fr>:ENABLe <Enable>

Enables the filtering on SPMI frames. Only the frames that match the selected filter conditions are displayed.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 748

SBUS<sb>:SPMI:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:SPMI:FILTer:FIENable? <Enabler>

SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:ENABLe <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 748

18.18.16.3 Software trigger

There are two commands for each parameter, that you can use for defining the SPMI settings.

For example, to set the *Frame type =Register 0 Write > Field =Data >00* value you can use one of the following commands:

- `TRIGger:SBSW:SPMI:FRAMe1:FLD1:DMIN 00`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `TRIGger:SBSW:SPMI:DMIN "Register 0 Write", "Data", 00`
Defines the parameter by using the frame and field name.

TRIGger:SBSW:SPMI:CHKall.....	1692
TRIGger:SBSW:SPMI:CLR.....	1692
TRIGger:SBSW:SPMI:INVert.....	1692
TRIGger:SBSW:SPMI:RST.....	1693
TRIGger:SBSW:SPMI:FREnable.....	1693
TRIGger:SBSW:SPMI:FRAME<fr>:ENABLE.....	1693
TRIGger:SBSW:SPMI:BIT.....	1693
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:BIT.....	1693
TRIGger:SBSW:SPMI:DMAX.....	1694
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:DMAX.....	1694
TRIGger:SBSW:SPMI:DMIN.....	1694
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:DMIN.....	1694
TRIGger:SBSW:SPMI:DOPerator.....	1694
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:DOPerator.....	1694
TRIGger:SBSW:SPMI:FIENable.....	1695
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:ENABLE.....	1695
TRIGger:SBSW:SPMI:IMAX.....	1695
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:IMAX.....	1695
TRIGger:SBSW:SPMI:IMIN.....	1696
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:IMIN.....	1696
TRIGger:SBSW:SPMI:IOperator.....	1696
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:IOperator.....	1696
TRIGger:SBSW:SPMI:ERENable.....	1696
TRIGger:SBSW:SPMI:ERRor<m>:ENABLE.....	1696
SBUS<sb>:SPMI:SWTIndex?.....	1697
SBUS<sb>:SPMI:SWTTime?.....	1697

TRIGger:SBSW:SPMI:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 750

TRIGger:SBSW:SPMI:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 750

TRIGger:SBSW:SPMI:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 750

TRIGger:SBSW:SPMI:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 750

TRIGger:SBSW:SPMI:FRENAble <Frame>,<Enabler>

TRIGger:SBSW:SPMI:FRENAble? <Enabler>

TRIGger:SBSW:SPMI:FRAME<fr>:ENABLe <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:
<fr> Index of the frame

Parameters:
<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 751

TRIGger:SBSW:SPMI:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:SPMI:BIT? <Bit>

TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:
<fr> Index of the frame
<fl> Index of the field

Parameters:
<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 751

TRIGger:SBSW:SPMI:DMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:SPMI:DMAX? <Data>

TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGE.

You can set the operator with **TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:DOPerator**.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See "Edit" on page 751

TRIGger:SBSW:SPMI:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:SPMI:DMIN? <Data>

TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See "Edit" on page 751

TRIGger:SBSW:SPMI:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:SPMI:DOPerator? <Operator>

TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 751

TRIGger:SBSW:SPMI:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:SPMI:FIENable? <Enabler>

TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 751

TRIGger:SBSW:SPMI:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:SPMI:IMAX? <Data>

TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with [TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:IOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 751

TRIGger:SBSW:SPMI:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:SPMI:IMIN? <Data>

TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 751

TRIGger:SBSW:SPMI:IOperator <Frame>,<Field>,<Operator>

TRIGger:SBSW:SPMI:IOperator? <Operator>

TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUAL | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 751

TRIGger:SBSW:SPMI:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:SPMI:ERENable? <Enabler>

TRIGger:SBSW:SPMI:ERROR<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> Index of the error

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 752

SBUS<sb>:SPMI:SWTIndex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:SPMI:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

18.18.16.4 Decode results

SBUS<sb>:SPMI:FCOut?	1698
SBUS<sb>:SPMI:FRAMe<fr>:ADDRess?	1698
SBUS<sb>:SPMI:FRAMe<fr>:BC?	1698
SBUS<sb>:SPMI:FRAMe<fr>:DATA?	1698
SBUS<sb>:SPMI:FRAMe<fr>:FLDCount?	1699
SBUS<sb>:SPMI:FRAMe<fr>:FLD<fl>:FVALue?	1699
SBUS<sb>:SPMI:FRAMe<fr>:FLD<fl>:LABel?	1699
SBUS<sb>:SPMI:FRAMe<fr>:FLD<fl>:STATe?	1700
SBUS<sb>:SPMI:FRAMe<fr>:FLD<fl>:VALue?	1700
SBUS<sb>:SPMI:FRAMe<fr>:RBRate?	1700
SBUS<sb>:SPMI:FRAMe<fr>:SA?	1701
SBUS<sb>:SPMI:FRAMe<fr>:START?	1701
SBUS<sb>:SPMI:FRAMe<fr>:STATus?	1701
SBUS<sb>:SPMI:FRAMe<fr>:STOP?	1702

SBUS<sb>:SPMI:FRAME<fr>:TYPE?	1702
SBUS<sb>:SPMI:FRAME<fr>:WBRate?	1703
SBUS<sb>:SPMI:FRAME<fr>:SYMBOL?	1703

SBUS<sb>:SPMI:FCount?

Returns the number of decoded frames in the acquisition.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count>

Usage:

Query only
Asynchronous command

SBUS<sb>:SPMI:FRAME<fr>:ADDRess?

Returns the address of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameADDR> Range: 0 to 65535
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:SPMI:FRAME<fr>:BC?

Returns the BC of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameBC> Range: 0 to 65535
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:SPMI:FRAME<fr>:DATA?

Returns the data value of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameData>

Usage:

Query only

SBUS<sb>:SPMI:FRAME<fr>:FLDCount?

Returns the field count of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Count>

Usage:

Query only

Asynchronous command

SBUS<sb>:SPMI:FRAME<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified byte.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<FormattedValue>

Usage:

Query only

Asynchronous command

SBUS<sb>:SPMI:FRAME<fr>:FLD<fl>:LABEL?

Returns the label of the fields in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Label>

Usage: Query only
Asynchronous command

SBUS<sb>:SPMI:FRAME<fr>:FLD<fl>:STATe?

Returns the overall state of the frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<State> OK | NOReponse | ACKerror | BPERror | PARerror | LENerror | ARBerror | SSCerror | CMDerror | CODerror | INComplete

*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:SPMI:FRAME<fr>:FLD<fl>:VALue?

Returns the data value of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Value> Increment: 1

*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:SPMI:FRAME<fr>:RBRate?

Returns the read bit rate of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameRBR> Increment: 1

*RST: 0

Default unit: bps

Usage: Query only

SBUS<sb>:SPMI:FRAMe<fr>:SA?

Returns the address of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<FrameSA> Range: 0 to 65535
 Increment: 1
 *RST: 0

Usage: Query only
 Asynchronous command

SBUS<sb>:SPMI:FRAMe<fr>:STARt?

Returns the start time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<FrameStart> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage: Query only
 Asynchronous command

SBUS<sb>:SPMI:FRAMe<fr>:STATus?

Returns the overall state of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<FrameState> OK | NOReponse | ACKerror | BPERror | PARerror | LENerror |
 ARBerror | SSCerror | CMDerror | CODerror | INComplete
 *RST: OK

Usage: Query only
 Asynchronous command

SBUS<sb>:SPMI:FRAME<fr>:STOP?

Returns the stop time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

SBUS<sb>:SPMI:FRAME<fr>:TYPE?

Returns the frame type.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameType> RZWR | RWR | RRD | ERWR | ERRD | ERWL | ERRL | MAWR |
MARD | BMRD | BSRD | TBOW | REST | SLEP | SHUT | WAK |
AUTH | INV | UNKN | ARB

RZWR: register 0 write

RWR: register write

RRD: register read

ERWR: extended register write

ERRD: extended register read

ERWL: extended register write long

ERRL: extended register read long

MAWR: main write

MARD: main read

BMRD: device descriptor block main read

BSRD: device descriptor block sub read

TBOW: transfer bus ownership

REST: reset

SLEP: sleep

SHUT: shutdown

WAK: wakeup

AUTH: authenticate

INV: invalid

UNKN: unknown

ARB: arbitration frame

*RST: RZWR

Usage: Query only
Asynchronous command

SBUS<sb>:SPMI:FRAME<fr>:WBRate?

Returns the write bit rate of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameWBR> Increment: 1
*RST: 0
Default unit: bps

Usage: Query only

SBUS<sb>:SPMI:FRAME<fr>:SYMBOL?

Returns the symbolic label of the specified frame if the label list is enabled.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<SymbolicName> String with symbolic name of the address
String with the symbolic name of the frame

Usage: Query only
Asynchronous command

18.18.17 RFFE (option R&S MXO5C-K550)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with `SBUS<sb>[:STATe]`.
- The bus is set to the correct type with `SBUS<sb>:TYPE`.

18.18.17.1 Configuration

<code>SBUS<sb>:RFFE:CLOCK:HYSteresis</code>	1704
<code>SBUS<sb>:RFFE:CLOCK:SOURce</code>	1704
<code>SBUS<sb>:RFFE:CLOCK:THReshold</code>	1704
<code>SBUS<sb>:RFFE:DATA:HYSteresis</code>	1704
<code>SBUS<sb>:RFFE:DATA:SOURce</code>	1705
<code>SBUS<sb>:RFFE:DATA:THReshold</code>	1705

SBUS<sb>:RFFE:GFILter.....	1705
SBUS<sb>:RFFE:GFWidth.....	1706
SBUS<sb>:RFFE:POSition.....	1706
SBUS<sb>:RFFE:RDMD.....	1706
SBUS<sb>:RFFE:SCALe.....	1706

SBUS<sb>:RFFE:CLOCK:HYSTeresis <Hysteresis>

Sets a hysteresis for the clock line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 761

SBUS<sb>:RFFE:CLOCK:SOURce <SourceClock>

Sets the source of the clock line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<SourceClock> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2 | M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["SCLK"](#) on page 760

SBUS<sb>:RFFE:CLOCK:THReshold <Threshold>

Sets a threshold value for the clock line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Threshold>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 761

SBUS<sb>:RFFE:DATA:HYSTeresis <DATA Hyst>

Sets a hysteresis for the data.

Suffix:
 <sb> 1 to 4, index of the serial bus

Parameters:
 <DATA Hyst>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 761

SBUS<sb>:RFFE:DATA:SOURce <SourceData>

Sets the source of the data line.

Suffix:
 <sb> 1 to 4, index of the serial bus

Parameters:
 <SourceData> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2 | M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["SDATA"](#) on page 760

SBUS<sb>:RFFE:DATA:THReshold <DATA Threshold>

Sets a threshold value for the data line.

Suffix:
 <sb> 1 to 4, index of the serial bus

Parameters:
 <DATA Threshold>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 761

SBUS<sb>:RFFE:GFILter <GlitchFilter>

Enables the glitch filter on the SCLK and SDATA lines to improve decode accuracy.

Suffix:
 <sb> 1 to 4, index of the serial bus

Parameters:
 <GlitchFilter> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Use glitch filter, Glitch filter width"](#) on page 761

SBUS<sb>:RFFE:GFWidth <GlitchFilterWdt>

Sets the maximum glitch width to be ignored.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<GlitchFilterWdt> Range: 1E-11 to 1E-08
Increment: 1E-11
*RST: 1E-09
Default unit: s

Usage: Asynchronous command

Manual operation: See ["Use glitch filter, Glitch filter width"](#) on page 761

SBUS<sb>:RFFE:POSition <RFFE position>

Sets the vertical position of the RFFE signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<RFFE position>

Usage: Asynchronous command

SBUS<sb>:RFFE:RDMD <ReadMode>

Selects, if the standard or synchronous read mode is used.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ReadMode> STRD | SREAD
STRD: standard
SREAD: synchronous read
*RST: STRD

Usage: Asynchronous command

Manual operation: See ["Read mode"](#) on page 761

SBUS<sb>:RFFE:SCALE <RFFE scale>

Set the vertical scale of the indicated RFFE signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<RFFE scale>

Usage:

Asynchronous command

18.18.17.2 Filter

There are two commands for each parameter, that you can use for defining the RFFE settings.

For example, to set the *Frame type =Register 0 Write > Field =Data >01100* value you can use one of the following commands:

- `SBUS:RFFE:FILTer:FRAMe1:FLD1:DMIN 01100`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `SBUS:RFFE:FILTer:DMIN "Register 0 Write", "Data", 01100`
Defines the parameter by using the frame and field name.

<code>SBUS<sb>:RFFE:FILTer:CHKall</code>	1707
<code>SBUS<sb>:RFFE:FILTer:CLR</code>	1708
<code>SBUS<sb>:RFFE:FILTer:INVert</code>	1708
<code>SBUS<sb>:RFFE:FILTer:RST</code>	1708
<code>SBUS<sb>:RFFE:FILTer:FRENable</code>	1708
<code>SBUS<sb>:RFFE:FILTer:FRAMe<fr>:ENABLE</code>	1708
<code>SBUS<sb>:RFFE:FILTer:BIT</code>	1709
<code>SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:BIT</code>	1709
<code>SBUS<sb>:RFFE:FILTer:DMAX</code>	1709
<code>SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:DMAX</code>	1709
<code>SBUS<sb>:RFFE:FILTer:DMIN</code>	1710
<code>SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:DMIN</code>	1710
<code>SBUS<sb>:RFFE:FILTer:DOPerator</code>	1710
<code>SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:DOPerator</code>	1710
<code>SBUS<sb>:RFFE:FILTer:FIENable</code>	1710
<code>SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:ENABLE</code>	1710
<code>SBUS<sb>:RFFE:FILTer:IMAX</code>	1711
<code>SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:IMAX</code>	1711
<code>SBUS<sb>:RFFE:FILTer:IMIN</code>	1711
<code>SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:IMIN</code>	1711
<code>SBUS<sb>:RFFE:FILTer:IOperator</code>	1712
<code>SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:IOperator</code>	1712
<code>SBUS<sb>:RFFE:FILTer:ERENable</code>	1712
<code>SBUS<sb>:RFFE:FILTer:ERRor<n>:ENABLE</code>	1712

SBUS<sb>:RFFE:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb>

1 to 4, index of the serial bus

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 762

SBUS<sb>:RFFE:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:
<sb> 1 to 4, index of the serial bus

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 762

SBUS<sb>:RFFE:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:
<sb> 1 to 4, index of the serial bus

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 762

SBUS<sb>:RFFE:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:
<sb> 1 to 4, index of the serial bus

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 762

SBUS<sb>:RFFE:FILTer:FRENAble <Frame>,<Enabler>

SBUS<sb>:RFFE:FILTer:FRENAble? <Enabler>

SBUS<sb>:RFFE:FILTer:FRAMe<fr>:ENABLe <Enable>

Enables the filtering on RFFE frames. Only the frames that match the selected filter conditions are displayed.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

SBUS<sb>:RFFE:FILTer:BIT <Frame>,<Field>,<Bit>

SBUS<sb>:RFFE:FILTer:BIT? <Bit>

SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<BitState> ONE | ZERO
 *RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 763

SBUS<sb>:RFFE:FILTer:DMAX <Frame>,<Field>,<Data>

SBUS<sb>:RFFE:FILTer:DMAX? <Data>

SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range if the operator is set to INRange or OORANGe.

You can set the operator with [SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:DOPerator](#).

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 763

SBUS<sb>:RFFE:FILTer:DMIN <Frame>,<Field>,<Data>

SBUS<sb>:RFFE:FILTer:DMIN? <Data>

SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 763

SBUS<sb>:RFFE:FILTer:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:RFFE:FILTer:DOPerator? <Operator>

SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange

*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 763

SBUS<sb>:RFFE:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:RFFE:FILTer:FIENable? <Enabler>

SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Enable"](#) on page 763

SBUS<sb>:RFFE:FILTer:IMAX <Frame>,<Field>,<Data>

SBUS<sb>:RFFE:FILTer:IMAX? <Data>

SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range if the operator is set to INRange.

You can set the operator with [SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:IOperator](#).

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 763

SBUS<sb>:RFFE:FILTer:IMIN <Frame>,<Field>,<Data>

SBUS<sb>:RFFE:FILTer:IMIN? <Data>

SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 763

SBUS<sb>:RFFE:FILTer:IOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:RFFE:FILTer:IOPerator? <Operator>

SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGe

*RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 763

SBUS<sb>:RFFE:FILTer:ERENable <ErrorName>,<Enabler>

SBUS<sb>:RFFE:FILTer:ERENable? <Enabler>

SBUS<sb>:RFFE:FILTer:ERRor<n>:ENABle <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 765

18.18.17.3 Software trigger

There are two commands for each parameter, that you can use for defining the RFFE settings.

For example, to set the *Frame type =Register 0 Write > Field =Data >01100* value you can use one of the following commands:

- `TRIGger:SBSW:RFFE:FRAMe1:FLD1:DMIN 01100`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `TRIGger:SBSW:RFFE:DMIN "Register 0 Write", "Data", 01100`
Defines the parameter by using the frame and field name.

TRIGger:SBSW:RFFE:CHKall.....	1713
TRIGger:SBSW:RFFE:CLR.....	1713
TRIGger:SBSW:RFFE:INVert.....	1713
TRIGger:SBSW:RFFE:RST.....	1714
TRIGger:SBSW:RFFE:FRENable.....	1714
TRIGger:SBSW:RFFE:FRAME<fr>:ENABle.....	1714
TRIGger:SBSW:RFFE:BIT.....	1714
TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:BIT.....	1714
TRIGger:SBSW:RFFE:DMAX.....	1715
TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:DMAX.....	1715
TRIGger:SBSW:RFFE:DMIN.....	1715
TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:DMIN.....	1715
TRIGger:SBSW:RFFE:DOPerator.....	1715
TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:DOPerator.....	1715
TRIGger:SBSW:RFFE:FIENable.....	1716
TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:ENABle.....	1716
TRIGger:SBSW:RFFE:IMAX.....	1716
TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:IMAX.....	1716
TRIGger:SBSW:RFFE:IMIN.....	1717
TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:IMIN.....	1717
TRIGger:SBSW:RFFE:IOPerator.....	1717
TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:IOPerator.....	1717
TRIGger:SBSW:RFFE:ERENable.....	1717
TRIGger:SBSW:RFFE:ERRor<m>:ENABle.....	1717
SBUS<sb>:RFFE:SWTIndex?.....	1718
SBUS<sb>:RFFE:SWTTime?.....	1718

TRIGger:SBSW:RFFE:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 767

TRIGger:SBSW:RFFE:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 767

TRIGger:SBSW:RFFE:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 767

TRIGger:SBSW:RFFE:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 767

TRIGger:SBSW:RFFE:FRENable <Frame>,<Enabler>

TRIGger:SBSW:RFFE:FRENable? <Enabler>

TRIGger:SBSW:RFFE:FRAME<fr>:ENABLE <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:
<fr> Index of the frame

Parameters:
<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 768

TRIGger:SBSW:RFFE:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:RFFE:BIT? <Bit>

TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:
<fr> Index of the frame

<fl> Index of the field

Parameters:
<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 768

TRIGger:SBSW:RFFE:DMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:RFFE:DMAX? <Data>

TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGE.

You can set the operator with **TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:DOPerator**.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See "Edit" on page 768

TRIGger:SBSW:RFFE:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:RFFE:DMIN? <Data>

TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See "Edit" on page 768

TRIGger:SBSW:RFFE:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:RFFE:DOPerator? <Operator>

TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

```
<Data_Operator>   EQUa| NEQua| LTHan| LETHan| GTHan| GETHan|
                   INRange| OORange
                   *RST:   EQUa|
```

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 768

TRIGger:SBSW:RFFE:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:RFFE:FIENable? <Enabler>

TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:ENABle <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<code><fr></code>	Index of the frame

<code><f ></code>	Index of the field

Parameters:

<CondEnabler> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 768

TRIGger:SBSW:RFFE:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:RFFE:IMAX? <Data>

TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:IMAX <Index Max>

Sets the end value of an index range for the software trigger if the operator is set to `INRange`.

You can set the operator with `TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:IOperator`.

Suffix:

<code><fr></code>	Index of the frame

<code><f ></code>	Index of the field

Parameters:

```
<Index_Max>      Range:    1 to 65535
                  Increment: 1
                  *RST:     65535
```

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 768

TRIGger:SBSW:RFFE:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:RFFE:IMIN? <Data>

TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 768

TRIGger:SBSW:RFFE:IOperator <Frame>,<Field>,<Operator>

TRIGger:SBSW:RFFE:IOperator? <Operator>

TRIGger:SBSW:RFFE:FRAME<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 768

TRIGger:SBSW:RFFE:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:RFFE:ERENable? <Enabler>

TRIGger:SBSW:RFFE:ERROR<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> Index of the error

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 769

SBUS<sb>:RFFE:SWTIndex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:RFFE:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

18.18.17.4 Decode results

SBUS<sb>:RFFE:FRAME<fr>:PADone?	1719
SBUS<sb>:RFFE:FRAME<fr>:PADZero?	1719
SBUS<sb>:RFFE:FRAME<fr>:PCTRI?	1719
SBUS<sb>:RFFE:FCOunt?	1720
SBUS<sb>:RFFE:FRAME<fr>:ADDRess?	1720
SBUS<sb>:RFFE:FRAME<fr>:BCOunt?	1720
SBUS<sb>:RFFE:FRAME<fr>:DATA?	1720
SBUS<sb>:RFFE:FRAME<fr>:FLDCount?	1721
SBUS<sb>:RFFE:FRAME<fr>:FLD<fl>:FVALue?	1721
SBUS<sb>:RFFE:FRAME<fr>:FLD<fl>:NAME?	1721
SBUS<sb>:RFFE:FRAME<fr>:FLD<fl>:STATe?	1722
SBUS<sb>:RFFE:FRAME<fr>:FLD<fl>:VALue?	1722
SBUS<sb>:RFFE:FRAME<fr>:RBTRate?	1722
SBUS<sb>:RFFE:FRAME<fr>:SADD?	1723
SBUS<sb>:RFFE:FRAME<fr>:START?	1723
SBUS<sb>:RFFE:FRAME<fr>:STATe?	1723

SBUS<sb>:RFFE:FRAME<fr>:STOP?	1724
SBUS<sb>:RFFE:FRAME<fr>:TYPE?	1724
SBUS<sb>:RFFE:FRAME<fr>:WBTRate?	1725
SBUS<sb>:RFFE:NEWList	1725
SBUS<sb>:RFFE:FRAME<fr>:SYMBOL?	1726
SBUS<sb>:RFFE:SYMBOLs	1726

SBUS<sb>:RFFE:FRAME<fr>:PADone?

Returns the parity address one of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<ParityAddr1> OK | NORESPONSE | BPERR | PARity | LENGth | VERSion |
SSC | GAP | INComplete
*RST: OK

Usage:

Query only
Asynchronous command

SBUS<sb>:RFFE:FRAME<fr>:PADZero?

Returns the parity address zero of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<ParityAddr0> OK | NORESPONSE | BPERR | PARity | LENGth | VERSion |
SSC | GAP | INComplete
*RST: OK

Usage:

Query only
Asynchronous command

SBUS<sb>:RFFE:FRAME<fr>:PCTRI?

Returns the parity control of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<ParityCtrl> OK | NORESPONSE | BPERR | PARity | LENGth | VERSion |
SSC | GAP | INComplete
*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:RFFE:FCOut?

Returns the number of decoded frames in the current acquisition.

Suffix:
<sb> 1 to 4, index of the serial bus

Return values:
<Count>

Usage: Query only
Asynchronous command

SBUS<sb>:RFFE:FRAMe<fr>:ADDRess?

Returns the register address of the selected frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:
<Address> Range: 0 to 65535
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:RFFE:FRAMe<fr>:BCOut?

Returns the byte count of the selected frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:
<BC> Range: 0 to 256
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:RFFE:FRAMe<fr>:DATA?

Returns the data value of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Data>

Usage: Query only

SBUS<sb>:RFFE:FRAMe<fr>:FLDCount?

Returns the field count of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Count>

Usage: Query only
Asynchronous command

SBUS<sb>:RFFE:FRAMe<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<FormattedValue>

Usage: Query only
Asynchronous command

SBUS<sb>:RFFE:FRAMe<fr>:FLD<fl>:NAME?

Returns the name (label) of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Label>

Usage: Query only
Asynchronous command

SBUS<sb>:RFFE:FRAMe<fr>:FLD<fl>:STATe?

Returns the overall state of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<State> OK | NORESPONSE | BPERR | PARity | LENGth | VERSion |
SSC | GAP | INComplete

*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:RFFE:FRAMe<fr>:FLD<fl>:VALue?

Returns the data value of the specified field in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Value> Increment: 1

*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:RFFE:FRAMe<fr>:RBTRate?

Returns the read bit rate of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<ReadBitRate> Increment: 1

*RST: 0

Default unit: bps

Usage: Query only

SBUS<sb>:RFFE:FRAME<fr>:SADD?

Returns the address of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<SA> Range: 0 to 15
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:RFFE:FRAME<fr>:START?

Returns the start time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Start> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:RFFE:FRAME<fr>:STATe?

Returns the overall state of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<State> OK | NORESPONSE | BPERR | PARity | LENGth | VERSion |
SSC | GAP | INComplete
*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:RFFE:FRAME<fr>:STOP?

Returns the stop time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<Stop> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

SBUS<sb>:RFFE:FRAME<fr>:TYPE?

Returns the type of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<Type> RZWR | RWR | ERWR | ERWL | MWR | MSKW | MCTW | RRD |
 ERRD | ERRL | MRD | MCTR | MOHO | IRSUM | UNDEF |
 UNKN | ERRor

RZWR

Register 0 write

RWR

Register write

RRD

Register read

ERWR

Extended register write

ERRD

Extended register read

ERWL

Extended register write long

ERRL

Extended register read long

MRD

Main device read

MWR

Main device write

MOHO

Main device Ownership Handove

IRSUM

Interrupt summary and notification

MSKW

Masked write

MCTR

Main device context transfer read

MCTW

Main device context transfer write

UNDEF

Undefined frame type

UNKN

Unknown frame type

ERRor

The bits defining the command sequence are not valid, no supported command sequence

*RST: RZWR

Usage:

Query only

Asynchronous command

SBUS<sb>:RFFE:FRAMe<fr>:WBTRate?

Returns the write bit rate of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<PrimaryBitRate> Increment: 1
 *RST: 0
 Default unit: bps

Usage:

Query only

SBUS<sb>:RFFE:NEWList <FileName>

Loads a symbol list file.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName>

Usage:

Setting only

Asynchronous command

SBUS<sb>:RFFE:FRAMe<fr>:SYMBol?

Returns the symbolic label of the specified sequence if the label list is enabled.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<SymbolicName> String with symbolic name of the frame

Usage:

Query only
 Asynchronous command

SBUS<sb>:RFFE:SYMBols <ShowSymbols>

Activates the symbol list to be used for decoding.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ShowSymbols> OFF | ON
 *RST: OFF

Usage:

Asynchronous command

18.18.18 10BASE-T1S (option R&S MXO5C-K560)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with `SBUS<sb>[:STATe]`.
- The bus is set to the correct type with `SBUS<sb>:TYPE`.

• Configuration.....	1726
• Filter.....	1729
• Software trigger.....	1734
• Decode results.....	1740

18.18.18.1 Configuration

SBUS<sb>:TNOS:POSition.....	1727
SBUS<sb>:TNOS:SCALe.....	1727
SBUS<sb>:TNOS:SOURce.....	1727
SBUS<sb>:TNOS:SYMBols.....	1727
SBUS<sb>:TNOS:THReshold:LOWer.....	1728
SBUS<sb>:TNOS:THReshold:HYSteresis.....	1728
SBUS<sb>:TNOS:THReshold:UPPer.....	1728
SBUS<sb>:TNOS:NEWList.....	1728

SBUS<sb>:TNOS:POSition <TENBTO position>

Sets the vertical position of the 10BASE-T1S signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<TENBTO position>

Usage:

Asynchronous command

SBUS<sb>:TNOS:SCALE <TENBTO scale>

Set the vertical scale of the indicated 10BASE-T1S signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<TENBTO scale>

Usage:

Asynchronous command

SBUS<sb>:TNOS:SOURce <Source>

Selects the source channel for the 10BASE-T1S protocol. Only analog channels can be used.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Source> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | M1 | M2 | M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage:

Asynchronous command

Manual operation: See ["Source"](#) on page 777

SBUS<sb>:TNOS:SYMBols <ShowSymbols>

Activates the symbol list to be used for decoding.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ShowSymbols> OFF | ON
*RST: OFF

Usage:

Asynchronous command

SBUS<sb>:TNOS:THReshold:LOWer <Lower Thres>

Sets a lower threshold.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Lower Thres>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 778

SBUS<sb>:TNOS:THReshold:HYSTeresis <Hysteresis>

Sets a value for the hysteresis.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 778

SBUS<sb>:TNOS:THReshold:UPPer <Upper Thres>

Sets an upper threshold.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Upper Thres>

Usage: Asynchronous command

Manual operation: See ["Threshold"](#) on page 778

SBUS<sb>:TNOS:NEWList <FileName>

Loads a symbol list file.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName> String parameter with path and file name.

Example:

```
SBUS1:TNOS:NEWList
'/home/storage/userData/Protocol/TNOS.csv'
SBUS1:TNOS:SYMBOLs ON
```

Usage: Setting only
Asynchronous command

18.18.18.2 Filter

There are two commands for each parameter, that you can use for defining the 10BASE-T1S settings.

For example, to set the *Frame type =MAC > Field =Data >00* value you can use one of the following commands:

- `SBUS:TNOS:FILTer:FRAMe1:FLD1:DMIN 00`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `SBUS:TNOS:FILTer:DMIN "MAC", "Data", 00`
Defines the parameter by using the frame and field name.

<code>SBUS<sb>:TNOS:FILTer:CHKall</code>	1729
<code>SBUS<sb>:TNOS:FILTer:CLR</code>	1730
<code>SBUS<sb>:TNOS:FILTer:RST</code>	1730
<code>SBUS<sb>:TNOS:FILTer:INVert</code>	1730
<code>SBUS<sb>:TNOS:FILTer:BIT</code>	1730
<code>SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:BIT</code>	1730
<code>SBUS<sb>:TNOS:FILTer:DMAX</code>	1731
<code>SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:DMAX</code>	1731
<code>SBUS<sb>:TNOS:FILTer:DMIN</code>	1731
<code>SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:DMIN</code>	1731
<code>SBUS<sb>:TNOS:FILTer:DOPerator</code>	1732
<code>SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:DOPerator</code>	1732
<code>SBUS<sb>:TNOS:FILTer:ERENable</code>	1732
<code>SBUS<sb>:TNOS:FILTer:ERRor<n>:ENABLE</code>	1732
<code>SBUS<sb>:TNOS:FILTer:FIENable</code>	1732
<code>SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:ENABLE</code>	1732
<code>SBUS<sb>:TNOS:FILTer:IMAX</code>	1733
<code>SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:IMAX</code>	1733
<code>SBUS<sb>:TNOS:FILTer:IMIN</code>	1733
<code>SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:IMIN</code>	1733
<code>SBUS<sb>:TNOS:FILTer:IOPerator</code>	1734
<code>SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:IOPerator</code>	1734
<code>SBUS<sb>:TNOS:FILTer:FRENable</code>	1734
<code>SBUS<sb>:TNOS:FILTer:FRAMe<fr>:ENABLE</code>	1734

SBUS<sb>:TNOS:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:
<sb> 1 to 4, index of the serial bus

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 781

SBUS<sb>:TNOS:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 781

SBUS<sb>:TNOS:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 781

SBUS<sb>:TNOS:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 781

SBUS<sb>:TNOS:FILTer:BIT <Frame>,<Field>,<Bit>

SBUS<sb>:TNOS:FILTer:BIT? <Bit>

SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO
 *RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 782

SBUS<sb>:TNOS:FILTer:DMAX <Frame>,<Field>,<Data>

SBUS<sb>:TNOS:FILTer:DMAX? <Data>

SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range if the operator is set to INRange or OORANGe.

You can set the operator with [SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:DOPerator](#).

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 782

SBUS<sb>:TNOS:FILTer:DMIN <Frame>,<Field>,<Data>

SBUS<sb>:TNOS:FILTer:DMIN? <Data>

SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 782

SBUS<sb>:TNOS:FILTer:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:TNOS:FILTer:DOPerator? <Operator>

SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan |
INRange | OORange

*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 782

SBUS<sb>:TNOS:FILTer:ERENable <ErrorName>,<Enabler>

SBUS<sb>:TNOS:FILTer:ERENable? <Enabler>

SBUS<sb>:TNOS:FILTer:ERRor<n>:ENABLe <Enable>

rcset

Suffix:

<sb> 1..4

<n> *

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 783

SBUS<sb>:TNOS:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:TNOS:FILTer:FIENable? <Enabler>

SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:ENABLe <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 782

SBUS<sb>:TNOS:FILTer:IMAX <Frame>,<Field>,<Data>

SBUS<sb>:TNOS:FILTer:IMAX? <Data>

SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range if the operator is set to INRange.

You can set the operator with [SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:IOperator](#).

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 782

SBUS<sb>:TNOS:FILTer:IMIN <Frame>,<Field>,<Data>

SBUS<sb>:TNOS:FILTer:IMIN? <Data>

SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 782

SBUS<sb>:TNOS:FILTer:IOPerator <Frame>,<Field>,<Operator>
SBUS<sb>:TNOS:FILTer:IOPerator? <Operator>
SBUS<sb>:TNOS:FILTer:FRAMe<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGe

*RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 782

SBUS<sb>:TNOS:FILTer:FRENAble <Frame>,<Enabler>

SBUS<sb>:TNOS:FILTer:FRENAble? <Enabler>

SBUS<sb>:TNOS:FILTer:FRAMe<fr>:ENABLe <Enable>

Enables the filtering on 10Base-T1S frames. Only the frames that match the selected filter conditions are displayed.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 782

18.18.18.3 Software trigger

There are two commands for each parameter, that you can use for defining the 10BASE-T1S settings.

For example, to set the *Frame type =MAC > Field =Data >00* value you can use one of the following commands:

- `TRIGger:SBSW:TNOS:FRAMe1:FLD1:DMIN 00`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `TRIGger:SBSW:TNOS:DMIN "MAC", "Data", 00`
Defines the parameter by using the frame and field name.

TRIGger:SBSW:TNOS:CHKall.....	1735
TRIGger:SBSW:TNOS:CLR.....	1735
TRIGger:SBSW:TNOS:INVert.....	1735
TRIGger:SBSW:TNOS:RST.....	1736
TRIGger:SBSW:TNOS:FRENable.....	1736
TRIGger:SBSW:TNOS:FRAME<fr>:ENABLE.....	1736
TRIGger:SBSW:TNOS:BIT.....	1736
TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:BIT.....	1736
TRIGger:SBSW:TNOS:DMAX.....	1737
TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:DMAX.....	1737
TRIGger:SBSW:TNOS:DMIN.....	1737
TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:DMIN.....	1737
TRIGger:SBSW:TNOS:DOPerator.....	1737
TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:DOPerator.....	1737
TRIGger:SBSW:TNOS:FIENable.....	1738
TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:ENABLE.....	1738
TRIGger:SBSW:TNOS:IMAX.....	1738
TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:IMAX.....	1738
TRIGger:SBSW:TNOS:IMIN.....	1739
TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:IMIN.....	1739
TRIGger:SBSW:TNOS:IOPerator.....	1739
TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:IOPerator.....	1739
TRIGger:SBSW:TNOS:ERENable.....	1739
TRIGger:SBSW:TNOS:ERRor<m>:ENABLE.....	1739
SBUS<sb>:TNOS:SWTIndex?.....	1740
SBUS<sb>:TNOS:SWTTime?.....	1740

TRIGger:SBSW:TNOS:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 784

TRIGger:SBSW:TNOS:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 784

TRIGger:SBSW:TNOS:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 784

TRIGger:SBSW:TNOS:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 784

TRIGger:SBSW:TNOS:FREnable <Frame>,<Enabler>

TRIGger:SBSW:TNOS:FREnable? <Enabler>

TRIGger:SBSW:TNOS:FRAMe<fr>:ENABLe <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:
<fr> Index of the frame

Parameters:
<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 785

TRIGger:SBSW:TNOS:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:TNOS:BIT? <Bit>

TRIGger:SBSW:TNOS:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:
<fr> Index of the frame

<fl> Index of the field

Parameters:
<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 785

TRIGger:SBSW:TNOS:DMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:TNOS:DMAX? <Data>

TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGE.

You can set the operator with [TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:DOPerator](#) on page 1737.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 785

TRIGger:SBSW:TNOS:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:TNOS:DMIN? <Data>

TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 785

TRIGger:SBSW:TNOS:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:TNOS:DOPerator? <Operator>

TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUAL | NEQUAL | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUAL

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 785

TRIGger:SBSW:TNOS:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:TNOS:FIENable? <Enabler>

TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 785

TRIGger:SBSW:TNOS:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:TNOS:IMAX? <Data>

TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with [TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:IOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 785

TRIGger:SBSW:TNOS:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:TNOS:IMIN? <Data>

TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 785

TRIGger:SBSW:TNOS:IOperator <Frame>,<Field>,<Operator>

TRIGger:SBSW:TNOS:IOperator? <Operator>

TRIGger:SBSW:TNOS:FRAME<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 785

TRIGger:SBSW:TNOS:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:TNOS:ERENable? <Enabler>

TRIGger:SBSW:TNOS:ERRor<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> Index of the error

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 786

SBUS<sb>:TNOS:SWTIndex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:TNOS:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

18.18.18.4 Decode results

SBUS<sb>:TNOS:FCOUNT?	1741
SBUS<sb>:TNOS:FRAME<fr>:FLDCOUNT?	1741
SBUS<sb>:TNOS:FRAME<fr>:BITRATE?	1741
SBUS<sb>:TNOS:FRAME<fr>:FLD<fl>:FVALUE?	1742
SBUS<sb>:TNOS:FRAME<fr>:FLD<fl>:LABEL?	1742
SBUS<sb>:TNOS:FRAME<fr>:FLD<fl>:STATE?	1742
SBUS<sb>:TNOS:FRAME<fr>:FLD<fl>:VALUE?	1743
SBUS<sb>:TNOS:FRAME<fr>:CRC?	1743
SBUS<sb>:TNOS:FRAME<fr>:DATA?	1744
SBUS<sb>:TNOS:FRAME<fr>:DTADDRESS?	1744
SBUS<sb>:TNOS:FRAME<fr>:DTSYMBOL?	1744
SBUS<sb>:TNOS:FRAME<fr>:FCRC?	1744
SBUS<sb>:TNOS:FRAME<fr>:FDATA?	1745
SBUS<sb>:TNOS:FRAME<fr>:FDADDRESS?	1745
SBUS<sb>:TNOS:FRAME<fr>:FSRADDRESS?	1745
SBUS<sb>:TNOS:FRAME<fr>:FTPLENTH?	1745

SBUS<sb>:TNOS:FRAME<fr>:SRADdress?	1746
SBUS<sb>:TNOS:FRAME<fr>:SRSYmbol?	1746
SBUS<sb>:TNOS:FRAME<fr>:STARt?	1746
SBUS<sb>:TNOS:FRAME<fr>:STATus?	1747
SBUS<sb>:TNOS:FRAME<fr>:STOP?	1747
SBUS<sb>:TNOS:FRAME<fr>:TPLenth?	1748
SBUS<sb>:TNOS:FRAME<fr>:TYPE?	1748

SBUS<sb>:TNOS:FCOunt?

Returns the number of decoded frames.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count> Total number of decoded frames.

Usage:

Query only
Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:FLDCount?

Returns the number of fields in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Count> Total number of fields.

Usage:

Query only
Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:BITRate?

Returns the primary bit rate.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<PrimaryBitRate> Increment: 1
*RST: 0
Default unit: bps

Usage:

Query only
Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified field.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Return values:

<FormattedValue>

Usage:

Query only
Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:FLD<fl>:LABel?

Returns the label of the specified field.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Return values:

<Label>

Usage:

Query only
Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:FLD<fl>:STATe?

Returns the state of the specified field.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Return values:

<State> OK | EPRMble | ESFD | EESD | ECRC | ELEN | INComplete

OK

The field has no error, it is valid.

EPRMble

Preamble error, the hex value of the preamble field is different from 0x5555555555555555 (56 alternating 0's and 1's).

ESFD

SFD error, the hex value of the SFD field is different from 0xD5

EESD

ESD error, the value of the ESD field does not correspond to the symbol pair "ESD, ESDOK"

ECRC

CRC error, the value of the FCS field does not match the calculated CRC.

ELEN

Length error, the number of bits in the specified field is higher or lower than expected.

INComplete

The frame is incomplete

*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:TNOS:FRAMe<fr>:FLD<fl>:VALue?

Returns the value of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Value> Increment: 1

*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:TNOS:FRAMe<fr>:CRC?

Returns the CRC for the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<CRC> Range: 0 to 4294967295

Increment: 1

*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:DATA?

Returns the data for the specified frame in comma-separated values.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Count>

<Values>

Usage:

Query only
Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:DTAddress?

Returns the destination address for the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<DestAddress> Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:DTSymbol?

Returns the destination symbol for the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<DestSymbNme>

Usage:

Query only
Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:FCRC?

Returns the formatted CRC for the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FormattedCRC>

Usage:

Query only

Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:FDATa?

Returns the formatted data for the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FormattedData>

Usage:

Query only

Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:FDTaddress?

Returns the formatted destination address of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FormattedDestAddr>

Usage:

Query only

Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:FSRaddress?

Returns the formatted SRC address for the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FormattedSrcAddr>

Usage:

Query only

Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:FTPLenth?

Returns the formatted type length for the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FormattedTypLenth>

Usage:

Query only

Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:SRADdress?

Returns the source address for the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<SourceAddress> Increment: 1
*RST: 0

Usage:

Query only

Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:SRSymbol?

Returns the frame of the source symbol.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<SrcSymbNme>

Usage:

Query only

Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:START?

Returns the start time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStart> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:STATus?

Returns the state of the frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<FrameState> OK | EPRMble | ESFD | EESD | ECRC | ELEN | INComplete

OK

The frame has no error, it is valid.

EPRMble

Preamble error, the hex value of the preamble field is different from 0x5555555555555555 (56 alternating 0's and 1's).

ESFD

SFD error, the hex value of the SFD field is different from 0xD5

EESD

ESD error, the value of the ESD field does not correspond to the symbol pair "ESD, ESDOK"

ECRC

CRC error, the value of the FCS field does not match the calculated CRC.

ELEN

Length error, the number of bits in the specified frame is higher or lower than expected.

INComplete

The frame is incomplete

*RST: OK

Usage:

Query only
 Asynchronous command

SBUS<sb>:TNOS:FRAME<fr>:STOP?

Returns the stop time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:TNOS:FRAMe<fr>:TPLenH?

Returns the type length for the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<TypeLenth> Range: 0 to 65535
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:TNOS:FRAMe<fr>:TYPE?

Returns the type of the frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameType> MAC | COMMit | BEACon | UNKN
*RST: MAC

Usage: Query only
Asynchronous command

18.18.19 100BASE-T1 (option R&S MXO5C-K560)

• Configuration	1749
• Filter	1751
• Software trigger	1756
• Decode results	1762

18.18.19.1 Configuration

SBUS<sb>:HBTO:MODE.....	1749
SBUS<sb>:HBTO:POLarity.....	1749
SBUS<sb>:HBTO:POSition.....	1749
SBUS<sb>:HBTO:SCALe.....	1750
SBUS<sb>:HBTO:SOURce.....	1750
SBUS<sb>:HBTO:SYMBols.....	1750
SBUS<sb>:HBTO:NEWList.....	1750

SBUS<sb>:HBTO:MODE <Mode>

Selects the operation mode.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Mode> MAIN | SUB | AUTO
*RST: AUTO

Usage: Asynchronous command

Manual operation: See ["Operation mode"](#) on page 792

SBUS<sb>:HBTO:POLarity <Polarity>

Selects the polarity of the data signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Polarity> NORMal | INVerted
*RST: NORMal

Usage: Asynchronous command

Manual operation: See ["Polarity"](#) on page 792

SBUS<sb>:HBTO:POSition <HBTO position>

Sets the vertical position of the 100BASE-T1 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<HBTO position>

Usage: Asynchronous command

SBUS<sb>:HBTO:SCALE <HBTO scale>

Set the vertical scale of the indicated 100BASE-T1 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<HBTO scale>

Usage:

Asynchronous command

SBUS<sb>:HBTO:SOURce Source

Selects the source channel.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

Source C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | M1 | M2 | M3 | M4 | M5 |
M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | R8 | O<n>C1 |
O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage:

Asynchronous command

Manual operation: See ["Source"](#) on page 792

SBUS<sb>:HBTO:SYMBOLs <ShowSymbols>

Activates the symbol list to be used for decoding.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ShowSymbols> OFF | ON
*RST: OFF

Usage:

Asynchronous command

Manual operation: See ["Show symbols"](#) on page 794

SBUS<sb>:HBTO:NEWList <FileName>

Loads a symbol list file.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName>

Example: `SBUS1:HBTO:NEWList`
`'/home/storage/userData/Protocol/HBTO.csv'`
`SBUS1:HBTO:SYMBOLS ON`

Usage: Setting only
Asynchronous command

Manual operation: See ["Show symbols"](#) on page 794

18.18.19.2 Filter

There are two commands for each parameter, that you can use for defining the 100BASE-T1 settings.

For example, to set the *Frame type =MAC > Field =Data >00* value you can use one of the following commands:

- `SBUS:HBTO:FILTer:FRAMe1:FLD1:DMIN 00`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `SBUS:HBTO:FILTer:DMIN "MAC", "Data", 00`
Defines the parameter by using the frame and field name.

<code>SBUS<sb>:HBTO:FILTer:CHKall</code>	1751
<code>SBUS<sb>:HBTO:FILTer:CLR</code>	1752
<code>SBUS<sb>:HBTO:FILTer:INVert</code>	1752
<code>SBUS<sb>:HBTO:FILTer:RST</code>	1752
<code>SBUS<sb>:HBTO:FILTer:BIT</code>	1752
<code>SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:BIT</code>	1752
<code>SBUS<sb>:HBTO:FILTer:DMAX</code>	1753
<code>SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:DMAX</code>	1753
<code>SBUS<sb>:HBTO:FILTer:DMIN</code>	1753
<code>SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:DMIN</code>	1753
<code>SBUS<sb>:HBTO:FILTer:DOPerator</code>	1753
<code>SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:DOPerator</code>	1753
<code>SBUS<sb>:HBTO:FILTer:ERENable</code>	1754
<code>SBUS<sb>:HBTO:FILTer:ERRor<n>:ENABle</code>	1754
<code>SBUS<sb>:HBTO:FILTer:FIENable</code>	1754
<code>SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:ENABle</code>	1754
<code>SBUS<sb>:HBTO:FILTer:FRENable</code>	1754
<code>SBUS<sb>:HBTO:FILTer:FRAMe<fr>:ENABle</code>	1754
<code>SBUS<sb>:HBTO:FILTer:IMAX</code>	1755
<code>SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:IMAX</code>	1755
<code>SBUS<sb>:HBTO:FILTer:IMIN</code>	1755
<code>SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:IMIN</code>	1755
<code>SBUS<sb>:HBTO:FILTer:IOPerator</code>	1756
<code>SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:IOPerator</code>	1756

SBUS<sb>:HBTO:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:
 <sb> 1 to 4, index of the serial bus

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 795

SBUS<sb>:HBTO:FILTER:CLR

Disables the filter for all available frames and error types.

Suffix:
 <sb> 1 to 4, index of the serial bus

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 795

SBUS<sb>:HBTO:FILTER:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:
 <sb> 1 to 4, index of the serial bus

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 795

SBUS<sb>:HBTO:FILTER:RST

Presets the state of the selected frames and error types.

Suffix:
 <sb> 1 to 4, index of the serial bus

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 795

SBUS<sb>:HBTO:FILTER:BIT <Frame>,<Field>,<Bit>

SBUS<sb>:HBTO:FILTER:BIT? <Bit>

SBUS<sb>:HBTO:FILTER:FRAME<fr>:FLD<fl>:BIT <BitState>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

SBUS<sb>:HBTO:FILTer:DMAX <Frame>,<Field>,<Data>

SBUS<sb>:HBTO:FILTer:DMAX? <Data>

SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range if the operator is set to `INRange` or `OORANGe`.

You can set the operator with `SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:DOPerator`.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

SBUS<sb>:HBTO:FILTer:DMIN <Frame>,<Field>,<Data>

SBUS<sb>:HBTO:FILTer:DMIN? <Data>

SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

SBUS<sb>:HBTO:FILTer:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:HBTO:FILTer:DOPerator? <Operator>

SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan |
INRange | OORange
*RST: EQUal

Usage: Asynchronous command

SBUS<sb>:HBTO:FILTer:ERENable <ErrorName>,<Enabler>

SBUS<sb>:HBTO:FILTer:ERENable? <Enabler>

SBUS<sb>:HBTO:FILTer:ERRor<n>:ENABle <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> index of the error

Parameters:

<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

SBUS<sb>:HBTO:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:HBTO:FILTer:FIENable? <Enabler>

SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:ENABle <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
*RST: OFF

Usage: Asynchronous command

SBUS<sb>:HBTO:FILTer:FRENable <Frame>,<Enabler>

SBUS<sb>:HBTO:FILTer:FRENable? <Enabler>

SBUS<sb>:HBTO:FILTer:FRAMe<fr>:ENABle <Enable>

Enables the filtering on 100BASE-T1 frames. Only the frames that match the selected filter conditions are displayed.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Parameters:****<Enable>** OFF | ON***RST:** ON**Usage:**

Asynchronous command

SBUS<sb>:HBTO:FILTer:IMAX <Frame>,<Field>,<Data>**SBUS<sb>:HBTO:FILTer:IMAX?** <Data>**SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:IMAX** <Index_Max>Sets the end value of an index range if the operator is set to *INRange*.You can set the operator with [SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:IOperator](#).**Suffix:****<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<Index_Max>** Range: 1 to 65535

Increment: 1

***RST:** 65535**Usage:**

Asynchronous command

SBUS<sb>:HBTO:FILTer:IMIN <Frame>,<Field>,<Data>**SBUS<sb>:HBTO:FILTer:IMIN?** <Data>**SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:IMIN** <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<Index_Min>** Range: 1 to 65535

Increment: 1

***RST:** 1**Usage:**

Asynchronous command

SBUS<sb>:HBTO:FILTer:IOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:HBTO:FILTer:IOPerator? <Operator>

SBUS<sb>:HBTO:FILTer:FRAMe<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGe

*RST: INRange

Usage: Asynchronous command

18.18.19.3 Software trigger

There are two commands for each parameter, that you can use for defining the 100BASE-T1 settings.

For example, to set the *Frame type =MAC > Field =Data >00* value you can use one of the following commands:

- TRIGger:SBSW:HBTO:FRAMe1:FLD1:DMIN 00
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- TRIGger:SBSW:HBTO:DMIN "MAC", "Data", 00
Defines the parameter by using the frame and field name.

TRIGger:SBSW:HBTO:CHKall.....	1757
TRIGger:SBSW:HBTO:CLR.....	1757
TRIGger:SBSW:HBTO:INVert.....	1757
TRIGger:SBSW:HBTO:RST.....	1757
TRIGger:SBSW:HBTO:FRENable.....	1757
TRIGger:SBSW:HBTO:FRAMe<fr>:ENABLE.....	1757
TRIGger:SBSW:HBTO:BIT.....	1758
TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:BIT.....	1758
TRIGger:SBSW:HBTO:DMAX.....	1758
TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:DMAX.....	1758
TRIGger:SBSW:HBTO:DMIN.....	1758
TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:DMIN.....	1758
TRIGger:SBSW:HBTO:DOPerator.....	1759
TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:DOPerator.....	1759
TRIGger:SBSW:HBTO:FIENable.....	1759
TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:ENABLE.....	1759
TRIGger:SBSW:HBTO:IMAX.....	1760
TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:IMAX.....	1760
TRIGger:SBSW:HBTO:IMIN.....	1760
TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:IMIN.....	1760

TRIGger:SBSW:HBTO:IOperator.....	1760
TRIGger:SBSW:HBTO:FRAME<fr>:FLD<fl>:IOperator.....	1760
TRIGger:SBSW:HBTO:ERENable.....	1761
TRIGger:SBSW:HBTO:ERRor<m>:ENABLE.....	1761
SBUS<sb>:HBTO:SWTindex?.....	1761
SBUS<sb>:HBTO:SWTTime?.....	1761

TRIGger:SBSW:HBTO:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 797

TRIGger:SBSW:HBTO:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 797

TRIGger:SBSW:HBTO:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 797

TRIGger:SBSW:HBTO:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 797

TRIGger:SBSW:HBTO:FRENable <Frame>,<Enabler>

TRIGger:SBSW:HBTO:FRENable? <Enabler>

TRIGger:SBSW:HBTO:FRAME<fr>:ENABLE <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:
 <fr> Index of the frame

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 797

TRIGger:SBSW:HBTO:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:HBTO:BIT? <Bit>

TRIGger:SBSW:HBTO:FRAME<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO
 *RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 798

TRIGger:SBSW:HBTO:DMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:HBTO:DMAX? <Data>

TRIGger:SBSW:HBTO:FRAME<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGE.

You can set the operator with [TRIGger:SBSW:HBTO:FRAME<fr>:FLD<fl>:DOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 798

TRIGger:SBSW:HBTO:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:HBTO:DMIN? <Data>

TRIGger:SBSW:HBTO:FRAME<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 798**TRIGger:SBSW:HBTO:DOPerator** <Frame>,<Field>,<Operator>**TRIGger:SBSW:HBTO:DOPerator?** <Operator>**TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:DOPerator** <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan |
INRange | OORange
*RST: EQUal

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 798**TRIGger:SBSW:HBTO:FIENable** <Frame>,<Field>,<Enabler>**TRIGger:SBSW:HBTO:FIENable?** <Enabler>**TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:ENABLE** <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
*RST: OFF

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 798

TRIGger:SBSW:HBTO:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:HBTO:IMAX? <Data>

TRIGger:SBSW:HBTO:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with **TRIGger:SBSW:HBTO:FRAME<fr>:FLD<fl>:IOperator**.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 798

TRIGger:SBSW:HBTO:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:HBTO:IMIN? <Data>

TRIGger:SBSW:HBTO:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 798

TRIGger:SBSW:HBTO:IOperator <Frame>,<Field>,<Operator>

TRIGger:SBSW:HBTO:IOperator? <Operator>

TRIGger:SBSW:HBTO:FRAME<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUAL | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 798

TRIGger:SBSW:HBT0:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:HBT0:ERENable? <Enabler>

TRIGger:SBSW:HBT0:ERRor<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> Index of the error

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 799

SBUS<sb>:HBT0:SWTIndex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295
 Increment: 1
 *RST: 0

Usage: Query only
 Asynchronous command

SBUS<sb>:HBT0:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

18.18.19.4 Decode results

SBUS<sb>:HBTO:FCOUNT?	1762
SBUS<sb>:HBTO:FRAME<fr>:FLDCOUNT?	1762
SBUS<sb>:HBTO:FRAME<fr>:BITRATE?	1763
SBUS<sb>:HBTO:FRAME<fr>:FLD<fl>:FVALUE?	1763
SBUS<sb>:HBTO:FRAME<fr>:FLD<fl>:LABEL?	1763
SBUS<sb>:HBTO:FRAME<fr>:FLD<fl>:STATE?	1764
SBUS<sb>:HBTO:FRAME<fr>:FLD<fl>:VALUE?	1764
SBUS<sb>:HBTO:FRAME<fr>:CRC?	1765
SBUS<sb>:HBTO:FRAME<fr>:DATA?	1765
SBUS<sb>:HBTO:FRAME<fr>:DTADDRESS?	1765
SBUS<sb>:HBTO:FRAME<fr>:DTSYMBOL?	1766
SBUS<sb>:HBTO:FRAME<fr>:FCRC?	1766
SBUS<sb>:HBTO:FRAME<fr>:FDATA?	1766
SBUS<sb>:HBTO:FRAME<fr>:FDADDRESS?	1766
SBUS<sb>:HBTO:FRAME<fr>:FSRADDRESS?	1767
SBUS<sb>:HBTO:FRAME<fr>:FTPLENTH?	1767
SBUS<sb>:HBTO:FRAME<fr>:SRADDRESS?	1767
SBUS<sb>:HBTO:FRAME<fr>:SRSYMBOL?	1768
SBUS<sb>:HBTO:FRAME<fr>:START?	1768
SBUS<sb>:HBTO:FRAME<fr>:STATUS?	1768
SBUS<sb>:HBTO:FRAME<fr>:STOP?	1769
SBUS<sb>:HBTO:FRAME<fr>:TPLENTH?	1769
SBUS<sb>:HBTO:FRAME<fr>:TYPE?	1769

SBUS<sb>:HBTO:FCOUNT?

Returns the number of decoded frames.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count> Total number of decoded frames.

Usage:

Query only
 Asynchronous command

SBUS<sb>:HBTO:FRAME<fr>:FLDCOUNT?

Returns the number of fields in the specified frame.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Return values:****<Count>** Total number of fields.**Usage:**

Query only

Asynchronous command

SBUS<sb>:HBTO:FRAMe<fr>:BITRate?

Returns the primary bit rate.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Return values:****<PrimaryBitRate>** Increment: 1
*RST: 0
Default unit: bps**Usage:**

Query only

Asynchronous command

SBUS<sb>:HBTO:FRAMe<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified field.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Return values:****<FormattedValue>****Usage:**

Query only

Asynchronous command

SBUS<sb>:HBTO:FRAMe<fr>:FLD<fl>:LABel?

Returns the label of the fields in the specified frame.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field

Return values:

<Label>

Usage:

Query only
Asynchronous command

SBUS<sb>:HBTO:FRAME<fr>:FLD<fl>:STATe?

Returns the state of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<fl> Index of the field

Return values:

<State> OK | EPRMble | ESFD | ELENgth | ECRC | UNCorrelated | INComplete

OK

The field is valid.

EPRMble

Preamble error

ESFD

Start frame delimiter (SFD) error

ELENgth

Erroneous field due to incorrect length

ECRC

Cyclic redundancy check (CRC) error, the value of the frame check sequence (FCS) field does not match the calculated checksum.

UNCorrelated

Uncorrelated field error

INComplete

Field not completely contained in the acquisition.

*RST: OK

Usage:

Query only
Asynchronous command

SBUS<sb>:HBTO:FRAME<fr>:FLD<fl>:VALue?

Returns the value of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<fl> Index of the field

Return values:

<Value> Increment: 1
 *RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:HBTO:FRAMe<fr>:CRC?

Returns the CRC (frame check) checksum of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<CRC> Range: 0 to 4294967295
 Increment: 1
 *RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:HBTO:FRAMe<fr>:DATA?

Returns the data for the selected frame in comma-separated values, corresponds to the "Data" column in the decode results table.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Count>

<Values>

Usage:

Query only
Asynchronous command

SBUS<sb>:HBTO:FRAMe<fr>:DTAddress?

Returns the destination address of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<DestAddress> Range: 0 to 281474976710655
 Increment: 1
 *RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:HBTO:FRAME<fr>:DTSymbol?

Returns the destination symbols of the selected frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:
<DestSymbNme>

Usage: Query only
Asynchronous command

SBUS<sb>:HBTO:FRAME<fr>:FCRC?

Returns the formatted CRC (frame check) checksum of the selected frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:
<FormattedCRC>

Usage: Query only
Asynchronous command

SBUS<sb>:HBTO:FRAME<fr>:FDATA?

Returns the formatted data for the selected frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:
<FormattedData>

Usage: Query only
Asynchronous command

SBUS<sb>:HBTO:FRAME<fr>:FDtAddress?

Returns the formatted destination address of the selected frame.

Suffix:
<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FormattedDestAddr>

Usage:

Query only
Asynchronous command

SBUS<sb>:HBTO:FRAME<fr>:FSRaddress?

Returns the formatted source address of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FormattedSrcAddr>

Usage:

Query only
Asynchronous command

SBUS<sb>:HBTO:FRAME<fr>:FTPLenth?

Returns the value of type /length field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FormattedTypLenth>

Usage:

Query only
Asynchronous command

SBUS<sb>:HBTO:FRAME<fr>:SRAddress?

Returns the source address of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<SourceAddress> Range: 0 to 281474976710655
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:HBTO:FRAMe<fr>:SRSYmbol?

Returns the source symbols of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<SrcSymbNme>

Usage:

Query only
Asynchronous command

SBUS<sb>:HBTO:FRAMe<fr>:START?

Returns the start time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStart> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

SBUS<sb>:HBTO:FRAMe<fr>:STATUs?

Returns the overall state of the frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameState> OK | EPRMble | ESFD | ELENgth | ECRC | UNCorrelated | INComplete

OK

Valid frame.

EPRMble

Erroneous frame due to preamble error.

ESFD

Erroneous frame due to SFD error.

ELENgth

Erroneous frame due to length / type error.

ECRC

Erroneous frame due to CRC error.

UNCorrelated

Uncorrelated frame

INComplete

Frame is incomplete

*RST: OK

Usage:

Query only

Asynchronous command

SBUS<sb>:HBTO:FRAME<fr>:STOP?

Returns the end time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26

Increment: 1E-10

*RST: 0

Default unit: s

Usage:

Query only

Asynchronous command

SBUS<sb>:HBTO:FRAME<fr>:TPLenth?

Returns the value of the type / length field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<TypeLenth> Range: 0 to 65535

Increment: 1

*RST: 0

Usage:

Query only

Asynchronous command

SBUS<sb>:HBTO:FRAME<fr>:TYPE?

Returns the type of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameType> IDLE | MAC | FILLer | UNKNown

IDLE

IDLE frame. This frame is used for clock synchronization.

MAC

MAC frame. This frame contains information that define how to go about transmitting and receiving frames.

FILLer

Filler frame. The frame is used to maintain transmission activity.

UNKNown

No meaningful frame can be determined.

*RST: MAC

Usage:

Query only

Asynchronous command

18.18.20 1000BASE-T1 (option R&S MXO5C-K560)

- [Configuration](#).....1770
- [Filter](#).....1772
- [Software trigger](#).....1778
- [Decode results](#).....1784

18.18.20.1 Configuration

SBUS<sb>:TBTO:MODE	1770
SBUS<sb>:TBTO:NEWList	1771
SBUS<sb>:TBTO:POLarity	1771
SBUS<sb>:TBTO:POSition	1771
SBUS<sb>:TBTO:SCALe	1771
SBUS<sb>:TBTO:SRCPlus	1772
SBUS<sb>:TBTO:SRCMinus	1772
SBUS<sb>:TBTO:SYMBols	1772

SBUS<sb>:TBTO:MODE <Mode>

Selects the operation mode for 1000BASE-T1.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Mode> MAIN | SUB | AUTO

*RST: AUTO

Usage:

Asynchronous command

Manual operation: See "[Operation mode](#)" on page 807

SBUS<sb>:TBTO:NEWList <FileName>

Loads a symbol list file.

Suffix:

<sb> 1 to 4, index of the serial bus

Setting parameters:

<FileName>

Example:

```
SBUS1:TBTO:NEWList
'/home/storage/userData/Protocol/TBTO.csv'
SBUS1:TBTO:SYMBOLs ON
```

Usage:

Setting only
Asynchronous command

Manual operation: See ["Show symbols"](#) on page 808

SBUS<sb>:TBTO:POLarity <Polarity>

Selects the polarity of the data signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Polarity> NORMal | INVerted
*RST: NORMal

Usage:

Asynchronous command

Manual operation: See ["Polarity"](#) on page 806

SBUS<sb>:TBTO:POSition <TBTO position>

Sets the vertical position of the 1000BASE-T1 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<TBTO position>

Usage:

Asynchronous command

SBUS<sb>:TBTO:SCALe <TBTO scale>

Set the vertical scale of the indicated 1000BASE-T1 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<TBTO scale>

Usage: Asynchronous command

SBUS<sb>:TBTO:SRCPlus <PLUSSource>

Selects the D+ data source channel for 1000BASE-T1.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<PLUSSource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | M1 | M2 | M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["Source plus"](#) on page 806

SBUS<sb>:TBTO:SRCMinus <MINUSSource>

Selects the D- data source channel for 1000BASE-T1.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<MINUSSource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | M1 | M2 | M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See ["Source minus"](#) on page 806

SBUS<sb>:TBTO:SYMBols <ShowSymbols>

Activates the symbol list to be used for decoding.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<ShowSymbols> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Show symbols"](#) on page 808

18.18.20.2 Filter

There are two commands for each parameter, that you can use for defining the 1000BASE-T1 settings.

For example, to set the *Frame type* =MAC > *Field* =Data >00 value you can use one of the following commands:

- `SBUS:TBTO:FILTer:FRAMe1:FLD1:DMIN 00`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `SBUS:TBTO:FILTer:DMIN "MAC", "Data", 00`
Defines the parameter by using the frame and field name.

<code>SBUS<sb>:TBTO:FILTer:CHKall</code>	1773
<code>SBUS<sb>:TBTO:FILTer:CLR</code>	1773
<code>SBUS<sb>:TBTO:FILTer:INVert</code>	1774
<code>SBUS<sb>:TBTO:FILTer:RST</code>	1774
<code>SBUS<sb>:TBTO:FILTer:BIT</code>	1774
<code>SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:BIT</code>	1774
<code>SBUS<sb>:TBTO:FILTer:DMAX</code>	1775
<code>SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:DMAX</code>	1775
<code>SBUS<sb>:TBTO:FILTer:DMIN</code>	1775
<code>SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:DMIN</code>	1775
<code>SBUS<sb>:TBTO:FILTer:DOPerator</code>	1775
<code>SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:DOPerator</code>	1775
<code>SBUS<sb>:TBTO:FILTer:ERENable</code>	1776
<code>SBUS<sb>:TBTO:FILTer:ERRor<n>:ENABLE</code>	1776
<code>SBUS<sb>:TBTO:FILTer:FIENable</code>	1776
<code>SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:ENABLE</code>	1776
<code>SBUS<sb>:TBTO:FILTer:FRENable</code>	1776
<code>SBUS<sb>:TBTO:FILTer:FRAMe<fr>:ENABLE</code>	1776
<code>SBUS<sb>:TBTO:FILTer:IMAX</code>	1777
<code>SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:IMAX</code>	1777
<code>SBUS<sb>:TBTO:FILTer:IMIN</code>	1777
<code>SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:IMIN</code>	1777
<code>SBUS<sb>:TBTO:FILTer:IOperator</code>	1778
<code>SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:IOperator</code>	1778

SBUS<sb>:TBTO:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 809

SBUS<sb>:TBTO:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 809

SBUS<sb>:TBTO:FILTER:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:
<sb> 1 to 4, index of the serial bus

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 809

SBUS<sb>:TBTO:FILTER:RST

Presets the state of the selected frames and error types.

Suffix:
<sb> 1 to 4, index of the serial bus

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 809

SBUS<sb>:TBTO:FILTER:BIT <Frame>,<Field>,<Bit>

SBUS<sb>:TBTO:FILTER:BIT? <Bit>

SBUS<sb>:TBTO:FILTER:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<fl> Index of the field

Parameters:
<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 810

SBUS<sb>:TBTO:FILTer:DMAX <Frame>,<Field>,<Data>

SBUS<sb>:TBTO:FILTer:DMAX? <Data>

SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range if the operator is set to INRange or OORANGE.

You can set the operator with **SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:DOPerator**.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See "Edit" on page 810

SBUS<sb>:TBTO:FILTer:DMIN <Frame>,<Field>,<Data>

SBUS<sb>:TBTO:FILTer:DMIN? <Data>

SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command

Manual operation: See "Edit" on page 810

SBUS<sb>:TBTO:FILTer:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:TBTO:FILTer:DOPerator? <Operator>

SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 810

SBUS<sb>:TBTO:FILTer:ERENable <ErrorName>,<Enabler>

SBUS<sb>:TBTO:FILTer:ERENable? <Enabler>

SBUS<sb>:TBTO:FILTer:ERRor<n>:ENABLE <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 811

SBUS<sb>:TBTO:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:TBTO:FILTer:FIENable? <Enabler>

SBUS<sb>:TBTO:FILTer:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 810

SBUS<sb>:TBTO:FILTer:FRENable <Frame>,<Enabler>

SBUS<sb>:TBTO:FILTer:FRENable? <Enabler>

SBUS<sb>:TBTO:FILTer:FRAME<fr>:ENABLE <Enable>

Enables the filtering on 1000BASE-T1 frames. Only the frames that match the selected filter conditions are displayed.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Parameters:****<Enable>** OFF | ON***RST:** ON**Usage:** Asynchronous command**SBUS<sb>:TBTO:FILTer:IMAX** <Frame>,<Field>,<Data>**SBUS<sb>:TBTO:FILTer:IMAX?** <Data>**SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:IMAX** <Index_Max>Sets the end value of an index range if the operator is set to **INRange**.You can set the operator with **SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:IOperator**.**Suffix:****<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<Index_Max>** Range: 1 to 65535

Increment: 1

***RST:** 65535**Usage:** Asynchronous command**Manual operation:** See **"Edit"** on page 810**SBUS<sb>:TBTO:FILTer:IMIN** <Frame>,<Field>,<Data>**SBUS<sb>:TBTO:FILTer:IMIN?** <Data>**SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:IMIN** <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:****<Index_Min>** Range: 1 to 65535

Increment: 1

***RST:** 1**Usage:** Asynchronous command**Manual operation:** See **"Edit"** on page 810

SBUS<sb>:TBTO:FILTer:IOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:TBTO:FILTer:IOPerator? <Operator>

SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGe

*RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 810

18.18.20.3 Software trigger

There are two commands for each parameter, that you can use for defining the 1000BASE-T1 settings.

For example, to set the *Frame type =MAC > Field =Data >00* value you can use one of the following commands:

- **TRIGger:SBSW:TBTO:FRAMe1:FLD1:DMIN 00**
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- **TRIGger:SBSW:TBTO:DMIN "MAC", "Data", 00**
Defines the parameter by using the frame and field name.

TRIGger:SBSW:TBTO:CHKall.....	1779
TRIGger:SBSW:TBTO:CLR.....	1779
TRIGger:SBSW:TBTO:INVert.....	1779
TRIGger:SBSW:TBTO:RST.....	1779
TRIGger:SBSW:TBTO:FRENable.....	1779
TRIGger:SBSW:TBTO:FRAMe<fr>:ENABLE.....	1779
TRIGger:SBSW:TBTO:BIT.....	1780
TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:BIT.....	1780
TRIGger:SBSW:TBTO:DMAX.....	1780
TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:DMAX.....	1780
TRIGger:SBSW:TBTO:DMIN.....	1780
TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:DMIN.....	1780
TRIGger:SBSW:TBTO:DOPerator.....	1781
TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:DOPerator.....	1781
TRIGger:SBSW:TBTO:FIENable.....	1781
TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:ENABLE.....	1781
TRIGger:SBSW:TBTO:IMAX.....	1782
TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:IMAX.....	1782
TRIGger:SBSW:TBTO:IMIN.....	1782

TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:IMIN.....	1782
TRIGger:SBSW:TBTO:IOperator.....	1782
TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:IOperator.....	1782
TRIGger:SBSW:TBTO:ERENable.....	1783
TRIGger:SBSW:TBTO:ERRor<m>:ENABLE.....	1783
SBUS<sb>:TBTO:SWTindex?.....	1783
SBUS<sb>:TBTO:SWTTime?.....	1783

TRIGger:SBSW:TBTO:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all](#), [Clear](#), [Invert](#), [Preset](#)" on page 812

TRIGger:SBSW:TBTO:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all](#), [Clear](#), [Invert](#), [Preset](#)" on page 812

TRIGger:SBSW:TBTO:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all](#), [Clear](#), [Invert](#), [Preset](#)" on page 812

TRIGger:SBSW:TBTO:RST

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all](#), [Clear](#), [Invert](#), [Preset](#)" on page 812

TRIGger:SBSW:TBTO:FRENable <Frame>,<Enabler>

TRIGger:SBSW:TBTO:FRENable? <Enabler>

TRIGger:SBSW:TBTO:FRAMe<fr>:ENABLE <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:
<fr> Index of the frame

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 813

TRIGger:SBSW:TBTO:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:TBTO:BIT? <Bit>

TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO
 *RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 813

TRIGger:SBSW:TBTO:DMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:TBTO:DMAX? <Data>

TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGe.

You can set the operator with [TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:DOPerator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max>

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 813

TRIGger:SBSW:TBTO:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:TBTO:DMIN? <Data>

TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min>

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 813**TRIGger:SBSW:TBTO:DOPerator** <Frame>,<Field>,<Operator>**TRIGger:SBSW:TBTO:DOPerator?** <Operator>**TRIGger:SBSW:TBTO:FRAME<fr>:FLD<fl>:DOPerator** <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange
*RST: EQUal

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 813**TRIGger:SBSW:TBTO:FIENable** <Frame>,<Field>,<Enabler>**TRIGger:SBSW:TBTO:FIENable?** <Enabler>**TRIGger:SBSW:TBTO:FRAME<fr>:FLD<fl>:ENABLE** <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
*RST: OFF

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 813

TRIGger:SBSW:TBTO:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:TBTO:IMAX? <Data>

TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with **TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:IOperator**.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See "Edit" on page 813

TRIGger:SBSW:TBTO:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:TBTO:IMIN? <Data>

TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See "Edit" on page 813

TRIGger:SBSW:TBTO:IOperator <Frame>,<Field>,<Operator>

TRIGger:SBSW:TBTO:IOperator? <Operator>

TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUAL | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 813

TRIGger:SBSW:TBTO:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:TBTO:ERENable? <Enabler>

TRIGger:SBSW:TBTO:ERRor<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> index of the error

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 814

SBUS<sb>:TBTO:SWTindex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295
 Increment: 1
 *RST: 0

Usage: Query only
 Asynchronous command

SBUS<sb>:TBTO:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

18.18.20.4 Decode results

SBUS<sb>:TBTO:FCOunt?	1784
SBUS<sb>:TBTO:FRAME<fr>:FLDCount?	1784
SBUS<sb>:TBTO:FRAME<fr>:BITRate?	1785
SBUS<sb>:TBTO:FRAME<fr>:FLD<fl>:FVAlue?	1785
SBUS<sb>:TBTO:FRAME<fr>:FLD<fl>:LABel?	1785
SBUS<sb>:TBTO:FRAME<fr>:FLD<fl>:STATe?	1786
SBUS<sb>:TBTO:FRAME<fr>:FLD<fl>:VALue?	1786
SBUS<sb>:TBTO:FRAME<fr>:CRC?	1787
SBUS<sb>:TBTO:FRAME<fr>:DATA?	1787
SBUS<sb>:TBTO:FRAME<fr>:DTADdress?	1787
SBUS<sb>:TBTO:FRAME<fr>:DTSYmbol?	1788
SBUS<sb>:TBTO:FRAME<fr>:FCRC?	1788
SBUS<sb>:TBTO:FRAME<fr>:FDATa?	1788
SBUS<sb>:TBTO:FRAME<fr>:FDAddress?	1788
SBUS<sb>:TBTO:FRAME<fr>:FSRaddress?	1789
SBUS<sb>:TBTO:FRAME<fr>:FTPLenth?	1789
SBUS<sb>:TBTO:FRAME<fr>:SRADdress?	1789
SBUS<sb>:TBTO:FRAME<fr>:SRSYmbol?	1789
SBUS<sb>:TBTO:FRAME<fr>:START?	1790
SBUS<sb>:TBTO:FRAME<fr>:STATus?	1790
SBUS<sb>:TBTO:FRAME<fr>:STOP?	1791
SBUS<sb>:TBTO:FRAME<fr>:TPLenth?	1791
SBUS<sb>:TBTO:FRAME<fr>:TYPE?	1791

SBUS<sb>:TBTO:FCOunt?

Returns the number of decoded frames.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Count> Total number of decoded frames.

Usage:

Query only
 Asynchronous command

SBUS<sb>:TBTO:FRAME<fr>:FLDCount?

Returns the number of fields in the specified frame.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Return values:****<Count>** Total number of fields.**Usage:**Query only
Asynchronous command**SBUS<sb>:TBTO:FRAME<fr>:BITRate?**

Returns the primary bit rate.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**Return values:****<PrimaryBitRate>** Range: 0 to 100000000000
Increment: 1
*RST: 0
Default unit: bps**Usage:**Query only
Asynchronous command**SBUS<sb>:TBTO:FRAME<fr>:FLD<fl>:FVALue?**

Returns the formatted value of the specified field.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Return values:****<FormattedValue>****Usage:**Query only
Asynchronous command**SBUS<sb>:TBTO:FRAME<fr>:FLD<fl>:LABel?**

Returns the label of the selected field in the specified frame.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field

Return values:

<Label>

Usage:

Query only
Asynchronous command

SBUS<sb>:TBTO:FRAME<fr>:FLD<fl>:STATe?

Returns the state of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<fl> Index of the field

Return values:

<State> OK | ERRFEC | ERRZERO | ERROOR | ERRCRC | INComplete

OK

Valid frame.

ERRFEC

Reed-Solomon forward error correction.

ERRZERO

Zero ternary symbol pair error.

ERROOR

Values are out of range error.

ERRCRC

Erroneous frame due to CRC error.

INComplete

Frame is incomplete.

*RST: OK

Usage:

Query only
Asynchronous command

SBUS<sb>:TBTO:FRAME<fr>:FLD<fl>:VALue?

Returns the value of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<fl> Index of the field

Return values:

<Value> *RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:TBTO:FRAME<fr>:CRC?

Returns the CRC (frame check) checksum of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<CRC> Range: 0 to 4294967295
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:TBTO:FRAME<fr>:DATA?

Returns the data for the selected frame in comma separated values. Corresponds to the Data column in the decode results table.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Count>

<Values>

Example: Query: SBUS:TBTO:FRAME1:DATA?
Return string, if there are 10 bytes:
10,45,87,123,0,54,67,1,0,9,0

Usage: Query only
Asynchronous command

SBUS<sb>:TBTO:FRAME<fr>:DTADdress?

Returns the destination address of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<DestAddress> Range: 0 to 281474976710655
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:TBTO:FRAME<fr>:DTSymbol?

Returns the destination symbols of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<DestSymbNme>

Usage:

Query only
Asynchronous command

SBUS<sb>:TBTO:FRAME<fr>:FCRC?

Returns the formatted CRC (frame check) checksum of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<FormattedCRC>

Usage:

Query only
Asynchronous command

SBUS<sb>:TBTO:FRAME<fr>:FDATa?

Returns the formatted data for the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<FormattedData>

Usage:

Query only
Asynchronous command

SBUS<sb>:TBTO:FRAME<fr>:FDTaddress?

Returns the formatted destination address of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<FormattedDestAddr>

Usage: Query only
Asynchronous command

SBUS<sb>:TBTO:FRAMe<fr>:FSRAddress?

Returns the formatted source address of the selected frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <FormattedSrcAddr>

Usage: Query only
Asynchronous command

SBUS<sb>:TBTO:FRAMe<fr>:FTPLenth?

Returns the value of type /length field of the selected frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <FormattedTypLenth>

Usage: Query only
Asynchronous command

SBUS<sb>:TBTO:FRAMe<fr>:SRADdress?

Returns the source address of the selected frame.

Suffix:
 <sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:
 <SourceAddress> Range: 0 to 281474976710655
 Increment: 1
 *RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:TBTO:FRAMe<fr>:SRSYmbol?

Returns the source symbols of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<SrcSymbNme>

Usage:Query only
Asynchronous command**SBUS<sb>:TBTO:FRAME<fr>:START?**

Returns the start time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:<FrameStart> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s**Usage:**Query only
Asynchronous command**SBUS<sb>:TBTO:FRAME<fr>:STATUs?**

Returns the overall state of the frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameState> OK | ERRFEC | ERRZERO | ERROOR | ERRCRC | INComplete

OK

Valid frame.

ERRFEC

Reed-Solomon forward error correction.

ERRZERO

Zero ternary symbol pair error.

ERROOR

Values are out of range error.

ERRCRC

Erroneous frame due to CRC error.

INComplete

Frame is incomplete

*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:TBTO:FRAME<fr>:STOP?

Returns the end time of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage: Query only
Asynchronous command

SBUS<sb>:TBTO:FRAME<fr>:TPLenth?

Returns the value of the type / length field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<TypeLenth> Range: 0 to 65535
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:TBTO:FRAME<fr>:TYPE?

Returns the type of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameType> IDLE | MAC | OAM | RSFEC | BH | CTLADDR | CTLCODE |
ZEROTSYM | UNKNown

IDLE

IDLE frame, used for clock synchronization

MAC

MAC frame, contains information that defines how to go about transmitting and receiving frames

OAM

Operations, administration, and maintenance frame

RSFEC

Reed Solomon forward error correction check frame

BH

Block header frame

CTLADDR

Control address frame

CTLCODE

Control code frame

ZEROTSYM

Zero ternary symbol frame

UNKNown

No meaningful frame can be determined.

*RST: MAC

Usage:

Query only

Asynchronous command

18.18.21 USB 1.1 (option R&S MXO5C-K570)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with `SBUS<sb>[:STATE]`.
- The bus is set to the correct type with `SBUS<sb>:TYPE`.

• Configuration	1792
• Filter	1795
• Software trigger	1800
• Decode results	1806

18.18.21.1 Configuration

SBUS<sb>:USBone:DPLus:SOURce	1793
SBUS<sb>:USBone:DMINus:SOURce	1793
SBUS<sb>:USBone:MODE	1793
SBUS<sb>:USBone:DPLus:THReshold	1793
SBUS<sb>:USBone:DPLus:HYSteresis	1794
SBUS<sb>:USBone:DMINus:THReshold	1794
SBUS<sb>:USBone:DMINus:HYSteresis	1794
SBUS<sb>:USBone:POSition	1794
SBUS<sb>:USBone:SCALE	1795

SBUS<sb>:USBone:DPLus:SOURce <DPlusSource>

Sets the source channel to which the D+ data line is connected.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DPlusSource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See "[D+ source](#), [D- source](#)" on page 826

SBUS<sb>:USBone:DMINus:SOURce <DMinusSource>

Sets the source channel to which the D- data line is connected.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DMinusSource> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See "[D+ source](#), [D- source](#)" on page 826

SBUS<sb>:USBone:MODE <Mode>

Selects the low speed or full speed variant of the USB 1.1 protocol.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Mode> USBLow | USBFull
*RST: USBLow

Usage: Asynchronous command

Manual operation: See "[Speed variant](#)" on page 826

SBUS<sb>:USBone:DPLus:THReshold <DPlusThreshold>

Sets a threshold value for the D+ line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DPlusThreshold>

Usage: Asynchronous command**Manual operation:** See "[D+ threshold](#)" on page 828

SBUS<sb>:USBone:DPLus:HYSTeresis <DPlusHyst>

Sets a hysteresis value for the D+ line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DPlusHyst>

Usage: Asynchronous command**Manual operation:** See "[D+ hysteresis](#)" on page 828

SBUS<sb>:USBone:DMINus:THReshold <DMinusThres>

Sets a threshold value for the D- line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DMinusThres>

Usage: Asynchronous command**Manual operation:** See "[D- threshold](#)" on page 828

SBUS<sb>:USBone:DMINus:HYSTeresis <DMinusHyst>

Sets a hysteresis value for the D- line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<DMinusHyst>

Usage: Asynchronous command**Manual operation:** See "[D- hysteresis](#)" on page 828

SBUS<sb>:USBone:POSition <Position>

Sets the vertical position of the USB 1.1 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Position> Range: 1 to 100

Usage:

Asynchronous command

SBUS<sb>:USBone:SCALE <Scale>

Sets the vertical scale of the USB 1.1 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Scale> Range: 1 to 5

Usage:

Asynchronous command

18.18.21.2 Filter

There are two commands for each parameter, that you can use for defining the USB 1.1 settings.

For example, to set the *Frame type* =WRITE > *Field* =Address > *Data* value you can use one of the following commands:

- SBUS:USBone:FILTer:FRAMe1:FLD1:DMIN 01100
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- SBUS:USBone:FILTer:DMIN "WRITE", "Address", 01100
Defines the parameter by using the frame and field name.

SBUS<sb>:USBone:FILTer:CHKall.....	1796
SBUS<sb>:USBone:FILTer:CLR.....	1796
SBUS<sb>:USBone:FILTer:INVert.....	1796
SBUS<sb>:USBone:FILTer:RST.....	1796
SBUS<sb>:USBone:FILTer:FRENable.....	1797
SBUS<sb>:USBone:FILTer:FRAMe<fr>:ENable.....	1797
SBUS<sb>:USBone:FILTer:DMAX.....	1797
SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1797
SBUS<sb>:USBone:FILTer:DMIN.....	1797
SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1797
SBUS<sb>:USBone:FILTer:DOPerator.....	1798
SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1798
SBUS<sb>:USBone:FILTer:ERENable.....	1798
SBUS<sb>:USBone:FILTer:ERRor<n>:ENable.....	1798
SBUS<sb>:USBone:FILTer:IMAX.....	1798
SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1798
SBUS<sb>:USBone:FILTer:IMIN.....	1799
SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1799
SBUS<sb>:USBone:FILTer:IOperator.....	1799
SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:IOperator.....	1799
SBUS<sb>:USBone:FILTer:BIT.....	1800

SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1800
SBUS<sb>:USBone:FILTer:FIENable.....	1800
SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:ENABLE.....	1800

SBUS<sb>:USBone:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 830

SBUS<sb>:USBone:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 830

SBUS<sb>:USBone:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 830

SBUS<sb>:USBone:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 830

SBUS<sb>:USBone:FILTer:FREnAble <Frame>,<Enabler>

SBUS<sb>:USBone:FILTer:FREnAble? <Enabler>

SBUS<sb>:USBone:FILTer:FRAMe<fr>:ENABLe <Enable>

Enables or disables the specific frame to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 830

SBUS<sb>:USBone:FILTer:DMAx <Frame>,<Field>,<Data>

SBUS<sb>:USBone:FILTer:DMAx? <Data>

SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:DMAx <Data_Max>

Sets the end value of a data pattern range if the operator is set to INRange or OORANGE.

You can set the operator with [SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:DOPerator](#).

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max> List of comma-separated values

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 831

SBUS<sb>:USBone:FILTer:DMin <Frame>,<Field>,<Data>

SBUS<sb>:USBone:FILTer:DMin? <Data>

SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:DMin <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min> List of comma-separated values

Usage:

Asynchronous command

Manual operation: See ["Edit"](#) on page 831

SBUS<sb>:USBone:FILTer:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:USBone:FILTer:DOPerator? <Operator>

SBUS<sb>:USBone:FILTer:FRAME<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange

*RST: EQUal

Usage:

Asynchronous command

Manual operation: See ["Edit"](#) on page 831

SBUS<sb>:USBone:FILTer:ERENable <ErrorName>,<Enabler>

SBUS<sb>:USBone:FILTer:ERENable? <Enabler>

SBUS<sb>:USBone:FILTer:ERRor<n>:ENABle <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage:

Asynchronous command

Manual operation: See ["Error type"](#) on page 832

SBUS<sb>:USBone:FILTer:IMAX <Frame>,<Field>,<Data>

SBUS<sb>:USBone:FILTer:IMAX? <Data>

SBUS<sb>:USBone:FILTer:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range if the operator is set to INRange.

You can set the operator with `SBUS<sb>:USBone:FILTer:IOperator`.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:**

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 831**SBUS<sb>:USBone:FILTer:IMIN** <Frame>,<Field>,<Data>**SBUS<sb>:USBone:FILTer:IMIN?** <Data>**SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:IMIN** <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:**

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 831**SBUS<sb>:USBone:FILTer:IOperator** <Frame>,<Field>,<Operator>**SBUS<sb>:USBone:FILTer:IOperator?** <Operator>**SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:IOperator** <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:**<sb>** 1 to 4, index of the serial bus**<fr>** Index of the frame**<fl>** Index of the field**Parameters:**

<Index_Operator> EQUal | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command**Manual operation:** See ["Edit"](#) on page 831

SBUS<sb>:USBone:FILTer:BIT <Frame>,<Field>,<Bit>

SBUS<sb>:USBone:FILTer:BIT? <Bit>

SBUS<sb>:USBone:FILTer:FRAME<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO

*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 831

SBUS<sb>:USBone:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:USBone:FILTer:FIENable? <Enabler>

SBUS<sb>:USBone:FILTer:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 831

18.18.21.3 Software trigger

There are two commands for each parameter, that you can use for defining the USB 1.1 settings.

For example, to set the *Frame type =WRITE > Field =Address >Data* value you can use one of the following commands:

- `TRIGger:SBSW:USBone:FRAME1:FLD1:DMIN 01100`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `STRIGger:SBSW:USBone:DMIN "WRITE", "Address", 01100`
Defines the parameter by using the frame and field name.

TRIGger:SBSW:USBone:CHKall.....	1801
TRIGger:SBSW:USBone:CLR.....	1801
TRIGger:SBSW:USBone:INVert.....	1801
TRIGger:SBSW:USBone:RST.....	1802
TRIGger:SBSW:USBone:FREnable.....	1802
TRIGger:SBSW:USBone:FRAMe<fr>:ENABle.....	1802
TRIGger:SBSW:USBone:BIT.....	1802
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:BIT.....	1802
TRIGger:SBSW:USBone:DMAx.....	1803
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:DMAx.....	1803
TRIGger:SBSW:USBone:DMin.....	1803
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:DMin.....	1803
TRIGger:SBSW:USBone:DOPerator.....	1803
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:DOPerator.....	1803
TRIGger:SBSW:USBone:FIENable.....	1804
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:ENABle.....	1804
TRIGger:SBSW:USBone:IMAX.....	1804
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:IMAX.....	1804
TRIGger:SBSW:USBone:IMIN.....	1805
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:IMIN.....	1805
TRIGger:SBSW:USBone:IOPerator.....	1805
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:IOPerator.....	1805
TRIGger:SBSW:USBone:ERENable.....	1805
TRIGger:SBSW:USBone:ERRor<m>:ENABle.....	1805
SBUS<sb>:USBone:SWTIndex?.....	1806
SBUS<sb>:USBone:SWTTime?.....	1806

TRIGger:SBSW:USBone:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 833

TRIGger:SBSW:USBone:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
Asynchronous command

Manual operation: See "[Check all, Clear, Invert, Preset](#)" on page 833

TRIGger:SBSW:USBone:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 833

TRIGger:SBSW:USBone:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 833

TRIGger:SBSW:USBone:FREnable <Frame>,<Enabler>

TRIGger:SBSW:USBone:FREnable? <Enabler>

TRIGger:SBSW:USBone:FRAME<fr>:ENABLE <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:
<fr> Index of the frame

Parameters:
<Enable> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 834

TRIGger:SBSW:USBone:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:USBone:BIT? <Bit>

TRIGger:SBSW:USBone:FRAME<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:
<fr> Index of the frame
<fl> Index of the field

Parameters:
<BitState> ONE | ZERO
*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 834

TRIGger:SBSW:USBone:DMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:USBone:DMAX? <Data>

TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGe.

You can set the operator with **TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:DOPerator**.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max> List of comma-separated values

Usage: Asynchronous command

Manual operation: See "Edit" on page 834

TRIGger:SBSW:USBone:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:USBone:DMIN? <Data>

TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min> List of comma-separated values

Usage: Asynchronous command

Manual operation: See "Edit" on page 834

TRIGger:SBSW:USBone:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:USBone:DOPerator? <Operator>

TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 834

TRIGger:SBSW:USBone:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:USBone:FIENable? <Enabler>

TRIGger:SBSW:USBone:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 834

TRIGger:SBSW:USBone:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:USBone:IMAX? <Data>

TRIGger:SBSW:USBone:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with [TRIGger:SBSW:USBone:FRAME<fr>:FLD<fl>:IOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 834

TRIGger:SBSW:USBone:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:USBone:IMIN? <Data>

TRIGger:SBSW:USBone:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 834

TRIGger:SBSW:USBone:IOperator <Frame>,<Field>,<Operator>

TRIGger:SBSW:USBone:IOperator? <Operator>

TRIGger:SBSW:USBone:FRAME<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUAL | INRange | RANGE
 *RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 834

TRIGger:SBSW:USBone:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:USBone:ERENable? <Enabler>

TRIGger:SBSW:USBone:ERROR<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> Index of the error

Parameters:

<Enable> OFF | ON
 *RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 835

SBUS<sb>:USBone:SWTIndex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:USBone:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

18.18.21.4 Decode results

SBUS<sb>:USBone:FCOut?	1807
SBUS<sb>:USBone:FRAME<fr>:ADDRess?	1807
SBUS<sb>:USBone:FRAME<fr>:FLDCount?	1807
SBUS<sb>:USBone:FRAME<fr>:BITRate?	1808
SBUS<sb>:USBone:FRAME<fr>:DATA?	1808
SBUS<sb>:USBone:FRAME<fr>:STARt?	1808
SBUS<sb>:USBone:FRAME<fr>:STATus?	1809
SBUS<sb>:USBone:FRAME<fr>:STOP?	1809
SBUS<sb>:USBone:FRAME<fr>:FLD<fl>:FVALue?	1810
SBUS<sb>:USBone:FRAME<fr>:FLD<fl>:LABel?	1810
SBUS<sb>:USBone:FRAME<fr>:FLD<fl>:STATe?	1810
SBUS<sb>:USBone:FRAME<fr>:FLD<fl>:VALue?	1811
SBUS<sb>:USBone:FRAME<fr>:CRC?	1811
SBUS<sb>:USBone:FRAME<fr>:FADDRess?	1812
SBUS<sb>:USBone:FRAME<fr>:FCRC?	1812
SBUS<sb>:USBone:FRAME<fr>:ENDPoiNt?	1812

SBUS<sb>:USBone:FRAME<fr>:FRNumber?	1812
SBUS<sb>:USBone:FRAME<fr>:PID?	1813
SBUS<sb>:USBone:FRAME<fr>:PIDName?	1813
SBUS<sb>:USBone:FRAME<fr>:TYPE?	1813

SBUS<sb>:USBone:FCOut?

Returns the number of decoded frames.

Suffix:

<sb> 1 to 4, index of the serial bus
Selects the serial bus.

Return values:

<Count> Total number of decoded frames.

Usage:

Query only
Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:ADDRess?

Returns the device address value of the indicated frame. That is, the address value that is shown in the decoded cells and in the decode results table.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<AddressValue> Range: 0 to 65535
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:FLDCount?

Returns the number of fields in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Count>

Usage:

Query only
Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:BITRate?

Returns the number of fields in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<BitRate> Increment: 1
 *RST: 0
 Default unit: bps

Usage: Query only
 Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:DATA?

Returns a comma-separated list of values, where the first value is the number of data bytes in the frame, and the remaining values are this number of data bytes.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Count>

<Values>

Example: SBUS:USB:FRAME2:DATA?
 13,7,7,8,9,16,17,18,19,20,21,21,22,255
 The first value, here 13, is the number of data bytes to follow.

Usage: Query only
 Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:START?

Returns the start time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStart> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage: Query only
 Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:STATus?

Returns the overall state of the frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameState> OK | PID | CRC | LENGth | BTST | INComplete

OK

The frame is valid.

PID

A packet identifier error signifies that the integrity check has failed, see [Packet structure](#) > "PID" in [Section 14.20.1, "USB protocol basics"](#), on page 820. The 8-bit PID is invalid, if its 4 least significant bits (LSB) are not the complement of its 4 most significant bits (MSB).

CRC

Cyclic redundancy check failed.

LENGth

Wrong length of frame.

BTST

Bit stuffing error occurred.

INComplete

The frame is not completely contained in the acquisition. The acquired part of the frame is usually valid, but cannot always be trusted.

*RST: OK

Usage:

Query only
Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:STOP?

Returns the end time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified field for the selected frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Return values:

<FormattedValue>

Usage:

Query only
Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:FLD<fl>:LABel?

Returns the name (label) of the specified field in the selected frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Return values:

<Label>

Usage:

Query only
Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:FLD<fl>:STATe?

Returns the overall state of the specified field for the selected frame.

Suffix:

<sb>	1 to 4, index of the serial bus
<fr>	Index of the frame
<fl>	Index of the field

Return values:

<State> OK | PID | CRC | LENGth | BTST | INComplete

OK

The field has no error, it is valid.

PID

A packet identifier error signifies that the integrity check has failed, see [Packet structure](#) > "PID" in [Section 14.20.1, "USB protocol basics"](#), on page 820. The 8-bit PID is invalid, if its 4 least significant bits (LSB) are not the complement of its 4 most significant bits (MSB).

CRC

Cyclic redundancy check failed.

LENGth

Wrong length of the field.

BTST

Bit stuffing error occurred.

INComplete

The field is not completely contained in the acquisition. The acquired part of the field is usually valid, but cannot always be trusted.

*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:FLD<fl>:VALue?

Returns the data value of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame
<fl> Index of the field

Return values:

<Value> Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:CRC?

Returns the cyclic redundancy check (CRC) checksum of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:

<CRCValue> Range: 0 to 65535
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:FADdress?

Returns the formatted address for the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FormattedAddrVal>

Usage:

Query only
Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:FCRC?

Returns the formatted CRC value for the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FormattedCRCVal>

Usage:

Query only
Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:ENDPoint?

Returns the endpoint for the selected serial bus and frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Endpoint> Range: 0 to 65535
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:FRNumber?

Returns the frame number for the selected serial bus and frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameNumber> Range: 0 to 65535
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:PID?

Returns the packet identifier for the selected serial bus and frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<Command> Range: 0 to 65535
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:PIDName?

Returns the name of the packet identifier for the selected serial bus and frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<FormattedCmd>

Usage:

Query only
 Asynchronous command

SBUS<sb>:USBone:FRAME<fr>:TYPE?

Returns the frame type of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<FrameType> UNKNown | DATA | TOKen | SOF | HSHK | PERR
 Unknown, data, token, start of frame, handshake, PRE/ERR
 frame (with PID=0x3C meaning either preamble or error)
 *RST: UNKNown

Usage: Query only
Asynchronous command

18.18.22 USB 2.0 (option R&S MXO5C-K570)

Before MXO 5C can accept the specific bus commands, make sure that:

- The decoding of the specified bus is enabled with `SBUS<sb>[:STATe]`.
- The bus is set to the correct type with `SBUS<sb>:TYPE`.
- [Configuration](#)..... 1814
- [Filter](#)..... 1816
- [Software trigger](#)..... 1821
- [Decode results](#)..... 1827

18.18.22.1 Configuration

SBUS<sb>:USBHspeed:SOURce	1814
SBUS<sb>:USBHspeed:THReshold:UPPer	1814
SBUS<sb>:USBHspeed:THReshold:LOWer	1815
SBUS<sb>:USBHspeed:THReshold:HYSTeresis	1815
SBUS<sb>:USBHspeed:POSition	1815
SBUS<sb>:USBHspeed:SCALe	1815

SBUS<sb>:USBHspeed:SOURce <Source>

Selects the differential signal source to which the data line is connected.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Source> C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 | D0 | D1 | D2 | D3 | D4 | D5
| D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15 | M1 | M2
| M3 | M4 | M5 | M6 | M7 | M8 | R1 | R2 | R3 | R4 | R5 | R6 | R7 |
R8 | O<n>C1 | O<n>C2 | ... | O<n>C8 (<n> = 2 to 8)

Usage: Asynchronous command

Manual operation: See "[Differential source](#)" on page 839

SBUS<sb>:USBHspeed:THReshold:UPPer <Upper Thres>

Sets the upper threshold value for the differential signal on the data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Upper Thres>

Usage: Asynchronous command

Manual operation: See ["Upper threshold"](#) on page 840

SBUS<sb>:USBHspeed:THReshold:LOWer <Lower Thres>

Sets the lower threshold value for the differential signal on the data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Lower Thres>

Usage:

Asynchronous command

Manual operation: See ["Lower threshold"](#) on page 841

SBUS<sb>:USBHspeed:THReshold:HYSTeresis <Hysteresis>

Sets a hysteresis value for the differential signal on the data line.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Hysteresis>

Usage:

Asynchronous command

Manual operation: See ["Hysteresis"](#) on page 841

SBUS<sb>:USBHspeed:POSition <Position>

Sets the vertical position of the USB 2.0 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Position> Range: 1 to 100

Usage:

Asynchronous command

SBUS<sb>:USBHspeed:SCALe <Scale>

Sets the vertical scale of the USB 2.0 signal.

Suffix:

<sb> 1 to 4, index of the serial bus

Parameters:

<Scale> Range: 1 to 5

Usage:

Asynchronous command

18.18.22.2 Filter

There are two commands for each parameter, that you can use for defining the USB 2.0 settings.

For example, to set the *Frame type =WRITE > Field =Address >Data* value you can use one of the following commands:

- `SBUS:USBHspeed:FILTer:FRAMe1:FLD1:DMIN 01100`
Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `SBUS:USBHspeed:FILTer:DMIN "WRITe", "Address", 01100`
Defines the parameter by using the frame and field name.

<code>SBUS<sb>:USBHspeed:FILTer:CHKall</code>	1816
<code>SBUS<sb>:USBHspeed:FILTer:CLR</code>	1817
<code>SBUS<sb>:USBHspeed:FILTer:INVert</code>	1817
<code>SBUS<sb>:USBHspeed:FILTer:RST</code>	1817
<code>SBUS<sb>:USBHspeed:FILTer:FRENAble</code>	1817
<code>SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:ENABLe</code>	1817
<code>SBUS<sb>:USBHspeed:FILTer:DMAx</code>	1818
<code>SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:DMAx</code>	1818
<code>SBUS<sb>:USBHspeed:FILTer:DMIN</code>	1818
<code>SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:DMIN</code>	1818
<code>SBUS<sb>:USBHspeed:FILTer:DOPerator</code>	1818
<code>SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:DOPerator</code>	1818
<code>SBUS<sb>:USBHspeed:FILTer:ERENABLe</code>	1819
<code>SBUS<sb>:USBHspeed:FILTer:ERRor<n>:ENABLe</code>	1819
<code>SBUS<sb>:USBHspeed:FILTer:IMAX</code>	1819
<code>SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:IMAX</code>	1819
<code>SBUS<sb>:USBHspeed:FILTer:IMIN</code>	1820
<code>SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:IMIN</code>	1820
<code>SBUS<sb>:USBHspeed:FILTer:IOPerator</code>	1820
<code>SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:IOPerator</code>	1820
<code>SBUS<sb>:USBHspeed:FILTer:BIT</code>	1820
<code>SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:BIT</code>	1820
<code>SBUS<sb>:USBHspeed:FILTer:FIENABLe</code>	1821
<code>SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:ENABLe</code>	1821

SBUS<sb>:USBHspeed:FILTer:CHKall

Enables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See "[Check all](#), [Clear](#), [Invert](#), [Preset](#)" on page 842

SBUS<sb>:USBHspeed:FILTer:CLR

Disables the filter for all available frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 842

SBUS<sb>:USBHspeed:FILTer:INVert

Inverts the current state of the frame and error types: all frames and error types that were enabled are disabled and vice versa.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 842

SBUS<sb>:USBHspeed:FILTer:RST

Presets the state of the selected frames and error types.

Suffix:

<sb> 1 to 4, index of the serial bus

Usage:

Setting only
Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 842

SBUS<sb>:USBHspeed:FILTer:FREnable <Frame>,<Enabler>**SBUS<sb>:USBHspeed:FILTer:FREnable? <Enabler>****SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:ENABLE <Enable>**

Enables or disables the specific frame to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Parameters:

<Enable> OFF | ON
*RST: ON

Usage:

Asynchronous command

Manual operation: See ["Frame type"](#) on page 843

SBUS<sb>:USBHspeed:FILTer:DMAX <Frame>,<Field>,<Data>

SBUS<sb>:USBHspeed:FILTer:DMAX? <Data>

SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:DMAX <Data_Max>

Sets the end value of a data pattern range if the operator is set to INRange or OORANGE.

You can set the operator with **SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:DOPerator**.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max> List of comma-separated values

Usage: Asynchronous command

Manual operation: See "Edit" on page 843

SBUS<sb>:USBHspeed:FILTer:DMIN <Frame>,<Field>,<Data>

SBUS<sb>:USBHspeed:FILTer:DMIN? <Data>

SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min> List of comma-separated values

Usage: Asynchronous command

Manual operation: See "Edit" on page 843

SBUS<sb>:USBHspeed:FILTer:DOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:USBHspeed:FILTer:DOPerator? <Operator>

SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQual | LTHan | LETHan | GTHan | GETHan |
 INRange | OORange
 *RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 843

SBUS<sb>:USBHspeed:FILTer:ERENable <ErrorName>,<Enabler>

SBUS<sb>:USBHspeed:FILTer:ERENable? <Enabler>

SBUS<sb>:USBHspeed:FILTer:ERRor<n>:ENABLE <Enable>

Defines the error type to be filtered on.

Suffix:

<sb> 1 to 4, index of the serial bus

<n> Index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 844

SBUS<sb>:USBHspeed:FILTer:IMAX <Frame>,<Field>,<Data>

SBUS<sb>:USBHspeed:FILTer:IMAX? <Data>

SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range if the operator is set to INRange.

You can set the operator with [SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:
 FLD<fl>:IOperator](#).

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535

Increment: 1

*RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 843

SBUS<sb>:USBHspeed:FILTer:IMIN <Frame>,<Field>,<Data>

SBUS<sb>:USBHspeed:FILTer:IMIN? <Data>

SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
Increment: 1
*RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 843

SBUS<sb>:USBHspeed:FILTer:IOPerator <Frame>,<Field>,<Operator>

SBUS<sb>:USBHspeed:FILTer:IOPerator? <Operator>

SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:IOPerator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUal | INRange | RANGE
*RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 843

SBUS<sb>:USBHspeed:FILTer:BIT <Frame>,<Field>,<Bit>

SBUS<sb>:USBHspeed:FILTer:BIT? <Bit>

SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO
 *RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 843

SBUS<sb>:USBHspeed:FILTer:FIENable <Frame>,<Field>,<Enabler>

SBUS<sb>:USBHspeed:FILTer:FIENable? <Enabler>

SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:ENABle <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 843

18.18.22.3 Software trigger

There are two commands for each parameter, that you can use for defining the USB 2.0 settings.

For example, to set the *Frame type =WRITE > Field =Address >Data* value you can use one of the following commands:

- `TRIGger:SBSW:USBHspeed:FRAMe1:FLD1:DMIN 01100`
 Defines the parameter by using the index <m> for the frame number and <n> for the field number.
- `STRIGger:SBSW:USBHspeed:DMIN "WRITE", "Address", 01100`
 Defines the parameter by using the frame and field name.

TRIGger:SBSW:USBHspeed:CHKall	1822
TRIGger:SBSW:USBHspeed:CLR	1822
TRIGger:SBSW:USBHspeed:INVert	1822
TRIGger:SBSW:USBHspeed:RST	1822
TRIGger:SBSW:USBHspeed:FRENable	1823
TRIGger:SBSW:USBHspeed:FRAMe<fr>:ENABle	1823
TRIGger:SBSW:USBHspeed:BIT	1823
TRIGger:SBSW:USBHspeed:FRAMe<fr>:FLD<fl>:BIT	1823
TRIGger:SBSW:USBHspeed:DMAX	1823
TRIGger:SBSW:USBHspeed:FRAMe<fr>:FLD<fl>:DMAX	1823
TRIGger:SBSW:USBHspeed:DMIN	1824

TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:DMIN.....	1824
TRIGger:SBSW:USBHspeed:DOPerator.....	1824
TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:DOPerator.....	1824
TRIGger:SBSW:USBHspeed:FIENable.....	1824
TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:ENABLE.....	1824
TRIGger:SBSW:USBHspeed:IMAX.....	1825
TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:IMAX.....	1825
TRIGger:SBSW:USBHspeed:IMIN.....	1825
TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:IMIN.....	1825
TRIGger:SBSW:USBHspeed:IOperator.....	1826
TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:IOperator.....	1826
TRIGger:SBSW:USBHspeed:ERENable.....	1826
TRIGger:SBSW:USBHspeed:ERRor<m>:ENABLE.....	1826
SBUS<sb>:USBHspeed:SWTindex?.....	1826
SBUS<sb>:USBHspeed:SWTTime?.....	1827

TRIGger:SBSW:USBHspeed:CHKall

Enables the software trigger for all available frames and error types.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 846

TRIGger:SBSW:USBHspeed:CLR

Disables the software trigger for all available frames and error types.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 846

TRIGger:SBSW:USBHspeed:INVert

Inverts the current state of the frame and error types for the software trigger: all frames and error types that were enabled are disabled and vice versa.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 846

TRIGger:SBSW:USBHspeed:RST

Presets the state of the selected frames and error types for the software trigger.

Usage: Setting only
 Asynchronous command

Manual operation: See ["Check all, Clear, Invert, Preset"](#) on page 846

TRIGger:SBSW:USBHspeed:FREnAble <Frame>,<Enabler>

TRIGger:SBSW:USBHspeed:FREnAble? <Enabler>

TRIGger:SBSW:USBHspeed:FRAMe<fr>:ENABle <Enable>

Enables or disables the checking condition for the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Frame type"](#) on page 846

TRIGger:SBSW:USBHspeed:BIT <Frame>,<Field>,<Bit>

TRIGger:SBSW:USBHspeed:BIT? <Bit>

TRIGger:SBSW:USBHspeed:FRAMe<fr>:FLD<fl>:BIT <BitState>

Sets the bit state of a field that only consists of one bit for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<BitState> ONE | ZERO

*RST: ZERO

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 847

TRIGger:SBSW:USBHspeed:DMAx <Frame>,<Field>,<Data>

TRIGger:SBSW:USBHspeed:DMAx? <Data>

TRIGger:SBSW:USBHspeed:FRAMe<fr>:FLD<fl>:DMAx <Data_Max>

Sets the end value of a data pattern range for the software trigger, if the operator is set to INRange or OORANGe.

You can set the operator with [TRIGger:SBSW:USBHspeed:FRAMe<fr>:FLD<fl>:DOperator](#).

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Max> List of comma-separated values

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 847

TRIGger:SBSW:USBHspeed:DMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:USBHspeed:DMIN? <Data>

TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:DMIN <Data_Min>

Specifies the data pattern, or sets the start value of a data pattern range for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Min> List of comma-separated values

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 847

TRIGger:SBSW:USBHspeed:DOPerator <Frame>,<Field>,<Operator>

TRIGger:SBSW:USBHspeed:DOPerator? <Operator>

TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:DOPerator <Data_Operator>

Sets the operator for the data pattern of the software trigger in the selected field of the selected frame.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Data_Operator> EQUal | NEQUal | LTHan | LETHan | GTHan | GETHan |
INRange | OORange
*RST: EQUal

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 847

TRIGger:SBSW:USBHspeed:FIENable <Frame>,<Field>,<Enabler>

TRIGger:SBSW:USBHspeed:FIENable? <Enabler>

TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:ENABLE <CondEnabler>

Enables or disables the checking condition for the selected field of the selected frame of the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<CondEnabler> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 847

TRIGger:SBSW:USBHspeed:IMAX <Frame>,<Field>,<Data>

TRIGger:SBSW:USBHspeed:IMAX? <Data>

TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:IMAX <Index_Max>

Sets the end value of an index range for the software trigger if the operator is set to INRange.

You can set the operator with [TRIGger:SBSW:USBone:FRAME<fr>:FLD<fl>:IOperator](#).

Suffix:

<fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Max> Range: 1 to 65535
 Increment: 1
 *RST: 65535

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 847

TRIGger:SBSW:USBHspeed:IMIN <Frame>,<Field>,<Data>

TRIGger:SBSW:USBHspeed:IMIN? <Data>

TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:IMIN <Index_Min>

Specifies the index, or sets the start value of an index range for the software trigger.

Suffix:

<fr> Index of the frame
 <fl> Index of the field

Parameters:

<Index_Min> Range: 1 to 65535
 Increment: 1
 *RST: 1

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 847

TRIGger:SBSW:USBHspeed:IOperator <Frame>,<Field>,<Operator>

TRIGger:SBSW:USBHspeed:IOperator? <Operator>

TRIGger:SBSW:USBHspeed:FRAME<fr>:FLD<fl>:IOperator <Index_Operator>

Sets the operator for the index in the selected field of the selected frame for the software trigger.

Suffix:

<fr> Index of the frame

<fl> Index of the field

Parameters:

<Index_Operator> EQUAL | INRange | RANGE

*RST: INRange

Usage: Asynchronous command

Manual operation: See ["Edit"](#) on page 847

TRIGger:SBSW:USBHspeed:ERENable <ErrorName>,<Enabler>

TRIGger:SBSW:USBHspeed:ERENable? <Enabler>

TRIGger:SBSW:USBHspeed:ERROR<m>:ENABLE <Enable>

Defines the error type for the software trigger.

Suffix:

<m> Index of the error

Parameters:

<Enable> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Error type"](#) on page 848

SBUS<sb>:USBHspeed:SWTindex?

Queries the software trigger index.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Index> Range: 0 to 4294967295

Increment: 1

*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:USBHspeed:SWTTime?

Queries the software trigger time in seconds.

If no software trigger event has occurred, the command returns *Invalid*.

Suffix:

<sb> 1 to 4, index of the serial bus

Return values:

<Time> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only
Asynchronous command

18.18.22.4 Decode results

SBUS<sb>:USBHspeed:FCOunt?	1827
SBUS<sb>:USBHspeed:FRAME<fr>:ADDRess?	1828
SBUS<sb>:USBHspeed:FRAME<fr>:FLDCount?	1828
SBUS<sb>:USBHspeed:FRAME<fr>:BITRate?	1828
SBUS<sb>:USBHspeed:FRAME<fr>:DATA?	1829
SBUS<sb>:USBHspeed:FRAME<fr>:STARt?	1829
SBUS<sb>:USBHspeed:FRAME<fr>:STATus?	1829
SBUS<sb>:USBHspeed:FRAME<fr>:STOP?	1830
SBUS<sb>:USBHspeed:FRAME<fr>:FLD<fl>:FVALue?	1830
SBUS<sb>:USBHspeed:FRAME<fr>:FLD<fl>:LABel?	1831
SBUS<sb>:USBHspeed:FRAME<fr>:FLD<fl>:STATe?	1831
SBUS<sb>:USBHspeed:FRAME<fr>:FLD<fl>:VALue?	1832
SBUS<sb>:USBHspeed:FRAME<fr>:CRC?	1832
SBUS<sb>:USBHspeed:FRAME<fr>:FADDRess?	1832
SBUS<sb>:USBHspeed:FRAME<fr>:FCRC?	1833
SBUS<sb>:USBHspeed:FRAME<fr>:ENDPoint?	1833
SBUS<sb>:USBHspeed:FRAME<fr>:FRNumber?	1833
SBUS<sb>:USBHspeed:FRAME<fr>:PID?	1834
SBUS<sb>:USBHspeed:FRAME<fr>:PIDName?	1834
SBUS<sb>:USBHspeed:FRAME<fr>:TYPE?	1834
SBUS<sb>:USBHspeed:FRAME<fr>:SPET?	1835
SBUS<sb>:USBHspeed:FRAME<fr>:SPEU?	1835
SBUS<sb>:USBHspeed:FRAME<fr>:SPPort?	1835
SBUS<sb>:USBHspeed:FRAME<fr>:SPS?	1836
SBUS<sb>:USBHspeed:FRAME<fr>:SPSC?	1836

SBUS<sb>:USBHspeed:FCOunt?

Returns the number of decoded frames.

Suffix:

<sb> 1 to 4, index of the serial bus
Selects the serial bus.

Return values:

<Count> Total number of decoded frames.

Usage:

Query only
Asynchronous command

SBUS<sb>:USBHspeed:FRAMe<fr>:ADDRess?

Returns the device address value of the indicated frame. That is, the address value that is shown in the decoded cells and in the decode results table.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<AddressValue> Range: 0 to 65535
Increment: 1
*RST: 0

Usage:

Query only
Asynchronous command

SBUS<sb>:USBHspeed:FRAMe<fr>:FLDCount?

Returns the number of fields in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Count>

Usage:

Query only
Asynchronous command

SBUS<sb>:USBHspeed:FRAMe<fr>:BITRate?

Returns the number of fields in the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Frame calculated bit Increment: 1
 rate> *RST: 0
 Default unit: bps

Usage:

Query only
 Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:DATA?

Returns a comma-separated list of values, where the first value is the number of data bytes in the frame, and the remaining values are this number of data bytes.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<Count>

<Values>

Example:

SBUS:USBH:FRAME3:DATA?
 5,24,156,75,62,230

The first value, here 5, is the number of data bytes to follow.

Usage:

Query only
 Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:START?

Returns the start time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<FrameStart> Range: -1E+26 to 1E+26
 Increment: 1E-10
 *RST: 0
 Default unit: s

Usage:

Query only
 Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:STATUs?

Returns the overall state of the frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameState> OK | PID | CRC | LENGth | BTST | INComplete

OK

The frame is valid.

PID

A packet identifier error signifies that the integrity check has failed, see [Packet structure](#) > "PID" in [Section 14.20.1, "USB protocol basics"](#), on page 820. The 8-bit PID is invalid, if its 4 least significant bits (LSB) are not the complement of its 4 most significant bits (MSB).

CRC

Cyclic redundancy check failed.

LENGth

Wrong length of frame.

BTST

Bit stuffing error occurred.

INComplete

The frame is not completely contained in the acquisition. The acquired part of the frame is usually valid, but cannot always be trusted.

*RST: OK

Usage:

Query only

Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:STOP?

Returns the end time of the specified frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FrameStop> Range: -1E+26 to 1E+26
Increment: 1E-10
*RST: 0
Default unit: s

Usage:

Query only

Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:FLD<fl>:FVALue?

Returns the formatted value of the specified field for the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<FormattedValue>

Usage:

Query only

Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:FLD<fl>:LABel?

Returns the name (label) of the specified field in the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Label>

Usage:

Query only

Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:FLD<fl>:STATe?

Returns the overall state of the specified field for the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<State> OK | PID | CRC | LENGth | BTST | INComplete

OK

The field has no error, it is valid.

PID

A packet identifier error signifies that the integrity check has failed, see [Packet structure](#) > "PID" in [Section 14.20.1, "USB protocol basics"](#), on page 820. The 8-bit PID is invalid, if its 4 least significant bits (LSB) are not the complement of its 4 most significant bits (MSB).

CRC

Cyclic redundancy check failed.

LENGth

Wrong length of the field.

BTST

Bit stuffing error occurred.

INComplete

The field is not completely contained in the acquisition. The acquired part of the field is usually valid, but cannot always be trusted.

*RST: OK

Usage: Query only
Asynchronous command

SBUS<sb>:USBHspeed:FRAMe<fr>:FLD<fl>:VALue?

Returns the data value of the specified field.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

<fl> Index of the field

Return values:

<Value> Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:USBHspeed:FRAMe<fr>:CRC?

Returns the cyclic redundancy check (CRC) checksum of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<CRCValue> Range: 0 to 65535
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:USBHspeed:FRAMe<fr>:FADdress?

Returns the formatted address for the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<FormattedAddrVal>

Usage: Query only
Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:FCRC?

Returns the formatted CRC value for the selected frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:
<FormattedCRCVal>

Usage: Query only
Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:ENDPoint?

Returns the endpoint for the selected serial bus and frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:
<Endpoint> Range: 0 to 65535
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:FRNumber?

Returns the frame number for the selected serial bus and frame.

Suffix:
<sb> 1 to 4, index of the serial bus
<fr> Index of the frame

Return values:
<FrameNumber> Range: 0 to 65535
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:PID?

Returns the packet identifier for the selected serial bus and frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<Command> Range: 0 to 65535
 Increment: 1
 *RST: 0

Usage:

Query only
 Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:PIDName?

Returns the name of the packet identifier for the selected serial bus and frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<FormattedCmd>

Usage:

Query only
 Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:TYPE?

Returns the frame type of the selected frame.

Suffix:

<sb> 1 to 4, index of the serial bus
 <fr> Index of the frame

Return values:

<FrameType> UNKNown | DATA | TOKen | SOF | HSHK | PERR | SPLit |
 PING | RSVD
 Unknown, data, token, start of frame, handshake, PRE/ERR
 frame (with PID=0x3C meaning either preamble or error), split
 frame, ping response, reserved
 *RST: UNKNown

Usage:

Query only
 Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:SPET?

Returns the content of the "SPLIT packet transaction Endpoint Type" field of the selected frame. This 2-bit field tells the USB hub, which split-transaction-state machine to use:

- 00 Control
- 01 Isochronous
- 10 Bulk
- 11 Interrupt

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Split ET> Range: 0 to 65535
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:SPEU?

Returns the content of the "SPLIT packet transaction E/U" field (end or unused) of the selected frame. This single-bit field, combined with the S field (see [SBUS<sb>:USBHspeed:FRAME<fr>:SPS?](#)), describes the type of "payload continuation encoding" used for start-split packets. For complete-split packets, it is unused.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Split E/U> Range: 0 to 65535
Increment: 1
*RST: 0

Example:

Usage: Query only
Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:SPPort?

Returns the content of the "SPLIT packet transaction Port" field of the selected frame. This field is a 7-bit word that contains the port number of the target hub, for which this split transaction is destined.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Split Port> Range: 0 to 65535
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:SPS?

Returns the content of the "SPLIT packet transaction S" field of the selected frame. This single-bit field indicates the speed for the interrupt or control transaction announced by this SPLIT packet: 0 = Full speed, 1 = Low speed.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Split S> Range: 0 to 65535
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

SBUS<sb>:USBHspeed:FRAME<fr>:SPSC?

Returns the content of the "SPLIT packet transaction Start / Complete" field of the selected frame. This single-bit field indicates the SPLIT token: 0 = start-split transaction, 1 = complete-split transaction.

Suffix:

<sb> 1 to 4, index of the serial bus

<fr> Index of the frame

Return values:

<Split SC> Range: 0 to 65535
Increment: 1
*RST: 0

Usage: Query only
Asynchronous command

18.19 Logic analysis on digital channels

This section describes the remote commands of MSO option R&S MXO5C-B1.

Some of the commands in the following section are asynchronous. An overlapping or asynchronous command does not automatically finish executing before the next command starts executing. If overlapping commands must be executed in a defined order, e.g. to avoid wrong measurement results, they must be serviced sequentially.

To prevent an overlapping execution of commands, one of the commands `*OPC`, `*OPC?` or `*WAI` can be used after the command or a command set.

For more information, see:

- www.rohde-schwarz.com/rc-via-scp, section "Command sequence and synchronization"

18.19.1 Digital channels

Except for `DIGital<m>:PROBe<ch>[:ENABle]`, all other `DIGital:` commands affect only the settings of the first MSO bus (Logic1). The settings of all other logic groups (Logic 2, 3,4) remain unchanged.

<code>DIGital<m>:PROBe<ch>[:ENABle]?</code>	1837
<code>DIGital<m>:HYSTeresis</code>	1837
<code>DIGital<m>:LABel</code>	1838
<code>DIGital<m>:SIZE</code>	1838
<code>DIGital<m>:SKEW</code>	1839
<code>DIGital<m>:STATe</code>	1839
<code>DIGital<m>:TECHnology</code>	1839
<code>DIGital<m>:THCoupling</code>	1840
<code>DIGital<m>:THReshold</code>	1840

`DIGital<m>:PROBe<ch>[:ENABle]?`

Enables one digital probe.

Suffix:

<code><m></code>	0 to 15, index of the logic channel Digital channels 0 to 7 belong to probe 1, and channels 8 to 15 belong to probe 2.
<code><ch></code>	1..2 Index of the logic probe (pod)

Return values:

`<ProbeConnected>` OFF | ON

Usage:

Query only
Asynchronous command

`DIGital<m>:HYSTeresis <Hysteresis>`

Sets the hysteresis for the indicated digital channel.

The setting affects only the settings of the first MSO bus (Logic1).

You can set the hysteresis for all buses with `PBUS<pb>:HYSTeresis<n>`.

Suffix:

<m> 0 to 15, index of the logic channel

Parameters:

<Hysteresis>

MAXimum | ROBust | NORMal

MAXimum

Maximum value that is possible and useful for the signal and its settings, to be used for noisy signals.

ROBust

Different hysteresis values for falling and rising edges to avoid an undefined state of the trigger system, to be used for very noisy signals.

NORMal

Small value suitable for the signal and its settings, to be used for clean signals.

Usage:

Asynchronous command

DIGital<m>:LABel <Label>

Sets a name for the indicated digital channel. The name is displayed in the diagram.

The setting affects only the settings of the first MSO bus (Logic1).

You can set the label for all buses with `PBUS<pb>:BIT<n>:LABel`

Suffix:

<m> 0 to 15, index of the logic channel

Parameters:

<Label>

String containing the channel name

Usage:

Asynchronous command

DIGital<m>:SIZE <Size>

Sets the vertical size for the channel group to which the indicated digital channel belongs.

Suffix:

<m> 0..15
Number of the digital channel.
Channel groups: 0..3; 4..7; 8..11; 12..15

Parameters:

<Size>

Number of vertical divisions per logic channel

Range: 0.2 to 10

Usage:

Asynchronous command

DIGital<m>:SKEW <Skew>

Sets an individual delay for each digital channel to time-align it with other digital channels. The skew value compensates delays that are known from the circuit specifics or caused by the different length of cables.

The setting affects only the settings of the first MSO bus (Logic1).

You can set the skew for all buses with [PBUS<pb>:BIT<n>:SKEW](#).

Suffix:

<m> 0 to 15, index of the logic channel

Parameters:

<Skew>

Usage:

Asynchronous command

DIGital<m>:STATe <State>

Enables or disables the indicated digital channel, displays it, and enables the Logic 1 if the bus was disabled.

If another active bus already uses the selected digital channel, the instrument disables the other bus to avoid conflicts.

For Logic 1, the DIGital<m>:STATe command has the same effect as [PBUS<pb>:BIT<n>\[:STATe\]](#). To enable digital channels for buses 2, 3 and 4, use the [PBUS<pb>:BIT<n>\[:STATe\]](#) command.

Suffix:

<m> 0 to 15, index of the logic channel

Parameters:

<State> OFF | ON

Usage:

Asynchronous command

DIGital<m>:TECHnology <Technology>

Selects the threshold voltage for various types of integrated circuits and applies it to all digital channels.

The setting affects only the settings of the first MSO bus (Logic1).

You can set the technology value for all buses with [PBUS<pb>:TECHnology](#).

Suffix:

<m> 0..15
The suffix is irrelevant.

Parameters:

<Technology> V15 | V25 | V165 | V125 | V09 | VM13 | V38 | V20 | V0 | MANual
See [PBUS<pb>:TECHnology](#).

Usage:

Asynchronous command

DIGital<m>:THCoupling <State>

Sets the threshold and the hysteresis for all digital channels of Logic1 to the same value.

Suffix:

<m> Irrelevant, omit the suffix.

Parameters:

<State> OFF | ON

Usage:

Asynchronous command

DIGital<m>:THReshold <Value>

Sets the logical threshold for the channel group to which the indicated digital channel belongs.

The setting affects only the settings of the first MSO bus (Logic1).

You can set the threshold for all buses with [PBUS<pb>:TECHnology](#) or [PBUS<pb>:THReshold<n>](#)

See also: [DIGital<m>:THCoupling](#) on page 1840

Suffix:

<m> 0..15
Number of the digital channel.
Channel groups: 0..3; 4..7; 8..11; 12..15

Parameters:

<Value>

Usage:

Asynchronous command

18.19.2 Logic configuration

The following commands configure the four logic groups (parallel buses).

PBUS<pb>:BIT<n>:LABel	1841
PBUS<pb>:BIT<n>:SKEW	1841
PBUS<pb>:BIT<n>[:STATe]	1842
PBUS<pb>:CLEar	1842
PBUS<pb>:CLOCK	1842
PBUS<pb>:CLON	1842
PBUS<pb>:CLSLope	1843
PBUS<pb>:DECTable:SHOW	1843
PBUS<pb>:DECTable:COUNt?	1843
PBUS<pb>:DECTable:DATA?	1844
PBUS<pb>:DIGSignals:POSition	1844
PBUS<pb>:DIGSignals:SCALe	1844
PBUS<pb>:DISPlay:SHBU	1844
PBUS<pb>:DISPlay:SHDI	1845

PBUS<pb>:HYSTeresis<n>.....	1845
PBUS<pb>:POSition.....	1846
PBUS<pb>:SCALe.....	1846
PBUS<pb>:SKEW.....	1846
PBUS<pb>:STATe.....	1847
PBUS<pb>:TECHnology.....	1847
PBUS<pb>:THCoupling.....	1847
PBUS<pb>:THReshold<n>.....	1848

PBUS<pb>:BIT<n>:LABel <Label>

Sets a name for the indicated digital channel. The name is displayed in the diagram.

Suffix:

<pb>	1 to 4, index of the logic group
<n>	0..15 Selects the bit of the bus word. Each bit corresponds to a digital channel.

Parameters:

<Label>	String containing the channel name

Usage: Asynchronous command

PBUS<pb>:BIT<n>:SKEW <Skew>

Sets an individual delay for each digital channel to time-align it with other digital channels.

The skew value compensates delays that are known from the circuit specifics or caused by the different length of cables. The skew between the probe boxes of the digital channels and the probe connectors of the analog channels is automatically aligned by the instrument.

Suffix:

<pb>	1 to 4, index of the logic group
<n>	0..15 Selects the bit of the bus word. Each bit corresponds to a digital channel.

Parameters:

<Skew>	Range: -2E-07 to 2E-07 Increment: 2E-10 *RST: 0 Default unit: s

Usage: Asynchronous command

Manual operation: See "D0-D15" on page 857

PBUS<pb>:BIT<n>[:STATe] <Assigned>

Enables the selected logic group. The corresponding signal icon appears on the signal bar.

If another active bus already uses the selected digital channel, the instrument disables the other bus to avoid conflicts.

Suffix:

<pb> 1 to 4, index of the logic group

<n> 0..15

Selects the bit of the bus word. Each bit corresponds to a digital channel.

Parameters:

<Assigned> OFF | ON

*RST: OFF

Usage: Asynchronous command

PBUS<pb>:CLEAr

Removes all assigned digital channels from the bus.

Suffix:

<pb> 1 to 4, index of the logic group

Usage: Setting only
Asynchronous command

PBUS<pb>:CLOCK <ClockSource>

Selects the digital channel used as clock.

Suffix:

<pb> 1 to 4, index of the logic group

Parameters:

<ClockSource> D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 | D8 | D9 | D10 | D11 | D12 | D13 | D14 | D15

Clock channel

*RST: D0

Usage: Asynchronous command

Manual operation: See ["Clock source"](#) on page 855

PBUS<pb>:CLON <Clocked>

Defines if the bus is a clocked bus - one of the digital channels serves as the clock of the bus.

Suffix:
 <pb> 1 to 4, index of the logic group

Parameters:
 <Clocked> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Bus clocked"](#) on page 855

PBUS<pb>:CLSLope <ClockSlope>

Selects the slope of the clock signal at which all digital channels of the bus are analyzed.

Suffix:
 <pb> 1 to 4, index of the logic group

Parameters:
 <ClockSlope> POSitive | NEGative | EITHer
 *RST: POSitive

Usage: Asynchronous command

Manual operation: See ["Clock slope"](#) on page 855

PBUS<pb>:DECTable:SHOW <DecodeTable>

If enabled, a result table is shown with decoded values and corresponding points in time of the bus signal. Each clock edge corresponds to one row in the table.

The decode table is only available for clocked buses to check the data words.

Suffix:
 <pb> 1 to 4, index of the logic group

Parameters:
 <DecodeTable> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Show decode table"](#) on page 855

PBUS<pb>:DECTable:COUNT?

Returns the number of rows in the decode table. Each clock edge corresponds to one row in the table. The decode table is only available for clocked buses.

Suffix:
 <pb> 1 to 4, index of the logic group

Return values:
 <Count> Number of rows

Usage: Query only
Asynchronous command

Manual operation: See ["Show decode table"](#) on page 855

PBUS<pb>:DECTable:DATA?

Returns a list of decoded values and corresponding points in time from the decode table. Each data pair corresponds to one clock edge, which is one row in the table. The decode table is only available for clocked buses.

Suffix:
<pb> 1 to 4, index of the logic group

Return values:
<Data> Comma-separated list of values

Usage: Query only
Asynchronous command

Manual operation: See ["Show decode table"](#) on page 855

PBUS<pb>:DIGSignals:POSition <DigChanPosition>

Sets the vertical position of all active digital channels.

Suffix:
<pb> 1 to 4, index of the logic group

Parameters:
<DigChanPosition> Range: 0 to 4294967295
Increment: 1
*RST: 0

Usage: Asynchronous command

PBUS<pb>:DIGSignals:SCALE <RelativeHeight>

Sets the size of the display that is used by each active digital signal.

Suffix:
<pb> 1 to 4, index of the logic group

Parameters:
<RelativeHeight> Range: 2 to 100
Increment: 0.5
*RST: 6.25
Default unit: %

Usage: Asynchronous command

PBUS<pb>:DISPlay:SHBU <ShowBus>

If enabled, the resulting bus signal and bus values are displayed in the diagram.

Suffix:
 <pb> 1 to 4, index of the logic group

Parameters:
 <ShowBus> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Show bus"](#) on page 854

PBUS<pb>:DISPlay:SHDI <ShwDigSigns>

If enabled, the selected digital channels are shown in the diagram. Each channel is displayed as a logic signal.

Suffix:
 <pb> 1 to 4, index of the logic group

Parameters:
 <ShwDigSigns> OFF | ON
 *RST: OFF

Usage: Asynchronous command

Manual operation: See ["Show dig. signals"](#) on page 852

PBUS<pb>:HYSTeresis<n> <Hysteresis>

Defines the size of the hysteresis for the respective channels.

Suffix:
 <pb> 1 to 4, index of the logic group
 <n> 1..4
 Selects the channel group:
 1 = digital channels 0..3
 2 = digital channels 4..7
 3 = digital channels 8..11
 4 = digital channels 12..15

Parameters:
 <Hysteresis> MAXimum | ROBust | NORMal

MAXIMUM = MAXimum
 Maximum value that is possible and useful for the signal and its settings (corresponds to "Medium" in the GUI).

ROBUST = ROBust
 Different hysteresis values for falling and rising edges to avoid an undefined state of the trigger system (corresponds to "Large" in the GUI).

NORMAL = NORMal
 The instrument sets a value suitable for the signal and its settings (corresponds to "Small" in the GUI).

Usage: Asynchronous command

Manual operation: See "[Hysteresis](#)" on page 854

PBUS<pb>:POSition <YPosition>

Sets the position of the indicated logic group waveform.

Suffix:

<pb> 1 to 4, index of the logic group

Parameters:

<YPosition> Range: 0 to 100
Increment: 0.1
*RST: 50
Default unit: %

Usage: Asynchronous command

PBUS<pb>:SCALE <RelativeHeight>

Sets the size of the display that is used by the indicated logic group waveform.

Suffix:

<pb> 1 to 4, index of the logic group

Parameters:

<RelativeHeight> Range: 3 to 100
Increment: 0.5
*RST: 10
Default unit: %

Usage: Asynchronous command

PBUS<pb>:SKEW <SkewOffset>

Sets a general delay for all digital channels.

Suffix:

<pb> 1 to 4, index of the logic group

Parameters:

<SkewOffset> Range: -2E-07 to 2E-07
Increment: 2E-10
*RST: 0
Default unit: s

Usage: Asynchronous command

Manual operation: See "[Skew](#)" on page 857

PBUS<pb>:STaTe <State>

Enables the selected logic group. The corresponding signal icon appears on the signal bar.

Dependencies: At least one digital channel must be enabled for the selected bus, otherwise the command does not work.

The bus is enabled automatically if the first digital channel is enabled with [PBUS<pb>:BIT<n>\[:STaTe\]](#).

Suffix:

<pb> 1 to 4, index of the logic group

Parameters:

<State> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["State"](#) on page 852

PBUS<pb>:TECHnology <Technology>

Selects the threshold voltage for various types of integrated circuits and applies it to all digital channels.

Suffix:

<pb> 1 to 4, index of the logic group

Parameters:

<Technology> V15 | V25 | V165 | V125 | V09 | VM13 | V38 | V20 | V0 | MANual
V15: TTL
V25: CMOS 5.0 V
V165: CMOS 3.3 V
V125: CMOS 2.5 V
V09: CMOS 1.85 V
VM13: ECL, -1.3 V
V38: PECL
V20: LVPECL
V0: Ground
MANual: Set a user-defined threshold value with [DIGital<m>:THReshold](#) on page 1840.
*RST: V165

Usage: Asynchronous command

Manual operation: See ["Technology, Threshold"](#) on page 853

PBUS<pb>:THCoupling <LevelCoupling>

Sets the threshold and the hysteresis for all digital channels and all buses to the same value.

For Logic 1, the command `DIGital<m>:THCoupling` has the same effect.

Suffix:

<pb> 1 to 4, index of the logic group

Parameters:

<LevelCoupling> OFF | ON
*RST: ON

Usage: Asynchronous command

Manual operation: See "[Level coupling](#)" on page 853

PBUS<pb>:THReshold<n> <Threshold>

Sets the logical threshold for the indicated channel group.

Alternatively you can use the following commands:

- To select from a list of predefined technologies: `PBUS<pb>:TECHnology`
- For logic 1: `DIGital<m>:THReshold`

See also `DIGital<m>:THCoupling` on page 1840.

Suffix:

<pb> 1 to 4, index of the logic group

<n> 1..4
Selects the channel group:
1 = digital channels 0..3;
2 = digital channels 4..7
3 = digital channels 8..11
4 = digital channels 12..15

Parameters:

<Threshold> Range: -8 to 8
Increment: 0.025
*RST: 0
Default unit: V

Usage: Asynchronous command

Manual operation: See "[Technology, Threshold](#)" on page 853

18.19.3 Digital resolution

ACQuire:DRESolution?

Returns the current digital resolution of the digital channels.

Return values:

<DigRes> Range: 1E-15 to 100
 Increment: 1E-11
 *RST: 0.0005
 Default unit: s

Usage:

Query only
 Asynchronous command

ACQuire:POINts:DVALue?

Returns the current digital record length used by each digital channel.

Return values:

<DigReclgth> Range: 1000 to 200000000
 Increment: 2
 *RST: 1000
 Default unit: pts

Usage:

Query only
 Asynchronous command

18.19.4 Export of digital data

The remote data transfer from the instrument to the controlling computer is performed using the following commands:

For fast export of several waveforms at once, use [EXPort:WAVEform:DATA\[:VALues\]?](#) on page 1109.

DIGital<m>:DATA:HEADer?	1849
DIGital<m>:DATA[:VALues]?.....	1850
PBUS<pb>:DATA:FORMat.....	1850
PBUS<pb>:DATA:HEADer?.....	1851
PBUS<pb>:DATA[:VALues]?.....	1851

DIGital<m>:DATA:HEADer?

Returns the header of digital channel data, the attributes of the waveform.

Suffix:

<m> 0 to 15, index of the logic channel

Return values:

<XStart> 1. header value: time of the first sample in s
 <XStop> 2. header value: time of the last sample in s
 <RecordLength> 3. header value: record length of the waveform in samples
 <ValuesPerSample> 4. header value: number of values per sample. For digital data, the result is always 1.

Example: DIG3:DATA:HEAD?
 -1E-07,9.9800000000000001E-08,1000,1
 Start time of the data is -1E-07 = -100 ns, and end time of the data is 9.9800000000000001E-08= 99.8 ns. The data stream has 1000 values with one value per sample.

Usage: Query only
 Asynchronous command

DIGital<m>:DATA[:VALues]? [<Offset>[,<Length>]]

Returns the data of the indicated digital channel for transmission from the instrument to the controlling computer. The data can be used in MATLAB, for example.

Without parameters, the complete waveform is retrieved. Using the offset and length parameters, data can be retrieved in smaller portions, which makes the command faster. If you send only one parameter, it is interpreted as offset, and the data is retrieved from offset to the end of the waveform.

Suffix:
 <m> 0..15
 Selects the digital channel.

Query parameters:
 <Offset> Number of offset values, which are ignored in the data transfer.
 <Length> Number of values to be retrieved.

Return values:
 <Data> List of values according to the format and content settings.

Usage: Query only
 Asynchronous command

PBUS<pb>:DATA:FORMat <DataFormat>

Sets the data format of bus values, which are displayed in the decode table and on the comb bus display.

It also sets the format for the number representation for remote data transfer with [PBUS<pb>:DATA\[:VALues\]?](#).

Suffix:
 <pb> 1 to 4, index of the logic group

Parameters:
 <DataFormat> HEX | OCT | BIN | ASCII | ASCii | SIGN | USIG
 *RST: HEX

Usage: Asynchronous command

Manual operation: See ["Data format"](#) on page 854

PBUS<pb>:DATA:HEADer?

Returns the header data of the indicated bus, the attributes of the data.

See also [DIGital<m>:DATA:HEADer?](#).

Suffix:

<pb> 1 to 4, index of the logic group

Return values:

<XStart> 1. header value: time of the first sample in s
 <XStop> 2. header value: time of the last sample in s
 <RecordLength> 3. header value: record length of the waveform in samples
 <ValuesPerSample> 4. header value: number of values per sample. For digital data, the result is always 1.

Usage:

Query only
 Asynchronous command

Manual operation: See ["Data format"](#) on page 854

PBUS<pb>:DATA[:VALues]? [<Offset>[,<Length>]]

Returns the data of the indicated logic.

Without parameters, the complete waveform is retrieved. Using the offset and length parameters, data can be retrieved in smaller portions, which makes the command faster. If you send only one parameter, it is interpreted as offset, and the data is retrieved from offset to the end of the waveform.

Requirements:

- [PBUS<pb>:STATe](#) is set to ON.
- [PBUS<pb>:DISPlay:SHBU](#) is set to ON.
- A number format is set with [PBUS<pb>:DATA:FORMat](#).

Suffix:

<pb> 1 to 4, index of the logic group

Query parameters:

<Offset> Number of offset waveform points to be skipped.
 Range: 0 to m. Limit: $n + m \leq \text{record length}$
 <Length> Number of waveform points to be retrieved.
 Range: 1 to n. Limit: $n + m \leq \text{record length}$

Return values:

<Data> List of values according to the format and content settings.

Waveform generator (option R&S MXO5C-B6)

Example:	<pre>PBUS:STAT ON PBUS:DISP:SHBU ON PBUS:DISP:BTYP COMB PBUS:DATA:FORMat HEX PBUS:DATA:VAL?</pre>
Usage:	Query only Asynchronous command
Manual operation:	See "Data format" on page 854

18.20 Waveform generator (option R&S MXO5C-B6)

This section describes the remote commands of the waveform generator.

The instrument preset does not affect the generator settings. Each generator has its own preset: `WGENerator<wg>:PRESet`.

Some of the commands in the following section are asynchronous. An overlapping or asynchronous command does not automatically finish executing before the next command starts executing. If overlapping commands must be executed in a defined order, e.g. to avoid wrong measurement results, they must be serviced sequentially.

To prevent an overlapping execution of commands, one of the commands `*OPC`, `*OPC?` or `*WAI` can be used after the command or a command set.

For more information, see:

- www.rohde-schwarz.com/rc-via-scp, section "Command sequence and synchronization"

18.20.1 Waveform generator setup

18.20.1.1 General settings

<code>WGENerator<wg>:FREQuency</code>	1853
<code>WGENerator<wg>:FUNCTion:PULSe[:WIDTh]</code>	1853
<code>WGENerator<wg>:FUNCTion:RAMP[:SYMMetry]</code>	1853
<code>WGENerator<wg>:FUNCTion[:SElect]</code>	1854
<code>WGENerator<wg>:FUNCTion[:SQUare]:DCYCLE</code>	1854
<code>WGENerator<wg>:OUTPut[:LOAD]</code>	1854
<code>WGENerator<wg>:PERiod</code>	1855
<code>WGENerator<wg>:PRESet</code>	1855
<code>WGENerator<wg>:SOURce</code>	1855
<code>WGENerator<wg>:VOLTage:DCLevel</code>	1856
<code>WGENerator<wg>:VOLTage:HIGH</code>	1856
<code>WGENerator<wg>:VOLTage:INVersion</code>	1856
<code>WGENerator<wg>:VOLTage:LOW</code>	1857

WGENerator<wg>:VOLTage:OFFSet.....	1857
WGENerator<wg>:VOLTage[:VPP].....	1857
WGENerator<wg>[:ENABLE].....	1858

WGENerator<wg>:FREQuency <Frequency>

Sets the frequency of the waveform.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<Frequency> Range: 0.001 to 100E+6 or lower, depending on the function type.
 Increment: 0.001
 *RST: 10E+6
 Default unit: Hz

Usage: Asynchronous command

Manual operation: See "Frequency" on page 861

WGENerator<wg>:FUNctioN:PULSe[:WIDTh] <PulseWidth>

Sets the pulse width, the pulse duration of the generated pulse waveform.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<PulseWidth> Range: 1.65E-08 to 90000
 Increment: 1
 *RST: 5E-07
 Default unit: s

Usage: Asynchronous command

Manual operation: See "Pulse width" on page 863

WGENerator<wg>:FUNctioN:RAMP[:SYMMetry] <RampSymmetry>

Sets the symmetry of a ramp waveform, the percentage of time the waveform is rising. By changing the symmetry of the ramp, you can create, for example, triangular waveforms.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<RampSymmetry> Range: 0 to 100
 Increment: 1
 *RST: 50
 Default unit: %

Usage: Asynchronous command
Manual operation: See ["Symmetry"](#) on page 862

WGENerator<wg>:FUNCTION[:SElect] <FunctionType>

Selects the type of waveform to be generated.

Suffix:
 <wg> 1 | 2, index of the waveform generator

Parameters:
 <FunctionType> SINusoid | SQUare | RAMP | DC | PULSe | SINC | CARDiac | GAUSs | LORNtz | HAVer | EXPRise | EXPFall | ARBitrary

SINC: cardinal sine
 HAVer: haversine (great-circle distance between two points on a sphere)
 *RST: SINusoid

Usage: Asynchronous command
Manual operation: See ["Function type"](#) on page 860

WGENerator<wg>:FUNCTION[:SQUare]:DCYCLE <SquareDutyCycle>

Sets the duty cycle for the pulse function.

Suffix:
 <wg> 1 | 2, index of the waveform generator

Parameters:
 <SquareDutyCycle> Range: 0.01 to 99.99
 Increment: 1
 *RST: 50
 Default unit: %

Usage: Asynchronous command
Manual operation: See ["Duty cycle"](#) on page 863

WGENerator<wg>:OUTPut[:LOAD] <Load>

Select the user load, the load of the DUT at its connection.

Suffix:
 <wg> 1 | 2, index of the waveform generator

Parameters:
 <Load> FIFTy | HIZ

FIFTy: 50Ω
 HIZ: High-Z (high input impedance)
 *RST: HIZ

Usage: Asynchronous command
Manual operation: See ["User load"](#) on page 862

WGENerator<wg>:PERiod <Period>

Sets the period of the pulse waveform, if `WGENerator<wg>:FUNCTION[:SElect]` is set to `PULSe`.

Suffix:
 <wg> 1 | 2, index of the waveform generator

Parameters:
 <Period> Range: 1E-08 to 1000
 Increment: 1
 *RST: 1E-06
 Default unit: s

Usage: Asynchronous command
Manual operation: See ["Period"](#) on page 863

WGENerator<wg>:PRESet

Presets the generator to a default setup. The default includes the following settings:

- "Function type" = "Sine"
- "Frequency" = "1 MHz"
- "Amplitude" = "1 Vpp"

Suffix:
 <wg> 1 | 2, index of the waveform generator

Usage: Setting only
 Asynchronous command

Manual operation: See ["Default setup"](#) on page 863

WGENerator<wg>:SOURce <OperationMode>

Selects the operation mode of the waveform generator-

Suffix:
 <wg> 1 | 2, index of the waveform generator

Parameters:
 <OperationMode> FUNCgen | MODulation | SWEep | ARBGenerator

FUNCgen

Enables the function generator and disables modulation, sweep, and arbitrary waveforms

MODulation

Enables the modulation, disables sweep and selects the sine function.

Waveform generator (option R&S MXO5C-B6)

SWEEp

Enables the sweep, disables modulation, and selects the sine function.

ARBGenerator

Selects the arbitrary function and disables modulation and sweep.

*RST: FUNCgen

Usage: Asynchronous command

WGENerator<wg>:VOLTage:DCLevel <DCLevel>

Sets the level for the DC signal, if **WGENerator<wg>:FUNCTION[:SElect]** is set to DC.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<DCLevel> Range: -5 to 5
Increment: 0.01
*RST: 0
Default unit: V

Usage: Asynchronous command

Manual operation: See "DC level" on page 863

WGENerator<wg>:VOLTage:HIGh <High>

Sets the high signal level of the output waveform.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<High> Range: -5.99 to 6
Increment: 0.1
*RST: 0.5
Default unit: V

Usage: Asynchronous command

WGENerator<wg>:VOLTage:INVersion <Inversion>

Inverts the waveform at the offset level.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<Inversion> OFF | ON
*RST: OFF

Usage: Asynchronous command
Manual operation: See ["Inversion"](#) on page 860

WGENerator<wg>:VOLTage:LOW <Low>

Sets the low signal level of the output waveform.

Suffix:
 <wg> 1 | 2, index of the waveform generator

Parameters:
 <Low> Range: -6 to 5.99
 Increment: 0.1
 *RST: -0.5
 Default unit: V

Usage: Asynchronous command

WGENerator<wg>:VOLTage:OFFSet <Offset>

Sets the vertical offset of the generated waveform.

Suffix:
 <wg> 1 | 2, index of the waveform generator

Parameters:
 <Offset> Range: -5.995 to 5.995
 Increment: 0.01
 *RST: 0
 Default unit: V

Usage: Asynchronous command

Manual operation: See ["Offset"](#) on page 862

WGENerator<wg>:VOLTage[:VPP] <Amplitude>

Sets the amplitude of the waveform.

Suffix:
 <wg> 1 | 2, index of the waveform generator

Parameters:
 <Amplitude> Range: 0.01 to 12
 Increment: 0.01
 *RST: 0.4
 Default unit: Vpp

Usage: Asynchronous command

Manual operation: See ["Amplitude"](#) on page 862

WGENerator<wg>[:ENABle] <State>

Enables the function generator.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<State> OFF | ON

*RST: No effect

Usage: Asynchronous command

Manual operation: See "State" on page 860

18.20.1.2 Modulation settings

WGENerator<wg>:MODulation[:STATe].....	1858
WGENerator<wg>:MODulation:AM:DCYCLE.....	1859
WGENerator<wg>:MODulation:AM:DEPTTh.....	1859
WGENerator<wg>:MODulation:AM:FREQuency.....	1859
WGENerator<wg>:MODulation:AM:SYMMetry.....	1860
WGENerator<wg>:MODulation:AM[:FUNCTioN].....	1860
WGENerator<wg>:MODulation:CARRier:FREQuency.....	1860
WGENerator<wg>:MODulation:CARRier:PERiod.....	1860
WGENerator<wg>:MODulation:FM:DCYCLE.....	1861
WGENerator<wg>:MODulation:FM:DEViation.....	1861
WGENerator<wg>:MODulation:FM:FREQuency.....	1861
WGENerator<wg>:MODulation:FM:SYMMetry.....	1862
WGENerator<wg>:MODulation:FM[:FUNCTioN].....	1862
WGENerator<wg>:MODulation:FSK:FONE.....	1862
WGENerator<wg>:MODulation:FSK:FTWO.....	1862
WGENerator<wg>:MODulation:FSK[:RATE].....	1863
WGENerator<wg>:MODulation:NDCLevel.....	1863
WGENerator<wg>:MODulation:NLPCent.....	1863
WGENerator<wg>:MODulation:PWM:DCYCLE.....	1864
WGENerator<wg>:MODulation:PWM:DEPTTh.....	1864
WGENerator<wg>:MODulation:PWM:FREQuency.....	1864
WGENerator<wg>:MODulation:PWM:SYMMetry.....	1865
WGENerator<wg>:MODulation:PWM[:FUNCTioN].....	1865
WGENerator<wg>:MODulation:TYPE.....	1865

WGENerator<wg>:MODulation[:STATe] <Modulation>

Enables or disables modulation.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<Modulation> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Modulation state"](#) on page 864

WGENerator<wg>:MODulation:AM:DCYCLE <SquareDutyCycle>

Sets the duty cycle for a square waveform. The duty cycle expresses for what percentage fraction of the period, the waveform is active, i.e. the signal state is high.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<SquareDutyCycle> Range: 10 to 90
Increment: 1
*RST: 50
Default unit: %

Usage: Asynchronous command

Manual operation: See ["Duty cycle"](#) on page 865

WGENerator<wg>:MODulation:AM:DEPTH <Depth>

Sets the modulation depth, the percentage of the amplitude range that is used for AM modulation.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<Depth> Range: 0 to 100
Increment: 1
*RST: 50
Default unit: %

Usage: Asynchronous command

Manual operation: See ["Depth"](#) on page 865

WGENerator<wg>:MODulation:AM:FREQUENCY <Frequency>

Sets the frequency of the modulation waveform for AM frequency modulation.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<Frequency> Range: 0.001 to 1000000
Increment: 0.001
*RST: 1000
Default unit: Hz

Usage: Asynchronous command

Manual operation: See ["Frequency"](#) on page 865

WGENerator<wg>:MODulation:AM:SYMMetry <RampSymmetry>

Sets the symmetry for the AM ramp modulation waveform, the percentage of time that the waveform is rising.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<RampSymmetry> Range: 0 to 100
Increment: 1
*RST: 50
Default unit: %

Usage: Asynchronous command

Manual operation: See ["Symmetry"](#) on page 865

WGENerator<wg>:MODulation:AM[:FUNCTION] <SignalType>

Selects the type of the modulating signal for AM modulation.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<SignalType> SINusoid | SQUare | RAMP
*RST: SINusoid

Usage: Asynchronous command

Manual operation: See ["Signal type"](#) on page 865

WGENerator<wg>:MODulation:CARRier:FREQuency <FreqCarrierAlias>

Sets the frequency of the carrier signal for a modulation waveform.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<FreqCarrierAlias> Range: 0.001 to 100000000
Increment: 0.001
*RST: 1000000
Default unit: Hz

Usage: Asynchronous command

WGENerator<wg>:MODulation:CARRier:PERiod <PeriodCarrierAlias>

Sets the period of the carrier signal for a modulation waveform.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<PeriodCarrierAlias> Range: 1E-08 to 1000
 Increment: 1
 *RST: 1E-06
 Default unit: s

Usage:

Asynchronous command

WGENerator<wg>:MODulation:FM:DCYcle <SquareDutyCycle>

Sets the duty cycle for a square waveform. The duty cycle expresses for what percentage fraction of the period, the waveform is active, i.e. the signal state is high.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<SquareDutyCycle> Range: 10 to 90
 Increment: 1
 *RST: 50
 Default unit: %

Usage:

Asynchronous command

Manual operation: See ["Duty cycle"](#) on page 865

WGENerator<wg>:MODulation:FM:DEVIation <Deviation>

Sets the frequency deviation, the maximum difference between the FM modulated signal and the carrier signal.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<Deviation> Range: 0.001 to 10000000
 Increment: 1
 *RST: 1000
 Default unit: Hz

Usage:

Asynchronous command

Manual operation: See ["Deviation"](#) on page 865

WGENerator<wg>:MODulation:FM:FREquency <Frequency>

Sets the frequency of the modulating waveform for FM modulation.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<Frequency> Range: 0.001 to 1000000
 Increment: 0.001
 *RST: 1000
 Default unit: Hz

Usage: Asynchronous command

Manual operation: See ["Frequency"](#) on page 865

WGENerator<wg>:MODulation:FM:SYMMetry <RampSymmetry>

Sets the symmetry for the FM ramp modulation waveform, the percentage of time that the waveform is rising.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<RampSymmetry> Range: 0 to 100
 Increment: 1
 *RST: 50
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Symmetry"](#) on page 865

WGENerator<wg>:MODulation:FM[:FUNCTION] <SignalType>

Selects the type of the modulating signal for FM modulation.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<SignalType> SINusoid | SQUare | RAMP
 *RST: SINusoid

Usage: Asynchronous command

Manual operation: See ["Signal type"](#) on page 865

WGENerator<wg>:MODulation:FSK:FONE <Frequency1>**WGENerator<wg>:MODulation:FSK:FTWO <Frequency2>**

Sets the frequency of the first /second signal in FSK modulated signal.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<Frequency2> Range: 0.001 to 100E+6
 Increment: 1
 *RST: 1000
 Default unit: Hz

Usage: Asynchronous command

Manual operation: See "Frequency 1/Frequency 2" on page 866

WGENerator<wg>:MODulation:FSK[:RATE] <Rate>

Sets the frequency at which the signal switches between [WGENerator<wg>:MODulation:FSK:FONE](#) and [WGENerator<wg>:MODulation:FSK:FTWO](#).

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<Rate> Range: 0.001 to 1000000
 Increment: 1
 *RST: 1000
 Default unit: Hz

Usage: Asynchronous command

Manual operation: See "FSK rate" on page 866

WGENerator<wg>:MODulation:NDCLevel <LevelDC>

Sets the DC noise level, if [WGENerator<wg>:FUNCTION\[:SElect\]](#) is set to DC.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<LevelDC> Range: 0 to 10
 Increment: 0.01
 *RST: 0
 Default unit: Vpp

Usage: Asynchronous command

Manual operation: See "Noise level for DC" on page 863

WGENerator<wg>:MODulation:NLPCent <LevelPct>

Sets the level of the noise in percentage of the set "Amplitude" output of the signal.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<LevelPct> Range: 0 to 100
 Increment: 0.1
 *RST: 0
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Noise level in %"](#) on page 862

WGENerator<wg>:MODulation:PWM:DCYcle <SquareDutyCycle>

Sets the duty cycle for a square waveform. The duty cycle expresses for what percentage fraction of the period, the waveform is active, i.e. the signal state is high.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<SquareDutyCycle> Range: 10 to 90
 Increment: 1
 *RST: 50
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Duty cycle"](#) on page 865

WGENerator<wg>:MODulation:PWM:DEPTth <Depth>

Sets the modulation depth, the percentage of the amplitude range that is used for PWM modulation.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<Depth> Range: 0 to 100
 Increment: 1
 *RST: 50
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Modulation depth"](#) on page 865

WGENerator<wg>:MODulation:PWM:FREQuency <Frequency>

Sets the frequency of the modulating waveform for PWM modulation.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<Frequency> Range: 0.001 to 1000000
 Increment: 0.001
 *RST: 1000
 Default unit: Hz

Usage: Asynchronous command

Manual operation: See ["Frequency"](#) on page 865

WGENerator<wg>:MODulation:PWM:SYMMetry <RampSymmetry>

Sets the symmetry for the PWM ramp modulation waveform, the percentage of time that the waveform is rising.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<RampSymmetry> Range: 0 to 100
 Increment: 1
 *RST: 50
 Default unit: %

Usage: Asynchronous command

Manual operation: See ["Symmetry"](#) on page 865

WGENerator<wg>:MODulation:PWM[:FUNCTION] <SignalType>

Selects the type of the modulating signal for PWM modulation.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<SignalType> SINusoid | SQUare | RAMP
 *RST: SINusoid

Usage: Asynchronous command

Manual operation: See ["Signal type"](#) on page 865

WGENerator<wg>:MODulation:TYPE <ModulationType>

Selects the modulation type, which defines how the carrier signal is modified.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<ModulationType> NONE | AM | FM | PWM | ASK | FSK
 *RST: AM

Usage: Asynchronous command

Manual operation: See ["Modulation type"](#) on page 864

18.20.1.3 ARB settings

WGENerator<wg>:ARBGen:NAME.....	1866
WGENerator<wg>:ARBGen:OPEN.....	1866
WGENerator<wg>:ARBGen:RUNMode.....	1866
WGENerator<wg>:ARBGen:RUNSingle.....	1867
WGENerator<wg>:ARBGen:SAMPles?.....	1867
WGENerator<wg>:ARBGen:SRATe.....	1867
WGENerator<wg>:ARBGen[:SOURce].....	1868

WGENerator<wg>:ARBGen:NAME <Folder>

Sets the file path and the file for an arbitrary waveform, if [WGENerator<wg>:ARBGen\[:SOURce\]](#) is set to [ARBiTrary](#).

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<Folder>

Usage: Asynchronous command

Manual operation: See ["Open"](#) on page 870

WGENerator<wg>:ARBGen:OPEN

Loads the arbitrary waveform, which is selected with the [WGENerator<wg>:ARBGen:NAME](#) command.

Suffix:

<wg> 1 | 2, index of the waveform generator

Usage: Event
Asynchronous command

Manual operation: See ["Open"](#) on page 870

WGENerator<wg>:ARBGen:RUNMode <RunMode>

Sets the duration for which the signal of the arbitrary generator will be output after the trigger event.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<RunMode> SINGle | REPetitive
*RST: REPetitive

Usage: Asynchronous command

Manual operation: See ["Run mode"](#) on page 869

WGENerator<wg>:ARBGen:RUNSingle

Executes a single period of the arbitrary signal generator, if [WGENerator<wg>:ARBGen:RUNMode](#) is set to `SINGLE`.

Suffix:

<wg> 1 | 2, index of the waveform generator

Usage: Event
Asynchronous command

Manual operation: See ["Run single"](#) on page 869

WGENerator<wg>:ARBGen:SAMPles?

Returns the number of samples in the loaded waveform.

Suffix:

<wg> 1 | 2, index of the waveform generator

Return values:

<NumSamples> Range: 0 to 128E+6
Increment: 10
*RST: 0
Default unit: pts

Usage: Query only
Asynchronous command

Manual operation: See ["Number of samples"](#) on page 870

WGENerator<wg>:ARBGen:SRATe <SampleRate>

Sets the sample rate for the arbitrary waveform.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<SampleRate> Range: 1 to 312500000
Increment: 10
*RST: 1000000
Default unit: Sa/s

Usage: Asynchronous command

Manual operation: See ["Sample rate"](#) on page 870

WGENerator<wg>:ARBGen[:SOURce] <WaveformSource>

Selects the source of the arbitrary waveform.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<WaveformSource> ARbitrary
*RST: ARbitrary

Usage: Asynchronous command

Manual operation: See ["Arb wfm source"](#) on page 870

18.20.1.4 Sweep settings

WGENerator<wg>:SWEep[:STATe]	1868
WGENerator<wg>:SWEep:TYPE	1868
WGENerator<wg>:SWEep:FSTart	1869
WGENerator<wg>:SWEep:TIME	1869
WGENerator<wg>:SWEep:FEND	1869

WGENerator<wg>:SWEep[:STATe] <Sweep>

Enables or disables the sweeping.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<Sweep> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Sweep state"](#) on page 866

WGENerator<wg>:SWEep:TYPE <Type>

Sets the type of the sweep, a linear or logarithmic change of the frequency.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<Type> LIN | LOG
*RST: LIN

Usage: Asynchronous command

Manual operation: See ["Sweep type"](#) on page 867

WGENerator<wg>:SWEep:FStart <StartFrequency>

Sets the start frequency of the sweep signal.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<StartFrequency> Range: 0.001 to 100E+6
Increment: 0.001
*RST: 1000
Default unit: Hz

Usage: Asynchronous command

Manual operation: See ["Start frequency"](#) on page 867

WGENerator<wg>:SWEep:TIME <Time>

Sets the duration of the sweep.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<Time> Range: 0.001 to 500
Increment: 1
*RST: 0.001
Default unit: s

Usage: Asynchronous command

Manual operation: See ["Sweep time"](#) on page 867

WGENerator<wg>:SWEep:FEND <StopFrequency>

Sets the stop frequency of the sweep signal.

Suffix:

<wg> 1 | 2, index of the waveform generator

Parameters:

<StopFrequency> Range: 0.001 to 100E+6
Increment: 0.001
*RST: 1000000
Default unit: Hz

Usage: Asynchronous command

Manual operation: See ["Stop frequency"](#) on page 867

18.20.2 Synchronize settings

WGENerator<wg>:COUPling:ALL.....	1870
WGENerator<wg>:COUPling:STATe.....	1870
WGENerator<wg>:COUPling:AMPLitude.....	1870
WGENerator<wg>:COUPling:PHASeshift.....	1871
WGENerator<wg>:COUPling[:FREQuency].....	1871
GENerator:SYNC[:COMBination].....	1871

WGENerator<wg>:COUPling:ALL <CoupleAll>

Enables the coupling of the generators, with the selected set of parameters: enabling, amplitude and frequency.

Suffix:

<wg> 1..2
Specifies the primary generator.

Parameters:

<CoupleAll> OFF | ON
*RST: OFF

Usage: Asynchronous command

WGENerator<wg>:COUPling:STATe <CoupleEnable>

Enables the coupling of the generators with the selected set of parameters: amplitude and frequency.

Suffix:

<wg> 1..2
Specifies the prime generator.

Parameters:

<CoupleEnable> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See "[Generator enable](#)" on page 871

WGENerator<wg>:COUPling:AMPLitude <CplAmplitude>

Enables the coupling of all amplitude parameters of the generators.

Suffix:

<wg> 1..2
Specifies the prime generator.

Parameters:

<CplAmplitude> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Frequency parameters"](#) on page 871

WGENerator<wg>:COUPling:PHASeshift <PhaseShift>

Sets the phase shift between the waveform of Gen1 and Gen2 when the frequency parameters of the two waveforms are coupled.

Suffix:

<wg> 1..2
Specifies the prime generator.

Parameters:

<PhaseShift> Range: -180 to 180
Increment: 1
*RST: 0
Default unit: °

Usage: Asynchronous command

Manual operation: See ["Phase Gen1 - Gen2"](#) on page 871

WGENerator<wg>:COUPling[:FREQuency] <CplFreq>

Enables the coupling of all frequency parameters of the generators.

Suffix:

<wg> 1..2
Specifies the prime generator.

Parameters:

<CplFreq> OFF | ON
*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Amplitude parameters"](#) on page 872

GENerator:SYNC[:COMBination] <Combination>

Selects which signals generated from the waveform generator are synchronized.

Parameters:

<Combination> NONE | GEN12
*RST: NONE

Usage: Asynchronous command

Manual operation: See ["Synchron start"](#) on page 871

18.21 ScopeSync

The DEvice<m> index corresponds to the number of the oscilloscope in the scope list of the "Add scope" dialog and the waveform notification, but the numbers are different. For example:

- DEvice1 is oscilloscope O2 with channel waveforms O2C1, O2C2 ...
- DEvice2 is oscilloscope O3 with channel waveforms O3C1, O3C2 ...
- DEvice6 is oscilloscope O7 with channel waveforms O7C1, O7C2 ...

SYNChronize:DEvice<m>:CHANnels.....	1872
SYNChronize:DEvice<m>:COMMunicate:NET[:HOSTname].....	1872
SYNChronize:DEvice<m>:CONNect.....	1873
SYNChronize:DEvice<m>:DISPlay.....	1873
SYNChronize:DEvice<m>:LOCKcontrols.....	1873
SYNChronize:DEvice<m>:NAME.....	1873
SYNChronize:DEvice<m>:SKEW:AUTO.....	1874
SYNChronize:DEvice<m>:SKEW[:VALue].....	1874
SYNChronize:DEvice<m>:TIMEbasesync.....	1874
SYNChronize:DEvice<m>[:ENABLE].....	1875
SYNChronize:DISConnect.....	1875
SYNChronize:LOAD:ABORT.....	1875
SYNChronize:LOAD[:WAVEform].....	1875

SYNChronize:DEvice<m>:CHANnels <Sources>

Selects the channels of scope 2 to be synchronized, displayed and analyzed. You can select active and inactive channels.

Suffix:

<m> 1 to 10, index = n-1 of the connected oscilloscope O<n>

Parameters:

<Sources> C1,C2,C3,C4,C5,C6,C7,C8

Usage:

Asynchronous command

Manual operation: See ["Select active channels"](#) on page 888

SYNChronize:DEvice<m>:COMMunicate:NET[:HOSTname] <Hostname>

Sets the IP address or the host name for the specified oscilloscope.

Suffix:

<m> 1 to 10, index = n-1 of the connected oscilloscope O<n>

Parameters:

<Hostname> String with the IP address or host name

Example:

SYNChronize:DEvice:COMMunicate:NET:HOSTname "169.254.168.172"

Usage:

Asynchronous command

Manual operation: See ["IP or hostname"](#) on page 886

SYNChronize:DEVIce<m>:CONNect <State>

Activates the connection between the two oscilloscopes, or between the R&S ScopeStudio software and the oscilloscope.

Suffix:

<m> 1 to 10, index = n-1 of the connected oscilloscope O<n>

Parameters:

<State> OFF | ON

Usage: Asynchronous command

Manual operation: See ["Connect"](#) on page 886

SYNChronize:DEVIce<m>:DISPlay <RemoteUpdate>

Enables the continuous display update on the actively connected oscilloscope (scope 2) when acquisition is controlled on scope 1.

The display update allows for visual comparison of the waveforms on both scopes.

Suffix:

<m> 1 to 10, index = n-1 of the connected oscilloscope O<n>

Parameters:

<RemoteUpdate> OFF | ON

*RST: ON

Usage: Asynchronous command

Manual operation: See ["Display update"](#) on page 889

SYNChronize:DEVIce<m>:LOCKcontrols <RemoteLock>

Locks the touchscreen and the front panel keys on the connected oscilloscope.

Suffix:

<m> 1 to 10, index = n-1 of the connected oscilloscope O<n>

Parameters:

<RemoteLock> OFF | ON

*RST: OFF

Usage: Asynchronous command

Manual operation: See ["Lock controls"](#) on page 888

SYNChronize:DEVIce<m>:NAME <Name>

Defines a name for the specified oscilloscope.

Suffix:

<m> 1 to 10, index = n-1 of the connected oscilloscope O<n>

Parameters:

<Name> String with the name of the connected oscilloscope.

Usage:

Asynchronous command

Manual operation:

See "[Device name](#)" on page 885

SYNChronize:DEVIce<m>:SKEW:AUTO

Determines the delay between the specified scope and scope 1 automatically, and sets the skew.

Suffix:

<m> 1 to 10, index = n-1 of the connected oscilloscope O<n>

Usage:

Setting only
Asynchronous command

Manual operation:

See "[Auto remote skew](#)" on page 887

SYNChronize:DEVIce<m>:SKEW[:VALue] <Skew>

Returns the skew value that was measured by [SYNChronize:DEVIce<m>:SKEW:AUTO](#). If you know the skew, or measure it manually, you can also set the value.

Suffix:

<m> 1 to 10, index = n-1 of the connected oscilloscope O<n>

Parameters:

<Skew> Range: -0.02 to 0.02
Increment: 1E-13
*RST: 8E-07
Default unit: s

Usage:

Asynchronous command

Manual operation:

See "[Remote skew](#)" on page 887

SYNChronize:DEVIce<m>:TIMEbasesync <SyncTimebase>

Enables or disables the timebase synchronization.

Suffix:

<m> 1 to 10, index = n-1 of the connected oscilloscope O<n>

Parameters:

<SyncTimebase> OFF | ON
*RST: ON

Usage:

Asynchronous command

Manual operation:

See "[Sync timebase](#)" on page 889

SYNChronize:DEVIce<m>[:ENABLE] <State>

Adds or removes an oscilloscope to the scope list.

Suffix:

<m> 1 to 10, index = n-1 of the connected oscilloscope O<n>

Parameters:

<State> OFF | ON

Usage: Asynchronous command

Manual operation: See ["+ Add"](#) on page 885

SYNChronize:DISConnect

Terminates the active connection.

Usage:

Event

Asynchronous command

Manual operation: See ["Disconnect"](#) on page 886

SYNChronize:LOAD:ABORt

Terminates the getting of signals.

Usage:

Setting only

Asynchronous command

Manual operation: See ["Get signals"](#) on page 889

SYNChronize:LOAD[:WAVEform]

Retrieves the waveforms of the latest acquisition from the connected oscilloscope. All selected analog channel waveforms are transferred. Digital channels and reference waveforms are not transferred.

Usage:

Setting only

Asynchronous command

Manual operation: See ["Get signals"](#) on page 889

18.22 Status reporting

This section describes the remote commands that are used to read the status registers.

For information on the structure, hierarchy, and contents of the status registers, see [Section 17.6, "Remote control - status reporting system"](#), on page 898.

• General commands.....	1876
• STATUS:OPERation register.....	1876
• STATUS:QUESTionable registers.....	1878
• Reading out the CONDition part.....	1880
• Reading out the EVENT part.....	1881
• Controlling the ENABLE part.....	1881
• Controlling the negative transition part.....	1882
• Controlling the positive transition part.....	1883
• Other status commands.....	1883
• Programming tips and examples.....	1884

18.22.1 General commands

STATUS:PRESet

Resets the status registers.

All PTRansition bits are set to 1, i.e. all transitions from 0 to 1 are detected.

All NTRansition bits are set to 0, i.e. a transition from 1 to 0 in a CONDition bit is not detected.

All EVENT bits are set to 0.

The ENABLE bits of STATUS:OPERation and STATUS:QUESTionable are set to 0, i.e. all events in these registers are not passed on.

Usage: Setting only
 SCPI confirmed

18.22.2 STATUS:OPERation register

STATUS:OPERation commands provide information on the activity of the instrument.

See also: [Section 17.6.3.3, "STATUS:OPERation register"](#), on page 903.

STATUS:OPERation:CONDition?.....	1876
STATUS:OPERation:ENABLE.....	1877
STATUS:OPERation[:EVENT]?.....	1877
STATUS:OPERation:NTRansition.....	1877
STATUS:OPERation:PTRansition.....	1878

STATUS:OPERation:CONDition?

Returns the bit of the action the instrument is currently executing. The contents of the STATUS:OPERation register is retained.

The bit assignment is described in [Section 17.6.3.3, "STATUS:OPERation register"](#), on page 903.

Usage: Query only
SCPI confirmed
Asynchronous command

STATus:OPERation:ENABLE <Enable>

Controls the ENABLE part of the STATus:OPERation register. The ENABLE defines which events in the EVENT part of the status register are forwarded to the OPERATION summary bit (bit 7) of the status byte. The status byte can be used to create a service request.

Parameters:

<Enable> Range: 1 to 65535
Increment: 1

Example: STATus:OPERation:ENABLE 5
The ALIGNment event (bit 0) and AUToset event (bit 2) are forwarded to the OPERATION summary bit of the status byte.

STATus:OPERation[:EVENT]?

The CONDition command returns information on actions the instrument is currently executing. The contents of the register is retained.

The EVENT command returns information on actions the instrument has executed since the last reading. Reading the EVENT register deletes its contents.

Bits:

- 0 = ALIGNment
- 2 = AUToset
- 4 = MEASuring
- 5 = WTRigger (wait for trigger)
- 6 = TRIGGERed

Example: For an example, see [Example "Querying with STATus:OPERation:CONDition"](#) on page 1885.

Usage: Query only
SCPI confirmed
Asynchronous command

STATus:OPERation:NTRansition <SumBit>

The command sets the bits of the NTRansition part of the STATus:OPERation register. A bit set in the NTRansition register causes a bit transition from 1 to 0 in the CONDition register to produce an entry in the EVENT register.

Reading the information does not clear the register.

Parameters:

<SumBit> Range: 0 to 65535
 Increment: 1

Usage:

SCPI confirmed
 Asynchronous command

STATus:OPERation:PTRansition <SumBit>

The command sets the bits of the PTRansition part of the STATus:OPERation register. A bit set in the PTRansition register causes a bit transition from 0 to 1 in the CONDition register to produce an entry in the EVENT register.

Reading the information does not clear the register.

Parameters:

<SumBit> Range: 0 to 65535
 Increment: 1

Usage:

SCPI confirmed
 Asynchronous command

18.22.3 STATus:QUEStionable registers

The commands of the STATus:QUEStionable subsystem control the status reporting structures of the STATus:QUEStionable registers.

See also: [Section 17.6.3.4, "STATus:QUEStionable register"](#), on page 904.

The query of the [:EVENT] and [:ENABLE] commands, return a list of the affected sources:

Table 18-3: Source values for STATus:QUEStionable:....[:EVENT] and STATus:QUEStionable:....[:ENABLE]

Bits	Source values	Description
For all bits	NONE	
	ALL	All available sources are activated
PPSupply	PRobe<m>	Active probe
POVerload	PRobe<m>	Active probe
COVerload	CHAN<m>	Analog channels
	WARNCHAN<m>	Warning overload channels
	EXTTRIGGERIN	External analog signal connected to the external trigger input
	TRIGGEROUT	Trigger out signal
TEMPerature	WINSTRUMENT	Temperature warning: indicates that the device is getting hot and should be cooled.
	EINSTRUMENT	Temperature error: the device is too hot and will automatically shut down in a few seconds.

Bits	Source values	Description
	WGENERATOR1	Temperature warning on waveform generator 1
	WGENERATOR2	Temperature warning on waveform generator 2
ADCState	CPCHAN<m>	Positive clipping for analog channels
	CNCHAN<m>	Negative clipping for analog channels
	CPPRobe<m>	Positive clipping for probes
	CNPRobe<m>	Negative clipping for probes
GOVerload	WGenEratOr<m>	Available generators
LIMit	MEAS<mg>	Enabled measurements
IMPRecise	MEAS<mg>	Enabled measurements
MASK	MASK<m>	Enabled masks
PLLunlock	PLL100	

Some of the status commands can be used interchangeably:

Table 18-4: Overview: STATus:QUESTionable and respective CHANnel, MEASurement and WGENerator commands

STATus:QUESTionable register	MEASurement
STATus:QUESTionable:COVerload Bit: CHANnel<ch>	CHANnel<ch>:OVERload:STATus
STATus:QUESTionable:COVerload Bit: WCHannel<ch>	CHANnel<ch>:WARNOverload:STATus
STATus:QUESTionable:COVerload Bit: EXTTRIGGERIN	TRIGger:ANEDge:OVERload:STATus
STATus:QUESTionable:COVerload Bit: TRIGGEROUT	TRIGger:ACTions:OUT:OVERload:STATus
STATus:QUESTionable:ADCState Bit: CPCHannel<ch>	CHANnel<ch>:ADCState:STATus:PClipping
STATus:QUESTionable:ADCState Bit: CNCHannel<ch>	CHANnel<ch>:ADCState:STATus:NClipping
STATus:QUESTionable:PPSupply Bit: CNCHannel<ch>	CHANnel<ch>:PPSupply:STATus
STATus:QUESTionable:LIMit Bit: MEAS<mg>	MEASurement<mg>:LIMit:STATus
STATus:QUESTionable:IMPRecise Bit: MEAS<mg>	MEASurement<mg>:IMPRecise:STATus

STATus:QUESTionable register	MEASurement
STATus:QUESTionable:GOVerload Bit: WGENerator<wg>	WGENerator<wg>:GOVerload
STATus:QUESTionable:TEMPerature Bit: WGENerator<wg>	WGENerator<wg>:TEMPerature

18.22.4 Reading out the CONDition part

See also: [Section 18.22.3, "STATus:QUESTionable registers"](#), on page 1878.

CHANnel<ch>:OVERload:STATus:CONDition?
CHANnel<ch>:ADCState:STATus:NCLipping:CONDition?
CHANnel<ch>:ADCState:STATus:PCLipping:CONDition?
CHANnel<ch>:WARNoverload:STATus:CONDition?
CHANnel<ch>:PPSupply:STATus:CONDition?
MEASurement<mg>:IMPRecise:STATus:CONDition?
MEASurement<mg>:LIMit:STATus:CONDition?
STATus:QUESTionable:MASK:CONDition?
TRIGger:ACTions:OUT:OVERload:STATus:CONDition?
TRIGger:ANEDge:OVERload:STATus:CONDition?
WGENerator<wg>:GOVerload:STATus:CONDition?
WGENerator<wg>:TEMPerature:STATus:CONDition?
STATus:QUESTionable:ADCState:CONDition?
STATus:QUESTionable:COVERload:CONDition?
STATus:QUESTionable:GOVerload:CONDition?
STATus:QUESTionable:IMPRecise:CONDition?
STATus:QUESTionable:LIMit:CONDition?
STATus:QUESTionable:PLL:CONDition?
STATus:QUESTionable:PPSupply:CONDition?
STATus:QUESTionable:TEMPerature:CONDition?

Returns the contents of the CONDition part of the status register to check for questionable instrument or measurement states. This part contains information on the action currently being performed in the instrument.

Reading the CONDition registers does not delete the contents since it indicates the current hardware status.

Return values:

<Value> bit dependent, comma-separated values

Usage:

Query only

18.22.5 Reading out the EVENT part

```

CHANnel<ch>:ADCState:STATus:NCLipping[:EVENT]?
CHANnel<ch>:ADCState:STATus:PCLipping[:EVENT]?
CHANnel<ch>:OVERload:STATus[:EVENT] <Value>
CHANnel<ch>:WARNoverload:STATus[:EVENT]?
CHANnel<ch>:PPSupply:STATus[:EVENT] <Value>
MEASurement<mg>:IMPRecise:STATus[:EVENT]?
MEASurement<mg>:LIMit:STATus[:EVENT]?
STATus:QUESTionable:MASK[:EVENT]?
TRIGger:ACTions:OUT:OVERload:STATus[:EVENT] <Value>
TRIGger:ANEDge:OVERload:STATus[:EVENT] <Value>
WGENerator<wg>:GOVerload:STATus[:EVENT] <Value>
WGENerator<wg>:TEMPerature:STATus[:EVENT] <Value>
STATus:QUESTionable:ADCState[:EVENT]?
STATus:QUESTionable:COVerload[:EVENT]?
STATus:QUESTionable:GOVerload[:EVENT]?
STATus:QUESTionable:IMPRecise[:EVENT]?
STATus:QUESTionable:LIMit[:EVENT]?
STATus:QUESTionable:PLL[:EVENT]?
STATus:QUESTionable:PPSupply[:EVENT]?
STATus:QUESTionable:TEMPerature[:EVENT]?

```

Returns the contents of the `EVENT` part of the status register to check if an event has occurred since the last reading.

Reading an `EVENT` register deletes its contents.

Return values:

<Value> bit dependent, comma-separated values
 See [Source values for STATus:QUESTionable:....\[:EVENT\] and STATus:QUESTionable:....\[:ENABLE\]](#) for a list of the return values.

Usage: Query only

18.22.6 Controlling the ENABLE part

See also: [Section 18.22.3, "STATus:QUESTionable registers"](#), on page 1878.

```

CHANnel<ch>:OVERload:STATus:ENABLE <Value>
CHANnel<ch>:ADCState:STATus:NCLipping:ENABLE <Value>
CHANnel<ch>:ADCState:STATus:PCLipping:ENABLE <Value>
CHANnel<ch>:WARNoverload:STATus:ENABLE <Value>
CHANnel<ch>:PPSupply:STATus:ENABLE <Value>
MEASurement<mg>:IMPRecise:STATus:ENABLE <Value>
MEASurement<mg>:LIMit:STATus:ENABLE <Value>
TRIGger:ACTions:OUT:OVERload:STATus:ENABLE <Value>
TRIGger:ANEDge:OVERload:STATus:ENABLE <Value>
WGENerator<wg>:GOVerload:STATus:ENABLE <Value>

```

WGENerator<wg>:TEMPerature:STATus:ENABle <Value>
STATus:QUEStionable:ADCState:ENABle <Value>
STATus:QUEStionable:COVerload:ENABle <Value>
STATus:QUEStionable:GOVerload:ENABle <Value>
STATus:QUEStionable:IMPRecise:ENABle <Value>
STATus:QUEStionable:LIMit:ENABle <Value>
STATus:QUEStionable:PLL:ENABle <Value>
STATus:QUEStionable:PPSupply:ENABle <Value>
STATus:QUEStionable:TEMPerature:ENABle <Value>

Sets the **ENABle** part that allows true conditions in the **EVENT** part to be reported for the summary bit in the status byte.

These events can be used for a service request. If a bit in the **ENABle** part is 1, and the corresponding **EVENT** bit is true, a positive transition occurs in the summary bit. This transition is reported to the next higher level.

See [Source values for STATus:QUEStionable:....\[:EVENT\]](#) and [STATus:QUEStionable:....\[:ENABle\]](#) for a list of the return values.

Parameters:

<Value> bit dependent, comma-separated values

18.22.7 Controlling the negative transition part

See also: [Section 18.22.3, "STATus:QUEStionable registers"](#), on page 1878.

CHANnel<ch>:ADCState:STATus:NCLipping:NTRansition <Value>
CHANnel<ch>:ADCState:STATus:PCCLipping:NTRansition <Value>
CHANnel<ch>:OVERload:STATus:NTRansition <Value>
CHANnel<ch>:PPSupply:STATus:NTRansition <Value>
CHANnel<ch>:WARNoverload:STATus:NTRansition <Value>
MEASurement<mg>:IMPRecise:STATus:NTRansition <Value>
MEASurement<mg>:LIMit:STATus:NTRansition <Value>
TRIGger:ACTions:OUT:OVERload:STATus:NTRansition <Value>
TRIGger:ACTions:OUT:OVERload:STATus:PTRansition <Value>
TRIGger:ANEDge:OVERload:STATus:NTRansition <Value>
WGENerator<wg>:GOVerload:STATus:NTRansition <Value>
WGENerator<wg>:TEMPerature:STATus:NTRansition <Value>
STATus:QUEStionable:ADCState:NTRansition <Value>
STATus:QUEStionable:COVerload:NTRansition <Value>
STATus:QUEStionable:GOVerload:NTRansition <Value>
STATus:QUEStionable:IMPRecise:NTRansition <Value>
STATus:QUEStionable:LIMit:NTRansition <Value>
STATus:QUEStionable:PLL:NTRansition <Value>
STATus:QUEStionable:PPSupply:NTRansition <Value>
STATus:QUEStionable:TEMPerature:NTRansition <Value>

Sets the negative transition filter.

If a bit is set, a transition from 1 to 0 in the condition part causes an entry to be made in the corresponding bit of the **EVENT** part of the register.

Parameters:

<Value> Source dependent, comma-separated values

18.22.8 Controlling the positive transition partSee also: [Section 18.22.3, "STATUS:QUESTIONable registers"](#), on page 1878.

CHANnel<ch>:ADCState:STATus:NCLipping:PTRansition <Value>
CHANnel<ch>:ADCState:STATus:PCLipping:PTRansition <Value>
CHANnel<ch>:OVERload:STATus:PTRansition <Value>
CHANnel<ch>:PPSupply:STATus:PTRansition <Value>
CHANnel<ch>:WARNoverload:STATus:PTRansition <Value>
MEASurement<mg>:IMPRecise:STATus:PTRansition <Value>
MEASurement<mg>:LIMit:STATus:PTRansition <Value>
TRIGger:ACTions:OUT:OVERload:STATus:PTRansition <Value>
TRIGger:ANEDge:OVERload:STATus:PTRansition <Value>
WGENerator<wg>:GOVerload:STATus:PTRansition <Value>
WGENerator<wg>:TEMPerature:STATus:PTRansition <Value>
STATus:QUESTIONable:ADCState:PTRansition <Value>
STATus:QUESTIONable:COVERload:PTRansition <Value>
STATus:QUESTIONable:GOVerload:PTRansition <Value>
STATus:QUESTIONable:IMPRecise:PTRansition <Value>
STATus:QUESTIONable:LIMit:PTRansition <Value>
STATus:QUESTIONable:PLL:PTRansition <Value>
STATus:QUESTIONable:PPSupply:PTRansition <Value>
STATus:QUESTIONable:TEMPerature:PTRansition <Value>

Sets the positive transition filter.

If a bit is set, a transition from 0 to 1 in the condition part causes an entry to be made in the corresponding bit of the `EVENT` part of the register.

Parameters:

<Value> Source dependent, comma-separated values

18.22.9 Other status commands

STATus:QUESTIONable:PLL:RCONdition <Value>

Reset condition, allows to continue after an PLL unlock of the external reference.

Setting parameters:

<Value> PLL100

Usage:

Setting only

18.22.10 Programming tips and examples

Example: Observing the limits violation of a measurement

The following example describes how to use the status register commands to observe if a violation of a measurement limit has occurred.

```
*SRE 8
// Enables the STATUS:QUESTionable bit in the service-request (SRE)

STATUS:QUESTionable:ENABLE 512
// Enables the LIMit bit of the STATUS:QUESTionable register

MEASurement1:ENABLE ON
MEASurement2:ENABLE ON
MEASurement3:ENABLE ON
// Enables measurement 1,2,3

STATUS:QUESTionable:LIMit:ENABLE ALL
// Enables the limit check for all active measurements

STATUS:QUESTionable:LIMit:ENABLE?
MEAS1,MEAS2,MEAS3
//Queries which measurement were active at the time the
//STATUS:QUESTionable:LIMit:ENABLE was send

*SRQ?
// A service request was sent

*STB?
72
// STATUS:QUESTionable is set:
// #72= 64 + 8 = 2^6 + 2^3
// 64 : bit 6 is awlays on when a SRQ is sent
// 8: bit 3 for STATUS:QUESTionable

STATUS:QUESTionable:EVENT?
512
// 512= 2^9,

STATUS:QUESTionable:LIMit:EVENT?
MEAS1,MEAS2
// Measurements 1 and 2 have exceeded the limit
// The event register is cleared after the query

STATUS:QUESTionable:LIMit:EVENT?
NONE
// The event bit has been set to 0 after the first query
```



```

STATus:QUEStionable:LIMit:CONDition?
MEAS1,MEAS2
// Measurements 1 and 2 are still exceeding the limit

STATus:QUEStionable:EVENT?
0

// Waiting for an event
*SRQ?

// Measurement 3 exceeds the limit

STATus:QUEStionable:LIMit:CONDition?
MEAS1,MEAS2,MEAS3
// Measurements 1,2 and 3 are currently exceeding the limit

STATus:QUEStionable:LIMit:EVENT?
MEAS3
// Measurement 3 has newly exceeded the limit
// The event register is cleared after the query

```

Example: Querying with STATus:OPERation:CONDition

The following example shows how the result of STATus:OPERation:CONDition? changes during a single acquisition.

```

SINGLe
// Measurement starts

STATus:OPERation:CONDition?
16
//Measuring

STATus:OPERation:CONDition?
48
//Pre trigger waiting time is over (16 Measuring + 32 WaitForTrigger)

STATus:OPERation:CONDition?
112
//Trigger is deactivated (16 Measuring + 32 WaitForTrigger + 64 Triggered)

STATus:OPERation:CONDition?
96
// Measurement has finished (32 WaitForTrigger + 64 Triggered)

```

Query OPC status in the event status register

If you activate a time-consuming operation and wait for completion with *OPC?, a time-out could occur before the operation is finished and you do not receive the returned

“1”. In addition, the test program is blocked while waiting with *OPC?. It is not possible to process other (not interdependent) commands in the meantime or to communicate with other instruments.

Thus, for time-consuming operations, you can avoid blocking the communication by sending the operation complete command *OPC:

*CLS

*OPC

Afterwards you can poll the operation complete status in the event status register with *ESR?.

This query returns the content of the event status register and afterwards clears the content. See also [Section 17.6.3.2, "Event status register \(ESR\) and event status enable register \(ESE\)"](#), on page 902.

18.23 Deprecated commands

The following commands are provided for compatibility to previous oscilloscope versions only. For new remote control programs, use the specified alternative commands.

18.23.1 Base instrument

Table 18-5: Status reporting

Legacy command	Replaced by	Comment
MEASurement<mg>:MARGin:STATus:CONDition? MEASurement<mg>:MARGin:STATus:ENABle MEASurement<mg>:MARGin:STATus:NTRansition MEASurement<mg>:MARGin:STATus:PTRansition MEASurement<mg>:MARGin:STATus[:EVENT]	Use MEASurement<mg>:LIMit:STATus: commands	Obsolete since FW 2.9
STATus:QUESTionable:MARGin:CONDition? STATus:QUESTionable:MARGin:ENABle STATus:QUESTionable:MARGin:NTRansition STATus:QUESTionable:MARGin:PTRansition STATus:QUESTionable:MARGin[:EVENT]?	Use STATus:QUESTionable:LIMit: commands	Obsolete since FW 2.9

18.23.2 Applications

Table 18-6: Signal configuration

Legacy command	Replaced by	Comment
TREference<m>:REFLevel	TREference<m>:CLK:REFLevel on page 1060	Replaced since FW 2.8

Table 18-7: Waveform generator

Legacy command	Replaced by	Comment
WGENerator:MODulation:NLABsolute	-	Obsolete since FW 2.8

Table 18-8: Power analysis

Legacy command	Replaced by	Comment
POWER<m>:HARMonics:MEASurement:REAL-power[:ACTual]	POWER<m>:HARMonics:MEASurement:POWER:ACTIVE[:ACTual]? on page 1231	Replaced since FW 2.8
POWER<m>:QUALity:DISPlay:POWER:REALpower	POWER<m>:QUALity:RESult:POWER:ACTIVE[:ACTual]? on page 1220	Replaced since FW 2.8
POWER<m>:QUALity:RESult:POWER:REAL-power:AVERage	POWER<m>:QUALity:RESult:POWER:ACTIVE:AVERage? on page 1220	Replaced since FW 2.8
POWER<m>:QUALity:RESult:POWER:REAL-power:EVTCount	POWER<m>:QUALity:RESult:POWER:ACTIVE:EVTCount? on page 1220	
POWER<m>:QUALity:RESult:POWER:REAL-power:NPEak	POWER<m>:QUALity:RESult:POWER:ACTIVE:NPEak? on page 1220	
POWER<m>:QUALity:RESult:POWER:REAL-power:PPEak	POWER<m>:QUALity:RESult:POWER:ACTIVE:PPEak? on page 1221	
POWER<m>:QUALity:RESult:POWER:REAL-power:RMS	POWER<m>:QUALity:RESult:POWER:ACTIVE:RMS? on page 1221	
POWER<m>:QUALity:RESult:POWER:REAL-power:STDDev	POWER<m>:QUALity:RESult:POWER:ACTIVE:STDDev? on page 1221	
POWER<m>:QUALity:RESult:POWER:REAL-power:WFMCount	POWER<m>:QUALity:RESult:POWER:ACTIVE:WFMCount? on page 1221	
POWER<m>:QUALity:RESult:POWER:REAL-power[:ACTual]	POWER<m>:QUALity:RESult:POWER:ACTIVE[:ACTual]? on page 1220	
POWER<m>:HARMonics:DISPlay:FRE-Quency:START[:VALue]	POWER<m>:HARMonics:DISPlay:HARMonics:START[:VALue] on page 1228	Replaced since FW 2.9
POWER<m>:HARMonics:DISPlay:FRE-Quency:STOP[:VALue]	POWER<m>:HARMonics:DISPlay:HARMonics:STOP[:VALue] on page 1228	

18.23.3 Serial protocols

18.23.3.1 General

Legacy command	Replaced by	Comment
SBUS<sb>:SETReflevels	-	No longer needed since FW 2.7

18.23.3.2 SPI

Table 18-9: SPI trigger

Legacy command	Replaced by	Comment
TRIGger:SPI:DMINpattern	TRIGger:SBHW:SPI:DMINpattern	Replaced since FW 2.3
TRIGger:SPI:DPOStion	TRIGger:SBHW:SPI:DPOStion	
TRIGger:SPI:FCONdition	TRIGger:SBHW:SPI:FCONdition	
TRIGger:SPI:PALignment	TRIGger:SBHW:SPI:PALignment	
TRIGger:SPI:TYPE	TRIGger:SBHW:SPI:TYPE	

Table 18-10: SPI decode results

Legacy command	Replaced by	Comment
SBUS<sb>:SPI:FRAMe<fr>:COUNT?	SBUS<sb>:SPI:FCOUNT?	Replaced since FW 2.6

18.23.3.3 QUAD-SPI

Table 18-11: QUAD-SPI decode results

Legacy command	Replaced by	Comment
SBUS<sb>:QSPI:FRAMe<fr>:DCOunt	SBUS<sb>:QSPI:FRAMe<fr>:FLDCount?	Replaced since FW 2.6
SBUS<sb>:QSPI:FRAMe<fr>:FLD<fl>:DVALue	SBUS<sb>:QSPI:FRAMe<fr>:FLD<fl>:VALue?	

18.23.3.4 I2C

Table 18-12: I2C trigger

Legacy command	Replaced by	Comment
TRIGger:I2C:ACCess	TRIGger:SBHW:I2C:ACCess	Replaced since FW 2.3
TRIGger:I2C:ACONdition	TRIGger:SBHW:I2C:ACONdition	
TRIGger:I2C:ADDReSS	TRIGger:SBHW:I2C:ADDReSS	
TRIGger:I2C:ADDTo	TRIGger:SBHW:I2C:ADDTo	
TRIGger:I2C:ADNack	TRIGger:SBHW:I2C:ADNack	
TRIGger:I2C:AMODE	TRIGger:SBHW:I2C:AMODE	
TRIGger:I2C:DCONdition	TRIGger:SBHW:I2C:DCONdition	
TRIGger:I2C:DMIN	TRIGger:SBHW:I2C:DMIN	
TRIGger:I2C:DPOStion	TRIGger:SBHW:I2C:DPOStion	
TRIGger:I2C:DRNack	TRIGger:SBHW:I2C:DRNack	
TRIGger:I2C:DWNack	TRIGger:SBHW:I2C:DWNack	
TRIGger:I2C:TYPE	TRIGger:SBHW:I2C:TYPE	

Table 18-13: I2C decode results

Legacy command	Replaced by	Comment
SBUS<sb>:I2C:FRAMe<fr>:COUNt SBUS<sb>:I2C:FRAMe<fr>:BYTE<o>:ACCess SBUS<sb>:I2C:FRAMe<fr>:BYTE<o>:ACKStart SBUS<sb>:I2C:FRAMe<fr>:BYTE<o>:COMPLete	-	No longer needed since FW 2.6
SBUS<sb>:I2C:FRAMe<fr>:BCOunt SBUS<sb>:I2C:FRAMe<fr>:BYTE<o>:STARt SBUS<sb>:I2C:FRAMe<fr>:BYTE<o>:VALue	SBUS<sb>:I2C:FRAMe<fr>:FLDCount? SBUS<sb>:I2C:FRAMe<fr>:FLD<fl>:STARt? SBUS<sb>:I2C:FRAMe<fr>:FLD<fl>:VALue?	Replaced since FW 2.6

18.23.3.5 I3C

Table 18-14: I3C decode results

Legacy command	Replaced by	Comment
SBUS<sb>:I3C:FRAMe<fr>:AACcess? SBUS<sb>:I3C:FRAMe<fr>:Access? SBUS<sb>:I3C:FRAMe<fr>:ACOMplete? SBUS<sb>:I3C:FRAMe<fr>:ADBStart? SBUS<sb>:I3C:FRAMe<fr>:ADEVice? SBUS<sb>:I3C:FRAMe<fr>:AMODE? SBUS<sb>:I3C:FRAMe<fr>:BYTE<o>:Access? SBUS<sb>:I3C:FRAMe<fr>:BYTE<o>:ACKStart? SBUS<sb>:I3C:FRAMe<fr>:BYTE<o>:COMPLete? SBUS<sb>:I3C:FRAMe<fr>:BYTE<o>:STARt?	-	No longer needed since FW 2.6
SBUS<sb>:I3C:FRAMe<fr>:BCOunt SBUS<sb>:I3C:FRAMe<fr>:COunt	SBUS<sb>:I3C:FRAMe<fr>:FLDCount?	Replaced since FW 2.6

18.23.3.6 UART

Table 18-15: UART configuration

Legacy command	Replaced by	Comment
SBUS<sb>:UART:EWORd	-	No longer needed since FW 2.7

Table 18-16: UART trigger

Legacy command	Replaced by	Comment
TRIGger:UART:DATA TRIGger:UART:DPOSition TRIGger:UART:FCONDition TRIGger:UART:OPERator TRIGger:UART:SOURce TRIGger:UART:TYPE	TRIGger:SBHW:UART:DATA TRIGger:SBHW:UART:DPOSition TRIGger:SBHW:UART:FCONDition TRIGger:SBHW:UART:OPERator TRIGger:SBHW:UART:SOURce TRIGger:SBHW:UART:TYPE	Replaced since FW 2.3

Table 18-17: UART decode results

Legacy command	Replaced by	Comment
SBUS<sb>:UART:WORD<w>:COUNT?	SBUS<sb>:UART:WCount?	Replaced since FW 2.6

18.23.3.7 CAN

Table 18-18: CAN trigger

Legacy command	Replaced by	Comment
TRIGger:CAN:ACKerror	TRIGger:SBHW:CAN:ACKerror	Replaced since FW 2.3
TRIGger:CAN:BITSterror	TRIGger:SBHW:CAN:BITSterror	
TRIGger:CAN:BORDer	TRIGger:SBHW:CAN:BORDer	
TRIGger:CAN:CRCErrror	TRIGger:SBHW:CAN:CRCErrror	
TRIGger:CAN:DCONdition	TRIGger:SBHW:CAN:DCONdition	
TRIGger:CAN:DLC	TRIGger:SBHW:CAN:DLC	
TRIGger:CAN:DLCCCondition	TRIGger:SBHW:CAN:DLCCCondition	
TRIGger:CAN:DMIN	TRIGger:SBHW:CAN:DMIN	
TRIGger:CAN:FORMerror	TRIGger:SBHW:CAN:FORMerror	Replaced since FW 2.3
TRIGger:CAN:FTYPe	TRIGger:SBHW:CAN:FTYPe	
TRIGger:CAN:ICONdition	TRIGger:SBHW:CAN:ICONdition	
TRIGger:CAN:IMAX	TRIGger:SBHW:CAN:IMAX	
TRIGger:CAN:IMIN	TRIGger:SBHW:CAN:IMIN	
TRIGger:CAN:ITYPe	TRIGger:SBHW:CAN:ITYPe	
TRIGger:CAN:TYPE	TRIGger:SBHW:CAN:TYPE	
TRIGger:CAN:FDATA:BRs	TRIGger:SBHW:CAN:FDATA:BRs	Replaced since FW 2.3
TRIGger:CAN:FDATA:DPOSition	TRIGger:SBHW:CAN:FDATA:DPOSition	
TRIGger:CAN:FDATA:ESI	TRIGger:SBHW:CAN:FDATA:ESI	
TRIGger:CAN:FDATA:SCERror	TRIGger:SBHW:CAN:FDATA:SCERror	
TRIGger:CAN:XDATA:AF:CONDItion	TRIGger:SBHW:CAN:XDATA:AF:CONDItion	Replaced since FW 2.3
TRIGger:CAN:XDATA:AF:MAX	TRIGger:SBHW:CAN:XDATA:AF:MAX	
TRIGger:CAN:XDATA:AF:MIN	TRIGger:SBHW:CAN:XDATA:AF:MIN	
TRIGger:CAN:XDATA:SDT:CONDItion	TRIGger:SBHW:CAN:XDATA:SDT:CONDItion	
TRIGger:CAN:XDATA:SDT:MAX	TRIGger:SBHW:CAN:XDATA:SDT:MAX	
TRIGger:CAN:XDATA:SDT:MIN	TRIGger:SBHW:CAN:XDATA:SDT:MIN	
TRIGger:CAN:XDATA:SEC	TRIGger:SBHW:CAN:XDATA:SEC	
TRIGger:CAN:XDATA:VCID:CONDItion	TRIGger:SBHW:CAN:XDATA:VCID:CONDItion	
TRIGger:CAN:XDATA:VCID:MAX	TRIGger:SBHW:CAN:XDATA:VCID:MAX	
TRIGger:CAN:XDATA:VCID:MIN	TRIGger:SBHW:CAN:XDATA:VCID:MIN	

Table 18-19: CAN decode results

Legacy command	Replaced by	Comment
SBUS<sb>:CAN:FRAME<fr>:BSEPosition?	-	No longer needed since FW 2.1
SBUS<sb>:CAN:FRAME<fr>:SDATa? SBUS<sb>:CAN:FRAME<fr>:SDEExport?	-	No longer needed since FW 2.6
SBUS<sb>:CAN:FRAME<fr>:BCOunt? SBUS<sb>:CAN:FRAME<fr>:BYTE<o>:FVALue? SBUS<sb>:CAN:FRAME<fr>:BYTE<o>:LABel? SBUS<sb>:CAN:FRAME<fr>:BYTE<o>:STATe? SBUS<sb>:CAN:FRAME<fr>:BYTE<o>:VALue? SBUS<sb>:CAN:FRAME<fr>:COUnT?	SBUS<sb>:CAN:FRAME<fr>:FLDCount? SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:FVALue? SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:LABel? SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:STATe? SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:VALue? SBUS<sb>:CAN:FCOunt?	Replaced since FW 2.6
SBUS<sb>:CAN:FRAME<fr>:XDATa<o>:SBC?	SBUS<sb>:CAN:FRAME<fr>:SBC?	Replaced since FW 2.7
SBUS<sb>:CAN:FRAME<fr>:FERCause? SBUS<sb>:CAN:FRAME<fr>:STUFF?	-	No longer needed since FW 2.9

18.23.3.8 LIN

Table 18-20: LIN trigger

Legacy command	Replaced by	Comment
TRIGger:LIN:CHKSError TRIGger:LIN:DCONdition TRIGger:LIN:DMIN TRIGger:LIN:DPOStion TRIGger:LIN:ICONdition TRIGger:LIN:IMAX TRIGger:LIN:IMIN TRIGger:LIN:IPERror TRIGger:LIN:SYERror TRIGger:LIN:TYPE	TRIGger:SBHW:LIN:CHKSError TRIGger:SBHW:LIN:DCONdition TRIGger:SBHW:LIN:DMIN TRIGger:SBHW:LIN:DPOStion TRIGger:SBHW:LIN:ICONdition TRIGger:SBHW:LIN:IMAX TRIGger:SBHW:LIN:IMIN TRIGger:SBHW:LIN:IPERror TRIGger:SBHW:LIN:SYERror TRIGger:SBHW:LIN:TYPE	Replaced since FW 2.3

Table 18-21: LIN decode results

Legacy command	Replaced by	Comment
SBUS<sb>:LIN:FRAME<fr>:IDState?	-	No longer needed since FW 2.6
SBUS<sb>:LIN:FRAME<fr>:BCOunt?	SBUS<sb>:LIN:FRAME<fr>:FLDCount?	Replaced since FW 2.6
SBUS<sb>:LIN:FRAME<fr>:BYTE<o>:COUNT?	SBUS<sb>:LIN:FRAME<fr>:FLDCount?	
SBUS<sb>:LIN:FRAME<fr>:BYTE<o>:FVALue?	SBUS<sb>:LIN:FRAME<fr>:FLD<fl>:FVALue?	
SBUS<sb>:LIN:FRAME<fr>:BYTE<o>:LABel?	SBUS<sb>:LIN:FRAME<fr>:FLD<fl>:LABel?	
SBUS<sb>:LIN:FRAME<fr>:BYTE<o>:STATe?	SBUS<sb>:LIN:FRAME<fr>:FLD<fl>:STATe?	
SBUS<sb>:LIN:FRAME<fr>:BYTE<o>:VALue?	SBUS<sb>:LIN:FRAME<fr>:FLD<fl>:VALue?	
SBUS<sb>:LIN:FRAME<fr>:COUNT?	SBUS<sb>:LIN:FCOunt?	

18.23.3.9 SENT

Table 18-22: SENT decode results

Legacy command	Replaced by	Comment
SBUS<sb>:SENT:FRAME<fr>:COUNT	-	No longer needed since FW 2.6
SBUS<sb>:SENT:FRAME<fr>:FCSValue?		
SBUS<sb>:SENT:FRAME<fr>:FIDValue?		
SBUS<sb>:SENT:FRAME<fr>:FPDValue?		
SBUS<sb>:SENT:FRAME<fr>:FSYNc?		
SBUS<sb>:SENT:FRAME<fr>:PDValue?		
SBUS<sb>:SENT:FRAME<fr>:NIBB<o>:STATe	SBUS<sb>:SENT:FRAME<fr>:FLD<fl>:STATe?	Replaced since FW 2.6
SBUS<sb>:SENT:FRAME<fr>:NIBB<o>:VALue	SBUS<sb>:SENT:FRAME<fr>:FLD<fl>:VALue?	

18.23.3.10 ARINC 429

Table 18-23: ARINC 429 trigger

Legacy command	Replaced by	Comment
TRIGger:SBSW:ARINC:FRAME<fr>:FLD<fl>:IMAX		Not supported
TRIGger:SBSW:ARINC:FRAME<fr>:FLD<fl>:IMIN		
TRIGger:SBSW:ARINC:FRAME<fr>:FLD<fl>:IOPera- tor		
TRIGger:SBSW:ARINC:IMAX		
TRIGger:SBSW:ARINC:IMIN		
TRIGger:SBSW:ARINC:IOPerator		

Table 18-24: ARINC 429 decode results

Legacy command	Replaced by	Comment
SBUS<sb>:ARINC:WORD<w>:COUNT?	SBUS<sb>:ARINC:WCOunt?	Replaced since FW 2.6

18.23.3.11 SpaceWire**Table 18-25: SpaceWire configuration**

Legacy command	Replaced by	Comment
SBUS<sb>:SWIRe:FILTer:IMAX SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:IMAX SBUS<sb>:SWIRe:FILTer:IMIN SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:IMIN SBUS<sb>:SWIRe:FILTer:IOPerator SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:IOPerator	-	No longer needed since FW 2.7

18.23.3.12 MIL-1553**Table 18-26: MIL-1553 decode results**

Legacy command	Replaced by	Comment
SBUS<sb>:MILStd:WORD<w>:COUNT	-	No longer needed since FW 2.6

18.23.3.13 SPMI**Table 18-27: SPMI decode results**

Legacy command	Replaced by	Comment
SBUS<sb>:SPMI:FRAMe<fr>:FDCount?	SBUS<sb>:SPMI:FRAMe<fr>:FLDCount?	Replaced since FW 2.6

18.23.3.14 RFFE**Table 18-28: RFFE configuration**

Legacy command	Replaced by	Comment
SBUS<sb>:RFFE:CLOCK:POLarity SBUS<sb>:RFFE:DATA:POLarity	-	No longer needed since FW 2.6

Table 18-29: RFFE decode results

Legacy command	Replaced by	Comment
SBUS<sb>:RFFE:SEQuence<se>:ADDReSS SBUS<sb>:RFFE:SEQuence<se>:BCOuNT SBUS<sb>:RFFE:SEQuence<se>:BYTE<o>:FVALue SBUS<sb>:RFFE:SEQuence<se>:BYTE<o>:NAME SBUS<sb>:RFFE:SEQuence<se>:BYTE<o>:STATe SBUS<sb>:RFFE:SEQuence<se>:BYTE<o>:VALue SBUS<sb>:RFFE:SEQuence<se>:DATA SBUS<sb>:RFFE:SEQuence<se>:RBTRate SBUS<sb>:RFFE:SEQuence<se>:SADD SBUS<sb>:RFFE:SEQuence<se>:STARt SBUS<sb>:RFFE:SEQuence<se>:STATe SBUS<sb>:RFFE:SEQuence<se>:STOP SBUS<sb>:RFFE:SEQuence<se>:TYPE SBUS<sb>:RFFE:SEQuence<se>:WBTRate SBUS<sb>:RFFE:SEQuence<se>:WCOuNT	-	No longer needed since FW 2.6
SBUS<sb>:RFFE:FRAMe<fr>:BC? SBUS<sb>:RFFE:FRAMe<fr>:FDCouNT? SBUS<sb>:RFFE:FRAMe<fr>:FLD<fl>:LABeL? SBUS<sb>:RFFE:FRAMe<fr>:RBRate? SBUS<sb>:RFFE:FRAMe<fr>:SA? SBUS<sb>:RFFE:FRAMe<fr>:STATuS? SBUS<sb>:RFFE:FRAMe<fr>:WBRate? SBUS<sb>:RFFE:SEQuence<se>:SYMBol SBUS<sb>:RFFE:FRAMe<fr>:PADZero SBUS<sb>:RFFE:FRAMe<fr>:PADone SBUS<sb>:RFFE:FRAMe<fr>:PCTRI	SBUS<sb>:RFFE:FRAMe<fr>:BCOuNT? SBUS<sb>:RFFE:FRAMe<fr>:FLDCOuNT? SBUS<sb>:RFFE:FRAMe<fr>:FLD<fl>:NAME? SBUS<sb>:RFFE:FRAMe<fr>:RBTRate? SBUS<sb>:RFFE:FRAMe<fr>:SADD? SBUS<sb>:RFFE:FRAMe<fr>:STATe? SBUS<sb>:RFFE:FRAMe<fr>:WBTRate? SBUS<sb>:RFFE:FRAMe<fr>:SYMBol? SBUS<sb>:RFFE:FRAMe<fr>:PADZero? SBUS<sb>:RFFE:FRAMe<fr>:PADone? SBUS<sb>:RFFE:FRAMe<fr>:PCTRl?	Replaced since FW 2.6

18.23.3.15 Manchester

Table 18-30: Manchester decode results

Legacy command	Replaced by	Comment
SBUS<sb>:MANCh:FRAMe<fr>:RES1?	SBUS<sb>:MANCh:FRAMe<fr>:CONE?	Replaced since FW 2.9
SBUS<sb>:MANCh:FRAMe<fr>:RES2?	SBUS<sb>:MANCh:FRAMe<fr>:CTWO?	
SBUS<sb>:MANCh:FRAMe<fr>:RES3?	SBUS<sb>:MANCh:FRAMe<fr>:CTHRee?	

18.23.3.16 NRZ clocked**Table 18-31: NRZ clocked decode results**

Legacy command	Replaced by	Comment
SBUS<sb>:NRZC:FRAMe<fr>:RES1?	SBUS<sb>:NRZC:FRAMe<fr>:CONE?	Replaced since FW 2.9
SBUS<sb>:NRZC:FRAMe<fr>:RES2?	SBUS<sb>:NRZC:FRAMe<fr>:CTWO?	
SBUS<sb>:NRZC:FRAMe<fr>:RES3?	SBUS<sb>:NRZC:FRAMe<fr>:CTHRee?	

18.23.3.17 NRZ unlocked**Table 18-32: NRZ unlocked decode results**

Legacy command	Replaced by	Comment
SBUS<sb>:NRZU:FRAMe<fr>:RES1?	SBUS<sb>:NRZU:FRAMe<fr>:CONE?	Replaced since FW 2.9
SBUS<sb>:NRZU:FRAMe<fr>:RES2?	SBUS<sb>:NRZU:FRAMe<fr>:CTWO?	
SBUS<sb>:NRZU:FRAMe<fr>:RES3?	SBUS<sb>:NRZU:FRAMe<fr>:CTHRee?	

18.23.3.18 10BASE-T1S**Table 18-33: 10BASE-T1S configuration**

Legacy command	Replaced by	Comment
SBUS<sb>:TNOS:HYSTeresis	-	No longer needed since FW 2.6

Table 18-34: 10BASE-T1S decode results

Legacy command	Replaced by	Comment
SBUS<sb>:TNOS:FRAMe<fr>:COUNT	-	No longer needed since FW 2.6
SBUS<sb>:TNOS:FRAMe<fr>:BYTE<o>:COUNT		
SBUS<sb>:TNOS:FRAMe<fr>:BCOunt	SBUS<sb>:TNOS:FRAMe<fr>:FLDCount?	Replaced since FW 2.6
SBUS<sb>:TNOS:FRAMe<fr>:BYTE<o>:FVALue	SBUS<sb>:TNOS:FRAMe<fr>:FLD<fl>:FVALue?	
SBUS<sb>:TNOS:FRAMe<fr>:BYTE<o>:LABel	SBUS<sb>:TNOS:FRAMe<fr>:FLD<fl>:LABel?	
SBUS<sb>:TNOS:FRAMe<fr>:BYTE<o>:STATe	SBUS<sb>:TNOS:FRAMe<fr>:FLD<fl>:STATe?	
SBUS<sb>:TNOS:FRAMe<fr>:BYTE<o>:VALue	SBUS<sb>:TNOS:FRAMe<fr>:FLD<fl>:VALue?	

18.23.3.19 100BASE-T1**Table 18-35: 100BASE-T1 decode results**

Legacy command	Replaced by	Comment
SBUS<sb>:HBTO:FRAMe<fr>:BYTE<o>:COUNT SBUS<sb>:HBTO:FRAMe<fr>:COUNT	-	No longer needed since FW 2.6
SBUS<sb>:HBTO:FRAMe<fr>:BCount? SBUS<sb>:HBTO:FRAMe<fr>:BYTE<o>:FVALue SBUS<sb>:HBTO:FRAMe<fr>:BYTE<o>:LABel SBUS<sb>:HBTO:FRAMe<fr>:BYTE<o>:STATe SBUS<sb>:HBTO:FRAMe<fr>:BYTE<o>:VALue	SBUS<sb>:CAN:FRAMe<fr>:FLDCount? SBUS<sb>:HBTO:FRAMe<fr>:FLD<fl>:FVALue? SBUS<sb>:HBTO:FRAMe<fr>:FLD<fl>:LABel? SBUS<sb>:HBTO:FRAMe<fr>:FLD<fl>:STATe? SBUS<sb>:HBTO:FRAMe<fr>:FLD<fl>:VALue?	Replaced since FW 2.6

18.23.3.20 1000BASE-T1**Table 18-36: 1000BASE-T1 configuration**

Legacy command	Replaced by	Comment
SBUS<sb>:TBTO:FRAMe<fr>:COUNT	SBUS<sb>:TBTO:FCOUNT?	Replaced since FW 2.8
SBUS<sb>:TBTO:SYMRate SBUS<sb>:TBTO:WNDSIZE	-	Obsolete since FW 2.8

19 Maintenance and support

The instrument does not need periodic maintenance. Only the cleaning of the instrument is essential.

We advise to check the nominal data from time to time.

To protect the front panel and to transport the instrument to another workplace safely and easily, various accessories are provided. Refer to the specifications document for available covers and cases and their order numbers.

19.1 Cleaning

How to clean the product is described in "[Cleaning the product](#)" on page 28.

Do not use any liquids for cleaning. Cleaning agents, solvents, acids and bases can damage the front panel labeling, plastic parts and display.

19.2 Changing fuses

If the product does not start, it is possible that a blown fuse is the cause.

The product is protected by 2 fuses of type Size 5x20 mm, 250V~, T5H (slow-blow), IEC 60127-2 (order no. 0099.6735.00), order number 0099.6735.00.

1. **WARNING!** The fuse is part of the AC power supply. Handling the fuse while the power is on can lead to electric shock.
Before changing the fuse:
 - a) Set the switch on the power supply to position [0].
 - b) Disconnect the product from the power source.
2. The fuse slot is on the rear panel between the mains switch and AC power supply connector.
Pull out the fuse holder.
3. Check the condition of the fuse.
4. Replace the blown fuse. Only use a fuse of the specified type.
5. Insert the fuse holder into its slot until it latches.

19.3 Contacting customer support

Technical support – where and when you need it

For quick, expert help with any Rohde & Schwarz product, contact our customer support center. A team of highly qualified engineers provides support and works with you to find a solution to your query on any aspect of the operation, programming or applications of Rohde & Schwarz products.

Contact information

Contact our customer support center at www.rohde-schwarz.com/support, or follow this QR code:



Figure 19-1: QR code to the Rohde & Schwarz support page

19.4 Information for technical support

If you encounter problems that you cannot solve yourself, contact your Rohde & Schwarz support center, see [Contacting customer support](#).

The support center finds solutions more quickly and efficiently, if you provide them with information on the instrument and an error description. To create, collect and save the required information, you can create a service report.

The service report is a ZIP file with a complete bug report, all relevant setup information, reporting and log files, alignment files, and the instrument configuration.

1. Open the "Settings" > "Maintenance" dialog.
2. Select the "Service" tab.
3. Tap "Create report".
If a USB flash drive is connected, the report is saved on the USB flash drive. Otherwise, the report is saved in the user data folder `/home/storage/userData`.
4. Create a support ticket that describes the problem, and attach the report file.

See also: [Section 5.7.5, "Service"](#), on page 113.

19.5 Data security

If you have to send the instrument to the service, or if the instrument is used in a secured environment, consider the document "Instrument Security Procedures" that is delivered on the MXO 5C webpage.

19.6 Transporting

Lifting and carrying

See: ["Lifting and carrying the instrument"](#) on page 24

Packing

Use the original packaging material. It consists of antistatic wrap for electrostatic protection and packing material designed for the product.

If you do not have the original packaging, use similar materials that provide the same level of protection. You can also contact your local Rohde & Schwarz service center for advice.

Securing

When moving the MXO 5C in a vehicle or using transporting equipment, make sure that the MXO 5C is properly secured. Only use items intended for securing objects.

Transport altitude

Unless otherwise specified in the specifications document, the maximum transport altitude without pressure compensation is 4500 m above sea level.

19.7 Storage

Protect the product against dust. Ensure that the environmental conditions, e.g. temperature range and climatic load, meet the values specified in the specifications document.

19.8 Disposal

Rohde & Schwarz is committed to making careful, ecologically sound use of natural resources and minimizing the environmental footprint of our products. Help us by disposing of waste in a way that causes minimum environmental impact.

Disposing of electrical and electronic equipment

A product that is labeled as follows cannot be disposed of in normal household waste after it has come to the end of its life. Even disposal via the municipal collection points for waste electrical and electronic equipment is not permitted.



Figure 19-2: Labeling in line with EU directive WEEE

Rohde & Schwarz has developed a disposal concept for the eco-friendly disposal or recycling of waste material. As a manufacturer, Rohde & Schwarz completely fulfills its obligation to take back and dispose of electrical and electronic waste. Contact your local service representative to dispose of the product.

List of commands

*CAL?	917
*CLS	918
*IDN?	918
*OPC	918
*OPT?	918
*RCL	918
*RST	919
*SAV	919
*SRE	919
*STB?	919
*TRG	920
*TST?	920
*WAI	920
ACQuire:AVailable?	966
ACQuire:AVERage?	967
ACQuire:COUnT	967
ACQuire:CURRent?	967
ACQuire:DRESolution?	1848
ACQuire:HISTory:CURRent	1078
ACQuire:HISTory:ISODate?	1078
ACQuire:HISTory:PLAY	1079
ACQuire:HISTory:REPLay	1079
ACQuire:HISTory:START	1079
ACQuire:HISTory:STOP	1079
ACQuire:HISTory:TPACq	1080
ACQuire:HISTory:TSABsolute?	1080
ACQuire:HISTory:TSDate?	1080
ACQuire:HISTory:TSRRelative?	1080
ACQuire:HISTory:TSRReference?	1081
ACQuire:HISTory[:STATe]	1081
ACQuire:INTErpolate	967
ACQuire:POINts:ARATe?	968
ACQuire:POINts:DVALue?	1849
ACQuire:POINts:MAXimum	968
ACQuire:POINts:MODE	968
ACQuire:POINts[:VALue]	968
ACQuire:POMemory?	969
ACQuire:RESolution?	969
ACQuire:RLReal?	970
ACQuire:ROLLmode:OSCapture	965
ACQuire:ROLLmode:POINts?	965
ACQuire:SEGMENTed:MAX	1002
ACQuire:SEGMENTed:STATe	1002
ACQuire:SRATe:MINimum	970
ACQuire:SRATe:MODE	970
ACQuire:SRATe[:VALue]	970
ACQuire:SRReal?	971

ACQuire:TYPE.....	971
AUToscale.....	963
CALCulate:MATH<m>:DATA:HEADer?.....	1076
CALCulate:MATH<m>:DATA:STYPe?.....	1077
CALCulate:MATH<m>:DATA[:VALues]?.....	1077
CALCulate:MATH<m>:ENVSelection.....	1076
CALCulate:MATH<m>:LABel.....	1075
CALCulate:MATH<m>:STATe.....	1073
CALCulate:MATH<m>:UNIT.....	1075
CALCulate:MATH<m>:VERTical:OFFSet.....	1075
CALCulate:MATH<m>:VERTical:SCALE:MODE.....	1076
CALCulate:MATH<m>:VERTical:SCALE[:VALue].....	1075
CALCulate:MATH<m>[:EXPReSSion][:DEFine].....	1073
CALCulate:SPECTrum<sp>:FREQuency:BANDwidth[:RESolution]:ADJJusted?.....	1158
CALCulate:SPECTrum<sp>:FREQuency:BANDwidth[:RESolution]:AUTO.....	1158
CALCulate:SPECTrum<sp>:FREQuency:BANDwidth[:RESolution]:RATio.....	1159
CALCulate:SPECTrum<sp>:FREQuency:BANDwidth[:RESolution][:VALue].....	1159
CALCulate:SPECTrum<sp>:FREQuency:CENTer.....	1159
CALCulate:SPECTrum<sp>:FREQuency:SCALE.....	1160
CALCulate:SPECTrum<sp>:FREQuency:SPAN.....	1160
CALCulate:SPECTrum<sp>:FREQuency:STARt.....	1160
CALCulate:SPECTrum<sp>:FREQuency:STOP.....	1161
CALCulate:SPECTrum<sp>:FREQuency:WINDow:TYPE.....	1161
CALCulate:SPECTrum<sp>:GATE:POSition.....	1166
CALCulate:SPECTrum<sp>:GATE:STARt.....	1166
CALCulate:SPECTrum<sp>:GATE:STOP.....	1166
CALCulate:SPECTrum<sp>:GATE:WIDTh.....	1167
CALCulate:SPECTrum<sp>:MAGNitude:LEVel.....	1162
CALCulate:SPECTrum<sp>:MAGNitude:RANGe.....	1162
CALCulate:SPECTrum<sp>:MAGNitude:SCALE.....	1162
CALCulate:SPECTrum<sp>:OVERlap:ENABle.....	1171
CALCulate:SPECTrum<sp>:OVERlap:FACTor:ADJJusted?.....	1172
CALCulate:SPECTrum<sp>:OVERlap:FACTor:VALue.....	1172
CALCulate:SPECTrum<sp>:OVERlap:FCOunt:ADJJusted?.....	1173
CALCulate:SPECTrum<sp>:OVERlap:FCOunt:LIMit:ENABle.....	1172
CALCulate:SPECTrum<sp>:OVERlap:FCOunt:VALue.....	1173
CALCulate:SPECTrum<sp>:OVERlap:FWIDTh?.....	1173
CALCulate:SPECTrum<sp>:PEXCursion.....	1164
CALCulate:SPECTrum<sp>:PLISt:COUNT?.....	1167
CALCulate:SPECTrum<sp>:PLISt:LABel:BORDER.....	953
CALCulate:SPECTrum<sp>:PLISt:LABel:FREQuency[:STATe].....	1170
CALCulate:SPECTrum<sp>:PLISt:LABel:INVert.....	1170
CALCulate:SPECTrum<sp>:PLISt:LABel:MAXCount.....	1170
CALCulate:SPECTrum<sp>:PLISt:LABel:MAXCount.....	1171
CALCulate:SPECTrum<sp>:PLISt:LABel[:STATe].....	1171
CALCulate:SPECTrum<sp>:PLISt:MAXCount.....	1168
CALCulate:SPECTrum<sp>:PLISt:MODE.....	1168
CALCulate:SPECTrum<sp>:PLISt:RESult[:VALue]?.....	1169
CALCulate:SPECTrum<sp>:PLISt:SORT:COLumn.....	1169
CALCulate:SPECTrum<sp>:PLISt:SORT:ORDer.....	1170

CALCulate:SPECTrum<sp>:PLISt:SOURce.....	1168
CALCulate:SPECTrum<sp>:PLISt:SPOW.....	1169
CALCulate:SPECTrum<sp>:PLISt[:STATe].....	1168
CALCulate:SPECTrum<sp>:PRESet.....	1163
CALCulate:SPECTrum<sp>:SOURce.....	1163
CALCulate:SPECTrum<sp>:STATe.....	1163
CALCulate:SPECTrum<sp>:THReshold.....	1164
CALCulate:SPECTrum<sp>:WAVEform:AVERage:COUNT.....	1164
CALCulate:SPECTrum<sp>:WAVEform:AVERage:DATA:HEADer?.....	1174
CALCulate:SPECTrum<sp>:WAVEform:AVERage:DATA[:VALues]?.....	1174
CALCulate:SPECTrum<sp>:WAVEform:AVERage:ENABle.....	1165
CALCulate:SPECTrum<sp>:WAVEform:MAXimum:DATA:HEADer?.....	1174
CALCulate:SPECTrum<sp>:WAVEform:MAXimum:DATA[:VALues]?.....	1174
CALCulate:SPECTrum<sp>:WAVEform:MAXimum:ENABle.....	1165
CALCulate:SPECTrum<sp>:WAVEform:MINimum:DATA:HEADer?.....	1174
CALCulate:SPECTrum<sp>:WAVEform:MINimum:DATA[:VALues]?.....	1174
CALCulate:SPECTrum<sp>:WAVEform:MINimum:ENABle.....	1165
CALCulate:SPECTrum<sp>:WAVEform:NORMal:DATA:FRAME<fr>[:VALues]?.....	1175
CALCulate:SPECTrum<sp>:WAVEform:NORMal:DATA:HEADer?.....	1174
CALCulate:SPECTrum<sp>:WAVEform:NORMal:DATA[:VALues]?.....	1174
CALCulate:SPECTrum<sp>:WAVEform:NORMal[:ENABle].....	1165
CALibration:DATE?.....	960
CALibration:RESult?.....	961
CALibration:TIME?.....	961
CALibration[:ALL].....	960
CHANnel<ch>:ADCState:STATus:NCLipping:CONDition?.....	1880
CHANnel<ch>:ADCState:STATus:NCLipping:ENABle.....	1881
CHANnel<ch>:ADCState:STATus:NCLipping:NTRansition.....	1882
CHANnel<ch>:ADCState:STATus:NCLipping:PTRansition.....	1883
CHANnel<ch>:ADCState:STATus:NCLipping[:EVENT]?.....	1881
CHANnel<ch>:ADCState:STATus:PCLipping:CONDition?.....	1880
CHANnel<ch>:ADCState:STATus:PCLipping:ENABle.....	1881
CHANnel<ch>:ADCState:STATus:PCLipping:NTRansition.....	1882
CHANnel<ch>:ADCState:STATus:PCLipping:PTRansition.....	1883
CHANnel<ch>:ADCState:STATus:PCLipping[:EVENT]?.....	1881
CHANnel<ch>:BANDwidth.....	975
CHANnel<ch>:COUPling.....	974
CHANnel<ch>:DATA:HEADer?.....	1004
CHANnel<ch>:DATA[:VALues]?.....	1004
CHANnel<ch>:EATScale.....	976
CHANnel<ch>:EATTenuation.....	976
CHANnel<ch>:IMPedance.....	977
CHANnel<ch>:INVert.....	974
CHANnel<ch>:OFFSet.....	973
CHANnel<ch>:OVERload:STATus:CONDition?.....	1880
CHANnel<ch>:OVERload:STATus:ENABle.....	1881
CHANnel<ch>:OVERload:STATus:NTRansition.....	1882
CHANnel<ch>:OVERload:STATus:PTRansition.....	1883
CHANnel<ch>:OVERload:STATus[:EVENT].....	1881
CHANnel<ch>:POSition.....	973

CHANnel<ch>:PPSupply:STATus:CONDition?	1880
CHANnel<ch>:PPSupply:STATus:ENABle	1881
CHANnel<ch>:PPSupply:STATus:NTRansition	1882
CHANnel<ch>:PPSupply:STATus:PTRansition	1883
CHANnel<ch>:PPSupply:STATus[:EVENT]	1881
CHANnel<ch>:RANGe	972
CHANnel<ch>:SCALE	972
CHANnel<ch>:SKEW:TIME	975
CHANnel<ch>:STATe	972
CHANnel<ch>:WARNOverload:STATus:CONDition?	1880
CHANnel<ch>:WARNOverload:STATus:ENABle	1881
CHANnel<ch>:WARNOverload:STATus:NTRansition	1882
CHANnel<ch>:WARNOverload:STATus:PTRansition	1883
CHANnel<ch>:WARNOverload:STATus[:EVENT]?	1881
CURSor<cu>:AOFF	1145
CURSor<cu>:COUNT?	1145
CURSor<cu>:DISPlay:VALues	1151
CURSor<cu>:FFT:SETCenter	1155
CURSor<cu>:FFT:TOCenter	1155
CURSor<cu>:FUNCTion	1145
CURSor<cu>:HORIZontal<n>:LABel	1151
CURSor<cu>:LABel	1150
CURSor<cu>:MAXimum:LEFT	1156
CURSor<cu>:MAXimum:NEXT	1156
CURSor<cu>:MAXimum:RIGHT	1156
CURSor<cu>:MAXimum[:PEAK]	1156
CURSor<cu>:PEXCursion	1156
CURSor<cu>:SIAD	1152
CURSor<cu>:SMODE	1146
CURSor<cu>:SOURce	1146
CURSor<cu>:SSCReen	1150
CURSor<cu>:SSOURce	1148
CURSor<cu>:STATe	1145
CURSor<cu>:STYLE	1157
CURSor<cu>:TRACking[:STATe]	1150
CURSor<cu>:USSource	1147
CURSor<cu>:VERTical<n>:LABel	1151
CURSor<cu>:X1ENvelope	1153
CURSor<cu>:X1Position	1148
CURSor<cu>:X2ENvelope	1153
CURSor<cu>:X2Position	1148
CURSor<cu>:XCoupling	1152
CURSor<cu>:XDELta:INVerse?	1154
CURSor<cu>:XDELta[:VALue]?	1154
CURSor<cu>:Y1Position	1149
CURSor<cu>:Y2Position	1150
CURSor<cu>:YCOupling	1152
CURSor<cu>:YDELta:SLOPe?	1155
CURSor<cu>:YDELta[:VALue]?	1154
DIGital<m>:DATA:HEADer?	1849

DIGital<m>:DATA[:VALues]?	1850
DIGital<m>:HYSTeresis	1837
DIGital<m>:LABel	1838
DIGital<m>:PROBe<ch>[:ENABLE]?	1837
DIGital<m>:SIZE	1838
DIGital<m>:SKEW	1839
DIGital<m>:STATe	1839
DIGital<m>:TECHnology	1839
DIGital<m>:THCOupling	1840
DIGital<m>:THReshold	1840
DISPlay:ANNotation:ARRow<m>:CLEar	940
DISPlay:ANNotation:ARRow<m>:COLor	940
DISPlay:ANNotation:ARRow<m>:DIRection	941
DISPlay:ANNotation:ARRow<m>:HEIGHt	941
DISPlay:ANNotation:ARRow<m>:HORizontal:POSition	941
DISPlay:ANNotation:ARRow<m>:REMOve	941
DISPlay:ANNotation:ARRow<m>:VERTical:POSition	942
DISPlay:ANNotation:ARRow<m>:WIDTh	942
DISPlay:ANNotation:ARRow<m>[:VALue]	942
DISPlay:ANNotation:CLEar	936
DISPlay:ANNotation:COLor<m>:CATalog?	937
DISPlay:ANNotation:PLINe<m>:CLEar	945
DISPlay:ANNotation:PLINe<m>:COLor	945
DISPlay:ANNotation:PLINe<m>:EXTend	945
DISPlay:ANNotation:PLINe<m>:REMOve	946
DISPlay:ANNotation:PLINe<m>[:VALue]	946
DISPlay:ANNotation:RECTangle<m>:CLEar	937
DISPlay:ANNotation:RECTangle<m>:COLor	938
DISPlay:ANNotation:RECTangle<m>:HEIGHt	938
DISPlay:ANNotation:RECTangle<m>:HORizontal:POSition	938
DISPlay:ANNotation:RECTangle<m>:REMOve	939
DISPlay:ANNotation:RECTangle<m>:VERTical:POSition	939
DISPlay:ANNotation:RECTangle<m>:WIDTh	939
DISPlay:ANNotation:RECTangle<m>[:VALue]	939
DISPlay:ANNotation:TEXT<m>:CLEar	943
DISPlay:ANNotation:TEXT<m>:COLor	943
DISPlay:ANNotation:TEXT<m>:FONTsize	943
DISPlay:ANNotation:TEXT<m>:HORizontal:POSition	944
DISPlay:ANNotation:TEXT<m>:REMOve	944
DISPlay:ANNotation:TEXT<m>:VERTical:POSition	944
DISPlay:ANNotation:TEXT<m>[:VALue]	944
DISPlay:ANNotation:TRANSparency	937
DISPlay:BACKlight:DIMMING	956
DISPlay:BACKlight[:BRIGtness]	956
DISPlay:CLR	956
DISPlay:COLor:SIGNAL:ASSign	947
DISPlay:COLor:SIGNAL:CATalog?	947
DISPlay:COLor:SIGNAL:COLor	947
DISPlay:COLor:SIGNAL:USE	948
DISPlay:DIAGram:CROSShair	951

DISPlay:DIAGram:FINegrid.....	951
DISPlay:DIAGram:GRID.....	951
DISPlay:DIAGram:LABels.....	951
DISPlay:DIAGram:STYLe.....	955
DISPlay:DIAGram:XFIXed.....	952
DISPlay:DIAGram:XPDivlabel.....	952
DISPlay:DIAGram:YFIXed.....	952
DISPlay:DIALog:FONTsize.....	953
DISPlay:DIALog:TRANsparency.....	953
DISPlay:INTensity.....	955
DISPlay:PERsistence:INFinite.....	954
DISPlay:PERsistence:RESet.....	954
DISPlay:PERsistence:TIME.....	954
DISPlay:PERsistence[:STATe].....	955
DISPlay:RESult:FONTsize.....	953
DISPlay:SIGNAL:LABel.....	974
DISPlay:TOOLbar:COUNt?.....	934
DISPlay:TOOLbar:DESelect.....	934
DISPlay:TOOLbar:RESTore.....	934
EXPort:HISTogram<m>:DATA:HEADer?.....	1096
EXPort:HISTogram<m>:DATA[:VALues]?.....	1096
EXPort:HISTogram<m>:NAME.....	1111
EXPort:HISTogram<m>:NORMalize.....	1110
EXPort:HISTogram<m>:SAVE.....	1111
EXPort:RESult:NAME.....	1113
EXPort:RESult:SAVE.....	1113
EXPort:RESult:SElect:CURSor.....	1113
EXPort:RESult:SElect:FRA:MARGin.....	1208
EXPort:RESult:SElect:FRA:MARKer.....	1208
EXPort:RESult:SElect:FRA:RESult.....	1208
EXPort:RESult:SElect:MEASurement.....	1114
EXPort:RESult:SElect:P3PHase<m>.....	1276
EXPort:RESult:SElect:POWER<m>.....	1211
EXPort:WAVEform:ABORT.....	1105
EXPort:WAVEform:AUTonaming:NAME.....	1105
EXPort:WAVEform:AUTonaming:PATH.....	1106
EXPort:WAVEform:AUTonaming:TYPE.....	1106
EXPort:WAVEform:CURSorset.....	1106
EXPort:WAVEform:DATA[:VALues]?.....	1109
EXPort:WAVEform:GATE.....	1106
EXPort:WAVEform:NAME.....	1107
EXPort:WAVEform:SAVE.....	1107
EXPort:WAVEform:SCOPE.....	1107
EXPort:WAVEform:SOURce.....	1108
EXPort:WAVEform:START.....	1109
EXPort:WAVEform:STOP.....	1109
EYE<e>:DISPlay:PERsistence:INFinite.....	1315
EYE<e>:DISPlay:PERsistence:RESet.....	1315
EYE<e>:DISPlay:PERsistence:STATe.....	1315
EYE<e>:DISPlay:PERsistence:TIME.....	1316

EYE<e>:HORizontal:ABSolute:POSition.....	1316
EYE<e>:HORizontal:ABSolute:RANGe.....	1316
EYE<e>:HORizontal:UINterval:POSition.....	1317
EYE<e>:HORizontal:UINterval:RANGe.....	1317
EYE<e>:HORizontal:UNIT.....	1317
EYE<e>:MSLices.....	1318
EYE<e>:QUALify:GATE.....	1318
EYE<e>:RFLSet.....	1318
EYE<e>:SAMTime.....	1319
EYE<e>:SOURce.....	1319
EYE<e>:STATe.....	1319
EYE<e>:TREFerence.....	1319
EYE<e>:VERTical:COUPle.....	1320
EYE<e>:VERTical:OFFSet.....	1320
EYE<e>:VERTical:POSition.....	1320
EYE<e>:VERTical:SCALe.....	1321
FORMat:BORDER.....	922
FORMat:BPATtern.....	922
FORMat[:DATA].....	921
FRANalysis:AMPLitude:ENABLE.....	1198
FRANalysis:AMPLitude:MODE.....	1188
FRANalysis:AMPLitude:OFFSet.....	1198
FRANalysis:AMPLitude:PROFile:APOint.....	1194
FRANalysis:AMPLitude:PROFile:COUNt.....	1194
FRANalysis:AMPLitude:PROFile:MODE.....	1195
FRANalysis:AMPLitude:PROFile:POINT<m>:AMPLitude.....	1195
FRANalysis:AMPLitude:PROFile:POINT<m>:FREQUENCY.....	1195
FRANalysis:AMPLitude:PROFile:POINT<m>:REMOve.....	1194
FRANalysis:AMPLitude:PROFile:SORT.....	1194
FRANalysis:AMPLitude:SCALe.....	1198
FRANalysis:AUToscale.....	1188
FRANalysis:CALibration:CALibration.....	1196
FRANalysis:CALibration:RESult?.....	1196
FRANalysis:CALibration:STATe.....	1196
FRANalysis:ENABLE.....	1187
FRANalysis:FREQUENCY:DATA?.....	1199
FRANalysis:FREQUENCY:MODE.....	1188
FRANalysis:FREQUENCY:STARt.....	1188
FRANalysis:FREQUENCY:STOP.....	1189
FRANalysis:GAIN:DATA?.....	1199
FRANalysis:GAIN:ENABLE.....	1197
FRANalysis:GAIN:OFFSet.....	1197
FRANalysis:GAIN:SCALe.....	1198
FRANalysis:GENerator:AMPLitude.....	1189
FRANalysis:GENerator:LOAD.....	1189
FRANalysis:GENerator[:CHANnel].....	1189
FRANalysis:HDEFinition[:ENABLE].....	1190
FRANalysis:INPut[:SOURce].....	1190
FRANalysis:MARGIN:GAIN:FREQUENCY?.....	1201
FRANalysis:MARGIN:GAIN:VALue?.....	1201

FRANalysis:MARGin:PHASe:FREQuency?	1201
FRANalysis:MARGin:PHASe:VALue?	1201
FRANalysis:MARGin:STATe	1200
FRANalysis:MARKer<m>:DIFFerence:FREQuency?	1202
FRANalysis:MARKer<m>:DIFFerence:GAIN?	1203
FRANalysis:MARKer<m>:DIFFerence:PHASe?	1203
FRANalysis:MARKer<m>:DIFFerence:REFerence<rc>?	1208
FRANalysis:MARKer<m>:FREQuency	1202
FRANalysis:MARKer<m>:GAIN?	1202
FRANalysis:MARKer<m>:INDex?	1203
FRANalysis:MARKer<m>:PHASe?	1202
FRANalysis:MARKer<m>:REFerence<rc>?	1207
FRANalysis:MARKer<m>:SSCreen	1203
FRANalysis:MARKer<m>:STATe	1201
FRANalysis:MEASurement:DELay:MODE	1190
FRANalysis:MEASurement:DELay:PERiod[:NUMBer]	1191
FRANalysis:MEASurement:DELay:STATe	1190
FRANalysis:MEASurement:DELay[:TIME]	1191
FRANalysis:MEASurement:POINt[:DISPlay]	1191
FRANalysis:MEASurement:RBW	1192
FRANalysis:OUTPut[:SOURce]	1192
FRANalysis:PHASe:DATA?	1199
FRANalysis:PHASe:ENABle	1197
FRANalysis:PHASe:MAXimum	1193
FRANalysis:PHASe:OFFSet	1197
FRANalysis:PHASe:SCALE	1197
FRANalysis:POINts:LOGarithmic	1192
FRANalysis:POINts:MODE	1192
FRANalysis:POINts:TOTal	1193
FRANalysis:REFCurve<rc>:CLEar	1204
FRANalysis:REFCurve<rc>:DATA?	1204
FRANalysis:REFCurve<rc>:ENABle	1206
FRANalysis:REFCurve<rc>:NAME	1204
FRANalysis:REFCurve<rc>:OFFSet	1205
FRANalysis:REFCurve<rc>:OPEN	1205
FRANalysis:REFCurve<rc>:SAVE	1205
FRANalysis:REFCurve<rc>:SCALE	1206
FRANalysis:REFCurve<rc>:SOURce	1206
FRANalysis:REFCurve<rc>:TOORiginal	1206
FRANalysis:REFCurve<rc>:UPDate	1207
FRANalysis:REFCurve<rc>:VMODE	1207
FRANalysis:REPeat	1193
FRANalysis:RESet	1193
FRANalysis:RESult:STATe	1200
FRANalysis:STATe	1187
GATE<g>:ABSolute:START	1055
GATE<g>:ABSolute:STOP	1055
GATE<g>:CURSor	1054
GATE<g>:ENABle	1053
GATE<g>:GCOupling	1053

GATE<g>:MODE.....	1054
GATE<g>:RELative:START.....	1055
GATE<g>:RELative:STOP.....	1055
GATE<g>:SHOW.....	1055
GATE<g>:ZDiagram.....	1054
GENerator:RCL.....	1104
GENerator:SAV.....	1105
GENerator:SYNC[:COMBination].....	1871
HCOPY:DATA?.....	1117
HCOPY:DESTination<m>.....	1114
HCOPY:DEVice<m>:INVerse.....	1115
HCOPY:DEVice<m>:LANGuage.....	1115
HCOPY:IMMEDIATE<m>.....	1116
HCOPY:IMMEDIATE<m>:NEXT.....	1115
HCOPY:ISBA.....	1116
HCOPY:SSD.....	1116
HCOPY:WBKG.....	1117
HDEFinition:BWIDth.....	1003
HDEFinition:RESolution?.....	1003
HDEFinition:STATe.....	1003
HISTogram<m>:ADD.....	1091
HISTogram<m>:COUNT?.....	1091
HISTogram<m>:ENABLE.....	1092
HISTogram<m>:MODE.....	1092
HISTogram<m>:REMove.....	1092
HISTogram<m>:RESet.....	1093
HISTogram<m>:SOURce.....	1093
HISTogram<m>:WINDow:ENABLE.....	1094
HISTogram<m>:WINDow:HORizontal:ABSolute:POSition.....	1094
HISTogram<m>:WINDow:HORizontal:ABSolute:SPAN.....	1094
HISTogram<m>:WINDow:HORizontal:ABSolute:START.....	1094
HISTogram<m>:WINDow:HORizontal:ABSolute:STOP.....	1094
HISTogram<m>:WINDow:HORizontal:MODE.....	1094
HISTogram<m>:WINDow:HORizontal:RELative:POSition.....	1095
HISTogram<m>:WINDow:HORizontal:RELative:SPAN.....	1095
HISTogram<m>:WINDow:HORizontal:RELative:START.....	1095
HISTogram<m>:WINDow:HORizontal:RELative:STOP.....	1095
HISTogram<m>:WINDow:VERTical:ABSolute:POSition.....	1095
HISTogram<m>:WINDow:VERTical:ABSolute:SPAN.....	1095
HISTogram<m>:WINDow:VERTical:ABSolute:START.....	1095
HISTogram<m>:WINDow:VERTical:ABSolute:STOP.....	1095
HISTogram<m>:WINDow:VERTical:MODE.....	1094
HISTogram<m>:WINDow:VERTical:RELative:POSition.....	1095
HISTogram<m>:WINDow:VERTical:RELative:SPAN.....	1095
HISTogram<m>:WINDow:VERTical:RELative:START.....	1095
HISTogram<m>:WINDow:VERTical:RELative:STOP.....	1095
LAYout<ly>:ACTive.....	929
LAYout<ly>:COUNT?.....	928
LAYout<ly>:DIAGram<da>:COUNT?.....	929
LAYout<ly>:DIAGram<da>:LABel.....	930

LAYout<ly>:DIAGram<da>:SOURce.....	930
LAYout<ly>:DIAGram<da>[:ENABle].....	930
LAYout<ly>:LABel.....	929
LAYout<ly>:NODE<no>:CHILdren<o>:CONTeNt<p>:ID.....	931
LAYout<ly>:NODE<no>:CHILdren<o>:CONTeNt<p>:TYPE.....	932
LAYout<ly>:NODE<no>:COUNT?.....	931
LAYout<ly>:NODE<no>:RATio.....	932
LAYout<ly>:NODE<no>:STYPe.....	932
LAYout<ly>:NODE<no>[:ENABle].....	931
LAYout<ly>:RESult<n>:HORizontal:RATio.....	933
LAYout<ly>:RESult<n>:VERTical:RATio.....	933
LAYout<ly>:RPOSition.....	933
LAYout<ly>:SACTive.....	929
LAYout<ly>:ZOOM<zo>:COUNT?.....	1065
LAYout<ly>:ZOOM<zo>:DIAG?.....	1065
LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:POSition.....	1065
LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:SPAN.....	1066
LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:START.....	1066
LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:STOP.....	1066
LAYout<ly>:ZOOM<zo>:HORizontal:ABSolute:WIDTh.....	1067
LAYout<ly>:ZOOM<zo>:HORizontal:MODE.....	1067
LAYout<ly>:ZOOM<zo>:HORizontal:RELative:POSition.....	1067
LAYout<ly>:ZOOM<zo>:HORizontal:RELative:SPAN.....	1068
LAYout<ly>:ZOOM<zo>:HORizontal:RELative:START.....	1068
LAYout<ly>:ZOOM<zo>:HORizontal:RELative:STOP.....	1069
LAYout<ly>:ZOOM<zo>:HORizontal:RELative:WIDTh.....	1069
LAYout<ly>:ZOOM<zo>:SOURce.....	1069
LAYout<ly>:ZOOM<zo>:SSCReen.....	1073
LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:POSition.....	1070
LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:RANGe.....	1070
LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:SPAN.....	1070
LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:START.....	1070
LAYout<ly>:ZOOM<zo>:VERTical:ABSolute:STOP.....	1071
LAYout<ly>:ZOOM<zo>:VERTical:MODE.....	1071
LAYout<ly>:ZOOM<zo>:VERTical:RELative:POSition.....	1071
LAYout<ly>:ZOOM<zo>:VERTical:RELative:SPAN.....	1072
LAYout<ly>:ZOOM<zo>:VERTical:RELative:START.....	1072
LAYout<ly>:ZOOM<zo>:VERTical:RELative:STOP.....	1072
LAYout<ly>:ZOOM<zo>:VERTical:RELative:WIDTh.....	1072
LAYout<ly>:ZOOM<zo>[:ENABle].....	1065
LAYout<ly>[:ENABle].....	928
MDEFaults:SETTings<m>:ENABle.....	1129
MDEFaults:SETTings<m>:EYE:ALGorithm.....	1129
MDEFaults:SETTings<m>:EYE:RELative:START.....	1130
MDEFaults:SETTings<m>:EYE:RELative:STOP.....	1130
MDEFaults:SETTings<m>:EYE:THReShold.....	1130
MEASurement<mg>:ACTive.....	1118
MEASurement<mg>:AMPTime:CSLoPe.....	1122
MEASurement<mg>:AMPTime:DELay<n>:DIRection.....	1124
MEASurement<mg>:AMPTime:DELay<n>:SLOPe.....	1124

MEASurement<mg>:AMPTime:DTOTrigger<n>:SLOPe.....	1124
MEASurement<mg>:AMPTime:ESLOPe.....	1123
MEASurement<mg>:AMPTime:PHASe:UNIT.....	1125
MEASurement<mg>:AMPTime:PSLOPe.....	1123
MEASurement<mg>:AMPTime:PTCount.....	1123
MEASurement<mg>:CLEar.....	1140
MEASurement<mg>:COUNT?.....	1118
MEASurement<mg>:DISPlay:REFLevel<rl>:LEVel.....	1121
MEASurement<mg>:DISPlay:RESults.....	1121
MEASurement<mg>:ENVSelect.....	1121
MEASurement<mg>:EYE:ABSolute:STARt.....	1131
MEASurement<mg>:EYE:ABSolute:STOP.....	1131
MEASurement<mg>:EYE:ALGorithm.....	1132
MEASurement<mg>:EYE:DEFSettings.....	1132
MEASurement<mg>:EYE:LEVel.....	1133
MEASurement<mg>:EYE:MODE.....	1133
MEASurement<mg>:EYE:RELative:STARt.....	1133
MEASurement<mg>:EYE:RELative:STOP.....	1134
MEASurement<mg>:EYE:USELevel.....	1134
MEASurement<mg>:FSRC.....	1119
MEASurement<mg>:GATE.....	1121
MEASurement<mg>:IMPRecise:STATus:CONDition?.....	1880
MEASurement<mg>:IMPRecise:STATus:ENABle.....	1881
MEASurement<mg>:IMPRecise:STATus:NTRansition.....	1882
MEASurement<mg>:IMPRecise:STATus:PTRansition.....	1883
MEASurement<mg>:IMPRecise:STATus[:EVENT]?.....	1881
MEASurement<mg>:JITTer:NCYCles.....	1126
MEASurement<mg>:JITTer:POLarity.....	1126
MEASurement<mg>:JITTer:REFLevel<rl>.....	1126
MEASurement<mg>:JITTer:RELPolarity.....	1127
MEASurement<mg>:JITTer:SLOPe.....	1128
MEASurement<mg>:JITTer:TREF.....	1128
MEASurement<mg>:JITTer:UNIT.....	1129
MEASurement<mg>:LIMit:STATus:CONDition?.....	1880
MEASurement<mg>:LIMit:STATus:ENABle.....	1881
MEASurement<mg>:LIMit:STATus:NTRansition.....	1882
MEASurement<mg>:LIMit:STATus:PTRansition.....	1883
MEASurement<mg>:LIMit:STATus[:EVENT]?.....	1881
MEASurement<mg>:MAIN.....	1120
MEASurement<mg>:MNOMeas.....	1141
MEASurement<mg>:MULTiple.....	1140
MEASurement<mg>:PROTocol:F2Name.....	1136
MEASurement<mg>:PROTocol:FD2Name.....	1136
MEASurement<mg>:PROTocol:FD2Value.....	1136
MEASurement<mg>:PROTocol:FDName.....	1135
MEASurement<mg>:PROTocol:FDValue.....	1135
MEASurement<mg>:PROTocol:FNAME.....	1135
MEASurement<mg>:REFLevel<rl>:REFerence.....	1125
MEASurement<mg>:REFLevel<rl>:RESult:LOWer?.....	1052
MEASurement<mg>:REFLevel<rl>:RESult:MIDDLE?.....	1052

MEASurement<mg>:REFLevel<rl>:RESult:SIGHigh?	1052
MEASurement<mg>:REFLevel<rl>:RESult:SIGLow?	1052
MEASurement<mg>:REFLevel<rl>:RESult:UPPer?	1052
MEASurement<mg>:RESult:AVG?	1137
MEASurement<mg>:RESult:EVENTs:COUNT?	1138
MEASurement<mg>:RESult:EVENTs:START?	1138
MEASurement<mg>:RESult:EVENTs:STOP?	1139
MEASurement<mg>:RESult:EVENTs:VALue?	1139
MEASurement<mg>:RESult:EVTCount?	1137
MEASurement<mg>:RESult:NPEak?	1137
MEASurement<mg>:RESult:PPEak?	1137
MEASurement<mg>:RESult:RMS?	1137
MEASurement<mg>:RESult:RSTDdev?	1137
MEASurement<mg>:RESult:START?	1138
MEASurement<mg>:RESult:STDDev?	1137
MEASurement<mg>:RESult:STOP?	1138
MEASurement<mg>:RESult:WFMCount?	1137
MEASurement<mg>:RESult[:ACTual]?	1137
MEASurement<mg>:SOURce	1118
MEASurement<mg>:SSRC	1119
MEASurement<mg>:STATistics:ARESet	1140
MEASurement<mg>:STATistics:RESet	1140
MEASurement<mg>:STATistics[:ENABLE]	1140
MEASurement<mg>:TRACk:AUTO	1141
MEASurement<mg>:TRACk:CONTiunous	1142
MEASurement<mg>:TRACk:DATA:HEADer?	1143
MEASurement<mg>:TRACk:DATA[:VALues]?	1143
MEASurement<mg>:TRACk:OFFSet	1142
MEASurement<mg>:TRACk:SCALe	1142
MEASurement<mg>:TRACk[:STATe]	1141
MEASurement<mg>[:ENABLE]	1118
METer:BANDwidth	1310
METer:DVMeter<m>:ACRMs:ENABle	1311
METer:DVMeter<m>:ACRMs:RESult?	1311
METer:DVMeter<m>:DC:ENABle	1312
METer:DVMeter<m>:DC:RESult?	1312
METer:DVMeter<m>:DCRMs:ENABle	1312
METer:DVMeter<m>:DCRMs:RESult?	1313
METer:DVMeter<m>:ENABle?	1311
METer:MTIME	1313
MMEMory:ATTRibute	1102
MMEMory:AUSave:ENABle	957
MMEMory:AUSave:INTerval	958
MMEMory:AUTonaming:DEFaultpath	958
MMEMory:AUTonaming:INDex	957
MMEMory:AUTonaming:PREFix	957
MMEMory:AUTonaming:RESall	958
MMEMory:AUTonaming:RESPath	958
MMEMory:AUTonaming:TEXT	959
MMEMory:AUTonaming:TIME	957

MMEMory:AUTonaming:USERtext.....	958
MMEMory:CATalog:LENGth?.....	1100
MMEMory:CATalog?.....	1100
MMEMory:CDIRectory.....	1099
MMEMory:COpy.....	1101
MMEMory:DATA.....	1102
MMEMory:DCATalog:LENGth?.....	1099
MMEMory:DCATalog?.....	1098
MMEMory:DELeTe.....	1101
MMEMory:DRIVes?.....	1098
MMEMory:GENerator:RCL.....	1103
MMEMory:GENerator:SAV.....	1104
MMEMory:LOAD:STATe.....	1103
MMEMory:MDIRectory.....	1099
MMEMory:MOVE.....	1101
MMEMory:NAME.....	1115
MMEMory:NDRive<m>:CONNeCt.....	926
MMEMory:NDRive<m>:DCONNeCt.....	926
MMEMory:NDRive<m>:LPATh.....	926
MMEMory:NDRive<m>:NPATh.....	926
MMEMory:NDRive<m>:PWORd.....	927
MMEMory:NDRive<m>:UNAMe.....	927
MMEMory:RCL.....	1103
MMEMory:RDIRectory.....	1099
MMEMory:SAV.....	1102
MMEMory:STORE:STATe.....	1103
MTESt<m>:ADD.....	1176
MTESt<m>:COUNT?.....	1177
MTESt<m>:DIAGram.....	1177
MTESt<m>:IMEXport:NAME.....	1177
MTESt<m>:IMEXport:OPEN.....	1177
MTESt<m>:IMEXport:SAVE.....	1178
MTESt<m>:ONViolation:BEEP.....	1183
MTESt<m>:ONViolation:SCREenshot.....	1183
MTESt<m>:ONViolation:STOP.....	1183
MTESt<m>:ONViolation:TRIGgerout.....	1184
MTESt<m>:ONViolation:WFMSave.....	1184
MTESt<m>:REMOve.....	1178
MTESt<m>:RESult:COUNT:FWAVEforms?.....	1185
MTESt<m>:RESult:COUNT:PWAVEforms?.....	1185
MTESt<m>:RESult:COUNT:WAVEforms?.....	1185
MTESt<m>:RESult:FRATe?.....	1186
MTESt<m>:RESult[:RESult]?.....	1186
MTESt<m>:SEGMeNt<n>:ADD.....	1179
MTESt<m>:SEGMeNt<n>:COUNT?.....	1179
MTESt<m>:SEGMeNt<n>:POINt<o>:ADD.....	1180
MTESt<m>:SEGMeNt<n>:POINt<o>:COUNT?.....	1180
MTESt<m>:SEGMeNt<n>:POINt<o>:REMOve.....	1181
MTESt<m>:SEGMeNt<n>:POINt<o>:VALId?.....	1181
MTESt<m>:SEGMeNt<n>:POINt<o>:X.....	1181

MTESt<m>:SEGMENT<n>:POINT<o>:Y.....	1182
MTESt<m>:SEGMENT<n>:REMove.....	1182
MTESt<m>:SEGMENT<n>:VALid?.....	1182
MTESt<m>:SOURce.....	1178
MTESt<m>:STATe.....	1178
MTESt<m>:VISible.....	1179
P3PHase<m>:HARMonics:AVAIlable<n>.....	1295
P3PHase<m>:HARMonics:DISPlay:BARGraph:VERTical:SCALE:TYPE.....	1294
P3PHase<m>:HARMonics:DISPlay:BARGraph[:ENABLE].....	1293
P3PHase<m>:HARMonics:DISPlay:HARMonics:START[:VALue].....	1294
P3PHase<m>:HARMonics:DISPlay:HARMonics:STOP[:VALue].....	1294
P3PHase<m>:HARMonics:DISPlay:HARMonics[:DISPlay].....	1294
P3PHase<m>:HARMonics:DISPlay:POWer<n>:WAVEform[:ENABLE].....	1301
P3PHase<m>:HARMonics:DISPlay:TOTal:POWer:WAVEform[:ENABLE].....	1301
P3PHase<m>:HARMonics:FREQuency:EN.....	1291
P3PHase<m>:HARMonics:MEASurement:CSOURCE:FREQuency<n>[:ACTual]?.....	1295
P3PHase<m>:HARMonics:MEASurement:POWer<n>:ACTive[:ACTual]?.....	1296
P3PHase<m>:HARMonics:MEASurement:THDFundament<n>[:ACTual]?.....	1296
P3PHase<m>:HARMonics:MEASurement:THDRms<n>[:ACTual]?.....	1296
P3PHase<m>:HARMonics:PFACTOR:MODE.....	1292
P3PHase<m>:HARMonics:PFACTOR:USER.....	1292
P3PHase<m>:HARMonics:POWer<n>:DATA:HEADer?.....	1308
P3PHase<m>:HARMonics:POWer<n>:DATA[:VALues]?.....	1309
P3PHase<m>:HARMonics:POWer<n>:VERTical:OFFSet.....	1301
P3PHase<m>:HARMonics:POWer<n>:VERTical:SCALE:MODE.....	1302
P3PHase<m>:HARMonics:POWer<n>:VERTical:SCALE[:VALue].....	1303
P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:HYSTeresis.....	1304
P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:LLEVel.....	1304
P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:MLEVel.....	1305
P3PHase<m>:HARMonics:REFLevel<rl>:ABSolute:ULEVel.....	1305
P3PHase<m>:HARMonics:REFLevel<rl>:LMODE.....	1305
P3PHase<m>:HARMonics:REFLevel<rl>:RELative:HYSTeresis.....	1306
P3PHase<m>:HARMonics:REFLevel<rl>:RELative:LOWer.....	1306
P3PHase<m>:HARMonics:REFLevel<rl>:RELative:MIDDLE.....	1307
P3PHase<m>:HARMonics:REFLevel<rl>:RELative:MODE.....	1307
P3PHase<m>:HARMonics:REFLevel<rl>:RELative:UPPer.....	1308
P3PHase<m>:HARMonics:RESult<n>:MAGNitude<o>:PERCent[:ACTual]?.....	1297
P3PHase<m>:HARMonics:RESult<n>:MAGNitude<o>:RMS[:ACTual]?.....	1297
P3PHase<m>:HARMonics:RESult<n>:VIOlation<o>?.....	1296
P3PHase<m>:HARMonics:RESult<n>[:FREQuency]?.....	1297
P3PHase<m>:HARMonics:REVision.....	1291
P3PHase<m>:HARMonics:RPOWer:MODE.....	1292
P3PHase<m>:HARMonics:RPOWer:USER.....	1293
P3PHase<m>:HARMonics:SOURce:CURREnt:W2V2a.....	1299
P3PHase<m>:HARMonics:SOURce:CURREnt:W3V3a.....	1299
P3PHase<m>:HARMonics:SOURce:CURREnt:W3VN3a.....	1299
P3PHase<m>:HARMonics:SOURce:CYCLE.....	1300
P3PHase<m>:HARMonics:SOURce:INOut.....	1298
P3PHase<m>:HARMonics:SOURce:LINes:W2V2a.....	1299
P3PHase<m>:HARMonics:SOURce:VOLTage:W2V2a.....	1299

P3PHase<m>:HARMonics:SOURce:VOLTage:W3V3a.....	1300
P3PHase<m>:HARMonics:SOURce:VOLTage:W3VN3a.....	1300
P3PHase<m>:HARMonics:SOURce:WIRing.....	1298
P3PHase<m>:HARMonics:STANDard.....	1291
P3PHase<m>:HARMonics:TOTal:POWer:DATA:HEADer?.....	1309
P3PHase<m>:HARMonics:TOTal:POWer:DATA[:VALues]?.....	1310
P3PHase<m>:HARMonics:TOTal:POWer:VERTical:OFFSet.....	1302
P3PHase<m>:HARMonics:TOTal:POWer:VERTical:SCALE:MODE.....	1302
P3PHase<m>:HARMonics:TOTal:POWer:VERTical:SCALE[:VALue].....	1303
P3PHase<m>:QUALity:DISPlay:CURREnt:CREStfactor<n>[:ENABLE].....	1279
P3PHase<m>:QUALity:DISPlay:CURREnt:PEAK<n>[:ENABLE].....	1279
P3PHase<m>:QUALity:DISPlay:CURREnt:RMS<n>[:ENABLE].....	1279
P3PHase<m>:QUALity:DISPlay:POWer<n>:ACTive[:ENABLE].....	1280
P3PHase<m>:QUALity:DISPlay:POWer<n>:APParent[:ENABLE].....	1280
P3PHase<m>:QUALity:DISPlay:POWer<n>:PFACtor[:ENABLE].....	1280
P3PHase<m>:QUALity:DISPlay:POWer<n>:PHASe[:ENABLE].....	1281
P3PHase<m>:QUALity:DISPlay:POWer<n>:REACTive[:ENABLE].....	1281
P3PHase<m>:QUALity:DISPlay:POWer<n>:WAVEform[:ENABLE].....	1301
P3PHase<m>:QUALity:DISPlay:TOTal:POWer:WAVEform[:ENABLE].....	1301
P3PHase<m>:QUALity:DISPlay:VOLTage:CREStfactor<n>[:ENABLE].....	1281
P3PHase<m>:QUALity:DISPlay:VOLTage:FREQuency<n>[:ENABLE].....	1281
P3PHase<m>:QUALity:DISPlay:VOLTage:PEAK<n>[:ENABLE].....	1282
P3PHase<m>:QUALity:DISPlay:VOLTage:RMS<n>[:ENABLE].....	1282
P3PHase<m>:QUALity:FREQuency:USER.....	1276
P3PHase<m>:QUALity:FREQuency:USER.....	1277
P3PHase<m>:QUALity:FREQuency[:VALue].....	1276
P3PHase<m>:QUALity:GATE.....	1300
P3PHase<m>:QUALity:PHASor:CURREnt:MAXimum.....	1278
P3PHase<m>:QUALity:PHASor:CURREnt:OFFSet.....	1278
P3PHase<m>:QUALity:PHASor:FSCReen.....	1278
P3PHase<m>:QUALity:PHASor:VOLTage:MAXimum.....	1278
P3PHase<m>:QUALity:PHASor:VOLTage:OFFSet.....	1278
P3PHase<m>:QUALity:PHASor[:ENABLE].....	1277
P3PHase<m>:QUALity:POWer<n>:DATA:HEADer?.....	1308
P3PHase<m>:QUALity:POWer<n>:DATA[:VALues]?.....	1309
P3PHase<m>:QUALity:POWer<n>:VERTical:OFFSet.....	1301
P3PHase<m>:QUALity:POWer<n>:VERTical:SCALE:MODE.....	1302
P3PHase<m>:QUALity:POWer<n>:VERTical:SCALE[:VALue].....	1303
P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:HYSTeresis.....	1304
P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:LLEVel.....	1304
P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:MLEVel.....	1305
P3PHase<m>:QUALity:REFLevel<rl>:ABSolute:ULEVel.....	1305
P3PHase<m>:QUALity:REFLevel<rl>:LMODE.....	1305
P3PHase<m>:QUALity:REFLevel<rl>:RELative:HYSTeresis.....	1306
P3PHase<m>:QUALity:REFLevel<rl>:RELative:LOWer.....	1306
P3PHase<m>:QUALity:REFLevel<rl>:RELative:MIDDLE.....	1307
P3PHase<m>:QUALity:REFLevel<rl>:RELative:MODE.....	1307
P3PHase<m>:QUALity:REFLevel<rl>:RELative:UPPer.....	1308
P3PHase<m>:QUALity:RESult:CSOURce:FREQuency<n>[:ACTual]?.....	1283
P3PHase<m>:QUALity:RESult:CURREnt:CREStfactor<n>[:ACTual]?.....	1283

P3PHase<m>:QUALity:RESult:CURRent:PEAK<n>[:ACTual]?	1284
P3PHase<m>:QUALity:RESult:CURRent:RMS<n>[:ACTual]?	1285
P3PHase<m>:QUALity:RESult:POWer:ACTive<n>[:ACTual]?	1285
P3PHase<m>:QUALity:RESult:POWer:APParent<n>[:ACTual]?	1286
P3PHase<m>:QUALity:RESult:POWer:PFACTOR<n>[:ACTual]?	1286
P3PHase<m>:QUALity:RESult:POWer:PHASe<n>[:ACTual]?	1287
P3PHase<m>:QUALity:RESult:POWer:REACTive<n>[:ACTual]?	1288
P3PHase<m>:QUALity:RESult:TOTal:CURRent:CREStfactor<n>[:ACTual]?	1284
P3PHase<m>:QUALity:RESult:TOTal:CURRent:PEAK<n>[:ACTual]?	1284
P3PHase<m>:QUALity:RESult:TOTal:CURRent:RMS<n>[:ACTual]?	1285
P3PHase<m>:QUALity:RESult:TOTal:POWer:ACTive<n>[:ACTual]?	1285
P3PHase<m>:QUALity:RESult:TOTal:POWer:APParent<n>[:ACTual]?	1286
P3PHase<m>:QUALity:RESult:TOTal:POWer:PFACTOR<n>[:ACTual]?	1287
P3PHase<m>:QUALity:RESult:TOTal:POWer:PHASe<n>[:ACTual]?	1287
P3PHase<m>:QUALity:RESult:TOTal:POWer:REACTive<n>[:ACTual]?	1288
P3PHase<m>:QUALity:RESult:TOTal:VOLTage:CREStfactor<n>[:ACTual]?	1289
P3PHase<m>:QUALity:RESult:TOTal:VOLTage:PEAK<n>[:ACTual]?	1289
P3PHase<m>:QUALity:RESult:TOTal:VOLTage:RMS<n>[:ACTual]?	1290
P3PHase<m>:QUALity:RESult:VOLTage:CREStfactor<n>[:ACTual]?	1288
P3PHase<m>:QUALity:RESult:VOLTage:PEAK<n>[:ACTual]?	1289
P3PHase<m>:QUALity:RESult:VOLTage:RMS<n>[:ACTual]?	1290
P3PHase<m>:QUALity:SOURce:CURRent:W2V2a	1299
P3PHase<m>:QUALity:SOURce:CURRent:W3V3a	1299
P3PHase<m>:QUALity:SOURce:CURRent:W3VN3a	1299
P3PHase<m>:QUALity:SOURce:CYCLE	1300
P3PHase<m>:QUALity:SOURce:INOut	1298
P3PHase<m>:QUALity:SOURce:LINes:W2V2a	1299
P3PHase<m>:QUALity:SOURce:VOLTage:W2V2a	1299
P3PHase<m>:QUALity:SOURce:VOLTage:W3V3a	1299
P3PHase<m>:QUALity:SOURce:VOLTage:W3VN3a	1299
P3PHase<m>:QUALity:SOURce:WIRing	1298
P3PHase<m>:QUALity:TOTal:POWer:DATA:HEADer?	1309
P3PHase<m>:QUALity:TOTal:POWer:DATA[:VALues]?	1310
P3PHase<m>:QUALity:TOTal:POWer:VERTical:OFFSet	1302
P3PHase<m>:QUALity:TOTal:POWer:VERTical:SCALE:MODE	1302
P3PHase<m>:QUALity:TOTal:POWer:VERTical:SCALE[:VALue]	1303
P3PHase<m>:TYPE	1275
P3PHase<m>[:ENABLE]	1275
PBUS<pb>:BIT<n>:LABel	1841
PBUS<pb>:BIT<n>:SKEW	1841
PBUS<pb>:BIT<n>[:STATe]	1842
PBUS<pb>:CLEAr	1842
PBUS<pb>:CLOCK	1842
PBUS<pb>:CLON	1842
PBUS<pb>:CLSLope	1843
PBUS<pb>:DATA:FORMat	1850
PBUS<pb>:DATA:HEADer?	1851
PBUS<pb>:DATA[:VALues]?	1851
PBUS<pb>:DECTable:COUNT?	1843
PBUS<pb>:DECTable:DATA?	1844

PBUS<pb>:DECTable:SHOW.....	1843
PBUS<pb>:DIGSignals:POSition.....	1844
PBUS<pb>:DIGSignals:SCALe.....	1844
PBUS<pb>:DISPlay:SHBU.....	1844
PBUS<pb>:DISPlay:SHDI.....	1845
PBUS<pb>:HYSTeresis<n>.....	1845
PBUS<pb>:POSition.....	1846
PBUS<pb>:SCALe.....	1846
PBUS<pb>:SKEW.....	1846
PBUS<pb>:STATe.....	1847
PBUS<pb>:TECHnology.....	1847
PBUS<pb>:THCoupling.....	1847
PBUS<pb>:THReshold<n>.....	1848
POWer<m>:ASKew[:EXECute].....	1211
POWer<m>:EFFiciency:DISPlay:RESult:OUTPut<n>:EFFiciency[:ENABLE].....	1251
POWer<m>:EFFiciency:DISPlay:RESult:OUTPut<n>:POWer[:ENABLE].....	1251
POWer<m>:EFFiciency:DISPlay:RESult:TOTal<n>:EFFiciency[:ENABLE].....	1251
POWer<m>:EFFiciency:DISPlay:RESult:TOTal<n>:OPOWer[:ENABLE].....	1251
POWer<m>:EFFiciency:DISPlay:WAVEform:INPut<n>:POWer[:ENABLE].....	1265
POWer<m>:EFFiciency:DISPlay:WAVEform:OUTPut<n>:POWer[:ENABLE].....	1265
POWer<m>:EFFiciency:DISPlay:WAVEform:TOTal<n>:OPOWer[:ENABLE].....	1265
POWer<m>:EFFiciency:GATE.....	1250
POWer<m>:EFFiciency:INPut<n>:CURRent[:SOURce].....	1248
POWer<m>:EFFiciency:INPut<n>:POWer:DATA:HEADer?.....	1273
POWer<m>:EFFiciency:INPut<n>:POWer:DATA[:VALues]?.....	1274
POWer<m>:EFFiciency:INPut<n>:POWer:VERTical:OFFSet.....	1266
POWer<m>:EFFiciency:INPut<n>:POWer:VERTical:SCALe:MODE.....	1266
POWer<m>:EFFiciency:INPut<n>:POWer:VERTical:SCALe[:VALue].....	1267
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:HYSTeresis.....	1268
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:LLEVel.....	1269
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:MLEVel.....	1269
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:ABSolute:ULEVel.....	1270
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:LMODE.....	1270
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:HYSTeresis.....	1270
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:LOWer.....	1271
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:MIDDLE.....	1271
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:MODE.....	1272
POWer<m>:EFFiciency:INPut<n>:REFLevel<rl>:RELative:UPPer.....	1273
POWer<m>:EFFiciency:INPut<n>:VOLTage[:SOURce].....	1248
POWer<m>:EFFiciency:INPut<n>[:TYPE].....	1249
POWer<m>:EFFiciency:ONUMber?.....	1249
POWer<m>:EFFiciency:OUTPut<n>:CURRent[:SOURce].....	1249
POWer<m>:EFFiciency:OUTPut<n>:POWer:DATA:HEADer?.....	1273
POWer<m>:EFFiciency:OUTPut<n>:POWer:DATA[:VALues]?.....	1274
POWer<m>:EFFiciency:OUTPut<n>:POWer:VERTical:OFFSet.....	1266
POWer<m>:EFFiciency:OUTPut<n>:POWer:VERTical:SCALe:MODE.....	1266
POWer<m>:EFFiciency:OUTPut<n>:POWer:VERTical:SCALe[:VALue].....	1267
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:HYSTeresis.....	1268
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:LLEVel.....	1269
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:MLEVel.....	1269

POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:ABSolute:ULEVel.....	1270
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:LMODE.....	1270
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:HYSTeresis.....	1270
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:LOWer.....	1271
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:MIDDLE.....	1271
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:MODE.....	1272
POWer<m>:EFFiciency:OUTPut<n>:REFLevel<rl>:RELative:UPPer.....	1273
POWer<m>:EFFiciency:OUTPut<n>:VOLTage[:SOURce].....	1250
POWer<m>:EFFiciency:OUTPut<n>[:TYPE].....	1250
POWer<m>:EFFiciency:RESult:INPut:POWer:AVERage?.....	1252
POWer<m>:EFFiciency:RESult:INPut:POWer:EVTCount?.....	1253
POWer<m>:EFFiciency:RESult:INPut:POWer:NPEak?.....	1253
POWer<m>:EFFiciency:RESult:INPut:POWer:PPEak?.....	1253
POWer<m>:EFFiciency:RESult:INPut:POWer:RMS?.....	1254
POWer<m>:EFFiciency:RESult:INPut:POWer:STDDev?.....	1254
POWer<m>:EFFiciency:RESult:INPut:POWer:WFMCount?.....	1254
POWer<m>:EFFiciency:RESult:INPut:POWer[:ACTual]?.....	1252
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:AVERage?.....	1252
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:EVTCount?.....	1253
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:NPEak?.....	1253
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:PPEak?.....	1253
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:RMS?.....	1254
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:STDDev?.....	1254
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency:WFMCount?.....	1254
POWer<m>:EFFiciency:RESult:TOTal:EFFiciency[:ACTual]?.....	1252
POWer<m>:EFFiciency:RESult:TOTal:OPower:AVERage?.....	1252
POWer<m>:EFFiciency:RESult:TOTal:OPower:EVTCount?.....	1253
POWer<m>:EFFiciency:RESult:TOTal:OPower:NPEak?.....	1253
POWer<m>:EFFiciency:RESult:TOTal:OPower:PPEak?.....	1253
POWer<m>:EFFiciency:RESult:TOTal:OPower:RMS?.....	1254
POWer<m>:EFFiciency:RESult:TOTal:OPower:STDDev?.....	1254
POWer<m>:EFFiciency:RESult:TOTal:OPower:WFMCount?.....	1254
POWer<m>:EFFiciency:RESult:TOTal:OPower[:ACTual]?.....	1252
POWer<m>:EFFiciency:STATistics:RESet.....	1211
POWer<m>:EFFiciency:STATistics:WFMCount?.....	1212
POWer<m>:EFFiciency:STATistics[:ENABLE].....	1211
POWer<m>:EFFiciency:TOTal<n>:OPower:DATA:HEADer?.....	1273
POWer<m>:EFFiciency:TOTal<n>:OPower:DATA[:VALues]?.....	1274
POWer<m>:EFFiciency:TOTal<n>:OPower:VERTical:OFFSet.....	1266
POWer<m>:EFFiciency:TOTal<n>:OPower:VERTical:SCALE:MODE.....	1266
POWer<m>:EFFiciency:TOTal<n>:OPower:VERTical:SCALE[:VALue].....	1267
POWer<m>:HARMonics:AVAILable?.....	1230
POWer<m>:HARMonics:DISPlay:BARGraph:VERTical:SCALE:TYPE.....	1228
POWer<m>:HARMonics:DISPlay:HARMonics:START[:VALue].....	1228
POWer<m>:HARMonics:DISPlay:HARMonics:STOP[:VALue].....	1228
POWer<m>:HARMonics:DISPlay:HARMonics[:DISPlay].....	1227
POWer<m>:HARMonics:DISPlay:POWer:WAVEform:ENABLE.....	1265
POWer<m>:HARMonics:FREQUENCY:EN.....	1226
POWer<m>:HARMonics:FREQUENCY:MIL.....	1227
POWer<m>:HARMonics:FREQUENCY:RTCA.....	1227

POWER<m>:HARMonics:MEASurement:FREQuency[:ACTual]?	1230
POWER<m>:HARMonics:MEASurement:POWer:ACTive[:ACTual]?	1231
POWER<m>:HARMonics:MEASurement:THDFundament[:ACTual]?	1231
POWER<m>:HARMonics:MEASurement:THDRms[:ACTual]?	1231
POWER<m>:HARMonics:PFACtor:USER	1229
POWER<m>:HARMonics:PFACtor[:MODE]	1230
POWER<m>:HARMonics:POWer:DATA:HEADer?	1274
POWER<m>:HARMonics:POWer:DATA[:VALues]?	1274
POWER<m>:HARMonics:POWer:VERTical:OFFSet	1266
POWER<m>:HARMonics:POWer:VERTical:SCALe:MODE	1266
POWER<m>:HARMonics:POWer:VERTical:SCALe[:VALue]	1267
POWER<m>:HARMonics:REFLevel<rl>:ABSolute:HYSTeresis	1268
POWER<m>:HARMonics:REFLevel<rl>:ABSolute:LLEVel	1269
POWER<m>:HARMonics:REFLevel<rl>:ABSolute:MLEVel	1269
POWER<m>:HARMonics:REFLevel<rl>:ABSolute:ULEVel	1270
POWER<m>:HARMonics:REFLevel<rl>:LMODE	1270
POWER<m>:HARMonics:REFLevel<rl>:RELative:HYSTeresis	1271
POWER<m>:HARMonics:REFLevel<rl>:RELative:LOWer	1271
POWER<m>:HARMonics:REFLevel<rl>:RELative:MIDDLE	1272
POWER<m>:HARMonics:REFLevel<rl>:RELative:MODE	1272
POWER<m>:HARMonics:REFLevel<rl>:RELative:UPPer	1273
POWER<m>:HARMonics:RESult<n>:MAGNitude:PERCent:MAXimum?	1232
POWER<m>:HARMonics:RESult<n>:MAGNitude:PERCent:MINimum?	1232
POWER<m>:HARMonics:RESult<n>:MAGNitude:PERCent[:ACTual]?	1232
POWER<m>:HARMonics:RESult<n>:MAGNitude:RMS:MAXimum?	1233
POWER<m>:HARMonics:RESult<n>:MAGNitude:RMS:MINimum?	1233
POWER<m>:HARMonics:RESult<n>:MAGNitude:RMS[:ACTual]?	1233
POWER<m>:HARMonics:RESult<n>:VIOLation?	1231
POWER<m>:HARMonics:RESult<n>[:FREQuency]?	1232
POWER<m>:HARMonics:REViision	1226
POWER<m>:HARMonics:RPOWer:USER	1229
POWER<m>:HARMonics:RPOWer[:MODE]	1228
POWER<m>:HARMonics:SOURce:CURRent	1225
POWER<m>:HARMonics:SOURce[:VOLTage]	1225
POWER<m>:HARMonics:STANDard	1226
POWER<m>:ONOff:INPut:AC:ABSolute[:VALue]	1244
POWER<m>:ONOff:INPut:DC:ABSolute[:VALue]	1245
POWER<m>:ONOff:INPut:TYPE	1245
POWER<m>:ONOff:INPut[:SOURce]	1245
POWER<m>:ONOff:ONUMber	1245
POWER<m>:ONOff:OUTPut<n>:DC:ABSolute[:VALue]	1246
POWER<m>:ONOff:OUTPut<n>:DISPlay:RESult[:ENABle]	1246
POWER<m>:ONOff:OUTPut<n>:DISPlay:RLINe[:ENABle]	1247
POWER<m>:ONOff:OUTPut<n>[:SOURce]	1246
POWER<m>:ONOff:RESult<n>:TIME[:ACTual]?	1247
POWER<m>:ONOff[:TYPE]	1247
POWER<m>:QUALity:DISPlay:CURRent:CREStfactor	1214
POWER<m>:QUALity:DISPlay:CURRent:PEAK	1214
POWER<m>:QUALity:DISPlay:CURRent:RMS	1215
POWER<m>:QUALity:DISPlay:POWer:ACTive	1215

POWer<m>:QUALity:DISPlay:POWer:APParent.....	1215
POWer<m>:QUALity:DISPlay:POWer:PFACtor.....	1215
POWer<m>:QUALity:DISPlay:POWer:PHASe.....	1216
POWer<m>:QUALity:DISPlay:POWer:REACtive.....	1216
POWer<m>:QUALity:DISPlay:POWer:WAVEform:ENABLE.....	1265
POWer<m>:QUALity:DISPlay:VOLTage:CRESTfactor.....	1216
POWer<m>:QUALity:DISPlay:VOLTage:FREQuency.....	1216
POWer<m>:QUALity:DISPlay:VOLTage:PEAK.....	1217
POWer<m>:QUALity:DISPlay:VOLTage:RMS.....	1217
POWer<m>:QUALity:FREQuency:USER.....	1213
POWer<m>:QUALity:FREQuency[:VALue].....	1213
POWer<m>:QUALity:GATE.....	1214
POWer<m>:QUALity:POWer:DATA:HEADer?.....	1274
POWer<m>:QUALity:POWer:DATA[:VALues]?.....	1274
POWer<m>:QUALity:POWer:VERTical:OFFSet.....	1266
POWer<m>:QUALity:POWer:VERTical:SCALE:MODE.....	1266
POWer<m>:QUALity:POWer:VERTical:SCALE[:VALue].....	1267
POWer<m>:QUALity:REFLevel<rl>:ABSolute:HYSTeresis.....	1268
POWer<m>:QUALity:REFLevel<rl>:ABSolute:LLEVel.....	1269
POWer<m>:QUALity:REFLevel<rl>:ABSolute:MLEVel.....	1269
POWer<m>:QUALity:REFLevel<rl>:ABSolute:ULEVel.....	1270
POWer<m>:QUALity:REFLevel<rl>:LMODE.....	1270
POWer<m>:QUALity:REFLevel<rl>:RELative:HYSTeresis.....	1271
POWer<m>:QUALity:REFLevel<rl>:RELative:LOWer.....	1271
POWer<m>:QUALity:REFLevel<rl>:RELative:MIDDLE.....	1272
POWer<m>:QUALity:REFLevel<rl>:RELative:MODE.....	1272
POWer<m>:QUALity:REFLevel<rl>:RELative:UPPer.....	1273
POWer<m>:QUALity:RESult:CURRent:CRESTfactor:AVERAge?.....	1219
POWer<m>:QUALity:RESult:CURRent:CRESTfactor:EVTCount?.....	1219
POWer<m>:QUALity:RESult:CURRent:CRESTfactor:NPEak?.....	1219
POWer<m>:QUALity:RESult:CURRent:CRESTfactor:PPEak?.....	1219
POWer<m>:QUALity:RESult:CURRent:CRESTfactor:RMS?.....	1219
POWer<m>:QUALity:RESult:CURRent:CRESTfactor:STDDev?.....	1219
POWer<m>:QUALity:RESult:CURRent:CRESTfactor:WFMCount?.....	1219
POWer<m>:QUALity:RESult:CURRent:CRESTfactor[:ACTual]?.....	1219
POWer<m>:QUALity:RESult:CURRent:PEAK:AVERAge?.....	1220
POWer<m>:QUALity:RESult:CURRent:PEAK:EVTCount?.....	1220
POWer<m>:QUALity:RESult:CURRent:PEAK:NPEak?.....	1220
POWer<m>:QUALity:RESult:CURRent:PEAK:PPEak?.....	1220
POWer<m>:QUALity:RESult:CURRent:PEAK:RMS?.....	1220
POWer<m>:QUALity:RESult:CURRent:PEAK:STDDev?.....	1220
POWer<m>:QUALity:RESult:CURRent:PEAK:WFMCount?.....	1220
POWer<m>:QUALity:RESult:CURRent:PEAK[:ACTual]?.....	1220
POWer<m>:QUALity:RESult:CURRent:RMS:AVERAge?.....	1220
POWer<m>:QUALity:RESult:CURRent:RMS:EVTCount?.....	1220
POWer<m>:QUALity:RESult:CURRent:RMS:NPEak?.....	1220
POWer<m>:QUALity:RESult:CURRent:RMS:PPEak?.....	1220
POWer<m>:QUALity:RESult:CURRent:RMS:RMS?.....	1220
POWer<m>:QUALity:RESult:CURRent:RMS:STDDev?.....	1220
POWer<m>:QUALity:RESult:CURRent:RMS:WFMCount?.....	1220

POWER<m>:QUALity:RESult:CURRent:RMS[:ACTual]?	1220
POWER<m>:QUALity:RESult:POWer:ACTive:AVERAge?	1220
POWER<m>:QUALity:RESult:POWer:ACTive:EVTCount?	1220
POWER<m>:QUALity:RESult:POWer:ACTive:NPEak?	1220
POWER<m>:QUALity:RESult:POWer:ACTive:PPEak?	1221
POWER<m>:QUALity:RESult:POWer:ACTive:RMS?	1221
POWER<m>:QUALity:RESult:POWer:ACTive:STDDev?	1221
POWER<m>:QUALity:RESult:POWer:ACTive:WFMCount?	1221
POWER<m>:QUALity:RESult:POWer:ACTive[:ACTual]?	1220
POWER<m>:QUALity:RESult:POWer:APParent:AVERAge?	1221
POWER<m>:QUALity:RESult:POWer:APParent:EVTCount?	1221
POWER<m>:QUALity:RESult:POWer:APParent:NPEak?	1221
POWER<m>:QUALity:RESult:POWer:APParent:PPEak?	1221
POWER<m>:QUALity:RESult:POWer:APParent:RMS?	1221
POWER<m>:QUALity:RESult:POWer:APParent:STDDev?	1221
POWER<m>:QUALity:RESult:POWer:APParent:WFMCount?	1221
POWER<m>:QUALity:RESult:POWer:APParent[:ACTual]?	1221
POWER<m>:QUALity:RESult:POWer:PFACTOR:AVERAge?	1221
POWER<m>:QUALity:RESult:POWer:PFACTOR:EVTCount?	1221
POWER<m>:QUALity:RESult:POWer:PFACTOR:NPEak?	1221
POWER<m>:QUALity:RESult:POWer:PFACTOR:PPEak?	1221
POWER<m>:QUALity:RESult:POWer:PFACTOR:RMS?	1221
POWER<m>:QUALity:RESult:POWer:PFACTOR:STDDev?	1221
POWER<m>:QUALity:RESult:POWer:PFACTOR:WFMCount?	1221
POWER<m>:QUALity:RESult:POWer:PFACTOR[:ACTual]?	1221
POWER<m>:QUALity:RESult:POWer:PHASe:AVERAge?	1222
POWER<m>:QUALity:RESult:POWer:PHASe:EVTCount?	1222
POWER<m>:QUALity:RESult:POWer:PHASe:NPEak?	1222
POWER<m>:QUALity:RESult:POWer:PHASe:PPEak?	1222
POWER<m>:QUALity:RESult:POWer:PHASe:RMS?	1222
POWER<m>:QUALity:RESult:POWer:PHASe:STDDev?	1222
POWER<m>:QUALity:RESult:POWer:PHASe:WFMCount?	1222
POWER<m>:QUALity:RESult:POWer:PHASe[:ACTual]?	1222
POWER<m>:QUALity:RESult:POWer:REACTive:AVERAge?	1222
POWER<m>:QUALity:RESult:POWer:REACTive:EVTCount?	1222
POWER<m>:QUALity:RESult:POWer:REACTive:NPEak?	1222
POWER<m>:QUALity:RESult:POWer:REACTive:PPEak?	1222
POWER<m>:QUALity:RESult:POWer:REACTive:RMS?	1222
POWER<m>:QUALity:RESult:POWer:REACTive:STDDev?	1222
POWER<m>:QUALity:RESult:POWer:REACTive:WFMCount?	1222
POWER<m>:QUALity:RESult:POWer:REACTive[:ACTual]?	1222
POWER<m>:QUALity:RESult:VOLTage:CREStfactor:AVERAge?	1223
POWER<m>:QUALity:RESult:VOLTage:CREStfactor:EVTCount?	1223
POWER<m>:QUALity:RESult:VOLTage:CREStfactor:NPEak?	1223
POWER<m>:QUALity:RESult:VOLTage:CREStfactor:PPEak?	1223
POWER<m>:QUALity:RESult:VOLTage:CREStfactor:RMS?	1223
POWER<m>:QUALity:RESult:VOLTage:CREStfactor:STDDev?	1223
POWER<m>:QUALity:RESult:VOLTage:CREStfactor:WFMCount?	1223
POWER<m>:QUALity:RESult:VOLTage:CREStfactor[:ACTual]?	1223
POWER<m>:QUALity:RESult:VOLTage:FREQuency:AVERAge?	1223

POWer<m>:QUALity:RESult:VOLTage:FREQuency:EVTCount?	1223
POWer<m>:QUALity:RESult:VOLTage:FREQuency:NPEak?	1223
POWer<m>:QUALity:RESult:VOLTage:FREQuency:PPEak?	1223
POWer<m>:QUALity:RESult:VOLTage:FREQuency:RMS?	1223
POWer<m>:QUALity:RESult:VOLTage:FREQuency:STDDev?	1223
POWer<m>:QUALity:RESult:VOLTage:FREQuency:WFMCount?	1223
POWer<m>:QUALity:RESult:VOLTage:FREQuency[:ACTual]?	1223
POWer<m>:QUALity:RESult:VOLTage:PEAK:AVERage?	1224
POWer<m>:QUALity:RESult:VOLTage:PEAK:EVTCount?	1224
POWer<m>:QUALity:RESult:VOLTage:PEAK:NPEak?	1224
POWer<m>:QUALity:RESult:VOLTage:PEAK:PPEak?	1224
POWer<m>:QUALity:RESult:VOLTage:PEAK:RMS?	1224
POWer<m>:QUALity:RESult:VOLTage:PEAK:STDDev?	1224
POWer<m>:QUALity:RESult:VOLTage:PEAK:WFMCount?	1224
POWer<m>:QUALity:RESult:VOLTage:PEAK[:ACTual]?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS:AVERage?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS:EVTCount?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS:NPEak?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS:PPEak?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS:RMS?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS:STDDev?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS:WFMCount?	1224
POWer<m>:QUALity:RESult:VOLTage:RMS[:ACTual]?	1224
POWer<m>:QUALity:SOURce:CURREnt	1212
POWer<m>:QUALity:SOURce:CYCLE	1213
POWer<m>:QUALity:SOURce[:VOLTage]	1213
POWer<m>:QUALity:STATistics:RESet	1211
POWer<m>:QUALity:STATistics:WFMCount?	1212
POWer<m>:QUALity:STATistics[:ENABLE]	1211
POWer<m>:SOA:LIMit:APPLY	1256
POWer<m>:SOA:LIMit:IMAX	1257
POWer<m>:SOA:LIMit:PMAX	1257
POWer<m>:SOA:LIMit:VMAX	1257
POWer<m>:SOA:MTESt<n>:IMEXport:NAME	1255
POWer<m>:SOA:MTESt<n>:IMEXport:OPEN	1255
POWer<m>:SOA:MTESt<n>:IMEXport:SAVE	1255
POWer<m>:SOA:MTESt<n>:ONViolation:BEEP	1261
POWer<m>:SOA:MTESt<n>:ONViolation:SCReenshot	1261
POWer<m>:SOA:MTESt<n>:ONViolation:STOP	1262
POWer<m>:SOA:MTESt<n>:ONViolation:TRIGgerout	1262
POWer<m>:SOA:MTESt<n>:ONViolation:WFMSave	1263
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:ADD	1258
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:COUNT?	1258
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:ADD	1258
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:COUNT?	1259
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:REMOve	1259
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:VALid?	1259
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:X	1260
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:POINT<p>:Y	1260
POWer<m>:SOA:MTESt<n>:SEGMENT<o>:REMOve	1261

POWer<m>:SOA:RESult<n>:COUNT:FWAVeforms?	1263
POWer<m>:SOA:RESult<n>:COUNT:PWAVeforms?	1263
POWer<m>:SOA:RESult<n>:COUNT:WAVeforms?	1264
POWer<m>:SOA:RESult<n>:FRATe?	1264
POWer<m>:SOA:RESult<n>[:RESult]?	1264
POWer<m>:SOA:SOURce:CURREnt	1256
POWer<m>:SOA:SOURce:VOLTage	1256
POWer<m>:SWITChing:DISPlay:CONDUction:COLor	1237
POWer<m>:SWITChing:DISPlay:CONDUction[:ENABLE]	1237
POWer<m>:SWITChing:DISPlay:LABel[:ENABLE]	1238
POWer<m>:SWITChing:DISPlay:NCONduction:COLor	1237
POWer<m>:SWITChing:DISPlay:NCONduction[:ENABLE]	1237
POWer<m>:SWITChing:DISPlay:POWer:WAVeform[:ENABLE]	1265
POWer<m>:SWITChing:DISPlay:TOFF:COLor	1237
POWer<m>:SWITChing:DISPlay:TOFF[:ENABLE]	1237
POWer<m>:SWITChing:DISPlay:TON:COLor	1237
POWer<m>:SWITChing:DISPlay:TON[:ENABLE]	1237
POWer<m>:SWITChing:DISPlay:TOTal[:ENABLE]	1238
POWer<m>:SWITChing:DISPlay:TYPE	1235
POWer<m>:SWITChing:POWer:DATA:HEADer?	1274
POWer<m>:SWITChing:POWer:DATA[:VALues]?	1274
POWer<m>:SWITChing:POWer:VERTical:OFFSet	1266
POWer<m>:SWITChing:POWer:VERTical:SCALE:MODE	1266
POWer<m>:SWITChing:POWer:VERTical:SCALE[:VALue]	1267
POWer<m>:SWITChing:REGion:CONDUction:STOP	1236
POWer<m>:SWITChing:REGion:CONDUction[:START]	1235
POWer<m>:SWITChing:REGion:NCONduction:STOP	1236
POWer<m>:SWITChing:REGion:NCONduction[:START]	1236
POWer<m>:SWITChing:REGion:TOFF:STOP	1236
POWer<m>:SWITChing:REGion:TOFF[:START]	1236
POWer<m>:SWITChing:REGion:TON:STOP	1235
POWer<m>:SWITChing:REGion:TON[:START]	1235
POWer<m>:SWITChing:REGion:TOTal:STOP	1236
POWer<m>:SWITChing:REGion:TOTal[:START]	1235
POWer<m>:SWITChing:RESult:CONDUction:ENERgy:AVERage?	1240
POWer<m>:SWITChing:RESult:CONDUction:ENERgy:EVTCount?	1241
POWer<m>:SWITChing:RESult:CONDUction:ENERgy:NPEak?	1241
POWer<m>:SWITChing:RESult:CONDUction:ENERgy:PPEak?	1242
POWer<m>:SWITChing:RESult:CONDUction:ENERgy:RMS?	1242
POWer<m>:SWITChing:RESult:CONDUction:ENERgy:STDDev?	1243
POWer<m>:SWITChing:RESult:CONDUction:ENERgy:WFMCount?	1243
POWer<m>:SWITChing:RESult:CONDUction:ENERgy[:ACTual]?	1240
POWer<m>:SWITChing:RESult:CONDUction:POWer:AVERage?	1240
POWer<m>:SWITChing:RESult:CONDUction:POWer:EVTCount?	1241
POWer<m>:SWITChing:RESult:CONDUction:POWer:NPEak?	1241
POWer<m>:SWITChing:RESult:CONDUction:POWer:PPEak?	1242
POWer<m>:SWITChing:RESult:CONDUction:POWer:RMS?	1242
POWer<m>:SWITChing:RESult:CONDUction:POWer:STDDev?	1243
POWer<m>:SWITChing:RESult:CONDUction:POWer:WFMCount?	1243
POWer<m>:SWITChing:RESult:CONDUction:POWer[:ACTual]?	1240

POWER<m>:SWITChing:RESult:NCONduction:ENERgy:AVERage?	1240
POWER<m>:SWITChing:RESult:NCONduction:ENERgy:EVTCount?	1241
POWER<m>:SWITChing:RESult:NCONduction:ENERgy:NPEak?	1241
POWER<m>:SWITChing:RESult:NCONduction:ENERgy:PPEak?	1242
POWER<m>:SWITChing:RESult:NCONduction:ENERgy:RMS?	1242
POWER<m>:SWITChing:RESult:NCONduction:ENERgy:STDDDev?	1243
POWER<m>:SWITChing:RESult:NCONduction:ENERgy:WFMCount?	1243
POWER<m>:SWITChing:RESult:NCONduction:ENERgy[:ACTual]?	1240
POWER<m>:SWITChing:RESult:NCONduction:POWER:AVERage?	1241
POWER<m>:SWITChing:RESult:NCONduction:POWER:EVTCount?	1241
POWER<m>:SWITChing:RESult:NCONduction:POWER:NPEak?	1241
POWER<m>:SWITChing:RESult:NCONduction:POWER:PPEak?	1242
POWER<m>:SWITChing:RESult:NCONduction:POWER:RMS?	1242
POWER<m>:SWITChing:RESult:NCONduction:POWER:STDDDev?	1243
POWER<m>:SWITChing:RESult:NCONduction:POWER:WFMCount?	1243
POWER<m>:SWITChing:RESult:NCONduction:POWER[:ACTual]?	1240
POWER<m>:SWITChing:RESult:TOFF:ENERgy:AVERage?	1241
POWER<m>:SWITChing:RESult:TOFF:ENERgy:EVTCount?	1241
POWER<m>:SWITChing:RESult:TOFF:ENERgy:NPEak?	1241
POWER<m>:SWITChing:RESult:TOFF:ENERgy:PPEak?	1242
POWER<m>:SWITChing:RESult:TOFF:ENERgy:RMS?	1242
POWER<m>:SWITChing:RESult:TOFF:ENERgy:STDDDev?	1243
POWER<m>:SWITChing:RESult:TOFF:ENERgy:WFMCount?	1243
POWER<m>:SWITChing:RESult:TOFF:ENERgy[:ACTual]?	1240
POWER<m>:SWITChing:RESult:TOFF:POWER:AVERage?	1241
POWER<m>:SWITChing:RESult:TOFF:POWER:EVTCount?	1241
POWER<m>:SWITChing:RESult:TOFF:POWER:NPEak?	1241
POWER<m>:SWITChing:RESult:TOFF:POWER:PPEak?	1242
POWER<m>:SWITChing:RESult:TOFF:POWER:RMS?	1242
POWER<m>:SWITChing:RESult:TOFF:POWER:STDDDev?	1243
POWER<m>:SWITChing:RESult:TOFF:POWER:WFMCount?	1243
POWER<m>:SWITChing:RESult:TOFF:POWER[:ACTual]?	1240
POWER<m>:SWITChing:RESult:TON:ENERgy:AVERage?	1241
POWER<m>:SWITChing:RESult:TON:ENERgy:EVTCount?	1241
POWER<m>:SWITChing:RESult:TON:ENERgy:NPEak?	1242
POWER<m>:SWITChing:RESult:TON:ENERgy:PPEak?	1242
POWER<m>:SWITChing:RESult:TON:ENERgy:RMS?	1242
POWER<m>:SWITChing:RESult:TON:ENERgy:STDDDev?	1243
POWER<m>:SWITChing:RESult:TON:ENERgy:WFMCount?	1243
POWER<m>:SWITChing:RESult:TON:ENERgy[:ACTual]?	1240
POWER<m>:SWITChing:RESult:TON:POWER:AVERage?	1241
POWER<m>:SWITChing:RESult:TON:POWER:EVTCount?	1241
POWER<m>:SWITChing:RESult:TON:POWER:NPEak?	1242
POWER<m>:SWITChing:RESult:TON:POWER:PPEak?	1242
POWER<m>:SWITChing:RESult:TON:POWER:RMS?	1242
POWER<m>:SWITChing:RESult:TON:POWER:STDDDev?	1243
POWER<m>:SWITChing:RESult:TON:POWER:WFMCount?	1243
POWER<m>:SWITChing:RESult:TON:POWER[:ACTual]?	1240
POWER<m>:SWITChing:RESult:TOTal:ENERgy:AVERage?	1241
POWER<m>:SWITChing:RESult:TOTal:ENERgy:EVTCount?	1241

POWer<m>:SWITching:RESult:TOTal:ENERgy:NPEak?	1242
POWer<m>:SWITching:RESult:TOTal:ENERgy:PPEak?	1242
POWer<m>:SWITching:RESult:TOTal:ENERgy:RMS?	1243
POWer<m>:SWITching:RESult:TOTal:ENERgy:STDDev?	1243
POWer<m>:SWITching:RESult:TOTal:ENERgy:WFMCount?	1244
POWer<m>:SWITching:RESult:TOTal:ENERgy[:ACTual]?	1240
POWer<m>:SWITching:RESult:TOTal:POWer:AVERage?	1241
POWer<m>:SWITching:RESult:TOTal:POWer:EVTCount?	1241
POWer<m>:SWITching:RESult:TOTal:POWer:NPEak?	1242
POWer<m>:SWITching:RESult:TOTal:POWer:PPEak?	1242
POWer<m>:SWITching:RESult:TOTal:POWer:RMS?	1243
POWer<m>:SWITching:RESult:TOTal:POWer:STDDev?	1243
POWer<m>:SWITching:RESult:TOTal:POWer:WFMCount?	1244
POWer<m>:SWITching:RESult:TOTal:POWer[:ACTual]?	1240
POWer<m>:SWITching:SOURce:CURREnt	1234
POWer<m>:SWITching:SOURce[:VOLTage]	1234
POWer<m>:SWITching:STATistics:ENABle	1211
POWer<m>:SWITching:STATistics:RESet	1211
POWer<m>:SWITching:STATistics:WFMCount?	1212
POWer<m>:TYPE	1210
POWer<m>[:ENABle]	1210
PROBe<ch>:ID:PARTnumber?	998
PROBe<ch>:ID:PRDate?	998
PROBe<ch>:ID:SRNumber?	999
PROBe<ch>:ID:SWVersion?	999
PROBe<ch>:PMETer:RESults:COMMon?	986
PROBe<ch>:PMETer:RESults:DIFFerential?	986
PROBe<ch>:PMETer:RESults:NEGative?	987
PROBe<ch>:PMETer:RESults:POSitive?	987
PROBe<ch>:PMETer:RESults:SINGLE?	985
PROBe<ch>:PMETer:STATe	985
PROBe<ch>:SETup:ACCoupling	984
PROBe<ch>:SETup:ADAPter	997
PROBe<ch>:SETup:ADVanced:AUDioverload	987
PROBe<ch>:SETup:ADVanced:FILTer	988
PROBe<ch>:SETup:ADVanced:PMToffset	988
PROBe<ch>:SETup:ADVanced:RANGe	988
PROBe<ch>:SETup:ADVanced:RDEFaults	996
PROBe<ch>:SETup:ADVanced:UNIT	994
PROBe<ch>:SETup:ALIGNment:GAIN:EXECute	995
PROBe<ch>:SETup:ALIGNment:WRITe	996
PROBe<ch>:SETup:ALIGNment:ZERO:EXECute	996
PROBe<ch>:SETup:ATTenuation:DEFProbe	979
PROBe<ch>:SETup:ATTenuation:MANual	978
PROBe<ch>:SETup:ATTenuation:MODE	978
PROBe<ch>:SETup:ATTenuation:TDEFprobe	998
PROBe<ch>:SETup:ATTenuation:UNIT	980
PROBe<ch>:SETup:ATTenuation[:AUTO]?	978
PROBe<ch>:SETup:BANDwidth?	980
PROBe<ch>:SETup:CAPacitance?	999

PROBe<ch>:SETup:CMOOffset.....	984
PROBe<ch>:SETup:CMOOffset.....	990
PROBe<ch>:SETup:DCRange:MAX?.....	1000
PROBe<ch>:SETup:DCRange:MIN?.....	1000
PROBe<ch>:SETup:DEGauss.....	993
PROBe<ch>:SETup:DISPlaydiff.....	984
PROBe<ch>:SETup:DMOOffset.....	990
PROBe<ch>:SETup:GAIN:AUTO?.....	993
PROBe<ch>:SETup:GAIN:MANual.....	993
PROBe<ch>:SETup:IMPedance?.....	1000
PROBe<ch>:SETup:LASer:STATe?.....	995
PROBe<ch>:SETup:MODE.....	983
PROBe<ch>:SETup:NAME?.....	981
PROBe<ch>:SETup:NOFFset.....	990
PROBe<ch>:SETup:OFFSet:AZERo.....	981
PROBe<ch>:SETup:OFFSet:STPRobe.....	994
PROBe<ch>:SETup:OFFSet:TOMean.....	980
PROBe<ch>:SETup:OFFSet:TOPMeter.....	995
PROBe<ch>:SETup:OFFSet:USEautozero.....	981
PROBe<ch>:SETup:OFFSet:ZADJust.....	994
PROBe<ch>:SETup:POFFset.....	991
PROBe<ch>:SETup:PRMode.....	989
PROBe<ch>:SETup:STATe?.....	982
PROBe<ch>:SETup:TERM:ADJust.....	991
PROBe<ch>:SETup:TERM:MEASure?.....	991
PROBe<ch>:SETup:TERM:MODE.....	992
PROBe<ch>:SETup:TERM:STATe.....	992
PROBe<ch>:SETup:TIPModel:INFO?.....	997
PROBe<ch>:SETup:TIPModel:NAME?.....	997
PROBe<ch>:SETup:TYPE?.....	982
PROBe<ch>:SETup:ZAXV.....	985
REFCurve<rc>:ABORt.....	1082
REFCurve<rc>:AXIS[:XMODE].....	1085
REFCurve<rc>:CLEAr.....	1082
REFCurve<rc>:DATA:HEADer?.....	1090
REFCurve<rc>:DATA:STYPe?.....	1089
REFCurve<rc>:DATA[:VALues]?.....	1091
REFCurve<rc>:HMODE.....	1086
REFCurve<rc>:NAME.....	1082
REFCurve<rc>:OFFSet.....	1083
REFCurve<rc>:OPEN.....	1083
REFCurve<rc>:POSition.....	1086
REFCurve<rc>:RESCale:HORizontal:FACTor.....	1087
REFCurve<rc>:RESCale:HORizontal:OFFSet.....	1087
REFCurve<rc>:RESCale:HORizontal:STATe.....	1087
REFCurve<rc>:RESCale:VERTical:FACTor.....	1088
REFCurve<rc>:RESCale:VERTical:OFFSet.....	1088
REFCurve<rc>:RESCale:VERTical:STATe.....	1088
REFCurve<rc>:RESTore.....	1083
REFCurve<rc>:SAVE.....	1083

REFCurve<rc>:SCALE.....	1085
REFCurve<rc>:SOURCE.....	1084
REFCurve<rc>:STATE.....	1084
REFCurve<rc>:TOORiginal.....	1089
REFCurve<rc>:UPDATE.....	1085
REFCurve<rc>:VMODE.....	1089
REFLevel<rl>:ABSolute:HYSTeresis.....	1049
REFLevel<rl>:ABSolute:LLEVel.....	1049
REFLevel<rl>:ABSolute:MLEVel.....	1049
REFLevel<rl>:ABSolute:ULEVel.....	1050
REFLevel<rl>:ENABLE.....	1048
REFLevel<rl>:LMODE.....	1049
REFLevel<rl>:RELative:HYSTeresis.....	1050
REFLevel<rl>:RELative:LOWer.....	1050
REFLevel<rl>:RELative:MIDDLE.....	1051
REFLevel<rl>:RELative:MODE.....	1051
REFLevel<rl>:RELative:UPPer.....	1052
RUN.....	962
RUNCont.....	962
RUNSingle.....	962
SAVeset:CONFig:PREView.....	1104
SAVeset:CONFig:UPReferences.....	1104
SBUS<sb>:ARINc:BRMode.....	1628
SBUS<sb>:ARINc:BRValue.....	1628
SBUS<sb>:ARINc:FILTer:BIT.....	1634
SBUS<sb>:ARINc:FILTer:CHKall.....	1633
SBUS<sb>:ARINc:FILTer:CLR.....	1633
SBUS<sb>:ARINc:FILTer:DMAX.....	1635
SBUS<sb>:ARINc:FILTer:DMIN.....	1635
SBUS<sb>:ARINc:FILTer:DOPerator.....	1635
SBUS<sb>:ARINc:FILTer:ERENable.....	1634
SBUS<sb>:ARINc:FILTer:ERRor<n>:ENABLE.....	1634
SBUS<sb>:ARINc:FILTer:FIENable.....	1636
SBUS<sb>:ARINc:FILTer:FRAMe<fr>:ENABLE.....	1636
SBUS<sb>:ARINc:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1634
SBUS<sb>:ARINc:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1635
SBUS<sb>:ARINc:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1635
SBUS<sb>:ARINc:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1635
SBUS<sb>:ARINc:FILTer:FRAMe<fr>:FLD<fl>:ENABLE.....	1636
SBUS<sb>:ARINc:FILTer:FRENable.....	1636
SBUS<sb>:ARINc:FILTer:INVert.....	1633
SBUS<sb>:ARINc:FILTer:RST.....	1634
SBUS<sb>:ARINc:MAXGap:BITS.....	1630
SBUS<sb>:ARINc:MAXGap:SElect.....	1631
SBUS<sb>:ARINc:MINGap:BITS.....	1631
SBUS<sb>:ARINc:MINGap:SElect.....	1631
SBUS<sb>:ARINc:NEWLlist.....	1630
SBUS<sb>:ARINc:POLarity.....	1629
SBUS<sb>:ARINc:POSition.....	1632
SBUS<sb>:ARINc:SCALE.....	1632

SBUS<sb>:ARINc:SOURce.....	1629
SBUS<sb>:ARINc:SWTIndex?.....	1640
SBUS<sb>:ARINc:SWTTime?.....	1641
SBUS<sb>:ARINc:SYMBols.....	1630
SBUS<sb>:ARINc:THReshold:HIGH.....	1629
SBUS<sb>:ARINc:THReshold:HYSTeresis.....	1629
SBUS<sb>:ARINc:THReshold:LOW.....	1630
SBUS<sb>:ARINc:WCOunt?.....	1641
SBUS<sb>:ARINc:WORD<w>:BITRate?.....	1642
SBUS<sb>:ARINc:WORD<w>:DATA?.....	1642
SBUS<sb>:ARINc:WORD<w>:LABel?.....	1642
SBUS<sb>:ARINc:WORD<w>:PATtern?.....	1643
SBUS<sb>:ARINc:WORD<w>:SDI?.....	1643
SBUS<sb>:ARINc:WORD<w>:SSM?.....	1643
SBUS<sb>:ARINc:WORD<w>:STARt?.....	1644
SBUS<sb>:ARINc:WORD<w>:STATe?.....	1644
SBUS<sb>:ARINc:WORD<w>:STOP?.....	1644
SBUS<sb>:ARINc:WORD<w>:SYMBol?.....	1645
SBUS<sb>:CAN:BITRate.....	1539
SBUS<sb>:CAN:FAST:HYSTeresis.....	1542
SBUS<sb>:CAN:FAST:THReshold.....	1541
SBUS<sb>:CAN:FCOunt?.....	1566
SBUS<sb>:CAN:FDATa:DBITRate.....	1540
SBUS<sb>:CAN:FDATa:SAMPlepoint.....	1540
SBUS<sb>:CAN:FILTer:BIT.....	1545
SBUS<sb>:CAN:FILTer:CHKall.....	1545
SBUS<sb>:CAN:FILTer:CLR.....	1545
SBUS<sb>:CAN:FILTer:DMAX.....	1546
SBUS<sb>:CAN:FILTer:DMIN.....	1546
SBUS<sb>:CAN:FILTer:DOPerator.....	1547
SBUS<sb>:CAN:FILTer:ERENable.....	1547
SBUS<sb>:CAN:FILTer:ERRor<n>:ENABle.....	1547
SBUS<sb>:CAN:FILTer:FIENable.....	1547
SBUS<sb>:CAN:FILTer:FRAMe<fr>:ENABle.....	1548
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1545
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1546
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1546
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1547
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1547
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1548
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1548
SBUS<sb>:CAN:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1549
SBUS<sb>:CAN:FILTer:FRENable.....	1548
SBUS<sb>:CAN:FILTer:IMAX.....	1548
SBUS<sb>:CAN:FILTer:IMIN.....	1548
SBUS<sb>:CAN:FILTer:INVert.....	1545
SBUS<sb>:CAN:FILTer:IOPerator.....	1549
SBUS<sb>:CAN:FILTer:RST.....	1545
SBUS<sb>:CAN:FRAMe<fr>:ACKState?.....	1566
SBUS<sb>:CAN:FRAMe<fr>:ACKValue?.....	1566

SBUS<sb>:CAN:FRAME<fr>:CSSTate?	1569
SBUS<sb>:CAN:FRAME<fr>:CSValue?	1569
SBUS<sb>:CAN:FRAME<fr>:DATA?	1569
SBUS<sb>:CAN:FRAME<fr>:DBITrate?	1576
SBUS<sb>:CAN:FRAME<fr>:DLCState?	1570
SBUS<sb>:CAN:FRAME<fr>:DLCValue?	1570
SBUS<sb>:CAN:FRAME<fr>:FDATa<o>:BRS?	1576
SBUS<sb>:CAN:FRAME<fr>:FDATa<o>:ESI?	1576
SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:FVAlue?	1568
SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:LABel?	1568
SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:STATe?	1567
SBUS<sb>:CAN:FRAME<fr>:FLD<fl>:VALue?	1568
SBUS<sb>:CAN:FRAME<fr>:FLDCount?	1566
SBUS<sb>:CAN:FRAME<fr>:IDSTate?	1570
SBUS<sb>:CAN:FRAME<fr>:IDType?	1571
SBUS<sb>:CAN:FRAME<fr>:IDValue?	1571
SBUS<sb>:CAN:FRAME<fr>:NBITrate?	1577
SBUS<sb>:CAN:FRAME<fr>:NDBYtes?	1571
SBUS<sb>:CAN:FRAME<fr>:SBC?	1574
SBUS<sb>:CAN:FRAME<fr>:STARt?	1572
SBUS<sb>:CAN:FRAME<fr>:STATus?	1572
SBUS<sb>:CAN:FRAME<fr>:STOP?	1572
SBUS<sb>:CAN:FRAME<fr>:SYMBol?	1573
SBUS<sb>:CAN:FRAME<fr>:TYPE?	1573
SBUS<sb>:CAN:FRAME<fr>:XDATa<o>:AF?	1574
SBUS<sb>:CAN:FRAME<fr>:XDATa<o>:FCRC?	1577
SBUS<sb>:CAN:FRAME<fr>:XDATa<o>:PCRC?	1574
SBUS<sb>:CAN:FRAME<fr>:XDATa<o>:SDT?	1575
SBUS<sb>:CAN:FRAME<fr>:XDATa<o>:SEC?	1575
SBUS<sb>:CAN:FRAME<fr>:XDATa<o>:VCID?	1575
SBUS<sb>:CAN:NEWList	1543
SBUS<sb>:CAN:POSition	1543
SBUS<sb>:CAN:SAMPlepoint	1539
SBUS<sb>:CAN:SCALe	1544
SBUS<sb>:CAN:SIC:HYSteresis	1541
SBUS<sb>:CAN:SIC:THReshold	1541
SBUS<sb>:CAN:SOURce	1540
SBUS<sb>:CAN:SWTIndex?	1564
SBUS<sb>:CAN:SWTTime?	1565
SBUS<sb>:CAN:SYMBols	1543
SBUS<sb>:CAN:TRCVmode	1542
SBUS<sb>:CAN:TYPE	1539
SBUS<sb>:CAN:XDATa:DBITrate	1542
SBUS<sb>:CAN:XDATa:SAMPlepoint	1542
SBUS<sb>:EXPResult:DETail	1325
SBUS<sb>:EXPResult:EXTension	1326
SBUS<sb>:EXPResult:PATH	1327
SBUS<sb>:EXPResult:SAVE	1326
SBUS<sb>:EXPResult:TIME	1326
SBUS<sb>:FORMat	1323

SBUS<sb>:HBTO:FCOut?	1762
SBUS<sb>:HBTO:FiLTeR:BIT	1752
SBUS<sb>:HBTO:FiLTeR:CHKaLL	1751
SBUS<sb>:HBTO:FiLTeR:CLR	1752
SBUS<sb>:HBTO:FiLTeR:DMAX	1753
SBUS<sb>:HBTO:FiLTeR:DMIN	1753
SBUS<sb>:HBTO:FiLTeR:DOPerator	1753
SBUS<sb>:HBTO:FiLTeR:ERENable	1754
SBUS<sb>:HBTO:FiLTeR:ERRor<n>:ENABle	1754
SBUS<sb>:HBTO:FiLTeR:FIENable	1754
SBUS<sb>:HBTO:FiLTeR:FRAMe<fr>:ENABle	1754
SBUS<sb>:HBTO:FiLTeR:FRAMe<fr>:FLD<fl>:BIT	1752
SBUS<sb>:HBTO:FiLTeR:FRAMe<fr>:FLD<fl>:DMAX	1753
SBUS<sb>:HBTO:FiLTeR:FRAMe<fr>:FLD<fl>:DMIN	1753
SBUS<sb>:HBTO:FiLTeR:FRAMe<fr>:FLD<fl>:DOPerator	1753
SBUS<sb>:HBTO:FiLTeR:FRAMe<fr>:FLD<fl>:ENABle	1754
SBUS<sb>:HBTO:FiLTeR:FRAMe<fr>:FLD<fl>:IMAX	1755
SBUS<sb>:HBTO:FiLTeR:FRAMe<fr>:FLD<fl>:IMIN	1755
SBUS<sb>:HBTO:FiLTeR:FRAMe<fr>:FLD<fl>:IOPerator	1756
SBUS<sb>:HBTO:FiLTeR:FRENable	1754
SBUS<sb>:HBTO:FiLTeR:IMAX	1755
SBUS<sb>:HBTO:FiLTeR:IMIN	1755
SBUS<sb>:HBTO:FiLTeR:INVert	1752
SBUS<sb>:HBTO:FiLTeR:IOPerator	1756
SBUS<sb>:HBTO:FiLTeR:RST	1752
SBUS<sb>:HBTO:FRAMe<fr>:BITRate?	1763
SBUS<sb>:HBTO:FRAMe<fr>:CRC?	1765
SBUS<sb>:HBTO:FRAMe<fr>:DATA?	1765
SBUS<sb>:HBTO:FRAMe<fr>:DTADdress?	1765
SBUS<sb>:HBTO:FRAMe<fr>:DTSYmbol?	1766
SBUS<sb>:HBTO:FRAMe<fr>:FCRC?	1766
SBUS<sb>:HBTO:FRAMe<fr>:FDATa?	1766
SBUS<sb>:HBTO:FRAMe<fr>:FDTaddress?	1766
SBUS<sb>:HBTO:FRAMe<fr>:FLD<fl>:FVALue?	1763
SBUS<sb>:HBTO:FRAMe<fr>:FLD<fl>:LABel?	1763
SBUS<sb>:HBTO:FRAMe<fr>:FLD<fl>:STATe?	1764
SBUS<sb>:HBTO:FRAMe<fr>:FLD<fl>:VALue?	1764
SBUS<sb>:HBTO:FRAMe<fr>:FLDCount?	1762
SBUS<sb>:HBTO:FRAMe<fr>:FSRAddress?	1767
SBUS<sb>:HBTO:FRAMe<fr>:FTPLenth?	1767
SBUS<sb>:HBTO:FRAMe<fr>:SRADdress?	1767
SBUS<sb>:HBTO:FRAMe<fr>:SRSYmbol?	1768
SBUS<sb>:HBTO:FRAMe<fr>:START?	1768
SBUS<sb>:HBTO:FRAMe<fr>:STATus?	1768
SBUS<sb>:HBTO:FRAMe<fr>:STOP?	1769
SBUS<sb>:HBTO:FRAMe<fr>:TPLenth?	1769
SBUS<sb>:HBTO:FRAMe<fr>:TYPE?	1769
SBUS<sb>:HBTO:MODE	1749
SBUS<sb>:HBTO:NEWList	1750
SBUS<sb>:HBTO:POLarity	1749

SBUS<sb>:HBTO:POStion.....	1749
SBUS<sb>:HBTO:SCALe.....	1750
SBUS<sb>:HBTO:SOURce.....	1750
SBUS<sb>:HBTO:SWTIndex?.....	1761
SBUS<sb>:HBTO:SWTTime?.....	1761
SBUS<sb>:HBTO:SYMBols.....	1750
SBUS<sb>:I2C:FCOunt?.....	1402
SBUS<sb>:I2C:FILTer:BIT.....	1392
SBUS<sb>:I2C:FILTer:CHKall.....	1388
SBUS<sb>:I2C:FILTer:CLR.....	1388
SBUS<sb>:I2C:FILTer:DMAX.....	1389
SBUS<sb>:I2C:FILTer:DMIN.....	1389
SBUS<sb>:I2C:FILTer:DOPerator.....	1390
SBUS<sb>:I2C:FILTer:ERENable.....	1390
SBUS<sb>:I2C:FILTer:ERRor<n>:ENABle.....	1390
SBUS<sb>:I2C:FILTer:FIENable.....	1392
SBUS<sb>:I2C:FILTer:FRAMe<fr>:ENABle.....	1389
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1392
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1389
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1389
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1390
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1392
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1390
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1391
SBUS<sb>:I2C:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1391
SBUS<sb>:I2C:FILTer:FRENable.....	1389
SBUS<sb>:I2C:FILTer:IMAX.....	1390
SBUS<sb>:I2C:FILTer:IMIN.....	1391
SBUS<sb>:I2C:FILTer:INVert.....	1388
SBUS<sb>:I2C:FILTer:IOPerator.....	1391
SBUS<sb>:I2C:FILTer:RST.....	1388
SBUS<sb>:I2C:FRAMe<fr>:AACCEss?.....	1403
SBUS<sb>:I2C:FRAMe<fr>:ACCEss?.....	1403
SBUS<sb>:I2C:FRAMe<fr>:ACOMplete?.....	1403
SBUS<sb>:I2C:FRAMe<fr>:ADBStArT?.....	1404
SBUS<sb>:I2C:FRAMe<fr>:ADDREss?.....	1404
SBUS<sb>:I2C:FRAMe<fr>:ADEVice?.....	1404
SBUS<sb>:I2C:FRAMe<fr>:AMODE?.....	1405
SBUS<sb>:I2C:FRAMe<fr>:ASTArT?.....	1405
SBUS<sb>:I2C:FRAMe<fr>:BITRate?.....	1405
SBUS<sb>:I2C:FRAMe<fr>:DATA?.....	1408
SBUS<sb>:I2C:FRAMe<fr>:FLD<fl>:FVALue?.....	1406
SBUS<sb>:I2C:FRAMe<fr>:FLD<fl>:LABel?.....	1406
SBUS<sb>:I2C:FRAMe<fr>:FLD<fl>:STArT?.....	1406
SBUS<sb>:I2C:FRAMe<fr>:FLD<fl>:STATe?.....	1407
SBUS<sb>:I2C:FRAMe<fr>:FLD<fl>:VALue?.....	1407
SBUS<sb>:I2C:FRAMe<fr>:FLDCount?.....	1406
SBUS<sb>:I2C:FRAMe<fr>:RWBStArT?.....	1408
SBUS<sb>:I2C:FRAMe<fr>:STArT?.....	1408
SBUS<sb>:I2C:FRAMe<fr>:STATus?.....	1409

SBUS<sb>:I2C:FRAMe<fr>:STOP?	1409
SBUS<sb>:I2C:FRAMe<fr>:SYMBol?	1410
SBUS<sb>:I2C:NEWList	1387
SBUS<sb>:I2C:POSition	1386
SBUS<sb>:I2C:SCALe	1386
SBUS<sb>:I2C:SCL:HYSteresis	1384
SBUS<sb>:I2C:SCL:SOURce	1384
SBUS<sb>:I2C:SCL:THReshold	1385
SBUS<sb>:I2C:SDA:HYSteresis	1385
SBUS<sb>:I2C:SDA:SOURce	1385
SBUS<sb>:I2C:SDA:THReshold	1386
SBUS<sb>:I2C:SWTIndex?	1401
SBUS<sb>:I2C:SWTTime?	1402
SBUS<sb>:I2C:SYMBols	1386
SBUS<sb>:I3C:FCOut?	1426
SBUS<sb>:I3C:FILTer:BIT	1419
SBUS<sb>:I3C:FILTer:CHKall	1415
SBUS<sb>:I3C:FILTer:CLR	1415
SBUS<sb>:I3C:FILTer:DMAX	1416
SBUS<sb>:I3C:FILTer:DMIN	1416
SBUS<sb>:I3C:FILTer:DOPerator	1417
SBUS<sb>:I3C:FILTer:ERENable	1417
SBUS<sb>:I3C:FILTer:ERRor<n>:ENABle	1417
SBUS<sb>:I3C:FILTer:FIENable	1419
SBUS<sb>:I3C:FILTer:FRAMe<fr>:ENABle	1416
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:BIT	1419
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:DMAX	1416
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:DMIN	1416
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:DOPerator	1417
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:ENABle	1419
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:IMAX	1417
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:IMIN	1418
SBUS<sb>:I3C:FILTer:FRAMe<fr>:FLD<fl>:IOPerator	1418
SBUS<sb>:I3C:FILTer:FRENable	1416
SBUS<sb>:I3C:FILTer:IMAX	1417
SBUS<sb>:I3C:FILTer:IMIN	1418
SBUS<sb>:I3C:FILTer:INVert	1415
SBUS<sb>:I3C:FILTer:IOPerator	1418
SBUS<sb>:I3C:FILTer:RST	1415
SBUS<sb>:I3C:FRAMe<fr>:ACK?	1430
SBUS<sb>:I3C:FRAMe<fr>:ACKStart?	1430
SBUS<sb>:I3C:FRAMe<fr>:ADDRes?	1426
SBUS<sb>:I3C:FRAMe<fr>:ASTart?	1426
SBUS<sb>:I3C:FRAMe<fr>:BITRate?	1427
SBUS<sb>:I3C:FRAMe<fr>:COMMan?	1432
SBUS<sb>:I3C:FRAMe<fr>:CRC?	1432
SBUS<sb>:I3C:FRAMe<fr>:DATA?	1427
SBUS<sb>:I3C:FRAMe<fr>:FADDress?	1432
SBUS<sb>:I3C:FRAMe<fr>:FCOMmand?	1433
SBUS<sb>:I3C:FRAMe<fr>:FCRC?	1433

SBUS<sb>:I3C:FRAMe<fr>:FLD<fl>:FVALue?	1430
SBUS<sb>:I3C:FRAMe<fr>:FLD<fl>:LABel?	1431
SBUS<sb>:I3C:FRAMe<fr>:FLD<fl>:STATe?	1431
SBUS<sb>:I3C:FRAMe<fr>:FLD<fl>:VALue?	1432
SBUS<sb>:I3C:FRAMe<fr>:FLDCount?	1427
SBUS<sb>:I3C:FRAMe<fr>:RWBit?	1433
SBUS<sb>:I3C:FRAMe<fr>:RWBStart?	1428
SBUS<sb>:I3C:FRAMe<fr>:START?	1428
SBUS<sb>:I3C:FRAMe<fr>:STATus?	1428
SBUS<sb>:I3C:FRAMe<fr>:STOP?	1429
SBUS<sb>:I3C:FRAMe<fr>:SYMBol?	1429
SBUS<sb>:I3C:FRAMe<fr>:TYPE?	1434
SBUS<sb>:I3C:MINGap:SELEct	1412
SBUS<sb>:I3C:MINGap:WIDTh	1412
SBUS<sb>:I3C:NEWList	1414
SBUS<sb>:I3C:POSition	1413
SBUS<sb>:I3C:SCALE	1413
SBUS<sb>:I3C:SCL:HYSTeresis	1411
SBUS<sb>:I3C:SCL:SOURce	1411
SBUS<sb>:I3C:SCL:THReshold	1411
SBUS<sb>:I3C:SDA:HYSTeresis	1411
SBUS<sb>:I3C:SDA:SOURce	1412
SBUS<sb>:I3C:SDA:THReshold	1412
SBUS<sb>:I3C:SWTIndex?	1425
SBUS<sb>:I3C:SWTTime?	1425
SBUS<sb>:I3C:SYMBols	1413
SBUS<sb>:LIN:BITRate	1578
SBUS<sb>:LIN:DATA:HYSTeresis	1578
SBUS<sb>:LIN:DATA:SOURce	1578
SBUS<sb>:LIN:DATA:THReshold	1579
SBUS<sb>:LIN:FCOut?	1595
SBUS<sb>:LIN:FILTer:BIT	1582
SBUS<sb>:LIN:FILTer:CHKall	1581
SBUS<sb>:LIN:FILTer:CLR	1582
SBUS<sb>:LIN:FILTer:DMAX	1583
SBUS<sb>:LIN:FILTer:DMIN	1583
SBUS<sb>:LIN:FILTer:DOPerator	1583
SBUS<sb>:LIN:FILTer:ERENable	1584
SBUS<sb>:LIN:FILTer:ERRor<n>:ENABLE	1584
SBUS<sb>:LIN:FILTer:FIENable	1584
SBUS<sb>:LIN:FILTer:FRAMe<fr>:ENABLE	1584
SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:BIT	1582
SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:DMAX	1583
SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:DMIN	1583
SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:DOPerator	1583
SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:ENABLE	1584
SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:IMAX	1585
SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:IMIN	1585
SBUS<sb>:LIN:FILTer:FRAMe<fr>:FLD<fl>:IOPerator	1586
SBUS<sb>:LIN:FILTer:FRENable	1584

SBUS<sb>:LIN:FILTer:IMAX.....	1585
SBUS<sb>:LIN:FILTer:IMIN.....	1585
SBUS<sb>:LIN:FILTer:INVert.....	1582
SBUS<sb>:LIN:FILTer:IOperator.....	1586
SBUS<sb>:LIN:FILTer:RST.....	1582
SBUS<sb>:LIN:FRAMe<fr>:BITRate?.....	1596
SBUS<sb>:LIN:FRAMe<fr>:CSValue?.....	1598
SBUS<sb>:LIN:FRAMe<fr>:DATA?.....	1598
SBUS<sb>:LIN:FRAMe<fr>:FLD<fl>:FVALue?.....	1597
SBUS<sb>:LIN:FRAMe<fr>:FLD<fl>:LABel?.....	1597
SBUS<sb>:LIN:FRAMe<fr>:FLD<fl>:STATe?.....	1596
SBUS<sb>:LIN:FRAMe<fr>:FLD<fl>:VALue?.....	1597
SBUS<sb>:LIN:FRAMe<fr>:FLDCount?.....	1596
SBUS<sb>:LIN:FRAMe<fr>:IDPValue?.....	1598
SBUS<sb>:LIN:FRAMe<fr>:IDValue?.....	1599
SBUS<sb>:LIN:FRAMe<fr>:PIDentifier?.....	1600
SBUS<sb>:LIN:FRAMe<fr>:STARt?.....	1599
SBUS<sb>:LIN:FRAMe<fr>:STATus?.....	1599
SBUS<sb>:LIN:FRAMe<fr>:STOP?.....	1600
SBUS<sb>:LIN:FRAMe<fr>:SYMBol?.....	1600
SBUS<sb>:LIN:NEWList.....	1580
SBUS<sb>:LIN:POLarity.....	1579
SBUS<sb>:LIN:POSition.....	1580
SBUS<sb>:LIN:SCALE.....	1580
SBUS<sb>:LIN:STANdard.....	1579
SBUS<sb>:LIN:SWTIndex?.....	1594
SBUS<sb>:LIN:SWTTime?.....	1595
SBUS<sb>:LIN:SYMBols.....	1580
SBUS<sb>:MANCh:BITRate:SElect.....	1514
SBUS<sb>:MANCh:BITRate:WIDTh.....	1514
SBUS<sb>:MANCh:DATA:HYSTeresis.....	1515
SBUS<sb>:MANCh:DATA:PHASe.....	1512
SBUS<sb>:MANCh:DATA:POLarity.....	1511
SBUS<sb>:MANCh:DATA:SOURce.....	1511
SBUS<sb>:MANCh:DATA:THLower.....	1514
SBUS<sb>:MANCh:DATA:THUPper.....	1514
SBUS<sb>:MANCh:ENABLE:HYSTeresis.....	1515
SBUS<sb>:MANCh:ENABLE:POLarity.....	1512
SBUS<sb>:MANCh:ENABLE:SOURce.....	1512
SBUS<sb>:MANCh:ENABLE:THReshold.....	1515
SBUS<sb>:MANCh:FCOunt?.....	1534
SBUS<sb>:MANCh:FILTer:BIT.....	1518
SBUS<sb>:MANCh:FILTer:CHKall.....	1517
SBUS<sb>:MANCh:FILTer:CLR.....	1517
SBUS<sb>:MANCh:FILTer:DMAX.....	1518
SBUS<sb>:MANCh:FILTer:DMIN.....	1519
SBUS<sb>:MANCh:FILTer:DOPerator.....	1519
SBUS<sb>:MANCh:FILTer:ERENable.....	1518
SBUS<sb>:MANCh:FILTer:ERRor<n>:ENABle.....	1518
SBUS<sb>:MANCh:FILTer:FIENable.....	1519

SBUS<sb>:MANCh:FiLTeR:FRAMe<fr>:ENABle.....	1520
SBUS<sb>:MANCh:FiLTeR:FRAMe<fr>:FLD<fl>:BIT.....	1518
SBUS<sb>:MANCh:FiLTeR:FRAMe<fr>:FLD<fl>:DMax.....	1518
SBUS<sb>:MANCh:FiLTeR:FRAMe<fr>:FLD<fl>:DMin.....	1519
SBUS<sb>:MANCh:FiLTeR:FRAMe<fr>:FLD<fl>:DOPerator.....	1519
SBUS<sb>:MANCh:FiLTeR:FRAMe<fr>:FLD<fl>:ENABle.....	1519
SBUS<sb>:MANCh:FiLTeR:FRAMe<fr>:FLD<fl>:IMAX.....	1520
SBUS<sb>:MANCh:FiLTeR:FRAMe<fr>:FLD<fl>:IMIN.....	1521
SBUS<sb>:MANCh:FiLTeR:FRAMe<fr>:FLD<fl>:IOPerator.....	1521
SBUS<sb>:MANCh:FiLTeR:FRENAble.....	1520
SBUS<sb>:MANCh:FiLTeR:IMAX.....	1520
SBUS<sb>:MANCh:FiLTeR:IMIN.....	1521
SBUS<sb>:MANCh:FiLTeR:INVerT.....	1517
SBUS<sb>:MANCh:FiLTeR:IOPerator.....	1521
SBUS<sb>:MANCh:FiLTeR:RST.....	1517
SBUS<sb>:MANCh:FORMat:ADDFrame.....	1522
SBUS<sb>:MANCh:FORMat:CLR.....	1523
SBUS<sb>:MANCh:FORMat:FCounT?.....	1523
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:ADDField.....	1523
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:COLor.....	1524
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:BITCounT.....	1525
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:BITOrder.....	1526
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:CLMN.....	1527
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:COLor.....	1525
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:CONDition.....	1525
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:FORMat.....	1526
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLD<fl>:NAME.....	1524
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:FLDCounT?.....	1523
SBUS<sb>:MANCh:FORMat:FRAMe<fr>:NAME.....	1524
SBUS<sb>:MANCh:FORMat:LOAD.....	1522
SBUS<sb>:MANCh:FORMat:SAVE.....	1522
SBUS<sb>:MANCh:FRAMe<fr>:CONE?.....	1537
SBUS<sb>:MANCh:FRAMe<fr>:CTHRee?.....	1538
SBUS<sb>:MANCh:FRAMe<fr>:CTWO?.....	1538
SBUS<sb>:MANCh:FRAMe<fr>:FLD<fl>:FVALue?.....	1536
SBUS<sb>:MANCh:FRAMe<fr>:FLD<fl>:LABel?.....	1535
SBUS<sb>:MANCh:FRAMe<fr>:FLD<fl>:STATe?.....	1534
SBUS<sb>:MANCh:FRAMe<fr>:FLD<fl>:VALue?.....	1535
SBUS<sb>:MANCh:FRAMe<fr>:FLDCounT?.....	1534
SBUS<sb>:MANCh:FRAMe<fr>:STARt?.....	1536
SBUS<sb>:MANCh:FRAMe<fr>:STATus?.....	1536
SBUS<sb>:MANCh:FRAMe<fr>:STOP?.....	1537
SBUS<sb>:MANCh:FRAMe<fr>:TYPE?.....	1537
SBUS<sb>:MANCh:FRAMe<fr>:WBRate?.....	1534
SBUS<sb>:MANCh:MINGap:SELeCt.....	1513
SBUS<sb>:MANCh:MINGap:WIDTh.....	1513
SBUS<sb>:MANCh:POSition.....	1515
SBUS<sb>:MANCh:SCALE.....	1516
SBUS<sb>:MANCh:SWTIndex?.....	1533
SBUS<sb>:MANCh:SWTTime?.....	1533

SBUS<sb>:MILStd:FILTer:BIT.....	1650
SBUS<sb>:MILStd:FILTer:CHKall.....	1649
SBUS<sb>:MILStd:FILTer:CLR.....	1649
SBUS<sb>:MILStd:FILTer:DMAX.....	1650
SBUS<sb>:MILStd:FILTer:DMIN.....	1651
SBUS<sb>:MILStd:FILTer:DOPerator.....	1651
SBUS<sb>:MILStd:FILTer:ERENable.....	1650
SBUS<sb>:MILStd:FILTer:ERRor<n>:ENABLE.....	1650
SBUS<sb>:MILStd:FILTer:FIENable.....	1653
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:ENABLE.....	1653
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1650
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1650
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1651
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1651
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:ENABLE.....	1653
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1651
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1652
SBUS<sb>:MILStd:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1652
SBUS<sb>:MILStd:FILTer:FRENable.....	1653
SBUS<sb>:MILStd:FILTer:IMAX.....	1651
SBUS<sb>:MILStd:FILTer:IMIN.....	1652
SBUS<sb>:MILStd:FILTer:INVert.....	1649
SBUS<sb>:MILStd:FILTer:IOPerator.....	1652
SBUS<sb>:MILStd:FILTer:RST.....	1649
SBUS<sb>:MILStd:NEWList.....	1647
SBUS<sb>:MILStd:POLarity.....	1646
SBUS<sb>:MILStd:POSition.....	1647
SBUS<sb>:MILStd:SCALE.....	1647
SBUS<sb>:MILStd:SOURce.....	1646
SBUS<sb>:MILStd:SWTIndex?.....	1659
SBUS<sb>:MILStd:SWTTime?.....	1659
SBUS<sb>:MILStd:SYMBols.....	1648
SBUS<sb>:MILStd:THReshold:HIGH.....	1646
SBUS<sb>:MILStd:THReshold:HYSTeresis.....	1646
SBUS<sb>:MILStd:THReshold:LOW.....	1647
SBUS<sb>:MILStd:WCOunt?.....	1659
SBUS<sb>:MILStd:WORD<w>:BITRate?.....	1660
SBUS<sb>:MILStd:WORD<w>:DATA?.....	1660
SBUS<sb>:MILStd:WORD<w>:INFO?.....	1660
SBUS<sb>:MILStd:WORD<w>:RTAdDress?.....	1661
SBUS<sb>:MILStd:WORD<w>:STARt?.....	1661
SBUS<sb>:MILStd:WORD<w>:STATus?.....	1661
SBUS<sb>:MILStd:WORD<w>:STOP?.....	1662
SBUS<sb>:MILStd:WORD<w>:SYMBol?.....	1662
SBUS<sb>:MILStd:WORD<w>:TYPE?.....	1663
SBUS<sb>:NRZC:CLK:HYSTeresis.....	1460
SBUS<sb>:NRZC:CLK:POLarity.....	1457
SBUS<sb>:NRZC:CLK:SOURce.....	1457
SBUS<sb>:NRZC:CLK:THReshold.....	1459
SBUS<sb>:NRZC:DATA:HYSTeresis.....	1460

SBUS<sb>:NRZC:DATA:POLarity.....	1458
SBUS<sb>:NRZC:DATA:SOURce.....	1457
SBUS<sb>:NRZC:DATA:THReshold.....	1460
SBUS<sb>:NRZC:ENABle:HYSTeresis.....	1461
SBUS<sb>:NRZC:ENABle:POLarity.....	1458
SBUS<sb>:NRZC:ENABle:SOURce.....	1458
SBUS<sb>:NRZC:ENABle:THReshold.....	1460
SBUS<sb>:NRZC:FCOunt?.....	1479
SBUS<sb>:NRZC:FILTer:BIT.....	1463
SBUS<sb>:NRZC:FILTer:CHKall.....	1462
SBUS<sb>:NRZC:FILTer:CLR.....	1462
SBUS<sb>:NRZC:FILTer:DMAX.....	1464
SBUS<sb>:NRZC:FILTer:DMIN.....	1464
SBUS<sb>:NRZC:FILTer:DOPerator.....	1464
SBUS<sb>:NRZC:FILTer:ERENable.....	1463
SBUS<sb>:NRZC:FILTer:ERRor<n>:ENABle.....	1463
SBUS<sb>:NRZC:FILTer:FIENable.....	1465
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:ENABle.....	1465
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1463
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1464
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1464
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1464
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1465
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1466
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1466
SBUS<sb>:NRZC:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1466
SBUS<sb>:NRZC:FILTer:FRENable.....	1465
SBUS<sb>:NRZC:FILTer:IMAX.....	1466
SBUS<sb>:NRZC:FILTer:IMIN.....	1466
SBUS<sb>:NRZC:FILTer:INVert.....	1462
SBUS<sb>:NRZC:FILTer:IOPerator.....	1466
SBUS<sb>:NRZC:FILTer:RST.....	1463
SBUS<sb>:NRZC:FORMat:ADDFrame.....	1467
SBUS<sb>:NRZC:FORMat:CLR.....	1468
SBUS<sb>:NRZC:FORMat:FCOunt?.....	1468
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:ADDField.....	1469
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:COLor.....	1469
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:BITCount.....	1470
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:BITorder.....	1472
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:CLMN.....	1472
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:COLor.....	1470
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:CONDition.....	1471
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:FORMat.....	1471
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLD<fl>:NAME.....	1470
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:FLDCount?.....	1469
SBUS<sb>:NRZC:FORMat:FRAMe<fr>:NAME.....	1469
SBUS<sb>:NRZC:FORMat:LOAD.....	1467
SBUS<sb>:NRZC:FORMat:SAVE.....	1468
SBUS<sb>:NRZC:FRAMe<fr>:CONE?.....	1483
SBUS<sb>:NRZC:FRAMe<fr>:CTHRee?.....	1483

SBUS<sb>:NRZC:FRAMe<fr>:CTWO?	1483
SBUS<sb>:NRZC:FRAMe<fr>:FLD<fl>:FVALue?	1481
SBUS<sb>:NRZC:FRAMe<fr>:FLD<fl>:LABel?	1480
SBUS<sb>:NRZC:FRAMe<fr>:FLD<fl>:STATe?	1480
SBUS<sb>:NRZC:FRAMe<fr>:FLD<fl>:VALue?	1481
SBUS<sb>:NRZC:FRAMe<fr>:FLDCount?	1479
SBUS<sb>:NRZC:FRAMe<fr>:START?	1482
SBUS<sb>:NRZC:FRAMe<fr>:STATus?	1481
SBUS<sb>:NRZC:FRAMe<fr>:STOP?	1482
SBUS<sb>:NRZC:FRAMe<fr>:TYPE?	1483
SBUS<sb>:NRZC:FRAMe<fr>:WBRate?	1480
SBUS<sb>:NRZC:MINGap:SElect	1459
SBUS<sb>:NRZC:MINGap:WIDTh	1459
SBUS<sb>:NRZC:POSition	1461
SBUS<sb>:NRZC:SCALe	1461
SBUS<sb>:NRZC:SWTindex?	1478
SBUS<sb>:NRZC:SWTTime?	1478
SBUS<sb>:NRZU:BITRate:SElect	1486
SBUS<sb>:NRZU:BITRate:WIDTh	1487
SBUS<sb>:NRZU:DATA:HYSTeresis	1487
SBUS<sb>:NRZU:DATA:POLarity	1485
SBUS<sb>:NRZU:DATA:SOURce	1484
SBUS<sb>:NRZU:DATA:THReshold	1487
SBUS<sb>:NRZU:ENABle:HYSTeresis	1488
SBUS<sb>:NRZU:ENABle:POLarity	1485
SBUS<sb>:NRZU:ENABle:SOURce	1485
SBUS<sb>:NRZU:ENABle:THReshold	1487
SBUS<sb>:NRZU:FCOunt?	1506
SBUS<sb>:NRZU:FILTer:BIT	1490
SBUS<sb>:NRZU:FILTer:CHKall	1489
SBUS<sb>:NRZU:FILTer:CLR	1489
SBUS<sb>:NRZU:FILTer:DMAX	1491
SBUS<sb>:NRZU:FILTer:DMIN	1491
SBUS<sb>:NRZU:FILTer:DOPerator	1491
SBUS<sb>:NRZU:FILTer:ERENable	1490
SBUS<sb>:NRZU:FILTer:ERRor<n>:ENABle	1490
SBUS<sb>:NRZU:FILTer:FIENable	1492
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:ENABle	1492
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:BIT	1490
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:DMAX	1491
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:DMIN	1491
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:DOPerator	1491
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:ENABle	1492
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:IMAX	1492
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:IMIN	1493
SBUS<sb>:NRZU:FILTer:FRAMe<fr>:FLD<fl>:IOPerator	1493
SBUS<sb>:NRZU:FILTer:FRENable	1492
SBUS<sb>:NRZU:FILTer:IMAX	1492
SBUS<sb>:NRZU:FILTer:IMIN	1493
SBUS<sb>:NRZU:FILTer:INVert	1489

SBUS<sb>:NRZU:FILTer:IOPerator.....	1493
SBUS<sb>:NRZU:FILTer:RST.....	1490
SBUS<sb>:NRZU:FORMat:ADDFrame.....	1494
SBUS<sb>:NRZU:FORMat:CLR.....	1495
SBUS<sb>:NRZU:FORMat:FCOunt?.....	1495
SBUS<sb>:NRZU:FORMat:FRAME<fr>:ADDField.....	1495
SBUS<sb>:NRZU:FORMat:FRAME<fr>:COLor.....	1496
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLD<fl>:BITCount.....	1497
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLD<fl>:BITOrder.....	1499
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLD<fl>:CLMN.....	1499
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLD<fl>:COLor.....	1497
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLD<fl>:CONDition.....	1498
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLD<fl>:FORMat.....	1498
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLD<fl>:NAME.....	1497
SBUS<sb>:NRZU:FORMat:FRAME<fr>:FLDCount?.....	1496
SBUS<sb>:NRZU:FORMat:FRAME<fr>:NAME.....	1496
SBUS<sb>:NRZU:FORMat:LOAD.....	1494
SBUS<sb>:NRZU:FORMat:SAVE.....	1495
SBUS<sb>:NRZU:FRAME<fr>:CONE?.....	1510
SBUS<sb>:NRZU:FRAME<fr>:CTHRee?.....	1510
SBUS<sb>:NRZU:FRAME<fr>:CTWO?.....	1510
SBUS<sb>:NRZU:FRAME<fr>:FLD<fl>:FVALue?.....	1508
SBUS<sb>:NRZU:FRAME<fr>:FLD<fl>:LABel?.....	1507
SBUS<sb>:NRZU:FRAME<fr>:FLD<fl>:STATe?.....	1507
SBUS<sb>:NRZU:FRAME<fr>:FLD<fl>:VALue?.....	1508
SBUS<sb>:NRZU:FRAME<fr>:FLDCount?.....	1506
SBUS<sb>:NRZU:FRAME<fr>:START?.....	1509
SBUS<sb>:NRZU:FRAME<fr>:STATus?.....	1508
SBUS<sb>:NRZU:FRAME<fr>:STOP?.....	1509
SBUS<sb>:NRZU:FRAME<fr>:TYPE?.....	1509
SBUS<sb>:NRZU:FRAME<fr>:WBRate?.....	1506
SBUS<sb>:NRZU:MINGap:SELEct.....	1486
SBUS<sb>:NRZU:MINGap:WIDTh.....	1486
SBUS<sb>:NRZU:POSition.....	1488
SBUS<sb>:NRZU:SCALE.....	1488
SBUS<sb>:NRZU:SWTIndex?.....	1505
SBUS<sb>:NRZU:SWTTime?.....	1505
SBUS<sb>:QSPI:CSEL:HYSTeresis.....	1353
SBUS<sb>:QSPI:CSEL:POLarity.....	1353
SBUS<sb>:QSPI:CSEL:SOURce.....	1353
SBUS<sb>:QSPI:CSEL:THReshold.....	1354
SBUS<sb>:QSPI:FCOunt?.....	1378
SBUS<sb>:QSPI:FILTer:BIT.....	1369
SBUS<sb>:QSPI:FILTer:CHKall.....	1368
SBUS<sb>:QSPI:FILTer:CLR.....	1368
SBUS<sb>:QSPI:FILTer:DMAX.....	1369
SBUS<sb>:QSPI:FILTer:DMIN.....	1369
SBUS<sb>:QSPI:FILTer:DOPerator.....	1370
SBUS<sb>:QSPI:FILTer:ERENable.....	1371
SBUS<sb>:QSPI:FILTer:ERRor<n>:ENABle.....	1371

SBUS<sb>:QSPI:FILTer:FIENable.....	1372
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:ENABLe.....	1372
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1369
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1369
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1369
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1370
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:ENABLe.....	1372
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1370
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1370
SBUS<sb>:QSPI:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1371
SBUS<sb>:QSPI:FILTer:FRENable.....	1372
SBUS<sb>:QSPI:FILTer:IMAX.....	1370
SBUS<sb>:QSPI:FILTer:IMIN.....	1370
SBUS<sb>:QSPI:FILTer:INVert.....	1368
SBUS<sb>:QSPI:FILTer:IOPerator.....	1371
SBUS<sb>:QSPI:FILTer:RST.....	1368
SBUS<sb>:QSPI:FRAMe<fr>:ADDR?.....	1379
SBUS<sb>:QSPI:FRAMe<fr>:ALT?.....	1379
SBUS<sb>:QSPI:FRAMe<fr>:BITRate?.....	1379
SBUS<sb>:QSPI:FRAMe<fr>:DATA?.....	1380
SBUS<sb>:QSPI:FRAMe<fr>:FDATa?.....	1380
SBUS<sb>:QSPI:FRAMe<fr>:FLD<fl>:FVALue?.....	1381
SBUS<sb>:QSPI:FRAMe<fr>:FLD<fl>:LABel?.....	1381
SBUS<sb>:QSPI:FRAMe<fr>:FLD<fl>:STATe?.....	1381
SBUS<sb>:QSPI:FRAMe<fr>:FLD<fl>:VALue?.....	1380
SBUS<sb>:QSPI:FRAMe<fr>:FLDCount?.....	1380
SBUS<sb>:QSPI:FRAMe<fr>:ILBL?.....	1382
SBUS<sb>:QSPI:FRAMe<fr>:IVALue?.....	1382
SBUS<sb>:QSPI:FRAMe<fr>:START?.....	1383
SBUS<sb>:QSPI:FRAMe<fr>:STATus?.....	1383
SBUS<sb>:QSPI:FRAMe<fr>:STOP?.....	1383
SBUS<sb>:QSPI:INSTruction.....	1354
SBUS<sb>:QSPI:IOONe:HYSTeresis.....	1354
SBUS<sb>:QSPI:IOONe:POLarity.....	1354
SBUS<sb>:QSPI:IOONe:POSition.....	1355
SBUS<sb>:QSPI:IOONe:SCALE.....	1355
SBUS<sb>:QSPI:IOONe:SOURce.....	1355
SBUS<sb>:QSPI:IOONe:THReshold.....	1355
SBUS<sb>:QSPI:IOThree:HYSTeresis.....	1356
SBUS<sb>:QSPI:IOThree:POLarity.....	1356
SBUS<sb>:QSPI:IOThree:POSition.....	1356
SBUS<sb>:QSPI:IOThree:SCALE.....	1357
SBUS<sb>:QSPI:IOThree:SOURce.....	1357
SBUS<sb>:QSPI:IOThree:THReshold.....	1357
SBUS<sb>:QSPI:IOTWo:HYSTeresis.....	1357
SBUS<sb>:QSPI:IOTWo:POLarity.....	1358
SBUS<sb>:QSPI:IOTWo:POSition.....	1358
SBUS<sb>:QSPI:IOTWo:SCALE.....	1358
SBUS<sb>:QSPI:IOTWo:SOURce.....	1358
SBUS<sb>:QSPI:IOTWo:THReshold.....	1359

SBUS<sb>:QSPI:IOZero:HYSTeresis.....	1359
SBUS<sb>:QSPI:IOZero:POLarity.....	1359
SBUS<sb>:QSPI:IOZero:POSition.....	1360
SBUS<sb>:QSPI:IOZero:SCALE.....	1360
SBUS<sb>:QSPI:IOZero:SOURce.....	1360
SBUS<sb>:QSPI:IOZero:THReshold.....	1360
SBUS<sb>:QSPI:LDOPcode.....	1363
SBUS<sb>:QSPI:OPCode:APPend.....	1362
SBUS<sb>:QSPI:OPCode:DALL.....	1362
SBUS<sb>:QSPI:OPCode:DElete.....	1362
SBUS<sb>:QSPI:OPCode:ITEM<n>:ADBYtes.....	1364
SBUS<sb>:QSPI:OPCode:ITEM<n>:ADLanes.....	1364
SBUS<sb>:QSPI:OPCode:ITEM<n>:ALT.....	1364
SBUS<sb>:QSPI:OPCode:ITEM<n>:CODE.....	1365
SBUS<sb>:QSPI:OPCode:ITEM<n>:DATA.....	1365
SBUS<sb>:QSPI:OPCode:ITEM<n>:DDR.....	1365
SBUS<sb>:QSPI:OPCode:ITEM<n>:DMCYcles.....	1366
SBUS<sb>:QSPI:OPCode:ITEM<n>:DTLanes.....	1366
SBUS<sb>:QSPI:OPCode:ITEM<n>:NAME.....	1366
SBUS<sb>:QSPI:OPCode:RESet.....	1363
SBUS<sb>:QSPI:OPCode:SIZE?.....	1363
SBUS<sb>:QSPI:SCLK:HYSTeresis.....	1361
SBUS<sb>:QSPI:SCLK:POLarity.....	1361
SBUS<sb>:QSPI:SCLK:SOURce.....	1361
SBUS<sb>:QSPI:SCLK:THReshold.....	1361
SBUS<sb>:QSPI:SVOP.....	1367
SBUS<sb>:QSPI:SWTIndex?.....	1377
SBUS<sb>:QSPI:SWTTime?.....	1378
SBUS<sb>:RESult.....	1324
SBUS<sb>:RFFE:CLOCK:HYSTeresis.....	1704
SBUS<sb>:RFFE:CLOCK:SOURce.....	1704
SBUS<sb>:RFFE:CLOCK:THReshold.....	1704
SBUS<sb>:RFFE:DATA:HYSTeresis.....	1704
SBUS<sb>:RFFE:DATA:SOURce.....	1705
SBUS<sb>:RFFE:DATA:THReshold.....	1705
SBUS<sb>:RFFE:FCOunt?.....	1720
SBUS<sb>:RFFE:FILTer:BIT.....	1709
SBUS<sb>:RFFE:FILTer:CHKall.....	1707
SBUS<sb>:RFFE:FILTer:CLR.....	1708
SBUS<sb>:RFFE:FILTer:DMAX.....	1709
SBUS<sb>:RFFE:FILTer:DMIN.....	1710
SBUS<sb>:RFFE:FILTer:DOPerator.....	1710
SBUS<sb>:RFFE:FILTer:ERENable.....	1712
SBUS<sb>:RFFE:FILTer:ERRor<n>:ENABLE.....	1712
SBUS<sb>:RFFE:FILTer:FIENable.....	1710
SBUS<sb>:RFFE:FILTer:FRAME<fr>:ENABLE.....	1708
SBUS<sb>:RFFE:FILTer:FRAME<fr>:FLD<fl>:BIT.....	1709
SBUS<sb>:RFFE:FILTer:FRAME<fr>:FLD<fl>:DMAX.....	1709
SBUS<sb>:RFFE:FILTer:FRAME<fr>:FLD<fl>:DMIN.....	1710
SBUS<sb>:RFFE:FILTer:FRAME<fr>:FLD<fl>:DOPerator.....	1710

SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1710
SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1711
SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1711
SBUS<sb>:RFFE:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1712
SBUS<sb>:RFFE:FILTer:FRENable.....	1708
SBUS<sb>:RFFE:FILTer:IMAX.....	1711
SBUS<sb>:RFFE:FILTer:IMIN.....	1711
SBUS<sb>:RFFE:FILTer:INVert.....	1708
SBUS<sb>:RFFE:FILTer:IOPerator.....	1712
SBUS<sb>:RFFE:FILTer:RST.....	1708
SBUS<sb>:RFFE:FRAMe<fr>:ADDResS?.....	1720
SBUS<sb>:RFFE:FRAMe<fr>:BCOunt?.....	1720
SBUS<sb>:RFFE:FRAMe<fr>:DATA?.....	1720
SBUS<sb>:RFFE:FRAMe<fr>:FLD<fl>:FVALue?.....	1721
SBUS<sb>:RFFE:FRAMe<fr>:FLD<fl>:NAME?.....	1721
SBUS<sb>:RFFE:FRAMe<fr>:FLD<fl>:STATe?.....	1722
SBUS<sb>:RFFE:FRAMe<fr>:FLD<fl>:VALue?.....	1722
SBUS<sb>:RFFE:FRAMe<fr>:FLDCount?.....	1721
SBUS<sb>:RFFE:FRAMe<fr>:PADone?.....	1719
SBUS<sb>:RFFE:FRAMe<fr>:PADZero?.....	1719
SBUS<sb>:RFFE:FRAMe<fr>:PCTRI?.....	1719
SBUS<sb>:RFFE:FRAMe<fr>:RBTRate?.....	1722
SBUS<sb>:RFFE:FRAMe<fr>:SADD?.....	1723
SBUS<sb>:RFFE:FRAMe<fr>:START?.....	1723
SBUS<sb>:RFFE:FRAMe<fr>:STATe?.....	1723
SBUS<sb>:RFFE:FRAMe<fr>:STOP?.....	1724
SBUS<sb>:RFFE:FRAMe<fr>:SYMBol?.....	1726
SBUS<sb>:RFFE:FRAMe<fr>:TYPE?.....	1724
SBUS<sb>:RFFE:FRAMe<fr>:WBTRate?.....	1725
SBUS<sb>:RFFE:GFILter.....	1705
SBUS<sb>:RFFE:GFWidth.....	1706
SBUS<sb>:RFFE:NEWList.....	1725
SBUS<sb>:RFFE:POSition.....	1706
SBUS<sb>:RFFE:RDMD.....	1706
SBUS<sb>:RFFE:SCALE.....	1706
SBUS<sb>:RFFE:SWTIndex?.....	1718
SBUS<sb>:RFFE:SWTTime?.....	1718
SBUS<sb>:RFFE:SYMBols.....	1726
SBUS<sb>:RMSBus.....	1324
SBUS<sb>:SENT:CLKPeriod.....	1601
SBUS<sb>:SENT:CLKTolerance.....	1602
SBUS<sb>:SENT:CRCMethod.....	1602
SBUS<sb>:SENT:CRCVersion.....	1602
SBUS<sb>:SENT:DATA:HYSTeresis.....	1603
SBUS<sb>:SENT:DATA:SOURce.....	1603
SBUS<sb>:SENT:DATA:THReshold.....	1603
SBUS<sb>:SENT:DNIBbles.....	1604
SBUS<sb>:SENT:FCOunt?.....	1619
SBUS<sb>:SENT:FILTer:BIT.....	1609
SBUS<sb>:SENT:FILTer:CHKall.....	1608

SBUS<sb>:SENT:FILTer:CLR.....	1608
SBUS<sb>:SENT:FILTer:DMAX.....	1610
SBUS<sb>:SENT:FILTer:DMIN.....	1610
SBUS<sb>:SENT:FILTer:DOPerator.....	1611
SBUS<sb>:SENT:FILTer:ERENable.....	1613
SBUS<sb>:SENT:FILTer:ERRor<n>:ENABle.....	1613
SBUS<sb>:SENT:FILTer:FIENable.....	1611
SBUS<sb>:SENT:FILTer:FRAMe<fr>:ENABle.....	1609
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1609
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1610
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1610
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1611
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1611
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1611
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1612
SBUS<sb>:SENT:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1612
SBUS<sb>:SENT:FILTer:FRENable.....	1609
SBUS<sb>:SENT:FILTer:IMAX.....	1611
SBUS<sb>:SENT:FILTer:IMIN.....	1612
SBUS<sb>:SENT:FILTer:INVert.....	1609
SBUS<sb>:SENT:FILTer:IOPerator.....	1612
SBUS<sb>:SENT:FILTer:RST.....	1609
SBUS<sb>:SENT:FRAMe<fr>:BITRate?.....	1620
SBUS<sb>:SENT:FRAMe<fr>:CSValue?.....	1620
SBUS<sb>:SENT:FRAMe<fr>:DATA?.....	1620
SBUS<sb>:SENT:FRAMe<fr>:FDValues?.....	1620
SBUS<sb>:SENT:FRAMe<fr>:FLD<fl>:FVALue?.....	1623
SBUS<sb>:SENT:FRAMe<fr>:FLD<fl>:LABel?.....	1624
SBUS<sb>:SENT:FRAMe<fr>:FLD<fl>:STATe?.....	1623
SBUS<sb>:SENT:FRAMe<fr>:FLD<fl>:VALue?.....	1623
SBUS<sb>:SENT:FRAMe<fr>:FLDCount?.....	1622
SBUS<sb>:SENT:FRAMe<fr>:FSCom?.....	1621
SBUS<sb>:SENT:FRAMe<fr>:FSDTa?.....	1621
SBUS<sb>:SENT:FRAMe<fr>:IDTYpe?.....	1621
SBUS<sb>:SENT:FRAMe<fr>:IDValue?.....	1622
SBUS<sb>:SENT:FRAMe<fr>:MTPDuration?.....	1622
SBUS<sb>:SENT:FRAMe<fr>:PAPTicks?.....	1624
SBUS<sb>:SENT:FRAMe<fr>:SCOM?.....	1624
SBUS<sb>:SENT:FRAMe<fr>:SDATa?.....	1625
SBUS<sb>:SENT:FRAMe<fr>:SENSor?.....	1625
SBUS<sb>:SENT:FRAMe<fr>:START?.....	1625
SBUS<sb>:SENT:FRAMe<fr>:STATus?.....	1625
SBUS<sb>:SENT:FRAMe<fr>:STOP?.....	1626
SBUS<sb>:SENT:FRAMe<fr>:SYMBol?.....	1626
SBUS<sb>:SENT:FRAMe<fr>:SYNCduration?.....	1627
SBUS<sb>:SENT:FRAMe<fr>:TYPE?.....	1627
SBUS<sb>:SENT:MODE.....	1604
SBUS<sb>:SENT:NEWList.....	1604
SBUS<sb>:SENT:POSition.....	1605
SBUS<sb>:SENT:PPFLength.....	1605

SBUS<sb>:SENT:PPULse.....	1605
SBUS<sb>:SENT:RDSL.....	1606
SBUS<sb>:SENT:SCALE.....	1606
SBUS<sb>:SENT:SFormat.....	1606
SBUS<sb>:SENT:SWTIndex?.....	1606
SBUS<sb>:SENT:SWTIndex?.....	1618
SBUS<sb>:SENT:SWTTime?.....	1607
SBUS<sb>:SENT:SWTTime?.....	1618
SBUS<sb>:SENT:SYMBOLs.....	1607
SBUS<sb>:SPI:BORDER.....	1328
SBUS<sb>:SPI:CSElect:HYSteresis.....	1328
SBUS<sb>:SPI:CSElect:POLarity.....	1329
SBUS<sb>:SPI:CSElect:SOURce.....	1329
SBUS<sb>:SPI:CSElect:THReshold.....	1329
SBUS<sb>:SPI:FCOut?.....	1347
SBUS<sb>:SPI:FILTer:BIT.....	1336
SBUS<sb>:SPI:FILTer:CHKall.....	1335
SBUS<sb>:SPI:FILTer:CLR.....	1335
SBUS<sb>:SPI:FILTer:DMAX.....	1336
SBUS<sb>:SPI:FILTer:DMIN.....	1337
SBUS<sb>:SPI:FILTer:DOPerator.....	1337
SBUS<sb>:SPI:FILTer:ERENable.....	1337
SBUS<sb>:SPI:FILTer:ERRor<n>:ENABle.....	1337
SBUS<sb>:SPI:FILTer:FIENable.....	1338
SBUS<sb>:SPI:FILTer:FRAMe<fr>:ENABle.....	1338
SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1336
SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1336
SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1337
SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1337
SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1338
SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1338
SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1339
SBUS<sb>:SPI:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1339
SBUS<sb>:SPI:FILTer:FRENable.....	1338
SBUS<sb>:SPI:FILTer:IMAX.....	1338
SBUS<sb>:SPI:FILTer:IMIN.....	1339
SBUS<sb>:SPI:FILTer:INVert.....	1335
SBUS<sb>:SPI:FILTer:IOPerator.....	1339
SBUS<sb>:SPI:FILTer:RST.....	1336
SBUS<sb>:SPI:FRAMe<fr>:BITRate?.....	1348
SBUS<sb>:SPI:FRAMe<fr>:DATA?.....	1348
SBUS<sb>:SPI:FRAMe<fr>:START?.....	1348
SBUS<sb>:SPI:FRAMe<fr>:STATus?.....	1349
SBUS<sb>:SPI:FRAMe<fr>:STOP?.....	1349
SBUS<sb>:SPI:FRAMe<fr>:WCOut?.....	1349
SBUS<sb>:SPI:FRAMe<fr>:WORD<w>:FMISo?.....	1350
SBUS<sb>:SPI:FRAMe<fr>:WORD<w>:FMOSi?.....	1350
SBUS<sb>:SPI:FRAMe<fr>:WORD<w>:MISO?.....	1350
SBUS<sb>:SPI:FRAMe<fr>:WORD<w>:MOSI?.....	1351
SBUS<sb>:SPI:FRAMe<fr>:WORD<w>:START?.....	1351

SBUS<sb>:SPI:FRAMe<fr>:WORD<w>:STOP?	1351
SBUS<sb>:SPI:FRCondition	1328
SBUS<sb>:SPI:MISO:HYSTeresis	1330
SBUS<sb>:SPI:MISO:POLarity	1330
SBUS<sb>:SPI:MISO:POSition	1333
SBUS<sb>:SPI:MISO:SCALe	1333
SBUS<sb>:SPI:MISO:SOURce	1330
SBUS<sb>:SPI:MISO:THReshold	1330
SBUS<sb>:SPI:MOSI:HYSTeresis	1331
SBUS<sb>:SPI:MOSI:POLarity	1331
SBUS<sb>:SPI:MOSI:POSition	1334
SBUS<sb>:SPI:MOSI:SCALe	1334
SBUS<sb>:SPI:MOSI:SOURce	1331
SBUS<sb>:SPI:MOSI:THReshold	1332
SBUS<sb>:SPI:SCLK:HYSTeresis	1332
SBUS<sb>:SPI:SCLK:SOURce	1332
SBUS<sb>:SPI:SCLK:THReshold	1332
SBUS<sb>:SPI:SWTindex?	1346
SBUS<sb>:SPI:SWTTime?	1347
SBUS<sb>:SPI:TIMEout	1333
SBUS<sb>:SPI:WSIZE	1333
SBUS<sb>:SPMI:FCOunt?	1698
SBUS<sb>:SPMI:FILTer:BIT	1687
SBUS<sb>:SPMI:FILTer:CHKall	1687
SBUS<sb>:SPMI:FILTer:CLR	1687
SBUS<sb>:SPMI:FILTer:DMAX	1688
SBUS<sb>:SPMI:FILTer:DMIN	1688
SBUS<sb>:SPMI:FILTer:DOPerator	1689
SBUS<sb>:SPMI:FILTer:ERENable	1689
SBUS<sb>:SPMI:FILTer:ERRor<n>:ENABLE	1689
SBUS<sb>:SPMI:FILTer:FIENable	1691
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:ENABLE	1691
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:BIT	1687
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:DMAX	1688
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:DMIN	1688
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:DOPerator	1689
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:ENABLE	1691
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:IMAX	1690
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:IMIN	1690
SBUS<sb>:SPMI:FILTer:FRAMe<fr>:FLD<fl>:IOPerator	1689
SBUS<sb>:SPMI:FILTer:FRENable	1691
SBUS<sb>:SPMI:FILTer:IMAX	1690
SBUS<sb>:SPMI:FILTer:IMIN	1690
SBUS<sb>:SPMI:FILTer:INVert	1687
SBUS<sb>:SPMI:FILTer:IOPerator	1689
SBUS<sb>:SPMI:FILTer:RST	1687
SBUS<sb>:SPMI:FRAMe<fr>:ADDRess?	1698
SBUS<sb>:SPMI:FRAMe<fr>:BC?	1698
SBUS<sb>:SPMI:FRAMe<fr>:DATA?	1698
SBUS<sb>:SPMI:FRAMe<fr>:FLD<fl>:FVALue?	1699

SBUS<sb>:SPMI:FRAMe<fr>:FLD<fl>:LABeL?	1699
SBUS<sb>:SPMI:FRAMe<fr>:FLD<fl>:STATe?	1700
SBUS<sb>:SPMI:FRAMe<fr>:FLD<fl>:VALue?	1700
SBUS<sb>:SPMI:FRAMe<fr>:FLDCount?	1699
SBUS<sb>:SPMI:FRAMe<fr>:RBRate?	1700
SBUS<sb>:SPMI:FRAMe<fr>:SA?	1701
SBUS<sb>:SPMI:FRAMe<fr>:START?	1701
SBUS<sb>:SPMI:FRAMe<fr>:STATus?	1701
SBUS<sb>:SPMI:FRAMe<fr>:STOP?	1702
SBUS<sb>:SPMI:FRAMe<fr>:SYMBol?	1703
SBUS<sb>:SPMI:FRAMe<fr>:TYPE?	1702
SBUS<sb>:SPMI:FRAMe<fr>:WBRate?	1703
SBUS<sb>:SPMI:GIDValue	1682
SBUS<sb>:SPMI:GSIDenable	1682
SBUS<sb>:SPMI:GTCHenable	1683
SBUS<sb>:SPMI:GTWDith	1683
SBUS<sb>:SPMI:NEWLst	1686
SBUS<sb>:SPMI:POSition	1685
SBUS<sb>:SPMI:SCALe	1685
SBUS<sb>:SPMI:SCLK:HYSTeresis	1683
SBUS<sb>:SPMI:SCLK:SOURce	1683
SBUS<sb>:SPMI:SCLK:THReshold	1684
SBUS<sb>:SPMI:SDATa:HYSTeresis	1684
SBUS<sb>:SPMI:SDATa:SOURce	1684
SBUS<sb>:SPMI:SDATa:THReshold	1685
SBUS<sb>:SPMI:SWTIndex?	1697
SBUS<sb>:SPMI:SWTTime?	1697
SBUS<sb>:SPMI:SYMBols	1685
SBUS<sb>:SWIRe:DATA:HYSTeresis	1664
SBUS<sb>:SWIRe:DATA:SOURce	1663
SBUS<sb>:SWIRe:DATA:THReshold	1664
SBUS<sb>:SWIRe:FCOut?	1675
SBUS<sb>:SWIRe:FILTer:BIT	1667
SBUS<sb>:SWIRe:FILTer:CHKall	1667
SBUS<sb>:SWIRe:FILTer:CLR	1667
SBUS<sb>:SWIRe:FILTer:DMAX	1668
SBUS<sb>:SWIRe:FILTer:DMIN	1669
SBUS<sb>:SWIRe:FILTer:DOPerator	1669
SBUS<sb>:SWIRe:FILTer:ERENable	1668
SBUS<sb>:SWIRe:FILTer:ERRor<n>:ENABLE	1668
SBUS<sb>:SWIRe:FILTer:FIENable	1669
SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:ENABLE	1670
SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:BIT	1667
SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:DMAX	1668
SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:DMIN	1669
SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:DOPerator	1669
SBUS<sb>:SWIRe:FILTer:FRAMe<fr>:FLD<fl>:ENABLE	1669
SBUS<sb>:SWIRe:FILTer:FRENable	1670
SBUS<sb>:SWIRe:FILTer:INVert	1667
SBUS<sb>:SWIRe:FILTer:RST	1667

SBUS<sb>:SWIRe:FRAMe<fr>:BITRate?	1675
SBUS<sb>:SWIRe:FRAMe<fr>:CODParity?	1676
SBUS<sb>:SWIRe:FRAMe<fr>:DATA?	1676
SBUS<sb>:SWIRe:FRAMe<fr>:DATParity?	1677
SBUS<sb>:SWIRe:FRAMe<fr>:ESCParity?	1677
SBUS<sb>:SWIRe:FRAMe<fr>:FLD<fl>:FVALue?	1679
SBUS<sb>:SWIRe:FRAMe<fr>:FLD<fl>:STATus?	1678
SBUS<sb>:SWIRe:FRAMe<fr>:FLD<fl>:TYPE?	1678
SBUS<sb>:SWIRe:FRAMe<fr>:FLD<fl>:VALue?	1679
SBUS<sb>:SWIRe:FRAMe<fr>:START?	1680
SBUS<sb>:SWIRe:FRAMe<fr>:STATe?	1679
SBUS<sb>:SWIRe:FRAMe<fr>:STOP?	1680
SBUS<sb>:SWIRe:FRAMe<fr>:TYPE?	1681
SBUS<sb>:SWIRe:MGAP	1665
SBUS<sb>:SWIRe:MINGap	1665
SBUS<sb>:SWIRe:POSition	1665
SBUS<sb>:SWIRe:SCALE	1666
SBUS<sb>:SWIRe:STRBe:HYSTeresis	1665
SBUS<sb>:SWIRe:STRBe:SOURce	1664
SBUS<sb>:SWIRe:STRBe:THReshold	1665
SBUS<sb>:SWIRe:SWTIndex?	1674
SBUS<sb>:SWIRe:SWTTime?	1674
SBUS<sb>:TBTO:FCOunt?	1784
SBUS<sb>:TBTO:FILTer:BIT	1774
SBUS<sb>:TBTO:FILTer:CHKall	1773
SBUS<sb>:TBTO:FILTer:CLR	1773
SBUS<sb>:TBTO:FILTer:DMAX	1775
SBUS<sb>:TBTO:FILTer:DMIN	1775
SBUS<sb>:TBTO:FILTer:DOPerator	1775
SBUS<sb>:TBTO:FILTer:ERENable	1776
SBUS<sb>:TBTO:FILTer:ERRor<n>:ENABLE	1776
SBUS<sb>:TBTO:FILTer:FIENable	1776
SBUS<sb>:TBTO:FILTer:FRAMe<fr>:ENABLE	1776
SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:BIT	1774
SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:DMAX	1775
SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:DMIN	1775
SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:DOPerator	1775
SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:ENABLE	1776
SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:IMAX	1777
SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:IMIN	1777
SBUS<sb>:TBTO:FILTer:FRAMe<fr>:FLD<fl>:IOPerator	1778
SBUS<sb>:TBTO:FILTer:FRENable	1776
SBUS<sb>:TBTO:FILTer:IMAX	1777
SBUS<sb>:TBTO:FILTer:IMIN	1777
SBUS<sb>:TBTO:FILTer:INVert	1774
SBUS<sb>:TBTO:FILTer:IOPerator	1778
SBUS<sb>:TBTO:FILTer:RST	1774
SBUS<sb>:TBTO:FRAMe<fr>:BITRate?	1785
SBUS<sb>:TBTO:FRAMe<fr>:CRC?	1787
SBUS<sb>:TBTO:FRAMe<fr>:DATA?	1787

SBUS<sb>:TBTO:FRAME<fr>:DTADdress?	1787
SBUS<sb>:TBTO:FRAME<fr>:DTSYmbol?	1788
SBUS<sb>:TBTO:FRAME<fr>:FCRC?	1788
SBUS<sb>:TBTO:FRAME<fr>:FDATa?	1788
SBUS<sb>:TBTO:FRAME<fr>:FDAddress?	1788
SBUS<sb>:TBTO:FRAME<fr>:FLD<fl>:FVALue?	1785
SBUS<sb>:TBTO:FRAME<fr>:FLD<fl>:LABel?	1785
SBUS<sb>:TBTO:FRAME<fr>:FLD<fl>:STATe?	1786
SBUS<sb>:TBTO:FRAME<fr>:FLD<fl>:VALue?	1786
SBUS<sb>:TBTO:FRAME<fr>:FLDCount?	1784
SBUS<sb>:TBTO:FRAME<fr>:FSRaddress?	1789
SBUS<sb>:TBTO:FRAME<fr>:FTPLentH?	1789
SBUS<sb>:TBTO:FRAME<fr>:SRADdress?	1789
SBUS<sb>:TBTO:FRAME<fr>:SRSYmbol?	1789
SBUS<sb>:TBTO:FRAME<fr>:START?	1790
SBUS<sb>:TBTO:FRAME<fr>:STATus?	1790
SBUS<sb>:TBTO:FRAME<fr>:STOP?	1791
SBUS<sb>:TBTO:FRAME<fr>:TPLentH?	1791
SBUS<sb>:TBTO:FRAME<fr>:TYPE?	1791
SBUS<sb>:TBTO:MODE	1770
SBUS<sb>:TBTO:NEWList	1771
SBUS<sb>:TBTO:POLarity	1771
SBUS<sb>:TBTO:POSition	1771
SBUS<sb>:TBTO:SCALe	1771
SBUS<sb>:TBTO:SRCMinus	1772
SBUS<sb>:TBTO:SRCPlus	1772
SBUS<sb>:TBTO:SWTIndex?	1783
SBUS<sb>:TBTO:SWTTime?	1783
SBUS<sb>:TBTO:SYMBols	1772
SBUS<sb>:THReshold	1325
SBUS<sb>:TNOS:FCOunt?	1741
SBUS<sb>:TNOS:FILTer:BIT	1730
SBUS<sb>:TNOS:FILTer:CHKall	1729
SBUS<sb>:TNOS:FILTer:CLR	1730
SBUS<sb>:TNOS:FILTer:DMAX	1731
SBUS<sb>:TNOS:FILTer:DMIN	1731
SBUS<sb>:TNOS:FILTer:DOPerator	1732
SBUS<sb>:TNOS:FILTer:ERENable	1732
SBUS<sb>:TNOS:FILTer:ERRor<n>:ENABLE	1732
SBUS<sb>:TNOS:FILTer:FIENable	1732
SBUS<sb>:TNOS:FILTer:FRAME<fr>:ENABLE	1734
SBUS<sb>:TNOS:FILTer:FRAME<fr>:FLD<fl>:BIT	1730
SBUS<sb>:TNOS:FILTer:FRAME<fr>:FLD<fl>:DMAX	1731
SBUS<sb>:TNOS:FILTer:FRAME<fr>:FLD<fl>:DMIN	1731
SBUS<sb>:TNOS:FILTer:FRAME<fr>:FLD<fl>:DOPerator	1732
SBUS<sb>:TNOS:FILTer:FRAME<fr>:FLD<fl>:ENABLE	1732
SBUS<sb>:TNOS:FILTer:FRAME<fr>:FLD<fl>:IMAX	1733
SBUS<sb>:TNOS:FILTer:FRAME<fr>:FLD<fl>:IMIN	1733
SBUS<sb>:TNOS:FILTer:FRAME<fr>:FLD<fl>:IOPerator	1734
SBUS<sb>:TNOS:FILTer:FRENable	1734

SBUS<sb>:TNOS:FILTer:IMAX.....	1733
SBUS<sb>:TNOS:FILTer:IMIN.....	1733
SBUS<sb>:TNOS:FILTer:INVert.....	1730
SBUS<sb>:TNOS:FILTer:IOPerator.....	1734
SBUS<sb>:TNOS:FILTer:RST.....	1730
SBUS<sb>:TNOS:FRAMe<fr>:BITRate?.....	1741
SBUS<sb>:TNOS:FRAMe<fr>:CRC?.....	1743
SBUS<sb>:TNOS:FRAMe<fr>:DATA?.....	1744
SBUS<sb>:TNOS:FRAMe<fr>:DTADdress?.....	1744
SBUS<sb>:TNOS:FRAMe<fr>:DTSYmbol?.....	1744
SBUS<sb>:TNOS:FRAMe<fr>:FCRC?.....	1744
SBUS<sb>:TNOS:FRAMe<fr>:FDATa?.....	1745
SBUS<sb>:TNOS:FRAMe<fr>:FDTAddress?.....	1745
SBUS<sb>:TNOS:FRAMe<fr>:FLD<fl>:FVALue?.....	1742
SBUS<sb>:TNOS:FRAMe<fr>:FLD<fl>:LABel?.....	1742
SBUS<sb>:TNOS:FRAMe<fr>:FLD<fl>:STATe?.....	1742
SBUS<sb>:TNOS:FRAMe<fr>:FLD<fl>:VALue?.....	1743
SBUS<sb>:TNOS:FRAMe<fr>:FLDCount?.....	1741
SBUS<sb>:TNOS:FRAMe<fr>:FSRAddress?.....	1745
SBUS<sb>:TNOS:FRAMe<fr>:FTPLenth?.....	1745
SBUS<sb>:TNOS:FRAMe<fr>:SRADdress?.....	1746
SBUS<sb>:TNOS:FRAMe<fr>:SRSYmbol?.....	1746
SBUS<sb>:TNOS:FRAMe<fr>:START?.....	1746
SBUS<sb>:TNOS:FRAMe<fr>:STATus?.....	1747
SBUS<sb>:TNOS:FRAMe<fr>:STOP?.....	1747
SBUS<sb>:TNOS:FRAMe<fr>:TPLenth?.....	1748
SBUS<sb>:TNOS:FRAMe<fr>:TYPE?.....	1748
SBUS<sb>:TNOS:NEWLlist.....	1728
SBUS<sb>:TNOS:POSition.....	1727
SBUS<sb>:TNOS:SCALE.....	1727
SBUS<sb>:TNOS:SOURce.....	1727
SBUS<sb>:TNOS:SWTindex?.....	1740
SBUS<sb>:TNOS:SWTTime?.....	1740
SBUS<sb>:TNOS:SYMBols.....	1727
SBUS<sb>:TNOS:THReshold:HYSTeresis.....	1728
SBUS<sb>:TNOS:THReshold:LOWer.....	1728
SBUS<sb>:TNOS:THReshold:UPPer.....	1728
SBUS<sb>:TYPE.....	1322
SBUS<sb>:UART:BITRate.....	1435
SBUS<sb>:UART:BORDER.....	1435
SBUS<sb>:UART:FILTer:BIT.....	1444
SBUS<sb>:UART:FILTer:CHKall.....	1441
SBUS<sb>:UART:FILTer:CLR.....	1441
SBUS<sb>:UART:FILTer:DMAX.....	1444
SBUS<sb>:UART:FILTer:DMIN.....	1443
SBUS<sb>:UART:FILTer:DOPerator.....	1443
SBUS<sb>:UART:FILTer:ERENable.....	1443
SBUS<sb>:UART:FILTer:ERRor<n>:ENABLE.....	1443
SBUS<sb>:UART:FILTer:FIENable.....	1445
SBUS<sb>:UART:FILTer:FRAMe<fr>:ENABLE.....	1445

SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1444
SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1444
SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1443
SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1443
SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1445
SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1442
SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1442
SBUS<sb>:UART:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1442
SBUS<sb>:UART:FILTer:FRENable.....	1445
SBUS<sb>:UART:FILTer:IMAX.....	1442
SBUS<sb>:UART:FILTer:IMIN.....	1442
SBUS<sb>:UART:FILTer:INVert.....	1441
SBUS<sb>:UART:FILTer:IOPerator.....	1442
SBUS<sb>:UART:FILTer:RST.....	1441
SBUS<sb>:UART:PACKets.....	1435
SBUS<sb>:UART:PARity.....	1436
SBUS<sb>:UART:POLarity.....	1436
SBUS<sb>:UART:RX:HYSTeresis.....	1436
SBUS<sb>:UART:RX:POSition.....	1439
SBUS<sb>:UART:RX:SCALE.....	1439
SBUS<sb>:UART:RX:SOURce.....	1437
SBUS<sb>:UART:RX:THReshold.....	1437
SBUS<sb>:UART:SBIT.....	1437
SBUS<sb>:UART:SSIZe.....	1437
SBUS<sb>:UART:SWTIndex?.....	1452
SBUS<sb>:UART:SWTTime?.....	1453
SBUS<sb>:UART:TOUT.....	1438
SBUS<sb>:UART:TX:HYSTeresis.....	1438
SBUS<sb>:UART:TX:POSition.....	1439
SBUS<sb>:UART:TX:SCALE.....	1440
SBUS<sb>:UART:TX:SOURce.....	1438
SBUS<sb>:UART:TX:THReshold.....	1439
SBUS<sb>:UART:WCOunt?.....	1453
SBUS<sb>:UART:WORD<w>:BITRate?.....	1453
SBUS<sb>:UART:WORD<w>:RXValue?.....	1454
SBUS<sb>:UART:WORD<w>:SOURce?.....	1454
SBUS<sb>:UART:WORD<w>:START?.....	1454
SBUS<sb>:UART:WORD<w>:STATe?.....	1455
SBUS<sb>:UART:WORD<w>:STOP?.....	1455
SBUS<sb>:UART:WORD<w>:TXValue?.....	1456
SBUS<sb>:USBHspeed:FCOunt?.....	1827
SBUS<sb>:USBHspeed:FILTer:BIT.....	1820
SBUS<sb>:USBHspeed:FILTer:CHKall.....	1816
SBUS<sb>:USBHspeed:FILTer:CLR.....	1817
SBUS<sb>:USBHspeed:FILTer:DMAX.....	1818
SBUS<sb>:USBHspeed:FILTer:DMIN.....	1818
SBUS<sb>:USBHspeed:FILTer:DOPerator.....	1818
SBUS<sb>:USBHspeed:FILTer:ERENable.....	1819
SBUS<sb>:USBHspeed:FILTer:ERRor<n>:ENABle.....	1819
SBUS<sb>:USBHspeed:FILTer:FIENable.....	1821

SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:ENABle.....	1817
SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1820
SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1818
SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1818
SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1818
SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1821
SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1819
SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1820
SBUS<sb>:USBHspeed:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1820
SBUS<sb>:USBHspeed:FILTer:FRENable.....	1817
SBUS<sb>:USBHspeed:FILTer:IMAX.....	1819
SBUS<sb>:USBHspeed:FILTer:IMIN.....	1820
SBUS<sb>:USBHspeed:FILTer:INVert.....	1817
SBUS<sb>:USBHspeed:FILTer:IOPerator.....	1820
SBUS<sb>:USBHspeed:FILTer:RST.....	1817
SBUS<sb>:USBHspeed:FRAMe<fr>:ADDReSS?.....	1828
SBUS<sb>:USBHspeed:FRAMe<fr>:BITRate?.....	1828
SBUS<sb>:USBHspeed:FRAMe<fr>:CRC?.....	1832
SBUS<sb>:USBHspeed:FRAMe<fr>:DATA?.....	1829
SBUS<sb>:USBHspeed:FRAMe<fr>:ENDPoint?.....	1833
SBUS<sb>:USBHspeed:FRAMe<fr>:FADDReSS?.....	1832
SBUS<sb>:USBHspeed:FRAMe<fr>:FCRC?.....	1833
SBUS<sb>:USBHspeed:FRAMe<fr>:FLD<fl>:FVALue?.....	1830
SBUS<sb>:USBHspeed:FRAMe<fr>:FLD<fl>:LABel?.....	1831
SBUS<sb>:USBHspeed:FRAMe<fr>:FLD<fl>:STATe?.....	1831
SBUS<sb>:USBHspeed:FRAMe<fr>:FLD<fl>:VALue?.....	1832
SBUS<sb>:USBHspeed:FRAMe<fr>:FLDCount?.....	1828
SBUS<sb>:USBHspeed:FRAMe<fr>:FRNumber?.....	1833
SBUS<sb>:USBHspeed:FRAMe<fr>:PID?.....	1834
SBUS<sb>:USBHspeed:FRAMe<fr>:PIDName?.....	1834
SBUS<sb>:USBHspeed:FRAMe<fr>:SPET?.....	1835
SBUS<sb>:USBHspeed:FRAMe<fr>:SPEU?.....	1835
SBUS<sb>:USBHspeed:FRAMe<fr>:SPPort?.....	1835
SBUS<sb>:USBHspeed:FRAMe<fr>:SPS?.....	1836
SBUS<sb>:USBHspeed:FRAMe<fr>:SPSC?.....	1836
SBUS<sb>:USBHspeed:FRAMe<fr>:START?.....	1829
SBUS<sb>:USBHspeed:FRAMe<fr>:STATus?.....	1829
SBUS<sb>:USBHspeed:FRAMe<fr>:STOP?.....	1830
SBUS<sb>:USBHspeed:FRAMe<fr>:TYPE?.....	1834
SBUS<sb>:USBHspeed:POSition.....	1815
SBUS<sb>:USBHspeed:SCALe.....	1815
SBUS<sb>:USBHspeed:SOURce.....	1814
SBUS<sb>:USBHspeed:SWTIndex?.....	1826
SBUS<sb>:USBHspeed:SWTTime?.....	1827
SBUS<sb>:USBHspeed:THReshold:HYSTeresis.....	1815
SBUS<sb>:USBHspeed:THReshold:LOWer.....	1815
SBUS<sb>:USBHspeed:THReshold:UPPer.....	1814
SBUS<sb>:USBone:DMINus:HYSTeresis.....	1794
SBUS<sb>:USBone:DMINus:SOURce.....	1793
SBUS<sb>:USBone:DMINus:THReshold.....	1794

SBUS<sb>:USBone:DPLus:HYSteresis.....	1794
SBUS<sb>:USBone:DPLus:SOURce.....	1793
SBUS<sb>:USBone:DPLus:THReshold.....	1793
SBUS<sb>:USBone:FCOunt?.....	1807
SBUS<sb>:USBone:FILTer:BIT.....	1800
SBUS<sb>:USBone:FILTer:CHKall.....	1796
SBUS<sb>:USBone:FILTer:CLR.....	1796
SBUS<sb>:USBone:FILTer:DMAX.....	1797
SBUS<sb>:USBone:FILTer:DMIN.....	1797
SBUS<sb>:USBone:FILTer:DOPerator.....	1798
SBUS<sb>:USBone:FILTer:ERENable.....	1798
SBUS<sb>:USBone:FILTer:ERRor<n>:ENABle.....	1798
SBUS<sb>:USBone:FILTer:FIENable.....	1800
SBUS<sb>:USBone:FILTer:FRAMe<fr>:ENABle.....	1797
SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:BIT.....	1800
SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:DMAX.....	1797
SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:DMIN.....	1797
SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:DOPerator.....	1798
SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:ENABle.....	1800
SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:IMAX.....	1798
SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:IMIN.....	1799
SBUS<sb>:USBone:FILTer:FRAMe<fr>:FLD<fl>:IOPerator.....	1799
SBUS<sb>:USBone:FILTer:FRENable.....	1797
SBUS<sb>:USBone:FILTer:IMAX.....	1798
SBUS<sb>:USBone:FILTer:IMIN.....	1799
SBUS<sb>:USBone:FILTer:INVert.....	1796
SBUS<sb>:USBone:FILTer:IOPerator.....	1799
SBUS<sb>:USBone:FILTer:RST.....	1796
SBUS<sb>:USBone:FRAMe<fr>:ADDResS?.....	1807
SBUS<sb>:USBone:FRAMe<fr>:BITRate?.....	1808
SBUS<sb>:USBone:FRAMe<fr>:CRC?.....	1811
SBUS<sb>:USBone:FRAMe<fr>:DATA?.....	1808
SBUS<sb>:USBone:FRAMe<fr>:ENDPoint?.....	1812
SBUS<sb>:USBone:FRAMe<fr>:FADDress?.....	1812
SBUS<sb>:USBone:FRAMe<fr>:FCRC?.....	1812
SBUS<sb>:USBone:FRAMe<fr>:FLD<fl>:FVALue?.....	1810
SBUS<sb>:USBone:FRAMe<fr>:FLD<fl>:LABel?.....	1810
SBUS<sb>:USBone:FRAMe<fr>:FLD<fl>:STATe?.....	1810
SBUS<sb>:USBone:FRAMe<fr>:FLD<fl>:VALue?.....	1811
SBUS<sb>:USBone:FRAMe<fr>:FLDCount?.....	1807
SBUS<sb>:USBone:FRAMe<fr>:FRNumber?.....	1812
SBUS<sb>:USBone:FRAMe<fr>:PID?.....	1813
SBUS<sb>:USBone:FRAMe<fr>:PIDName?.....	1813
SBUS<sb>:USBone:FRAMe<fr>:START?.....	1808
SBUS<sb>:USBone:FRAMe<fr>:STATus?.....	1809
SBUS<sb>:USBone:FRAMe<fr>:STOP?.....	1809
SBUS<sb>:USBone:FRAMe<fr>:TYPE?.....	1813
SBUS<sb>:USBone:MODE.....	1793
SBUS<sb>:USBone:POSition.....	1794
SBUS<sb>:USBone:SCALe.....	1795

SBUS<sb>:USBone:SWTIndex?	1806
SBUS<sb>:USBone:SWTTime?	1806
SBUS<sb>:ZCOupling	1325
SBUS<sb>[:STATe]	1322
SENSe[:ROSCillator]:OUTPut[:ENABle]	1005
SENSe[:ROSCillator]:SOURce	1005
SERVice:REPort	961
SESSion:LOAD[:EXECute]	1111
SESSion:SAVE:ABORT	1112
SESSion:SAVE:CHANnel	1112
SESSion:SAVE:REFerence	1112
SESSion:SAVE[:EXECute]	1112
SESSion:USERpref	1113
SINGLE	962
STATus:OPERation:CONDition?	1876
STATus:OPERation:ENABle	1877
STATus:OPERation:NTRansition	1877
STATus:OPERation:PTRansition	1878
STATus:OPERation[:EVENT]?	1877
STATus:PRESet	1876
STATus:QUESTionable:ADCState:CONDition?	1880
STATus:QUESTionable:ADCState:ENABle	1882
STATus:QUESTionable:ADCState:NTRansition	1882
STATus:QUESTionable:ADCState:PTRansition	1883
STATus:QUESTionable:ADCState[:EVENT]?	1881
STATus:QUESTionable:COVerload:CONDition?	1880
STATus:QUESTionable:COVerload:ENABle	1882
STATus:QUESTionable:COVerload:NTRansition	1882
STATus:QUESTionable:COVerload:PTRansition	1883
STATus:QUESTionable:COVerload[:EVENT]?	1881
STATus:QUESTionable:GOVerload:CONDition?	1880
STATus:QUESTionable:GOVerload:ENABle	1882
STATus:QUESTionable:GOVerload:NTRansition	1882
STATus:QUESTionable:GOVerload:PTRansition	1883
STATus:QUESTionable:GOVerload[:EVENT]?	1881
STATus:QUESTionable:IMPRecise:CONDition?	1880
STATus:QUESTionable:IMPRecise:ENABle	1882
STATus:QUESTionable:IMPRecise:NTRansition	1882
STATus:QUESTionable:IMPRecise:PTRansition	1883
STATus:QUESTionable:IMPRecise[:EVENT]?	1881
STATus:QUESTionable:LIMit:CONDition?	1880
STATus:QUESTionable:LIMit:ENABle	1882
STATus:QUESTionable:LIMit:NTRansition	1882
STATus:QUESTionable:LIMit:PTRansition	1883
STATus:QUESTionable:LIMit[:EVENT]?	1881
STATus:QUESTionable:MASK:CONDition?	1880
STATus:QUESTionable:MASK[:EVENT]?	1881
STATus:QUESTionable:PLL:CONDition?	1880
STATus:QUESTionable:PLL:ENABle	1882
STATus:QUESTionable:PLL:NTRansition	1882

STATus:QUESTionable:PLL:PTRansition.....	1883
STATus:QUESTionable:PLL:RCONdition.....	1883
STATus:QUESTionable:PLL[:EVENT]?.....	1881
STATus:QUESTionable:PPSupply:CONDection?.....	1880
STATus:QUESTionable:PPSupply:ENABle.....	1882
STATus:QUESTionable:PPSupply:NTRansition.....	1882
STATus:QUESTionable:PPSupply:PTRansition.....	1883
STATus:QUESTionable:PPSupply[:EVENT]?.....	1881
STATus:QUESTionable:TEMPerature:CONDection?.....	1880
STATus:QUESTionable:TEMPerature:ENABle.....	1882
STATus:QUESTionable:TEMPerature:NTRansition.....	1882
STATus:QUESTionable:TEMPerature:PTRansition.....	1883
STATus:QUESTionable:TEMPerature[:EVENT]?.....	1881
STOP.....	962
SYNChronize:DEVIce<m>:CHANnels.....	1872
SYNChronize:DEVIce<m>:COMMunicate:NET[:HOSTname].....	1872
SYNChronize:DEVIce<m>:CONNection.....	1873
SYNChronize:DEVIce<m>:DISPlay.....	1873
SYNChronize:DEVIce<m>:LOCKcontrols.....	1873
SYNChronize:DEVIce<m>:NAME.....	1873
SYNChronize:DEVIce<m>:SKEW:AUTO.....	1874
SYNChronize:DEVIce<m>:SKEW[:VALue].....	1874
SYNChronize:DEVIce<m>:TIMebasesync.....	1874
SYNChronize:DEVIce<m>[:ENABle].....	1875
SYNChronize:DISConnect.....	1875
SYNChronize:LOAD:ABORT.....	1875
SYNChronize:LOAD[:WAVEform].....	1875
SYSTem:APUP.....	961
SYSTem:COMMunicate:NET[:HOSTname].....	924
SYSTem:DATE.....	924
SYSTem:DISPlay:MESSAge:STATe.....	923
SYSTem:DISPlay:MESSAge[:TEXT].....	923
SYSTem:DISPlay:UPDate.....	922
SYSTem:EXIT.....	924
SYSTem:FW:FILEpath.....	924
SYSTem:FW:START.....	925
SYSTem:PRESet.....	925
SYSTem:SHUTdown.....	925
SYSTem:TIME.....	925
TIMebase:DIVisions?.....	964
TIMebase:HORIZontal:POSition.....	964
TIMebase:RANGe.....	963
TIMebase:REFerence.....	964
TIMebase:ROLL:ENABle.....	964
TIMebase:ROLL:MTIME.....	965
TIMebase:ROLL:STATe?.....	966
TIMebase:SCALE.....	963
TREFerence<m>:CDR:SOFTware:ALGorithm.....	1056
TREFerence<m>:CDR:SOFTware:BWIDth.....	1057
TREFerence<m>:CDR:SOFTware:CFRequency:CRSYnc.....	1057

TREference<m>:CDR:SOFTware:PLL:DAMPing.....	1057
TREference<m>:CDR:SOFTware:PLL:ORDER.....	1058
TREference<m>:CDR:SOFTware:PLL:SYNC.....	1058
TREference<m>:CDR:SOFTware:RELWidth.....	1058
TREference<m>:CDR:SOFTware:SELResults.....	1059
TREference<m>:CDR:SOFTware:SREStimate.....	1058
TREference<m>:CLK:FACTor.....	1059
TREference<m>:CLK:FREQuency.....	1059
TREference<m>:CLK:OFFSet.....	1060
TREference<m>:CLK:REFLevel.....	1060
TREference<m>:EDGE.....	1060
TREference<m>:ENABle.....	1061
TREference<m>:GATE.....	1061
TREference<m>:REFLevel.....	1062
TREference<m>:RFLSet.....	1062
TREference<m>:SOURce.....	1062
TREference<m>:STATe?.....	1062
TREference<m>:SYMRate.....	1063
TREference<m>:TYPE.....	1063
TRFS:COUNT?.....	1063
TRIGger:ACTions:BEEP.....	1038
TRIGger:ACTions:OUT:DELay.....	1039
TRIGger:ACTions:OUT:OVERload:STATus:CONDition?.....	1880
TRIGger:ACTions:OUT:OVERload:STATus:ENABle.....	1881
TRIGger:ACTions:OUT:OVERload:STATus:NTRansition.....	1882
TRIGger:ACTions:OUT:OVERload:STATus:PTRansition.....	1882
TRIGger:ACTions:OUT:OVERload:STATus:PTRansition.....	1883
TRIGger:ACTions:OUT:OVERload:STATus[:EVENT].....	1881
TRIGger:ACTions:OUT:PLENgtH.....	1039
TRIGger:ACTions:OUT:POLarity.....	1040
TRIGger:ACTions:OUT:SOURce.....	1039
TRIGger:ACTions:OUT:STATe.....	1039
TRIGger:ACTions:SCReenshot.....	1040
TRIGger:ACTions:STOP.....	1040
TRIGger:ACTions:WFMSave.....	1040
TRIGger:ANEDge:COUPling.....	1011
TRIGger:ANEDge:CUToff:HIGHPass.....	1012
TRIGger:ANEDge:CUToff:LOWPass.....	1012
TRIGger:ANEDge:FILTer.....	1012
TRIGger:ANEDge:LEVel.....	1011
TRIGger:ANEDge:NREJect.....	1012
TRIGger:ANEDge:OVERload:STATus:CONDition?.....	1880
TRIGger:ANEDge:OVERload:STATus:ENABle.....	1881
TRIGger:ANEDge:OVERload:STATus:NTRansition.....	1882
TRIGger:ANEDge:OVERload:STATus:PTRansition.....	1883
TRIGger:ANEDge:OVERload:STATus[:EVENT].....	1881
TRIGger:EVENT<ev>:EDGE:SLOPe.....	1011
TRIGger:EVENT<ev>:GLITCh:POLarity.....	1013
TRIGger:EVENT<ev>:GLITCh:RANGe.....	1013
TRIGger:EVENT<ev>:GLITCh:WIDTh.....	1013

TRIGger:EVENT<ev>:INTERval:DELTA.....	1022
TRIGger:EVENT<ev>:INTERval:RANGE.....	1022
TRIGger:EVENT<ev>:INTERval:SLOPe.....	1023
TRIGger:EVENT<ev>:INTERval:WIDTh.....	1023
TRIGger:EVENT<ev>:LEVel<n>:RUNT:LOWer.....	1015
TRIGger:EVENT<ev>:LEVel<n>:RUNT:UPPer.....	1016
TRIGger:EVENT<ev>:LEVel<n>:SLEW:LOWer.....	1023
TRIGger:EVENT<ev>:LEVel<n>:SLEW:UPPer.....	1024
TRIGger:EVENT<ev>:LEVel<n>:WINDow:LOWer.....	1018
TRIGger:EVENT<ev>:LEVel<n>:WINDow:UPPer.....	1018
TRIGger:EVENT<ev>:LEVel<n>[:VALue].....	1007
TRIGger:EVENT<ev>:PATtern:QUALify:ANALog:CHAN<n>:HLX.....	1030
TRIGger:EVENT<ev>:PATtern:QUALify:DIGital:CHAN<n>:HLX.....	1030
TRIGger:EVENT<ev>:PATtern:QUALify:DIGital:LOGic.....	1031
TRIGger:EVENT<ev>:PATtern:QUALify:LOGic.....	1030
TRIGger:EVENT<ev>:PATtern:QUALify:SOURces.....	1031
TRIGger:EVENT<ev>:RUNT:DELTA.....	1016
TRIGger:EVENT<ev>:RUNT:POLarity.....	1016
TRIGger:EVENT<ev>:RUNT:RANGE.....	1017
TRIGger:EVENT<ev>:RUNT:WIDTh.....	1017
TRIGger:EVENT<ev>:SETHold:CSORce:EDGE.....	1026
TRIGger:EVENT<ev>:SETHold:CSORce:LEVel.....	1026
TRIGger:EVENT<ev>:SETHold:CSORce[:VALue].....	1027
TRIGger:EVENT<ev>:SETHold:HTIME.....	1027
TRIGger:EVENT<ev>:SETHold:STIME.....	1027
TRIGger:EVENT<ev>:SLEW:DELTA.....	1024
TRIGger:EVENT<ev>:SLEW:RANGE.....	1024
TRIGger:EVENT<ev>:SLEW:RATE.....	1025
TRIGger:EVENT<ev>:SLEW:SLOPe.....	1025
TRIGger:EVENT<ev>:SOURce.....	1008
TRIGger:EVENT<ev>:STATe:QUALify:ANALog:CHAN<n>:HLX.....	1028
TRIGger:EVENT<ev>:STATe:QUALify:DIGital:CHAN<n>:HLX.....	1029
TRIGger:EVENT<ev>:STATe:QUALify:DIGital:LOGic.....	1029
TRIGger:EVENT<ev>:STATe:QUALify:LOGic.....	1028
TRIGger:EVENT<ev>:STATe:SLOPe.....	1028
TRIGger:EVENT<ev>:TIMEout:RANGE.....	1021
TRIGger:EVENT<ev>:TIMEout:TIME.....	1021
TRIGger:EVENT<ev>:TYPE.....	1007
TRIGger:EVENT<ev>:WIDTh:DELTA.....	1014
TRIGger:EVENT<ev>:WIDTh:POLarity.....	1014
TRIGger:EVENT<ev>:WIDTh:RANGE.....	1014
TRIGger:EVENT<ev>:WIDTh:WIDTh.....	1015
TRIGger:EVENT<ev>:WINDow:DELTA.....	1019
TRIGger:EVENT<ev>:WINDow:RANGE.....	1019
TRIGger:EVENT<ev>:WINDow:TIME.....	1020
TRIGger:EVENT<ev>:WINDow:WIDTh.....	1020
TRIGger:FILTermode.....	1037
TRIGger:FINDlevel.....	1007
TRIGger:FORCE.....	1032
TRIGger:HOLDoff:AUTotime?.....	1033

TRIGger:HOLDoff:EVENTs.....	1034
TRIGger:HOLDoff:MAX.....	1034
TRIGger:HOLDoff:MIN.....	1034
TRIGger:HOLDoff:MODE.....	1032
TRIGger:HOLDoff:SCALing.....	1033
TRIGger:HOLDoff:TIME.....	1034
TRIGger:LFReject.....	1038
TRIGger:MEVents:AEVents.....	1008
TRIGger:MEVents:MODE.....	1006
TRIGger:MEVents:SEquence<se>:COUNT.....	1009
TRIGger:MEVents:SEquence<se>:DELay.....	1009
TRIGger:MEVents:SEquence<se>:RESet:EVENT.....	1009
TRIGger:MEVents:SEquence<se>:RESet:TIMEout:TIME.....	1010
TRIGger:MEVents:SEquence<se>:RESet:TIMEout[:ENABLE].....	1010
TRIGger:MODE.....	1031
TRIGger:NOISe<m>:ABSolute.....	1035
TRIGger:NOISe<m>:EFFective?.....	1035
TRIGger:NOISe<m>:MODE.....	1036
TRIGger:NOISe<m>:PERDivision.....	1036
TRIGger:NOISe<m>:RELative.....	1036
TRIGger:NOISe<m>[:STATe].....	1037
TRIGger:RFReject.....	1038
TRIGger:SBHW:CAN:ACKError.....	1550
TRIGger:SBHW:CAN:BITSterror.....	1550
TRIGger:SBHW:CAN:BORDER.....	1551
TRIGger:SBHW:CAN:CRCErrors.....	1551
TRIGger:SBHW:CAN:DCONDition.....	1551
TRIGger:SBHW:CAN:DLC.....	1552
TRIGger:SBHW:CAN:DLCCondition.....	1552
TRIGger:SBHW:CAN:DMIN.....	1552
TRIGger:SBHW:CAN:FDATa:BRS.....	1552
TRIGger:SBHW:CAN:FDATa:DPOSition.....	1553
TRIGger:SBHW:CAN:FDATa:ESI.....	1553
TRIGger:SBHW:CAN:FDATa:SCERror.....	1553
TRIGger:SBHW:CAN:FORMError.....	1553
TRIGger:SBHW:CAN:FTYPE.....	1554
TRIGger:SBHW:CAN:ICONDition.....	1554
TRIGger:SBHW:CAN:IMAX.....	1554
TRIGger:SBHW:CAN:IMIN.....	1555
TRIGger:SBHW:CAN:ITYPe.....	1555
TRIGger:SBHW:CAN:TYPE.....	1555
TRIGger:SBHW:CAN:XDATa:AF:CONDition.....	1556
TRIGger:SBHW:CAN:XDATa:AF:MAX.....	1557
TRIGger:SBHW:CAN:XDATa:AF:MIN.....	1557
TRIGger:SBHW:CAN:XDATa:SDT:CONDition.....	1557
TRIGger:SBHW:CAN:XDATa:SDT:MAX.....	1557
TRIGger:SBHW:CAN:XDATa:SDT:MIN.....	1558
TRIGger:SBHW:CAN:XDATa:SEC.....	1558
TRIGger:SBHW:CAN:XDATa:VCID:CONDition.....	1558
TRIGger:SBHW:CAN:XDATa:VCID:MAX.....	1559

TRIGger:SBHW:CAN:XData:VCID:MIN.....	1559
TRIGger:SBHW:I2C:ACcEss.....	1393
TRIGger:SBHW:I2C:ACONdition.....	1394
TRIGger:SBHW:I2C:ADDReSS.....	1394
TRIGger:SBHW:I2C:ADDTo.....	1394
TRIGger:SBHW:I2C:ADNaCK.....	1394
TRIGger:SBHW:I2C:AMODe.....	1395
TRIGger:SBHW:I2C:DCONdition.....	1395
TRIGger:SBHW:I2C:DMIN.....	1395
TRIGger:SBHW:I2C:DPOStion.....	1395
TRIGger:SBHW:I2C:DRNaCK.....	1396
TRIGger:SBHW:I2C:DWNaCK.....	1396
TRIGger:SBHW:I2C:TYPE.....	1393
TRIGger:SBHW:LIN:CHKSeRror.....	1589
TRIGger:SBHW:LIN:DCONdition.....	1589
TRIGger:SBHW:LIN:DMIN.....	1588
TRIGger:SBHW:LIN:DPOStion.....	1588
TRIGger:SBHW:LIN:ICONdition.....	1588
TRIGger:SBHW:LIN:IMAX.....	1588
TRIGger:SBHW:LIN:IMIN.....	1587
TRIGger:SBHW:LIN:IPERror.....	1587
TRIGger:SBHW:LIN:SYERror.....	1587
TRIGger:SBHW:LIN:TYPE.....	1586
TRIGger:SBHW:SPI:DMINpatterN.....	1341
TRIGger:SBHW:SPI:DPOStion.....	1341
TRIGger:SBHW:SPI:FCONdition.....	1341
TRIGger:SBHW:SPI:PALignment.....	1340
TRIGger:SBHW:SPI:TYPE.....	1340
TRIGger:SBHW:UART:DATA.....	1446
TRIGger:SBHW:UART:DPOStion.....	1446
TRIGger:SBHW:UART:FCONdition.....	1446
TRIGger:SBHW:UART:OPERator.....	1446
TRIGger:SBHW:UART:SOURce.....	1446
TRIGger:SBHW:UART:TYPE.....	1447
TRIGger:SBSW:ARINc:BIT.....	1638
TRIGger:SBSW:ARINc:CHKall.....	1637
TRIGger:SBSW:ARINc:CLR.....	1637
TRIGger:SBSW:ARINc:DMAx.....	1639
TRIGger:SBSW:ARINc:DMIN.....	1639
TRIGger:SBSW:ARINc:DOPERator.....	1639
TRIGger:SBSW:ARINc:ERENable.....	1640
TRIGger:SBSW:ARINc:ERRor<m>:ENABle.....	1640
TRIGger:SBSW:ARINc:FIENable.....	1640
TRIGger:SBSW:ARINc:FRAMe<fr>:ENABle.....	1638
TRIGger:SBSW:ARINc:FRAMe<fr>:FLD<fl>:BIT.....	1638
TRIGger:SBSW:ARINc:FRAMe<fr>:FLD<fl>:DMAx.....	1639
TRIGger:SBSW:ARINc:FRAMe<fr>:FLD<fl>:DMIN.....	1639
TRIGger:SBSW:ARINc:FRAMe<fr>:FLD<fl>:DOPERator.....	1639
TRIGger:SBSW:ARINc:FRAMe<fr>:FLD<fl>:ENABle.....	1640
TRIGger:SBSW:ARINc:FRENable.....	1638

TRIGger:SBSW:ARINc:INVert.....	1637
TRIGger:SBSW:ARINc:RST.....	1638
TRIGger:SBSW:CAN:BIT.....	1561
TRIGger:SBSW:CAN:CHKall.....	1560
TRIGger:SBSW:CAN:CLR.....	1560
TRIGger:SBSW:CAN:DMAX.....	1561
TRIGger:SBSW:CAN:DMIN.....	1562
TRIGger:SBSW:CAN:DOPerator.....	1562
TRIGger:SBSW:CAN:ERENable.....	1564
TRIGger:SBSW:CAN:ERRor<m>:ENABle.....	1564
TRIGger:SBSW:CAN:FIENable.....	1562
TRIGger:SBSW:CAN:FRAMe<fr>:ENABle.....	1561
TRIGger:SBSW:CAN:FRAMe<fr>:FLD<fl>:BIT.....	1561
TRIGger:SBSW:CAN:FRAMe<fr>:FLD<fl>:DMAX.....	1561
TRIGger:SBSW:CAN:FRAMe<fr>:FLD<fl>:DMIN.....	1562
TRIGger:SBSW:CAN:FRAMe<fr>:FLD<fl>:DOPerator.....	1562
TRIGger:SBSW:CAN:FRAMe<fr>:FLD<fl>:ENABle.....	1562
TRIGger:SBSW:CAN:FRAMe<fr>:FLD<fl>:IMAX.....	1563
TRIGger:SBSW:CAN:FRAMe<fr>:FLD<fl>:IMIN.....	1563
TRIGger:SBSW:CAN:FRAMe<fr>:FLD<fl>:IOPerator.....	1564
TRIGger:SBSW:CAN:FRENable.....	1561
TRIGger:SBSW:CAN:IMAX.....	1563
TRIGger:SBSW:CAN:IMIN.....	1563
TRIGger:SBSW:CAN:INVert.....	1560
TRIGger:SBSW:CAN:IOPerator.....	1564
TRIGger:SBSW:CAN:RST.....	1560
TRIGger:SBSW:HBTO:BIT.....	1758
TRIGger:SBSW:HBTO:CHKall.....	1757
TRIGger:SBSW:HBTO:CLR.....	1757
TRIGger:SBSW:HBTO:DMAX.....	1758
TRIGger:SBSW:HBTO:DMIN.....	1758
TRIGger:SBSW:HBTO:DOPerator.....	1759
TRIGger:SBSW:HBTO:ERENable.....	1761
TRIGger:SBSW:HBTO:ERRor<m>:ENABle.....	1761
TRIGger:SBSW:HBTO:FIENable.....	1759
TRIGger:SBSW:HBTO:FRAMe<fr>:ENABle.....	1757
TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:BIT.....	1758
TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:DMAX.....	1758
TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:DMIN.....	1758
TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:DOPerator.....	1759
TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:ENABle.....	1759
TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:IMAX.....	1760
TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:IMIN.....	1760
TRIGger:SBSW:HBTO:FRAMe<fr>:FLD<fl>:IOPerator.....	1760
TRIGger:SBSW:HBTO:FRENable.....	1757
TRIGger:SBSW:HBTO:IMAX.....	1760
TRIGger:SBSW:HBTO:IMIN.....	1760
TRIGger:SBSW:HBTO:INVert.....	1757
TRIGger:SBSW:HBTO:IOPerator.....	1760
TRIGger:SBSW:HBTO:RST.....	1757

TRIGger:SBSW:I2C:BIT.....	1398
TRIGger:SBSW:I2C:CHKall.....	1397
TRIGger:SBSW:I2C:CLR.....	1397
TRIGger:SBSW:I2C:DMAX.....	1398
TRIGger:SBSW:I2C:DMIN.....	1399
TRIGger:SBSW:I2C:DOPerator.....	1399
TRIGger:SBSW:I2C:ERENable.....	1401
TRIGger:SBSW:I2C:ERRor<m>:ENABLE.....	1401
TRIGger:SBSW:I2C:FIENable.....	1399
TRIGger:SBSW:I2C:FRAMe<fr>:ENABLE.....	1398
TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:BIT.....	1398
TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:DMAX.....	1398
TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:DMIN.....	1399
TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:DOPerator.....	1399
TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:ENABLE.....	1399
TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:IMAX.....	1400
TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:IMIN.....	1400
TRIGger:SBSW:I2C:FRAMe<fr>:FLD<fl>:IOPerator.....	1401
TRIGger:SBSW:I2C:FRENable.....	1398
TRIGger:SBSW:I2C:IMAX.....	1400
TRIGger:SBSW:I2C:IMIN.....	1400
TRIGger:SBSW:I2C:INVert.....	1397
TRIGger:SBSW:I2C:IOPerator.....	1401
TRIGger:SBSW:I2C:RST.....	1397
TRIGger:SBSW:I3C:BIT.....	1421
TRIGger:SBSW:I3C:CHKall.....	1420
TRIGger:SBSW:I3C:CLR.....	1420
TRIGger:SBSW:I3C:DMAX.....	1422
TRIGger:SBSW:I3C:DMIN.....	1422
TRIGger:SBSW:I3C:DOPerator.....	1422
TRIGger:SBSW:I3C:ERENable.....	1424
TRIGger:SBSW:I3C:ERRor<m>:ENABLE.....	1424
TRIGger:SBSW:I3C:FIENable.....	1423
TRIGger:SBSW:I3C:FRAMe<fr>:ENABLE.....	1421
TRIGger:SBSW:I3C:FRAMe<fr>:FLD<fl>:BIT.....	1421
TRIGger:SBSW:I3C:FRAMe<fr>:FLD<fl>:DMAX.....	1422
TRIGger:SBSW:I3C:FRAMe<fr>:FLD<fl>:DMIN.....	1422
TRIGger:SBSW:I3C:FRAMe<fr>:FLD<fl>:DOPerator.....	1422
TRIGger:SBSW:I3C:FRAMe<fr>:FLD<fl>:ENABLE.....	1423
TRIGger:SBSW:I3C:FRAMe<fr>:FLD<fl>:IMAX.....	1423
TRIGger:SBSW:I3C:FRAMe<fr>:FLD<fl>:IMIN.....	1424
TRIGger:SBSW:I3C:FRAMe<fr>:FLD<fl>:IOPerator.....	1424
TRIGger:SBSW:I3C:FRENable.....	1421
TRIGger:SBSW:I3C:IMAX.....	1423
TRIGger:SBSW:I3C:IMIN.....	1424
TRIGger:SBSW:I3C:INVert.....	1420
TRIGger:SBSW:I3C:IOPerator.....	1424
TRIGger:SBSW:I3C:RST.....	1421
TRIGger:SBSW:LIN:BIT.....	1591
TRIGger:SBSW:LIN:CHKall.....	1590

TRIGger:SBSW:LIN:CLR.....	1590
TRIGger:SBSW:LIN:DMAX.....	1591
TRIGger:SBSW:LIN:DMIN.....	1592
TRIGger:SBSW:LIN:DOPerator.....	1592
TRIGger:SBSW:LIN:ERENable.....	1594
TRIGger:SBSW:LIN:ERRor<m>:ENABLE.....	1594
TRIGger:SBSW:LIN:FIENable.....	1592
TRIGger:SBSW:LIN:FRAME<fr>:ENABLE.....	1591
TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:BIT.....	1591
TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:DMAX.....	1591
TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:DMIN.....	1592
TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:DOPerator.....	1592
TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:ENABLE.....	1592
TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:IMAX.....	1593
TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:IMIN.....	1593
TRIGger:SBSW:LIN:FRAME<fr>:FLD<fl>:IOPerator.....	1594
TRIGger:SBSW:LIN:FRENable.....	1591
TRIGger:SBSW:LIN:IMAX.....	1593
TRIGger:SBSW:LIN:IMIN.....	1593
TRIGger:SBSW:LIN:INVert.....	1590
TRIGger:SBSW:LIN:IOPerator.....	1594
TRIGger:SBSW:LIN:RST.....	1590
TRIGger:SBSW:MANCh:BIT.....	1529
TRIGger:SBSW:MANCh:CHKall.....	1528
TRIGger:SBSW:MANCh:CLR.....	1528
TRIGger:SBSW:MANCh:DMAX.....	1530
TRIGger:SBSW:MANCh:DMIN.....	1530
TRIGger:SBSW:MANCh:DOPerator.....	1530
TRIGger:SBSW:MANCh:ERENable.....	1532
TRIGger:SBSW:MANCh:ERRor<m>:ENABLE.....	1532
TRIGger:SBSW:MANCh:FIENable.....	1531
TRIGger:SBSW:MANCh:FRAME<fr>:ENABLE.....	1529
TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:BIT.....	1529
TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:DMAX.....	1530
TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:DMIN.....	1530
TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:DOPerator.....	1530
TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:ENABLE.....	1531
TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:IMAX.....	1531
TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:IMIN.....	1532
TRIGger:SBSW:MANCh:FRAME<fr>:FLD<fl>:IOPerator.....	1532
TRIGger:SBSW:MANCh:FRENable.....	1529
TRIGger:SBSW:MANCh:IMAX.....	1531
TRIGger:SBSW:MANCh:IMIN.....	1532
TRIGger:SBSW:MANCh:INVert.....	1528
TRIGger:SBSW:MANCh:IOPerator.....	1532
TRIGger:SBSW:MANCh:RST.....	1529
TRIGger:SBSW:MILStd:BIT.....	1655
TRIGger:SBSW:MILStd:CHKall.....	1654
TRIGger:SBSW:MILStd:CLR.....	1654
TRIGger:SBSW:MILStd:DMAX.....	1656

TRIGger:SBSW:MILStd:DMIN.....	1656
TRIGger:SBSW:MILStd:DOPerator.....	1656
TRIGger:SBSW:MILStd:ERENable.....	1658
TRIGger:SBSW:MILStd:ERRor<m>:ENABle.....	1658
TRIGger:SBSW:MILStd:FIENable.....	1657
TRIGger:SBSW:MILStd:FRAMe<fr>:ENABle.....	1655
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:BIT.....	1655
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:DMAX.....	1656
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:DMIN.....	1656
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:DOPerator.....	1656
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:ENABle.....	1657
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:IMAX.....	1657
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:IMIN.....	1658
TRIGger:SBSW:MILStd:FRAMe<fr>:FLD<fl>:IOPerator.....	1658
TRIGger:SBSW:MILStd:FRENable.....	1655
TRIGger:SBSW:MILStd:IMAX.....	1657
TRIGger:SBSW:MILStd:IMIN.....	1658
TRIGger:SBSW:MILStd:INVert.....	1655
TRIGger:SBSW:MILStd:IOPerator.....	1658
TRIGger:SBSW:MILStd:RST.....	1655
TRIGger:SBSW:NRZC:BIT.....	1475
TRIGger:SBSW:NRZC:CHKall.....	1474
TRIGger:SBSW:NRZC:CLR.....	1474
TRIGger:SBSW:NRZC:DMAX.....	1475
TRIGger:SBSW:NRZC:DMIN.....	1475
TRIGger:SBSW:NRZC:DOPerator.....	1476
TRIGger:SBSW:NRZC:ERENable.....	1478
TRIGger:SBSW:NRZC:ERRor<m>:ENABle.....	1478
TRIGger:SBSW:NRZC:FIENable.....	1476
TRIGger:SBSW:NRZC:FRAMe<fr>:ENABle.....	1474
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:BIT.....	1475
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:DMAX.....	1475
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:DMIN.....	1475
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:DOPerator.....	1476
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:ENABle.....	1476
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:IMAX.....	1476
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:IMIN.....	1477
TRIGger:SBSW:NRZC:FRAMe<fr>:FLD<fl>:IOPerator.....	1477
TRIGger:SBSW:NRZC:FRENable.....	1474
TRIGger:SBSW:NRZC:IMAX.....	1476
TRIGger:SBSW:NRZC:IMIN.....	1477
TRIGger:SBSW:NRZC:INVert.....	1474
TRIGger:SBSW:NRZC:IOPerator.....	1477
TRIGger:SBSW:NRZC:RST.....	1474
TRIGger:SBSW:NRZU:BIT.....	1501
TRIGger:SBSW:NRZU:CHKall.....	1500
TRIGger:SBSW:NRZU:CLR.....	1501
TRIGger:SBSW:NRZU:DMAX.....	1502
TRIGger:SBSW:NRZU:DMIN.....	1502
TRIGger:SBSW:NRZU:DOPerator.....	1503

TRIGger:SBSW:NRZU:ERENable.....	1504
TRIGger:SBSW:NRZU:ERRor<m>:ENABLE.....	1504
TRIGger:SBSW:NRZU:FIENable.....	1503
TRIGger:SBSW:NRZU:FRAMe<fr>:ENABLE.....	1501
TRIGger:SBSW:NRZU:FRAMe<fr>:FLD<fl>:BIT.....	1501
TRIGger:SBSW:NRZU:FRAMe<fr>:FLD<fl>:DMAX.....	1502
TRIGger:SBSW:NRZU:FRAMe<fr>:FLD<fl>:DMIN.....	1502
TRIGger:SBSW:NRZU:FRAMe<fr>:FLD<fl>:DOPerator.....	1503
TRIGger:SBSW:NRZU:FRAMe<fr>:FLD<fl>:ENABLE.....	1503
TRIGger:SBSW:NRZU:FRAMe<fr>:FLD<fl>:IMAX.....	1503
TRIGger:SBSW:NRZU:FRAMe<fr>:FLD<fl>:IMIN.....	1504
TRIGger:SBSW:NRZU:FRAMe<fr>:FLD<fl>:IOPerator.....	1504
TRIGger:SBSW:NRZU:FRENable.....	1501
TRIGger:SBSW:NRZU:IMAX.....	1503
TRIGger:SBSW:NRZU:IMIN.....	1504
TRIGger:SBSW:NRZU:INVert.....	1501
TRIGger:SBSW:NRZU:IOPerator.....	1504
TRIGger:SBSW:NRZU:RST.....	1501
TRIGger:SBSW:QSPI:BIT.....	1374
TRIGger:SBSW:QSPI:CHKall.....	1373
TRIGger:SBSW:QSPI:CLR.....	1373
TRIGger:SBSW:QSPI:DMAX.....	1374
TRIGger:SBSW:QSPI:DMIN.....	1375
TRIGger:SBSW:QSPI:DOPerator.....	1375
TRIGger:SBSW:QSPI:ERENable.....	1377
TRIGger:SBSW:QSPI:ERRor<m>:ENABLE.....	1377
TRIGger:SBSW:QSPI:FIENable.....	1376
TRIGger:SBSW:QSPI:FRAMe<fr>:ENABLE.....	1374
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:BIT.....	1374
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:DMAX.....	1374
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:DMIN.....	1375
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:DOPerator.....	1375
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:ENABLE.....	1376
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:IMAX.....	1376
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:IMIN.....	1376
TRIGger:SBSW:QSPI:FRAMe<fr>:FLD<fl>:IOPerator.....	1377
TRIGger:SBSW:QSPI:FRENable.....	1374
TRIGger:SBSW:QSPI:IMAX.....	1376
TRIGger:SBSW:QSPI:IMIN.....	1376
TRIGger:SBSW:QSPI:INVert.....	1373
TRIGger:SBSW:QSPI:IOPerator.....	1377
TRIGger:SBSW:QSPI:RST.....	1374
TRIGger:SBSW:RFFE:BIT.....	1714
TRIGger:SBSW:RFFE:CHKall.....	1713
TRIGger:SBSW:RFFE:CLR.....	1713
TRIGger:SBSW:RFFE:DMAX.....	1715
TRIGger:SBSW:RFFE:DMIN.....	1715
TRIGger:SBSW:RFFE:DOPerator.....	1715
TRIGger:SBSW:RFFE:ERENable.....	1717
TRIGger:SBSW:RFFE:ERRor<m>:ENABLE.....	1717

TRIGger:SBSW:RFFE:FIENable.....	1716
TRIGger:SBSW:RFFE:FRAMe<fr>:ENABle.....	1714
TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:BIT.....	1714
TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:DMAX.....	1715
TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:DMIN.....	1715
TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:DOPerator.....	1715
TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:ENABle.....	1716
TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:IMAX.....	1716
TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:IMIN.....	1717
TRIGger:SBSW:RFFE:FRAMe<fr>:FLD<fl>:IOPerator.....	1717
TRIGger:SBSW:RFFE:FRENable.....	1714
TRIGger:SBSW:RFFE:IMAX.....	1716
TRIGger:SBSW:RFFE:IMIN.....	1717
TRIGger:SBSW:RFFE:INVert.....	1713
TRIGger:SBSW:RFFE:IOPerator.....	1717
TRIGger:SBSW:RFFE:RST.....	1714
TRIGger:SBSW:SENT:BIT.....	1615
TRIGger:SBSW:SENT:CHKall.....	1614
TRIGger:SBSW:SENT:CLR.....	1614
TRIGger:SBSW:SENT:DMAX.....	1615
TRIGger:SBSW:SENT:DMIN.....	1616
TRIGger:SBSW:SENT:DOPerator.....	1616
TRIGger:SBSW:SENT:ERENable.....	1618
TRIGger:SBSW:SENT:ERRor<m>:ENABle.....	1618
TRIGger:SBSW:SENT:FIENable.....	1615
TRIGger:SBSW:SENT:FRAMe<fr>:ENABle.....	1614
TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:BIT.....	1615
TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:DMAX.....	1615
TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:DMIN.....	1616
TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:DOPerator.....	1616
TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:ENABle.....	1615
TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:IMAX.....	1617
TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:IMIN.....	1617
TRIGger:SBSW:SENT:FRAMe<fr>:FLD<fl>:IOPerator.....	1617
TRIGger:SBSW:SENT:FRENable.....	1614
TRIGger:SBSW:SENT:IMAX.....	1617
TRIGger:SBSW:SENT:IMIN.....	1617
TRIGger:SBSW:SENT:INVert.....	1614
TRIGger:SBSW:SENT:IOPerator.....	1617
TRIGger:SBSW:SENT:RST.....	1614
TRIGger:SBSW:SPI:BIT.....	1343
TRIGger:SBSW:SPI:CHKall.....	1342
TRIGger:SBSW:SPI:CLR.....	1342
TRIGger:SBSW:SPI:DMAX.....	1343
TRIGger:SBSW:SPI:DMIN.....	1344
TRIGger:SBSW:SPI:DOPerator.....	1344
TRIGger:SBSW:SPI:ERENable.....	1346
TRIGger:SBSW:SPI:ERRor<m>:ENABle.....	1346
TRIGger:SBSW:SPI:FIENable.....	1345
TRIGger:SBSW:SPI:FRAMe<fr>:ENABle.....	1343

TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:BIT.....	1343
TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:DMAX.....	1343
TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:DMIN.....	1344
TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:DOPerator.....	1344
TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:ENABle.....	1345
TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:IMAX.....	1345
TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:IMIN.....	1345
TRIGger:SBSW:SPI:FRAME<fr>:FLD<fl>:IOPerator.....	1346
TRIGger:SBSW:SPI:FRENable.....	1343
TRIGger:SBSW:SPI:IMAX.....	1345
TRIGger:SBSW:SPI:IMIN.....	1345
TRIGger:SBSW:SPI:INVert.....	1342
TRIGger:SBSW:SPI:IOPerator.....	1346
TRIGger:SBSW:SPI:RST.....	1343
TRIGger:SBSW:SPMI:BIT.....	1693
TRIGger:SBSW:SPMI:CHKall.....	1692
TRIGger:SBSW:SPMI:CLR.....	1692
TRIGger:SBSW:SPMI:DMAX.....	1694
TRIGger:SBSW:SPMI:DMIN.....	1694
TRIGger:SBSW:SPMI:DOPerator.....	1694
TRIGger:SBSW:SPMI:ERENable.....	1696
TRIGger:SBSW:SPMI:ERRor<m>:ENABle.....	1696
TRIGger:SBSW:SPMI:FIENable.....	1695
TRIGger:SBSW:SPMI:FRAME<fr>:ENABle.....	1693
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:BIT.....	1693
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:DMAX.....	1694
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:DMIN.....	1694
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:DOPerator.....	1694
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:ENABle.....	1695
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:IMAX.....	1695
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:IMIN.....	1696
TRIGger:SBSW:SPMI:FRAME<fr>:FLD<fl>:IOPerator.....	1696
TRIGger:SBSW:SPMI:FRENable.....	1693
TRIGger:SBSW:SPMI:IMAX.....	1695
TRIGger:SBSW:SPMI:IMIN.....	1696
TRIGger:SBSW:SPMI:INVert.....	1692
TRIGger:SBSW:SPMI:IOPerator.....	1696
TRIGger:SBSW:SPMI:RST.....	1693
TRIGger:SBSW:SWIRe:BIT.....	1672
TRIGger:SBSW:SWIRe:CHKall.....	1671
TRIGger:SBSW:SWIRe:CLR.....	1671
TRIGger:SBSW:SWIRe:DMAX.....	1672
TRIGger:SBSW:SWIRe:DMIN.....	1673
TRIGger:SBSW:SWIRe:DOPerator.....	1673
TRIGger:SBSW:SWIRe:ERENable.....	1674
TRIGger:SBSW:SWIRe:ERRor<m>:ENABle.....	1674
TRIGger:SBSW:SWIRe:FIENable.....	1673
TRIGger:SBSW:SWIRe:FRAME<fr>:ENABle.....	1672
TRIGger:SBSW:SWIRe:FRAME<fr>:FLD<fl>:BIT.....	1672
TRIGger:SBSW:SWIRe:FRAME<fr>:FLD<fl>:DMAX.....	1672

TRIGger:SBSW:SWIRe:FRAMe<fr>:FLD<fl>:DMIN.....	1673
TRIGger:SBSW:SWIRe:FRAMe<fr>:FLD<fl>:DOPerator.....	1673
TRIGger:SBSW:SWIRe:FRAMe<fr>:FLD<fl>:ENABle.....	1673
TRIGger:SBSW:SWIRe:FRENable.....	1672
TRIGger:SBSW:SWIRe:INVert.....	1671
TRIGger:SBSW:SWIRe:RST.....	1671
TRIGger:SBSW:TBTO:BIT.....	1780
TRIGger:SBSW:TBTO:CHKall.....	1779
TRIGger:SBSW:TBTO:CLR.....	1779
TRIGger:SBSW:TBTO:DMAX.....	1780
TRIGger:SBSW:TBTO:DMIN.....	1780
TRIGger:SBSW:TBTO:DOPerator.....	1781
TRIGger:SBSW:TBTO:ERENable.....	1783
TRIGger:SBSW:TBTO:ERRor<m>:ENABle.....	1783
TRIGger:SBSW:TBTO:FIENable.....	1781
TRIGger:SBSW:TBTO:FRAMe<fr>:ENABle.....	1779
TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:BIT.....	1780
TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:DMAX.....	1780
TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:DMIN.....	1780
TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:DOPerator.....	1781
TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:ENABle.....	1781
TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:IMAX.....	1782
TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:IMIN.....	1782
TRIGger:SBSW:TBTO:FRAMe<fr>:FLD<fl>:IOPerator.....	1782
TRIGger:SBSW:TBTO:FRENable.....	1779
TRIGger:SBSW:TBTO:IMAX.....	1782
TRIGger:SBSW:TBTO:IMIN.....	1782
TRIGger:SBSW:TBTO:INVert.....	1779
TRIGger:SBSW:TBTO:IOPerator.....	1782
TRIGger:SBSW:TBTO:RST.....	1779
TRIGger:SBSW:TNOS:BIT.....	1736
TRIGger:SBSW:TNOS:CHKall.....	1735
TRIGger:SBSW:TNOS:CLR.....	1735
TRIGger:SBSW:TNOS:DMAX.....	1737
TRIGger:SBSW:TNOS:DMIN.....	1737
TRIGger:SBSW:TNOS:DOPerator.....	1737
TRIGger:SBSW:TNOS:ERENable.....	1739
TRIGger:SBSW:TNOS:ERRor<m>:ENABle.....	1739
TRIGger:SBSW:TNOS:FIENable.....	1738
TRIGger:SBSW:TNOS:FRAMe<fr>:ENABle.....	1736
TRIGger:SBSW:TNOS:FRAMe<fr>:FLD<fl>:BIT.....	1736
TRIGger:SBSW:TNOS:FRAMe<fr>:FLD<fl>:DMAX.....	1737
TRIGger:SBSW:TNOS:FRAMe<fr>:FLD<fl>:DMIN.....	1737
TRIGger:SBSW:TNOS:FRAMe<fr>:FLD<fl>:DOPerator.....	1737
TRIGger:SBSW:TNOS:FRAMe<fr>:FLD<fl>:ENABle.....	1738
TRIGger:SBSW:TNOS:FRAMe<fr>:FLD<fl>:IMAX.....	1738
TRIGger:SBSW:TNOS:FRAMe<fr>:FLD<fl>:IMIN.....	1739
TRIGger:SBSW:TNOS:FRAMe<fr>:FLD<fl>:IOPerator.....	1739
TRIGger:SBSW:TNOS:FRENable.....	1736
TRIGger:SBSW:TNOS:IMAX.....	1738

TRIGger:SBSW:TNOS:IMIN.....	1739
TRIGger:SBSW:TNOS:INVert.....	1735
TRIGger:SBSW:TNOS:IOPerator.....	1739
TRIGger:SBSW:TNOS:RST.....	1736
TRIGger:SBSW:UART:BIT.....	1449
TRIGger:SBSW:UART:CHKall.....	1448
TRIGger:SBSW:UART:CLR.....	1448
TRIGger:SBSW:UART:DMAX.....	1449
TRIGger:SBSW:UART:DMIN.....	1450
TRIGger:SBSW:UART:DOPerator.....	1450
TRIGger:SBSW:UART:ERENable.....	1452
TRIGger:SBSW:UART:ERRor<m>:ENABle.....	1452
TRIGger:SBSW:UART:FIENable.....	1450
TRIGger:SBSW:UART:FRAMe<fr>:ENABle.....	1449
TRIGger:SBSW:UART:FRAMe<fr>:FLD<fl>:BIT.....	1449
TRIGger:SBSW:UART:FRAMe<fr>:FLD<fl>:DMAX.....	1449
TRIGger:SBSW:UART:FRAMe<fr>:FLD<fl>:DMIN.....	1450
TRIGger:SBSW:UART:FRAMe<fr>:FLD<fl>:DOPerator.....	1450
TRIGger:SBSW:UART:FRAMe<fr>:FLD<fl>:ENABle.....	1450
TRIGger:SBSW:UART:FRAMe<fr>:FLD<fl>:IMAX.....	1451
TRIGger:SBSW:UART:FRAMe<fr>:FLD<fl>:IMIN.....	1451
TRIGger:SBSW:UART:FRAMe<fr>:FLD<fl>:IOPerator.....	1452
TRIGger:SBSW:UART:FRENable.....	1449
TRIGger:SBSW:UART:IMAX.....	1451
TRIGger:SBSW:UART:IMIN.....	1451
TRIGger:SBSW:UART:INVert.....	1448
TRIGger:SBSW:UART:IOPerator.....	1452
TRIGger:SBSW:UART:RST.....	1448
TRIGger:SBSW:USBHspeed:BIT.....	1823
TRIGger:SBSW:USBHspeed:CHKall.....	1822
TRIGger:SBSW:USBHspeed:CLR.....	1822
TRIGger:SBSW:USBHspeed:DMAX.....	1823
TRIGger:SBSW:USBHspeed:DMIN.....	1824
TRIGger:SBSW:USBHspeed:DOPerator.....	1824
TRIGger:SBSW:USBHspeed:ERENable.....	1826
TRIGger:SBSW:USBHspeed:ERRor<m>:ENABle.....	1826
TRIGger:SBSW:USBHspeed:FIENable.....	1824
TRIGger:SBSW:USBHspeed:FRAMe<fr>:ENABle.....	1823
TRIGger:SBSW:USBHspeed:FRAMe<fr>:FLD<fl>:BIT.....	1823
TRIGger:SBSW:USBHspeed:FRAMe<fr>:FLD<fl>:DMAX.....	1823
TRIGger:SBSW:USBHspeed:FRAMe<fr>:FLD<fl>:DMIN.....	1824
TRIGger:SBSW:USBHspeed:FRAMe<fr>:FLD<fl>:DOPerator.....	1824
TRIGger:SBSW:USBHspeed:FRAMe<fr>:FLD<fl>:ENABle.....	1824
TRIGger:SBSW:USBHspeed:FRAMe<fr>:FLD<fl>:IMAX.....	1825
TRIGger:SBSW:USBHspeed:FRAMe<fr>:FLD<fl>:IMIN.....	1825
TRIGger:SBSW:USBHspeed:FRAMe<fr>:FLD<fl>:IOPerator.....	1826
TRIGger:SBSW:USBHspeed:FRENable.....	1823
TRIGger:SBSW:USBHspeed:IMAX.....	1825
TRIGger:SBSW:USBHspeed:IMIN.....	1825
TRIGger:SBSW:USBHspeed:INVert.....	1822

TRIGger:SBSW:USBHspeed:IOperator.....	1826
TRIGger:SBSW:USBHspeed:RST.....	1822
TRIGger:SBSW:USBone:BIT.....	1802
TRIGger:SBSW:USBone:CHKall.....	1801
TRIGger:SBSW:USBone:CLR.....	1801
TRIGger:SBSW:USBone:DMAX.....	1803
TRIGger:SBSW:USBone:DMIN.....	1803
TRIGger:SBSW:USBone:DOPerator.....	1803
TRIGger:SBSW:USBone:ERENable.....	1805
TRIGger:SBSW:USBone:ERRor<m>:ENABLE.....	1805
TRIGger:SBSW:USBone:FIENable.....	1804
TRIGger:SBSW:USBone:FRAMe<fr>:ENABLE.....	1802
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:BIT.....	1802
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:DMAX.....	1803
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:DMIN.....	1803
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:DOPerator.....	1803
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:ENABLE.....	1804
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:IMAX.....	1804
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:IMIN.....	1805
TRIGger:SBSW:USBone:FRAMe<fr>:FLD<fl>:IOperator.....	1805
TRIGger:SBSW:USBone:FRENable.....	1802
TRIGger:SBSW:USBone:IMAX.....	1804
TRIGger:SBSW:USBone:IMIN.....	1805
TRIGger:SBSW:USBone:INVert.....	1801
TRIGger:SBSW:USBone:IOperator.....	1805
TRIGger:SBSW:USBone:RST.....	1802
TRIGger:ZONE:EXPRession[:DEFine].....	1042
TRIGger:ZONE:HISTory.....	1047
TRPRobe:SETup:ATTenuation:UNIT?.....	1001
TRPRobe:SETup:ATTenuation[:AUTO]?.....	1001
TRPRobe:SETup:NAME?.....	1001
TRPRobe:SETup:STATe?.....	1001
TRPRobe:SETup:TYPE?.....	1002
USERdefined:PRESet:NAME.....	959
USERdefined:PRESet:OPEN.....	959
USERdefined:PRESet:SAVE.....	959
USERdefined:PRESet[:ENABLE].....	960
WGENerator<wg>:ARBGen:NAME.....	1866
WGENerator<wg>:ARBGen:OPEN.....	1866
WGENerator<wg>:ARBGen:RUNMode.....	1866
WGENerator<wg>:ARBGen:RUNSingle.....	1867
WGENerator<wg>:ARBGen:SAMPles?.....	1867
WGENerator<wg>:ARBGen:SRATe.....	1867
WGENerator<wg>:ARBGen[:SOURce].....	1868
WGENerator<wg>:COUPling:ALL.....	1870
WGENerator<wg>:COUPling:AMPLitude.....	1870
WGENerator<wg>:COUPling:PHASeshift.....	1871
WGENerator<wg>:COUPling:STATe.....	1870
WGENerator<wg>:COUPling[:FREQuency].....	1871
WGENerator<wg>:FREQuency.....	1853

WGENerator<wg>:FUNCTION:PULSe[:WIDTh].....	1853
WGENerator<wg>:FUNCTION:RAMP[:SYMMetry].....	1853
WGENerator<wg>:FUNCTION[:SElect].....	1854
WGENerator<wg>:FUNCTION[:SQUare]:DCYCLE.....	1854
WGENerator<wg>:GOVerload:STATus:CONDition?.....	1880
WGENerator<wg>:GOVerload:STATus:ENABle.....	1881
WGENerator<wg>:GOVerload:STATus:NTRansition.....	1882
WGENerator<wg>:GOVerload:STATus:PTRansition.....	1883
WGENerator<wg>:GOVerload:STATus[:EVENT].....	1881
WGENerator<wg>:MODulation:AM:DCYCLE.....	1859
WGENerator<wg>:MODulation:AM:DEPTh.....	1859
WGENerator<wg>:MODulation:AM:FREQuency.....	1859
WGENerator<wg>:MODulation:AM:SYMMetry.....	1860
WGENerator<wg>:MODulation:AM[:FUNCTION].....	1860
WGENerator<wg>:MODulation:CARRier:FREQuency.....	1860
WGENerator<wg>:MODulation:CARRier:PERiod.....	1860
WGENerator<wg>:MODulation:FM:DCYCLE.....	1861
WGENerator<wg>:MODulation:FM:DEVIation.....	1861
WGENerator<wg>:MODulation:FM:FREQuency.....	1861
WGENerator<wg>:MODulation:FM:SYMMetry.....	1862
WGENerator<wg>:MODulation:FM[:FUNCTION].....	1862
WGENerator<wg>:MODulation:FSK:FONE.....	1862
WGENerator<wg>:MODulation:FSK:FTWO.....	1862
WGENerator<wg>:MODulation:FSK[:RATE].....	1863
WGENerator<wg>:MODulation:NDCLevel.....	1863
WGENerator<wg>:MODulation:NLPCent.....	1863
WGENerator<wg>:MODulation:PWM:DCYCLE.....	1864
WGENerator<wg>:MODulation:PWM:DEPTh.....	1864
WGENerator<wg>:MODulation:PWM:FREQuency.....	1864
WGENerator<wg>:MODulation:PWM:SYMMetry.....	1865
WGENerator<wg>:MODulation:PWM[:FUNCTION].....	1865
WGENerator<wg>:MODulation:TYPE.....	1865
WGENerator<wg>:MODulation[:STATe].....	1858
WGENerator<wg>:OUTPut[:LOAD].....	1854
WGENerator<wg>:PERiod.....	1855
WGENerator<wg>:PRESet.....	1855
WGENerator<wg>:SOURce.....	1855
WGENerator<wg>:SWEep:FEND.....	1869
WGENerator<wg>:SWEep:FSTart.....	1869
WGENerator<wg>:SWEep:TIME.....	1869
WGENerator<wg>:SWEep:TYPE.....	1868
WGENerator<wg>:SWEep[:STATe].....	1868
WGENerator<wg>:TEMPerature:STATus:CONDition?.....	1880
WGENerator<wg>:TEMPerature:STATus:ENABle.....	1882
WGENerator<wg>:TEMPerature:STATus:NTRansition.....	1882
WGENerator<wg>:TEMPerature:STATus:PTRansition.....	1883
WGENerator<wg>:TEMPerature:STATus[:EVENT].....	1881
WGENerator<wg>:VOLTage:DCLevel.....	1856
WGENerator<wg>:VOLTage:HIGH.....	1856
WGENerator<wg>:VOLTage:INVersion.....	1856

WGENerator<wg>:VOLTage:LOW.....	1857
WGENerator<wg>:VOLTage:OFFSet.....	1857
WGENerator<wg>:VOLTage[:VPP].....	1857
WGENerator<wg>[:ENABle].....	1858
XY<m>:SWAP.....	1313
XY<m>:XSOurce.....	1314
XY<m>:YSOurce.....	1314
XY<m>[:STATe].....	1314
ZONE<m>:ACOMbination.....	1042
ZONE<m>:ADD.....	1041
ZONE<m>:AREA<n>:ADD.....	1042
ZONE<m>:AREA<n>:COUNT?.....	1042
ZONE<m>:AREA<n>:INTersect.....	1043
ZONE<m>:AREA<n>:LABel.....	1043
ZONE<m>:AREA<n>:POINT<o>:ADD.....	1044
ZONE<m>:AREA<n>:POINT<o>:COUNT?.....	1044
ZONE<m>:AREA<n>:POINT<o>:REMove.....	1044
ZONE<m>:AREA<n>:POINT<o>:VALid?.....	1045
ZONE<m>:AREA<n>:POINT<o>:X.....	1045
ZONE<m>:AREA<n>:POINT<o>:Y.....	1045
ZONE<m>:AREA<n>:REMove.....	1046
ZONE<m>:AREA<n>:STATe.....	1046
ZONE<m>:AREA<n>:VALid?.....	1043
ZONE<m>:COUNT?.....	1046
ZONE<m>:DIAGram.....	1046
ZONE<m>:REMove.....	1047
ZONE<m>:SOURce.....	1047
ZONE<m>[:VISible].....	1047