Tektronix[®]



Power Analysis Application

3-PWR Datasheet

File	Utility	Help	ł	4	1	I					Tekr	ronix
Measure	Name	Meas	Source(s)	Value	Min	Мах	Mean	Std Dev	Population		Search	Results
Bus 1	Power	Frequency	88.21	60.06 Hz	59.88 Hz	60.20 Hz	60.02 Hz	53.93 mHz	230			
Bus 2	Power	V RMS	III. III	14.09 V	14.06 V	14.12 V	14.09 V	6.042 mV	230		Power I	Quality 60.06 Hz
	Power	L RMS	(20.00)	378.5 mA	377.7 mA	381.1 mA	379.8 mA	563.8 µA	230		VRMS:	14.1 V 378 mA
Search	Power	V Crest Factor	88.60	1.306	1.304	1,321	1307	3.023 m	230		V CP:	1.31
Harmonics	Power	I Crest Factor	25.00	2.008	2.003	2.046	2.022	5.328 m	230		TrPwr:	4.21 W
	Power	True Power	IME. (11)	4.212 W	4.192 W	4.237 W	4.223 W	6.373 mW	230		ApPwr	5.33 VA
	Power	Reactive Power	11.	3.272 VAR	3.272 VAR	3.308 VAR	3.287 VAR	6.603 mVAR	230		Phase:	37.9 *
	Power	Apparent Power	11. (2)	5.333 VA	5.317 VA	5.373 VA	5.351 VA	8.205 mVA	230			
	Power	Power Factor		789.6 m	787.9 m	789.8 m	789.1 m	478.9 µ	230			
	Power	Phase Angle	111.020	37.85 *	37.84 *	38.01 *	37.90 *	44.66 m*	230			
	AU	AVA			JA.				A			
Ch1 C 5.00 V/div 2 50 Ω 1 100 MHz 1	100 mA/div M Ω 00 MHz	dath 5.00 W/div Ch 1 * Ch 2				D15 Mati -D0 Ref Bus	DVM AFG	Horizontal 20.0 ms/div SR:50.0 kS/s RL:10 kots	Trisser II A	cquisition ample 465 kAcqs	RF 9	May 201

Key performance specifications

- Power Loss measurements at the switching device for improving switching power supply efficiency
- Automated Ripple measurement setup eliminates manual processes
- Automated THD, True Power, Apparent Power, Power Factor, and Crest Factor features eliminate tedious manual calculations

Key features

- Customizable safe operating area mask testing with linear and log scale for reliability testing
- Precompliance testing to the EN61000-3-2 Class A and MIL Standard 1399 Section 300A Standards reduces compliance test time and risk
- Modulation analysis quickly provides accurate active power factor characterization
- Deskew wizard ensures accurate, time-correlated results
- Correct scale factor and unit display while using third-party current probes eliminates manual calculations and human error

Applications

- Power loss measurement at switching device
- Characterization of power semiconductor devices
- Optimal drive characterization of synchronous rectifiers
- Measurement and analysis of ripple and noise
- Precompliance testing to IEC standard EN61000 3-2 Class A, MIL Standard 1399 Section 300A, and up to 400 harmonics
- · Debugging active power factor correction circuits

3-PWR

With the 3-PWR Power Analysis Application installed on an 3 Series MDO, an embedded designer who rarely deals with power measurements can quickly get the same accurate, repeatable results as a power supply expert. By simply adding a software license to the 3 series MDO, along with differential voltage and current probes, it forms a complete measurement system for power supply design and test.

The Power Analysis application provides a number of specific measurements to characterize power supplies: Switching Component Analysis, Input Analysis, and Output Analysis.

Switching component analysis

The accurate calculation and evaluation of energy loss in power supplies has become even more critical with the drive to higher power conversion efficiency and greater reliability.

Switching loss measurements

Although almost all components of a power supply contribute to energy losses, the majority of energy losses in a switch-mode power supply (SMPS) occur when the switching transistor transitions from an OFF to an ON state (turn-on loss) and vice versa (turn-off loss). By measuring the voltage drop across the switching device and the current flowing through the switching device, the Power Analysis application measures the switching losses as shown in the following figure.



Switching loss measurements

Safe operating area

The Safe Operating Area (SOA) plot is a graphical technique for evaluating a switching device to ensure that it is not being stressed beyond its maximum specifications. SOA testing can be used to validate performance over a range of operating conditions, including load variations, temperature changes, and variations in input voltages. Limit testing can also be used with SOA plots to automate the validation. An example of an SOA plot is shown in the following figure.



Safe operating area (SOA) display

Input analysis

Power quality measurements and current harmonics are two common sets of measurements made on the input section of a power supply to analyze the effects of the power supply on the power line.

Power quality

Power quality refers to a power supply's ability to function properly with the electric power that is supplied to it. These measurements help to understand the effects of distortions caused by nonlinear loads, including the power supply itself. The measurements include RMS voltage and current, true and apparent power, crest factor, line frequency, and power factor, as shown in the following figure.



Power quality measurements

Current harmonics

Because a switching power supply presents a nonlinear load to the power line, the input voltage and current waveforms are not identical. Current is drawn for some portion of the input cycle, causing the generation of harmonics on the input current waveform. Excessive harmonic energy can affect the operation of other equipment connected to the power line, as well as increase the cost of delivering the electric power. Therefore, power supply designers can use the current harmonics measurements to assure precompliance of their designs to industry standards (such as IEC61000-3-2 Class A and MIL Standard 1399 Section 300A) before investing in the official compliance testing.



Current harmonics measurements

2

Output analysis

The ultimate goal of a DC-output power supply is to transform input power into one or more DC-output voltages. Especially for switching power supplies, the output measurements are essential. These measurements include line ripple, switching ripple, and modulation analysis.

Line and switching ripple

The quality of a power supply's DC output should be clean with minimal noise and ripple. Ripple measures the amount of AC-output signal.

The automated ripple measurement offers a special autoset function that allows you to specify a DC offset, and optimizes the vertical scale for the best results. The horizontal scale is not affected by the autoset, so you can adjust the horizontal scale to look at line-frequency ripple or higherfrequency switching ripple.



Output ripple measurements

Modulation analysis

Modulation is important in a feedback system to control the loop. However, too much modulation can cause the loop to become unstable. The Power Analysis application calculates and shows the trend in the on-time and off-time information of a modulated signal controlling the output control loop on a power supply, as shown in the following figure.



Modulation analysis on a MOSFET's gate drive during power-up

The modulation analysis could also be used to measure the response of the power supply's control loop to change in input voltage ("line regulation") or change in load ("load regulation").

3

Specifications

All specifications are guaranteed unless noted otherwise. All specifications apply to all models unless noted otherwise.

Instrument compatibility

3-PWR

All models of 3 Series MDO

Measurements

Power quality measurements	V _{RMS} , V _{Crest Factor} , Frequency, I _{RMS} , I _{Crest Factor} , True Power, Apparent Power, Reactive Power, Power Factor, Phase Angle
Switching loss measurements	
Power loss	T _{On} , T _{Off} , Conduction, Total
Energy loss	T _{On} , T _{Off} , Conduction, Total
Harmonics	THD-F, THD-R, RMS measurements up to 400 harmonics
	Graphical and table displays of harmonics
	Test to IEC61000-3-2 Class A and MIL-STD-1399 Section 300 A
Ripple measurements	V_{Ripple} and I_{Ripple}
Modulation analysis	Graphical display of +Pulse Width, -Pulse Width, Period, Frequency, +Duty Cycle, and -Duty Cycle modulation types
Safe operating area	Graphical display and mask testing of switching device safe operating area measurements
dV/dt and dl/dt measurements	Cursor measurements of slew rate
eskew	
	Recommended deskew values automatically calculated based on propagation delay. Deskews can be set to recommended values

	or adjusted manually.
TekVPI and TekProbe II	Nominal propagation delay value automatically loaded
Built-in probe model list	Nominal propagation delay value provided when probe is selected
Other	Propagation delay can be manually entered



Mess- und Prüftechnik, Die Experten,

Ordering information

Module

3-PWR

Adds power measurement and analysis.

Recommended accessories

067-1686-xx	Deskew fixture
TEK-DPG	Deskew pulse generator

Typical recommended power probes

Voltage and current probes are required for most power measurements.

THDP0200	± 1.5 kV, 200 MHz TekVPI $^{\ensuremath{\textcircled{B}}}$ high-voltage differential probe
TCP0030A	30 A AC/DC TekVPI [®] current probe, 120 MHz BW